



# M Commands

---

This chapter describes the Cisco NX-OS quality of service (QoS) commands that begin with M.

# match access-group

To identify a specified access control list (ACL) group as a match criteria for a class map, use the **match access-group** command. To remove an ACL match criteria from a class map, use the **no** form of this command.

**match access-group name** *acl-name*

**no match access-group name** *acl-name*

## Syntax Description

**name** *acl-name* Matches on the characteristics in the ACL name specified.

## Command Default

None

## Command Modes

Class-map type qos configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines



### Note

The **permit** and **deny** ACL keywords do not affect the matching of packets.

## Examples

This example shows how to create a qos class map that matches characteristics of the ACL my\_acl:

```
switch(config)# class-map class_acl
switch(config-cmap-qos)# match access-group name my_acl
```

## Related Commands

| Command               | Description          |
|-----------------------|----------------------|
| <b>show class-map</b> | Displays class maps. |

# match cos

To define the class of traffic using the class of service (CoS) value in a type qos class map, use the **match cos** command. To remove the match on the CoS value, use the **no** form of this command.

**match** [**not**] **cos** *cos-list*

**no match** [**not**] **cos** *cos-list*

## Syntax Description

|                 |                                                                                    |
|-----------------|------------------------------------------------------------------------------------|
| <b>not</b>      | (Optional) Negates the specified match result.                                     |
| <i>cos-list</i> | Specified CoS value or list of specified CoS values. Valid values are from 0 to 7. |

## Command Default

None

## Command Modes

Class-map type qos configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

To specify a list of values, use one of the following options:

- Specify a range of values separated by a dash
- Specify a noncontiguous list of values separated by commas



### Note

Only class maps of type qos support the optional **not** keyword form of this command. Class maps of type queuing do not support the **not** keyword.

## Examples

This example shows how to match on the CoS value for a type qos class map:

```
switch(config)# class-map class_acl
switch(config-cmap-qos)# match cos 5-7
```

## Related Commands

| Command               | Description          |
|-----------------------|----------------------|
| <b>show class-map</b> | Displays class maps. |

# match dscp

To identify specific differentiated services code point (DSCP) values in the DiffServ field of the IP Header (either IPv4 or IPv6) as a match criteria, use the **match dscp** command. To remove specified DSCP values as a match criteria, use the **no** form of this command.

**match** [**not**] **dscp** *dscp-list*

**no match** [**not**] **dscp** *dscp-list*

## Syntax Description

|                  |                                                                                                           |
|------------------|-----------------------------------------------------------------------------------------------------------|
| <b>not</b>       | (Optional) Negates the specified match result.                                                            |
| <i>dscp-list</i> | Specified DSCP value or list of DSCP values. See <a href="#">Table 1</a> for a list of valid DSCP values. |

## Command Default

None

## Command Modes

Class-map type qos configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

The standard DSCP values are shown in [Table 1](#).

**Table 1**      **Standard DSCP Values**

| DSCP Value | Description                                      |
|------------|--------------------------------------------------|
| af11       | AF11 dscp (001010)—decimal value 10              |
| af12       | AF12 dscp (001100)—decimal value 12              |
| af13       | AF13 dscp (001110)—decimal value 14              |
| af21       | AF21 dscp (010010)—decimal value 18              |
| af22       | AF22 dscp (010100)—decimal value 20              |
| af23       | AF23 dscp (010110)—decimal value 22              |
| af31       | AF31 dscp (011010)—decimal value 26              |
| af32       | AF40 dscp (011100)—decimal value 28              |
| af33       | AF33 dscp (011110)—decimal value 30              |
| af41       | AF41 dscp (100010)—decimal value 34              |
| af42       | AF42 dscp (100100)—decimal value 36              |
| af43       | AF43 dscp (100110)—decimal value 38              |
| cs1        | CS1 (precedence 1) dscp (001000)—decimal value 8 |

**Table 1**      **Standard DSCP Values (continued)**

| DSCP Value | Description                                       |
|------------|---------------------------------------------------|
| cs2        | CS2 (precedence 2) dscp (010000)—decimal value 16 |
| cs3        | CS3 (precedence 3) dscp (011000)—decimal value 24 |
| cs4        | CS4 (precedence 4) dscp (100000)—decimal value 32 |
| cs5        | CS5 (precedence 5) dscp (101000)—decimal value 40 |
| cs6        | CS6 (precedence 6) dscp (110000)—decimal value 48 |
| cs7        | CS7 (precedence 7) dscp (111000)—decimal value 56 |
| default    | Default dscp (000000)—decimal value 0             |
| ef         | EF dscp (101110)—decimal value 46                 |

To specify a list of values, use one of the following options:

- Specify a range of values separated by a dash
- Specify a noncontiguous list of values separated by commas

### Examples

This example shows how to match on DSCP value af21:

```
switch(config)# class-map my_test
switch(config-cmap-qos)# match dscp af21
```

### Related Commands

| Command        | Description          |
|----------------|----------------------|
| show class-map | Displays class maps. |

# match ip rtp

To configure a class map to use the Real-Time Protocol (RTP) port as a match criteria, use the **match ip rtp** command. To remove the RTP port as a match criteria, use the **no** form of this command.

**match** [**not**] **ip rtp** *port-list*

**no match** [**not**] **ip rtp** *port-list*

## Syntax Description

|                  |                                                                                                    |
|------------------|----------------------------------------------------------------------------------------------------|
| <b>not</b>       | (Optional) Negates the specified match result.                                                     |
| <i>port-list</i> | Specified UDP port or list of UDP ports that are using RTP. Valid values range from 2000 to 65535. |

## Command Default

None

## Command Modes

Class-map type qos configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

To specify a list of values, use one of the following options:

- Specify a range of values separated by a dash
- Specify a noncontiguous list of values separated by commas

## Examples

This example shows how to match on a port using RTP:

```
switch(config)# class-map my_test
switch(config-cmap-qos)# match ip rtp 2300
```

## Related Commands

| Command               | Description          |
|-----------------------|----------------------|
| <b>show class-map</b> | Displays class maps. |

# match precedence

To configure a class map to use the precedence value in the type of service (ToS) byte field of the IP header (either IPv4 or IPv6) as a match criteria, use the **match precedence** command. To remove the precedence values as a match criteria, use the **no** form of this command.

**match** [**not**] **precedence** *precedence-list*

**no match** [**not**] **precedence** *precedence-list*

## Syntax Description

|                        |                                                                                                                                       |
|------------------------|---------------------------------------------------------------------------------------------------------------------------------------|
| <b>not</b>             | (Optional) Negates the specified match result.                                                                                        |
| <i>precedence-list</i> | Specified IP precedence value or list of IP precedence values specified in bytes. Valid values are shown in <a href="#">Table 2</a> . |

## Command Default

None

## Command Modes

Class-map type qos configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

See [Table 2](#) for a list of precedence values.

**Table 2**      **Precedence Values**

| Precedence Value | Description                         |
|------------------|-------------------------------------|
| 0-7              | IP precedence value                 |
| critical         | Critical precedence (5)             |
| flash            | Flash precedence (3)                |
| flash-override   | Flash override precedence (4)       |
| immediate        | Immediate precedence (2)            |
| internet         | Internetwork control precedence (6) |
| network          | Network control precedence (7)      |
| priority         | Priority precedence (1)             |
| routine          | Routine precedence (0)              |

To specify a list of values, use one of the following options:

- Specify a range of values separated by a dash
- Specify a noncontiguous list of values separated by commas

---

**Examples**

This example shows how to match on an IP precedence value:

```
switch(config)# class-map my_test  
switch(config-cmap-qos)# match precedence 7
```

---

**Related Commands**

| Command               | Description          |
|-----------------------|----------------------|
| <b>show class-map</b> | Displays class maps. |



# match protocol

To configure a class map to use a specific protocol as a match criterion, use the **match protocol** command. To remove the specified protocol as a match criteria, use the **no** form of this command.

**match** [**not**] **protocol** *protocol-name*

**no match** [**not**] **protocol** *protocol-name*

|                           |                                                                        |                                                                              |
|---------------------------|------------------------------------------------------------------------|------------------------------------------------------------------------------|
| <b>Syntax Description</b> | <b>not</b>                                                             | (Optional) Negates the specified match result.                               |
|                           | <i>protocol-name</i>                                                   | Specified protocol name. Valid values are shown in <a href="#">Table 3</a> . |
| <b>Command Default</b>    | None                                                                   |                                                                              |
| <b>Command Modes</b>      | Class-map type qos configuration                                       |                                                                              |
| <b>Command History</b>    | <b>Release</b>                                                         | <b>Modification</b>                                                          |
|                           | 6.0(2)N1(1)                                                            | This command was introduced.                                                 |
| <b>Usage Guidelines</b>   | The list of valid protocol names is shown in <a href="#">Table 3</a> . |                                                                              |

**Table 3** Protocol Names

| Argument | Description                                      |
|----------|--------------------------------------------------|
| arp      | Address Resolution Protocol (ARP)                |
| clns_es  | CLNS End Systems                                 |
| clns_is  | CLNS Intermediate System                         |
| dhcp     | Dynamic Host Configuration (DHCP)                |
| iscsi    | Internet Small Computer System Interface (iSCSI) |
| ldp      | Label Distribution Protocol (LDP)                |
| netbios  | NetBIOS Extended User Interface (NetBEUI)        |

To specify more than one protocol, enter the command more than once with the desired protocol value each time.

**Examples** This example shows how to match on a specified protocol:

```
switch(config)# class-map my_test
switch(config-cmap-qos)# match protocol ldp
```

■ match protocol

**Related Commands**

| Command               | Description          |
|-----------------------|----------------------|
| <b>show class-map</b> | Displays class maps. |

# match qos-group

To configure a class map to use a specific QoS group value as a match criterion, use the **match qos-group** command. To remove the specified protocol as a match criteria, use the **no** form of this command.

**match** [**not**] **qos-group** *qos-group-list*

**no match** [**not**] **qos-group** *qos-group-list*

## Syntax Description

|                       |                                                                                                         |
|-----------------------|---------------------------------------------------------------------------------------------------------|
| <b>not</b>            | (Optional) Negates the specified match result.                                                          |
| <i>qos-group-list</i> | Specified Qos group value or list of QoS group values specified in bytes. Valid values are from 2 to 5. |

## Command Default

None

## Command Modes

Class map type network-qos configuration  
Class map type queuing configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

The QoS group is an internal label and is not part of the packet payload or any packet header. The QoS group values have no mathematical significance. For example, a QoS group value of 2 is not greater than 1; the values are used only to internally differentiate QoS groups. As such, this value has local significance only.

You match on the QoS group only in egress policies because its value is undefined until you set it in an ingress policy.

To specify a list of values, use one of the following options:

- Specify a range of values separated by a dash
- Specify a noncontiguous list of values separated by commas

## Examples

This example shows how to match on a specified QoS group value:

```
switch(config)# class-map type queuing my_test
switch(config-cmap-qos)# match qos-group 6
switch(config-cmap-qos)#
```

| Related Commands | Command                           | Description                                  |
|------------------|-----------------------------------|----------------------------------------------|
|                  | <b>class-map type network-qos</b> | Creates or modifies a network qos class map. |
|                  | <b>class-map type queuing</b>     | Creates or modifies a queuing class map.     |
|                  | <b>show class-map</b>             | Displays class maps.                         |

# mtu (ERSPAN)

To set the maximum transmission unit (MTU) size for Encapsulated Remote Switched Port Analyzer (ERSPAN) packets in a monitor session, use the **mtu** command. To remove the configured MTU, use the **no** form of this command.

**mtu** *mtu-value*

**no mtu** *mtu-value*

## Syntax Description

|                  |                                                                                                    |
|------------------|----------------------------------------------------------------------------------------------------|
| <i>mtu-value</i> | Maximum allowable MTU for ERSPAN packets in a monitor session. The range is from 64 to 1518 bytes. |
|------------------|----------------------------------------------------------------------------------------------------|

## Command Default

Default is no truncation enabled.

## Command Modes

ERSPAN session configuration mode

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

ERSPAN packets larger than the specified allowable size for the monitor session are truncated. This command does not require a license.

## Examples

This example shows how to set an MTU value for an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# erspan-id 100
switch(config-erspan-src)# mtu 100
switch(config-erspan-src)#
```

## Related Commands

| Command                     | Description                                        |
|-----------------------------|----------------------------------------------------|
| <b>monitor session</b>      | Configures a SPAN or ERSPAN session.               |
| <b>show monitor session</b> | Displays the SPAN or ERSPAN session configuration. |

# mtu (interface)

To configure the maximum transmission unit (MTU) size for Layer 2 and Layer 3 Ethernet interfaces, use the **mtu** command. To remove the configured MTU, use the **no** form of this command.

**mtu** *mtu-value*

**no mtu** *mtu-value*

## Syntax Description

|                  |                                                                                      |
|------------------|--------------------------------------------------------------------------------------|
| <i>mtu-value</i> | MTU value for the class of service (CoS). The range is from 64 to 9216.1500 to 9216. |
|------------------|--------------------------------------------------------------------------------------|

## Command Default

Default MTU value is 1500. For FCoE cos 3, the default is 2158.

## Command Modes

Policy map type network-qos class configuration

## Command History

| Release     | Modification                 |
|-------------|------------------------------|
| 6.0(2)N1(1) | This command was introduced. |

## Usage Guidelines

You can configure an MTU for each virtual link in the system.

## Examples

This example shows how to set an MTU value for a class in a type network-qos policy map:

```
switch(config)# class-map type network-qos my_class1
switch(config-cmap-nq)# match qos-group 1
switch(config-cmap-nq)# exit
switch(config)# policy-map type network-qos my_policy1
switch(config-pmap-nq)# class type network-qos my_class1
switch(config-pmap-nq-c)# mtu 5000
switch(config-pmap-nq-c)#
```

## Related Commands

| Command                | Description                                             |
|------------------------|---------------------------------------------------------|
| <b>service-policy</b>  | Attaches a policy map to an interface or system policy. |
| <b>show class-map</b>  | Displays class maps.                                    |
| <b>show policy-map</b> | Displays policy maps.                                   |
| <b>system qos</b>      | Configures a system policy.                             |