



Show Commands

This chapter describes the Cisco NX-OS Hot Standby Router Protocol (HSRP) **show** commands.

show hsrp

To display Hot Standby Router Protocol (HSRP) information for each HSRP group, use the **show hsrp** command.

```
show hsrp [interface {ethernet slot/port | port-channel number | vlan vlan-id}] [group
group-number] [active | init | listen | standby] [all] [brief] [detail] [ipv4]
```

Syntax Description	
interface	(Optional) Specifies the interface for which to display HSRP information.
ethernet <i>slot/port</i>	Specifies the Ethernet interface and the slot number and port number. The slot number is from 1 to 255, and the port number is from 1 to 128.
port-channel <i>number</i>	Specifies the EtherChannel interface and EtherChannel number. The range is from 1 to 4096.
vlan <i>vlan-id</i>	Specifies the VLAN interface. The range is from 1 to 4094.
group <i>group-number</i>	(Optional) Specifies the HSRP group number of the interface to display information about. The range is from 0 to 4095.
active	(Optional) Displays HSRP groups that are in an active state.
init	(Optional) Displays HSRP groups that are in an initialization state.
listen	(Optional) Displays HSRP groups that are in an listen state.
standby	(Optional) Displays HSRP groups that are in an standby state.
all	(Optional) Displays all HSRP groups.
brief	(Optional) Summarizes each virtual gateway or virtual forwarder with a single line of output.
detail	(Optional) Displays detailed information about HSRP groups.
ipv4	(Optional) Displays HSRP IPv4 groups.

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines Use the **show hsrp** command to display information about HSRP groups. The **brief** keyword displays a single line of information about each virtual gateway or virtual forwarder.

If you have not configured authentication, the **show hsrp** command will display the following string:

```
Authentication text "cisco"
```

This is the default behavior of HSRP as defined in [RFC 2281](#):

```
If no authentication data is configured, the RECOMMENDED default
value is 0x63 0x69 0x73 0x63 0x6F 0x00 0x00 0x00.
```

This command does not require a license.

**Note**

Make sure the LAN Base Services license is installed on the switch to enable Layer 3 interfaces.

Examples

This example shows how to display the default information about HSRP:

```
switch# show hsrp
Vlan1 - Group 1 (HSRP-V1) (IPv4)
  Local state is Active, priority 150 (Cfged 150), may preempt
  Forwarding threshold(for vPC), lower: 1 upper: 150
  Preemption Delay (Seconds) Reload:300
  Hello time 3 sec, holdtime 10 sec
  Next hello sent in 0.793000 sec(s)
  Virtual IP address is 10.1.1.3 (Cfged)
  Active router is local
  Standby router is unknown
  Authentication text "cisco"
  Virtual mac address is 0000.0c07.ac01 (Default MAC)
  17 state changes, last state change 1w0d
  IP redundancy name is hsrp-Vlan1-1 (default)
...
```

**Note**

The authentication text string in the preceding example indicates that authentication has not been configured on the interface.

This example shows how to display a brief summary of HSRP information:

```
switch# show hsrp brief
          P indicates configured to preempt.
          |
Interface  Grp Prio P State   Active addr   Standby addr   Group addr
Vlan1      1  150 P Active local        unknown       10.1.1.3      (conf)
Vlan2      2  150 P Active local        unknown       10.1.2.3      (conf)
...
```

Related Commands

Command	Description
feature hsrp	Enables the HSRP feature.

show hsrp delay

To display the Hot Standby Router Protocol (HSRP) group delay information, use the **show hsrp delay** command.

```
show hsrp delay [interface {ethernet slot/port | port-channel number[.sub_if_number] | vlan
vlan_id}] [group group-number] [all] [brief]
```

Syntax Description

interface	(Optional) Specifies the interface type and number for which to display HSRP information.
ethernet slot/port	(Optional) Specifies the Ethernet interface. The slot number is from 1 to 255, and the port number is from 1 to 128.
port-channel number	(Optional) Specifies the EtherChannel interface. The EtherChannel number is from 1 to 4096.
.sub_if-number	(Optional) Subinterface number. The range is from 1 to 4093.
vlan vlan-id	(Optional) Specifies the VLAN interface. The range is from 1 to 4094.
group group-number	(Optional) Specifies the HSRP group number of the interface to display information about. The range is from 0 to 4095.
all	(Optional) Specifies all HSRP information.
brief	(Optional) Specifies brief HSRP information.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command does not require a license.



Note

Make sure the LAN Base Services license is installed on the switch to enable Layer 3 interfaces.

Examples

This example shows how to display HSRP delay information:

```
switch# show hsrp delay
-----
Interface      Minimum  Reload
-----
Eth1/5         30      0
switch#
```

Related Commands

Command	Description
delay minimum	Configures the delay information for HSRP groups.
feature hsrp	Enables the HSRP feature.
hsrp delay	Configures the delay information for HSRP groups.

show hsrp summary

To display Hot Standby Router Protocol (HSRP) summary information for each HSRP group, use the **show hsrp summary** command.

show hsrp summary

Syntax Description This command has no arguments or keywords.

Command Default None

Command Modes Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command does not require a license.



Note

Make sure the LAN Base Services license is installed on the switch to enable Layer 3 interfaces.

Examples

This example shows how to display a summary of HSRP information:

```
switch# show hsrp summary

HSRP Summary:

Extended-hold (NSF) disabled
Global HSRP-BFD disabled

Total Groups: 1
  Version::   V1-IPV4: 1       V2-IPV4: 0       V2-IPV6: 0
    State::   Active: 0       Standby: 0       Listen: 0
    State::   V6-Active: 0     V6-Standby: 0     V6-Listen: 0

Total HSRP Enabled interfaces: 1

Total Packets:
  Tx - Pass: 0       Fail: 0
  Rx - Good: 0

Packet for unknown groups: 0

Total MTS: Rx: 25

switch#
```

Related Commands	Command	Description
	feature hsrp	Enables the HSRP feature.
	hsrp	Configures HSRP groups.

