



## Cisco Plug-in for OpenFlow Commands

---

- [activate](#), page 2
- [controller](#), page 4
- [hardware profile openflow](#), page 6
- [of-port interface \(OpenFlow\)](#), page 7
- [max-backoff](#), page 9
- [openflow](#), page 10
- [pipeline](#), page 12
- [probe-interval](#), page 13
- [rate-limit](#), page 14
- [show openflow copyright](#), page 15
- [show openflow interface](#) , page 16
- [show openflow switch](#), page 18
- [show openflow switch controller](#), page 21
- [show openflow switch flows](#), page 24
- [show openflow switch ports](#), page 27
- [show openflow switch stats](#), page 29
- [show openflow hardware capabilities](#), page 31
- [switch \(OpenFlow\)](#), page 34
- [shutdown \(OpenFlow\)](#), page 36
- [tls trust-point](#), page 37

# activate

To activate an application installed in a virtual services container, use the **activate** command in virtual services configuration mode. To deactivate the application, use the **no activate** form of this command.

**activate**

**no activate**

## Syntax Description

This command has no arguments or keywords.

## Command Default

The application installed in the virtual services container is not activated.

## Command Modes

Virtual services configuration (config-virt-serv)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.

## Examples

The following example shows how an application installed in a virtual services container is activated .

```
Device# virtual-service install name openflow_agent package
bootflash:/ofa-1.0.0-n3000-SPA-k9.ova
```

```
Note: Installing package 'bootflash:/ofa-1.0.0-n3000-SPA-k9.ova' for virtual service
'openflow_agent'. Once the install has finished, the VM may be activated. Use 'show
virtual-service list' for progress.
Device# 2013 Mar  8 20:35:23 n3k-202-194-2 %$ VDC-1 %$ %VMAN-2-INSTALL_STATE: Successfully
installed virtual service 'openflow_agent'
Device# configure terminal
Device(config)# virtual-service openflow_agent
Device(config-virt-serv)# activate
```

## Related Commands

Command	Description
<a href="#">hardware profile openflow</a>	Enables support and allocates resources for Cisco Plug-in for OpenFlow VLAN tagging actions on the device hardware.
<a href="#">show virtual-service list</a>	Displays the status of installation of all applications on the virtual service container.
<a href="#">show virtual-service version</a>	Displays the version of an application installed in the virtual service container of a device.
<a href="#">show virtual-service version installed</a>	Displays the version of OpenFlow Agent application installed on the virtual services container of device.

Command	Description
<a href="#">virtual-service</a>	Provisions an application installed in the virtual services container of a device.
<a href="#">virtual-service install</a>	Installs an application on the virtual services container of a device.

# controller

To configure a controller for a Cisco Plug-in for OpenFlow logical switch, use the **controller** command in logical switch configuration mode. To remove the controller definitions for the logical switch, use the **no** form of this command.

**controller ipv4** *ipv4-address* [**port** *port-number*][**vrf** *vrf-name*]**security** {**none**| **tls**}**no-tls**

**no controller ipv4** *ipv4-address* [**port***port-number*][**vrf** *vrf-name*]**security** {**none**| **tls**}

## Syntax Description

<b>ipv4</b> <i>ipv4-address</i>	Specifies the IPv4 address of the controller.
<b>port</b> <i>port-number</i>	(Optional) Specifies the port through which the device must connect to the controller. The default value is 6533.
<b>vrf</b> <i>vrf-name</i>	(Optional) Specifies the virtual routing and forwarding (VRF) instance defined for the controller. The default value is default.
<b>security none</b>	(Optional) Disables Transport Layer Security (TLS) for the controller connection.
<b>security tls</b>	(Optional) Enables Transport Layer Security (TLS) for the controller connection.

## Command Default

No controllers are defined for Cisco Plug-in for OpenFlow. If the **security none** keyword is not used, TLS has to be configured using the **security tls** command.

## Command Modes

Logical switch configuration (config-ofa-switch)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.
Cisco Plug-in for OpenFlow Release 1.1	This command was modified. The <b>no-tls</b> keyword was added.

## Examples

The following example shows how the **controller** command is used to configure a controller for an Cisco Plug-in for OpenFlow logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# pipeline 201

Device(config-ofa-switch)# controller ipv4 10.1.0.6 port 6666 security none
Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

## Related Commands

Command	Description
<a href="#">of-port interface (OpenFlow)</a>	Configures an interface as a port of an Cisco Plug-in for OpenFlow logical switch
<a href="#">openflow</a>	Configures Cisco Plug-in for OpenFlow.
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode
<a href="#">show openflow hardware capabilities</a>	Displays the match and action capabilities of a device.

# hardware profile openflow

To enable support and allocates resources for Cisco Plug-in for OpenFlow VLAN tagging actions on the device hardware, use the **hardware profile openflow** command in global configuration mode. To disable VLAN tagging actions, use the **no** form of this command.

**hardware profile openflow**

**no hardware profile openflow**

## Syntax Description

This command has no keywords or arguments.

## Command Default

VLAN tagging actions for Cisco Plug-in for OpenFlow are disabled.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
6.0(2)U1(1)	This command was introduced.

## Usage Guidelines

The **hardware profile openflow** command must be entered before an application is installed on the virtual services container of a device.

## Examples

```
Device# configure terminal
Device(config)# hardware profile openflow
Device(config)# exit
Device# copy running-config startup-config
Device# reload
```

## Related Commands

Command	Description
<a href="#">virtual-service install</a>	Installs an application on the virtual services container of a device.

## of-port interface (OpenFlow)

To configure an interface as a port of an Cisco Plug-in for OpenFlow logical switch, use the **of-port interface** command in logical switch configuration mode. To remove port configurations for an interface on an Cisco Plug-in for OpenFlow logical switch, use the **no** form of this command.

**of-port interface** *interface-name*

**no of-port interface** *interface-name*

### Syntax Description

<i>interface-name</i>	Name of interface to be configured.
-----------------------	-------------------------------------

### Command Default

No ports are configured for the Cisco Plug-in for OpenFlow logical switch.

### Command Modes

Logical switch configuration (config-ofa-switch)

### Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.

### Usage Guidelines

Do not abbreviate the interface type. Ensure that interface types used are spelled out clearly and typed in lowercase, as shown in the examples. For example, **ethernet** and **port-channel**. If the keyword is abbreviated or not in lowercase, the interface is not configured. Ensure that the interface name does not have a space between the interface type and number.

The Ethernet interface configured can be a member interface of a port channel.

You must configure an interface as a port of Cisco Plug-in for OpenFlow only when Cisco Plug-in for OpenFlow is active and running. When an interface is configured as a port of Cisco Plug-in for OpenFlow, the **mode openflow** configuration is added to the interface. This configuration is removed when the **no** form of **of-port interface** is used only if the Cisco Plug-in for OpenFlow is running and active.

### Examples

The following example shows how the **interface** command is used to configure an interface to be a port of an Cisco Plug-in for OpenFlow logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# of-port interface ethernet1/1
Device(config-ofa-switch)# of-port interface port-channel1
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

**Related Commands**

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode



# max-backoff

To configure the maximum TCP triggered backoff interval for which Cisco Plug-in for OpenFlow can wait before retrying a connection to the controller, use the **max-backoff** command in logical switch configuration mode. To restore the default backoff interval, use the **no** form of this command.

**max-backoff** *backoff-timer*

**no****max-backoff** *backoff-timer*

## Syntax Description

<i>backoff-timer</i>	Interval, in seconds, for which a device can wait before retrying a connection to the controller.
	<ul style="list-style-type: none"> <li>• Range is from 1 to 65535.</li> <li>• Default value is 8 seconds.</li> </ul>

## Command Default

A maximum backoff of 8 seconds is configured.

## Command Modes

Logical switch configuration (config-ofa-switch)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow 1.1	This command was introduced.

## Examples

The following example shows how the **max-backoff** command is used to configure a controller for an OpenFlow Agent logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# max-backoff 3
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

# openflow

To configure Cisco Plug-in for OpenFlow and enter Cisco Plug-in for OpenFlow Release configuration mode, use the **openflow** command in global configuration mode. To remove all configurations made for Cisco Plug-in for OpenFlow and exit Cisco Plug-in for OpenFlow Release configuration mode, use the **no** form of this command.

**openflow**

**no openflow**

## Command Default

The Cisco Plug-in for OpenFlow is not configured.

## Command Modes

Global configuration (config)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.

## Examples

The following example shows how the **openflow** command is used to configure the Cisco Plug-in for OpenFlow.

```
Device> enable
Device(config)# openflow
Device(config-oft)# switch 1
Device(config-oft-switch)# controller ipv4 10.1.0.6
Device(config-oft-switch)# interface ethernet1/1
Device(config-oft-switch)# end
Device# copy running-config startup-config
```

## Related Commands

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.
<a href="#">of-port interface (OpenFlow)</a>	Configures an interface as a port of an Cisco Plug-in for OpenFlow logical switch
<a href="#">openflow</a>	Configures Cisco Plug-in for OpenFlow.
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode
<a href="#">max-backoff</a>	Configures an interval for which Cisco Plug-in for OpenFlow logical switch must wait before retrying a connection to the controller.
<a href="#">tls trust-point</a>	Configures local and remote trust points needed for a Transport Layer Security (TLS) connection to the controller
<a href="#">probe-interval</a>	Configures an interval that Cisco Plug-in for OpenFlow logical switch waits before sending a probe to query an idle connection to controller.

Command	Description
<a href="#">pipeline</a>	Configures a pipeline.
<a href="#">rate-limit</a>	Configures the rate at which packets are sent to a controller by Cisco Plug-in for OpenFlow logical switch.

# pipeline

To configure a pipeline for a Cisco Plug-in for OpenFlow logical switch, use the **pipeline** command in logical switch configuration mode. To remove the pipeline configurations, use the **no** form of this command.

**pipeline** *pipeline-id*

**no pipeline**

## Syntax Description

<i>pipeline-id</i>	Configures pipeline number. This value must be taken from the output of the <b>show openflow hardware capabilities</b>
--------------------	--

## Command Default

A pipeline is not configured.

## Command Modes

Logical switch configuration (config-ofa-switch)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.1	This command was introduced.

## Usage Guidelines

This command specifies the forwarding table used by Cisco Plug-in for OpenFlow logical switch. You can use the **show openflow hardware capabilities** command to view supported pipelines for a device.

## Examples

The following example shows how to configure a pipeline for an Cisco Plug-in for OpenFlow logical switch for a Nexus 3000 Series device.

```
Device(config)# openflow
Device(config-ofa)# switch 1
! Specifies the pipeline that enables the L3 ACL Forwarding Table.
Device(config-ofa)# pipeline 201
```

## Related Commands

Command	Description
<a href="#">show openflow hardware capabilities</a>	Displays the match and action capabilities of a device.

# probe-interval

To configure an interval that Cisco Plug-in for OpenFlow logical switch waits before sending a probe to query an idle connection to controller, use the **probe-interval** command in logical switch configuration mode. To restore the default probe interval, use the **no** form of this command.

**probe-interval** *probe-interval*

**no probe-interval** *probe-interval*

## Syntax Description

<i>probe-interval</i>	Interval, in seconds, at which an idle controller connection is probed.
	<ul style="list-style-type: none"> <li>• Default value is 5 seconds.</li> <li>• Range is from 5 to 65535.</li> </ul>

## Command Default

The idle controller connection is probed every 5 seconds.

## Command Modes

Logical switch configuration (config-ofa-switch)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.1	This command was introduced.

## Examples

The following example shows how the **probe-interval** command is used to configure a probe interval for an idle controller connection.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa)# probe-interval 6
Device(config-ofa)# end
Device# copy running-config startup-config
```

# rate-limit

To configure the rate at which packets are sent to the controller by Cisco Plug-in for OpenFlow logical switch, use the **rate-limit** command in the logical switch configuration mode. To remove the rate limit configurations, use the **no** form of this command.

**rate-limit packet\_in** *packet-rate* **burst** *number-of-packets*

**no rate-limit packet\_in** *packet-rate* **burst** *number-of-packets*

## Syntax Description

<b>packet_in</b> <i>packet-rate</i>	Configures, in packets per seconds, the maximum rate at which packets are sent to controller. <ul style="list-style-type: none"> <li>Range is from 1 to 65535.</li> <li>Default value is 0. This indicates that rate limit is disabled and that packets are sent at the maximum possible rate.</li> </ul>
<b>burst</b> <i>number-of-packets</i>	Configures the maximum supported bursts or number of packets destined for the controller that can be stored by the logical switch at any time. <ul style="list-style-type: none"> <li>Range is from 1 to 65535.</li> </ul>

## Command Default

Rate limit is not configured for Cisco Plug-in for OpenFlow logical switch.

## Command Modes

Logical switch configuration (config-ofa-switch)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.1	This command was introduced.

## Examples

The following example shows how the **rate-limit** command is used to configure the rate limit for Cisco Plug-in for OpenFlow logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# rate-limit packet_in 30 burst 50
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

# show openflow copyright

To display copyright and open-source information related to Cisco Plug-in for OpenFlow, use the **show openflow copyright** command in privileged EXEC mode.

**show openflow copyright**

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

## Examples

The following is sample output of the **show openflow copyright** command:

```
Device# show openflow copyright
```

```
Cisco Nexus Operating System (NX-OS) Software
TAC support: http://www.cisco.com/tac
Copyright (c) 2002-2013, Cisco Systems, Inc. All rights reserved.
The copyrights to certain works contained in this software are
owned by other third parties and used and distributed under
license. Certain components of this software are licensed under
the GNU General Public License (GPL) version 2.0 or the GNU
Lesser General Public License (LGPL) Version 2.1. A copy of each
such license is available at
http://www.opensource.org/licenses/gpl-2.0.php and
http://www.opensource.org/licenses/lgpl-2.1.php
```

## Related Commands

Command	Description
<a href="#">openflow</a>	Configures Cisco Plug-in for OpenFlow.

# show openflow interface

To display a list of Cisco Plug-in for OpenFlow logical switch ports, use the **show openflow interface switch** command in privileged EXEC mode.

**show openflow interface** [*interface-name*] [**switch** *switch-id*]

## Syntax Description

<i>interface-name</i>	(Optional) Name of the interface. See Usage Guidelines for more details.
<i>switch-id</i>	(Optional) Unique switch identifier. <b>1</b> is the only permitted value.

## Command Default

Displays a list of all interfaces associated with the Cisco Plug-in for OpenFlow logical switch.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

## Usage Guidelines

Do not abbreviate the interface. Ensure that the **ethernet** or **port-channel** keywords are spelled out completely and are typed in lowercase. For example, **ethernet1/1** or **port-channel2**. If the keyword is abbreviated or not in lowercase, the interface is not configured.

Only interfaces specified by the **interface (OpenFlow)** command can display an output.

## Examples

The following is sample output of the **show openflow interface** command:

```
Device# show openflow interface
```

```
Logical Switch Id: 1
  Interfaces:
    Ethernet1/11
    Ethernet1/12
    Ethernet1/13
    Ethernet1/2
    Ethernet1/24
    Ethernet1/25
    Ethernet1/3
    Ethernet1/4
    port-channel2
```

```
Device# show openflow interface ethernet1/2 switch 1
```

```
Logical Switch Id: 1
  Interface: ethernet1/2
Device# show openflow interface switch 1

  Interfaces:
```



```
Ethernet1/11  
Ethernet1/12  
Ethernet1/13  
Ethernet1/2  
Ethernet1/24  
Ethernet1/25  
Ethernet1/3  
Ethernet1/4  
port-channel2
```

**Related Commands**

Command	Description
<a href="#">of-port interface (OpenFlow)</a>	Configures an interface as a port of an Cisco Plug-in for OpenFlow logical switch
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode

# show openflow switch

To display information related to an Cisco Plug-in for OpenFlow logical switch, use the **show openflow switch** command in privileged EXEC mode.

**show openflow switch** [*switch-id*]

## Syntax Description

<i>switch-id</i>	(Optional) Cisco Plug-in for OpenFlow logical switch ID. Only the value <b>1</b> is permitted.
------------------	--

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.

## Examples

The following is sample output of the **show openflow switch** command on Nexus 3000 Series Device.

```
Device# show openflow switch 1
```

```
Logical Switch Context
Id: 1
Switch type: Forwarding
Pipeline id: 201
Signal version: Openflow 1.0
Data plane: secure
Table-Miss default: NONE
Config state: no-shutdown
Working state: enabled
Rate limit (packet per second): 0
Burst limit: 0
Max backoff (sec): 8
Probe interval (sec): 5
TLS local trustpoint name: not configured
TLS remote trustpoint name: not configured
Stats coll. period (sec): 5
Logging flow changes: Disabled
OFA Description:
  Manufacturer: Cisco Systems, Inc.
  Hardware: N3K-C3064PQ V01
  Software: 6.0(2)U2(1) of_agent 1.1.0_fc1
  Serial Num: SSI15200QD8
  DP Description: n3k-200-141-3:sw1
OF Features:
  DPID:0001547fee00c2a0
  Number of tables:1
  Number of buffers:256
  Capabilities: FLOW_STATS TABLE_STATS PORT_STATS
  Actions: OUTPUT SET_VLAN_VID STRIP_VLAN SET_DL_SRC SET_DL_DST
Controllers:
  1.1.1.1:6653, Protocol: TLS, VRF: s
Interfaces:
```

```
Ethernet1/1
Ethernet1/7
```

**Table 1: show openflow switch Field Descriptions**

Field	Description
Id	Cisco Plug-in for OpenFlow logical switch identifier.
Switch type	Type of switch. The possible values are as follows: <ul style="list-style-type: none"> <li>• Forwarding—Forwards packets to controller.</li> </ul>
Pipeline ID	Identifier used for pipeline.
Layer	Network layer on which the switch operates.
Data plane: secure	Security levels of the data plane.
Table-Miss default:	Fallback state of switch.
Signal version	OpenFlow version.
Config state:	The switch is in a configuration state of no shutdown.
Working state:	The switch is in a working state.
TLS	Transport Layer Security (TLS) capability and trust points.
Rate Limit	Rate limit.
Burst Limit	Burst limit.
Maximum Backoff	Maximum backoff.
Probe interval	Probe interval.
Stats coll. period (sec):	Time period at which stats are collected.
Logging Flow changes	
Manufacturer: Cisco Systems, Inc.	Manufacturer of the Cisco Plug-in for OpenFlow software.

Field	Description
Hardware	Device on which the Cisco Plug-in for OpenFlow is installed.
Software:	Operating system running on the device.
Serial Num:	Serial Number of the device.
DP Description	Data Path description used by the controller to identify the device.
DPID	Data Path identifier used by the controller to identify the device.
Number of tables	Number of flows defined for the device on the controller.
Number of buffers	Number of buffers allocated to the device.
Capabilites:	Match capabilities available on this device.
Actions:	Actions available on this device.
Controllers: 192.168.1.31:8005, Protocol: TCP, VRF: default 192.168.94.173:6633, Protocol: TCP, VRF: management	Controllers connected to this device, port number used, protocol used for between the controller and the device, and the VRF on which the controller is defined.
Interfaces:	List of interfaces defined for the device.

# show openflow switch controller

To display information about controllers connected to an Cisco Plug-in for OpenFlow switch, use the **show openflow switch controller** command in privileged EXEC mode.

**show openflow switch** [*switch-id*] [**controllers**[**stats**]]

## Syntax Description

<i>switch-id</i>	(Optional) Cisco Plug-in for OpenFlow logical switch identifier.
<b>stats</b>	(Optional) Cisco Plug-in for OpenFlow Displays controller based statistics.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

## Usage Guidelines

A device can connect to up to eight controllers.

## Examples

The following is sample output of the **show openflow switch 1 controllers** command:

```
Device# show openflow switch 1 controllers
```

```
Logical Switch Id: 1
Total Controllers: 1
  Controller: 1
    10.168.1.31:7777
    Protocol: tcp
    VRF: default
    Connected: Yes
    Role: Other
    state:ACTIVE
    sec_since_connect:31474
```

The following is sample output of the **show openflow switch 1 controllers** command:

```
Device# show openflow switch 1 controllers
```

```
Logical Switch Id: 1
Total Controllers: 1
  Controller: 1
    10.86.201.162:8050
    Protocol: tcp
    VRF: management
    Local Trustpoint: disabled
    Remote Trustpoint: disabled
    Connected: Yes
    Role: Master
    state:ACTIVE
    sec_since_connect:36844
```

**Table 2: show openflow switch controllers Field Description**

Field	Descriptions
Logical Switch Id: 1	Indicates the unique switch identifier.
Total Controllers: 1	Indicates the total number of controllers connected to this device.
Controller: 1	Indicates the controller identifier.
192.168.1.31:7777	Indicates the IP address of the controller and the controller port used for the connection.
Protocol: TCP	Indicates the protocol used for controller-device communication.
VRF: default	Indicates the virtual routing and forwarding (VRF) instance of which the controller is part of.
Local Trustpoint	Status of local trustpoint
Remote Trustpoint	Status of remote trustpoint
Connected: Yes	Indicates whether the switch is connected to the controller.
Role: Other	Indicates the role of the controller. <ul style="list-style-type: none"> <li>• Master—Full access, at most one</li> <li>• Slave - Read-only access</li> <li>• Other— Default role, full access</li> </ul>
state:ACTIVE	Indicates the state of the controller. Possible values are given below: <ul style="list-style-type: none"> <li>• ACTIVE—The controller is active.</li> <li>• BACKOFF—The controller is in a state of backoff.</li> </ul>
sec_since_connect	Indicates the number of seconds that have elapsed since the connector connected to the device.

**Related Commands**

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.

Command	Description
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode

# show openflow switch flows

To display a list of flows defined for Cisco Plug-in for OpenFlow logical switch and related information, use the **show openflow switch flows** command in privileged EXEC mode.

**show openflow switch** *switch-id* **flows**[**configured**| **controller**| **default**| **fixed**| **pending**| **pending-del**][**brief** | **summary**]

## Syntax Description

<i>switch-id</i>	(Optional) Cisco Plug-in for OpenFlow logical switch identifier.
<b>configured</b>	(Optional) Displays information related to configured flows.
<b>controller</b>	(Optional) Displays flow information related to controllers.
<b>default</b>	(Optional) Displays default information related to flows.
<b>fixed</b>	(Optional) Displays information related to fixed flows.
<b>fixed</b>	(Optional) Displays information related to fixed flows.
<b>pending</b>	(Optional) Displays information related to pending flows.
<b>pending-del</b>	(Optional) Displays brief information related to flows pending deletion.
<b>summary</b>	(Optional) Displays a summary of information related to flows.

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

## Usage Guidelines

The flows displayed are configured by the controller that is connected to Cisco Plug-in for OpenFlow logical switch on the device.

## Examples

The following is sample output of the **show openflow switch 1 flows** command:

```
Device# show openflow switch 1 flows
Logical Switch Id: 1
Total flows: 1
1
  Rule:          ip,d1_vlan=99
  Actions:       strip_vlan,output:1
```



```

Priority:      0x8000
Table:        0
Cookie:        0x466c6f7732
Duration:      176.383s
Number of packets: 0
Number of bytes: 0

```

Device# **show openflow switch 1 flows**

Total flows: 2

Flow: 1

```

Rule:          ip,d1_vlan=99
Actions:        strip_vlan,output:1
Priority:        0x8000
Table:          0
Cookie:         0x466c6f7732
Duration:        96.359s
Number of packets: 0
Number of bytes: 0

```

Flow: 2

```

Rule:          ip,in_port=2,d1_vlan=50
Actions:        output:1
Priority:        0x8000
Table:          0
Cookie:         0x1
Duration:        95.504s
Number of packets: 0
Number of bytes: 0

```

**Table 3: show openflow switch flows Field Descriptions**

Field	Descriptions
Rule	<p>List of rules defined for the flow. This is related to the match capabilities of the device. The possible rules are listed below:</p> <ul style="list-style-type: none"> <li>• <b>dl_vlan=vlan-id</b>—Packet has the given VLAN ID.</li> <li>• <b>in_port</b>—Packet has arrived on the given input port.</li> <li>• <b>ip</b>—Packet uses the IP protocol.</li> <li>• <b>nw_dst</b>—Packet is destined for a given destination address prefix.</li> <li>• <b>nw_src</b>—Packet is from a given source address prefix.</li> <li>• <b>nw_tos</b>—Packet has the given IP ToS bits set.</li> <li>• <b>tp_dst</b>—Packet is destined for the given TCP/UDP destination port.</li> <li>• <b>tp_src</b>—Packet is from for the given TCP/UDP source port.</li> </ul>

Field	Descriptions
Actions	<p>List of actions to be defined if a packet matches the flow (abides by the rules defined in the flow). The possible actions are:</p> <ul style="list-style-type: none"> <li>• drop—Drop.</li> <li>• mod_vlan_vid—Rewrite VLAN ID.</li> <li>• output:<i>number</i>—Output to one or more physical ports.</li> <li>• output:6533—Output to the controller.</li> <li>• strip_vlan—Strip the VLAN ID.</li> <li>• mod_dl_src—Modify the source MAC address.</li> <li>• mod_dl_dst—Modify the destination MAC address.</li> </ul> <p>If multiple actions are associated with a flow, they are processed in the order specified. The output action should be the last action in the action list. Any action after the output action is not supported.</p>
Priority	Priority of the flow.
Table	Table number.
Cookies	Cookies defined for the flow.
Duration	Duration, in seconds, for which the flow was executed.
Number of packets: 0	Number of packets/bytes that matched the flow.
Number of bytes: 0	Number of bytes exchanged for the flow.

**Related Commands**

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode

## show openflow switch ports

To display the mapping between the Cisco Plug-in for OpenFlow logical switch ports and the device's physical interfaces, use the **show openflow switch ports** command in privileged EXEC mode.

**showopenflow switch** [*switch-id* [*ports*]]

### Syntax Description

<i>switch-id</i>	(Optional) Cisco Plug-in for OpenFlow logical switch identifier.
<b>ports</b>	(Optional) Displays send and receive statistics for each port defined for an Cisco Plug-in for OpenFlow logical switch.

### Command Modes

Privileged EXEC (#)

### Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

### Examples

The following is sample output of the **show openflow switch 1 ports** command:

Device# **show openflow switch 1 ports**

```

Logical Switch Id: 1
Port  Interface Name    Config-State  Link-State  Features
  2   Ethernet1/2        PORT_UP      LINK_UP     10MB-FD
  3   Ethernet1/3        PORT_UP      LINK_DOWN   100MB-HD AUTO_NEG
  4   Ethernet1/4        PORT_UP      LINK_UP     10MB-FD
 11   Ethernet1/11       PORT_UP      LINK_UP     1GB-FD
 12   Ethernet1/12       PORT_UP      LINK_UP     1GB-FD
 13   Ethernet1/13       PORT_UP      LINK_UP     1GB-FD
 24   Ethernet1/24       PORT_UP      LINK_DOWN   1GB-HD AUTO_NEG
 25   Ethernet1/25       PORT_UP      LINK_DOWN   1GB-HD AUTO_NEG
321   port-channel2      PORT_UP      LINK_DOWN   100MB-HD AUTO_NEG

```

**Table 4: show openflow switch 1 ports Field Description table**

Field	Descriptions
Logical Switch Id: 1	Indicates the unique switch identifier.
Port	Indicates port numbers assigned for an interface by Cisco Plug-in for OpenFlow logical switch.
Interface Name	Indicates the name of the physical interface.
Config-State	Indicates the configured state of a port or interface.

Field	Descriptions
Link-State	Indicates the physical link state of a port or interface.
Features	<p>Indicates the configured speed or duplex settings. The values of the output are read as follows:</p> <ul style="list-style-type: none"> <li>• 10MB-FD— Displays that the port has been set to 10-Mbps speed and full duplex.</li> <li>• 10MB-HD—Displays that the port has been set to 10-Mbps speed and half duplex.</li> <li>• 100MB-HD AUTO_NEG— Displays that the port has been auto-negotiated to 100-Mbps speed and half duplex.</li> <li>• 1GB-FD— Displays that the port has been set to 1-Gbps speed and full duplex.</li> <li>• 1GB-HD AUTO_NEG—Displays that the port has been auto-negotiated to 1-Gbps speed and half duplex.</li> </ul>

**Related Commands**

Command	Description
<a href="#">of-port interface (OpenFlow)</a>	Configures an interface as a port of an Cisco Plug-in for OpenFlow logical switch
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode

# show openflow switch stats

To display send and receive statistics for each port defined for the Cisco Plug-in for OpenFlow logical switch, use the **show openflow switch stats** command in privileged EXEC mode.

**show openflow switch** *switch-id* **stats**

## Syntax Description

<i>switch-id</i>	(Optional) Cisco Plug-in for OpenFlow logical switch identifier.
------------------	--

## Command Modes

Privileged EXEC (#)

## Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

## Examples

The following is sample output of the **show openflow switch 1 stats** command:

```
Device# show openflow switch 1 stats
Logical Switch Id: 1
Total ports 9
    Port 4: rx pkts=8570, bytes=2459590, drop=0, errs=0,
    tx pkts=8585, bytes=2461949, drop=0, errs=0,
    Port 2: rx pkts=0, bytes=0, drop=0, errs=0,
    tx pkts=0, bytes=0, drop=0, errs=0,
Total tables 1
  Table 0: classifier
    Wildcards = 0x3ffffff
    Max entries = 1000000
    Active entries = 0
    Number of lookups = 0
    Number of matches = 0
```

The following is sample output of the **show openflow switch 1 stats** command:

```
Device# show openflow switch 1 stats
Logical Switch Id: 1
Total ports: 1
    Port 4: rx pkts=8570, bytes=2459590, drop=0, errs=0,
    tx pkts=8585, bytes=2461949, drop=0, errs=0,
    Port 2: rx pkts=0, bytes=0, drop=0, errs=0,
    tx pkts=0, bytes=0, drop=0, errs=0,
Total tables: 1
  Table 0: classifier
```

```

Wildcards = 0x3ffffff
Max entries = 1500
Active entries = 0
Number of lookups = 0
Number of matches = 0

```

**Table 5: Field Description table for show openflow openflow\_agent switch 1 stats**

Field	Descriptions
Logical Switch Id: 1	Indicates the unique switch identifier.
Total ports: 1	Indicates the total number of ports defined for the switch.
Port: N	Indicates the port number.
rx pkts=0, bytes=0, errs=0	Indicates the number of packets and bytes received by the port and the number of errors generated while receiving data.
tx pkts=0, bytes=376480	Indicates number of packets and bytes sent by the port.
Total tables	Indicates the total number of tables defined for the device on the controller.
Table 0: classifier	Indicates the name of the table.
Wildcards	Indicates the wildcard character.
Max entries	Indicates the maximum number of flow entries defined in the table.
Active entries	Indicates the number of active flow entries in the table.
Number of lookups	Indicates the number of table lookups that have occurred.
Number of matches	Indicates the number of matches that have occurred for the flow entries in the table.

#### Related Commands

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode

# show openflow hardware capabilities

To display the match and action capabilities of a device, use the **show openflow hardware capabilities** command in privileged EXEC mode.

**show openflow hardware capabilities**

**Syntax Description** This command has no arguments or keywords.

**Command Modes** Privileged EXEC (#)

Command History	Release	Modification
	Cisco Plug-in for OpenFlow Release 1.0	This command was introduced.

**Usage Guidelines** This command displays the list of match and action capabilities supported on this device. The controller connected to this device can define flows using this match criteria and can associate actions to be executed when packets match the flow criteria. The match and action criteria supported for various devices are given below.

**Examples** The following is sample output for the **show openflow hardware capabilities** command.

The following is sample output for Nexus 3000 Series device.

Device# **show openflow hardware capabilities**

```

Pipeline ID: 201

Flow table ID: 0

Match Capabilities                               Match Types
-----
ethernet type                                    mandatory
VLAN ID                                          optional
VLAN priority code point                       optional
IP DSCP                                         optional
IP protocol                                     optional
IPv4 source address                           lengthmask
IPv4 destination address                     lengthmask
source port                                    optional
destination port                              optional
in port (virtual or physical)                 optional

Actions:
  output to: specified interface, use normal forwarding, controller
  set: set eth source mac, set eth destination mac, set vlan id
  pop: pop vlan tag
  other actions: drop packet

Pipeline ID: 202

```

**show openflow hardware capabilities**

```

Flow table ID: 0

Match Capabilities
-----
ethernet type
VLAN ID
VLAN priority code point
IP DSCP
IP protocol
IPv4 source address
IPv4 destination address
source port
destination port
in port (virtual or physical)

Match Types
-----
mandatory
optional
optional
optional
optional
lengthmask
lengthmask
optional
optional
optional

Actions:
  output to: specified interface, use normal forwarding, controller
  set: set eth source mac, set eth destination mac, set vlan id
  pop: pop vlan tag
  other actions: drop packet


Flow table ID: 1

Match Capabilities
-----
ethernet mac destination
VLAN ID

Match Types
-----
mandatory
mandatory

Actions:
  output to: specified interface
  other actions: drop packet

```

**Table 6: show openflow hardware capabilities Field Descriptions**

Command	Description
Pipeline ID	Pipeline to be configured for using the table.
Flow table ID	Table number in a logical switch.
Min Timer	Minimum time at which polling for statistics occurs.
Max Timer	Maximum time at which polling for statistics occurs.
Match Capabilities	Displays a list of match capabilities that can be defined for this device. The definitions of the different match criteria can be found in the OpenFlow 1.0 specification.
Match Types	Displays the type of match criteria. The match types and their meaning are as followed: <ul style="list-style-type: none"> <li>• required—This criteria must be defined for a flow.</li> <li>• optional—This criteria may be defined for a flow. It is optional.</li> <li>• prefix—This criteria is an IP prefix.</li> </ul>



Command	Description
Actions	<p>Displays a list of actions that can be defined for this device, if a packet matches the flow criteria. The actions can be as follows:</p> <ul style="list-style-type: none"> <li>• output to—Output the packet to the specified location.</li> <li>• set—Set the specified parameter for a packet.</li> <li>• pop—Remove the specified parameter for a packet.</li> <li>• other actions—Execute the specified action. The actions can be as follows: <ul style="list-style-type: none"> <li>◦ drop—Drop the packet.</li> </ul> </li> </ul>
Stats	Displays a list of parameters for which statistics are collected.
Others: packet out	Sending of packets to an output location (packet out) is supported by this Cisco Plug-in for OpenFlow.

**Related Commands**

Command	Description
<a href="#">hardware profile openflow</a>	Enables support and allocates resources for Cisco Plug-in for OpenFlow VLAN tagging actions on the device hardware.

## switch (OpenFlow)

To configure Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode, use the **switch** command in Cisco Plug-in for OpenFlow Release configuration mode. To remove the Cisco Plug-in for OpenFlow logical switch configurations, use the **no** form of this command.

**switch** *logical-switch-id*

**no switch** *logical-switch-id*

### Syntax Description

<i>logical-switch-id</i>	Specifies a numerical ID for the logical switch.
	<ul style="list-style-type: none"> <li>Only logical switch ID 1 is supported.</li> </ul>

### Command Default

Cisco Plug-in for OpenFlow logical switch is not defined.

### Command Modes

Cisco Plug-in for OpenFlow Release configuration (config-ofa)

### Command History

Release	Modification
Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

### Examples

The following example describes how the **switch** command is used in configuring Cisco Plug-in for OpenFlow logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# controller ipv4 10.1.0.6
Device(config-ofa-switch)# interface ethernet1/1
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

### Related Commands

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.
<a href="#">of-port interface (OpenFlow)</a>	Configures an interface as a port of an Cisco Plug-in for OpenFlow logical switch
<a href="#">openflow</a>	Configures Cisco Plug-in for OpenFlow.

Command	Description
<a href="#">switch (OpenFlow)</a>	Configures Cisco Plug-in for OpenFlow logical switch used for Layer 2 switching and enter logical switch configuration mode
<a href="#">max-backoff</a>	Configures an interval for which Cisco Plug-in for OpenFlow logical switch must wait before retrying a connection to the controller.
<a href="#">tls trust-point</a>	Configures local and remote trust points needed for a Transport Layer Security (TLS) connection to the controller
<a href="#">probe-interval</a>	Configures an interval that Cisco Plug-in for OpenFlow logical switch waits before sending a probe to query an idle connection to controller.
<a href="#">pipeline</a>	Configures a pipeline.
<a href="#">rate-limit</a>	Configures the rate at which packets are sent to a controller by Cisco Plug-in for OpenFlow logical switch.

# shutdown (OpenFlow)

To disable an Cisco Plug-in for OpenFlow logical switch, use the **shutdown** command in logical switch configuration mode. To re-enable the Cisco Plug-in for OpenFlow logical switch, use the **no** form of this command.

**shutdown**

**no shutdown**

**Syntax Description** This command has no arguments or keywords.

**Command Default** The Cisco Plug-in for OpenFlow logical switch is enabled.

**Command Modes** Logical switch configuration (config-ofa-switch)

Command History	Release	Modification
	Cisco Plug-in for OpenFlow Version 1.0	This command was introduced.

**Examples** The following example describes how the **shutdown** command is used to disable an Cisco Plug-in for OpenFlow logical switch.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# shutdown
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

## tls trust-point

To configure local and remote trust points needed for a Transport Layer Security (TLS) connection to the controller, use the **tls trust-point** command in logical switch configuration mode.

**tls trust-point local** *local-trust-point-name* **remote** *remote-trust-point-name*

**no tls trust-point local** *local-trust-point-name* **remote** *remote-trust-point-name*

### Syntax Description

<b>local</b> <i>local-trust-point-name</i>	Configures the local trust point.
<b>remote</b> <i>remote-trust-point-name</i>	Configures the remote trust point.

### Command Default

TLS is enabled for controller connections, but TLS trust points are not configured.

### Command Modes

Logical switch configuration (config-ofa-switch)

### Command History

Release	Modification
Cisco Plug-in for OpenFlow Release 1.1	This command was introduced.

### Usage Guidelines

This command does not set up the TLS connection and only configures the trust points.

If this command is not configured, TLS must be disabled in order for the controller connection to work using the **no-tls** keyword of the **controller** command. Otherwise the controller connection fails.

### Examples

The following example shows how the **tls trust-point** command is used to configure a TLS connection to a controller.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# controller ipv4 10.1.1.1
Device(config-ofa-switch)# tls trust-point local XXX remote YYY
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

The following example shows how TLS must be disabled if the **tls trust-point** command is not used.

```
Device> enable
Device# configure terminal
Device(config)# openflow
Device(config-ofa)# switch 1
Device(config-ofa-switch)# controller ipv4 10.1.1.1 security none
Device(config-ofa-switch)# end
Device# copy running-config startup-config
```

**Related Commands**

Command	Description
<a href="#">controller</a>	Configure a controller for an Cisco Plug-in for OpenFlow.