show access-group mode interface

To display the ACL configuration on a Layer 2 interface, use the **show access-group mode interface** command.

show access-group mode interface [interface interface-number]

Syntax Description	interface	(Optional) Interface type; valid values are ethernet , fastethernet ,	
	0	gigabitethernet, tengigabitethernet, and port-channel.	
	interface-number	(Optional) Interface number.	
Defaults	This command has	no default settings.	
Command Modes	Privileged EXEC		
Command History	Release	Modification	
	12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch.	
	12.2(25)EW	Support for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 series switch.	
Usage Guidelines	The valid values for	r the port number depend on the chassis used.	
xamples	This example shows how to display the ACL configuration on the Fast Ethernet interface 6/1:		
	Switch# show acce Interface FastEth Access group m Switch#		
Related Commands	access-group mode	e	

show adjacency

To display information about the Layer 3 switching adjacency table, use the show adjacency command.

Syntax Description	interface	(Optional) Interface type; possible valid values are ethernet , fastethernet , gigabitethernet , tengigabitethernet , pos , ge-wan , and atm .
	interface-number	(Optional) Module and port number; see the "Usage Guidelines" section for valid values.
	null interface-number	(Optional) Specifies the null interface; the valid value is 0 .
	port-channel number	(Optional) Specifies the channel interface; valid values are a maximum of 64 values ranging from 1 to 256.
	vlan vlan-id	(Optional) Specifies the VLAN; valid values are from 1 to 4094.
	detail	(Optional) Displays the information about the protocol detail and timer.
	internal	(Optional) Displays the information about the internal data structure.
	summary	(Optional) Displays a summary of CEF-adjacency information.
Defaults	This command has	s no default settings.
Command Modes	EXEC	
		Nodification
	Release	Modification Extended to include the 10-Gigabit Ethernet interface.
Command History	Release I 12.2(25)EW I	Extended to include the 10-Gigabit Ethernet interface.
	ReleaseI12.2(25)EWIThe interface-numinterface-numberexample, if you spthat is installed in a	
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you spetthat is installed in afor the port number	Extended to include the 10-Gigabit Ethernet interface. <i>There argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid values</i>
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you specthat is installed in afor the port numberHardware Layer 3	Extended to include the 10-Gigabit Ethernet interface. <i>Eber</i> argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid value er are from 1 to 48. switching adjacency statistics are updated every 60 seconds.
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you spthat is installed in afor the port numberHardware Layer 3The following info	Extended to include the 10-Gigabit Ethernet interface. <i>Eber</i> argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid value er are from 1 to 48. switching adjacency statistics are updated every 60 seconds. prmation is contained in the show adjacency command:
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you spetthat is installed in afor the port numberHardware Layer 3The following info• Protocol interface	Extended to include the 10-Gigabit Ethernet interface. <i>aber</i> argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid value er are from 1 to 48. switching adjacency statistics are updated every 60 seconds. prmation is contained in the show adjacency command: face.
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you specthat is installed in afor the port numberHardware Layer 3The following infor• Protocol interface• Type of routing	Extended to include the 10-Gigabit Ethernet interface. Extended to include the 10-Gigabit Ethernet interface. Ether argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid value er are from 1 to 48. switching adjacency statistics are updated every 60 seconds. prmation is contained in the show adjacency command: face. ag protocol that is configured on the interface.
Command History	ReleaseI12.2(25)EWIThe interface-numberinterface-numberexample, if you spthat is installed in afor the port numberHardware LayerHardware LayerThe following info• Protocol inter• Type of routin• Interface addr	Extended to include the 10-Gigabit Ethernet interface. Extended to include the 10-Gigabit Ethernet interface. Ether argument designates the module and port number. Valid values for depend on the specified interface type and the chassis and module that are used. For ecify a Gigabit Ethernet interface and have a 48-port 10/100BASE-T Ethernet modul a 13-slot chassis, valid values for the module number are from 1 to 13, and valid value er are from 1 to 48. switching adjacency statistics are updated every 60 seconds. prmation is contained in the show adjacency command: face. ag protocol that is configured on the interface.

- MAC address of the adjacent router.
- Time left before the adjacency rolls out of the adjacency table. After it rolls out, a packet must use the same next hop to the destination.

Examples

This example shows how to display adjacency information:

Switch# show adjacency				
Protocol	Interface	Address		
IP	FastEthernet2/3	172.20.52.1(3045)		
IP	FastEthernet2/3	172.20.52.22(11)		
Switch#				

This example shows how to display a summary of adjacency information:

```
Switch# show adjacency summary
Adjacency Table has 2 adjacencies
Interface Adjacency Count
FastEthernet2/3 2
Switch#
```

This example shows how to display protocol detail and timer information:

```
Switch# show adjacency detail
Protocol Interface
                             Address
ΙP
       FastEthernet2/3
                             172.20.52.1(3045)
                             0 packets, 0 bytes
                             00000000FF92000038000000000000
                             00605C865B2800D0BB0F980B0800
                                      03:58:12
                             ARP
ΙP
       FastEthernet2/3
                             172.20.52.22(11)
                             0 packets, 0 bytes
                             00000000FF92000038000000000000
                             00801C93804000D0BB0F980B0800
                             ARP
                                      03:58:06
```

Switch#

This example shows how to display adjacency information for a specific interface:

Switch# #	show adjacency fastetherne	t2/3
Protocol	Interface	Address
IP	FastEthernet2/3	172.20.52.1(3045)
IP	FastEthernet2/3	172.20.52.22(11)
Switch#		

Related Commands debug adjacency

Γ

show arp access-list

To display detailed information on an ARP access list, use the show arp command.

show arp access-list

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes EXEC

 Command History
 Release
 Modification

 12.1(19)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display the ARP ACL information for a switch:

Switch# **show arp access-list** ARP access list rose permit ip 10.101.1.1 0.0.0.255 mac any

permit ip 20.3.1.0 0.0.0.255 mac any

Related Commands access-group mode arp access-list ip arp inspection filter vlan

show auto install status

To display the status of an automatic installation, use the show auto install status command.

show auto install status

Syntax Description	This command h	has no arguments or keywords.
Defaults	This command l	nas no default settings.
Command Modes	Privileged EXE	C
Command History	Release	Modification
	12.2(20)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Examples	switch is curren	nows how to display the IP address of the TFTP server and to display whether or not the tly acquiring the configuration file on the TFTP server:

Switch# show auto install status

Status	:	Downloading config file
DHCP Server	:	20.0.0.1
TFTP Server	:	30.0.3
Config File Fetched	:	Undetermined

The first IP address in the display indicates the server that is used for the automatic installation. The second IP address indicates the TFTP server that provided the configuration file.

show auto qos

To display the automatic quality of service (auto-QoS) configuration that is applied, use the **show auto qos** user EXEC command.

show auto qos [interface [interface-id]] [{begin | exclude | include} expression]

Syntax Description		
Syntax Description	interface <i>interface-id</i> (Optional) Displays auto-QoS information for the specified interface for all interfaces. Valid interfaces include physical ports.	
	begin	(Optional) Begins with the line that matches the expression.
	exclude	(Optional) Excludes lines that match the expression.
	include	(Optional) Includes lines that match the specified expression.
	expression	(Optional) Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Usage Guidelines	-	rface <i>interface-id</i> command displays the auto-QoS configuration; it does not s to the configuration that might be in effect.
	To display information al commands:	bout the QoS configuration that might be affected by auto-QoS, use one of these
	• show qos	
	show qosshow qos map	
	•	interface-id
	 show qos map 	

Examples

This example shows output from the **show auto qos** command when auto-QoS is enabled:

```
Switch# show auto gos
00:00:55:qos
00:00:56:qos map cos 3 to dscp 26
00:00:57:gos map cos 5 to dscp 46
00:00:58:qos map dscp 16 to tx-queue 1
00:00:58:qos map dscp 32 to tx-queue 1
00:00:58:qos dbl
00:00:59:policy-map autoqos-voip-policy
00:00:59: class class-default
00:00:59:
           dbl
00:00:59:interface GigabitEthernet1/1
00:00:59: qos trust device cisco-phone
00:00:59: gos trust cos
00:00:59: tx-queue 3
00:00:59: priority high
00:00:59: shape percent 70
00:00:59: service-policy output autoqos-voip-policyend
```

This example shows output from the **show auto qos interface** command when the **auto qos voip cisco-phone** interface configuration command is entered:

```
Switch# show auto gos interface
Initial configuration applied by AutoQoS:
I.
interface GigabitEthernet1/1
gos trust device cisco-phone
qos trust cos
tx-queue 3
priority high
shape percent 70
service-policy output autoqos-voip-policy
1
interface GigabitEthernet1/2
gos trust device cisco-phone
gos trust cos
tx-queue 3
priority high
shape percent 70
service-policy output autoqos-voip-policy
```

This example shows output from the **show auto qos interface gigabitethernet1/1** command when the **auto qos voip cisco-phone** interface configuration command is entered:

```
Switch# show auto qos interface gigabitethernet1/1
Initial configuration applied by AutoQoS:
!
interface GigabitEthernet1/1
qos trust device cisco-phone
qos trust cos
tx-queue 3
priority high
shape percent 70
service-policy output autoqos-voip-policy
```

This example shows output from the **show auto qos** command when auto-QoS is disabled:

```
Switch# show auto qos
AutoQoS is disabled
```

Related Commands auto gos voip

show bootflash:

To display information about the bootflash: file system, use the show bootflash: command.

show bootflash: [all | chips | filesys]

```
Syntax Description
                   all
                               (Optional) Displays all possible Flash information.
                   chips
                               (Optional) Displays Flash chip information.
                   filesys
                               (Optional) Displays file system information.
Defaults
                   This command has no default settings.
Command Modes
                   EXEC
Command History
                                   Modification
                   Release
                   12.1(8a)EW
                                   Support for this command was introduced on the Catalyst 4500 series switch.
Examples
                   This example shows how to display file system status information:
                   Switch> show bootflash: filesys
                   ----- FILE SYSTEM STATUS ------
                     Device Number = 0
                   DEVICE INFO BLOCK: bootflash
                     Magic Number
                                          = 6887635 File System Vers = 10000
                                                                                  (1.0)
                                          = 1000000 Sector Size = 40000
                     Length
                                                                       = FFFFFFFF
                     Programming Algorithm = 39
                                                      Erased State
                     File System Offset = 40000
                                                      Length = F40000
                     MONLIB Offset
                                         = 100
                                                    Length = C628
                     Bad Sector Map Offset = 3FFF8
                                                     Length = 8
                     Squeeze Log Offset = F80000
                                                    Length = 40000
                     Squeeze Buffer Offset = FC0000
                                                      Length = 40000
                     Num Spare Sectors
                                       = 0
                       Spares:
                   STATUS INFO:
                     Writable
                     NO File Open for Write
                     Complete Stats
                     No Unrecovered Errors
                     No Squeeze in progress
                   USAGE INFO:
                                   = 917CE8 Bytes Available = 628318
                     Bvtes Used
                     Bad Sectors = 0
                                             Spared Sectors = 0
                     OK Files
                                   = 2
                                             Bytes = 917BE8
                     Deleted Files = 0
                                             Bytes = 0
                     Files w/Errors = 0
                                             Bytes = 0
                   Switch>
```

This example shows how to display system image information:

```
Switch> show bootflash:

-# - ED --type-- --crc--- -seek-- nlen -length- -----date/time----- name

1 .. image 8C5A393A 237E3C 14 2063804 Aug 23 1999 16:18:45 c4-boot-mz

2 .. image D86EE0AD 957CE8 9 7470636 Sep 20 1999 13:48:49 rp.halley

Switch>
```

This example shows how to display all bootflash information:

```
Switch> show bootflash: all
-# - ED --type-- --crc--- seek-- nlen -length- -----date/time----- name
1 .. image
             8C5A393A 237E3C 14 2063804 Aug 23 1999 16:18:45 c4-boot-
mz
2 .. image
             D86EE0AD 957CE8 9 7470636 Sep 20 1999 13:48:49 rp.halley
6456088 bytes available (9534696 bytes used)
-----FILE SYSTEM STATUS------
 Device Number = 0
DEVICE INFO BLOCK: bootflash
 Magic Number
                    = 6887635 File System Vers = 10000
                                                         (1.0)
                     = 1000000 Sector Size = 40000
 Length
 Programming Algorithm = 39 Erased State
                                                = FFFFFFFF
 File System Offset = 40000 Length = F40000
                    = 100 \qquad \text{Length} = C628
 MONLIB Offset
 Bad Sector Map Offset = 3FFF8
                                Length = 8
  Squeeze Log Offset = F80000
                                 Length = 40000
  Squeeze Buffer Offset = FC0000 Length = 40000
 Num Spare Sectors
                   = 0
   Spares:
STATUS INFO:
 Writable
 NO File Open for Write
 Complete Stats
 No Unrecovered Errors
 No Squeeze in progress
USAGE INFO:
            = 917CE8 Bytes Available = 628318
 Bytes Used
 Bad Sectors = 0 Spared Sectors = 0
           = 2
                       Bytes = 917BE8
 OK Files
 Deleted Files = 0 Bytes = 0
Files w/Errors = 0 Bytes = 0
Switch>
```

show bootvar

To display BOOT environment variable information, use the show bootvar command.

show bootvar

Syntax Description	This command has no arguments or keywords.
--------------------	--

- **Defaults** This command has no default settings.
- **Command Modes** Privileged EXEC

 Release
 Modification

 12.1(8a)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display BOOT environment variable information:

Switch# show bootvar BOOT variable = sup:1; CONFIG_FILE variable does not exist BOOTLDR variable does not exist Configuration register is 0x0 Switch#

show cable-diagnostics tdr

To display the test results for the TDR cable diagnostics, use the show cable-diagnostics tdr command.

show cable-diagnostics tdr {interface {interface interface-number}}

Note	This command will command.	ll be deprecated in future Cisco IOS releases. Please use the diagnostic start				
Syntax Description	interface interfac	<i>e</i> Interface type; valid values are fastethernet and gigabitethernet .				
	interface-number	Module and port number.				
Defaults	This command has	s no default settings.				
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.2(25)SG	Support for this command was introduced on the Catalyst 4500 series switch.				
Usage Guidelines	the following lineWS-X4548-G	B-RJ45				
	• WS-X4548-G					
	• WS-X4524-G					
	WS-X4013+TWS-C4948	5				
	• WS-C4948-10)GE				
		e fault is displayed in meters (m).				
Examples	This example show	This example shows how to display information about the TDR test:				
	a	le-diagnostics tdr interface gi4/13				

Switch#

Table 2-13 describes the fields in the show cable-diagnostics tdr command output.

Field	Description
Interface	Interface tested.
Speed	Current line speed.
Pair	Local pair name.
Cable Length	Distance to the fault in meters (m).
Channel	Pair designation (A, B, C, or D).
Status	Pair status displayed is one of the following:
	• Terminated—The link is up.
	• Fault—Cable fault (open or short)

Table 2-13 show cable-diagnostics tdr Command Output Fields

Related Commands test cable-diagnostics tdr

show cdp neighbors

To display detailed information about the neighboring devices that are discovered through CDP, use the **show cdp neighbors** command.

show cdp neighbors [type number] [detail]

Syntax Description	type	(Optional) Interfact want information; gigabitethernet, to	possible valio	d values are et	hernet, fas	
	number	(Optional) Interfac you want informat		t is connected	to the neig	hbors about which
	detail	(Optional) Display including network version.			-	-
Defaults	This command h	as no default settings				
Command Modes	Privileged EXEC	2				
Command History	Release	Modification				
	12.2(25)EW	Extended to include	the 10-Gigal	bit Ethernet in	terface.	
Usage Guidelines	The vlan keywor Engine II.	d is supported in Cat	alyst 4500 se	eries switches	that are con	figured with a Supervise
	The port-channel values are from 0 to 282; values from 257 to 282 are supported on the CSM and the FWSM only.					
Examples	This example sh	ows how to display th	e informatio	n about the CI	OP neighbor	rs:
Examples	This example she Switch# show co		ne informatio	n about the CI	DP neighbor	rs:
Examples	Switch# show co		Trans Brid	ge, B - Sourc	ce Route Bi	ridge
Examples	Switch# show co Capability Code Device ID	lp neighbors es: R - Router, T - S - Switch, H - Local Intrfce	Trans Brid Host, I - Holdtme	ge, B - Sourc IGMP, r - Reg Capability	ce Route Br peater, P - Platform	ridge – Phone Port ID
Examples	Switch# show co Capability Code Device ID lab-7206	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0</pre>	Trans Brid Host, I - Holdtme 157	ge, B - Sourc IGMP, r - Reg Capability R	ce Route B peater, P - Platform 7206VXR	ridge - Phone Port ID Fas 0/0/0
Examples	Switch# show co Capability Code Device ID lab-7206 lab-as5300-1	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0 Eth 0 Eth 0</pre>	Trans Brid Host, I - Holdtme 157 163	ge, B - Sourc IGMP, r - Rep Capability R R R	ce Route Br peater, P - Platform 7206VXR AS5300	ridge - Phone Port ID Fas 0/0/0 Fas 0
Examples	Switch# show co Capability Code Device ID lab-7206 lab-as5300-1 lab-as5300-2	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0 Eth 0 Eth 0 Eth 0</pre>	Trans Brid Host, I - Holdtme 157 163 159	ge, B - Sourc IGMP, r - Reg Capability R R R R	ce Route Br peater, P - Platform 7206VXR AS5300 AS5300	ridge - Phone Port ID Fas 0/0/0 Fas 0 Eth 0
Examples	Switch# show co Capability Code Device ID lab-7206 lab-as5300-1 lab-as5300-2 lab-as5300-3	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0 Eth 0 Eth 0 Eth 0 Eth 0 Eth 0</pre>	Trans Brid Host, I - Holdtme 157 163 159 122	ge, B - Sourc IGMP, r - Rep Capability R R R R R R	ce Route Br peater, P - Platform 7206VXR AS5300 AS5300 AS5300	ridge - Phone Port ID Fas 0/0/0 Fas 0 Eth 0 Eth 0
Examples	Switch# show co Capability Code Device ID lab-7206 lab-as5300-1 lab-as5300-2 lab-as5300-3 lab-as5300-4	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0 Eth 0</pre>	Trans Brid Host, I - Holdtme 157 163 159 122 132	ge, B - Sourc IGMP, r - Rep Capability R R R R R R R R	ce Route Br peater, P - Platform 7206VXR AS5300 AS5300 AS5300 AS5300	ridge - Phone Port ID Fas 0/0/0 Fas 0 Eth 0 Eth 0 Fas 0/0
Examples	Switch# show co Capability Code Device ID lab-7206 lab-as5300-1 lab-as5300-2 lab-as5300-3	<pre>hp neighbors s: R - Router, T - S - Switch, H - Local Intrfce Eth 0 Eth 0 Eth 0 Eth 0 Eth 0 Eth 0</pre>	Trans Brid Host, I - Holdtme 157 163 159 122	ge, B - Sourc IGMP, r - Rep Capability R R R R R R	ce Route Br peater, P - Platform 7206VXR AS5300 AS5300 AS5300	ridge - Phone Port ID Fas 0/0/0 Fas 0 Eth 0 Eth 0 Fas 0/0

Table 2-14 describes the fields that are shown in the example.

Field	Definition
Device ID	Configured ID (name), MAC address, or serial number of the neighbor device.
Local Intrfce	(Local Interface) The protocol that is used by the connectivity media.
Holdtme	(Holdtime) Remaining amount of time, in seconds, that the current device holds the CDP advertisement from a transmitting router before discarding it.
Capability	Capability code that is discovered on the device. This device type is listed in the CDP Neighbors table. Possible values are as follows:
	R—Router
	T—Transparent bridge
	B—Source-routing bridge
	S—Switch
	H—Host
	I—IGMP device
	r—Repeater
	P—Phone
Platform	Product number of the device.
Port ID	Protocol and port number of the device.

Table 2-14show cdp neighbors Field Descriptions

This example shows how to display detailed information about your CDP neighbors:

```
Switch# show cdp neighbors detail
_____
Device ID: lab-7206
Entry address(es):
 IP address: 172.19.169.83
Platform: cisco 7206VXR, Capabilities: Router
Interface: Ethernet0, Port ID (outgoing port): FastEthernet0/0/0
Holdtime : 123 sec
Version :
Cisco Internetwork Operating System Software
IOS (tm) 5800 Software (C5800-P4-M), Version 12.1(2)
Copyright (c) 1986-2002 by Cisco Systems, Inc.
advertisement version: 2
Duplex: half
_____
Device ID: lab-as5300-1
Entry address(es):
 IP address: 172.19.169.87
.
Switch#
```

Table 2-15 describes the fields that are shown in the example.

Field	Definition
Device ID	Name of the neighbor device and either the MAC address or the serial number of this device.
Entry address(es)	List of network addresses of neighbor devices.
[network protocol] address	Network address of the neighbor device. The address can be in IP, IPX, AppleTalk, DECnet, or CLNS protocol conventions.
Platform	Product name and number of the neighbor device.
Capabilities	Device type of the neighbor. This device can be a router, a bridge, a transparent bridge, a source-routing bridge, a switch, a host, an IGMP device, or a repeater.
Interface	Protocol and port number of the port on the current device.
Holdtime	Remaining amount of time, in seconds, that the current device holds the CDP advertisement from a transmitting router before discarding it.
Version:	Software version running on the neighbor device.
advertisement version:	Version of CDP that is being used for CDP advertisements.
Duplex:	Duplex state of connection between the current device and the neighbor device.

Table 2-15show cdp neighbors detail Field Descriptions

Related Commands

show cdp (refer to Cisco IOS documentation)
show cdp entry (refer to Cisco IOS documentation)
show cdp interface (refer to Cisco IOS documentation)
show cdp traffic (refer to Cisco IOS documentation)

show class-map

To display class map information, use the show class-map command.

show class-map class_name

Syntax Description		Nome of the alo				
Syntax Description	class_name	Name of the clas	ss map.			
Defaults	This command	has no default set	tings.			
Command Modes	Privileged EXE	С				
	U					
Command History	Release	Modification				
Command motory	12.1(8a)EW		is comm	and was intr	oduced on the	e Catalyst 4500 series switch.
	12.2(25)SG	Displays resul				
						-
Examples	This axample sh	nows how to displ	av close	man inform	ation for all a	lass mans:
Examples	-	-	ay class	map mitorm		lass maps.
	Switch# show c Class Map mat	: lass-map .ch-any class-de	fault (id 0)		
	Match any	ch-any class-si	mole (i	4 2)		
	Match any	chi-any class-si	шрте (т	u 2)		
	Class Map mat Match ip pr	ch-all ipp5 (id	1)			
		ch-all agg-2 (i	d 3)			
	Switch#					
	This example sh	nows how to displ	ay class	map inform	ation for a spe	ecific class map:
	Switch# show c					
	Class Map mat Match ip pr	ch-all ipp5 (id recedence 5	11)			
	Switch#					
	Assume there as	re two active flow	's as sho	wn below or	n Fast Etherne	t interface 6/1:
	SrcIp	DstIp	IpProt	SrcL4Port	DstL4Port	
		192.168.20.20	20	6789	81	
	192.168.10.10	192.168.20.20	20	6789	21	
	With following burst value.	configuration, eac	ch flow y	will be polic	ed to a 10000	00 bps with an allowed 9000-byte
Note	If you use the n	natch flow ip sou	rce-add	ressldestina	tion-address	command, these two flows are

consolidated into one flow and they have the same source and destination address.

```
Switch# config terminal
Enter configuration commands, one per line. End with \ensuremath{\texttt{CNTL}}/\ensuremath{\texttt{Z}}.
Switch(config) # class-map c1
Switch(config-cmap)# match flow ip source-address ip destination-address ip protocol 14
source-port 14 destination-port
Switch(config-cmap)# exit
Switch(config) # policy-map p1
Switch(config-pmap)# class c1
Switch(config-pmap-c)# police 1000000 9000
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
Switch(config)# interface fastEthernet 6/1
Switch(config-if)# service-policy input p1
Switch(config-if) # end
Switch# write memory
Switch# show policy-map interface
FastEthernet6/1
class-map c1
   match flow ip source-address ip destination-address ip protocol 14 source-port 14
destination-port
1
policy-map p1
    class c1
       police 1000000 bps 9000 byte conform-action transmit exceed-action drop
I.
interface FastEthernet 6/1
 service-policy input p1
Switch# show class-map c1
Class Map match-all c1 (id 2)
   Match flow ip source-address ip destination-address ip protocol 14 source-port 14
destination-port
Switch#
```

Related Commands

class-map show policy-map show policy-map interface

show diagnostic content

To display test information about the test ID, test attributes, and supported coverage test levels for each test and for all modules, use the **show diagnostic content** command.

show diagnostic content module {**all** | *num*}

Syntax Description	all	Displays all the modules on the chassis.
-,	num	Module number.
Defaults	This command h	as no default settings.
Command Modes	EXEC	
Command History	Release	Modification
	12.2(20)EWA	Support for this command was introduced on the Catalyst 4500 series switch.
Examples	<pre>modules of the c Switch# show d: module 1: Diagnostics te B/* - Bas: P/V/* - Per D/N/* - Diss S/* - Only X/* - Not F/* - Fixe E/* - Alwa A/I - Mon: m/* - Mana</pre>	<pre>iagnostic content module all est suite attributes: ic ondemand test / NA port test / Per device test / NA ruptive test / Non-disruptive test / NA y applicable to standby unit / NA a health monitoring test / NA ed monitoring interval test / NA ays enabled monitoring test / NA itoring is active / Monitoring is inactive datory bootup test, can't be bypassed / NA</pre>
	ID Test Name	ping test, always active / NA Testing Interval e Attributes (day hh:mm:ss.ms)
	2) packet-me	or-bootup> **D****I** not configured emory-bootup> **D****I** not configured emory-ongoing> **N****I*0 not configured

module 6: Diagnostics test suite attributes: B/* - Basic ondemand test / NA P/V/* - Per port test / Per device test / NA D/N/* - Disruptive test / Non-disruptive test / NA $\mathrm{S/*}$ - Only applicable to standby unit / NA $\ensuremath{\mathbb{X}}\xspace/*$ – Not a health monitoring test / NA F/* - Fixed monitoring interval test / NA ${\rm E}/{\rm *}$ - Always enabled monitoring test / NA A/I - Monitoring is active / Monitoring is inactive $\ensuremath{\texttt{m}}\xspace \star$ - Mandatory bootup test, can't be by passed / NA o/* - Ongoing test, always active / NA Testing Interval (day hh:mm:ss.ms) ID Test Name Attributes ____ ______ 1) linecard-online-diag -----> **D****I** not configured Switch#

Related Commands show diagnostic result module show diagnostic result module test 2 show diagnostic result module test 3

show diagnostic result module

To display the module-based diagnostic test results, use the show diagnostic result module command.

show diagnostic result module [slot-num | all] [test [test-id | test-id-range | all]] [detail]

Syntax Description	slot-num	(Optional) Specifies the slot on which diagnostics are displayed.
	all	(Optional) Displays the diagnostics for all slots.
	test	(Optional) Displays selected tests on the specified module.
	test-id	(Optional) Specifies a single test ID.
	test-id-range	(Optional) Specifies a range of test IDs.
	all	(Optional) Displays the diagnostics for all tests.
	detail	(Optional) Displays the complete test results.
Defaults	A summary of t	he test results for all modules in the chassis is displayed.
command Modes	Privileged EXE	C
Command History	Release	Modification
	12.2(18)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	Switch# show d	iagnostic result module
	Current bootup	diagnostic level: minimal
	module 1:	
		nostic result: PASS evel at card bootup: bypass
	Test results	: (. = Pass, F = Fail, U = Untested)
	2) packet-	sor-bootup> U memory-bootup> U memory-ongoing> U
	module 4:	
	-	nostic result: PASS evel at card bootup: minimal
	Test results	: (. = Pass, F = Fail, U = Untested)
	1) linecar	d-online-diag> .

```
module 5:
Overall diagnostic result: PASS
Diagnostic level at card bootup: minimal
Test results: (. = Pass, F = Fail, U = Untested)
1) linecard-online-diag -----> .
```

```
module 6:
```

```
Overall diagnostic result: PASS
Diagnostic level at card bootup: minimal
Test results: (. = Pass, F = Fail, U = Untested)
1) linecard-online-diag -----> .
```

This example shows how to display the online diagnostics for module 1:

```
Switch# show diagnostic result module 1 detail
```

Current bootup diagnostic level: minimal

module 1:

Overall diagnostic result: PASS Diagnostic level at card bootup: minimal

Test results: (. = Pass, F = Fail, U = Untested)

1) supervisor-bootup -----> .

```
Error code ------> 0 (DIAG_SUCCESS)
Total run count ------> 0
Last test execution time -----> n/a
First test failure time -----> n/a
Last test failure time -----> n/a
Last test pass time -----> n/a
Total failure count -----> 0
Consecutive failure count -----> 0
```

Power-On-Self-Test Results for ACTIVE Supervisor

```
Power-on-self-test for Module 1: WS-X4014
Port/Test Status: (. = Pass, F = Fail)
Reset Reason: PowerUp Software/User
```

```
      Port Traffic: L2 Serdes Loopback ...

      0: . 1: . 2: . 3: . 4: . 5: . 6: . 7: . 8: . 9: . 10: . 11: .

      12: . 13: . 14: . 15: . 16: . 17: . 18: . 19: . 20: . 21: . 22: . 23: .

      24: . 25: . 26: . 27: . 28: . 29: . 30: . 31: .
```

```
Port Traffic: L2 Asic Loopback ...
0: . 1: . 2: . 3: . 4: . 5: . 6: . 7: . 8: . 9: . 10: . 11: .
12: . 13: . 14: . 15: . 16: . 17: . 18: . 19: . 20: . 21: . 22: . 23: .
24: . 25: . 26: . 27: . 28: . 29: . 30: . 31: .
Port Traffic: L3 Asic Loopback ...
0: . 1: . 2: . 3: . 4: . 5: . 6: . 7: . 8: . 9: . 10: . 11: .
12: . 13: . 14: . 15: . 16: . 17: . 18: . 19: . 20: . 21: . 22: . 23: .
24: . 25: . 26: . 27: . 28: . 29: . 30: . 31: . au: .
Switch Subsystem Memory ...
1: . 2: . 3: . 4: . 5: . 6: . 7: . 8: . 9: . 10: . 11: . 12: .
13: . 14: . 15: . 16: . 17: . 18: . 19: . 20: . 21: . 22: . 23: . 24: .
25: . 26: . 27: . 28: . 29: . 30: . 31: . au: .
25: . 26: . 27: . 28: . 29: . 30: . 31: . 32: . 33: . 34: . 35: . 36: .
37: . 38: . 39: . 40: . 41: . 42: . 43: . 44: . 45: . 46: . 47: . 48: .
49: . 50: . 51: . 52: . 53: . 54: .
```

Module 1 Passed

2) packet-memory-bootup -----> .

```
Error code ------> 0 (DIAG_SUCCESS)

Total run count ------> 0

Last test execution time -----> n/a

First test failure time -----> n/a

Last test failure time -----> n/a

Last test pass time -----> n/a

Total failure count -----> 0

Consecutive failure count -----> 0

packet buffers on free list: 64557 bad: 0 used for ongoing tests: 979
```

```
Number of errors found: 0
Cells with hard errors (failed two or more tests): 0
Cells with soft errors (failed one test, includes hard): 0
Suspect bad cells (uses a block that tested bad): 0
total buffers: 65536
bad buffers: 0 (0.0%)
good buffers: 65536 (100.0%)
Bootup test results:1
No errors.
```

3) packet-memory-ongoing -----> U

```
Error code ------> 0 (DIAG_SUCCESS)

Total run count ------> 0

Last test execution time -----> n/a

First test failure time -----> n/a

Last test failure time -----> n/a

Last test pass time -----> n/a

Total failure count -----> 0

Consecutive failure count -----> 0

packet buffers on free list: 64557 bad: 0 used for ongoing tests: 979
```

```
Packet memory errors: 0 0
Current alert level: green
Per 5 seconds in the last minute:
   0 0 0 0 0 0 0 0 0 0
   0 0
Per minute in the last hour:
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
Per hour in the last day:
   0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0
Per day in the last 30 days:
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
Direct memory test failures per minute in the last hour:
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
   0 0 0 0 0 0 0 0 0 0
Potential false positives: 0 0
 Ignored because of rx errors: 0 0
 Ignored because of cdm fifo overrun: 0 0
 Ignored because of oir: 0 0
 Ignored because isl frames received: 0 0
 Ignored during boot: 0 0
 Ignored after writing hw stats: 0 0
 Ignored on high gigaport: 0
Ongoing diag action mode: Normal
Last 1000 Memory Test Failures:
Last 1000 Packet Memory errors:
First 1000 Packet Memory errors:
```

Switch#

show diagnostic result module test

To display the results of the bootup packet memory test, use the **show diagnostic result module test** command. The output indicates whether the test passed, failed, or was not run.

show diagnostic result module [N | all] [test test-id] [detail]

Syntax Description	N	Specifies the module number.
	all	Specifies all modules.
	test test-id	Specifies the number for the tdr test on the platform.
	detail	(Optional) Specifies the display of detailed information for analysis.
		This option is recommended.
Defaults	Non-detailed results	
Command Modes	EXEC mode	
Command History	Release	Modification
Usage Guidelines	12.2(25)SG The detail keyword is	This command was introduced on the Catalyst 4500 series switch.
	The detail keyword is This example shows h	
Usage Guidelines Examples	The detail keyword is This example shows h	s intended for use by Cisco support personnel when analyzing failures. now to display the results of the bootup packet memory tests:
	The detail keyword is This example shows h Switch# show diagne	s intended for use by Cisco support personnel when analyzing failures. now to display the results of the bootup packet memory tests: pstic result module 6 detail
	The detail keyword is This example shows h Switch# show diagno module 6: Overall diagnosti	s intended for use by Cisco support personnel when analyzing failures. now to display the results of the bootup packet memory tests: pstic result module 6 detail
	The detail keyword is This example shows h Switch# show diagno module 6: Overall diagnosti Test results:(. =	s intended for use by Cisco support personnel when analyzing failures. now to display the results of the bootup packet memory tests: pstic result module 6 detail c result:PASS

```
Slot Ports Card Type
                                Diag Status
                                           Diag Details
6 48 10/100/1000BaseT (RJ45)V, Cisco/IEEE Passed
                                         None
Detailed Status
_____
             U = Unknown
. = Pass
L = Loopback failure S = Stub failure
I = Ilc failure P = Port failure
E = SEEPROM failure G = GBIC integrity check failure
Ports 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16
         .
            .
              .
                 .
                    .
                      .
                         .
                           .
                              .
                                   .
                                      .
                                         .
Ports 17 18 19 20 21 22 23 24 25 26 27 28 29 30 31 32
   .
           .
              .
                .
                      .
                         .
                           .
Ports 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
              .
           •
                .
                   .
                      •
                         •
                           .
                              .
                                 .
                                   .
   .
        .
                                      .
                                         .
  2) online-diag-tdr:
  Port 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24
  _____
      Port 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48
  _____
     Error code -----> 0 (DIAG_SUCCESS)
      Total run count -----> 1
      Last test execution time -----> Jan 22 2001 03:01:54
      First test failure time -----> n/a
      Last test failure time -----> n/a
      Last test pass time -----> Jan 22 2001 03:01:54
      Total failure count -----> 0
      Consecutive failure count -----> 0
Detailed Status
_____
TDR test is in progress on interface Gi6/1
```

Switch#

Related Commands dia

diagnostic start

show diagnostic result module test 2

To display the results of the bootup packet memory test, use the **show diagnostic result module test 2** command. The output indicates whether the test passed, failed, or was not run.

show diagnostic result module N test 2 [detail]

Syntax Description	<i>N</i> Specifies the module number.				
	detail (Optional) Specifies the display of detailed information for analysi				
Defaults	Non-detailed results				
ommand Modes	EXEC mode				
command History	Release Modification				
	12.2(18)EWThis command was introduced on the Catalyst 4500 series switch.				
Jsage Guidelines	The detail keyword is intended for use by Cisco support personnel when analyzing failures.				
xamples	This example shows how to display the results of the bootup packet memory tests:				
	Switch# show diagnostic result module 1 test 2				
	Test results: (. = Pass, F = Fail, U = Untested)				
	2) packet-memory-bootup> .				
	This example shows how to display detailed results from the bootup packet memory tests:				
	Switch# show diagnostic result module 2 test 2 detail				
	Test results: (. = Pass, F = Fail, U = Untested)				
	2) packet-memory-bootup> .				
	Error code> 0 (DIAG_SUCCESS) Total run count> 0 Last test execution time> n/a First test failure time> n/a Last test failure time> n/a Last test pass time> n/a Total failure count> 0				
	Consecutive failure count> 0 packet buffers on free list: 64557 bad: 0 used for ongoing tests: 979				

```
Number of errors found: 0
Cells with hard errors (failed two or more tests): 0
Cells with soft errors (failed one test, includes hard): 0
Suspect bad cells (uses a block that tested bad): 0
total buffers: 65536
bad buffers: 0 (0.0%)
good buffers: 65536 (100.0%)
Bootup test results:
No errors.
```

Related Commands diagnos

diagnostic monitor action show diagnostic result module test 3

show diagnostic result module test 3

To display the results from the ongoing packet memory test, use the **show diagnostic result module test 3** command. The output indicates whether the test passed, failed, or was not run.

show diagnostic result module N test 3 [detail]

Syntax Description	N Module number.
	detail (Optional) Specifies the display of detailed information for analysis.
efaults	Non-detailed results
mmand Modes	EXEC mode
ommand History	Release Modification
	12.2(18)EWThis command was introduced on the Catalyst 4500 series switch.
sage Guidelines	The detail keyword is intended for use by Cisco support personnel when analyzing failures.
kamples	This example shows how to display the results from the ongoing packet memory tests: Switch# show diagnostic result module 1 test 3
	Test results: (. = Pass, F = Fail, U = Untested)
	3) packet-memory-ongoing> .
	This example shows how to display the detailed results from the ongoing packet memory tests:
	Switch# show diagnostic result module 1 test 3 detail
	Test results: (. = Pass, F = Fail, U = Untested)
	3) packet-memory-ongoing> .
	Error code> 0 (DIAG_SUCCESS) Total run count> 0 Last test execution time> n/a First test failure time> n/a Last test failure time> n/a Last test pass time> n/a Total failure count> 0 Consecutive failure count> 0 packet buffers on free list: 64557 bad: 0 used for ongoing tests: 979

```
Packet memory errors: 0 0
Current alert level: green
Per 5 seconds in the last minute:
    0 0 0 0 0 0 0 0 0 0
    0 0
Per minute in the last hour:
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
Per hour in the last day:
    0 0 0 0 0 0 0 0 0 0
    0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0
    0 0 0 0
Per day in the last 30 days:
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
Direct memory test failures per minute in the last hour:
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0 \ 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
    0 0 0 0 0 0 0 0 0 0
Potential false positives: 0 0
  Ignored because of rx errors: 0 0
  Ignored because of cdm fifo overrun: 0 0
  Ignored because of oir: 0 0
  Ignored because isl frames received: 0 0
  Ignored during boot: 0 0
  Ignored after writing hw stats: 0 0
  Ignored on high gigaport: 0
Ongoing diag action mode: Normal
Last 1000 Memory Test Failures: v
Last 1000 Packet Memory errors:
First 1000 Packet Memory errors:
```

Related Commands

show diagnostic result module test 2

diagnostic monitor action

show dot1x

To display the 802.1X statistics and operational status for the entire switch or for a specified interface, use the **show dot1x** command.

show dot1x [interface interface-id] | [statistics [interface interface-id]] | [all]

Syntax Description	interface interface-	<i>id</i> (Optional) Displays the 802.1X status for the specified port.
, ,	statistics	(Optional) Displays 802.1X statistics for the switch or the specified interface.
	all	(Optional) Displays per-interface 802.1X configuration information for all interfaces with a non-default 802.1X configuration.
Defaults	This command has n	o default settings.
Command Modes	Privileged EXEC	
Command History	Release	Aodification
	12.1(12c)EW S	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(19)EW I	Display enhanced to show the guest-VLAN value.
		Support for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 eries switch.
		Support for currently-assigned reauthentication timer (if the timer is configured to nonor the Session-Timeout value) was added.
	12.2(31)SG S	Support for port direction control and critical recovery was added.
Usage Guidelines		an interface, the global parameters and a summary are displayed. If you specify an for that interface are displayed.
		Atistics keyword without the interface option, the statistics are displayed for all cify the statistics keyword with the interface option, the statistics are displayed for e.
	-	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> t the lines that contain <i>Output</i> are displayed.
		nmand displays the currently-assigned reauthentication timer and time remaining on, if reauthentication is enabled.
Examples	This example shows	how to display the output from the show dot1x command:
	Switch# show dot1x Sysauthcontrol = D Dot1x Protocol Ver Dot1x Oper Control	isabled

Catalyst 4500 Series Switch Cisco IOS Command Reference—Release 12.2(31)SG

```
Dot1x Admin Controlled Directions = Both
Critical Recovery Delay = 500
Critical EAP = Enabled
Switch#
```

This example shows how to display the 802.1X statistics for a specific port:

```
Switch# show dot1x interface fastethernet6/1
Dot1x Info for FastEthernet6/1
_____
PAE = AUTHENTICATOR
PortControl = AUTO
ControlDirection = Both
HostMode = SINGLE_HOST
ReAuthentication = Disabled
QuietPeriod = 60
ServerTimeout = 30
SuppTimeout = 30
ReAuthPeriod = 3600 (Locally configured)
ReAuthMax = 2 MaxReq = 2
TxPeriod = 30
RateLimitPeriod = 0
Critical-Auth = Enabled
Critical Recovery Action = Reinitialize
Critical-Auth VLAN = 3
Dot1x Authenticator Client List Empty
Authorized By = Critical-Auth
Vlan Policy = 3
```



Switch#

Table 2-16 provides a partial list of the displayed fields. The remaining fields in the display show internal state information. For a detailed description of these state machines and their settings, refer to the 802.1X specification.

Table 2-16 show dot1x interface Field Description

Field	Description
PortStatus	Status of the port (authorized or unauthorized). The status of a port is displayed as authorized if the dot1x port-control interface configuration command is set to auto and has successfully completed authentication.
Port Control	Setting of the dot1x port-control interface configuration command.
MultiHosts	Setting of the dot1x multiple-hosts interface configuration command (allowed or disallowed).

This is an example of output from the **show dot1x statistics interface gigabitethernet1/1** command. Table 2-17 describes the fields in the display.

Switch# show dot1x statistics interface gigabitethernet1/1

Field	Description
TxReq/TxReqId	Number of EAP-request/identity frames that have been sent.
TxTotal	Number of EAPOL frames of any type that have been sent.
RxStart	Number of valid EAPOL-start frames that have been received.
RxLogoff	Number of EAPOL-logoff frames that have been received.
RxRespId	Number of EAP-response/identity frames that have been received.
RxResp	Number of valid EAP-response frames (other than response/identity frames) that have been received.
RxInvalid	Number of EAPOL frames that have been received and have an unrecognized frame type.
RxLenError	Number of EAPOL frames that have been received in which the packet body length field is invalid.
RxTotal	Number of valid EAPOL frames of any type that have been received.
RxVersion	Protocol version number carried in the most recently received EAPOL frame.
LastRxSrcMac	Source MAC address carried in the most recently received EAPOL frame.

Table 2-17	show dot1x statistics	Field Descriptions

Related Commands

mac-address-table notification dot1x critical dot1x critical eapol dot1x critical recovery delay dot1x critical vlan dot1x guest-vlan dot1x max-reauth-req dot1x port-control

show environment

To display the environment alarm, operational status, and current reading for the chassis, use the **show environment** command.

show environment [alarm] | [status [chassis | fantray | powersupply | supervisor]] | [temperature]

Syntax Description	alarm	(Optional) Sp	ecifies the al	larm statu	s of the chassis.	
	status	(Optional) Sp	ecifies the o	perational	l status information.	
	chassis	(Optional) Sp	ecifies the o	perational	l status of the chassis.	
	fantray	(Optional) Sp	ecifies the st	atus of the	e fan tray, and shows fan tray power consump	
	powersupply	(Optional) Sp	ecifies the st	atus of th	e power supply.	
	supervisor	(Optional) Sp	ecifies the st	atus of th	e supervisor engine.	
	temperature	(Optional) Sp	ecifies the cu	urrent cha	ssis temperature readings.	
Defaults	This command h		ettings.			
Command Modes	Privileged EXEC	1				
Command History	Release	Modification				
	12.1(8a)EW	2.1(8a)EW Support for this command was introduced on the Catalyst 4500 series switch.				
	12.1(12c)EW	Support for t environment	•		eneric environment information with the sh ee.	
Examples	This example sho	nows how to display information about the environment alarms, operational status, and ture readings for the chassis:				
-xampioo	current temperatu	are readings to	the chassis.			
	current temperatu Switch# show en no alarm	•	t the chassis.			
	Switch# show en	Nvironment Nture Emperature Thr	eshold	= 32 deg = 75 deg	rees Celsius rees Celsius rees Celsius	
	Switch# show en no alarm Chassis Tempera Chassis Over Te Chassis Critica Power Supply Model N	vironment ature emperature Thr al Temperature Jo Typ	reshold Threshold Far	= 32 deg = 75 deg = 95 deg	rees Celsius	
	Switch# show er no alarm Chassis Tempera Chassis Over Te Chassis Critica Power Supply Model N	ature mperature Thr I Temperature	reshold Threshold Far pe Sta	= 32 deg = 75 deg = 95 deg 1 1 1 1	rrees Celsius rrees Celsius	
	Switch# show en no alarm Chassis Tempera Chassis Over Te Chassis Critica Power Supply Model N PS1 PWR-C45	vironment ture mperature Thr 1 Temperature No Typ 	reshold Far pe Sta 1400W goo Max ne System	= 32 deg = 75 deg = 95 deg n utus od Min	rees Celsius rees Celsius Sensor good Absolute	

Power supplies needed by system : 1 Chassis Type : WS-C4507R Supervisor Led Color : Green Fantray : good Power consumed by Fantray : 50 Watts

This example shows how to display information about the environment alarms:

Switch# **show environment alarm** no alarm Switch#

Switch# show environment status

This example shows how to display information about the power supplies, chassis type, and fan trays:

Power Fan Supply Model No Type Status Sensor _____ _____ PWR-C45-1400AC AC 1400W good PS1 good PS2 none --_ _ _ _ Max Min Power Supply Max Min Absolute (Nos in Watts) Inline Inline System System Maximum _____ _____ 0 0 1360 1360 1400 PS1 --___ PS2 ----___ Power supplies needed by system : 1 Chassis Type : WS-C4507R Supervisor Led Color : Green Fantray : good Power consumed by Fantray : 50 Watts Switch# This example shows how to display information about the chassis: Switch# show environment status chassis

```
Chassis Type :WS-C4006
Switch#
```

This example shows how to display information about the fan tray:

```
Switch# show environment status fantray
Fantray : good
Power consumed by Fantray : 50 Watts
Switch#
```

This example shows how to display information about the power supply:

Switch#	show environment	status pow	ersupply	
Power				Fan
Supply	Model No	Туре	Status	Sensor
PS1	WS-X4008	AC 400W	good	good
PS2	WS-X4008	AC 400W	good	good
PS3	none			
Switch#				

This example shows how to display information about the supervisor engine:

```
Switch# show environment status supervisor
Supervisor Led Color :Green
Switch#
```

This example shows how to display information about the temperature of the chassis:

```
Switch# show environment temperature
Chassis Temperature = 32 degrees Celsius
Chassis Over Temperature Threshold = 75 degrees Celsius
Chassis Critical Temperature Threshold = 95 degrees Celsius
Switch#
```

show errdisable detect

To display the error disable detection status, use the show errdisable detect command.

show errdisable detect

Syntax Description	This command has no	arguments or keywords.
--------------------	---------------------	------------------------

- **Defaults** This command has no default settings.
- Command Modes Privileged EXEC

Command HistoryReleaseModification12.1(8a)EWSupport for this command was introduced on the Catalyst 4500 series switch.12.1(19)EWDisplay includes the status of storm control.

Examples

This example shows how to display the error disable detection status:

Switch# show errdis ErrDisable Reason	
udld	Enabled
bpduguard	Enabled
security-violatio	Enabled
channel-misconfig	Disabled
psecure-violation	Enabled
vmps	Enabled
pagp-flap	Enabled
dtp-flap	Enabled
link-flap	Enabled
12ptguard	Enabled
gbic-invalid	Enabled
dhcp-rate-limit	Enabled
unicast-flood	Enabled
storm-control	Enabled
ilpower	Enabled
arp-inspection	Enabled
Switch#	

Related Commands

errdisable detect errdisable recovery show interfaces status
show errdisable recovery

To display error disable recovery timer information, use the show errdisable recovery command.

show errdisable recovery

Syntax Description	This command h	as no arguments	or keywords.
--------------------	----------------	-----------------	--------------

- **Defaults** This command has no default settings.
- Command Modes Privileged EXEC

Command History	Release	Modification
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(19)EW	Display includes the status of storm control.

Examples

This example shows how to display recovery timer information for error disable:

ErrDisable Reason	Timer Status			
udld	Disabled			
bpduguard	Disabled			
security-violatio	Disabled			
channel-misconfig	Disabled			
vmps	Disabled			
pagp-flap	Disabled			
dtp-flap	Disabled			
link-flap	Disabled			
12ptguard	Disabled			
psecure-violation	Disabled			
gbic-invalid	Disabled			
dhcp-rate-limit	Disabled			
unicast-flood	Disabled			
storm-control	Disabled			
arp-inspection	Disabled			
Timer interval:30 s	econds			
Interfaces that will	l be enabled at	t the	next	timeout:
Interface Errdisa	able reason	Time	left((sec)
Fa7/32 ar	p-inspect		13	

Related Commands

errdisable detect errdisable recovery show interfaces status

show etherchannel

To display EtherChannel information for a channel, use the show etherchannel command.

Suntax Description		
Syntax Description	channel-group	(Optional) Number of the channel group; valid values are from 1 to 64.
	port-channel	Displays port-channel information.
	brief	Displays a summary of EtherChannel information.
	detail	Displays detailed EtherChannel information.
	summary	Displays a one-line summary per channel group.
	port	Displays EtherChannel port information.
	load-balance	Displays load-balance information.
	protocol	Displays the enabled protocol.
Defaults	This command h	as no default settings.
ommand Modes	Privileged EXEC	2
ommand History	Release	Modification
······	12 1(0) EW	
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(8a)EW 12.1(13)EW	Support for this command was introduced on the Catalyst 4500 series switch. Support for LACP was added to this command.
lsage Guidelines	12.1(13)EW If you do not spe In the output bel means that the p	Support for LACP was added to this command. ecify a channel group, all channel groups are displayed. ow, the Passive port list field is displayed for Layer 3 port channels only. This field hysical interface, which is still not up, is configured to be in the channel group (and
	12.1(13)EW If you do not spe In the output bel means that the p indirectly is in th This example sh	Support for LACP was added to this command. ecify a channel group, all channel groups are displayed. ow, the Passive port list field is displayed for Layer 3 port channels only. This field
	12.1(13)EW If you do not spe In the output bel means that the p indirectly is in th This example sh Switch# show et	Support for LACP was added to this command. ecify a channel group, all channel groups are displayed. ow, the Passive port list field is displayed for Layer 3 port channels only. This field hysical interface, which is still not up, is configured to be in the channel group (and he only port channel in the channel group). ows how to display port-channel information for a specific group: therchannel 1 port-channel Port-channels in the group:
Jsage Guidelines Examples	12.1(13)EW If you do not spe In the output bel means that the p indirectly is in th This example sh	Support for LACP was added to this command. ecify a channel group, all channel groups are displayed. ow, the Passive port list field is displayed for Layer 3 port channels only. This field hysical interface, which is still not up, is configured to be in the channel group (and he only port channel in the channel group). ows how to display port-channel information for a specific group: therchannel 1 port-channel Port-channels in the group:

```
Ports in the Port-channel:
Index Load Port
------
Switch#
```

This example shows how to display load-balancing information:

```
Switch# show etherchannel load-balance
Source XOR Destination mac address
Switch#
```

This example shows how to display a summary of information for a specific group:

```
Switch# show etherchannel 1 brief
Group state = L3
Ports: 2 Maxports = 8
port-channels: 1 Max port-channels = 1
Switch#
```

This example shows how to display detailed information for a specific group:

```
Switch# show etherchannel 1 detail
Group state = L3
Ports: 2 Maxports = 8
Port-channels: 1 Max Port-channels = 1
              Ports in the group:
               _____
Port: Fa5/4
_____
           = EC-Enbld Down Not-in-Bndl Usr-Config
Port state
Channel group = 1Mode = DesirableGcchange = 0Port-channel = nullGC = 0x00000000Psudo-agport
                                            Psudo-agport = Pol
Port indx
            = 0
                        Load = 0x00
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode. P - Device learns on physical port.
Timers: H - Hello timer is running.
                                      Q - Quit timer is running.
       S - Switching timer is running. I - Interface timer is running.
Local information:
                              Hello
                                      Partner PAgP
                                                       Learning Group
         Flags State Timers Interval Count Priority Method Ifindex
Port
Fa5/4
        d U1/S1
                              15
                                       0
                                              128
                                                        Anv
                                                                  0
Age of the port in the current state: 02h:33m:14s
Port: Fa5/5
_____
Port state
           = EC-Enbld Down Not-in-Bndl Usr-Config
Channel group = 1Mode = DesirablePort-channel = nullGC = 0x0000000
                                             Gcchange = 0
                                            Psudo-agport = Pol
Port indx
                        Load = 0x00
            = 0
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
      A - Device is in Auto mode. P - Device learns on physical port.
Timers: H - Hello timer is running.
                                      Q - Quit timer is running.
       S - Switching timer is running. I - Interface timer is running.
Local information:
                              Hello Partner PAgP
                                                       Learning Group
Port.
        Flags State Timers Interval Count Priority Method Ifindex
Fa5/5
        d U1/S1
                                      0
                                              128
                             1s
                                                                 0
                                                        Anv
```

```
Age of the port in the current state: 02h:33m:17s
         Port-channels in the group:
             ------
Port-channel: Po1
_____
Age of the Port-channel = 02h:33m:52s
Logical slot/port = 10/1 Number of ports in agport = 0
                               HotStandBy port = null
GC
                = 0 \times 000000000
Passive port list = Fa5/4 Fa5/5
Port state
                = Port-channel L3-Ag Ag-Not-Inuse
Ports in the Port-channel:
Index Load Port
_____
Switch#
```

This example shows how to display a one-line summary per channel group:

This example shows how to display EtherChannel port information for all ports and all groups:

Switch# show etherchannel port

```
Channel-group listing:
               _____
Group: 1
_____
              Ports in the group:
               _____
Port: Fa5/4
_____
Port state = EC-Enbld Down Not-in-Bndl Usr-Config
Channel group = 1 Mode = Desirable Gcchange = 0
Port-channel = null GC = 0x00000000 Psudo-agport = Pol
Port indx
           = 0
                         Load = 0x00
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
A - Device is in Auto mode. P - Device learns on physical port.
Timers: H - Hello timer is running. Q - Quit timer is running.
       S - Switching timer is running. I - Interface timer is running.
Local information:
                            Hello Partner PAgP
                                                    Learning Group
Port
        Flags State Timers Interval Count Priority Method Ifindex
Fa5/4
        d U1/S1
                             1s
                                 0
                                           128
                                                      Any
                                                                0
Age of the port in the current state: 02h:40m:35s
Port: Fa5/5
_____
Port state = EC-Enbld Down Not-in-Bndl Usr-Config
Channel group = 1 Mode = Desirable Gcchange = 0
Port-channel = null GC = 0x00000000 Psudo-agport = Pol
Port indx = 0 Load = 0x00
Port indx = 0
                         Load = 0x00
```

```
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
A - Device is in Auto mode. P - Device learns on physical port.
Timers: H - Hello timer is running. Q - Quit timer is running.
S - Switching timer is running. I - Interface timer is running.
<...output truncated...>
Switch#
This example shows how to display the protocol enabled:
Switch# show etherchannel protocol
Channel-group listing:
```

Group: 12 Protocol: PAgP Group: 24

Protocol: - (Mode ON) Switch#

Related Commands

interface port-channel

channel-group

show flowcontrol

To display the per-interface status and statistics related to flow control, use the **show flowcontrol** command.

show flowcontrol [module slot | interface interface]

	(Optional) Limits the display to interfaces on a specific module.
interface interface	(Optional) Displays the status on a specific interface.
This command has no d	efault settings.
Privileged EXEC	
Release Mod	ification
-	This command has no d Privileged EXEC

mmand History	Kelease	MODIFICATION
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.2(25)EW	Support for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 series switch.

Usage Guidelines Table 2-18 describes the fields in the **show flowcontrol** command output.

Table 2-18 show flowcontrol Command Output

Field	Description
Port	Module and port number.
Send-Flowcontrol-Admin	Flow-control administration. Possible settings: on indicates the local port sends flow control to the far end; off indicates the local port does not send flow control to the far end; desired indicates the local end sends flow control to the far end if the far end supports it.
Send-Flowcontrol-Oper	Flow-control operation. Possible setting: disagree indicates the two ports could not agree on a link protocol.
Receive-Flowcontrol-Admin	Flow-control administration. Possible settings: on indicates the local port requires the far end to send flow control; off indicates the local port does not allow the far end to send flow control; desired indicates the local end allows the far end to send flow control.
Receive-Flowcontrol-Oper	Flow-control operation. Possible setting: disagree indicates the two ports could not agree on a link protocol.
RxPause	Number of pause frames received.
TxPause	Number of pause frames transmitted.

Examples

This example shows how to display the flow control status on all the Gigabit Ethernet interfaces:

Switch# show flowcontrol

SWICCIII BIIC		ICTOT				
Port	Send Flow	vControl	Receive H	FlowControl	RxPause	TxPause
	admin	oper	admin	oper		
Tel/1	off	off	on	off	0	0
Te1/2	off	off	on	off	0	0
Gi1/3	off	off	desired	on	0	0
Gi1/4	off	off	desired	on	0	0
Gi1/5	off	off	desired	on	0	0
Gi1/6	off	off	desired	on	0	0
Gi3/1	off	off	desired	off	0	0
Gi3/2	off	off	desired	off	0	0
Gi3/3	off	off	desired	off	0	0
Gi3/4	off	off	desired	off	0	0
Gi3/5	off	off	desired	off	0	0
Gi3/6	off	off	desired	off	0	0
Switch#						

This example shows how to display the flow control status on module 1:

Switch#	show flow	wcontrol r	nodule 1			
Port	Send Flow	wControl	Receive 3	FlowControl	RxPause	TxPause
	admin	oper	admin	oper		
Gi1/1	desired	off	off	off	0	0
Gi1/2	on	disagree	on	on	0	0
Switch#						

This example shows how to display the flow control status on Gigabit Ethernet interface 3/4:

Switch#show flowcontrol interface gigabitethernet3/4PortSend FlowControlReceive FlowControlRxPauseadminoperadminoper--------------------Gi3/4offoffonon0Switch#---------------

This example shows how to display the flow control status on 10-Gigabit Ethernet interface 1/1:

Switch# sh	ow flowco	ntrol int	erface t	engigabiteth	ernet1/1	
Port	Send Flo	wControl	Receive	FlowControl	RxPaus	e TxPause
	admin	oper	admin	oper		
Te1/1 Switch#	off	off	on	off	0	0

Related Commands

show interfaces status

flowcontrol

show hw-module uplink

To display the current uplink mode, use the show hw-module uplink command.

show hw-module uplink

Defaults	None	
Command Modes	Privileged EXE	C
Command History	Release 12.2(25)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch.
Usage Guidelines	_	ink mode is different than configured mode, the output displays the change. current (operational) uplink selection is displayed.
Examples	Switch# show h Active uplink This example sh	nows the output displaying the current (active) uplinks: w-module uplink configuration is TenGigabitEthernet nows the output for redundant systems in SSO mode if the 10-Gigabit Ethernet uplinks the Gigabit Ethernet uplinks are selected:
	Switch# show h Active uplink (will be Gigak	ww-module uplink configuration is TenGigabitEthernet pitEthernet after next reload) reload shelf' or power-cycle of chassis is required to
	-	nows the output for redundant systems in RPR mode if the 10-Gigabit Ethernet uplinks he Gigabit Ethernet uplinks are selected:
	Active uplink (will be Gigab	w-module uplink configuration is TenGigabitEthernet bitEthernet after next reload) ctive supervisor is required to apply the new configuration.

Related Commands hw-module uplink select

show idprom

To display the IDPROMs for the chassis, supervisor engine, module, power supplies, fan trays, clock module, and multiplexer (mux) buffer, use the **show idprom** command.

show idprom {all | chassis | module [mod] | interface int_name | supervisor | power-supply
 number | fan-tray}

Syntax Description	all	Displays information for all IDPROMs.		
	chassis	Displays information for the chassis IDPROMs.		
	module	Displays information for the module IDPROMs.		
	mod	(Optional) Specifies the module name.		
	<pre>interface int_name</pre>	Displays information for the GBIC or SFP IDPROMs.		
	supervisor	Displays information for the supervisor engine IDPROMs.		
	power-supply numb	<i>Der</i> Displays information for the power supply IDPROMs.		
	fan-tray	Displays information for the fan tray IDPROMs.		
Defaults	This command has n	o default settings.		
Command Modes	Privileged EXEC			
Command History	Release M	lodification		
	12.1(8a)EW Su	upport for this command was introduced on the Catalyst 4500 series switch.		
		Support for the power-supply , fan-tray , clock-module , and mux-buffer keywords was added.		
	12.1(13)EW Su	upport for interface keyword was added.		
		nhanced the show idprom interface output to include the hexadecimal display of the GBIC/SFP SEEPROM contents.		
		upport for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 eries switch.		

```
Common Block Checksum = 4199
 Idprom Size = 256
Block Count = 2
FRU Major Type = 0x4201
FRU Minor Type = 303
OEM String = Cisco Systems, Inc.
Product Number = WS-X4306
Serial Number = 00000135
Part Number = <tbd>
Hardware Revision = 0.2
Manufacturing Bits = 0x0000
Engineering Bits = 0 \times 0000
Snmp OID = 0.0.0.0.0.0.0.0
Power Consumption = 0
RMA Failure Code = 0 0 0 0
Linecard Block Signature = 0x4201
Linecard Block Version = 1
Linecard Block Length = 24
Linecard Block Checksum = 658
Feature Bits = 0x000000000000000
Card Feature Index = 50
MAC Base = 0010.7bab.9830
MAC Count = 6
Switch#
```

This example shows how to display IDPROM information for the GBICs on the Gigabit Ethernet interface 1/2:

```
Switch# show idprom interface gigabitethernet1/2
GBIC Serial EEPROM Contents:
Common Block:
 Identifier
                 = GBIC [0x1]
Extended Id
                 = Not specified/compliant with defined MOD_DEF [0x0]
Connector
                 = SC connector [0x1]
 Transceiver
 Speed
                  = Not available [0x0]
  Media
                  = Not available [0x0]
 Technology
                  = Not available [0x0]
                 = Not available [0x0]
 Link Length
 GE Comp Codes = Not available [0x0]
 SONET Comp Codes = Not available [0x0]
 Encoding
                 = 8B10B [0x1]
 BR, Nominal
                 = 130000000 MHz
 Length(9u) in km = GBIC does not support single mode fibre, or the length
                    must be determined from the transceiver technology.
 Length(9u)
                  = > 25.4 km
 Length(50u)
                  = GBIC does not support 50 micron multi-mode fibre, or the
                    length must be determined from the transceiver technology.
                 = GBIC does not support 62.5 micron multi-mode fibre, or
 Length(62.5u)
                    the length must be determined from transceiver technology.
                = GBIC does not support copper cables, or the length must
 Length(Copper)
                    be determined from the transceiver technology.
 Vendor name
                  = CISCO-FINISAR
 Vendor OUI
                  = 36965
                  = FTR-0119-CSC
 Vendor Part No.
 Vendor Part Rev. = B
 Wavelength
                  = Not available
CC_BASE
                 = 0x1A
Extended ID Fields
Options
                  = Loss of Signal implemented TX_FAULT signal implemented TX_DISABLE is
implemented and disables the serial output [0x1A]
BR, max
                  = Unspecified
 BR, min
                  = Unspecified
```

Catalyst 4500 Series Switch Cisco IOS Command Reference—Release 12.2(31)SG

```
Vendor Serial No. = K1273DH
 Date code = 030409
Diag monitoring = Implemented
Calibration type = Internal
Rx pwr measuremnt = Optical Modulation Amplitude (OMA)
Address change = Required
CC_EXT
                = 0 \times B2
Vendor Specific ID Fields:
20944D30 29 00 02 80 22 33 38 3D C7 67 83 E8 DF 65 6A AF )..."38=Gg^Ch_ej/
SEEPROM contents (hex) size 128:
0x0000 01 00 01 00 00 00 00 00 00 00 00 01 0D 00 00 FF
                                                     . . . . . . . . . . . . . . . .
0x0010 00 00 00 00 43 49 53 43 4F 2D 46 49 4E 49 53 41
                                                    ....CISCO-FINISA
0x0020 52 20 20 20 00 00 90 65 46 54 52 2D 30 31 31 39
                                                    R ..^PeFTR-0119
0x0030
       2D 43 53 43 20 20 20 20 42 20 20 20 00 00 1A
                                                    -CSC B
                                                               . . . .
0x0040
       00 1A 00 00 4B 31 32 37 33 44 48 20 20 20 20 20
                                                     ....K1273DH
0x0050
       20 20 20 20 30 33 30 34 30 39 20 20 64 00 00 B2
                                                       030409 d..2
0x0060 29 00 02 80 22 33 38 3D C7 67 83 E8 DF 65 6A AF
                                                    )..^@"38=Gg^C._ej.
0x0070 1A 80 ED 00 00 00 00 00 00 00 00 00 38 23 3C 1B
                                                    .^@m....8#<.
Switch#
```

This example shows how to display IDPROM information for the 10-Gigabit Ethernet interface 1/1:

Switch# show idprom interface tengigab	pitethernet1/1
X2 Serial EEPROM Contents:	
Non-Volatile Register (NVR) Fields	
X2 MSA Version supported	:0xA
NVR Size in bytes	:0x100
-	:0xD0
-	:0xB
Customer Field Address	:0x77
Vendor Field Address	:0xA7
Extended Vendor Field Address	:0x100
Reserved	:0x0
Transceiver type	:0x2 =X2
Optical connector type	:0x1 =SC
Bit encoding	:0x1 =NRZ
Normal BitRate in multiple of 1M b/s	:0x2848
Protocol Type	:0x1 =10GgE
	-
Standards Compliance Codes :	
10GbE Code Byte 0	:0x2 =10GBASE-LR
10GbE Code Byte 1	:0x0
SONET/SDH Code Byte 0	:0x0
SONET/SDH Code Byte 1	:0x0
SONET/SDH Code Byte 2	:0x0
SONET/SDH Code Byte 3	:0x0
10GFC Code Byte 0	:0x0
10GFC Code Byte 1	:0x0
10GFC Code Byte 2	:0x0
10GFC Code Byte 3	:0x0
Transmission range in 10m	:0x3E8
Fibre Type :	
Fibre Type Byte 0	:0x40 =NDSF only
Fibre Type Byte 1	:0x0 =Unspecified
Centre Optical Wavelength in 0.01nm s	steps - Channel 0 :0x1 0xFF 0xB8
Centre Optical Wavelength in 0.01nm s	steps - Channel 1 :0x0 0x0 0x0
Centre Optical Wavelength in 0.01nm s	steps - Channel 2 :0x0 0x0 0x0
Centre Optical Wavelength in 0.01nm s	steps - Channel 3 :0x0 0x0 0x0
Package Identifier OUI :0xC09820	

```
Transceiver Vendor OUI :0x3400800
Transceiver vendor name :CISCO-OPNEXT, INC
Part number provided by transceiver vendor
                                         :TRT5021EN-SMC-W
Revision level of part number provided by vendor :00
Vendor serial number
                         :ONJ08290041
Vendor manufacturing date code :2004072000
Reserved1 : 00 02 02 20 D1 00 00
Basic Field Checksum :0x10
Customer Writable Area :
 0x00: 58 32 2D 31 30 47 42 2D 4C 52 20 20 20 20 20 20 20
 0x10: 20 20 20 20 20 4F 4E 4A 30 38 32 39 30 30 34 31
 0x20: 31 30 2D 32 30 33 36 2D 30 31 20 20 41 30 31 20
Vendor Specific :
 0x30: 00 00 00 00 11 E2 69 A9 2F 95 C6 EE D2 DA B3 FD
 0x40: 9A 34 4A 24 CB 00 00 00 00 00 00 00 00 00 EF FC
 0x50: F4 AC 1A D7 11 08 01 36 00
Switch#
```

This example shows how to display IDPROM information for the supervisor engine:

```
Switch# show idprom supervisor
Supervisor Idprom:
Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
 Common Block Checksum = 4153
 Idprom Size = 256
Block Count = 2
FRU Major Type = 0x4101
FRU Minor Type = 333
OEM String = Cisco Systems, Inc.
 Product Number = WS-X4014
 Serial Number = JAB05320CCE
 Part Number = 73 - 6854 - 04
Part Revision = 05
Manufacturing Deviation String = 0
Hardware Revision = 0.4
Manufacturing Bits = 0x0000
 Engineering Bits = 0 \times 0000
Snmp OID = 0.0.0.0.0.0.0.0
 Power Consumption = 0
 RMA Failure Code = 0 \ 0 \ 0 \ 0
 Supervisor Block Signature = 0x4101
 Supervisor Block Version = 1
 Supervisor Block Length = 24
 Supervisor Block Checksum = 548
 Feature Bits = 0x000000000000000
Card Feature Index = 95
MAC Base = 0007.0ee5.2a44
MAC Count = 2
Switch#
```

```
This example shows how to display IDPROM information for the chassis:
```

```
Switch# show idprom chassis
Chassis Idprom:
 Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
Common Block Checksum = 4285
Idprom Size = 256
Block Count = 2
FRU Major Type = 0x4001
 FRU Minor Type = 24
OEM String = Cisco Systems, Inc.
 Product Number = WS-C4006
 Serial Number = FOX04473737
Part Number = 73 - 4289 - 02
Part Revision = 02
Manufacturing Deviation String = 0x00
Hardware Revision = 0.2
Manufacturing Bits = 0x0000
Engineering Bits = 0 \times 0000
 Snmp OID = 0.0.0.0.0.0.0.0
Chassis Block Signature = 0x4001
Chassis Block Version = 1
Chassis Block Length = 22
Chassis Block Checksum = 421
Feature Bits = 0x000000000000000
MAC Base = 0004.dd42.2600
MAC Count = 1024
Switch#
```

This example shows how to display IDPROM information for power supply 1:

```
Switch# show idprom power-supply 1
Power Supply 0 Idprom:
Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
Common Block Checksum = 10207
Idprom Size = 256
Block Count = 1
FRU Major Type = 0xAB01
FRU Minor Type = 8224
OEM String = Cisco Systems, Inc.
Product Number = WS-CAC-1440W
Serial Number = ACP05180002
Part Number = 34-XXXX-01
Part Revision = A0
Manufacturing Deviation String =
Hardware Revision = 1.1
Manufacturing Bits = 0x0000
Engineering Bits = 0x3031
Snmp OID = 9.12.3.65535.65535.65535.65535.65535
Power Consumption = -1
RMA Failure Code = 255 255 255 255
Power Supply Block Signature = 0xFFFF
PowerSupply Block Version = 255
PowerSupply Block Length = 255
PowerSupply Block Checksum = 65535
Feature Bits = 0x0000000FFFFFFFF
Current @ 110V = -1
Current @ 220V = -1
StackMIB OID = 65535
Switch#
```

This example shows how to display IDPROM information for the fan tray:

```
Switch# show idprom fan-tray
Fan Tray Idprom :
Common Block Signature = 0xABAB
Common Block Version = 1
Common Block Length = 144
Common Block Checksum = 19781
Idprom Size = 256
Block Count = 1
FRU Major Type = 0x4002
FRU Minor Type = 0
OEM String = "Cisco Systems"
 Product Number = WS-X4502-fan
Serial Number =
Part Number =
Part Revision =
Manufacturing Deviation String =
Hardware Revision = 0.1
Manufacturing Bits = 0xFFFF
Engineering Bits = 0xFFFF
Snmp OID = 65535.65535.65535.65535.65535.65535.65535.65535
Power Consumption = -1
RMA Failure Code = 255 255 255 255
Switch#
```

show interfaces

To display traffic on a specific interface, use the show interfaces command.

show interfaces [{{fastethernet mod/interface-number} | {gigabitethernet mod/interface-number} | {tengigabitethernet mod/interface-number} | {null interface-number} | vlan vlan_id} | status}]

Syntax Description	fastethernet	(Optional) Specifies the Fast Ethernet module and interface.
bymax bescription	mod/interface-r	
	gigabitetherne mod/interface-r	
	tengigabitethe mod/interface-r	
	null interface-n	<i>number</i> (Optional) Specifies the null interface; the valid value is 0.
	vlan vlan_id	(Optional) Specifies the VLAN; valid values are from 1 to 4094.
	status	(Optional) Displays status information.
Defaulte	This server at 1	
Defaults	This command I	has no default settings.
Command Modes	Privileged EXE	С
	6	
Command History	Release	Modification
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(12c)EW	Support for extended VLAN addresses was added.
	12.2(25)EW	Support for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 series switch.
Usage Guidelines	packets. The sta	e collected on a per-VLAN basis for Layer 2-switched packets and Layer 3-switched tistics are available for both unicast and multicast. The Layer 3-switched packet counts both the ingress and egress directions. The per-VLAN statistics are updated every
	show interfaces in the show inte	you might see a difference in the duplex mode that is displayed between the s command and the show running-config commands. The duplex mode that is displayed erfaces command is the actual duplex mode that the interface is running. The s command shows the operating mode for an interface, while the show running-config

If you do not enter any keywords, all counters for all modules are displayed.

command shows the configured mode for an interface.

```
Examples
                   This example shows how to display traffic for a Gigabit Ethernet interface 2/5:
                   Switch# show interfaces gigabitethernet2/5
                   GigabitEthernet9/5 is up, line protocol is up
                   Hardware is C4k 1000Mb 802.3, address is 0001.64f8.3fa5 (bia 0001.64f8.3fa5)
                   Internet address is 172.20.20.20/24
                   MTU 1500 bytes, BW 1000000 Kbit, DLY 10 usec,
                   reliability 255/255, txload 1/255, rxload 1/255
                   Encapsulation ARPA, loopback not set
                   Keepalive set (10 sec)
                   Full-duplex, 1000Mb/s
                   ARP type: ARPA, ARP Timeout 04:00:00
                   Last input 00:00:00, output never, output hang never
                   Last clearing of "show interface" counters never
                   Oueueing strategy: fifo
                   Output queue 0/40, 0 drops; input queue 0/75, 0 drops
                   5 minute input rate 1000 bits/sec, 2 packets/sec
                   5 minute output rate 0 bits/sec, 0 packets/sec
                   L2 Switched: ucast: 8199 pkt, 1362060 bytes - mcast: 6980 pkt, 371952 bytes
                   L3 in Switched: ucast: 0 pkt, 0 bytes - mcast: 0 pkt, 0 bytes mcast
                   L3 out Switched: ucast: 0 pkt, 0 bytes - mcast: 0 pkt, 0 bytes
                   300114 packets input, 27301436 bytes, 0 no buffer
                   Received 43458 broadcasts, 0 runts, 0 giants, 0 throttles
                   0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
                   0 input packets with dribble condition detected
                   15181 packets output, 1955836 bytes, 0 underruns
                   0 output errors, 0 collisions, 3 interface resets
                   0 babbles, 0 late collision, 0 deferred
                   0 lost carrier, 0 no carrier
                   0 output buffer failures, 0 output buffers swapped out
                   Switch#
```

This example shows how to display traffic for a 10-Gigabit Ethernet interface 1/1:

Switch# show interfaces tengigabitethernet1/1 Name: Tengigabitethernet1/1 Switchport: Enabled Administrative Mode: private-vlan promiscuous trunk Operational Mode: private-vlan promiscuous (suspended member of bundle Pol) Administrative Trunking Encapsulation: negotiate Operational Trunking Encapsulation: native Negotiation of Trunking: Off Access Mode VLAN: none Trunking Native Mode VLAN: none Administrative Native VLAN tagging: enabled Voice VLAN: none Administrative private-vlan host-association: none Administrative private-vlan mapping: 202 (VLAN0202) 303 (VLAN0303) 304 (VLAN0304) Administrative private-vlan trunk native VLAN: none Administrative private-vlan trunk Native VLAN tagging: enabled Administrative private-vlan trunk encapsulation: 802.1q Administrative private-vlan trunk normal VLANs: none Administrative private-vlan trunk private VLANs: none Administrative private-vlan mapping trunk: New 202 (VLAN0202) 303 (VLAN0303) 304 (VLAN0304) 204 (VLAN0204) 305 (VLAN0305) 306 (VLAN0306) Operational private-vlan: 202 (VLAN0202) 303 (VLAN0303) 304 (VLAN0304) Trunking VLANs Enabled: ALL Pruning VLANs Enabled: 2-1001 Capture Mode Disabled Capture VLANs Allowed: ALL Switch#

This example shows how to display status information for Gigabit Ethernet interface 1/2:

Switch#	show interfa	ces gigabitethe	ernet1/2	status	
Port	Name	Status	Vlan	Duplex	Speed Type
Gi1/2		notconnect	1	auto	1000 1000-XWDM-RXONLY
Switch#					

This example shows how to display status information for the interfaces on the supervisor engine:

Switch# show interfaces status

Port	Name	Status	Vlan	Duplex	Speed Type
Te1/1		connected	1	full	10G 10GBase-LR
Te1/2		connected	1	full	10G 10GBase-LR
Switch#					

show interfaces capabilities

To display the interface capabilities for an interface or for all the interfaces on a switch, use the **show interfaces capabilities** command.

show interfaces capabilities [{module mod}]

show interfaces [interface interface-number] capabilities

Syntax Description	module mod	(Optional) Display information for the specified module only.		
	<i>interface</i> (Optional) Interface type; valid values are fastethernet , gigabiteth tengigabitethernet , and port-channel .			
	interface-number	(Optional) Port number.		
Defaults	This command has n	o default settings.		
Command Modes	Privileged EXEC			
Command History	Release	Modification		
	12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch.		
	12.2(25)EW	Support for the 10-Gigabit Ethernet interface was introduced on the Catalyst 4500 series switch.		
Hanna Cuidalinaa				
Usage Guidelines	interface-number dep 10/100-Mbps Fast Et	r argument designates the module and port number. Valid values for pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48		
	<i>interface-number</i> dep 10/100-Mbps Fast Et chassis, valid values	pend on the chassis and module used. For example, if you have a 48-port		
	<i>interface-number</i> dep 10/100-Mbps Fast Et chassis, valid values This example shows	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48		
	interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model:</pre>	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic		
	interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type:	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic Unsupported GBIC		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed:</pre>	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic Unsupported GBIC 1000		
	interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type:	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic Unsupported GBIC 1000 full		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex:</pre>	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic Unsupported GBIC 1000 full		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex: Trunk encap. typ</pre>	pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1 WS-X4516-Gbic Unsupported GBIC 1000 full e: 802.1Q, ISL		
Usage Guidelines Examples	<pre>interface-number deg 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex: Trunk encap. typ Trunk mode: Channel: Broadcast suppre</pre>	<pre>pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1</pre>		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values f This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex: Trunk encap. typ Trunk mode: Channel: Broadcast suppre Flowcontrol:</pre>	<pre>pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1</pre>		
	<pre>interface-number deg 10/100-Mbps Fast Et chassis, valid values This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex: Trunk encap. typ Trunk mode: Channel: Broadcast suppre Flowcontrol: VLAN Membership:</pre>	<pre>pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1</pre>		
	<pre>interface-number dep 10/100-Mbps Fast Et chassis, valid values f This example shows Switch# show inter GigabitEthernet1/1 Model: Type: Speed: Duplex: Trunk encap. typ Trunk mode: Channel: Broadcast suppre Flowcontrol:</pre>	<pre>pend on the chassis and module used. For example, if you have a 48-port thernet RJ-21 (telco connector) switching module installed in a Catalyst 4507 for the slot number are from 2 to 13 and valid values for the port number are 1 to 48 how to display the interface capabilities for a module: faces capabilities module 1</pre>		

CoS rewrite:	yes
ToS rewrite:	yes
Inline power:	no
SPAN:	source/destination
UDLD	yes
Link Debounce:	no
Link Debounce Time:	no
Port Security	yes
Dotlx	yes
GigabitEthernet1/2	
Model:	WS-X4516-Gbic
Type:	Unsupported GBIC
Speed:	1000
Duplex:	full
Trunk encap. type:	802.1Q,ISL
Trunk mode:	on,off,desirable,nonegotiate
Channel:	yes
Broadcast suppression	:percentage(0-100), hw
Flowcontrol:	<pre>rx-(off,on,desired),tx-(off,on,desired)</pre>
VLAN Membership:	static, dynamic
Fast Start:	yes
Queuing:	rx-(N/A), tx-(4q1t, Sharing/Shaping)
CoS rewrite:	yes
ToS rewrite:	yes
Inline power:	no
SPAN:	source/destination
UDLD	yes
Link Debounce:	no
Link Debounce Time:	no
Port Security	yes
Dot1x	ves
Switch#	-

This example shows how to display the interface capabilities for the 10-Gigabit Ethernet interface 1/1:

```
Switch# show interfaces tengigabitethernet1/1 capabilities
```

1	TenGigabitEthernet1/1	
	Model:	WS-X4517-X2
	Туре:	10GBase-LR
	Speed:	10000
	Duplex:	full
	Trunk encap. type:	802.1Q,ISL
	Trunk mode:	on,off,desirable,nonegotiate
	Channel:	yes
	Broadcast suppression:	percentage(0-100), hw
	Flowcontrol:	<pre>rx-(off,on),tx-(off,on)</pre>
	VLAN Membership:	static, dynamic
	Fast Start:	yes
	Queuing:	rx-(N/A), $tx-(1p3q1t$, Sharing/Shaping)
	CoS rewrite:	yes
	ToS rewrite:	yes
	Inline power:	no
	SPAN:	source/destination
	UDLD:	yes
	Link Debounce:	no
	Link Debounce Time:	no
	Port Security:	yes
	Dot1x:	yes
	Maximum MTU:	9198 bytes (Jumbo Frames)
	Multiple Media Types:	no
	Diagnostic Monitoring:	N/A
ŝ	Switch#	

This example shows how to display the interface capabilities for Gigabit Ethernet interface 1/1:

```
Switch# show interfaces gigabitethernet1/1 capabilities GigabitEthernet1/1
```

GigabitEthernet1/1	
Model:	WS-X4014-Gbic
Type:	No Gbic
Speed:	1000
Duplex:	full
Trunk encap. type:	802.1Q,ISL
Trunk mode:	on,off,desirable,nonegotiate
Channel:	yes
Broadcast suppression	:percentage(0-100), hw
Flowcontrol:	<pre>rx-(off,on,desired),tx-(off,on,desired)</pre>
VLAN Membership:	static, dynamic
Fast Start:	yes
Queuing:	<pre>rx-(N/A), tx-(4qlt, Sharing/Shaping)</pre>
CoS rewrite:	yes
ToS rewrite:	yes
Inline power:	no
SPAN:	source/destination
UDLD:	yes
Link Debounce:	no
Link Debounce Time:	no
Port Security:	yes
Dot1x:	yes
MTU Supported:	jumbo frames, baby giants
Switch#	

This example shows how to display the interface capabilities for Fast Ethernet interface 3/1:

Switch# show interfaces fastethernet3/1 capabilities

FastEthernet3/1	_
Model:	WS-X4148-RJ-RJ-45
Type:	10/100BaseTX
Speed:	10,100,auto
Duplex:	half,full,auto
Trunk encap. type:	802.1Q,ISL
Trunk mode:	on,off,desirable,nonegotiate
Channel:	yes
Broadcast suppression	:percentage(0-100), sw
Flowcontrol:	rx-(none),tx-(none)
VLAN Membership:	static, dynamic
Fast Start:	yes
Queuing:	rx-(N/A), $tx-(4qlt, Shaping)$
CoS rewrite:	yes
ToS rewrite:	yes
Inline power:	no
SPAN:	source/destination
UDLD:	yes
Link Debounce:	no
Link Debounce Time:	no
Port Security:	yes
Dot1x:	yes
MTU Supported:	no jumbo frames, baby giants
Switch#	

Related Commands show interfaces counters

show interfaces counters

To display the traffic on the physical interface, use the show interfaces counters command.

show interfaces counters [all | detail | errors | storm-control | trunk] [module mod]

Syntax Description	all	(Optional) Displays all the interface counters including errors, trunk, and detail.					
	detail	(Optional) Displays the detailed interface counters.					
	errors	(Optional) Displays the interface error counters.					
	storm-control	(Optional) Displays the number of packets discarded due to suppression on the interface.					
	trunk	(Optional) Displays the interface trunk counters.					
	module mod	(Optional) Limits the display to interfaces on a specific module.					
Defaults	This command h	nas no default settings.					
Command Modes	Privileged EXEC	2					
Command History	Release	Modification					
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.					
	12.1(19)EW	Support for storm control.					
	12.2(18)EW	Support for the display of total suppression discards.					
Usage Guidelines	If you do not ent	ter any keywords, all the counters for all modules are displayed					
Usaye Guidennes	If you do not enter any keywords, all the counters for all modules are displayed. The display for the storm-control keyword includes the suppressed multicast bytes.						
	The display for t						
Examples	This example sh	ows how to display the error counters for a specific module:					
-	Switch# show i	nterfaces counters errors module 1					
	Port Al: Gi1/1 Gi1/2	ign-Err FCS-Err Xmit-Err Rcv-Err UnderSize 0 0 0 0 0 0 0 0 0 0 0					
	Port Sing Gi1/1	le-Col Multi-Col Late-Col Excess-Col Carri-Sen Runts Giants 0 0 0 0 0 0 0 0 0					
	Gi1/2 Switch#						
	This example sh	ows how to display the traffic that is seen by a specific module:					
	Switch# show i	nterfaces counters module 1					
	Port	InOctets InUcastPkts InMcastPkts InBcastPkts					

Gi1/1	0	0	0	0
Gi1/2	0	0	0	0
Port	OutOctets	OutUcastPkts	OutMcastPkts	OutBcastPkts
Gi1/1	0	0	0	0
Gi1/2	0	0	0	0
Switch#				

This example shows how to display the trunk counters for a specific module:

```
Switch# show interfaces counters trunk module 1
```

Port	TrunkFramesTx	TrunkFramesRx	WrongEncap
Gi1/1	0	0	0
Gi1/2	0	0	0
Switch#			

This example shows how to display the number of packets that are discarded due to suppression:

Switch# show interfaces counters storm-control

Multicast Suppression : Enabled

Port	BcastSuppLevel	TotalSuppressionDiscards
Fa5/35	10.00%	6278550
Switch#		

Related Commands show interfaces capabilities

show interfaces description

To display a description and status of an interface, use the show interfaces description command.

show interfaces [interface] description

Syntax Description	interface	(Optional)	Type of inter	face.
Defaults	This comm	and has no defa	ult settings.	
Command Modes	Privileged 1	EXEC		
Command History	Release	Modific	ation	
	12.1(8a)EV	W Support	for this com	nmand was introduced on the Catalyst 4500 series switch.
Examples	This examp	ble shows how to	o display inf	formation for all interfaces:
	Switch# sh	now interfaces	descriptio	n
	Interface		Protocol	Description
	PO0/0 PO0/1	admin down	down	First interface
	Gi1/1	admin down up	down up	GigE to server farm

show interfaces link

To display how long a cable has been disconnected from an interface, use the **show interfaces link** command:

show interfaces link [module mod_num]

Syntax Description	<pre>module mod_nu</pre>	<i>m</i> (Optional) Limits the display to interfaces on a module.				
Defaults	This command h	as no default settings.				
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.2(18)EW	Support for this command was introduced on the Catalyst 4500 series switch.				
Usage Guidelines		ate is up, the command displays 0:00. If the interface state is down, the time (in hours, onds) is displayed.				
Examples	This example shows how to display active link-level information:					
	Switch# show in					
	Port Name	Down Time				
	Gi1/1 Gi1/2	00:00:00 00:00:00				
	Gi3/1	00:00:00				
	Gi3/2	00:00:00				
	Fa4/1	00:00:00				
	Fa4/2	00:00:00				
	Fa4/3	00:00:00				
	Fa4/4 00:00:00					
	This example shows how to display inactive link-level information: Switch# show interfaces link					
	Switch# show in	terfaces link				
	Port Name	Down Time				
	Gi3/4	1 minute 28 secs				
	Gi3/5	1 minute 28 secs				
	Gi3/6 Gi4/1	1 minute 28 secs 1 minute 28 secs				
		the cable has been disconnected from the port for 1 minute and 28 seconds.				

show interfaces mtu

To display the maximum transmission unit (MTU) size of all the physical interfaces and SVIs on the switch, use the **show interfaces mtu** command.

show interfaces mtu [module mod]

Syntax Description	module mod	(Optional) Limits the display to interfaces on a specific module.
Defaults	This command	has no default settings.
ommand Modes	EXEC	
ommand History	Release	Modification
Command History	Release 12.1(13)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch
Command History Examples	12.1(13)EW This example s	
	12.1(13)EW This example s	Support for this command was introduced on the Catalyst 4500 series switch shows how to display the MTU size for all interfaces on module 1:
	12.1(13)EW This example s Switch> show	Support for this command was introduced on the Catalyst 4500 series switch shows how to display the MTU size for all interfaces on module 1: interfaces mtu module 1
	12.1(13)EW This example s Switch> show Port Name	Support for this command was introduced on the Catalyst 4500 series switch shows how to display the MTU size for all interfaces on module 1: interfaces mtu module 1 MTU

Related Commands mtu

show interfaces private-vlan mapping

To display PVLAN mapping information for VLAN SVIs, use the **show interfaces private-vlan mapping** command.

show interfaces private-vlan mapping [active]

Syntax Description	active (C	Optional) Displays active interfaces only.
Defaults	This command	has no default settings.
Command Modes	Privileged EXE	C
Command History	Release	Modification
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Usage Guidelines Examples		displays SVI information only. nows how to display PVLAN mapping information:
•	Switch# show i	nterfaces private-vlan mapping ndary VLAN Type
	vlan2 301 vlan2 302 Switch#	isolated isolated
Related Commands	private-vlan private-vlan m	apping

show interfaces status

To display the interface status or a list of interfaces in error-disabled state, use the **show interfaces status** command.

show interfaces status [err-disabled]

Syntax Description	ription err-disabled (Optional) Displays interfaces in error-disabled state.						
Defaults	This command	has no default settings.					
Command Modes	Privileged EXE	BC .					
Command History	Release	Modification					
	12.1(8a)EW		nd was int	roduced or	the C	atalyst 4500 series switch.	
Examples	This example s	This example shows how to display the status of all interfaces:					
	SWILCH# SHOW .	Interfaces status					
	Port Name	Status	Vlan	Duplex	Speed	Туре	
	Gi1/1	disabled	routed			missing	
	Gi1/2	notconnect	1	full		unknown (4)	
	Fa5/1	disabled	routed	auto		10/100BaseTX	
	Fa5/2	disabled	routed	auto		10/100BaseTX	
	Fa5/3	disabled	routed	auto		10/100BaseTX	
	Fa5/4	disabled	routed	auto	auto	10/100BaseTX	
	···					10/1000	
	Fa5/15	disabled	routed	auto		10/100BaseTX	
	Fa5/16	disabled	routed	auto		10/100BaseTX	
	Fa5/17 Switch#	disabled	routed	auto	auto	10/100BaseTX	
	This example s	This example shows how to display the status of interfaces in an error-disabled state:					
	Switch# show :	interfaces status err-di	sabled				
	Port Name Fa9/4	Status notconnect	Reason link-f				
	informational error message when the timer expires on a cause						
	5d04h:%PM-SP- Switch#	5d04h:%PM-SP-4-ERR_RECOVER:Attempting to recover from link-flap err-disable state on Fa9/4					
Related Commands	errdisable dete show errdisab						

show interfaces switchport

To display the administrative and operational status of a switching (nonrouting) port, use the **show interfaces switchport** command.

show interfaces [interface-id] switchport [module mod]

Syntax Description	interface-id	(Optional) Interface ID for the physical port.			
	module mod(Optional) Limits the display to interfaces on the specified module; valid values are from 1 to 6.				
Defaults	This command I	has no default settings.			
command Modes	Privileged EXE	С			
Command History	Release	Modification			
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.			
	12.1(19)EW	Support for per-interface display.			
	12.2(18)EW	Support for displaying the status of native VLAN tagging in the command output.			
	Trunking Native Mode VLAN: 1 (default) Trunking VLANs Enabled: ALL Pruning VLANs Enabled: ALL Switch#				
	This example shows how to display switch-port information for module 1:				
	Switch# show i Name:Gi1/1 Switchport:Ena Administrative Operational Mo Administrative Negotiation of Access Mode VL Trunking Nativ Administrative Administrative Operational pr Trunking VLANS Pruning VLANS	<pre>interfaces switchport module 1 abled a Mode:dynamic auto ode:down a Trunking Encapsulation:negotiate Trunking:On LAN:1 (default) re Mode VLAN:1 (default) a private-vlan host-association:none a private-vlan mapping:none rivate-vlan:none</pre>			
	Name:Gi1/2 Switchport:Ena	ubled			

```
Administrative Mode:dynamic auto
Operational Mode:down
Administrative Trunking Encapsulation:negotiate
Negotiation of Trunking:On
Access Mode VLAN:1 (default)
Trunking Native Mode VLAN:1 (default)
Administrative private-vlan host-association:none
Administrative private-vlan mapping:none
Operational private-vlan:none
Trunking VLANs Enabled:ALL
Pruning VLANs Enabled:2-1001
Switch#
```

This example shows how to display the status of native VLAN tagging on the port:

```
Switch# show interfaces f3/1 switchport
show interface f3/1 switchport
Name: Fa3/1
Switchport: Enabled
Administrative Mode: private-vlan trunk promiscuous
Operational Mode: private-vlan trunk promiscuous
Administrative Trunking Encapsulation: negotiate
Operational Trunking Encapsulation: dotlq
Negotiation of Trunking: On
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Voice VLAN: none
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: 1
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dotlg
Administrative private-vlan trunk normal VLANs: 1
Administrative private-vlan trunk associations: none
Administrative private-vlan trunk mappings:
    10 (VLAN0010) 100 (VLAN0100)
Operational private-vlan:
  10 (VLAN0010) 100 (VLAN0100)
Trunking VLANs Enabled: ALL
Pruning VLANs Enabled: 2-1001
Capture Mode Disabled
Capture VLANs Allowed: ALL
Unknown unicast blocked: disabled
```

Unknown multicast blocked: disabled Appliance trust: none Switch#

Related Commands show interfaces capabilities show interfaces counters

show interfaces transceiver

To display diagnostic-monitoring data for all interfaces that have transceivers installed, use the **show** interfaces transceiver command.

show interfaces {{[int_name] transceiver {[detail]} | {transceiver [module mod] | detail
[module mod]}}

Syntax Description	int_name	(Optional) Interface.
	detail	(Optional) Displays the calibrated values and the A2D readouts if the readout values differ from the calibrated values. Also displays the high-alarm, high-warning, low-warning, and low-alarm thresholds.
	module mod	(Optional) Limits the display to interfaces on a specific module.
Defaults	The noninterfac	e-specific versions of the show interfaces transceiver command are enabled by default.
	a transceiver (G	becific versions of these commands are enabled by default if the specified interface has BIC or SFP) that is configured for diagnostic monitoring, and the transceiver is in a sports diagnostic monitoring.
Command Modes	Privileged EXE	C
Command History	Release	Modification
	12.1(20)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.2(18)EW	Support for the calibration keyword was withdrawn.
Usage Guidelines		faces transceiver command provides useful information under the following conditions:
	• At least one	e transceiver is installed on a chassis that is configured for diagnostic monitoring.
	• The transce	iver is in a module that supports diagnostic monitoring.
	If you notice the	at the alarm and warning flags have been set on a transceiver, reenter the command to

If you notice that the alarm and warning flags have been set on a transceiver, reenter the command to confirm.

Examples

This example shows how to display diagnostic monitoring data for all interfaces with transceivers installed on the switch:

Switch# show interfaces transceiver

++ : hig NA or N/	e is external h alarm, + : A: not applic iamperes, dBm	high war able, Tx:	ning, - : transmit,	low warni Rx: recei	ng, :	-
				Optical	Optical	
	Temperature	Voltage	Current	Tx Power	Rx Power	
Port	(Celsius)	(Volts)	(mA)	(dBm)	(dBm)	
	40.1					
Gi1/1	48.1	3.30	0.0	8.1 ++	N/A	
Gi1/2	33.0	3.30	1.8	-10.0	-36.9	
Gi2/1	43.7	5.03	50.6 +	-16.7	N/A	
Gi2/2	39.2	5.02	25.7	0.8	N/A	
witch#						

Switch#



Note The value for the Optical Tx Power (in dBm) equals ten times log (Tx Power in mW). If the Tx Power value is 3 mW, then the Optical Tx Power value equals 10 * log (3), which equals 10 * .477 or 4.77 dBm. The Optical Rx Power value behaves similarly. If the Tx Power or the Rx Power is zero, then its dBm value is undefined and is shown as N/A (not applicable).

This example shows how to display detailed diagnostic monitoring data, including calibrated values, alarm and warning thresholds, A2D readouts, and alarm and warning flags. The A2D readouts are reported separately in parentheses only if they differ from the calibrated values:

```
Switch# show interfaces transceiver detail
```

mA: milliamperes, dBm: decibels (milliwatts), NA or N/A: not applicable. ++ : high alarm, + : high warning, - : low warning, -- : low alarm. A2D readouts (if they differ), are reported in parentheses. The threshold values are calibrated.

	Temperature (Celsius)	(Celsius)	Threshold (Celsius)	Threshold (Celsius)	Threshold (Celsius)
		100.0			
Gi1/2	34.9	100.0	100.0	0.0	0.0
Gi2/1	43.5	70.0	60.0	5.0	0.0
	39.1	70.0	60.0	5.0	0.0
		High Alarm	High Warn	Low Warn	Low Alarm
	Voltage	Threshold	Threshold	Threshold	Threshold
Port	(Volts)	(Volts)		. ,	. ,
Gi1/1		6.50			
Gi1/2	3.30	6.50	6.50	N/A	N/A
Gi2/1	5.03	5.50	5.25	4.75	4.50
Gi2/2	5.02	5.50	5.25	4.75	4.50
	Current	High Alarm Threshold	5		
	(milliamperes)		(mA)		
	0.0	130.0			N/A
Gi1/2	1.7	130.0	130.0	N/A	N/A
Gi2/1	50.6 +	60.0	40.0	10.0	5.0
Gi2/2	25.8	60.0	40.0	10.0	5.0

Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
	8.1 ++		8.1	N/A	N/A
Gi1/2	-9.8	8.1	8.1	N/A	N/A
Gi2/1	-16.7 (-13.0)	3.4	3.2	-0.3	-0.5
Gi2/2	0.8 (5.1)	3.4	3.2	-0.3	-0.5
Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Threshold	Low Alarm Threshold (dBm)
Gi1/1	N/A	8.1	8.1	N/A	N/A
Gi1/2	-30.9	8.1	8.1	N/A	N/A
	N/A (-28.5)	5.9	-6.7	-28.5	
Gi2/2	N/A (-19.5)	5.9	-6.7	-28.5	-28.5
itch#					

Switch#

This example shows how to display the monitoring data for the interfaces that have transceivers installed on module 2:

Switch# show interfaces transceiver module 2

If device is externally calibrated, only calibrated values are printed. ++ : high alarm, + : high warning, - : low warning, -- : low alarm. NA or N/A: not applicable, Tx: transmit, Rx: receive. mA: milliamperes, dBm: decibels (milliwatts).

				Optical	Optical
	Temperature	Voltage	Current	Tx Power	Rx Power
Port	(Celsius)	(Volts)	(mA)	(dBm)	(dBm)
Gi2/1	43.7	5.03	50.6 +	-16.7	N/A
Gi2/2	39.2	5.02	25.7	0.8	N/A
Switch#					

This example shows how to display the detailed monitoring data for the interfaces that have transceivers installed on module 2:

Switch# show interfaces transceiver detail module 2 $% \left({{\left({{{\left({{{\left({{{\left({{{\left({{{c}}}} \right)}} \right.}$

mA: milliamperes, dBm: decibels (milliwatts), NA or N/A: not applicable. ++ : high alarm, + : high warning, - : low warning, -- : low alarm. A2D readouts (if they differ), are reported in parentheses. The threshold values are calibrated.

Port	Temperature (Celsius)	High Alarm Threshold (Celsius)	High Warn Threshold (Celsius)	Low Warn Threshold (Celsius)	Low Alarm Threshold (Celsius)
Gi2/1	43.5	70.0	60.0	5.0	0.0
Gi2/2	39.1	70.0	60.0	5.0	
Port	Voltage (Volts)	High Alarm Threshold (Volts)	High Warn Threshold (Volts)	Low Warn Threshold (Volts)	Low Alarm Threshold (Volts)
Gi2/1	5.03	5.50	5.25	4.75	4.50
Gi2/2	5.02	5.50	5.25	4.75	4.50

Port	Current (milliamperes)	High Alarm Threshold (mA)	Threshold	Threshold (mA)	Threshold
Gi2/1	50.6 +	60.0	40.0	10.0	5.0
Gi2/2	25.8	60.0	40.0	10.0	5.0
Port	Optical Transmit Power (dBm)	Threshold	Threshold	Threshold	Threshold
	-16.7 (-13.0) 0.8 (5.1)				
Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	Threshold	Threshold	Threshold
	N/N (20 E)				
	N/A (-28.5) N/A (-19.5)				-28.5
Switch#	14/11 (19.9)	5.5	0.7	20.5	20.5

This example shows how to display the monitoring data for the transceivers on interface Gi1/2:

```
Switch# show interfaces g1/2 transceiver
ITU Channel 23 (1558.98 nm),
Transceiver is externally calibrated.
If device is externally calibrated, only calibrated values are printed.
++ : high alarm, + : high warning, - : low warning, -- : low alarm.
NA or N/A: not applicable, Tx: transmit, Rx: receive.
mA: milliamperes, dBm: decibels (milliwatts).
```

				Optical	Optical
	Temperature	Voltage	Current	Tx Power	Rx Power
Port	(Celsius)	(Volts)	(mA)	(dBm)	(dBm)
Gi2/1	43.7	5.03	50.6 +	-16.7	N/A
Switch#					

This example shows how to display detailed the monitoring data for the transceivers on interface Gi1/2:

Switch# show interfaces g1/2 transceiver detail

```
ITU Channel 23 (1558.98 nm),
Transceiver is externally calibrated.
mA: milliamperes, dBm: decibels (milliwatts), NA or N/A: not applicable.
++ : high alarm, + : high warning, - : low warning, -- : low alarm.
A2D readouts (if they differ), are reported in parentheses.
The threshold values are calibrated.
```

Port	Temperature (Celsius)	High Alarm Threshold (Celsius)	High Warn Threshold (Celsius)	Low Warn Threshold (Celsius)	Low Alarm Threshold (Celsius)
Gi2/1	43.5	70.0	60.0	5.0	0.0
Port	Voltage (Volts)	High Alarm Threshold (Volts)	High Warn Threshold (Volts)	Low Warn Threshold (Volts)	Low Alarm Threshold (Volts)
Gi2/1	5.03	5.50	5.25	4.75	4.50

Port	Current (milliamperes)	Threshold	High Warn Threshold (mA)		Low Alarm Threshold (mA)
Gi2/1	50.6 +	60.0	40.0	10.0	5.0
Port	Optical Transmit Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gi2/1	-16.7 (-13.0)			-0.3	-0.5
Port	Optical Receive Power (dBm)	High Alarm Threshold (dBm)	High Warn Threshold (dBm)	Low Warn Threshold (dBm)	Low Alarm Threshold (dBm)
Gi2/1	N/A (-28.5)		-6.7	-28.5	-28.5

Switch#

Related Commands

show idprom show interfaces status

show interfaces trunk

To display port and module interface-trunk information, use the show interfaces trunk command.

show interfaces trunk [module mod]

	module	· ·	ptional) Limits the c m 1 to 6.	lisplay to interfa	ces on the specified module; valid values are	
Defaults	This com	imand has no	default settings.			
Command Modes	Privilege	d EXEC				
Command History	Release	Мос	lification			
	12.1(8a)	EW Sup	port for this comma	and was introduc	ced on the Catalyst 4500 series switch.	
Examples	This exa	mple shows ho	ow to display interfa	ace-trunk inform	nation for module 5:	
Examples	This example shows how to display interface-trunk information for module 5:					
	Switch#	show interfa	ces trunk module	5		
	Port	Mode	Encapsulation	Status	Native vlan	
	<i>1</i>		negotiate	routed	1	
	Fa5/1	routed	negocrace		1	
	Fa5/1 Fa5/2	routed	negotiate	routed	1	
	Fa5/2 Fa5/3 Fa5/4	routed	negotiate negotiate negotiate	routed	1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5	routed routed routed routed	negotiate negotiate negotiate negotiate	routed routed routed routed	1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6	routed routed routed routed off	negotiate negotiate negotiate negotiate negotiate	routed routed routed routed not-trunking	1 1 1 10	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7	routed routed routed off off	negotiate negotiate negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking	1 1 1 10 10	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8	routed routed routed off off off	negotiate negotiate negotiate negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking	1 1 1 10 10 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9	routed routed routed off off off desirable	negotiate negotiate negotiate negotiate negotiate negotiate n-isl	routed routed routed not-trunking not-trunking not-trunking trunking	1 1 1 1 10 10 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8	routed routed routed off off off	negotiate negotiate negotiate negotiate negotiate negotiate n-isl negotiate	routed routed routed not-trunking not-trunking not-trunking	1 1 1 10 10 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10	routed routed routed off off desirable desirable	negotiate negotiate negotiate negotiate negotiate negotiate n-isl	routed routed routed not-trunking not-trunking not-trunking trunking not-trunking	1 1 1 1 10 10 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11	routed routed routed off off desirable desirable routed	negotiate negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed	1 1 1 1 10 10 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12	routed routed routed off off desirable desirable routed	negotiate negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed	1 1 1 1 10 10 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port	routed routed routed off off desirable desirable routed routed Vlans allo	negotiate negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1	routed routed routed off off desirable desirable routed routed Vlans allo none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/1 Fa5/2	routed routed routed off off desirable desirable routed routed Vlans allo none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/2 Fa5/3	routed routed routed off off desirable desirable routed routed Vlans allo none none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/2 Fa5/3 Fa5/4	routed routed routed off off desirable routed routed Vlans allo none none none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/2 Fa5/3 Fa5/4 Fa5/5	routed routed routed off off desirable desirable routed routed Vlans allo none none none none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6	routed routed routed off off desirable routed routed Vlans allo none none none none none none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	
	Fa5/2 Fa5/3 Fa5/4 Fa5/5 Fa5/6 Fa5/7 Fa5/8 Fa5/9 Fa5/10 Fa5/11 Fa5/12 Fa5/48 Port Fa5/1 Fa5/2 Fa5/3 Fa5/4 Fa5/5	routed routed routed off off desirable desirable routed routed Vlans allo none none none none none	negotiate negotiate negotiate negotiate negotiate n-isl negotiate negotiate negotiate negotiate	routed routed routed not-trunking not-trunking not-trunking not-trunking routed routed	1 1 1 1 10 10 1 1 1 1 1 1	

D= E / 1 0	
Fa5/10	none
Fa5/11	none
Fa5/12	none
Fa5/48	none
145/40	none
Port	Vlans allowed and active in management domain
Fa5/1	none
Fa5/2	none
Fa5/3	none
Fa5/4	none
Fa5/5	none
Fa5/6	none
Fa5/7	none
Fa5/8	200
Fa5/9	1-6,10,20,50,100,152,200,300,303-305,349-351,400,500,521,524,570,801-8
02,850,91	17,999,1002-1005
Fa5/10	none
Fa5/11	none
Fa5/12	none
Fa5/48	none
Port	Vlans in spanning tree forwarding state and not pruned
Fa5/1	none
Fa5/2	none
Fa5/3	none
Fa5/4	none
Fa5/5	none
Fa5/6	none
Fa5/7	none
Fa5/8	200
Fa5/9	1-6,10,20,50,100,152,200,300,303-305,349-351,400,500,521,524,570,801-8
	L7,999,1002-1005
Fa5/10	none
Fa5/11	none
1 43/11	
Fa5/48	none
Switch#	
This even	anle shows how to display trunking information for active trunking ports.

This example shows how to display trunking information for active trunking ports:

Switch# show interfaces trunk

Port Mode Encapsulation Status Native vlan Fa5/9 desirable n-isl trunking 1 Vlans allowed on trunk Port Fa5/9 1-1005 Vlans allowed and active in management domain Port Fa5/9 1-6,10,20,50,100,152,200,300,303-305,349-351,400,500,521,524,570,801-8 02,850,917,999,1002-1005 Vlans in spanning tree forwarding state and not pruned Port 1-6, 10, 20, 50, 100, 152, 200, 300, 303-305, 349-351, 400, 500, 521, 524, 570, 801-8 Fa5/9 02,850,917,999,1002-1005 Switch#
show ip arp inspection

To show the status of dynamic ARP inspection for a specific range of VLANs, use the **show ip arp inspection** command.

show ip arp inspection {[statistics] vlan vlan-range | interfaces [interface-name]}

Syntax Description	statisti	ics	have been		s for the following types of packets that feature: forwarded, dropped, MAC lidation failure.	
	vlan vlan-range(Optional) When used with the statistics keyword, displays to statistics for the selected range of VLANs. Without the statistics keyword, displays the configuration and operating state of DA selected range of VLANs.					
	interfa	aces interface-name	the provid command	led interface. When	state and the rate limit of ARP packets for n the interface name is not specified, the state and rate limit for all applicable	
Defaults	This co	mmand has no defat	ult settings.			
Command Modes	Privileg	ged EXEC				
Command History	Releas	e Modifica	ation			
	12.1(1	9)EW Support	for this comm	and was introduced	d on the Catalyst 4500 series switch.	
Examples	This ex VLAN	-	display the st	atistics of packets	that have been processed by DAI for	
	Switch	# show ip arp insp	ection statis	stics vlan 3		
	Vlan	Forwarded	Dropped	DHCP Drops	ACL Drops	
	3	31753	102407	102407	0	
	Vlan	DHCP Permits	ACL Permits	Source MAC Fail	lures	
	3	31753	0		0	
	Vlan	Dest MAC Failure	s IP Valida	ation Failures		
	 3 Switch:	 0		0		

This example shows how to display the statistics of packets that have been processed by DAI for all active VLANs:

Vlan	Forwarded	Dropped	DHCP Drops	ACL Drops
1	0	0	0	0
2	0	0	0	0
3	68322	220356	220356	0
4	0	0	0	0
100	0	0	0	0
101	0	0	0	0
1006	0	0	0	0
1007	0	0	0	0
Vlan	DHCP Permits	ACL Permits	Source MAC Fa	ilures
1	0	0		0
2	0	0		0
3	68322	0		0
4	0	0		0
100	0	0		0
101	0	0		0
1006	0	0		0
1007	0	0		0
Vlan	Dest MAC Failure		tion Failures	
1	()	0	
2	()	0	
3	()	0	
4	()	0	
100	()	0	
101	()	0	
1006	()	0	
1007	()	0	
Switch#				

Switch# show ip arp inspection statistics

This example shows how to display the configuration and operating state of DAI for VLAN 1:

```
Switch# show ip arp inspection vlan 1 % \left( {{{\bf{n}}_{{\rm{n}}}} \right)
Source Mac Validation : Disabled
Destination Mac Validation : Disabled
IP Address Validation : Disabled
      Configuration Operation ACL Match
Vlan
                                                  Static ACL
 ____
        -----
                       -----
                                                    _____
        Enabled
                      Active
   1
        ACL Logging DHCP Logging
Vlan
 ____
  1
        Deny
                       Deny
Switch#
```

This example shows how to display the trust state of Fast Ethernet interface 6/1:

Switch# show ip arp inspection interfaces fastEthernet 6/1 Interface Trust State Rate (pps) Burst Interval ----- -----_____ 20 5 Fa6/1 Untrusted Switch#

This example shows how to display the trust state of the interfaces on the switch:

Switch# show ip Interface	arp inspection Trust State	interfaces Rate (pps)
Gi1/1	Untrusted	15
Gi1/2	Untrusted	15
Gi3/1	Untrusted	15
Gi3/2	Untrusted	15
Fa3/3	Trusted	None
Fa3/4	Untrusted	15
Fa3/5	Untrusted	15
Fa3/6	Untrusted	15
Fa3/7	Untrusted	15
Switch#		

Related Commands

arp access-list clear ip arp inspection log show ip arp inspection

show ip arp inspection log

To show the status of the log buffer, use the show ip arp inspection log command.

show ip arp inspection log

Syntax Description This co	mmand has no	o arguments or	keywords.
----------------------------	--------------	----------------	-----------

- **Defaults** This command has no default settings.
- Command Modes Privileged EXEC

 Release
 Modification

 12.1(19)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display the current contents of the log buffer before and after the buffers are cleared:

Switch# show ip arp inspection log Total Log Buffer Size : 10 Syslog rate : 0 entries per 10 seconds.

Interface	Vlan	Sender MAC	Sender IP	Num of Pkts
Fa6/3	1	0002.0002.0002	1.1.1.2	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.3	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.4	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.5	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.6	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.7	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.8	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.9	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.10	1(12:02:52 UTC Fri Apr 25 2003)
Fa6/3	1	0002.0002.0002	1.1.1.11	1(12:02:52 UTC Fri Apr 25 2003)
				5(12:02:52 UTC Fri Apr 25 2003)
Switch#				

This example shows how to clear the buffer with the **clear ip arp inspection log** command:

```
Switch# clear ip arp inspection log
Switch# show ip arp inspection log
Total Log Buffer Size : 10
Syslog rate : 0 entries per 10 seconds.
No entries in log buffer.
Switch#
```

Related Commands

arp access-list clear ip arp inspection log

show ip cef vlan

To view IP CEF VLAN interface status and configuration information and display the prefixes for a specific interface, use the **show ip cef vlan** command.

show ip cef vlan vlan_num [detail]

Syntax Description	vlan_num	Number of the VLAN.				
	detail (Optional) Displays detailed information.					
Defaults	This command	l has no default settings.				
Command Modes	Privileged EX	EC				
Command History	Release	Modification				
	12.1(8a)EW	Support for this command	l was introduced on the Catalyst 4500 series switch.			
Examples	Switch# show Prefix 0.0.0.0/0 0.0.0.0/32 10.7.0.0/16 10.16.18.0/23 Switch#		Interface FastEthernet3/3 FastEthernet3/3 FastEthernet3/3			
	This example shows how to display detailed IP CEF information for a specific VLAN: Switch# show ip cef vlan 1003 detail IP Distributed CEF with switching (Table Version 2364), flags=0x0 1383 routes, 0 reresolve, 0 unresolved (0 old, 0 new) 1383 leaves, 201 nodes, 380532 bytes, 2372 inserts, 989 invalidations 0 load sharing elements, 0 bytes, 0 references universal per-destination load sharing algorithm, id 9B6C9823 3 CEF resets, 0 revisions of existing leaves refcounts: 54276 leaf, 51712 node Adjacency Table has 5 adjacencies Switch#					

show ip dhcp snooping

To display the DHCP snooping configuration, use the show ip dhcp snooping command.

show ip dhcp snooping

- **Defaults** This command has no default settings.
- Command Modes Privileged EXEC

 Release
 Modification

 12.1(12c)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

 12.2(25)EWA
 Support for option 82 on untrusted ports was added.

Examples

This example shows how to display the DHCP snooping configuration:

Switch# show ip dhcp snooping Switch DHCP snooping is enabled DHCP snooping is configured on the following VLANs: 5 10 Insertion of option 82 is enabled Option82 on untrusted port is not allowed Verification of hwaddr field is enabled Interface Trusted Rate limit (pps) _____ ____ _____ FastEthernet6/11 10 no FastEthernet6/36 50 ves Switch#

Related Commandsip dhcp snooping
ip dhcp snooping information option
ip dhcp snooping limit rate
ip dhcp snooping trust
ip dhcp snooping vlan

show ip dhcp snooping binding

To display the DHCP snooping binding entries, use the show ip dhcp snooping binding command.

show ip dhcp snooping binding [ip-address] [mac-address] [vlan vlan_num]
[interface interface_num]

Syntax Description		
- /	n ip-address	(Optional) IP address for the binding entries.
	mac-address	(Optional) MAC address for the binding entries.
	vlan vlan_num	(Optional) Specifies a VLAN.
	<pre>interface interface_num</pre>	(Optional) Specifies an interface.
Defaults	If no argument is specified	l, the switch will display the entire DHCP snooping binding table.
Command Modes	Privileged EXEC	
Command History	Release Modific	cation
	12.1(12c)EW Support	t for this command was introduced on the Catalyst 4500 series switch.
Usage Guidelines		d on a VLAN only if both the global snooping and the VLAN snooping are
Jsage Guidelines	enabled.	
zamples	enabled. To configure a range of VI range. This example shows how t	
Examples Wwitch# show ig MacAddress	enabled. To configure a range of VI range. This example shows how t dhcp snooping binding IP Address Lease (secor	LANs, use the optional <i>last_vlan</i> argument to specify the end of the VLAN to display the DHCP snooping binding entries for a switch:
Examples	enabled. To configure a range of VI range. This example shows how t dhcp snooping binding IP Address Lease (secor	LANs, use the optional <i>last_vlan</i> argument to specify the end of the VLAN to display the DHCP snooping binding entries for a switch:
Examples Switch# show ig MacAddress	enabled. To configure a range of VI range. This example shows how t o dhcp snooping binding IP Address Lease (secor 10.0.0.1 1600	LANs, use the optional <i>last_vlan</i> argument to specify the end of the VLAN to display the DHCP snooping binding entries for a switch:
witch# show in WacAddress	enabled. To configure a range of VI range. This example shows how t o dhcp snooping binding IP Address Lease (secor 10.0.0.1 1600	LANs, use the optional <i>last_vlan</i> argument to specify the end of the VLAN to display the DHCP snooping binding entries for a switch: nds) Type VLAN Interface dhcp-snooping 100 FastEthernet3/1 to display an IP address for DHCP snooping binding entries:
Examples Switch# show ig MacAddress Supposed by Switch#	enabled. To configure a range of VI range. This example shows how t dhcp snooping binding IP Address Lease (secor 10.0.0.1 1600 This example shows how t	LANs, use the optional <i>last_vlan</i> argument to specify the end of the VLAN to display the DHCP snooping binding entries for a switch: nds) Type VLAN Interface

This example shows how to display the MAC address for the DHCP snooping binding entries:

Switch# show ip dhcp snooping binding 55.5.5.2 0002.b33f.3d5f

MacAddress	IpAddress	Lease(sec)	Туре	VLAN Interface
 00:02:B3:3F:3D:5F Switch#	55.5.5.2	492	dhcp-snooping	99 FastEthernet6/36

This example shows how to display the DHCP snooping binding entries' MAC address for a specific VLAN:

Switch# show ip dhcp snooping binding 55.5.5.2 0002.b33f.3d5f vlan 99

MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
 00:02:B3:3F:3D:5F Switch#	55.5.5.2	479	dhcp-snooping	99	FastEthernet6/36

This example shows how to display the dynamic DHCP snooping binding entries:

Switch# show ip dhcp snooping binding dynamic

MacAddress	IP Address	Lease (seconds)	Туре	VLAN	Interface	
0000.0100.0201	10.0.0.1	1600	dhcp-snooping	100	FastEthernet3/1	
Switch#						

This example shows how to display the DHCP snooping binding entries on VLAN 100:

Switch# show ip dhcp snooping binding vlan 100'

MacAddress	IP Address	Lease (seconds)	Туре	VLAN	Interface
0000.0100.0201 Switch#	10.0.0.1	1600	dhcp-snooping	100	FastEthernet3/1

This example shows how to display the DHCP snooping binding entries on Ethernet interface 0/1:

${\tt Switch} \#$ show ip dhcp snooping binding interface fastethernet3/1

MacAddress	IP Address	Lease (seconds)	Туре	VLAN	Interface
0000.0100.0201	10.0.0.1	1600	dhcp-snooping	100	FastEthernet3/1

Table 2-19 describes the fields in the show ip dhcp snooping command output.

Table 2-19show ip dhcp snooping Command Output

Field	Description
Mac Address	Client hardware MAC address.
IP Address	Client IP address assigned from the DHCP server.
Lease (seconds)	IP address lease time.
Туре	Binding type; statically configured from CLI or dynamically learned.
VLAN	VLAN number of the client interface.
Interface	Interface that connects to the DHCP client host.

Switch#

Related Commands

ip dhcp snooping information option ip dhcp snooping limit rate ip dhcp snooping trust

- ip igmp snooping
- ip igmp snooping vlan

show ip dhcp snooping database

To display the status of the DHCP snooping database agent, use the **show ip dhcp snooping database** command.

show ip dhcp snooping database [detail]

Syntax Description	detail (Optional) Provides additional operating state and statistics information.						
Defaults	This command l	as no default settings.					
Command Modes	Privileged EXEC						
Command History	Release	Modification					
-	12.1(12c)EW	Support for this command was introduced on the Catalyst 4500 series switch.					
	12.1(19)EW	Added support of state and statistics information.					
Examples	This example sh	ows how to display the DHCP snooping database:					
	Agent URL : Write delay Ti Abort Timer : Agent Running Delay Timer Ex Abort Timer Ex Last Succeded Last Failed Ti	: No piry : Not Running piry : Not Running Time : None me : None ason : No failure recorded. : 0 Startup Failures : 0 nsfers : 0 Failed Transfers : 0					
	Successful Wri Media Failures						
	Switch# show i Agent URL : tf Write delay Ti Abort Timer :						
		: No piry : 7 (00:00:07) piry : Not Running					

0

0 0

```
Last Succeded Time : None
Last Failed Time : 17:14:25 UTC Sat Jul 7 2001
Last Failed Reason : Unable to access URL.
Total Attempts :
Successful Transfers :
Successful Reads :
                         21 Startup Failures :
                                                       0
                         0 Failed Transfers :
                                                       21
                           0 Failed Reads :
                                                       0
                 :
Successful Writes
                           0
                               Failed Writes
                                                       21
                                             :
Media Failures :
                           0
First successful access: Read
Last ignored bindings counters :
Binding Collisions : 0
                                Expired leases
                                               :
                          0
Invalid interfaces :
                                Unsupported vlans :
Parse failures :
                           0
Last Ignored Time : None
Total ignored bindings counters:
Binding Collisions : 0
Invalid interfaces : 0
                                Expired leases :
                                Unsupported vlans :
Parse failures : 0
```

Switch#

Related Commands

ip dhcp snooping ip dhcp snooping database ip dhcp snooping information option ip dhcp snooping limit rate ip dhcp snooping trust ip dhcp snooping vlan

show ip igmp interface

To view IP IGMP interface status and configuration information, use the **show ip igmp interface** command.

show ip igmp interface [fastethernet slot/port | gigabitethernet slot/port |
 tengigabitethernet slot/port | null interface-number | vlan vlan_id]

Syntax Description		
	fastethernet slot/port	(Optional) Specifies the Fast Ethernet interface and the number of the slot and port.
	gigabitethernet slot/port	(Optional) Specifies the Gigabit Ethernet interface and the number of the slot and port; valid values are from 1 to 9.
	tengigabitethernet slot/port	(Optional) Specifies the 10-Gigabit Ethernet interface and the number of the slot and port; valid values are from 1 to 2.
	null interface-number	(Optional) Specifies the null interface and the number of the interface; the only valid value is 0 .
	vlan vlan_id	(Optional) Specifies the VLAN and the number of the VLAN; valid values are from 1 to 4094.
Defaults	If you do not specify	a VLAN, information for VLAN 1 is shown.
Command Modes	Privileged EXEC	
Command History	Release M	odification
	12.1(8a)EW Su	upport for this command was introduced on the Catalyst 4500 series switch.
	12.1(12c)EW A	dded support for extended VLAN addresses.
		dded support for extended VLAN addresses. dded support for the 10-Gigabit Ethernet interface.
Usage Guidelines	12.2(25)EW A	
Usage Guidelines Examples	12.2(25)EW A If you omit the option all interfaces.	dded support for the 10-Gigabit Ethernet interface.

Related Commandsclear ip igmp group
show ip igmp snooping mrouter

show ip igmp profile

To view all configured IGMP profiles or a specified IGMP profile, use the **show ip igmp profile** privileged EXEC command.

show ip igmp profile [profile number]

Syntax Description	profile number	(Optional) IGMP profile number to be displayed; valid ranges are from 1 to 4294967295.			
Defaults	This command ha	as no default settings.			
Command Modes	Privileged EXEC				
Command History	Release	Modification			
	12.1(11b)EW	Support for this command was introduced on the Catalyst 4500 series switch.			
Examples	This example sho	ws how to display IGMP profile 40:			
Examples	-	ws how to display IGMP profile 40: igmp profile 40			
	1 I	.1.1 233.255.255.255			
	This example shows how to display all IGMP profiles:				
	IGMP Profile 4 permit	igmp profile .9.0 230.9.9.0 .9.0 229.255.255.255			

Related Commands ip igmp profile

show ip igmp snooping

To display information on dynamically learned and manually configured VLAN switch interfaces, use the **show ip igmp snooping** command.

show ip igmp snooping [querier | groups | mrouter] [vlan vlan_id] a.b.c.d [summary | sources |
hosts] [count]

Syntax Description						
	querier	(Optional) Specifies that the display will contain IP address and version information.				
	groups	 (Optional) Specifies that the display will list VLAN members sorted by group IP addresses. (Optional) Specifies that the display will contain information on dynamically learned and manually configured multicast switch interfaces. (Optional) Specifies a VLAN; valid values are from 1 to 1001 and from 1006 to 4094 				
	mrouter					
	vlan vlan_id					
	a.b.c.d	Group or multicast IP address.				
	summary	(Optional) Specifies a display of detailed information for a v2 or v3 group.				
	sources	(Optional) Specifies a list of the source IPs for the specified group.				
	hosts	(Optional) Specifies a list of the host IPs for the specified group.				
	count	(Optional) Specifies a display of the total number of group addresses learned by the system on a global or per-VLAN basis.				
Defaults		has no default settings.				
Command Modes	EXEC					
Command Modes	EXEC Release	Modification				
Command Modes	EXEC Release 12.1(8a)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch.				
	EXEC Release	Modification				

Examples

This example shows how to display the global snooping information on the switch:

Switch# show ip igmp snooping

Global IGMP Snooping confi	gu	irati	on:
IGMP snooping IGMPv3 snooping Report suppression TCN solicit query TCN flood query count	:	Enab Enab Disa	led led
Vlan 1:			
IGMP snooping IGMPv2 immediate leave Explicit host tracking Multicast router learning CGMP interoperability mode		: : ode :	
Vlan 2:			
IGMP snooping IGMPv2 immediate leave Explicit host tracking Multicast router learning CGMP interoperability mode Switch>		: : ode :	Enabled Disabled Enabled pim-dvmrp IGMP_ONLY

This example shows how to display the snooping information on VLAN 2:

Switch# show ip igmp snooping vlan 2

Global IGMP Snooping configuration: IGMP snooping : Enabled

IGMPv3 snooping	:	Enabled
Report suppression	:	Enabled
TCN solicit query	:	Disabled
TCN flood query count	:	2

Vlan 2:

IGMP snooping : Enabled IGMPv2 immediate leave : Disabled Explicit host tracking : Enabled Multicast router learning mode : pim-dvmrp CGMP interoperability mode : IGMP_ONLY Switch>

This example shows how to display IGMP querier information for all VLANs on a switch:

Switch#	show ip igmp sn	ooping querier	
Vlan	IP Address	IGMP Version	Port
2	10.10.10.1	v2	Router
3	172.20.50.22	v3	Fa3/15
Switch>			

This example shows how to display IGMP querier information for VLAN 5 when running IGMPv2:

```
Switch# show ip igmp snooping querier vlan 5
IP address :5.5.5.10
IGMP version :v2
Port :Fa3/1
Max response time :10s
Switch>
```

This example shows how to display IGMP querier information for VLAN 5 when running IGMPv3:

Switch# show ip igmp	snooping querier vlan 5
IP address	:5.5.5.10
IGMP version	:v3
Port	:Fa3/1
Max response time	:10s
Query interval	:60s
Robustness variable	:2
Switch>	

This example shows how to display snooping information for a specific group:

```
Switch# show ip igmp snooping group
```

Vlan	Group	Version	Ports
2	224.0.1.40	v3	Router
2	224.2.2.2	v3	Fa6/2
Switch>			

This example shows how to display the group's host types and ports in VLAN 1:

Switch#	show ip igmp	snooping grou	ıp vlan 1	
Vlan	Group	Host Type	e Ports	
1	229.2.3.4	v3	fa2/1 fa2/3	
1	224.2.2.2	v3	Fa6/2	
Switch>				

This example shows how to display the group's host types and ports in VLAN 1:

```
        Switch#
        show ip igmp snooping group vlan 10 226.6.6.7

        Vlan
        Group
        Version
        Ports

        10
        226.6.6.7
        v3
        Fa7/13, Fa7/14

        Switch>
```

This example shows how to display the current state of a group with respect to a source IP address:

Switch# show ip igmp snooping group vlan 10 226.6.6.7 sources Source information for group 226.6.6.7: Timers: Expired sources are deleted on next IGMP General Query

SourceIP	Expires	Uptime	Inc Hosts	Exc Hosts
2.0.0.1	00:03:04	00:03:48	2	0
2.0.0.2	00:03:04	00:02:07	2	0
Switch>				

This example shows how to display the current state of a group with respect to a host MAC address:

Switch# show ip igmp snooping group vlan 10 226.6.6.7 hosts IGMPv3 host information for group 226.6.6.7 Timers: Expired hosts are deleted on next IGMP General Query Host (MAC/IP) Filter mode Expires Uptime # Sources

175.1.0.29	INCLUDE	stopped	00:00:51	2
175.2.0.30	INCLUDE	stopped	00:04:14	2
Switch>				

This example shows how to display summary information for a v3 group:

Switch# show ip igmp snooping	group vlan 10 226.6.6.7 summary
Group Address (Vlan 10)	: 226.6.6.7
Host type	: v3
Member Ports	: Fa7/13, Fa7/14
Filter mode	: INCLUDE
Expires	: stopped
Sources	: 2
Reporters (Include/Exclude)	: 2/0
Switch>	

This example shows how to display multicast router information for VLAN 1:

```
Switch# show ip igmp snooping mrouter vlan 1
vlan ports
1 Gi1/1,Gi2/1,Fa3/48,Router
Switch#
```

This example shows how to display the total number of group addresses learned by the system globally:

Switch# **show ip igmp snooping group count** Total number of groups: 54 Switch>

This example shows how to display the total number of group addresses learned on VLAN 5:

```
Switch# show ip igmp snooping group vlan 5 count
Total number of groups: 30
Switch>
```

Related Commands

ip igmp snooping ip igmp snooping vlan immediate-leave ip igmp snooping vlan mrouter ip igmp snooping vlan static show ip igmp interface show ip igmp snooping mrouter show mac-address-table multicast

show ip igmp snooping membership

To display host membership information, use the show ip igmp snooping membership command.

show ip igmp snooping membership [interface interface_num] [vlan vlan_id]
[reporter a.b.c.d] [source a.b.c.d group a.b.c.d]

Syntax Description	interface interface_num	(Optional) Displays IP address and version information of an interface.
	vlan vlan_id	(Optional) Displays VLAN members sorted by group IP address of a VLAN; valid values are from 1 to 1001 and from 1006 to 4094.
	reporter a.b.c.d	(Optional) Displays membership information for a specified reporter.
	source a.b.c.d	(Optional) Specifies a reporter, source, or group IP address.
	group a.b.c.d	(Optional) Displays all members of a channel (source, group), sorted by interface or VLAN.
Defaults	This command has no def	ault settings.
Command Modes	Privileged EXEC	
Command History	Release Modifi	cation
	12.1(20)EW Support	rt for this command was introduced on the Catalyst 4500 series switch.
	12.2(25)EW Added	support for the 10-Gigabit Ethernet interface.
Usage Guidelines	This command is valid on	ly if explicit host tracking is enabled on the switch.
Examples	This example shows how	to display host membership for the Gigabit Ethernet interface 4/1:
Examples	Switch# show ip igmp s #channels: 5 #hosts : 1	nooping membership interface gigabitethernet4/1
Examples	Switch# show ip igmp so #channels: 5 #hosts : 1 Source/Group Interface 40.40.40.2/224.10.10.10	
Examples	Switch# show ip igmp so #channels: 5 #hosts : 1 Source/Group Interface 40.40.40.2/224.10.10.10 40.40.40.4/224.10.10.10 Switch#	nooping membership interface gigabitethernet4/1 Reporter Uptime Last-Join Last-Leave 0 Gi4/1 20.20.20.20 00:23:37 00:06:50 00:20:30
Examples	Switch# show ip igmp so #channels: 5 #hosts : 1 Source/Group Interface 40.40.40.2/224.10.10.10 40.40.40.4/224.10.10.10 Switch# This example shows how Switch# show ip igmp so #channels: 5 #hosts : 1	nooping membership interface gigabitethernet4/1 Reporter Uptime Last-Join Last-Leave 0 Gi4/1 20.20.20.20 00:23:37 00:06:50 00:20:30 0Gi4/1 20.20.20.20 00:39:42 00:09:17 -

This example shows how to display host membership information for VLAN 20 and to delete the explicit host tracking:

Switch# show ip igmp snooping membership vlan 20 Snooping Membership Summary for Vlan 20 _____ Total number of channels:5 Total number of hosts :4 Interface Reporter Uptime Last-Join/ Source/Group Last-Leave _____ 40.0.0.1/224.1.1.1 Fa7/37 0002.4ba0.a4f6 00:00:04 00:00:04 / 40.0.0.2/224.1.1.1 Fa7/37 0002.fd80.f770 00:00:17 00:00:17 / 40.0.0.3/224.1.1.1 Fa7/36 20.20.20.20 00:00:04 00:00:04 / 40.0.0.4/224.1.1.1 Fa7/35 20.20.20.210 00:00:17 00:00:17 / 40.0.0.5/224.1.1.1 Fa7/37 0002.fd80.f770 00:00:17 00:00:17 / Switch# clear ip igmp snooping membership vlan 20 Switch#

Related Commands clear ip igmp snooping membership ip igmp snooping vlan explicit-tracking show ip igmp snooping vlan

show ip igmp snooping mrouter

To display information on the dynamically learned and manually configured multicast switch interfaces, use the **show ip igmp snooping mrouter** command.

show ip igmp snooping mrouter [{vlan vlan-id}]

Syntax Description	vlan vlan-id	(Optional) Specifies a VLAN; valid values are from 1 to 1001 and from 1006 to 4094.
Defaults	This command	has no default settings.
Command Modes	Privileged EXI	EC
Command History	Release	Modification
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(19)EW	Added support for extended VLAN addresses.
	You can displa	or a VLAN that has IGMP snooping enabled. y IGMP snooping information for the VLAN interfaces by entering the show ip igmp <i>vlan-num</i> command.
Examples	This example s	hows how to display snooping information for a specific VLAN:
	Switch# show vlan	ip igmp snooping mrouter vlan 1 ports
	+ 1 Switch#	Gi1/1,Gi2/1,Fa3/48,Switch
Related Commands	show ip igmp	ing vlan mrouter interface

show mac-address-table multicast

show ip igmp snooping vlan

To display information on the dynamically learned and manually configured VLAN switch interfaces, use the **show ip igmp snooping vlan** command.

show ip igmp snooping vlan vlan_num

Syntax Description	vlan_num	Number of the VLAN; valid values are from 1 to 1001 and from 1006 to 4094.	
Defaults	This command h	nas no default settings.	
Command Modes	Privileged EXE	C	
Command History	Release	Modification	
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.	
	12.1(12c)EW	Support for extended addressing was added.	
Usage Guidelines		e the show mac-address-table multicast command to display the entries in the MAC r a VLAN that has IGMP snooping enabled.	
Examples	This example shows how to display snooping information for a specific VLAN: Switch# show ip igmp snooping vlan 2 vlan 2		
	IGMP snooping IGMP snooping IGMP snooping IGMP snooping IGMP snooping	is globally enabled TCN solicit query is globally enabled global TCN flood query count is 2 is enabled on this Vlan immediate-leave is disabled on this Vlan mrouter learn mode is pim-dvmrp on this Vlan is running in IGMP_ONLY mode on this Vlan	
Related Commands	ip igmp snoopin ip igmp snoopin show ip igmp ir show ip igmp sn	ng vlan immediate-leave ng vlan mrouter ng vlan static	

show ip interface

To display the usability status of interfaces that are configured for IP, use the **show ip interface** command.

show ip interface [type number]

Syntax Description	type	(Optional) Interface type.
	number	(Optional) Interface number.
Defaults	This command	has no default settings.
Command Modes	EXEC	
Command History	Release	Modification
	12.2(25)EW	Extended to include the 10-Gigabit Ethernet interface.
Usage Guidelines	interface is usa If the software from the routin determine back	software automatically enters a directly connected route in the routing table if the able. A usable interface is one through which the software can send and receive packets. determines that an interface is not usable, it removes the directly connected routing entry ing table. Removing the entry allows the software to use dynamic routing protocols to kup routes to the network, if any.
		able, the interface is marked "up."
		an optional interface type, you see information only on that specific interface.
	If you specify	no optional arguments, you see information on all the interfaces.
	fast switching	chronous interface is encapsulated with PPP or Serial Line Internet Protocol (SLIP), IP is enabled. The show ip interface command on an asynchronous interface that is with PPP or SLIP displays a message indicating that IP fast switching is enabled.
Examples	This example s	shows how to display the usability status for a specific VLAN:
	Vlan1 is up, Internet ad Broadcast a Address det MTU is 1500 Helper addr Directed br Outgoing ac	ress is not set roadcast forwarding is disabled rcess list is not set rcess list is not set

Local Proxy ARP is disabled Security level is default Split horizon is enabled ICMP redirects are always sent ICMP unreachables are always sent ICMP mask replies are never sent IP fast switching is enabled IP fast switching on the same interface is disabled IP Flow switching is disabled IP CEF switching is enabled IP Fast switching turbo vector IP Normal CEF switching turbo vector IP multicast fast switching is enabled IP multicast distributed fast switching is disabled IP route-cache flags are Fast, CEF Router Discovery is disabled IP output packet accounting is disabled IP access violation accounting is disabled TCP/IP header compression is disabled RTP/IP header compression is disabled Probe proxy name replies are disabled Policy routing is disabled Network address translation is disabled WCCP Redirect outbound is disabled WCCP Redirect inbound is disabled WCCP Redirect exclude is disabled BGP Policy Mapping is disabled Sampled Netflow is disabled IP multicast multilayer switching is disabled Netflow Data Export (hardware) is enabled Switch#

Table 2-20 describes the fields that are shown in the example.

Field	Description
Ethernet0 is up	If the interface hardware is usable, the interface is marked "up." For an interface to be usable, both the interface hardware and line protocol must be up.
line protocol is up	If the interface can provide two-way communication, the line protocol is marked "up." For an interface to be usable, both the interface hardware and line protocol must be up.
Internet address and subnet mask	IP address and subnet mask of the interface.
Broadcast address	Broadcast address.
Address determined by	Status of how the IP address of the interface was determined.
MTU	MTU value that is set on the interface.
Helper address	Helper address, if one has been set.
Secondary address	Secondary address, if one has been set.
Directed broadcast forwarding	Status of directed broadcast forwarding.
Multicast groups joined	Multicast groups to which this interface belongs.
Outgoing access list	Status of whether the interface has an outgoing access list set.
Inbound access list	Status of whether the interface has an incoming access list set.

Table 2-20 show ip interface Field Descriptions

Field	Description
Proxy ARP	Status of whether Proxy Address Resolution Protocol (ARP) is enabled for the interface.
Security level	IP Security Option (IPSO) security level set for this interface.
Split horizon	Status of split horizon.
ICMP redirects	Status of the redirect messages on this interface.
ICMP unreachables	Status of the unreachable messages on this interface.
ICMP mask replies	Status of the mask replies on this interface.
IP fast switching	Status of whether fast switching has been enabled for this interface. Fast switching is typically enabled on serial interfaces, such as this one.
IP SSE switching	Status of the IP silicon switching engine (SSE).
Router Discovery	Status of the discovery process for this interface. It is typically disabled on serial interfaces.
IP output packet accounting	Status of IP accounting for this interface and the threshold (maximum number of entries).
TCP/IP header compression	Status of compression.
Probe proxy name	Status of whether the HP Probe proxy name replies are generated.
WCCP Redirect outbound is enabled	Status of whether packets that are received on an interface are redirected to a cache engine.
WCCP Redirect exclude is disabled	Status of whether packets that are targeted for an interface are excluded from being redirected to a cache engine.
Netflow Data Export (hardware) is enabled	NDE hardware flow status on the interface.

Table 2-20	show in interface	Field Descriptions	(continued)
	Show ip internace		continucu/

show ip mfib

To display all active Multicast Forwarding Information Base (MFIB) routes, use the **show ip mfib** command.

show ip mfib [all | counters | log [n]]

Syntax Description	all	(Optional) Specifies all routes in the MFIB, including those routes that are used to accelerate fast switching but that are not necessarily in the upper-layer routing protocol table.
	counters	(Optional) Specifies the counts of MFIB-related events. Only nonzero counters are shown.
	log	(Optional) Specifies a log of the most recent number of MFIB-related events. The most recent event is first.
	n	(Optional) Number of events.
Defaults	This comma	and has no default settings.
Command Modes	Privileged E	XEC
Command History	Release	Modification
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Usage Guidelines		able contains a set of IP multicast routes; each route in the MFIB table contains several flag- te to the route.
	MFIB route	ags indicate how a packet that matches a route is forwarded. For example, the IC flag on an indicates that some process on the switch needs to receive a copy of the packet. These flag ed with MFIB routes:
		Copy (IC) flag—Set on a route when a process on the switch needs to receive a copy of al matching the specified route.
	the route	ng (S) flag—Set on a route when a switch process needs notification that a packet matching e is received. In the expected behavior, the protocol code updates the MFIB state in response ng received a packet on a signaling interface.
	the C fla	ted (C) flag—When set on a route, the C flag has the same meaning as the S flag, except tha ag indicates that only packets sent by directly connected hosts to the route should be signaled tocol process.
	on interface	also have a set of flags associated with one or more interfaces. For an (S,G) route, the flags 1 indicate how the ingress packets should be treated and whether packets matching the route orwarded onto interface 1. These per-interface flags are associated with the MFIB routes:
		ng (A)—Set on the RPF interface when a packet that arrives on the interface and that is as Accepting (A) is forwarded to all Forwarding (F) interfaces.

- Forwarding (F)—Used with the A flag as described above. The set of forwarding interfaces together form a multicast olist or output interface list.
- Signaling (S)—Set on an interface when a multicast routing protocol process in Cisco IOS needs to be notified of ingress packets on that interface.
- Not Platform (NP) fast-switched—Used with the F flag. A forwarding interface is also marked as Not Platform fast-switched whenever that output interface cannot be fast-switched by the platform hardware and requires software forwarding.

For example, the Catalyst 4006 switch with Supervisor Engine III cannot switch tunnel interfaces in hardware so these interfaces are marked with the NP flag. When an NP interface is associated with a route, a copy of every ingress packet arriving on an Accepting interface is sent to the switch software forwarding path for software replication and then forwarded to the NP interface.

Examples

This example shows how to display all active MFIB routes:

```
Switch# show ip mfib
IP Multicast Forwarding Information Base
Entry Flags: C - Directly Connected, S - Signal,
             IC - Internal Copy
Interface Flags: A - Accept, F - Forward, NS - Signal,
            NP - Not platform switched
Packets: Fast/Partial/Slow Bytes: Fast/Partial/Slow:
(171.69.10.13, 224.0.1.40), flags (IC)
  Packets: 2292/2292/0, Bytes: 518803/0/518803
  Vlan7 (A)
  Vlan100 (F NS)
  Vlan105 (F NS)
(*, 224.0.1.60), flags ()
   Packets: 2292/0/0, Bytes: 518803/0/0
  Vlan7 (A NS)
(*, 224.0.1.75), flags ()
   Vlan7 (A NS)
(10.34.2.92, 239.192.128.80), flags ()
  Packets: 24579/100/0, 2113788/15000/0 bytes
  Vlan7 (F NS)
  Vlan100 (A)
(*, 239.193.100.70), flags ()
  Packets: 1/0/0, 1500/0/0 bytes
  Vlan7 (A)
Switch#
```

Related Commands clear ip mfib counters

L

show ip mfib fastdrop

To show all currently active fast-drop entries and to show whether fast drop is enabled, use the **show ip mfib fastdrop** command.

show ip mfib fastdrop

- **Syntax Description** This command has no arguments or keywords.
- **Defaults** This command has no default settings.

Command Modes Privileged EXEC

 Release
 Modification

 12.1(8a)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display all currently active fast-drop entries and whether fast drop is enabled.

Switch# show ip mfib fasttdrop
MFIB fastdrop is enabled.
MFIB fast-dropped flows:
(10.0.0.1, 224.1.2.3, Vlan9) 00:01:32
(10.1.0.2, 224.1.2.3, Vlan9) 00:02:30
(1.2.3.4, 225.6.7.8, Vlan3) 00:01:50
Switch#

Related Commands clear ip mfib fastdrop

show ip mroute

To display IP multicast routing table information, use the show ip mroute command.

show ip mroute [interface_type slot/port | host_name | host_address [source] | active [kbps |
interface_type num] | count | pruned | static | summary]

Syntax Description	interface_type slot/port	(Optional) Interface type and number of the slot and port; valid values for <i>interface type</i> are fastethernet , gigabitethernet , tengigabitethernet , null , and vlan .
	host_name	(Optional) Name or IP address as defined in the DNS hosts table.
	host_address source	(Optional) IP address or name of a multicast source.
	active	(Optional) Displays the rate that active sources are sending to multicast groups.
	kbps interface_type num	(Optional) Minimum rate at which active sources are sending to multicast groups; active sources sending at this rate or greater will be displayed. Valid values are from 1 to 4294967295 kbps.
	count	(Optional) Displays the route and packet count information.
	pruned	(Optional) Displays the pruned routes.
	static	(Optional) Displays the static multicast routes.
	summary	(Optional) Displays a one-line, abbreviated summary of each entry in the IP multicast routing table.
Defaults Command Modes	This command has r Privileged EXEC	o default settings.
Command History	Release N	lodification
	12.1(8a)EW S	upport for this command was introduced on the Catalyst 4500 series switch.
	12.2(25)EW A	dded support for the 10-Gigabit Ethernet interface.
Usage Guidelines	entries in the IP mul The show ip mroute to <i>kbps</i> . The multicast routin entries. The star refe refers to the destination	ptional arguments and keywords, the show ip mroute command displays all the ticast routing table. active <i>kbps</i> command displays all the sources sending at a rate greater than or equal g table is populated by creating source, group (S,G) entries from star, group (*,G) ers to all source addresses, the "S" refers to a single source address, and the "G" ton multicast group address. In creating (S,G) entries, the software uses the best path roup found in the unicast routing table (through Reverse Path Forwarding (RPF).
	8-	

Examples This example shows how to display all the entries in the IP multicast routing table: Switch# show ip mroute IP Multicast Routing Table Flags:D - Dense, S - Sparse, s - SSM Group, C - Connected, L - Local, P - Pruned, R - RP-bit set, F - Register flag, T - SPT-bit set, J - Join SPT, M - MSDP created entry, X - Proxy Join Timer Running A - Advertised via MSDP, U - URD, I - Received Source Specific Host Report. Outgoing interface flags:H - Hardware switched Timers:Uptime/Expires Interface state: Interface, Next-Hop or VCD, State/Mode (*, 230.13.13.1), 00:16:41/00:00:00, RP 10.15.1.20, flags:SJC Incoming interface:GigabitEthernet4/8, RPF nbr 10.15.1.20 Outgoing interface list: GigabitEthernet4/9, Forward/Sparse-Dense, 00:16:41/00:00:00, H (*, 230.13.13.2), 00:16:41/00:00:00, RP 10.15.1.20, flags:SJC Incoming interface:GigabitEthernet4/8, RPF nbr 10.15.1.20, RPF-MFD Outgoing interface list: GigabitEthernet4/9, Forward/Sparse-Dense, 00:16:41/00:00:00, H (10.20.1.15, 230.13.13.1), 00:14:31/00:01:40, flags:CJT Incoming interface:GigabitEthernet4/8, RPF nbr 10.15.1.20, RPF-MFD Outgoing interface list: GigabitEthernet4/9, Forward/Sparse-Dense, 00:14:31/00:00:00, H (132.206.72.28, 224.2.136.89), 00:14:31/00:01:40, flags:CJT Incoming interface:GigabitEthernet4/8, RPF nbr 10.15.1.20, RPF-MFD Outgoing interface list:Null Switch#

This example shows how to display the rate that the active sources are sending to the multicast groups and to display only the active sources that are sending at greater than the default rate:

Switch# show ip mroute active

```
Active IP Multicast Sources - sending > = 4 kbps
Group: 224.2.127.254, (sdr.cisco.com)
Source: 146.137.28.69 (mbone.ipd.anl.gov)
Rate: 1 pps/4 kbps(lsec), 4 kbps(last 1 secs), 4 kbps(life avg)
Group: 224.2.201.241, ACM 97
Source: 130.129.52.160 (webcast3-e1.acm97.interop.net)
Rate: 9 pps/93 kbps(lsec), 145 kbps(last 20 secs), 85 kbps(life avg)
Group: 224.2.207.215, ACM 97
Source: 130.129.52.160 (webcast3-e1.acm97.interop.net)
Rate: 3 pps/31 kbps(lsec), 63 kbps(last 19 secs), 65 kbps(life avg)
Switch#
```

This example shows how to display route and packet count information:

Switch# show ip mroute count
IP Multicast Statistics
56 routes using 28552 bytes of memory
13 groups, 3.30 average sources per group
Forwarding Counts:Pkt Count/Pkts per second/Avg Pkt Size/Kilobits per second

```
Other counts:Total/RPF failed/Other drops(OIF-null, rate-limit etc)
Group:224.2.136.89, Source count:1, Group pkt count:29051
Source:132.206.72.28/32, Forwarding:29051/-278/1186/0, Other:85724/8/56665
Switch#
```

This example shows how to display summary information:

```
Switch# show ip mroute summary
IP Multicast Routing Table
Flags: D - Dense, S - Sparse, s - SSM Group, C - Connected, L - Local,
        P - Pruned, R - RP-bit set, F - Register flag, T - SPT-bit set,
        J - Join SPT, M - MSDP created entry, X - Proxy Join Timer Running
        A - Advertised via MSDP, U - URD, I - Received Source Specific Host
        Report
Outgoing interface flags: H - Hardware switched
Timers: Uptime/Expires
Interface state: Interface, Next-Hop or VCD, State/Mode
```

Switch#

Table 2-21 describes the fields shown in the output.

Field	Description
Flags:	Information about the entry.
D - Dense	Entry is operating in dense mode.
S - Sparse	Entry is operating in sparse mode.
s - SSM Group	Entry is a member of an SSM group.
C - Connected	Member of the multicast group is present on the directly connected interface.
L - Local	Switch is a member of the multicast group.
P - Pruned	Route has been pruned. This information is retained in case a downstream member wants to join the source.
R - Rp-bit set	Status of the (S,G) entry; is the (S,G) entry pointing toward the RP. The R - Rp-bit set is typically a prune state along the shared tree for a particular source.
F - Register flag	Status of the software; indicates if the software is registered for a multicast source.
T - SPT-bit set	Status of the packets; indicates if the packets been received on the shortest path source tree.

Field	Description			
J - Join SPT	For (*, G) entries, indicates that the rate of traffic flowing down the shared tree is exceeding the SPT-Threshold set for the group. (The default SPT-Threshold setting is 0 kbps.) When the J - Join SPT flag is set, the next (S,G) packet received down the shared tree triggers an (S,G) join in the direction of the source causing the switch to join the source tree.			
	For (S, G) entries, indicates that the entry was created because the SPT-Threshold for the group was exceeded. When the J - Join SPT flag is set for (S,G) entries, the switch monitors the traffic rate on the source tree and attempts to switch back to the shared tree for this source if the traffic rate on the source tree falls below the group's SPT-Threshold for more than one minute.			
	The switch measures the traffic rate on the shared tree and compares the measured rate to the group's SPT-Threshold once every second. If the traffic rate exceeds the SPT-Threshold, the J- Join SPT flag is set on the (*, G) entry until the next measurement of the traffic rate. The flag is cleared when the next packet arrives on the shared tree and a new measurement interval is started.			
	If the default SPT-Threshold value of 0 Kbps is used for the group, the J- Join SPT flag is always set on (*, G) entries and is never cleared. When the default SPT-Threshold value is used, the switch immediately switches to the shortest-path tree when traffic from a new source is received.			
Outgoing interface flag:	Information about the outgoing entry.			
H - Hardware switched	Entry is hardware switched.			
Timer:	Uptime/Expires.			
Interface state:	Interface, Next-Hop or VCD, State/Mode.			
(*, 224.0.255.1) (198.92.37.100/32, 224.0.255.1)	Entry in the IP multicast routing table. The entry consists of the IP address of the source switch followed by the IP address of the multicast group. An asterisk (*) in place of the source switch indicates all sources.			
	Entries in the first format are referred to as $(*,G)$ or "star comma G" entries. Entries in the second format are referred to as (S,G) or "S comma G" entries. $(*,G)$ entries are used to build (S,G) entries.			
uptime	How long (in hours, minutes, and seconds) the entry has been in the IP multicast routing table.			
expires	How long (in hours, minutes, and seconds) until the entry is removed from the IP multicast routing table on the outgoing interface.			

 Table 2-21
 show ip mroute Field Descriptions (continued)

Field

	•				
RP	Address of the RP switch. For switches and access servers operating in sparse mode, this address is always 0.0.0.0.				
flags:	Information about the entry.				
Incoming interface	Expected interface for a multicast packet from the source. If the packet is not received on this interface, it is discarded.				
RPF neighbor	IP address of the upstream switch to the source. "Tunneling" indicates that this switch is sending data to the RP encapsulated in Register packets. The hexadecimal number in parentheses indicates to which RP it is registering. Each bit indicates a different RP if multiple RPs per group are used.				
DVMRP or Mroute	Status of whether the RPF information is obtained from the DVMRP routing table or the static mroutes configuration.				
Outgoing interface list	Interfaces through which packets are forwarded. When the ip pim nbma-mode command is enabled on the interface, the IP address of the PIM neighbor is also displayed.				
Ethernet0	Name and number of the outgoing interface.				
Next hop or VCD	Next hop specifies downstream neighbor's IP address. VCD specifies the virtual circuit descriptor number. VCD0 indicates that the group is using the static-map virtual circuit.				
Forward/Dense	Status of the packets; indicates if they are they forwarded on the interface if there are no restrictions due to access lists or the TTL threshold. Following the slash (/), mode in which the interface is operating (dense or sparse).				
Forward/Sparse	Sparse mode interface is in forward mode.				
time/time (uptime/expiration time)	Per interface, how long (in hours, minutes, and seconds) the entry has been in the IP multicast routing table. Following the slash (/), how long (in hours, minutes, and seconds) until the entry is removed from the IP multicast routing table.				

 Table 2-21
 show ip mroute Field Descriptions (continued)

Description

Related Commands

ip multicast-routing (refer to Cisco IOS documentation) **ip pim** (refer to Cisco IOS documentation)

show ip source binding

To display IP source bindings that are configured on the system, use the **show ip source binding** EXEC command.

show ip source binding [ip-address] [mac-address] [dhcp-snooping | static] [vlan vlan-id]
[interface interface-name]

			nal) Binding IP a	ddress.		
Syntax Description	ip-address	(Optio	nai) Binding IF a			
	mac-address	(Optio	nal) Binding MA	C address.		
	dhcp-snooping	(Optio	nal) DHCP-snoo	ping type bin	ding.	
	static	(Optio	nal) Statically co	onfigured bind	ding.	
	vlan vlan-id	(Optio	nal) VLAN numl	ber.		
	interface interface-n	ame (Optio	nal) Binding inte	erface.		
Defaults	Displays both static a	and DHCP snoop	ing bindings.			
Command Modes	Privileged EXEC					
	Deleges	Modificatio				
Command History	Release	wodificatio	n			
Command History	12.1(19)EW			as introduced	on the Cata	lyst 4500 series switch
Jsage Guidelines	12.1(19)EW The optional paramet	Support for ers filter the dis	this command wa	t.	on the Cata	lyst 4500 series switch
Usage Guidelines	12.1(19)EW The optional paramet This example shows h	Support for ers filter the dis how to display th	this command wa	t.	on the Cata	lyst 4500 series switch
Jsage Guidelines	12.1(19)EW The optional paramet	Support for ers filter the dis how to display th	this command wa	t.		Interface
Jsage Guidelines	12.1(19)EW The optional paramet This example shows h Switch# show ip sou MacAddress	Support for ers filter the dis how to display th irce binding IpAddress	this command wa play output resul te IP source bind Lease(sec)	t. ings: Type	VLAN	Interface
Usage Guidelines	12.1(19)EW The optional paramet This example shows h Switch# show ip sou MacAddress	Support for ers filter the dis how to display th irce binding IpAddress	this command wa play output resul te IP source bind Lease(sec)	t. ings: Type	VLAN	Interface
Usage Guidelines	12.1(19)EW The optional paramet This example shows H Switch# show ip sou MacAddress 	Support for ers filter the dis how to display the irce binding IpAddress 	this command wa play output resul the IP source bind: Lease(sec) 	t. ings: Type 	VLAN 10	Interface FastEthernet6/10
Command History Usage Guidelines Examples	12.1(19)EW The optional paramet This example shows h Switch# show ip sou MacAddress 	Support for ers filter the dis how to display the irce binding IpAddress 	this command wa play output resul the IP source binds 	t. Type static ng entry of IP DA.000B stat	VLAN 10 Paddress 11 ic vlan 10 10 interfa	Interface FastEthernet6/10 .0.01: interface Fa6/10

Related Commands ip source binding

show ip verify source

To display the IP source guard configuration and filters on a particular interface, use the **show ip verify source** command.

show ip verify source [interface interface_num]

Syntax Description	interface <i>interface_num</i> (Optional) Specifies an interface.
Defaults	This command has no default settings.
Command Modes	Privileged EXEC
Command History	ReleaseModification12.1(19)EWSupport for this command was introduced on the Catalyst 4500 series switch.
Examples	 These examples show how to display the IP source guard configuration and filters on a particular interface with the show ip verify source interface command: This output appears when DHCP snooping is enabled on VLANs 10–20, interface fa6/1 has IP source filter mode that is configured as IP, and an existing IP address binding 10.0.0.1 is on VLAN 10:
	Interface Filter-type Filter-mode IP-address Mac-address Vlan
	fa6/1 ip active 10.0.0.1 10 fa6/1 ip active deny-all 11-20
	 Note The second entry shows that a default PVACL (deny all IP traffic) is installed on the port for those snooping-enabled VLANs that do not have a valid IP source binding. This output appears when you enter the show ip verify source interface fa6/2 command and DHCH snooping is enabled on VLANs 10–20, interface fa6/1 has IP source filter mode that is configured as IP, and there is an existing IP address binding 10.0.0.1 on VLAN 10:
	Interface Filter-type Filter-mode IP-address Mac-address Vlan
	fa6/2 ip inactive-trust-port
	• This output appears when you enter the show ip verify source interface fa6/3 command and the interface fa6/3 does not have a VLAN enabled for DHCP snooping:
	Interface Filter-type Filter-mode IP-address Mac-address Vlan
	fa6/3 ip inactive-no-snooping-vlan

• This output appears when you enter the **show ip verify source interface fa6/4** command and the interface fa6/4 has an IP source filter mode that is configured as IP MAC and the existing IP MAC that binds 10.0.0.2/aaaa.bbbb.cccc on VLAN 10 and 11.0.0.1/aaaa.bbbb.cccd on VLAN 11:

Interface	Filter-type	Filter-mode	IP-address	Mac-address	Vlan
fa6/4	ip-mac	active	10.0.2	aaaa.bbbb.cccc	10
fa6/4	ip-mac	active	11.0.0.1	aaaa.bbbb.cccd	11
fa6/4	ip-mac	active	deny-all	deny-all	12-20

• This output appears when you enter the **show ip verify source interface fa6/5** command and the interface fa6/5 has IP source filter mode that is configured as IP MAC and existing IP MAC binding 10.0.0.3/aaaa.bbbb.ccce on VLAN 10, but port security is not enabled on fa6/5:

Interface	Filter-type	Filter-mode	IP-address	Mac-address	Vlan
fa6/5 fa6/5	ip-mac ip-mac	active active	10.0.0.3 deny-all	permit-all permit-all	10 11-20

```
Note
```

Enable port security first because the DHCP security MAC filter cannot apply to the port or VLAN.

• This output appears when you enter the **show ip verify source interface fa6/6** command and the interface fa6/6 does not have IP source filter mode that is configured:

DHCP security is not configured on the interface fa6/6.

This example shows how to display all the interfaces on the switch that have DHCP snooping security enabled with the **show ip verify source** command.

The output is an accumulation of per-interface show CLIs:

Interface	Filter-type	Filter-mode	IP-address	Mac-address	Vlan
fa6/1	ip	active	10.0.1		10
fa6/1	ip	active	deny-all		11-20
fa6/2	ip	inactive-tru	st-port		
fa6/3	ip	inactive-no-	snooping-vlan		
fa6/4	ip-mac	active	10.0.2	aaaa.bbbb.cccc	10
fa6/4	ip-mac	active	11.0.0.1	aaaa.bbbb.cccd	11
fa6/4	ip-mac	active	deny-all	deny-all	12-20
fa6/5	ip-mac	active	10.0.3	permit-all	10
fa6/5	ip-mac	active	deny-all	permit-all	11-20

Related Commands

ip dhcp snooping information option ip dhcp snooping limit rate ip dhcp snooping trust ip igmp snooping ip igmp snooping vlan ip source binding ip verify source vlan dhcp-snooping show ip source binding
show ipc

To display IPC information, use the **show ipc** command. **show ipc** {**nodes** | **ports** | **queue** | **status**}

Syntax Description	nodes	Displays the participating nodes.					
	ports	Displays the local IPC ports.					
	queue	queue Displays the contents of the IPC retransmission queue.					
	status Displays the status of the local IPC server.						
	status						
Defaults	This command	has no default settings.					
Command Modes	Privileged EXE	2C					
Command History	Release	Modification					
,	12.1(12c)EW		oduced on the Catalyst 4500 series switch				
-	This example s	hows how to display the participating no	des:				
	Switch# show	-					
	There are 3 no ID Type	odes in this IPC realm. e Name	Last Last				
			Sent Heard				
	10000 Loca		0 0				
		2010000 Local GALIOS IPC:Card 0 0 2020000 Ethernet GALIOS IPC:Card 12 26					
	Switch#						
	This example shows how to display the local IPC ports:						
	Switch# show There are 11 p						
		Type Name (c	current/peak/total)				
	Port ID						
	10000.1	unicast IPC Master:Zone					
	10000.1 10000.2	unicast IPC Master:Echo					
	10000.1 10000.2 10000.3	unicast IPC Master:Echo unicast IPC Master:Control					
	10000.1 10000.2	unicast IPC Master:Echo					
	10000.1 10000.2 10000.3 10000.4 10000.5	unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port	0 heard = 1635 0/1/1635				
	10000.1 10000.2 10000.3 10000.4 10000.5	unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port unicast GALIOS RF :Active	0 heard = 1635 0/1/1635				
	10000.1 10000.2 10000.3 10000.4 10000.5 index = 0	<pre>unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port unicast GALIOS RF :Active 0 seat_id = 0x2020000 last sent =</pre>					
	10000.1 10000.2 10000.3 10000.4 10000.5 index = 0	<pre>unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port unicast GALIOS RF :Active 0 seat_id = 0x2020000 last sent = unicast GALIOS RED:Active</pre>	0 heard = 2 0/1/2				
	10000.1 10000.2 10000.3 10000.4 10000.5 index = (10000.6 index = (2020000.3 2020000.4	<pre>unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port unicast GALIOS RF :Active 0 seat_id = 0x2020000 last sent = unicast GALIOS RED:Active 0 seat_id = 0x2020000 last sent = unicast GALIOS IPC:Card 2:Contr unicast GALIOS RFS :Standby</pre>	0 heard = 2 0/1/2				
	10000.1 10000.2 10000.3 10000.4 10000.5 index = (10000.6 index = (2020000.3	<pre>unicast IPC Master:Echo unicast IPC Master:Control unicast Remote TTY Server Port unicast GALIOS RF :Active 0 seat_id = 0x2020000 last sent = unicast GALIOS RED:Active 0 seat_id = 0x2020000 last sent = unicast GALIOS IPC:Card 2:Contr</pre>	0 heard = 2 0/1/2				

show ipc

0/1/17

RPC packets: current/peak/total

Switch#

This example shows how to display the contents of the IPC retransmission queue:

```
Switch# show ipc queue
There are 0 IPC messages waiting for acknowledgement in the transmit queue.
There are 0 IPC messages waiting for a dditional fragments.
There are 0 IPC messages currently on the IPC inboundQ.
There are 0 messages currently in use by the system.
Switch#
```

This example shows how to display the status of the local IPC server:

Switch# show ipc status IPC System Status: This processor is the IPC master server. 6000 IPC message headers in cache 3363 messages in, 1680 out, 1660 delivered to local port, 1686 acknowledgements received, 1675 sent, 0 NACKS received, 0 sent, 0 messages dropped on input, 0 messages dropped on output 0 no local port, 0 destination unknown, 0 no transport 0 missing callback or queue, 0 duplicate ACKs, 0 retries, 0 message timeouts. 0 ipc_output failures, 0 mtu failures, 0 msg alloc failed, 0 emer msg alloc failed, 0 no origs for RPC replies 0 pak alloc failed, 0 memd alloc failed 0 no hwq, 1 failed opens, 0 hardware errors No regular dropping of IPC output packets for test purposes Switch#

show I2protocol-tunnel

show I2protocol-tunnel

To display information about the Layer 2 protocol tunnel ports, use the **show l2protocol-tunnel** command. This command displays information for the interfaces with protocol tunneling enabled.

show l2protocol-tunnel [interface interface-id] [[summary] | {begin | exclude | include}
expression]

Syntax Description	interface interface-id	(Optional) Specifies the interface for which protocol tunneling information appears. Valid interfaces are physical ports and port channels; the port channel range is 1 to 64.				
	summary	(Optional) Displays only Layer 2 protocol summary information.				
	begin	(Optional) Displays information beginning with the line that matches the <i>expression</i> .				
	exclude	(Optional) Displays information that excludes lines that match the <i>expression</i> .				
	include	(Optional) Displays the lines that match the specified <i>expression</i> .				
	expression	(Optional) Expression in the output to use as a reference point.				

Command Modes User EXEC

Command History	Release	Modification
	12.2(18)EW	This command was first introduced on the Catalyst 4500 series switch.
	12.2(25)EW	Added support for the 10-Gigabit Ethernet interface.

Usage Guidelines After enabling Layer 2 protocol tunneling on an access or 802.1Q tunnel port with the **l2protocol-tunnel** command, you can configure some or all of these parameters:

- Protocol type to be tunneled
- Shutdown threshold
- Drop threshold

If you enter the **show l2protocol-tunnel** [**interface** *interface-id*] command, only information about the active ports on which all the parameters are configured appears.

If you enter the **show l2protocol-tunnel summary** command, only information about the active ports on which some or all of the parameters are configured appears.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show l2protocol-tunnel command:

Switch> **show 12protocol-tunnel** COS for Encapsulated Packets: 5

		Threshold	Threshold	Encapsulation Counter	Counter	Counter
 Fa0/10						
Fa0/10	stp			9847	1866	0
	vtp				12	0
	-				860	0
	pagp				0	0
	lacp udld			-	-	
- 0 /1 1					211	0
Fa0/11	-	1100			2350	0
	stp	1100			13	0
	vtp	1100		3	67	0
	pagp		900	856	5848	0
	lacp		900	0	0	0
	udld		900	0	0	0
Fa0/12	cdp			2356	0	0
	stp			11787	0	0
	vtp			81	0	0
	pagp			0	0	0
	lacp			849	0	0
	udld			0	0	0
Fa0/13	cdp			2356	0	0
	stp			11788	0	0
	vtp			81	0	0
	pagp			0	0	0
	lacp			849	0	0
	udld			0	0	0
Switch#						

This is an example of output from the show l2protocol-tunnel summary command:

Switch> show 12protocol-tunnel summary COS for Encapsulated Packets: 5

Port	Protocol	Threshold (cdp/stp/vtp)	Drop Threshold (cdp/stp/vtp) (pagp/lacp/udld)	Status
Fa0/10	stp vtp	//	//	up
		//	//	· 1
- Fa0/11	cdp stp vtp	1100/1100/1100	//	up
pa	gp lacp udld	//	900/ 900/ 900	
Fa0/12	cdp stp vtp	//	//	up
pa	gp lacp udld	//	//	
Fa0/13	cdp stp vtp	//	//	up
pa	gp lacp udld	//	//	
Fa0/14	cdp stp vtp	//	//	down
pa	gp udld	//	//	
Fa0/15	cdp stp vtp	//	//	down
pa	gp udld	//	//	
Fa0/16	cdp stp vtp	//	//	down
pa	gp lacp udld	//	//	
		//	//	down
pa	gp lacp udld	//	//	
Switch#	:			

Related Commands clear I2protocol-tunnel counter (refer to Cisco IOS documentation) 12protocol-tunnel 12protocol-tunnel 12protocol-tunnel 12protocol-tunnel

show lacp

To display LACP information, use the **show lacp** command.

show lacp [channel-group] {counters | internal | neighbors | sys-id }

Syntax Description												
ntax Description	<i>channel-group</i> (Optional) Number of the channel group; valid values are from 1 to 64.											
	counters	Display	s the LAC	CP statisti	cal info	nation.						
	internal	Display	s the inte	rnal infor	nation.							
	neighbors	Display	s the neig	ghbor info	rmation							
	sys-id	Display	s the LA	CP system	identif	ation.						
Defaults	This command	l has no defat	ılt setting	s.								
Command Modes	Privileged EX	EC										
Command History	Release	Modific	ation									
	12.1(13)EW			command	was int	duced on the Catalyst 4500 series s	witches.					
	sys-id keywor	u.										
Examples	This example	shows how to	display l	LACP stat	istical i	formation for a specific channel group	This example shows how to display LACP statistical information for a specific channel group:					
	Switch# show	lacp 1 coun					up.					
		T 3 0 5 5 1			T 3 0 5	-	ιp.					
		LACPDUs ent Recv	Sent	rker Recv	LACP Pkts		ıp.					
	Port Se	ent Recv					лр.					
		ent Recv p: 1					лр.					
	Port Sa Channel group Fa4/1 8 Fa4/2 14	ent Recv p: 1 15 4 18	Sent 0 0	Recv 0 0	Pkts 3 3	Err 	ıp.					
	Port Se Channel group Fa4/1 8 Fa4/2 14 Fa4/3 14	ent Recv p: 1 15 4 18 4 18	Sent 0 0 0	Recv 0 0 0	Pkts 3 3 0	0	ıр.					
	Port Sa Channel group Fa4/1 8 Fa4/2 14	ent Recv p: 1 15 4 18 4 18	Sent 0 0	Recv 0 0	Pkts 3 3	0	φ.					
	Port Se Channel group Fa4/1 8 Fa4/2 14 Fa4/3 14 Fa4/4 13	ent Recv 	Sent 0 0 0 0	Recv 0 0 0 0	Pkts 3 3 0 0	0	ι μ .					
	Port Se Channel group Fa4/1 8 Fa4/2 14 Fa4/3 14 Fa4/4 13 Switch# The output dis	ent Recv p: 1 15 4 18 4 18 3 18 splays the foll	Sent 0 0 0 0 0 0 0 0	Recv 0 0 0 0 0	Pkts 3 3 0 0	0	_					

This example shows how to display internal information for the interfaces belonging to a specific channel:

Switch#	Switch# show lacp 1 internal							
Flags:	S - Devic	e sends P	DUs at slow	rate. F - Dev	ice sends	s PDUs at	fast rat	ze.
	A - Devic	e is in A	ctive mode.	P - Dev	ice is ir	n Passive	e mode.	
Channel	group 1							
			LACPDUs	LACP Port	Admin	Oper	Port	Port
Port	Flags	State	Interval	Priority	Кеу	Кеу	Number	State
Fa4/1	saC	bndl	30s	32768	100	100	0xc1	0x75
Fa4/2	saC	bndl	30s	32768	100	100	0xc2	0x75
Fa4/3	saC	bndl	30s	32768	100	100	0xc3	0x75
Fa4/4	saC	bndl	30s	32768	100	100	0xc4	0x75
Switch#								

Table 2-22 lists the output field definitions.

Field	Description				
State	State of the specific port at the current moment is displayed; allowed values are as follows:				
	• <i>bndl</i> —Port is attached to an aggregator and bundled with other ports.				
	• <i>susp</i> —Port is in a suspended state; it is not attached to any aggregator.				
	• <i>indep</i> —Port is in an independent state (not bundled but able to switch data traffic. In this case, LACP is not running on the partner port).				
	• <i>hot-sby</i> —Port is in a Hot-standby state.				
	• <i>down</i> —Port is down.				
LACPDUs Interval	Interval setting.				
LACP Port Priority	Port priority setting.				
Admin Key	Administrative key.				
Oper Key	Operator key.				
Port Number	Port number.				
Port State	State variables for the port encoded as individual bits within a single octet with the following meaning [1]:				
	• bit0 : <i>LACP_Activity</i>				
	• bit1 : <i>LACP_Timeout</i>				
	• bit2: Aggregation				
	• bit3: Synchronization				
	• bit4: Collecting				
	• bit5 : <i>Distributing</i>				
	• bit6 : <i>Defaulted</i>				
	• bit7 : <i>Expired</i>				

Table 2-22show lacp internal Command Output Fields

This example shows how to display LACP neighbors information for a specific port channel:

```
Switch# show lacp 1 neighbor
Flags: S - Device sends PDUs at slow rate. F - Device sends PDUs at fast rate.
        A - Device is in Active mode.
                                           P - Device is in Passive mode.
Channel group 1 neighbors
         Partner
                                 Partner
Port
                                Port Number
         System ID
                                                 Age
                                                         Flags
        8000,00b0.c23e.d84e
Fa4/1
                                 0x81
                                                 29s
                                                         Ρ
Fa4/2
         8000,00b0.c23e.d84e
                                 0x82
                                                 0s
                                                         Ρ
Fa4/3
         8000,00b0.c23e.d84e
                                 0x83
                                                 0s
                                                         Ρ
Fa4/4
         8000,00b0.c23e.d84e
                                 0x84
                                                 0s
                                                         Ρ
          Port
                       Admin
                                 Oper
                                           Port
         Priority
                       Key
                                 Key
                                           State
         32768
                       200
                                 200
Fa4/1
                                           0x81
Fa4/2
         32768
                                 200
                       200
                                           0x81
Fa4/3
         32768
                       200
                                 200
                                           0x81
                       200
Fa4/4
         32768
                                 200
                                           0x81
Switch#
```

In the case where no PDUs have been received, the default administrative information is displayed in braces.

This example shows how to display the LACP system identification:

Switch> **show lacp sys-id** 8000,AC-12-34-56-78-90 Switch>

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

Related Commands lacp port-priority lacp system-priority

show mac access-group interface

To display the ACL configuration on a Layer 2 interface, use the **show mac access-group interface** command.

show mac access-group interface [interface interface-number]

Syntax Description	interface	(Optional) Specifies the interface type; valid values are ethernet , fastethernet gigabitethernet , tengigabitethernet , pos , atm , port-channel , and ge-wan .				
	interface-number	(Optional) Specifies the port number.				
Defaults	This command has	no default settings.				
ommand Modes	Privileged EXEC					
Command History	Release Modification					
	12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch.				
lsage Guidelines	The valid values fo	r the port number depend on the chassis used.				
Jsage Guidelines Examples		r the port number depend on the chassis used. rs how to display the ACL configuration on interface fast 6/1:				

Related Commands access-group mode

show mac-address-table address

To display MAC address table information for a specific MAC address, use the **show mac-address-table address** command.

show mac-address-table address mac_addr [interface type slot/port | protocol protocol | vlan
vlan_id]

Syntax Description	mac_addr	48-bit MAC address; the valid format is H.H.H.
	interface type slot/po	<i>(Optional)</i> Displays information for a specific interface; valid values for <i>type</i> are fastethernet , gigabitethernet , and tengigabitethernet .
	protocol protocol	(Optional) Specifies a protocol. See the "Usage Guidelines" section for more information.
	vlan vlan_id	(Optional) Displays entries for the specific VLAN only; valid values are from 1 to 4094.
Defaults	This command has no	default settings.
Command Modes	Privileged EXEC	
Command History		
Command History	Release Mo	odification
Command History		podification pport for this command was introduced on the Catalyst 4500 series switch.
Command History	12.1(8a)EW Su	
Command History	12.1(8a)EW Su 12.1(12c)EW Acc	pport for this command was introduced on the Catalyst 4500 series switch.
Command History Usage Guidelines	12.1(8a)EW Su 12.1(12c)EW Ac 12.2(25)EW Ac For the MAC address Ac	pport for this command was introduced on the Catalyst 4500 series switch. Ided support for extended VLAN addresses.
	12.1(8a)EWSu12.1(12c)EWAc12.2(25)EWAcFor the MAC addressthe "vlan" column no	pport for this command was introduced on the Catalyst 4500 series switch. Ided support for extended VLAN addresses. Ided support for the 10-Gigabit Ethernet interface.
	12.1(8a)EWSu12.1(12c)EWAc12.2(25)EWAcFor the MAC addressthe "vlan" column no	pport for this command was introduced on the Catalyst 4500 series switch. Ided support for extended VLAN addresses. Ided support for the 10-Gigabit Ethernet interface. table entries that are used by the routed ports, the routed port name is displayed in t the internal VLAN number. ons for the <i>protocol</i> variable are as follows:
	12.1(8a)EWSu12.1(12c)EWAc12.2(25)EWAcFor the MAC addressthe "vlan" column noThe keyword definition	pport for this command was introduced on the Catalyst 4500 series switch. Ided support for extended VLAN addresses. Ided support for the 10-Gigabit Ethernet interface. table entries that are used by the routed ports, the routed port name is displayed in t the internal VLAN number. ons for the <i>protocol</i> variable are as follows: P protocol.
	12.1(8a)EWSu12.1(12c)EWAc12.2(25)EWAcFor the MAC address the "vlan" column no The keyword definition• ip specifies the II• ipx specifies the	pport for this command was introduced on the Catalyst 4500 series switch. Ided support for extended VLAN addresses. Ided support for the 10-Gigabit Ethernet interface. table entries that are used by the routed ports, the routed port name is displayed in t the internal VLAN number. ons for the <i>protocol</i> variable are as follows: P protocol.

Examples	This example shows how to display MAC address table information for a specific MAC address:					
Related Commands	Unicast	show mac-addres Entries mac address	s-table a	ddress 0030.94fc.0dff	port	
	1 Fa6/1 Fa6/2 Switch#	0030.94fc.0dff 0030.94fc.0dff 0030.94fc.0dff	static static	<pre>ip,ipx,assigned,other ip,ipx,assigned,other ip,ipx,assigned,other</pre>	Switch Switch Switch	
	show ma show ma	ac-address-table ac-address-table ac-address-table ac-address-table	count dynamic	2		

show mac-address-table dynamic show mac-address-table interface show mac-address-table multicast show mac-address-table protocol show mac-address-table static show mac-address-table vlan

show mac-address-table aging-time

To display the MAC address aging time, use the show mac-address-table aging-time command.

show mac-address-table aging-time [vlan vlan_id]

Syntax Description	vlan vlan_id	(Optional) Specifies a VLAN; valid values are from 1 to 4094.			
Defaults	This command has no default settings.				
Command Modes	Privileged EX	EC			
Command History	Release	Modification			
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.			
	12.1(12c)EW	Support for extended addressing was added.			
Examples	Switch# show	shows how to display the currently configured aging time for all VLANs: mac-address-table aging-time			
	This example s	shows how to display the currently configured aging time for a specific VLAN:			
	Vlan Aging	mac-address-table aging-time vlan 100 Time			
	100 300				
	Switch#				
Related Commands	show mac-add show mac-add show mac-add show mac-add show mac-add	Iress-table address Iress-table count Iress-table dynamic Iress-table interface Iress-table multicast Iress-table protocol Iress-table static			

show mac-address-table vlan

show mac-address-table count

To display the number of entries currently in the MAC address table, use the **show mac-address-table count** command.

show mac-address-table count [vlan vlan_id]

Syntax Description	vlan vlan_id	(Optional) Specifies a VLAN; vali	d values are from 1 to 4094.
Defaults	This command h	aas no default settings.	
Command Modes	Privileged EXE	2	
Command History	Release	Modification	
	12.1(8a)EW	Support for this command was in	troduced on the Catalyst 4500 series switch.
	12.1(12c)EW	Added support for extended VLA	N addresses.
	Static Unicast Total Unicast I Total Unicast I Multicast MAC	Address (User-defined) Count: Address (System-defined) Count: MAC Addresses In Use: MAC Addresses Available: Address Count: t MAC Addresses Available:	0 1 1 32768 1 16384
Related Commands	show mac-addr show mac-addr show mac-addr show mac-addr		

show mac-address-table dynamic

To display the dynamic MAC address table entries only, use the **show mac-address-table dynamic** command.

show mac-address-table dynamic [address mac_addr | interface type slot/port |
protocol protocol | vlan vlan_id]

Syntax Description	address mac_ada	(Optional) Specifies a 48-bit MAC address	; the valid format is H.H.H.				
	interface type slo		(Optional) Specifies an interface to match; valid values for <i>type</i> are fastethernet , gigabitethernet , and tengigabitethernet .				
	protocol protocol	(Optional) Specifies a protocol. See the "Up more information.	sage Guidelines" section for				
	vlan vlan_id	(Optional) Displays entries for a specific V to 4094.	LAN; valid values are from 1				
Defaults	This command ha	o default settings.					
Command Modes	Privileged EXEC						
Command History	Release	Iodification					
Command History	Release 12.1(8a)EW	lodification upport for this command was introduced on the Cat	talyst 4500 series switch.				
Command History			talyst 4500 series switch.				
Command History	12.1(8a)EW	upport for this command was introduced on the Cat	•				
	12.1(8a)EW 12.1(12c)EW 12.2(25)EW The keyword defin	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface.	•				
	12.1(8a)EW12.1(12c)EW12.2(25)EWThe keyword defin• assigned spector	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface. ions for the <i>protocol</i> argument are as follows: uses assigned protocol entries.	•				
	12.1(8a)EW 12.1(12c)EW 12.2(25)EW The keyword defin • assigned spec • ip specifies II	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface. ions for the <i>protocol</i> argument are as follows: les assigned protocol entries. rotocol.	•				
	12.1(8a)EW12.1(12c)EW12.2(25)EWThe keyword defin• assigned spector	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface. ions for the <i>protocol</i> argument are as follows: les assigned protocol entries. rotocol.	•				
Command History Usage Guidelines	 12.1(8a)EW 12.1(12c)EW 12.2(25)EW The keyword define assigned spection ip specifies IF ip specifies IF 	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface. ions for the <i>protocol</i> argument are as follows: les assigned protocol entries. rotocol.	•				
	 12.1(8a)EW 12.1(12c)EW 12.2(25)EW The keyword defin assigned specifies If ip specifies If ipx specifies If other specifie 	upport for this command was introduced on the Cat added support for extended VLAN addresses. added support for the 10-Gigabit Ethernet interface. ions for the <i>protocol</i> argument are as follows: les assigned protocol entries. rotocol. X protocols.	annel interface changes the por				

Examples

This example shows how to display all the dynamic MAC address entries:

Switch#	show	mac-address-table	dynamic
---------	------	-------------------	---------

Unicast	Entries		• • •	
vlan	mac address	type	protocols	port
	+	+	++	
1	0000.0000.0201	dynamic	ip	FastEthernet6/15
1	0000.0000.0202	dynamic	ip	FastEthernet6/15
1	0000.0000.0203	dynamic	ip,assigned	FastEthernet6/15
1	0000.0000.0204	dynamic	ip,assigned	FastEthernet6/15
1	0000.0000.0205	dynamic	ip,assigned	FastEthernet6/15
2	0000.0000.0101	dynamic	ip	FastEthernet6/16
2	0000.0000.0102	dynamic	ip	FastEthernet6/16
2	0000.0000.0103	dynamic	ip,assigned	FastEthernet6/16
2	0000.0000.0104	dynamic	ip,assigned	FastEthernet6/16
2	0000.0000.0105	dynamic	ip,assigned	FastEthernet6/16
Switch#				

This example shows how to display the dynamic MAC address entries with a specific protocol type (in this case, assigned):

Switch# show mac-address-table dynamic protocol assigned

vlan	Entries mac address	type +	protocols	port
1	0000.0000.0203	dynamic	ip,assigned	FastEthernet6/15
1	0000.0000.0204	dynamic	ip,assigned	FastEthernet6/15
1	0000.0000.0205	dynamic	ip,assigned	FastEthernet6/15
2	0000.0000.0103	dynamic	ip,assigned	FastEthernet6/16
2	0000.0000.0104	dynamic	ip,assigned	FastEthernet6/16
2	0000.0000.0105	dynamic	ip,assigned	FastEthernet6/16
Switch#				

Related Commands

show mac-address-table protocol show mac-address-table static show mac-address-table vlan

show mac-address-table interface

To display the MAC address table information for a specific interface, use the **show mac-address-table interface** command.

show mac-address-table interface type slot/port

Syntax Description	type	Interface type; valid value: tengigabitethernet .	s are ethernet , f a	astethernet, gigab	bitethernet , and
	slot/port	Number of the slot and pos	rt.		
efaults	This comma	nd has no default settings.			
ommand Modes	Privileged E	XEC			
ommand History	Release	Modification			
	12.1(8a)EW	Support for this comma	and was introduc	ced on the Catalyst	4500 series switch.
			10 Circhit Ethan	rnat intarfaca	
Isage Guidelines		Added support for the address table entries that are plumn not the internal VLAN	used by the rout		l port name is displayed
-	For the MAC the "vlan" co	address table entries that are for a stable and a stable of the stable	used by the rout number.	ed ports, the routed	
_	For the MAC the "vlan" co This exampl	address table entries that are	used by the route number. address table int	ed ports, the routed	
-	For the MAC the "vlan" co This exampl Switch# sho Unicast Ent vlan mac	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p	used by the rout number. address table inf face fastethern	ed ports, the routed formation for a spe het6/16 port	ecific interface:
	For the MAC the "vlan" co This exampl Switch# sho Unicast Ent vlan mac	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries	used by the rout number. address table in face fastethern	ed ports, the routed formation for a spe het6/16 port	ecific interface:
	For the MAC the "vlan" co This exampl Switch# sho Unicast Ent vlan mac 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 	used by the rout number. address table inf face fastethern protocols	ed ports, the routed formation for a spe bet6/16 FastEtherne FastEtherne	ecific interface: et6/16 et6/16
-	For the MAC the "vlan" co This exampl Switch# shc Unicast Ent vlan mac 2 000 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 0.0000.0101 dynamic othe 0.0000.0102 dynamic othe 0.0000.0103 dynamic othe	used by the rout number. address table inf face fastethern protocols	ed ports, the routed formation for a spe bet6/16 FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16
	For the MAC the "vlan" co This exampl Switch# shc Unicast Ent vlan mac 2 000 2 000 2 000 2 000 2 000	address table entries that are blumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 	used by the rout number. address table inf face fastethern protocols	ed ports, the routed formation for a spe bet6/16 FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16 et6/16
-	For the MAC the "vlan" co This exampl Switch# shc Unicast Ent vlan mac 2 000 2 000 2 000 2 000 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 0.0000.0101 dynamic othe 0.0000.0102 dynamic othe 0.0000.0103 dynamic othe	used by the rout number. address table inf face fastethern protocols	ed ports, the routed formation for a spe bet6/16 FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16 et6/16 et6/16 et6/16
	For the MAC the "vlan" co This exampl Switch# shc Unicast Ent vlan mac 2 000 2 000 2 000 2 000 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 0.0000.0101 dynamic othe 0.0000.0102 dynamic othe 0.0000.0103 dynamic othe 0.0000.0104 dynamic othe 0.0000.0105 dynamic othe 0.0000.0106 dynamic othe	used by the rout number. address table inf face fastethern protocols	ed ports, the routed formation for a spe het6/16 FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16 et6/16 et6/16 et6/16
Jsage Guidelines Examples	For the MAC the "vlan" co This exampl Switch# sho Unicast Ent vlan mac 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 	used by the route number. address table inf face fastethern protocols	ed ports, the routed formation for a spe het6/16 FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16 et6/16 et6/16 et6/16
-	For the MAC the "vlan" co This exampl Switch# sho Unicast Ent vlan mac 2 000 2 000	address table entries that are olumn not the internal VLAN e shows how to display MAC w mac-address-table interf ries address type p 	used by the route number. address table inf face fastethern protocols er er er er er er	ed ports, the routed formation for a spe het6/16 FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne FastEtherne	ecific interface: et6/16 et6/16 et6/16 et6/16 et6/16 et6/16

Related Commands

show mac-address-table address show mac-address-table aging-time show mac-address-table count show mac-address-table dynamic show mac-address-table multicast show mac-address-table protocol show mac-address-table static show mac-address-table vlan

show mac-address-table multicast

To display information about the multicast MAC address table, use the **show mac-address-table multicast** command.

show mac-address-table multicast [count | {igmp-snooping [count]} | {user [count]} |
{vlan vlan_num}]

Syntax Description	count	(Optional) Displays the number of multicast entries.				
	igmp-snooping	(Optional) Displays only the	addresses learned by IGMP snooping.			
	user	(Optional) Displays only the	user-entered static addresses.			
	vlan vlan_num	(Optional) Displays information 1 to 4094.	on for a specific VLAN only; valid values are from			
Defaults	This command ha	s no default settings.				
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.1(8a)EW	Support for this command was	introduced on the Catalyst 4500 series switch.			
	12.1(12c)EW	Added support for extended VL	AN addresses.			
Usage Guidelines		ess table entries that are used by not the the internal VLAN num	the routed ports, the routed port name is displayed in ber.			
Examples	This example show	ws how to display multicast MA	C address table information for a specific VLAN:			
	Multicast Entrie vlan mac add	lress type ports	n 1			
	1 ffff.ffff.ffff system Switch,Fa6/15 Switch#					
	This example shows how to display the number of multicast MAC entries for all VLANs:					
	Switch# show mac MAC Entries for	-address-table multicast cou all vlans:	nt			
	Multicast MAC Ad Total Multicast Switch#	ddress Count: MAC Addresses Available:	141 16384			

Related Commands

show mac-address-table address show mac-address-table aging-time show mac-address-table count show mac-address-table dynamic show mac-address-table interface show mac-address-table protocol show mac-address-table static show mac-address-table vlan

show mac-address-table notification

To display the MAC address table notification status and history, use the **show mac-address-table notification** command.

show mac-address-table notification [change] [interface [interface-id]] | [mac-move] | [threshold]

Syntax Description	change	(Optional) Displays the MAC address change notification status.				
	interface	(Optional) Displays MAC change information for an interfaces.				
	interface-id	(Optional) Displays the information for a specific interface. Valid				
		interfaces include physical ports and port channels.				
	mac-move	(Optional) Displays MAC move notification status.				
	threshold	(Optional) Displays the MAC threshold notification status.				
Defaults	This command	has no default settings.				
Command Modes	Privileged EXE	3C				
Command History	Release	Modification				
	12.2(31)SG	Support for this command was introduced on the Catalyst 4500 series switch				
	allowed in the l Use the interfa	led or disabled, the MAC change notification interval, the maximum number of entries history table, and the history table contents. Ace keyword to display the flags for all interfaces. If the <i>interface-id</i> is included, only the interface are displayed.				
Examples	This example s	hows how to display all the MAC address notification information:				
	MAC Notificat: Interval betwo Number of MAC Number of MAC Number of Not: Maximum Number Current Histo:	<pre>mac-address-table notification change ion Feature is Enabled on the switch een Notification Traps : 1 secs Addresses Added : 5 Addresses Removed : 1 ifications sent to NMS : 3 r of entries configured in History Table : 500 ry Table Length : 3 ion Traps are Enabled contents</pre>				
	History Index MAC Changed Me Operation: Add					

```
History Index 2, Entry Timestamp 481834, Despatch Timestamp 481834

MAC Changed Message :

Operation: Added Vlan: 1 MAC Addr: 1234.5678.9ab1 Dot1dBasePort: 323

Operation: Added Vlan: 1 MAC Addr: 1234.5678.9ab2 Dot1dBasePort: 323

Operation: Added Vlan: 1 MAC Addr: 1234.5678.9ab3 Dot1dBasePort: 323

Operation: Added Vlan: 1 MAC Addr: 1234.5678.9ab4 Dot1dBasePort: 323

History Index 3, Entry Timestamp 484334, Despatch Timestamp 484334

MAC Changed Message :

Operation: Deleted Vlan: 1 MAC Addr: 1234.5678.9ab0 Dot1dBasePort: 323

Switch#
```

This example shows how to display the MAC address change status on the FastEthernet interface 7/1:

```
Switch# show mac-address-table notification change interface FastEthernet 7/1MAC Notification Feature is Enabled on the switchInterfaceMAC Added Trap MAC Removed Trap-------FastEthernet7/1EnabledDisabled
```

Switch#

This example shows how to display the MAC address move status:

```
Switch# show mac-address-table notification mac-move
MAC Move Notification: Enabled
Switch#
```

This example shows how to display the MAC address table utilization status:

```
Switch# show mac-address-table notification threshold
Status limit Interval
enabled 50 120
Switch#
```

Related Commands

clear mac-address-table mac-address-table notification snmp-server enable traps snmp trap mac-notification change

show mac-address-table protocol

To display the MAC address table information that is based on the protocol, use the **show mac-address-table protocol** command.

show mac-address-table protocol {assigned | ip | ipx | other}

Syntax Description	assigned	Specifies	the assign	ned protoco	i enti	ries.			
	ір	Specifies	the IP pro	otocol entri	es.				
	ipx Specifies the IPX protocol entries.								
	other	Specifies	the other	protocol er	tries	•			
Defaults	This comm	nand has no de	efault setti	ngs.					
Command Modes	Privileged	EXEC							
Command History	Release	Modif	fication						
	12.1(8a)E	EW Suppo	ort for this	command	wasi	ntroduced	on the Catalyst 45	500 series switch.	
_	the "vlan"	column not th	e the inter	rnal VLAN	num	ber.	-	ort name is displaye	
_	the "vlan" This exam this case, a Switch# s	column not th ple shows how assigned):	e the inter to displa =====table	rnal VLAN y the MAC protocol	num addre	ber. ess table en	tries that have a sp	ort name is displaye pecific protocol typ	
	the "vlan" This exam this case, a Switch# s vlan ma	column not th ple shows how assigned):	e the inter to display	y the MAC	num addre assi	ber. ess table en gned	tries that have a sports		
_	the "vlan" This exam this case, a Switch# s vlan ma 200 005	column not th pple shows how assigned): how mac-address caddress 	to display	y the MAC protocol protocol assigned	addre assi qos +	ber. ess table en gned Switch	tries that have a sports		
_	the "vlan" This exam this case, a Switch# s vlan ma 200 005 100 005	column not the apple shows how assigned): conserved as a second	e the inter to display	y the MAC protocol protocol assigned	addre assi qos + 	ber. ess table en gned	tries that have a sports		
	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000	column not the apple shows how assigned): conserved as a served a	to display	y the MAC protocol protocol assigned assigned assigned	addre assi qos + 	ber. ess table en gned Switch Switch Switch Switch Switch	tries that have a sports		
_	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000 1 005	Column not the apple shows how assigned): Show mac-address ac address ad	to display to display type static static dynamic static	y the MAC protocol protocol assigned assigned assigned assigned	addro assi qos + 	ber. ess table en gned Switch Switch Switch Switch Switch Switch	tries that have a sports		
_	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000 1 005 4 005	column not th aple shows how assigned): caddress caddress co.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400 c0.3e8d.6400	to display to display type type static static static dynamic static static	y the MAC protocol protocol assigned assigned assigned	addre assi qos + 	ber. ess table en gned Switch Switch Switch Switch Switch	tries that have a sports		
_	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 5 005 4092 000 1 005 4 005 4092 005 4092 005	column not the pple shows how assigned): show mac-address co.3e8d.6400	to display to display type type static static static static static static static static static static	y the MAC protocol protocol assigned assigned assigned assigned assigned assigned assigned	num addre assi qos + 	ber. ess table en gned switch Switch Switch Switch Switch Switch Switch Switch Switch Switch	tries that have a sports		
	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 5 005 4092 000 1 005 4 005 4092 005 4092 005 1 001	column not th pple shows how assigned): conserved and the conserved and the conserve	to display static static static static static static static static static static static	y the MAC protocol protocol assigned assigned assigned assigned assigned assigned	num addre assi qos + 	ber. ess table en gned switch Switch Switch Switch Switch Switch Switch Switch	tries that have a sports		
	the "vlan" This exam this case, a Switch# s vlan ma 200 005 5 005 4092 000 1 005 4092 005 4092 005 4092 005 1 001 Switch#	column not the pple shows how assigned): show mac-address co.3e8d.6400	e the inter to display constraints type static static static static static static static static static dynamic dynamic	y the MAC protocol protocol assigned assigned assigned assigned assigned assigned assigned	addre assi qos + 	ber. ess table en gned *	ports		
_	the "vlan" This exam this case, a Switch# s vlan ma 	Column not the apple shows how assigned): Show mac-address a address 30.3e8d.6400	e the inter to display ess-table type static static static static static static dynamic dynamic dynamic other outp	y the MAC protocol protocol assigned assig	addre assi qos + 	ber. ess table en gmed switch Switch Switch Switch Switch Switch Switch Fa5/9 ous exampl	ports		
_	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000 1 005 4092 005 4092 005 1 001 Switch# This exam Switch# s Unicast E	column not the apple shows how assigned): show mac-address ac address ac ad ac	e the inter to display ess-table type static static static static dynamic dynamic dynamic other outp	y the MAC protocol protocol assigned assig	addro assi qos + orevic othe	ber. ess table en gned Switch	tries that have a sports		
Jsage Guidelines	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000 1 005 4 005 4 005 4 005 1 001 Switch# This exam Switch# s Unicast E vlan m	column not the apple shows how assigned): bhow mac-address ac address ac address ac address ac address ac address ac address ac address ac address	e the inter to display ess-table type static static static dynamic dynamic dynamic dynamic dynamic type	y the MAC protocol protocol assigned assig	num addro assi qos + orevic othe	ber. ess table en gned Switch Switch Switch Switch Switch Switch Switch Fa5/9 ous exampl r	ports	pecific protocol typ	
_	the "vlan" This exam this case, a Switch# s vlan ma + 200 005 100 005 5 005 4092 000 1 005 4 005 4 005 4 005 1 001 Switch# This exam Switch# s Unicast E vlan m + 1 0	column not the apple shows how assigned): bhow mac-address ac address ac address ac address ac address ac address ac address ac address ac address	e the inter to display ess-table type static static static dynamic dynamic dynamic dynamic other outp	y the MAC protocol protocol assigned assig	num addre assi qos + orevic othe occol	ber. ess table en gned Switch Switch Switch Switch Switch Switch Switch Fa5/9 ous exampl r	tries that have a sports ports e:	pecific protocol typ	

1	0000.0000.0203	dynamic	other	FastEthernet6/15
1	0000.0000.0204	dynamic	other	FastEthernet6/15
1	0030.94fc.0dff	static	ip,ipx,assigned,other	Switch
2	0000.0000.0101	dynamic	other	FastEthernet6/16
2	0000.0000.0102	dynamic	other	FastEthernet6/16
2	0000.0000.0103	dynamic	other	FastEthernet6/16
2	0000.0000.0104	dynamic	other	FastEthernet6/16
Fa6/1	0030.94fc.0dff	static	ip, ipx, assigned, other	Switch
Fa6/2	0030.94fc.0dff	static	ip,ipx,assigned,other	Switch
Multica	st Entries			
vlan				
	++	+-		
1	++ ffff.ffff.ffff	system S	witch,Fa6/15	
1 2	++ ffff.ffff.ffff ffff.ffff.ffff	system S system F	witch,Fa6/15	
1 2 1002	++ ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system	witch,Fa6/15	
1 2 1002 1003	++ ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system system	witch,Fa6/15	
1 2 1002 1003 1004	++ ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system system system	witch,Fa6/15	
1 2 1002 1003 1004 1005	++ ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system system system system system	witch,Fa6/15 a6/16	
1 2 1002 1003 1004 1005 Fa6/1	++ ffff.fff.ffff ffff.fff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system system system system system system S	witch,Fa6/15 2a6/16 witch,Fa6/1	
1 2 1002 1003 1004 1005 Fa6/1	++ ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff ffff.ffff.ffff	system S system F system system system system system system S	witch,Fa6/15 a6/16	

Related Commands

show mac-address-table address show mac-address-table aging-time show mac-address-table count show mac-address-table dynamic show mac-address-table interface show mac-address-table multicast show mac-address-table static show mac-address-table static

show mac-address-table static

To display the static MAC address table entries only, use the **show mac-address-table static** command.

show mac-address-table static [address mac_addr | interface type number | protocol protocol |
 vlan vlan_id]

Syntax Description	address mac_aa	ldr	(Optiona H.H.H.	al) Specifies a 48-bit MA	AC address to match; the valid format is
	interface type n	umber			e to match; valid values for <i>type</i> are and tengigabitethernet .
	protocol protoco	ol		al) Specifies a protocol. Formation.	See the "Usage Guidelines" section for
	vlan vlan_id		(Optiona 1 to 4094		or a specific VLAN; valid values are from
Defaults	This command h	as no def	ault setting	gs.	
Command Modes	Privileged EXEC	C			
Command History	Release	Modifi	cation		
	12.1(8a)EW	Suppor	t for this c	command was introduce	d on the Catalyst 4500 series switch.
	12.1(12c)EW	Added	support fo	or extended VLAN addr	esses.
	12.2(25)EW	Added	support fo	or the 10-Gigabit Ethern	et interface.
Usage Guidelines	For the MAC add the "vlan" colum				l ports, the routed port name is displayed in
	The keyword def	finitions f	or the <i>prot</i>	tocol argument are as fo	llows:
	•		•	protocol entries.	
	• ip specifies t		•	r	
	 ipx specifies 	-			
			•		
	• other specif	ies the ot	ner protoco	of entries.	
Examples	This example sho	ows how	to display	all the static MAC addr	ess entries:
	Switch# show ma Unicast Entries vlan mac add	s dress	type	protocols	port
	1 0030.94	4fc.0dff	statio	; ip,ipx,assigned,oth ; ip,ipx,assigned,oth	

```
Fa6/2 0030.94fc.0dff
                    static ip, ipx, assigned, other Switch
Multicast Entries
vlan mac address
                   type
                         ports
_____
  1
    ffff.ffff.ffff system Switch,Fa6/15
  2 ffff.ffff.ffff system Fa6/16
     ffff.ffff.ffff system
1002
      ffff.ffff.ffff system
ffff.ffff.ffff system
1003
1004
      ffff.fff.fff system
1005
Fa6/1 ffff.ffff system Switch,Fa6/1
Fa6/2 ffff.ffff.ffff system Switch, Fa6/2
Switch#
```

This example shows how to display the static MAC address entries with a specific protocol type (in this case, assigned):

```
Switch# show mac-address-table static protocol assigned
Unicast Entries
vlan mac address type
                         protocols
                                            port
0030.94fc.0dff static ip, ipx, assigned, other Switch
                 static ip, ipx, assigned, other Switch
  1
Fa6/1
     0030.94fc.0dff
Fa6/2
     0030.94fc.0dff
                   static ip, ipx, assigned, other Switch
Multicast Entries
vlan
     mac address
                type
                       ports
_____+
 1 ffff.ffff.ffff system Switch,Fa6/15
  2 ffff.ffff.ffff system Fa6/16
     ffff.ffff.ffff system
1002
     ffff.ffff.ffff system
1003
      ffff.fff.ffff
1004
                  system
1005
      ffff.fff.ffff
                  system
Fa6/1 ffff.ffff system Switch,Fa6/1
    ffff.ffff.ffff system Switch,Fa6/2
Fa6/2
Switch#
```

Related Commands

show mac-address-table address show mac-address-table aging-time show mac-address-table count show mac-address-table dynamic show mac-address-table interface show mac-address-table multicast show mac-address-table protocol show mac-address-table vlan

L

show mac-address-table vlan

To display information about the MAC address table for a specific VLAN, use the **show mac-address-table vlan** command.

show mac-address-table [vlan vlan_id] [protocol protocol]

Syntax Description	vlan vlan_id	(Optional) D 4094.	isplays the entries for a spo	ecific VLAN; valid values are from 1 to
	protocol protoco	ol (Optional) Sp information.	pecifies a protocol. See the	e "Usage Guidelines" section for more
Defaults	This command h	as no default setting	<u>3</u> 5.	
Command Modes	Privileged EXEC			
Command History	Release	Modification		
	12.1(8a)EW	Support for this c	ommand was introduced o	on the Catalyst 4500 series switch.
	12.1(12c)EW		ded addressing was added	•
	 assigned specifies ip specifies ipx specifies other specifies 	ecifies the assigned the IP protocol. the IPX protocols. ties the other protocol	ol entries.	
Examples	Switch# show ma	c-address-table v		C address table for a specific VLAN:
	Unicast Entries vlan mac add	lress type	protocols	port
	1 0000.00	000.0201 dynamic		FastEthernet6/15
		000.0202 dynamic 000.0203 dynamic	_	FastEthernet6/15 FastEthernet6/15
		00.0204 dynamic		FastEthernet6/15
		—	: ip, ipx, assigned, other	
	Multicast Entri vlan mac ad		ports	

```
1 ffff.ffff system Switch,Fa6/15 Switch#
```

This example shows how to display MAC address table information for a specific protocol type:

```
Switch# show mac-address-table vlan 100 protocol other
Unicast Entries
```

vlan mac address type protocols port 1 0000.0000.0203 dynamic other FastEthernet6/15 1 0000.0000.0204 dynamic other FastEthernet6/15 1 0030.94fc.0dff static ip, ipx, assigned, other Switch Multicast Entries vlan mac address type ports _____+ 1 ffff.ffff.ffff system Switch,Fa6/15 Switch#

Related Commands

show mac-address-table address show mac-address-table aging-time show mac-address-table count show mac-address-table dynamic show mac-address-table interface show mac-address-table multicast show mac-address-table protocol show mac-address-table static

show module

To display information about the module, use the **show module** command.

show module [mod | all]

Syntax Description	mod	(Optional) Number of the module; vali	d values vary from ch	assis to chassis.		
	all	(Optional) Displays information for all	modules.			
Defaults	This command	has no default settings.				
command Modes	Privileged EXE	C				
Command History	Release	Modification				
	12.1(8a)EW	Support for this command was intro	duced on the Catalys	st 4500 series switch.		
	12.2(25)EW	Enhanced the output of the show id 10-Gigabit Ethernet interface.	prom interface com	mand to include the		
		ne "Status" displays as "PwrFault."				
Examples	This example shows how to display information for all the modules.					
	-	hows the show module command outputes. The system does not have enough p	•			
	Switch# show r Mod Ports Car	rd Type	Model	Serial No.		
	1 2 100 2 6 100 3 18 100 5 0 Not	DOBaseX (GBIC) Supervisor(active) DOBaseX (GBIC) DOBaseX (GBIC) t enough power for module /100BaseTX (RJ45)	WS-X4014 WS-X4306 WS-X4418 WS-X4148-FX-MT WS-X4148	JAB054109GH 00000110 JAB025104WK 0000000000 JAB023402RP		
	M MAC address		Sw	Status		
	1 005c.9d1a. 2 0010.7bab.9	f9d0 to 005c.9d1a.f9df 0.5 12.1(11) 9920 to 0010.7bab.9925 0.2 2b36 to 0050.7356.2b47 1.0				

6 0050.0f10.28b0 to 0050.0f10.28df 1.0 Ok Switch#

This example shows how to display information for a specific module:

Switch# show module mod2

Mod	Ports Card Type		Model		Ser	ial No.
2	2 Catalyst 4000 supervise	or 2 (Active)	 WS-X6K-SU	 P2-2GE	SAD)4450LF1
Mod	MAC addresses	Hw	Fw	Sw		Status
2	0001.6461.39c0 to 0001.6461.	.39c1 1.1	6.1(3)	6.2(0.	97)	Ok
Mod	Sub-Module M	Model	Serial		Hw	Status
2	Policy Feature Card 2	WS-F6K-PFC2	SAD04440HV	U	1.0	Ok
2	Cat4k MSFC 2 daughterboard W	WS-F6K-MSFC2	SAD04430J9	K	1.1	Ok
Swit	cch#					

This example shows how to display information for all the modules on the switch:

Switch# **show module** Chassis Type : WS-C4506

Power consumed by backplane : 0 Watts

Mod Ports Card Type		Model	Serial No.
1 6 XG (X2), 1000BaseX (SFP) 5 3 6 1000BaseX (GBIC)			"" 00000110
M MAC addresses	Hw Fw	Sw	Status
1 0004.dd46.7700 to 0004.dd46.7705 3 0010.7bab.9920 to 0010.7bab.9925 Switch#	0.0 12.2(20r)		

show monitor

To display information about the SPAN session, use the show monitor command.

show monitor [session] [range session-range | local | remote | all | session-number] [detail]

Syntax Description	session	(Optional) Displays the SPAN information for a session.
	range	(Optional) Displays information for a range of sessions.
	session-range	(Optional) Specifies a range of sessions.
	local	(Optional) Displays all local SPAN sessions.
	remote	(Optional) Displays the RSPAN source and destination sessions.
	all	(Optional) Displays the SPAN and RSPAN sessions.
	session-number	(Optional) Session number; valid values are from1 to 6.
	detail	(Optional) Displays the detailed SPAN information for a session.
Defaults Command Modes	The detail keywo Privileged EXEC	rd only displays lines with a nondefault configuration.
ommand History	Release	Modification
ommand History	Release 12.1(8a)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch.
ommand History		
command History	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Command History	12.1(8a)EW 12.1(13)EW	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session.
Command History	12.1(8a)EW 12.1(13)EW 12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements.
Command History Examples	12.1(8a)EW 12.1(13)EW 12.1(19)EW 12.1(20)EW 12.2(20)EW	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements. Added support to display configuration state for remote SPAN and learning. Added support to display ACLs that are applied to SPAN sessions.
	12.1(8a)EW 12.1(13)EW 12.1(19)EW 12.1(20)EW 12.2(20)EW	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements. Added support to display configuration state for remote SPAN and learning. Added support to display ACLs that are applied to SPAN sessions.
	12.1(8a)EW 12.1(13)EW 12.1(19)EW 12.1(20)EW 12.2(20)EW This example sho Catalyst 4500 series Switch# show more Session 1	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements. Added support to display configuration state for remote SPAN and learning. Added support to display ACLs that are applied to SPAN sessions.
	12.1(8a)EW 12.1(13)EW 12.1(19)EW 12.1(20)EW 12.2(20)EW This example shot Catalyst 4500 series Switch# show more	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements. Added support to display configuration state for remote SPAN and learning. Added support to display ACLs that are applied to SPAN sessions.
	12.1(8a)EW 12.1(13)EW 12.1(19)EW 12.1(20)EW 12.2(20)EW This example shot Catalyst 4500 series Switch# show mon Session 1	Support for this command was introduced on the Catalyst 4500 series switch. Added support for differing directions within a single user session. Output enhanced to display configuration status of SPAN enhancements. Added support to display configuration state for remote SPAN and learning. Added support to display ACLs that are applied to SPAN sessions. we how to display whether ACLs are applied to a given SPAN session on a ties switch: hitor

Destination Ports	:	Fa6/2
Encapsulation	:	Native
Ingress	:	Disabled
Learning	:	Disabled
Filter VLANs	:	1
IP Access-group	:	10

This example shows how to display SPAN information for session 2:

```
Switch# show monitor session 2
Session 2
------
Type : Remote Source Session
Source Ports:
RX Only: Fal/1-3
Dest RSPAN VLAN: 901
Ingress : Enabled, default VLAN=2
Learning : Disabled
Switch#
```

This example shows how to display the detailed SPAN information for session 1:

```
Switch# show monitor session 1 detail
Session 1
_____
Type
                 : Local Session
Source Ports
                 :
   RX Only
                : None
   TX Only
               : None
   Both
                : Gi1/1, CPU
Source VLANs
                :
   RX Only
                : None
   TX Only
                : None
   Both
                 : None
Source RSPAN VLAN : Fa6/1
Destination Ports : Fa6/1
   Encapsulation : DOT1Q
         Ingress : Enabled, default VLAN = 2
Filter VLANs
             : None
 Filter Types RX : Good
 Filter Types TX : None
Dest Rspan Vlan : 901
Ingress : Enabled, default VLAN=2
Learning : Disabled
IP Access-group : None
Switch#
```

This example shows how to display SPAN information for session 1 beginning with the line that starts with Destination:

```
Switch# show monitor session 1 | begin Destination
Destination Ports: None
Filter VLANs: None
Switch#
Switch#
```

Related Commands monitor session

show pagp

To display information about the port channel, use the **show pagp** command.

show pagp [group-number] {counters | internal | neighbor}

Syntax Description	group-number	(Option	onal) Channel-group number; valid values are from 1 to 64.	
	counters	Specifie	fies the traffic counter information.	
	internal	Specifie	fies the PAgP internal information.	
	neighbor	Specifie	fies the PAgP neighbor information.	
Defaults	This command h	as no defau	ault settings.	
Command Modes	Privileged EXEC			
Command History	Release	Modifica	cation	
	12.1(8a)EW You can enter an	Support : y show pag	t for this command was introduced on the Catalyst 4500 series switch agp command to display the active PAgP port-channel information. To	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf	Support a y show pag formation, e	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group.	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf	Support a y show pag formation, e	t for this command was introduced on the Catalyst 4500 series switch agp command to display the active PAgP port-channel information. To	
Command History Usage Guidelines Examples	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa	Support a y show pag formation, e ows how to agp counter	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group.	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa	Support a y show pag formation, e ows how to agp counter prmation	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group.	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa Info Port Sent Channel group:	Support : y show pag formation, e ows how to agp counter prmation : Recv	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group. to display information about the PAgP counter: Flush Sent Recv	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa Info Port Sent Channel group: Fa5/4 2660	Support : y show pag formation, e ows how to agp counter prmation = Recv	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group. to display information about the PAgP counter:	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa Info Port Sent Channel group:	Support a y show pag formation, e ows how to agp counter prmation t Recv	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group. to display information about the PAgP counter: Flush Sent Recv	
Usage Guidelines	12.1(8a)EW You can enter any the nonactive inf This example sho Switch# show pa Info Port Sent Channel group: Fa5/4 2660 Fa5/5 2676	Support a y show pag formation, e ows how to agp counter prmation t Recv	agp command to display the active PAgP port-channel information. To , enter the show pagp command with a group. to display information about the PAgP counter:	

This example shows how to display internal PAgP information:

	show pa			1 1 1 1 .	<i>a</i> 5			
Flags:	s: S - Device is sending Slow hello. C - Device is in Consistent state. A - Device is in Auto mode.							
Timers:	H - Hel	lo time:	r is runn	ing.	Q – Qı	uit timer	is running	•
	S - Swi	tching t	timer is :	running.	I - I1	nterface t	imer is run	nning.
Channel	group 1							
				Hello	Partner	PAgP	Learning	
Port	Flags	State	Timers	Interval	Count	Priority	Method	IfIndx
Fa5/4	SC	U6/S7		30s	1	128	Any	129
Fa5/5	SC	U6/S7		30s	1	128	Any	129
Switch#								

This example shows how to display PAgP neighbor information for all neighbors:

	<pre>show pagp neighbor S - Device is sending A - Device is in Auto :</pre>		Device is in Con Device learns on		
Channel	group 1 neighbors				
	Partner	Partner	Partner	Partner Group	
Port	Name	Device ID	Port Age	Flags Cap.	
Fa5/4	JAB031301	0050.0f10.230c	2/45 2s	SAC 2D	
Fa5/5	JAB031301	0050.0f10.230c	2/46 27s	SAC 2D	
Channel	group 2 neighbors				
	Partner	Partner	Partner	Partner Group	
Port	Name	Device ID	Port Age	Flags Cap.	
Fa5/6	JAB031301	0050.0f10.230c	2/47 10s	SAC 2F	
Fa5/7	JAB031301	0050.0f10.230c	2/48 11s	SAC 2F	
0.1.1.1.1					

Switch#

Related Commands

pagp learn-method pagp port-priority

show policy-map

To display information about the policy map, use the show policy-map command.

show policy-map [policy_map_name]

Syntax Description policy_map_name (Optional) Name of the policy map. Defaults This command has no default settings. **Command Modes** Privileged EXEC **Command History** Release Modification 12.1(8a)EW Support for this command was introduced on the Catalyst 4500 series switch. Examples This example shows how to display information for all the policy maps: Switch# show policy-map Policy Map ipp5-policy class ipp5 set ip precedence 6 Switch# This example shows how to display information for a specific policy map: Switch# show policy ipp5-policy Policy Map ipp5-policy class ipp5 set ip precedence 6 Switch# **Related Commands** class-map policy-map show class-map show policy-map interface

show policy-map control-plane

To display the configuration either of a class or of all classes for the policy map of a control plane, use the **show policy-map control-plane** command.

show policy-map control-plane [input [class class-name] | [class class-name]]

Syntax Description	input	(Optional) Displays statistics for the attached input policy.				
	class class-name	(Optional) Displays the name of the class.				
Defaults	This command has no default settings.					
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.2(31)SG	Support for this command was introduced on the Catalyst 4500 series switch				
Usage Guidelines		nap control-plane command displays information for aggregate control-plane of the number or rate of packets that are going to the process level.				
Examples	polices traffic that i	is that the policy map TEST is associated with the control plane. This policy map matches the class-map TEST, while allowing all other traffic (that matches the fault) to go through as is. Table 2-23 describes the fields shown in the display.				
	Switch# show policy-map control-plane					
	Control Plane					
	Service-policy input: system-cpp-policy					
	Class-map: system-cpp-eapol (match-all) 0 packets Match: accoss group pame system cpp capel					
	Match: access-group name system-cpp-eapol Class-map: system-cpp-bpdu-range (match-all)					
	0 packets Match: access-group name system-cpp-bpdu-range					
	Class-map: system-cpp-cdp (match-all) 28 packets Match: access-group name system-cpp-cdp					
	police: Per					
	Class-map: sy 0 packets	/stem-cpp-garp (match-all)				

Match: access-group name system-cpp-garp Class-map: system-cpp-sstp (match-all) 0 packets Match: access-group name system-cpp-sstp Class-map: system-cpp-cgmp (match-all) 0 packets Match: access-group name system-cpp-cgmp Class-map: system-cpp-ospf (match-all) 0 packets Match: access-group name system-cpp-ospf Class-map: system-cpp-igmp (match-all) 0 packets Match: access-group name system-cpp-igmp Class-map: system-cpp-pim (match-all) 0 packets Match: access-group name system-cpp-pim Class-map: system-cpp-all-systems-on-subnet (match-all) 0 packets Match: access-group name system-cpp-all-systems-on-subnet Class-map: system-cpp-all-routers-on-subnet (match-all) 0 packets Match: access-group name system-cpp-all-routers-on-subnet Class-map: system-cpp-ripv2 (match-all) 0 packets Match: access-group name system-cpp-ripv2 Class-map: system-cpp-ip-mcast-linklocal (match-all) 0 packets Match: access-group name system-cpp-ip-mcast-linklocal Class-map: system-cpp-dhcp-cs (match-all) 0 packets Match: access-group name system-cpp-dhcp-cs Class-map: system-cpp-dhcp-sc (match-all) 0 packets Match: access-group name system-cpp-dhcp-sc Class-map: system-cpp-dhcp-ss (match-all) 0 packets Match: access-group name system-cpp-dhcp-ss Class-map: class-default (match-any) 0 packets Match: any 0 packets Switch#

Field	Description
Fields Associated with Classes o	r Service Policies
Service-policy input	Name of the input service policy that is applied to the control plane. (If configured, this field will also show the output service policy.)
Class-map	Class of traffic being displayed. Traffic is displayed for each configured class. The choice for implementing class matches (for example, match-all or match-any) can also appear next to the traffic class.
Match	Match criteria for the specified class of traffic.
	Note For more information about the variety of match criteria options available, refer to the chapter "Configuring the Modular Quality of Service Command-Line Interface" in the Cisco IOS Quality of Service Solutions Configuration Guide.
Fields Associated with Traffic Po	licing
police	police command has been configured to enable traffic policing.
conformed	Action to be taken on packets conforming to a specified rate; displays the number of packets and bytes on which the action was taken.
exceeded	Action to be taken on packets exceeding a specified rate; displays the number of packets and bytes on which the action was taken.

Table 2-23	show policy	y-map control-plan	e Field Descriptions
------------	-------------	--------------------	----------------------

Related Commands

control-plane
service-policy input (control-plane)

show policy-map interface

To display the statistics and configurations of the input and output policies that are attached to an interface, use the **show policy-map interface** command.

show policy-map interface [{fastethernet interface-number} | {gigabitethernet interface-number} | {port-channel number} | {vlan vlan_id}] [input | output]

Syntax Description	fastethernet ini	terface-number	(Optional) Specifies the Fast Ethernet 802.3 interface.		
	gigabitetherne	t interface-number	 (Optional) Specifies the Gigabit Ethernet 802.3z interface. (Optional) Specifies the port channel. (Optional) Specifies the VLAN ID; valid values are from 1 to 4094. 		
	port-channel n	umber			
	vlan vlan_id				
	input		(Optional) Specifies input policies only.		
	output		(Optional) Specifies output policies only.		
Defaults	This command h	as no default settings	3.		
command Modes	Privileged EXE	2			
Command History	Release	Modification			
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.			
	12.1(12c)EW	Added support for extended VLAN addresses.			
	12.2(25)SG	Displays results fo	or full flow policing.		
xamples	This example sh attached to an ir		ne statistics and configurations of all input and output policies		
	Switch# show p	olicy-map interface			
	FastEthernet6	/1			
	service-poli	cy input:ipp5-polic	су		
	0 packet match:ip set:	ipp5 (match-all) s precedence 5 cedence 6			
	class-map: 0 packet match:an 0 pack	У	ch-any)		

```
service-policy output:ipp5-policy
class-map:ipp5 (match-all)
0 packets
match:ip precedence 5
set:
    ip precedence 6
class-map:class-default (match-any)
0 packets
match:any
0 packets
Switch#
```

This example shows how to display the input policy statistics and configurations for a specific interface:

```
Switch# show policy-map interface fastethernet 5/36 input service-policy input:ipp5-policy
```

```
class-map:ipp5 (match-all)
    0 packets
    match:ip precedence 5
    set:
        ip precedence 6
    class-map:class-default (match-any)
        0 packets
    match:any
        0 packets
Switch#
```

With the following configuration, each flow is policed to a 1000000 bps with an allowed 9000-byte burst value.

```
<u>Note</u>
```

If you use the **match flow ip source-address/destination-address** command, these two flows are consolidated into one flow and they have the same source and destination address.

```
Switch# config terminal
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) # class-map c1
Switch(config-cmap)# match flow ip source-address ip destination-address ip protocol 14
source-port 14 destination-port
Switch(config-cmap) # exit
Switch(config) # policy-map p1
Switch(config-pmap)# class c1
Switch(config-pmap-c) # police 1000000 9000
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
Switch(config)# interface fastEthernet 6/1
Switch(config-if)# service-policy input p1
Switch(config-if)# end
Switch# write memory
Switch# show policy-map interface
FastEthernet6/1
class-map c1
   match flow ip source-address ip destination-address ip protocol 14 source-port 14
destination-port
```

L

policy-map p1 class c1 police 1000000 bps 9000 byte conform-action transmit exceed-action drop I interface FastEthernet 6/1 service-policy input p1 Switch# show policy-map p1 Policy Map p1 Class c1 police 1000000 bps 9000 byte conform-action transmit exceed-action drop Switch# show policy-map interface FastEthernet6/1 Service-policy input: p1 Class-map: c1 (match-all) 15432182 packets Match: flow ip source-address ip destination-address ip protocol 14 source-port 14 destination-port police: Per-interface Conform: 64995654 bytes Exceed: 2376965424 bytes Class-map: class-default (match-any) 0 packets Match: any 0 packets Switch#

Related Commands

class-map policy-map show class-map show qos

show policy-map interface vlan

To show the QoS policy-map information applied to a specific VLAN on an interface, use the **show policy-map interface vlan** command.

show policy-map interface vlan interface-id vlan vlan-id

yntax Description	interface interface-	<i>id</i> (Optional) Displays QoS policy-map information for a specific interface.
	vlan vlan-id	(Optional) Displays QoS policy-map information for a specific VLAN.
ommand Modes	Privileged EXEC	
ommand History	Release N	Iodification
	12.1(13)EW S	upport for this command was introduced on the Catalyst 4500 series switch.
amples	Take the following c	configuration as an example:
	interface GigabitE vlan-range 20,400 service-policy i vlan-range 300-30 service-policy o) .nput p1)1
	This example shows interface:	how to display policy-map statistics on VLAN 20 on the Gigabit Ethernet 6/1
	Switch# show polic GigabitEthernet3/	y-map interface gigabitEthernet 3/1 vlan 20 /1 vlan 20
	Service-policy i	.nput: pl
	0 packets Match: any 0 packets police: Per-	iss-default (match-any) Finterface) bytes Exceed: 0 bytes

Related Commands service-policy show policy-map interface

show port-security

To display the port security settings for an interface or for the switch, use the **show port-security** command.

show port-security [address] [interface interface-id] [vlan vlan-id]

Syntax Description	address	(Op port		s all secure MAC add	resses for all ports or for a specifi
	interface inter	face-id (Op	tional) Display	s port security setting	s for a specific interface.
	vlan vlan-id	-			s for a specific VLAN.
Command Modes	Privileged EXE	C			
Command History	Release	Modificatio	n		
-	12.1(13)EW	Support for	this command	was introduced on th	e Catalyst 4500 series switch.
	12.2(18)EW			lisplay sticky MAC a	· · · · · · · · · · · · · · · · · · ·
	12.2(10)EWA			lisplay setting on a pe	
Usage Guidelines	status of all sec If you enter the	ure ports on the	e switch.	-	e administrative and operational nd displays port security settings
	•	•	-	ort-security address rmation for each secu	command displays the secure MA
	command displ	ays all the MA	C addresses for command to di	the interface with ag	ow port-security address interfaing information for each secure dresses for an interface even if yo
Examples	This example sl	hows how to di	splay port secu	rity settings for the en	ntire switch:
	Switch# show y Secure Port N		CurrentAddr (Count)	SecurityViolation (Count)	Security Action
	 Fa3/1	2	2	0	Restrict
	Fa3/2	2	2	0	Restrict
	Fa3/3	2	2	0	Shutdown
	Fa3/4	2	2	0	Shutdown
	Fa3/5	2	2	0	Shutdown
	Fa3/6	2	2	0	Shutdown
	Fa3/7 Fa3/8	2 2	2 2	0	Shutdown Shutdown
	ras/8	2	2	0	SILUCUOWII

1

0

0

Shutdown

Fa3/10

Fa3/11	1	0	0	Shutdown
Fa3/12	1	0	0	Restrict
Fa3/13	1	0	0	Shutdown
Fa3/14	1	0	0	Shutdown
Fa3/15	1	0	0	Shutdown
Fa3/16	1	0	0	Shutdown
Total Addresses i Max Addresses lim Global SNMP trap Switch#	it in System (e:	xcluding one		:8 :1024 :20 (traps per second)

This example shows how to display port security settings for interface Fast Ethernet port 1:

Switch# show port-security	interface fastethernet 5/1
Port Security	: Enabled
Port Status	: Secure-up
Violation Mode	: Shutdown
Aging Time	: 0 mins
Aging Type	: Absolute
SecureStatic Address Aging	: Disabled
Maximum MAC Addresses	: 1
Total MAC Addresses	: 1
Configured MAC Addresses	: 0
Sticky MAC Addresses	: 1
Last Source Address	: 0000.0001.001a
Security Violation Count	: 0
Switch#	

This example shows how to display the maximum allowed number of secure MAC addresses and the current number of secure MAC addressees on Fast Ethernet port 1:

Switch# show port-security interface fastethernet5/1 vlan Default maximum: 22 VLAN Maximum Current 2 22 3 3 22 3 4 22 3 5 22 1 6 22 2 Switch#

This example shows how to display the port security settings on Fast Ethernet port 1 for VLANs 2 and 3:

Switch# show port-security interface fastethernet5/1 vlan 2-3 Default maximum: 22 VLAN Maximum Current 2 22 3 3 22 3 Switch#

This example shows how to display all secure MAC addresses configured on Fast Ethernet port 1 with aging information for each address.

Switch# show port-security interface fastethernet5/1 address

Secure Mac Address Table _____ Mac Address 0001.0001.0001 SecureConfigured 0001.0001.0002 SecureSticky Vlan Mac Address Type Ports Remaining Age(mins) _ _ _ _ ____ _____ 2 Gi1/1 2 Gi1/1 _ 0001.0001.0003 SecureSticky 2 Gi1/1 _ 0001.0001.0001 SecureConfigured Gi1/1 3 _

3	0001.0001.0002	SecureSticky	Gi1/1	-	
3	0001.0001.0003	SecureSticky	Gi1/1	-	
4	0001.0001.0001	SecureConfigured	Gi1/1	-	
4	0001.0001.0002	SecureSticky	Gi1/1	-	
4	0001.0001.0003	SecureSticky	Gi1/1	-	
5	0001.0001.0001	SecureConfigured	Gi1/1	-	
6	0001.0001.0001	SecureConfigured	Gi1/1	-	
6	0001.0001.0002	SecureConfigured	Gi1/1	-	

Total Addresses: 12 Switch#

This example shows how to display all secure MAC addresses configured on VLANs 2 and 3 on Fast Ethernet port 1 with aging information for each address:

```
Switch# show port-security interface fastethernet5/1 address vlan 2-3
```

Secure Mac Address Table _____ Vlan Mac Address Type Ports Remaining Age(mins) Туре -----2 0001.0001.0001 SecureConfigured Gi1/1 2 0001.0001.0002 SecureSticky Gi1/1 _ Gi1/1 2 0001.0001.0003 SecureSticky _ 3 0001.0001.0001 SecureConfigured Gi1/1 _ 0001.0001.0002 SecureSticky 0001.0001.0003 SecureSticky 3 Gi1/1 3 Gi1/1 _ _____ Total Addresses: 12

```
Total Addresses: 12
Switch#
```

This example shows how to display all secure MAC addresses configured on all switch interfaces:

Switch# show port-security address

Secure Mac Address Table

Vlan	Mac Address	Туре	Ports	Remaining Age (mins)
	0000.0001.0000		Fa3/1	15 (I)
1		SecureConfigured		- ()
-	0000.0001.0001	SecureConfigured	Fa3/1	14 (I)
1	0000.0001.0100	SecureConfigured	Fa3/2	-
1	0000.0001.0101	SecureConfigured	Fa3/2	-
1	0000.0001.0200	SecureConfigured	Fa3/3	-
1	0000.0001.0201	SecureConfigured	Fa3/3	-
1	0000.0001.0300	SecureConfigured	Fa3/4	-
1	0000.0001.0301	SecureConfigured	Fa3/4	-
1	0000.0001.1000	SecureDynamic	Fa3/5	-
1	0000.0001.1001	SecureDynamic	Fa3/5	-
1	0000.0001.1100	SecureDynamic	Fa3/6	-
1	0000.0001.1101	SecureDynamic	Fa3/6	-
1	0000.0001.1200	SecureSticky	Fa3/7	-
1	0000.0001.1201	SecureSticky	Fa3/7	-
1	0000.0001.1300	SecureSticky	Fa3/8	-
1	0000.0001.1301	SecureSticky	Fa3/8	-

Total Addresses in System (excluding one mac per port) :8 Max Addresses limit in System (excluding one mac per port) :3072 Switch#

This example shows how to display the maximum allowed number of secure MAC addresses and the current number of secure MAC addresses on interface Gigabitethernet1/1:

```
Switch# show port-security interface gigabitethernet1/1 vlan
Default maximum: 22
VLAN Maximum
               Current
    2
              22
                          3
    3
              22
                          3
    4
              22
                          3
    5
              22
                          1
    6
              22
                          2
```

Switch#

This example shows how to display the port security settings on interface Gigabitethernet1/1 for VLANs 2 and 3:

```
Switch# show port-security interface gigabitethernet1/1 vlan 2-3
Default maximum: 22
VLAN Maximum Current
2 22 3
3 22 3
Switch#
```

This example shows how to display all secure MAC addresses configured on interface Gigabitethernet1/1 with aging information for each address.

Switch# show port-security interface gigabitethernet1/1 address

Secure Mac Address Table

Vlan	Mac Address	Туре	Ports	Remaining Age(mins)
2	0001.0001.0001	SecureConfigured	Gi1/1	_
2	0001.0001.0002	SecureSticky	Gi1/1	-
3	0001.0001.0001	SecureConfigured	Gi1/1	-
3	0001.0001.0002	SecureSticky	Gi1/1	-
3	0001.0001.0003	SecureSticky	Gi1/1	-
4	0001.0001.0001	SecureConfigured	Gi1/1	-
4	0001.0001.0003	SecureSticky	Gi1/1	_
6	0001.0001.0001	SecureConfigured	Gi1/1	-
6	0001.0001.0002	SecureConfigured	Gi1/1	_

Total Addresses: 12

Switch#

This example shows how to display all secure MAC addresses configured on VLANs 2 and 3 on interface Gigabitethernet1/1 with aging information for each address:

Switch# show port-security interface gigabitethernet1/1 address vlan 2-3

'lan	Mac Address	Туре	Ports	Remaining Age(mins)
2	0001.0001.0001	SecureConfigured	Gi1/1	-
2	0001.0001.0002	SecureSticky	Gi1/1	_
2	0001.0001.0003	SecureSticky	Gi1/1	_
3	0001.0001.0001	SecureConfigured	Gi1/1	_
3	0001.0001.0002	SecureSticky	Gi1/1	_
3	0001.0001.0003	SecureSticky	Gi1/1	_

Related Commands switchport port-security

show power

To display information about the power status, use the show power command.

show power [available | capabilities | detail | inline {[interface] | consumption default | module
mod} | module | status | supplies]

Syntax Description	available	(Optional) Displays the available system power.
	capabilities	(Optional) Displays the individual power supply capabilities.
	detail	(Optional) Displays detailed information on power resources.
	inline	(Optional) Displays the PoE status.
	interface	(Optional) Type of interface; the only valid value is fastethernet.
	consumption def	ault (Optional) Displays the PoE consumption.
	module mod	(Optional) Displays the PoE consumption for the specified module.
	module	(Optional) Displays the power consumption for each module.
	status	(Optional) Displays the power supply status.
	supplies	(Optional) Displays the number of power supplies needed by the system.
Defaults	This command has	s no default settings.
Command Modes	Privileged EXEC	
	Thinegeu Little	
Command History	Release	Modification
Command History	Release 12.1(8a)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch.
Command History		
Command History	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.1(8a)EW 12.2(25)SG If a powered device	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS. e is connected to an interface with external power, the switch does not recognize the
	12.1(8a)EW 12.2(25)SG If a powered device	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS.
	12.1(8a)EW12.2(25)SGIf a powered devicepowered device. Tunknown.	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS. e is connected to an interface with external power, the switch does not recognize the he Device column in the output of the show power inline command displays as
	12.1(8a)EW 12.2(25)SG If a powered device powered device. T unknown. If your port is not	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS. e is connected to an interface with external power, the switch does not recognize th he Device column in the output of the show power inline command displays as capable of supporting Power over Ethernet, you will receive this message:
Command History Usage Guidelines	12.1(8a)EW 12.2(25)SG If a powered device powered device. T unknown. If your port is not Power over Ether	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS. e is connected to an interface with external power, the switch does not recognize the he Device column in the output of the show power inline command displays as capable of supporting Power over Ethernet, you will receive this message: net not supported on interface Admin
	 12.1(8a)EW 12.2(25)SG If a powered device powered device. T unknown. If your port is not Power over Ether The show power is not power in the show power in the show power is not power is not power in the show power is not power power is not power is not power power power is not power powe	Support for this command was introduced on the Catalyst 4500 series switch. Displays inline power handling for the Supervisor Engine II-TS. e is connected to an interface with external power, the switch does not recognize th he Device column in the output of the show power inline command displays as capable of supporting Power over Ethernet, you will receive this message:

Examples

This example shows how to display information about the general power supply:

Power	show power Model No	Туре	Status		Inline Status
	 PWR-C45-2800AC PWR-C45-1000AC		-	-	-
*** Pow	er Supplies of dif	ferent type	e have been de	tected**	*
	upplies needed by upplies currently	-			
Power S	ummarv	1	Maximum		
(in Wa	tts)				
	Power (12V)	328	1360		
Inline	Power (-50V)	0	1400		
Backpla	ne Power (3.3V)	10	40		
 Total U Switch#		 338 (not t	to exceed Tota	l Maximu	m Available = 750)

This example shows how to display the amount of available system power:

Switch# show power available Power Summary (in Watts) Available Used Remaining ----- ----- ------ System Power 1360 280 1080 Inline Power 1400 0 1400 Maximum Power 2800 280 2520

Switch#

Total

This example shows how to display detailed information for system power.

Switch# Power	show power detai	1		Fan	Tnline
	Model No	Туре	Status		
PS1 PS1-1 PS1-2 PS1-3	PWR-C45-1400DC	DCSP1400W 12.5A 15.0A 15.0A	off	good	n.a.
PS2	none				
	upplies needed by upplies currently	-			
Power S	ummary]	Maximum		
(in Wa	tts) 	Used A	vailable		
System	Power (12V)	360	360		
	Power (-50V)		0		
Backpla	ne Power (3.3V)	U 	40		

360

400

Module Inline Power Summary (Watts)

(12V -> -48V on board conversion) ------Maximum Used Available Mod _____ ____ _ _ _ 5 1 25 ____ _____ _ _ _ Watts Used of System Power (12V) Mod Model currently out of reset in reset ----- ------_ _ _ _
 1
 WS-X4013+TS
 180

 2
 WS-X4506-GB-T
 60

 3
 WS-X424-GB-RJ45
 90

 - Fan Tray
 30
 180 180 60 20 90 50 30 - ----- Fan Tray ----- ------ ------_____ 360 330 250 Total Watts used of Chassis Inline Power (-50V) Inline Power Admin Inline Power Oper PS Device Mod Model PS Device Efficiencv _____ _____ _____ _____ 2 WS-X4506-GB-T 0 0 0 0 89 3 WS-X4424-GB-RJ45 ----_ _____ _____ _____ Total 0 0 0 0 Watts used of Module Inline Power (12V -> -50V) Inline Power Admin Inline Power Oper Mod Model PS Device PS Device Efficiency ____ _____ _____ _____ _____ WS-X4013+TS 1 6 5 3 3 90 -----_____ _____ Switch#

This example shows how to display power consumption for the module.

Switch# show power module

Watts	Watts Used of System Power (12V)									
Mod	Model	currently	out of reset	in reset						
1	WS-X4013+TS	180	180	180						
2	WS-X4506-GB-T	60	60	20						
3	WS-X4424-GB-RJ45	90	90	50						
	Fan Tray	30								
	Total	360	330	250						

Watts used of Chassis Inline Power (-50V)

		Inline Po	ower Admin	Inline Po	ower Oper	
Mod	Model	PS	Device	PS	Device	Efficiency
2	WS-X4506-GB-T	0	0	0	0	89
3	WS-X4424-GB-RJ45	-	-	-	-	-
	Total	0	0	0	0	
Watts	used of Module In	line Power	r (12V -> -	50V)		
		Inline Po	ower Admin	Inline Po	ower Oper	
Mod	Model	PS	Device	PS	Device	Efficiency
1	WS-X4013+TS	6	5	3	3	90

Switch#



The "Inline Power Oper" column displays the PoE consumed by the powered devices attached to the module in addition to the PoE consumed by the FPGAs and other hardware components on the module. The "Inline Power Admin" column displays only the PoE allocated by the powered devices attached to the module.

This example shows how to display the power status information:

Switch#	show po	wer stat	us				
Power						Fan	Inline
Supply	Model N	0	Туре	St	atus	Sensor	Status
PS1	PWR-C45	-2800AC	AC 28	00W go	bod	good	good
PS2	PWR-C45	-2800AC	AC 28	00W go	bod	good	good
Power S	upply	Max	Min	Max	Min	Absolute	
(Nos in	Watts)	Inline	Inline	System	System	Maximum	
PS1		1400	1400	1360	1360	2800	
PS2		1400	1400	1360	1360	2800	
Switch#							

This example shows how to verify the PoE consumption for the switch:

```
Switch# show power inline consumption default
Default PD consumption : 5000 mW
Switch#
```

This example shows how to display the status of inline power:

Switch# **show power inline** Available:677(w) Used:117(w) Remaining:560(w)

Interface	Admin	Oper				(Watts) To Device	Device			Class
Fa3/1	auto	on		17.3		15.4	Ieee PD			0
Fa3/2	auto	on		4.5		4.0	Ieee PD			1
Fa3/3	auto	on		7.1		6.3	Cisco IP	Phone	7960	0
Fa3/4	auto	on		7.1		6.3	Cisco IP	Phone	7960	n/a
Fa3/5	auto	on		17.3		15.4	Ieee PD			0
Fa3/6	auto	on		17.3		15.4	Ieee PD			0
Fa3/7	auto	on		4.5		4.0	Ieee PD			1
Fa3/8	auto	on		7.9		7.0	Ieee PD			2
Fa3/9	auto	on		17.3		15.4	Ieee PD			3
Fa3/10	auto	on		17.3		15.4	Ieee PD			4
Fa3/11	auto	off		0		0	n/a			n/a
Fa3/12	auto	off		0		0	n/a			n/a
Fa3/13	auto	off		0		0	n/a			n/a
Fa3/14	auto	off		0		0	n/a			n/a
Fa3/15	auto	off		0		0	n/a			n/a
Fa3/16	auto	off		0		0	n/a			n/a
Fa3/17	auto	off		0		0	n/a			n/a
Fa3/18	auto	off		0		0	n/a			n/a
Totals:		10	on	117.	5	104.6				
Switch#										

This example shows how to display the number of power supplies needed by the system:

```
Switch# show power supplies
Power supplies needed by system = 2
Switch#
```

This example shows how to display the PoE status for Fast Ethernet interface 3/1:

Switch# show power inline fastethernet3/1 Available:677(w) Used:11(w) Remaining:666(w)									
Interface Admin	Oper	Power From PS	(Watts) To Device	Device	Class				
Fa3/1 auto	on	11.2	10.0	Ieee PD	0				
Interface AdminP (Wat	owerMax . ts)		ption						
Fa3/1 Switch#	15.4		10.0						

```
<u>Note</u>
```

When the Supervisor Engine II+TS is used with the 1400 W DC power supply (PWR-C45-1400DC), and only one 12.5 A input of the DC power supply is used, the supervisor engine's power consumption may vary depending on whether there is any linecard inserted at slot 2 and 3, as well as on the type of linecards inserted. This amount varies between 155 W and 330 W. This variability also affects the maximum amount of available supervisor engine inline power, which can also vary from 0 W to 175 W. Therefore, it is possible for a supervisor engine to deny inline power to some connected inline power devices when one or more linecards are inserted into the chassis.

The output of the commands **show power detail** and **show power module** display the supervisor engine's variable power consumption and its inline power summary.

Switch# show power detai sh power detail	1			
Power			Fan	Inline
Supply Model No	Туре	Status	Sensor	Status
PS1 PWR-C45-1400DC			good	n.a.
PS1-1	12.5A			
PS1-2	15.0A			
PS1-3	15.0A	off		
PS2 none				
Power supplies needed by Power supplies currently Power Summary (in Watts)	available	: 1 Maximum		
System Power (12V)	360	360		
Inline Power (-50V)	0	0		
Backplane Power (3.3V)	0	40		
Total Module Inline Power Summ		400		
$(12V \rightarrow -48V \text{ on board co})$	nversion)			

1	5	25				
1 		25				
Mr. 1	M. J. J.		Used of Sys			
Mod 	Model		ly out of	reset 1 	n reset 	
1	WS-X4013+TS	180	180		180	
2	WS-X4506-GB-T	60	60		20	
3	WS-X4424-GB-RJ45	90	90		50	
 	Fan Tray	30				
	Total	360	330		250	
			ed of Chassi ower Admin)V)
Mod	Model		Device	PS	Device	Efficienc
2	WS-X4506-GB-T	0	0	0	0	89
3	WS-X4424-GB-RJ45	-	-	-	-	-
	Total	0	0	0	0	
			ed of Module ower Admin			-> -50V)
-	Model	PS	Device	PS	Device	Efficienc
Mod			Device	10	Device	
1 Swit(WS-X4013+TS Ch#sh power module	6	5	3	3	90
 1 Swit(WS-X4013+TS	6 Watts		3 tem Powe	3 	
1 Swite sh po Mod	WS-X4013+TS Ch#sh power module ower module Model	6 Watts current	5 Used of Sys	3 tem Powe reset i	3 r (12V) n reset 	
1 Switc sh po Mod 	WS-X4013+TS Ch#sh power module ower module Model WS-X4013+TS	6 Watts current 180	5 Used of Sys ly out of 180	3 tem Powe reset i 	3 n reset 180	
1 Swite sh po Mod	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current	5 Used of Sys	3 tem Powe reset i	3 r (12V) n reset 	
1 Swite sh po Mod 1 2	WS-X4013+TS Ch#sh power module ower module Model WS-X4013+TS	6 Watts current 180 60	5 Used of Sys ly out of 180 60	3 tem Powe reset i 	3 r (12V) n reset 180 20	
1 Swite sh po Mod 1 2	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90	5 Used of Sys ly out of 180 60 90	3 	3 r (12V) n reset 180 20	
1 Swite sh po Mod 1 2	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi	3 tem Powe reset i s Inline	3 r (12V) n reset 180 20 50 250 Power (-50	90
1 Switch sh po Mod 1 2 3 	WS-X4013+TS Ch#sh power module ower module Model 	Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device	3 tem Powe reset i s Inline Inline P	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper	90
1 Swite sh po Mod 1 2 3 	WS-X4013+TS Ch#sh power module ower module Model 	Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin	3 tem Powe reset i s Inline Inline P	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper	90
1 Switt sh po Mod 1 2 3 	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device	3 tem Powe reset i s Inline Inline P PS	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper Device	90
1 Switt sh po Mod 1 2 3 Mod 2	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device 0	3 tem Powe reset i s Inline Inline P PS	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper Device	90 DV) Efficienc
1 Switch sh po Mod 1 2 3 Mod 2	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device 0 0 ed of Module	3 tem Powe reset i s Inline P PS 0 0 Inline	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper Device 0 0 Power (12V	90
1 Switt Sh po Mod 1 2 3 	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device 0 0 ed of Module ower Admin	3 tem Powe reset i s Inline Inline P PS 0 0 Inline Inline P	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper Device 0 0 Power (12V ower Oper	90
1 Switt sh po Mod 1 2 3 2 3	WS-X4013+TS Ch#sh power module ower module Model 	6 Watts current 180 60 90 30 	5 Used of Sys ly out of 180 60 90 330 ed of Chassi ower Admin Device 0 0 ed of Module	3 tem Powe reset i s Inline Inline P PS 0 0 Inline Inline P	3 r (12V) n reset 180 20 50 250 Power (-50 ower Oper Device 0 0 Power (12V ower Oper	90

Related Commands

power dc input power inline power inline consumption power redundancy-mode power supplies required

I

show qos

To display QoS information, use the show qos command.

show qos

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes Privileged EXEC

 Release
 Modification

 12.1(8a)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows the output that might be displayed if you do not enter any keywords:

Switch# **show qos** QoS is enabled globally Switch#

Related Commandsqos (global configuration mode)qos (interface configuration mode)

show qos aggregate policer

To display QoS aggregate policer information, use the show qos aggregate policer command.

show qos aggregate policer [aggregate_name]

Syntax Description	aggregate_name	e (Optional) Named aggregate policer.
Defaults	This command h	nas no default settings.
Command Modes	Privileged EXEC	2
Command History	Release	Modification
	12.1(8a)EW	Modification Support for this command was introduced on the Catalyst 4500 series switch.
Command History Usage Guidelines Examples	12.1(8a)EW The aggregate point	Support for this command was introduced on the Catalyst 4500 series switch.

show qos dbl

To display global Dynamic Buffer Limiting (DBL) information, use the show qos dbl command.

show qos dbl

Syntax Description This command has no arguments or keywords.
--

- **Defaults** This command has no default settings.
- **Command Modes** Privileged EXEC

 Release
 Modification

 12.1(13)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display global DBL information: Switch# show qos dbl DBL is enabled globally

DBL flow includes vlan DBL flow includes 14-ports DBL does not use ecn to indicate congestion DBL exceed-action mark probability:15% DBL max credits:15 DBL aggressive credit limit:10 DBL aggressive buffer limit:2 packets Switch#

Related Commandsqos (global configuration mode)
qos dbl

show qos interface

To display queueing information, use the show qos interface command.

show qos interface {fastethernet interface-number | gigabitethernet interface-number} |
[vlan vlan_id | port-channel number]

Syntax Description	fastethernet interface-number			Specifies the Fast Ethernet 802.3 interface.					
	gigabitetherne	et interface-ni	umber	Specifies the	Gigabit Ethernet 802.3z interface.				
	vlan vlan_id			(Optional) Sp 4094.	pecifies the VLAN ID; valid values are from 1 to				
	port-channel /	number		(Optional) Specifies the port channel; valid ranges are from 1 to 64.					
Defaults	This command	This command has no default settings.							
Command Modes	Privileged EXE	C							
Command History	Release	Modificat	ion						
	12.1(8a)EW	Support fo	or this comma	and was intro	duced on the Catalyst 4500 series switch.				
	12.1(13)EW	Added sup	port for exte	nded VLAN	addresses.				
	12.1(19)EW	Display cl	hanged to inc	lude the Port	Trust Device.				
Examples	Port QoS i Administra Operationa Port Trust	gos interfac abled globall	e fastethern Ly cust State: State: 'un sco-phone'	tet 6/1	ion:				
	Tx-Queue 1 2 3 4 Switch#	e Bandwidth ShapeRate Priority QueueSize (bps) (bps) (packets) 31250000 disabled N/A 240 31250000 disabled N/A 240 31250000 disabled normal 240 31250000 disabled N/A 240							
Related Commands	qos map cos show qos tx-queue								

show qos maps

To display QoS map information, use the show qos maps command.

show qos maps [cos | dscp [policed | tx-queue]]

Syntax Description	cos	(Optional) Displays CoS map information.					
	dscp						
	policed	(Optional) Displays policed map information.					
	tx-queue	(Optional) Displays tx-queue map information.					
Defaults	This commar	nd has no default settings.					
Command Modes	Privileged EX	XEC					
Command History	Release	Modification					
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.					
Examples	Switch# sho						
Examples	Switch# sho w DSCP-TxQueue						
Examples	Switch# sho DSCP-TxQueu d1 :d2 0 : 	v gos maps e Mapping Table (dscp = d1d2) L 2 3 4 5 6 7 8 9 L 01 01 01 01 01 01 01 01					
Examples	Switch# sho DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0:	v gos maps e Mapping Table (dscp = d1d2) 1 2 3 4 5 6 7 8 9					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0:	<pre>v gos maps e Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0:	<pre>v gos maps a Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 1 01 01 01 01 01 01 01 01 0 01 01 01 01 02 02 02 02 2 02 02 02 02 02 02 02 2 03 03 03 03 03 03 03 03 3 03 03 03 03 03 03 04 04</pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0 1 : 01 0 2 : 02 0 3 : 02 0 4 : 03 0 5 : 04 0	<pre>v gos maps e Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0:	<pre>v gos maps a Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 1 01 01 01 01 01 01 01 01 1 01 01 01 01 02 02 02 02 2 02 02 02 02 02 02 02 2 03 03 03 03 03 03 03 03 3 03 03 03 03 03 03 03 04 04 4 04 04 04 04 04 04 04 04</pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0:	<pre>v gos maps = Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 04 6 : 04 04 Policed DSC d1 :d2 0 : 0 : 00 0:	<pre>v gos maps a Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 1 01 01 01 01 01 01 01 01 1 01 01 01 01 01 01 01 2 02 02 02 02 02 02 2 02 02 02 02 02 02 02 2 03 03 03 03 03 03 03 03 3 03 03 03 03 03 03 03 04 04 4 04 04 04 04 04 04 04 04 4 04 04 9 Mapping Table (dscp = d1d2) 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0: Policed DSCI d1 :d2 0 : 0 : 00 0: 1 : 10 1:	<pre>v qos maps = Mapping Table (dscp = d1d2) 1 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 : d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0: Policed DSCI d1 : d2 0 : 0 : 00 0: 1 : 10 1: 2 : 20 2:	<pre>v qos maps = Mapping Table (dscp = d1d2) 1 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0: Policed DSCI d1 :d2 0 : 0 : 00 0: 1 : 10 1: 2 : 20 2: 3 : 30 3:	<pre>v qos maps = Mapping Table (dscp = d1d2) 1 2 3 4 5 6 7 8 9 </pre>					
Examples	Switch# show DSCP-TxQueue d1 :d2 0 : 0 : 01 0: 1 : 01 0: 2 : 02 0: 3 : 02 0: 4 : 03 0: 5 : 04 0: 6 : 04 0: Policed DSCI d1 :d2 0 : 0 : 00 0: 1 : 10 1: 2 : 20 2: 3 : 30 3:	<pre>v qos maps = Mapping Table (dscp = d1d2) 1 2 3 4 5 6 7 8 9 </pre>					

DSC	CP-Co	S I	ſapŗ	ping	у Та	able	e (d	lscr) =	d1o	12)
d1	:d2	0	1	2	3	4	5	6	7	8	9
0	:	00	00	00	00	00	00	00	00	01	01
1	:	01	01	01	01	01	01	02	02	02	02
2	:	02	02	02	02	03	03	03	03	03	03
3	:	03	03	04	04	04	04	04	04	04	04
4	:	05	05	05	05	05	05	05	05	06	06
5	:	06	06	06	06	06	06	07	07	07	07
6	:	07	07	07	07						
Cos	S-DSC	CP N	ſapŗ	oing	y Ta	able	Э				
	CoS	: () 1	L 2	2 3	3 4	1 5	56	5 7	7	

DSCP: 0 8 16 24 32 40 48 56

Switch#

Related Commands

qos (global configuration mode) qos (interface configuration mode)

show redundancy

To display redundancy facility information, use the **show redundancy** command.

show redundancy {clients | counters | history | states}

Syntax Description						
	clients	(Optional) Displays information about the redundancy facility client.				
	counters (Optional) Displays information about the redundancy facility counter					
	history	(Optional) Displays a log of past status and related information for the redundancy facility.				
	states	(Optional) Displays information about the redundancy facility state.				
Defaults	Its This command has no default settings.					
ommand Modes	Privileged EXEC					
Command History	Release	Modification				
	12.1.(13)EW	Support for this command was introduced on the Catalyst 4500 series switch (Catalyst 4507R only).				
	4507r-demo#sho					
		em Information :				
	Availab Switchovers sy	-				
	Availab Switchovers sy Last s Configured Operating	em Information : ble system uptime = 2 days, 2 hours, 39 minutes rstem experienced = 0 Standby failures = 0				
	Availab Switchovers sy Last s Configured Operating	<pre>image: See in the second second</pre>				

Switch#

This example shows how to display redundancy facility client information:

```
Switch# show redundancy clients

clientID = 0 clientSeq = 0 RF_INTERNAL_MSG

clientID = 30 clientSeq = 135 Redundancy Mode RF

clientID = 28 clientSeq = 330 GALIOS_CONFIG_SYNC

clientID = 65000 clientSeq = 65000 RF_LAST_CLIENT Switch
```

The output displays the following information:

- clientID displays the client's ID number.
- clientSeq displays the client's notification sequence number.
- Current redundancy facility state.

This example shows how to display the redundancy facility counter information:

```
Switch# show redundancy counters
Redundancy Facility OMs
              comm link up = 1
        comm link down down = 0
          invalid client tx = 0
          null tx by client = 0
               tx failures = 0
      tx msg length invalid = 0
      client not rxing msgs = 0
 rx peer msg routing errors = 0
          null peer msg rx = 0
        errored peer msg rx = 0
                 buffers tx = 1535
     tx buffers unavailable = 0
                 buffers rx = 1530
      buffer release errors = 0
 duplicate client registers = 0
  failed to register client = 0
       Invalid client syncs = 0
```

This example shows how to display redundancy facility history information:

```
Switch# show redundancy history
00:00:01 client added: RF_INTERNAL_MSG(0) seq=0
00:00:01 client added: RF_LAST_CLIENT(65000) seq=65000
00:00:01 client added: GALIOS_CONFIG_SYNC(28) seq=330
00:00:03 client added: Redundancy Mode RF(30) seq=135
```

```
00:00:03 *my state = INITIALIZATION(2) *peer state = DISABLED(1)
00:00:03 RF_PROG_INITIALIZATION(100) RF_INTERNAL_MSG(0) op=0 rc=11
00:00:03 RF_PROG_INITIALIZATION(100) Redundancy Mode RF(30) op=0 rc=11
00:00:03 RF_PROG_INITIALIZATION(100) GALIOS_CONFIG_SYNC(28) op=0 rc=11
00:00:03 RF_PROG_INITIALIZATION(100) RF_LAST_CLIENT(65000) op=0 rc=11
00:00:03 *my state = NEGOTIATION(3) peer state = DISABLED(1)
00:00:25 RF_EVENT_GO_ACTIVE(511) op=0
00:00:25 *my state = ACTIVE-FAST(9) peer state = DISABLED(1)
00:00:25 RF_STATUS_MAINTENANCE_ENABLE(403) Redundancy Mode RF(30) op=0
00:00:25 RF_STATUS_MAINTENANCE_ENABLE(403) GALIOS_CONFIG_SYNC(28) op=0
00:00:25 RF_PROG_ACTIVE_FAST(200) RF_INTERNAL_MSG(0) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_FAST(200) Redundancy Mode RF(30) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_FAST(200) GALIOS_CONFIG_SYNC(28) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_FAST(200) RF_LAST_CLIENT(65000) op=0 rc=11
00:00:25 *my state = ACTIVE-DRAIN(10) peer state = DISABLED(1)
00:00:25 RF_PROG_ACTIVE_DRAIN(201) RF_INTERNAL_MSG(0) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_DRAIN(201) Redundancy Mode RF(30) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_DRAIN(201) GALIOS_CONFIG_SYNC(28) op=0 rc=11
00:00:25 RF_PROG_ACTIVE_DRAIN(201) RF_LAST_CLIENT(65000) op=0 rc=11
---cut---cut---cut---
---cut---cut---cut---
00:01:34 RF_PROG_PLATFORM_SYNC(300) RF_INTERNAL_MSG(0) op=0 rc=11
00:01:34 RF_PROG_PLATFORM_SYNC(300) Redundancy Mode RF(30) op=0 rc=11
00:01:34 RF_PROG_PLATFORM_SYNC(300) GALIOS_CONFIG_SYNC(28) op=0 rc=0
00:01:34 RF_EVENT_CLIENT_PROGRESSION(503) GALIOS_CONFIG_SYNC(28) op=1 rc=0
00:01:36 RF_EVENT_PEER_PROG_DONE(506) GALIOS_CONFIG_SYNC(28) op=300
00:01:36 RF_PROG_PLATFORM_SYNC(300) RF_LAST_CLIENT(65000) op=0 rc=0
00:01:36 RF_EVENT_CLIENT_PROGRESSION(503) RF_LAST_CLIENT(65000) op=1 rc=0
00:01:36 RF_EVENT_PEER_PROG_DONE(506) RF_LAST_CLIENT(65000) op=300
00:01:38 *my state = ACTIVE(13) *peer state = STANDBY COLD(4)
```

This example shows how to display information about the redundancy facility state:

```
Switch# show redundancy states
```

```
my state = 13 -ACTIVE
    peer state = 8 -STANDBY HOT
          Mode = Duplex
          Unit = Primary
        Unit ID = 2
Redundancy Mode (Operational) = Stateful Switchover
Redundancy Mode (Configured) = Stateful Switchover
     Split Mode = Disabled
   Manual Swact = Enabled
Communications = Up
   client count = 21
 client_notification_TMR = 240000 milliseconds
         keep_alive TMR = 9000 milliseconds
        keep_alive count = 0
    keep_alive threshold = 18
           RF debug mask = 0x0
Switch#
```

Related Commands

redundancy redundancy force-switchover

show running-config

To display the module status and configuration, use the show running-config command.

show running-config [module slot]

Syntax Description	module slot	(Optional) Specifies the module slot number; valid values are from 1 to 6.					
Defaults	This command has no default settings.						
Command Modes	Privileged EXEC						
Command History	Release Modification						
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.					
Usage Guidelines	In some cases, you might see a difference in the duplex mode displayed when you enter the show interfaces command and the show running-config command. If you do see a difference, the duplex mode displayed in the show interfaces command is the actual duplex mode that the interface is running. The show interfaces command shows the operating mode for an interface, while the show running-config command shows the configured mode for an interface. The show running-config command output for an interface may display a duplex mode configuration but no configuration for the speed. When no speed is displayed in the output, it indicates that the interface speed is configured to be auto and that the duplex mode shown becomes the operational setting once the speed is configured to something other than auto. With this configuration, it is possible that the operating duplex mode for that interface does not match the duplex mode shown with the show running-config command.						
Examples	Switch# show r 03:23:36:%SYS- Building confi Current config ! version 12.1 no service pad service timest service timest no service pas ! hostname Switc ! !	-5-CONFIG_I:Configured from console by consolesh runn iguration guration:3268 bytes d camps debug uptime camps log uptime ssword-encryption ch					
	power supplies ip subnet-zero						

```
!
!
interface FastEthernet1
no ip address
shutdown
duplex auto
speed auto
Switch#
```

This example shows the output for the **show running-config** command when you have enabled the **switchport voice vlan** command:

```
Switch# show running-config int fastethernet 6/1
Building configuration...
Current configuration:133 bytes
!
interface FastEthernet6/1
switchport voice vlan 2
no snmp trap link-status
spanning-tree portfast
channel-group 1 mode on
end
```

Switch#

show slavebootflash:

To display information about the standby bootflash file system, use the **show slavebootflash:** command.

show slavebootflash: [all | chips | filesys]

Syntax Description	all (Optional) Displays all possible Flash information.						
	chips (Optional) Displays Flash chip information.						
	filesys	(Optional) Displays file system information.					
Defaults	This command has no default settings.						
Command Modes	EXEC						
Command History	Release	Modification					
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.					
Examples	Switch# show F I Device Numb	er = 0 LOCK: bootflash					
	Length Programming File System MONLIB Offs Bad Sector Squeeze Log Squeeze Buf Num Spare S Spares: STATUS INFO: Writable NO File Ope	= 1000000 Sector Size = 40000 Algorithm = 39 Erased State = FFFFFFF offset = 40000 Length = F40000 et = 100 Length = C628 Map Offset = 3FFF8 Length = 8 Offset = F80000 Length = 40000 fer Offset = FC0000 Length = 40000 ectors = 0					
	Complete St No Unrecove No Squeeze USAGE INFO: Bytes Used Bad Sectors OK Files Deleted Fil Files w/Err Switch>	red Errors in progress = 917CE8 Bytes Available = 628318 = 0 Spared Sectors = 0 = 2 Bytes = 917BE8 es = 0 Bytes = 0					

This example shows how to display system image information:

```
Switch# show slavebootflash:
-# - ED --type-- --crc-- -seek-- nlen -length- ----date/time----- name
1 .. image 8C5A393A 237E3C 14 2063804 Aug 23 1999 16:18:45 c4-boot-mz
2 .. image D86EE0AD 957CE8 9 7470636 Sep 20 1999 13:48:49 rp.halley
Switch>
```

This example shows how to display all bootflash information:

```
Switch# show slavebootflash: all
-# - ED --type-- --crc--- seek-- nlen -length- ----date/time----- name
1 .. image
            8C5A393A 237E3C 14 2063804 Aug 23 1999 16:18:45 c4-boot-
mz
2 .. image
            D86EE0AD 957CE8 9 7470636 Sep 20 1999 13:48:49 rp.halley
6456088 bytes available (9534696 bytes used)
-----FILE SYSTEM STATUS------
 Device Number = 0
DEVICE INFO BLOCK: bootflash
 Magic Number
                    = 6887635 File System Vers = 10000
                                                        (1.0)
                    = 1000000 Sector Size = 40000
 Length
                               Erased State
 Programming Algorithm = 39
                                               = FFFFFFFF
 File System Offset = 40000 Length = F40000
                               Length = C628
 MONLIB Offset
                     = 100
 Bad Sector Map Offset = 3FFF8
                                Length = 8
 Squeeze Log Offset = F80000
                                Length = 40000
 Squeeze Buffer Offset = FC0000 Length = 40000
 Num Spare Sectors
                    = 0
   Spares:
STATUS INFO:
 Writable
 NO File Open for Write
 Complete Stats
 No Unrecovered Errors
 No Squeeze in progress
USAGE INFO:
              = 917CE8 Bytes Available = 628318
 Bytes Used
 Bad Sectors = 0 Spared Sectors = 0
          = 2
                       Bytes = 917BE8
 OK Files
 Deleted Files = 0 Bytes = 0
Files w/Errors = 0 Bytes = 0
Switch>
```

show slaveslot0:

To display information about the file system on the standby supervisor engine, use the **show slaveslot0:** command.

show slot0: [all | chips | filesys]

Syntax Description	all	 (Optional) Displays all Flash information including the output from the show slot0: chips and show slot0: filesys commands. (Optional) Displays Flash chip register information. 					
	chips						
	filesys	(Optional) Displays file system status information.					
Defaults	This command has no default settings.						
Command Modes	EXEC						
Command History	Release	Modification					
	12.1(8a)EW	<i>W</i> Support for this command was introduced on the Catalyst 4500 series switch.					
Examples	Switch# show a -# - EDtype 1 image	<pre>hows how to display a summary of the file system: slaveslot0: ecrcseek nlen -lengthdate/time name 6375DBB7 A4F144 6 10678468 Nov 09 1999 10:50:42 halley available (10678596 bytes used)</pre>					
	This example shows how to display Flash chip information:						
	******** Inte ATTRIBUTE MEM Config Optic Config Statu Card Status Write Protec Voltage Cnt	<pre>slaveslot0: chips 1 Series 2+ Status/Register Dump ******* ORY REGISTERS: on Reg (4000): 2 us Reg (4002): 0 Reg (4100): 1 ct Reg (4100): 1 ct Reg (4104): 4 rl Reg (410C): 0 de Reg (4140): 2</pre>					
	Intelligent Compatible :	0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0					

```
COMMON MEMORY REGISTERS: Bank 1
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global
        Status Reg: B0B0
 Block Status Regs:
  8 : B0B0 B0B0 B0B0 B0B0
                         B0B0 B0B0 B0B0
                                      B0B0
   16 : B0B0 B0B0 B0B0 B0B0
                         B0B0 B0B0 B0B0
                                      B0B0
   COMMON MEMORY REGISTERS: Bank 2
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global
        Status Reg: B0B0
 Block Status Regs:
   8 : B0B0 B0B0 B0B0 B0B0
                         B0B0
                             B0B0 B0B0
                                      в0в0
           B0B0 B0B0
                    B0B0
   16 :
      B0B0
                         B0B0
                             B0B0
                                 B0B0
                                      B0B0
   24 : B0B0 B0B0 B0B0 B0B0
                         B0B0 B0B0 B0B0 B0B0
COMMON MEMORY REGISTERS: Bank 3
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global Status Reg: B0B0
 Block Status Regs:
   8 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
                                      B0B0
   16 : B0B0 B0B0 B0B0 B0B0
                         B0B0
                             BOBO
                                 B0B0
                                      B0B0
   COMMON MEMORY REGISTERS: Bank 4
 Intelligent ID Code : FFFFFFF
   IID Not Intel -- assuming bank not populated
This example shows how to display file system information:
```

```
Switch# show slaveslot0: filesys
----- FILE SYSTEM STATUS ------
 Device Number = 0
DEVICE INFO BLOCK: slot0
 Magic Number = 6887635 File System Vers = 10000
                                                         (1.0)
                     = 1000000 Sector Size = 20000
 Length
 Programming Algorithm = 4
                               Erased State
                                               = FFFFFFFF
 File System Offset = 20000 Length = FA0000
                              Length = F568
 MONLIB Offset = 100
 Bad Sector Map Offset = 1FFF0
                              Length = 10
 Squeeze Log Offset = FC0000
                              Length = 20000
 Squeeze Buffer Offset = FE0000
                              Length = 20000
 Num Spare Sectors = 0
   Spares:
STATUS INFO:
 Writable
 NO File Open for Write
 Complete Stats
 No Unrecovered Errors
 No Squeeze in progress
USAGE INFO:
              = 9F365C Bytes Available = 5AC9A4
 Bytes Used
             = 0
 Bad Sectors
                        Spared Sectors = 0
              = 1
                        Bytes = 9F35DC
 OK Files
 Deleted Files = 0
                       Bytes = 0
 Files w/Errors = 0
                       Bytes =
Switch>
```

show slot0:

To display information about the slot0: file system, use the **show slot0:** command.

show slot0: [all | chips | filesys]

Syntax Description	all (Optional) Displays all Flash information including the output from the s chips and show slot0: filesys commands.							
	chips	(Optional) Displays Flash chip register information.						
	filesys	(Optional) Displays file system status information.						
Defaults	This command	has no default settings.						
Command Modes	EXEC							
Command History	Release	Modification						
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.						
	5705404 bytes Switch>	available (10678596 bytes used)						
	This example s	hows how to display Flash chip information:						
	Switch# show ******* Inte ATTRIBUTE MEM Config Opti Config Stat Card Status Write Prote Voltage Cnt	<pre>slot0: chips l Series 2+ Status/Register Dump ******* ORY REGISTERS: on Reg (4000): 2 us Reg (4002): 0</pre>						
	Intelligent Compatible	0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0						

```
COMMON MEMORY REGISTERS: Bank 1
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global
      Status Reg: B0B0
 Block Status Regs:
  16 : B0B0 B0B0 B0B0 B0B0
                       B0B0 B0B0 B0B0 B0B0
  COMMON MEMORY REGISTERS: Bank 2
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global
       Status Reg: B0B0
 Block Status Regs:
  16 : B0B0 B0B0 B0B0 B0B0
                       B0B0 B0B0 B0B0
                                   B0B0
  24 : B0B0 B0B0 B0B0
                   B0B0
                       B0B0 B0B0 B0B0
                                   B0B0
COMMON MEMORY REGISTERS: Bank 3
 Intelligent ID Code : 8989A0A0
 Compatible Status Reg: 8080
 Global
       Status Reg: B0B0
 Block Status Regs:
  8 : B0B0 B0B0 B0B0 B0B0
                       B0B0 B0B0 B0B0
                                   B0B0
  16 : B0B0 B0B0 B0B0 B0B0 B0B0 B0B0 B0B0
                                   B0B0
  24 : B0B0 B0B0 B0B0 B0B0
                       B0B0 B0B0 B0B0 B0B0
COMMON MEMORY REGISTERS: Bank 4
 Intelligent ID Code : FFFFFFF
  IID Not Intel -- assuming bank not populated
Switch>
```

This example shows how to display file system information:

```
Switch# show slot0: filesys
----- FILE SYSTEM STATUS ------
 Device Number = 0
DEVICE INFO BLOCK: slot0
 Magic Number = 6887635 File System Vers = 10000
                                                         (1.0)
                     = 1000000 Sector Size = 20000
 Length
 Programming Algorithm = 4
                               Erased State
                                               = FFFFFFFF
 File System Offset = 20000 Length = FA0000
 MONLIB Offset = 100
                              Length = F568
 Bad Sector Map Offset = 1FFF0
                              Length = 10
 Squeeze Log Offset = FC0000
                              Length = 20000
 Squeeze Buffer Offset = FE0000
                               Length = 20000
 Num Spare Sectors = 0
   Spares:
STATUS INFO:
 Writable
 NO File Open for Write
 Complete Stats
 No Unrecovered Errors
 No Squeeze in progress
USAGE INFO:
              = 9F365C Bytes Available = 5AC9A4
 Bytes Used
             = 0
 Bad Sectors
                        Spared Sectors = 0
              = 1
                        Bytes = 9F35DC
 OK Files
 Deleted Files = 0
                        Bytes = 0
 Files w/Errors = 0
                        Bvtes = 0
Switch>
```

show spanning-tree

To display spanning-tree state information, use the show spanning-tree command.

show spanning-tree [bridge_group | active | backbonefast | bridge [id] | inconsistentports |
interface type | root | summary [total] | uplinkfast | vlan vlan_id | pathcost method | detail]

Syntax Description	bridge_group active	(Optional) Specifies the bridge group number; valid values are from 1 to 255. (Optional) Displays the spanning-tree information on active interfaces only.					
	backbonefast	(Optional) Displays the spanning-tree BackboneFast status.					
	bridge	(Optional) Displays the bridge status and configuration information.					
	id	(Optional) Name of the bridge.					
	inconsistentports	(Optional) Displays the root inconsistency state.					
	interface type	(Optional) Specifies the interface type and number; valid values are fastethernet , gigabitethernet , tengigabitethernet , port-channel (1 to 64), and vlan (1 to 4094).					
	root	(Optional) Displays the root bridge status and configuration.					
	summary	(Optional) Specifies a summary of port states.					
	total	(Optional) Displays the total lines of the spanning-tree state section.					
	uplinkfast	(Optional) Displays the spanning-tree UplinkFast status.					
	vlan vlan_id	(Optional) Specifies the VLAN ID; valid values are from 1 to 4094.					
	pathcost method	(Optional) Displays the default path cost calculation method used.					
	detail	(Optional) Displays a summary of interface information.					
Command Modes	Privileged EXEC						
Command History	Release	dification					
		Support for this command was introduced on the Catalyst 4500 series switch.					
		Support for extended addressing was added.					
	12.2(25)EW	Added support for the 10-Gigabit Ethernet interface.					
	12.2(23)EW	Added support for the fo-organit Ethernet interface.					
	12.2(25)EW	Added support for the 10-Orgaon Ethernet interface.					
Examples		s how to display spanning-tree information on the active interfaces only:					
Examples		s how to display spanning-tree information on the active interfaces only:					

```
Current root has priority 16384, address 0060.704c.7000
Root port is 265 (FastEthernet5/9), cost of root path is 38
Topology change flag not set, detected flag not set
Number of topology changes 0 last change occurred 18:13:54 ago
Times: hold 1, topology change 24, notification 2
hello 2, max age 14, forward delay 10
Timers: hello 0, topology change 0, notification 0
Port 265 (FastEthernet5/9) of VLAN1 is forwarding
Port path cost 19, Port priority 128, Port Identifier 129.9.
Designated root has priority 16384, address 0060.704c.7000
Designated bridge has priority 32768, address 00e0.4fac.b000
Designated port id is 128.2, designated path cost 19
Timers: message age 3, forward delay 0, hold 0
Number of transitions to forwarding state: 1
BPDU: sent 3, received 32852
```

```
Switch#
```

This example shows how to display the spanning-tree BackboneFast status:

This example shows how to display spanning-tree information for the bridge:

```
Switch# show spanning-tree bridge
VLAN1
 Bridge ID Priority
                       32768
                      0050.3e8d.6401
            Address
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
VLAN2
 Bridge ID Priority 32768
            Address
                      0050.3e8d.6402
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
VLAN3
 Bridge ID Priority
                       32768
                       0050.3e8d.6403
            Address
            Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
Switch#
```

This example shows how to display a summary of interface information:

```
Switch# show spanning-tree
```

```
VLAN1

Spanning tree enabled protocol ieee

Root ID Priority 32768

Address 0030.94fc.0a00

This bridge is the root

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Bridge ID Priority 32768

Address 0030.94fc.0a00

Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec

Aging Time 300
```

Catalyst 4500 Series Switch Cisco IOS Command Reference—Release 12.2(31)SG
Interface						Desi	gnated	
Name		Port ID					Bridge ID	
							32768 0030.94fc.0a00	
VLAN2								
Spanning t	ree enable	ed protoc	ol iee	e				
Root ID	Priority	32768						
	Address	0030.	94fc.0	a01				
	This brid	lge is th	e root					
	Hello Tin	ne 2 se	c Max	Age 2	20 sec	For	ward Delay 15 sec	
Bridge ID	Priority	32768						
	Address	0030.	94fc.0	a01				
	Hello Tin	ne 2 se	c Max	Age 2	20 sec	For	ward Delay 15 sec	
	Aging Tim	ne 300						
Interface						Desi	gnated	
Name			Prio	Cost	Sts		Bridge ID	Port ID
			128	19	FWD		32768 0030.94fc.0a01	129.80

This example shows how to display spanning-tree information for Fast Ethernet interface 5/9:

```
Switch# show spanning-tree interface fastethernet5/9
Interface Fa0/10 (port 23) in Spanning tree 1 is ROOT-INCONSISTENT
Port path cost 100, Port priority 128
Designated root has priority 8192, address 0090.0c71.a400
Designated bridge has priority 32768, address 00e0.1e9f.8940
Designated port is 23, path cost 115
Timers: message age 0, forward delay 0, hold 0
BPDU: sent 0, received 0
The port is in the portfast mode
Switch#
```

This example shows how to display spanning-tree information for a specific VLAN:

```
Switch# show spanning-tree vlan 1
VLAN1 is executing the ieee compatible Spanning Tree protocol
 Bridge Identifier has priority 32768, address 0030.94fc.0a00
  Configured hello time 2, max age 20, forward delay 15
  We are the root of the spanning tree
  Topology change flag not set, detected flag not set
  Number of topology changes 5 last change occurred 01:50:47 ago
          from FastEthernet6/16
  Times: hold 1, topology change 35, notification 2
         hello 2, max age 20, forward delay 15
  Timers: hello 0, topology change 0, notification 0, aging 300
 Port 335 (FastEthernet6/15) of VLAN1 is forwarding
   Port path cost 19, Port priority 128, Port Identifier 129.79.
   Designated root has priority 32768, address 0030.94fc.0a00
   Designated bridge has priority 32768, address 0030.94fc.0a00
   Designated port id is 129.79, designated path cost 0
   Timers:message age 0, forward delay 0, hold 0
   Number of transitions to forwarding state:1
   BPDU:sent 6127, received 0
Switch#
```

This example shows how to display spanning-tree information for a specific bridge group:

Switch# show spanning-tree vlan 1 UplinkFast is disabled BackboneFast is disabled Switch#

This example shows how to display a summary of port states:

```
Switch# show spanning-tree summary
Root bridge for:VLAN1, VLAN2.
PortFast BPDU Guard is disabled
EtherChannel misconfiguration guard is enabled
UplinkFast is disabled
BackboneFast is disabled
Default pathcost method used is short
```

Name		Blocking	Listenin	g Learning	f Forwarding	g STP Active
VLAN1		0	0	0	1	1
VLAN2		0	0	0	1	1
	2 VLANS 0			 0	· ·	
Switch#	Z VLANS U	0		0 2	i 2	2

This example shows how to display the total lines of the spanning-tree state section:

```
Switch# show spanning-tree summary totals
Root bridge for:VLAN1, VLAN2.
PortFast BPDU Guard is disabled
EtherChannel misconfiguration guard is enabled
UplinkFast is disabled
BackboneFast is disabled
Default pathcost method used is short
Name Blocking Listening Learning Forwarding STP Active
```

2 VLANs	0	0	0	2	2

Switch#

This example shows how to determine whether any ports are in root inconsistent state:

Switch# show spanning-tree inconsistentports

Name	Interface	Inconsistency
VLAN1	FastEthernet3/1	Root Inconsistent

Number of inconsistent ports (segments) in the system:1 Switch#

Related Commands

spanning-tree backbonefast spanning-tree cost spanning-tree guard spanning-tree pathcost method spanning-tree portfast default spanning-tree portfast (interface configuration mode) spanning-tree port-priority spanning-tree uplinkfast spanning-tree vlan

show spanning-tree mst

To display MST protocol information, use the show spanning-tree mst command.

show spanning-tree mst [configuration]

show spanning-tree mst [instance-id] [detail]

show spanning-tree mst [instance-id] interface interface [detail]

configuration	(Optional) Displays region configuration information.						
instance-id	(Optional) Instance identification number; valid values are from 0 to 15.						
detail	(Optional) Displays detailed MST protocol information.						
interface interface	(Optional) Interface type and number; valid values for type are fastethernet , gigabitethernet , tengigabitethernet , port-channel , and vlan . See the "Usage Guidelines" section for more information.						
This command has no	o default settings.						
Privileged EXEC							
Release	Modification						
12.1(12c)EW	Support for this command was introduced on the Catalyst 4500 series switch.						
12.2(25)EW	Added support for the 10-Gigabit Ethernet interface.						
This command is not	supported on systems that are configured with a Supervisor Engine I.						
In the output display of display. This message primary VLAN. The of the other states o	of the show spanning-tree mst configuration command, a warning message might						
In the output display of display. This message primary VLAN. The instance as the associ	of the show spanning-tree mst configuration command, a warning message might e appears if you do not map secondary VLANs to the same instance as the associated display includes a list of the secondary VLANs that are not mapped to the same						
-	instance-id detail interface interface This command has no Privileged EXEC Release 12.1(12c)EW 12.2(25)EW						

Examples This example shows how to display region configuration information:

```
Switch# show spanning-tree mst configuration

Name [leo]

Revision 2702

Instance Vlans mapped

------

0 1-9,11-19,21-29,31-39,41-4094

1 10,20,30,40

-------

Switch#
```

This example shows how to display additional MST protocol values:

```
Switch# show spanning-tree mst 3 detail
# # # # # # MST03 vlans mapped: 3,3000-3999
Bridge address 0002.172c.f400 priority 32771 (32768 sysid 3)
Root this switch for MST03
GigabitEthernet1/1 of MST03 is boundary forwarding
Port info port id 128.1 priority 128
cost 20000
Designated root address 0002.172c.f400 priority 32771
cost 0
Designated bridge address 0002.172c.f400 priority 32771 port
id 128.1
Timers: message expires in 0 sec, forward delay 0, forward transitions 1
Bpdus (MRecords) sent 4, received 0
FastEthernet4/2 of MST03 is backup blocking
Port info port id 128.194 priority 128 cost
200000
Designated root address 0002.172c.f400 priority 32771
cost 0
Designated bridge address 0002.172c.f400 priority 32771 port id
128.193
Timers: message expires in 2 sec, forward delay 0, forward transitions 1
Bpdus (MRecords) sent 3, received 252
Switch#
```

This example shows how to display MST information for a specific interface:

```
Switch# show spanning-tree mst 0 interface fastethernet4/1 detail
Edge port: no (trunk) port guard : none
(default)
Link type: point-to-point (point-to-point) bpdu filter: disable
(default)
Boundary : internal bpdu guard : disable
(default)
FastEthernet4/1 of MST00 is designated forwarding
Vlans mapped to MST00 1-2,4-2999,4000-4094
Port info port id 128.193 priority 128 cost
200000
Designated root address 0050.3e66.d000 priority 8193
cost 20004
Designated ist master address 0002.172c.f400 priority 49152
cost 0
Designated bridge address 0002.172c.f400 priority 49152 port id
128.193
Timers: message expires in 0 sec, forward delay 0, forward transitions 1
Bpdus sent 492, received 3
Switch#
```

Related Commands

spanning-tree mst spanning-tree mst forward-time spanning-tree mst hello-time spanning-tree mst max-hops spanning-tree mst root

show storm-control

To display the broadcast storm control settings on the switch or on the specified interface, use the **show storm-control** command.

show storm-control [interface-id | broadcast]

	<i>interface-id</i> (Optional) Specifies the interface ID for the physical port.									
	broadcast (Optional) Displays the broadcast storm threshold setting.									
Command Modes	Privileged I	EXEC								
Command History	Release	Ν	odification							
	12.1(19)EV	W S	upport for th	his comma	and was	introdu	ced on tl	he Cataly	vst 4500 se	ries switch
	12.2(25)EV	W A	dded suppo	ort for the	10-Giga	ıbit Ethe	ernet int	erface.		
Jsage Guidelines	-	enter an interface ot enter an interf ch.							-	
Examples										
xamples	Because no Switch# sh	xample of outpu traffic type keyv ow storm-contro Filter State	word was en			ast stori			•	
zamples	Because no Switch# sh Interface	traffic type keyv	word was en	ntered, the	Curren	ast stori			•	
Examples	Because no Switch# sh Interface Gi2/1 Gi4/1	traffic type keys w storm-contro Filter State Forwarding Forwarding	vord was en 	Lower 30.00% 30.00%	Curren Curren N, N,	ast stori nt /A /A			•	
Examples	Because no Switch# sh Interface Gi2/1	traffic type keyv w storm-contro Filter State Forwarding	vord was en 51 Upper 30.00%	Lower 30.00%	Curren Curren N, N,	ast stori nt /A			•	
Examples	Because no Switch# sh Interface Gi2/1 Gi4/1 Gi4/3 Switch# This is an e	traffic type keys w storm-contro Filter State Forwarding Forwarding	vord was en Upper 30.00% 30.00% 30.00%	Lower 	curren Curren N, N, N, m-contr	ast storn	m contro	ol setting	s are displ	ayed.
xamples	Because no Switch# sh Interface Gi2/1 Gi4/1 Gi4/3 Switch# This is an e no traffic ty Switch# sh Interface	traffic type keys w storm-contro Filter State Forwarding Forwarding Forwarding xample of output ype keyword was w storm-contro Filter State	vord was en Upper 30.00% 30.00% 30.00% t from the sl entered, the bl fastethe Level	Lower 30.00% 30.00% 30.00% how storr e broadca ernet2/17 Current	e broadc Curren N, N, N, N, St storm	ast storn	m contro	ol setting	s are displ	ayed.
xamples	Because no Switch# sh Interface Gi2/1 Gi4/1 Gi4/3 Switch# This is an e no traffic ty Switch# sh Interface	traffic type keys w storm-contro Filter State Forwarding Forwarding Forwarding xample of output ye keyword was	vord was en Upper 30.00% 30.00% 30.00% t from the sl entered, the bl fastethe Level	Lower 30.00% 30.00% 30.00% how storr e broadca ernet2/17	e broadc Curren N, N, N, N, St storm	ast storn	m contro	ol setting	s are displ	ayed.
Examples	Because no Switch# sh Interface Gi2/1 Gi4/1 Gi4/3 Switch# This is an e no traffic ty Switch# sh Interface Fa2/17 Switch# This is an ex	traffic type keys w storm-contro Filter State Forwarding Forwarding Forwarding xample of output ype keyword was w storm-contro Filter State	vord was en Upper 30.00% 30.00% 30.00% t from the sl entered, the bl fastethe Level 50.00% from the sh	Lower 	e broadc Curren N, N, N, St storm	ast storn ht /A /A ol comm control	m contro nand for settings	e a specifi s are disp a specific	ied interfa blayed.	ayed. ce. Becaus e and traffi
Examples	Because no Switch# sh Interface Gi2/1 Gi4/1 Gi4/3 Switch# This is an e no traffic ty Switch# sh Interface Fa2/17 Switch# This is an ex type, where Switch# sh Interface	traffic type keys w storm-contro Filter State Forwarding Forwarding Forwarding xample of output ye keyword was w storm-contro Filter State Forwarding	vord was en Upper 30.00% 30.00% 30.00% 30.00% t from the sl entered, the bl fastethe Level 50.00% from the sh l threshold bl gigabite	Lower 	curren Curren N, N, N, m-contr st storm r	ast storn ht /A /A ol comm control ol comm hat traff	m contro nand for settings	e a specifi s are disp a specific	ied interfa blayed.	ayed. ce. Becaus e and traffi

Switch#

Table 2-24 describes the fields in the show storm-control display.

Table 2-24 show storm-control Field Descriptions

Field	Description					
Interface	Displays the ID of the interface.					
Filter State	Displays the status of the filter:					
	• Blocking—Storm control is enabled, and a storm has occurred.					
	• Forwarding—Storm control is enabled, and no storms have occurred.					
	• Inactive—Storm control is disabled.					
Level	Displays the threshold level set on the interface for broadcast traffic.					
Current	Displays the bandwidth utilization of broadcast traffic as a percentage of total available bandwidth. This field is valid only when storm control is enabled.					
_	Note N/A is displayed for interfaces that do storm control in the hardware.					

Related Commands

storm-control show interfaces counters show running-config

show system mtu

To display the global MTU setting, use the show system mtu command.

show system mtu

- **Defaults** This command has no default settings.
- **Command Modes** Privileged EXEC

 Release
 Modification

 12.1(12c)EW
 Support for this command was introduced on the Catalyst 4500 series switch.

Examples This example shows how to display the global MTU setting: Switch# show system mtu Global Ethernet MTU is 1550 bytes. Switch#

Related Commands system mtu

show tech-support

To display troubleshooting information for TAC, use the **show tech-support** command.

show tech-support [bridging | cef | ipmulticast | isis | password [page] | page]

Syntax Description	bridging	(Optional) Specifies bridging-related information.						
	cef	(Optional) Specifies CEF-related information.						
	ipmulticast	(Optional) Specifies IP multicast-related information.						
	isis	(Optional) Specifies CLNS and ISIS-related information.						
	password	Optional) Includes passwords and other security information in the output.						
	page	(Optional) Displays one page of information at a time in the output.						
Defaults	The defaults ar	re as follows:						
	• Outputs ar	e displayed without page breaks.						
	Passwords	and other security information are removed from the output.						
Command Modes	Privileged EXI	EC						
Command History	Release	Modification						
Command History	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.						
	12.1(8a)EW Output from th combination C of the current s	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes.						
Command History Usage Guidelines	12.1(8a)EW Output from th combination C of the current s Press the Retu	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output						
	12.1(8a)EW Output from th combination C of the current s Press the Retu of information.	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. rn key to display the next line of output, or press the Space bar to display the next page. If you do not enter the page keyword, the output scrolls. It does not stop for page breaks.						
	12.1(8a)EW Output from th combination C of the current s Press the Retu of information. If you enter the in the output. If you do not er	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. rn key to display the next line of output, or press the Space bar to display the next page If you do not enter the page keyword, the output scrolls. It does not stop for page breaks password keyword, password encryption is enabled, but only the encrypted form appears						
	12.1(8a)EW Output from th combination C of the current s Press the Retu of information. If you enter the in the output. If you do not er output are repla	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. rn key to display the next line of output, or press the Space bar to display the next page . If you do not enter the page keyword, the output scrolls. It does not stop for page breaks. password keyword, password encryption is enabled, but only the encrypted form appears ther the password keyword, the passwords and other security-sensitive information in the aced in the output with the word "removed." -support commands are a compilation of several show commands and the output can be For a sample display of the output of the show tech-support command, see the individual						
	12.1(8a)EW Output from the combination C of the current se Press the Retu of information. If you enter the in the output. If you do not er output are replated The show tech quite lengthy. Fe	Support for this command was introduced on the Catalyst 4500 series switch. The show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. The key to display the next line of output, or press the Space bar to display the next page If you do not enter the page keyword, the output scrolls. It does not stop for page breaks. password keyword, password encryption is enabled, but only the encrypted form appears ther the password keyword, the passwords and other security-sensitive information in the aced in the output with the word "removed." -support commands are a compilation of several show commands and the output can be For a sample display of the output of the show tech-support command, see the individual d listed. e show tech-support command without arguments, the output displays the equivalent of						
	12.1(8a)EW Output from th combination C of the current s Press the Retu of information. If you enter the in the output. If you do not er output are repla The show tech quite lengthy. F show command	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. rn key to display the next line of output, or press the Space bar to display the next page . If you do not enter the page keyword, the output scrolls. It does not stop for page breaks password keyword, password encryption is enabled, but only the encrypted form appears ther the password keyword, the passwords and other security-sensitive information in the aced in the output with the word "removed." -support commands are a compilation of several show commands and the output can be For a sample display of the output of the show tech-support command, see the individual d listed. e show tech-support command without arguments, the output displays the equivalent of mands:						
	12.1(8a)EW Output from the combination C of the current s Press the Retu of information. If you enter the in the output. If you do not er output are repla The show tech quite lengthy. F show command If you enter the these show cor	Support for this command was introduced on the Catalyst 4500 series switch. e show tech-support command may be terminated in midstream with the key trl+Alt+6. The command output is buffered so that the command terminates when output sub-command running under this command completes. rn key to display the next line of output, or press the Space bar to display the next page . If you do not enter the page keyword, the output scrolls. It does not stop for page breaks. password keyword, password encryption is enabled, but only the encrypted form appears ther the password keyword, the passwords and other security-sensitive information in the aced in the output with the word "removed." -support commands are a compilation of several show commands and the output can be For a sample display of the output of the show tech-support command, see the individual d listed. e show tech-support command without arguments, the output displays the equivalent of mands:						

- show interfaces
- show controllers
- show process memory
- show process cpu
- show buffers
- show logging
- show module
- show power
- show environment
- show interfaces switchport
- show interfaces trunk
- show vlan

If you enter the **ipmulticast** keyword, the output displays the equivalent of these **show** commands:

- show ip pim interface
- show ip pim interface count
- show ip pim neighbor
- show ip pim rp
- show ip igmp groups
- show ip igmp interface
- show ip mroute count
- show ip mroute
- show ip mcache
- show ip dvmrp route

Examples For a sample display of the **show tech-support** command output, see the commands listed in the "Usage Guidelines" section for more information.

Related Commands See the "Usage Guidelines" section.

show udld

To display the administrative and operational UDLD status, use the show udld command.

show udld interface-id

Syntax Description	interface-id	Name of the interface.
Defaults	This command	has no default settings.
ommand Modes	Privileged EXE	C
Command History	Release	Modification
-	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.
	12.2(25)EW	Added support for the 10-Gigabit Ethernet interface.
Jsage Guidelines	If you do not en interfaces is dis	nter an interface ID value, the administrative and operational UDLD status for all splayed.
xamples	This example s	hows how to display the UDLD state for Gigabit Ethernet interface 2/2:
	Switch# show Interface Gi2	udld gigabitethernet2/2 /2
	Port enable au Port enable op Current bidir Current opera Message inter Time out inter	
	Device ID Current na Device nau Port ID: 1 Neighbor o Neighbor o Message in	eighbor state: Bidirectional me: 0050e2826000

Related Commandsudld (global configuration mode)udld (interface configuration mode)

show vlan

To display VLAN information, use the **show vlan** command.

show vlan [brief | id vlan_id | name name]

show vlan private-vlan [type]

Syntax Description	brief	(Optional) Displays only a single line for each VLAN, naming the VLAN, status, and ports.								
	id vlan_id(Optional) Displays information about a single VLAN identified by VLAN ID number; valid values are from 1 to 4094.									
	name <i>name</i> (Optional) Displays information about a single VLAN identified by VLAN nativalid values are an ASCII string from 1 to 32 characters.									
	private-vlan Displays private VLAN information.									
	type	(Optional) Private VLAN type.								
Defaults	This command	has no default settings.								
Command Modes	Privileged EXE	C								
Command History	Release	Modification								
Johnnanu History	12.1(8a)EW Support for this command was introduced on the Catalyst 4500 series switch.									
	12.1(8a)EW	Support for this command was introduced on the Catalyst 4500 series switch.								
	12.1(8a)EW 12.1(12c)EW	Support for this command was introduced on the Catalyst 4500 series switch. Added support for extended VLAN addresses.								
Examples	12.1(12c)EW	Added support for extended VLAN addresses.								
Examples	12.1(12c)EW This example sl domain: Switch# show w	Added support for extended VLAN addresses.								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002	Added support for extended VLAN addresses.								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002 3 VLAN003	Added support for extended VLAN addresses. hows how to display the VLAN parameters for all VLANs within the administrative Plan Status Ports active Fa5/9 active Fa5/9 active Fa5/9								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002 3 VLAN003 4 VLAN0004	Added support for extended VLAN addresses. hows how to display the VLAN parameters for all VLANs within the administrative Plan Status Ports active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002 3 VLAN003	Added support for extended VLAN addresses. hows how to display the VLAN parameters for all VLANs within the administrative Plan Status Ports active Fa5/9 active Fa5/9 active Fa5/9								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002 3 VLAN0003 4 VLAN0004 5 VLAN0005	Added support for extended VLAN addresses. hows how to display the VLAN parameters for all VLANs within the administrative Plan Status Ports Active Fa5/9 Activ								
Examples	12.1(12c)EW This example sl domain: Switch# show v VLAN Name 1 default 2 VLAN0002 3 VLAN0003 4 VLAN0004 5 VLAN0005 6 VLAN0006	Added support for extended VLAN addresses. hows how to display the VLAN parameters for all VLANs within the administrative Plan Status Ports active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9 active Fa5/9								

917 999 1002 1003 1004	trcrf- fddine	917			act: act:	ive ive ive ive ive	Fag Fag Fag Fag Fag Fag	5/9 5/9 5/9 5/9 5/9 5/9			
VLAN	Туре	SAID	MTU	Parent	RingNo	Bridge	eNo	Stp	BrdgMode	Trans1	Trans2
1	enet	100001	1500	_	_	-		_	_	0	0
2	enet	100002	1500	-	-	-		_	_	0	0
3	enet	100003	1500	-	-	-		-	-	303	0
4	enet	100004	1500	-	-	-		-	-	304	0
5	enet	100005	1500	-	-	-		-	-	305	0
6	enet	100006	1500	-	-	-		-	-	0	0
10	enet	100010	1500	-	-	-		-	-	0	0
20	enet	100020	1500	-	-	-		-	-	0	0
50	enet	100050	1500	-	-	-		-	-	0	0
<(Dutput	truncated.	>								
850	enet	100850	1500	-	-	_		-	-	0	0
917	enet	100917	1500	-	-	-		-	-	0	0
999	enet	100999	1500	-	-	-		-	-	0	0
1002	fddi	101002	1500	-	0	-		-	-	0	0
1003	trcrf	101003	4472	1005	3276	-		-	srb	0	0
1004	fdnet	101004	1500	-	-	-		ieee	-	0	0
1005	trbrf	101005	4472	-	-	15		ibm	-	0	0
VLAN	AREHor	os STEHops	Backup	CRF							

VLAN AREHops STEHops Backup CRF

----- ----- ------802 0 0 off 1003 7 7 off Switch#

This example shows how to display the VLAN name, status, and associated ports only:

Switch# show vlan brief		
VLAN Name	Status	Ports
	·	
1 default	active	Fa5/9
2 VLAN0002	active	Fa5/9
3 VLAN0003	active	Fa5/9
4 VLAN0004	active	Fa5/9
5 VLAN0005	active	Fa5/9
10 VLAN0010	active	Fa5/9
999 VLAN0999	active	Fa5/9
1002 fddi-default	active	Fa5/9
1003 trcrf-default	active	Fa5/9
1004 fddinet-default	active	Fa5/9
1005 trbrf-default	active	Fa5/9
Switch#		

This example shows how to display the VLAN parameters for VLAN 3 only:

Switch# show vlan id 3

 VLAN Name
 Status
 Ports

 3
 VLAN0003
 active
 Fa5/9

 VLAN Type
 SAID
 MTU
 Parent RingNo
 BridgeNo
 Stp
 BrdgMode
 Trans1
 Trans2

 3
 enet
 100003
 1500
 303
 0

Table 2-25 describes the fields in the show vlan command output.

Field	Description
VLAN	VLAN number.
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.
Туре	Media type of the VLAN.
SAID	Security Association Identifier value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.

Table 2-25 show vlan Command Output Fields

The following example shows how to verify that the primary vlan and secondary vlans are correctly associated with each other and the same association also exists on the PVLAN port:

```
Switch# show vlan private-vlan
```

Primary	Secondary	Туре		Ports	
					-
10	100		community	Fa3/1,	Fa3/2

Now, let's say that you remove the VLAN association, as follows:

You can use the following command to verify PVLAN configuration on the interface:

Switch# s	show interface f	3/2 status			
Port	Name	Status	Vlan	Duplex	Speed Type

Fa3/2	connected	pvlan seco a-full	a-100 10/100BaseTX
Switch# show interface	f3/1 status		
Port Name	Status	Vlan Duplex	Speed Type
Fa3/1	connected	pvlan prom a-full	a-100 10/100BaseTX
Switch#			

Related Commands v

vlan database vlan (VLAN Database mode) vtp (global configuration mode)

show vlan access-map

To display the contents of a VLAN access map, use the show vlan access-map command.

show vlan access-map [map-name]

Syntax Description	map-name	(Optional) Name of the VLAN access map.
Defaults	This command h	as no default settings.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.1(12c)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Examples	This command s	hows how to display the contents of a VLAN access map:
		Lan access-map mordred
	Vlan access-mar	
		ip address 13 : forward capture
	Switch#	
Related Commands	vlan access-map	

show vlan counters

To display the software-cached counter values, use the show vlan counters command.

show vlan [id vlanid] counters

Syntax Description	id vlanid	(Optional) Displays the so	ftware-cached counter values for a specific VLAN.	
Defaults	This command	has no default settings.		
Command Modes	Privileged EXE	C		
Command History	Release	Modification		
	12.1(13)EW	Support for this comma	and was introduced on the Catalyst 4500 series switches	•
Usage Guidelines		show vlan counters com for all VLANs are displaye	mand without specifying the VLAN ID, the software-cac	ched
Examples	Switch# show		oftware-cached counter values for a specific VLAN:	
		Sunters include broadcas	-	
	Vlan Id L2 Unicast Pac L2 Unicast Oct		: 1 : 0 : 0	
	L3 Input Unica L3 Input Unica	ast Octets	: 0 : 0	
	L3 Output Unio L3 Output Unio L3 Output Mult	cast Octets	: 0 : 0 : 0	
	L3 Output Mult L3 Input Mult:	ticast Octets icast Packets	: 0 : 0	
	L3 Input Mult: L2 Multicast 1 L2 Multicast (Packets	: 0 : 1 : 94	
	Switch>			

Related Commands clear vlan counters

show vlan dot1q tag native

To display all the ports on the switch that are eligible for native VLAN tagging as well as their current native VLAN tagging status, use the **show vlan dot1q tag native** command.

show vlan dot1q tag native

Syntax Description This command has no arguments or keywords.

Command Modes User EXEC

Command History	Release	Modification
	12.1(18)EW	This command was introduced on the Catalyst 4500 series switch.

Examples

This is an example of output from the **show vlan dot1q tag native** command:

Switch# **show vlan dotlq tag native** dotlq native vlan tagging is disabled globally

Per Port Native Vlan Tagging State

Port	Operational Mode	Native VLAN Tagging State
f3/2	trunk	enabled
f3/16	PVLAN trunk	disabled
f3/16	trunk	enabled

Related Commands

switchport mode

vlan (global configuration) (refer to Cisco IOS documentation) vlan (VLAN configuration) (refer to Cisco IOS documentation)

show vlan internal usage

Use the show vlan internal usage command to display information about the internal VLAN allocation.

show vlan [id vlan-id] internal usage

Syntax Description	id vlan-id	(Optional) Displays internal VLAN allocation information for the specified VLAN;
		valid values are from 1 to 4094.
Defaults	This command	has no default settings.
Command Modes	Privileged EXE	C
Command History	Release	Modification
	12.1(19)EW	Support for this command was introduced on the Catalyst 4500 series switch.
Examples	_	hows how to display information about the current internal VLAN allocation:
	1025 - 1026 - 1027 - 1028 - 1029 Port-char 1030 GigabitEt 1032 FastEther 1033 FastEther 1129 -	nnel6 Chernet1/2 cnet3/20
	VLAN:	hows how to display information about the internal VLAN allocation for a specific
		rlan id 1030 internal usage
	VLAN Usage	
	1030 GigabitEt	.HELIKEL1/2

vlan internal allocation policy

Related Commands

show vlan mtu

L

To display the minimum and maximum transmission unit (MTU) sizes of each VLAN, use the **show vlan mtu** command.

show vlan mtu

Syntax Description This command has no arguments or keywords Defaults This command has no default settings. **Command Modes** EXEC **Command History** Modification Release 12.1(13)EW Support for this command was introduced on the Catalyst 4500 series switch. **Usage Guidelines** The MTU Mismatch column in the command output indicates whether all the ports in the VLAN have the same MTU. When "yes" is displayed in the MTU_Mismatch column, it means that the VLAN has a port with different MTUs, and packets might be dropped that are switched from a port with a larger MTU to a port with a smaller MTU. If the VLAN does not have an SVI, the hyphen (-) symbol is displayed in the SVI MTU column. For a VLAN, if the MTU-Mismatch column displays yes, the names of the port with the MinMTU and the port with the MaxMTU are displayed. For a VLAN, if the SVI_MTU is bigger than the MinMTU, "TooBig" is displayed after the SVI_MTU. **Examples** This is an example of output from the show vlan mtu command: Switch# show vlan mtu SVI_MTU MinMTU(port) VLAN MaxMTU(port) MTU_Mismatch _____ _____ _____ 1 1500 1500 1500 No Switch> **Related Commands** mtu

show vlan private-vlan

To display private VLAN information, use the show vlan private-vlan command.

show vlan private-vlan [type]

regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. Examples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Primary Secondary Type Ports 2 301 community 2 302 community 10 community 100 101	Syntax Description	type		Optional) Displays the private VLAN type; valid types are isolated, primary community, nonoperational, and normal.	,
Command History Release Modification 12.1(8a)EW Support for this command was introduced on the Catalyst 4500 series switch. 12.2(20)EW Support for community VLAN was added. Jsage Guidelines When the show vlan private-vlan type command displays a VLAN type as normal, it indicates that regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. Examples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Primary Secondary Type Ports 2 301 community 2 301 community 10 101 isolated	Defaults	This con	nmand has i	no default settings.	
12.1(8a)EW Support for this command was introduced on the Catalyst 4500 series switch. 12.2(20)EW Support for community VLAN was added. Isage Guidelines When the show vlan private-vlan type command displays a VLAN type as normal, it indicates tha regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. xamples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Ports Primary Secondary Type Ports 2 301 community Fa5/3, Fa5/25 2 302 community Interval 100 101 isolated Interval	command Modes	Privilege	ed EXEC		
12.2(20)EW Support for community VLAN was added. Isage Guidelines When the show vlan private-vlan type command displays a VLAN type as normal, it indicates tha regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. Examples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Primary Secondary Type Ports 2 301 community 2 302 community 10 community Fa5/3, Fa5/25 2 302 community 100 101 isolated	Command History	Release	N	Modification	
12.2(20)EW Support for community VLAN was added. Isage Guidelines When the show vlan private-vlan type command displays a VLAN type as normal, it indicates tha regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. Examples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Primary Secondary Type Ports 2 301 community 2 302 community 10 community Fa5/3, Fa5/25 2 302 community 100 101 isolated		12.1(8a)	EW S	Support for this command was introduced on the Catalyst 4500 series swi	ch.
Jsage Guidelines When the show vlan private-vlan type command displays a VLAN type as normal, it indicates tha regular VLAN has been used in the private VLAN configuration. When normal is displayed, this indicates that two VLANs have been associated before the type was set, and the private VLAN is no operational. This information is useful for debugging purposes. Examples This example shows how to display information about all currently configured private VLANs: Switch# show vlan private-vlan Primary Secondary Type Ports 2 301 community 10 community 100 101				Support for community VLAN was added	
Switch# show vlan private-vlan Primary Secondary Type Primary Secondary Type 2 301 community 2 302 community 10 community 100 101	lsage Guidelines	regular V indicates	/LAN has b s that two V	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA	this
2 301 community Fa5/3, Fa5/25 2 302 community 10 community 100 101 isolated	-	regular V indicates operation	/LAN has t s that two V nal. This in:	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes.	this N is not
2 302 community 10 community 100 101 isolated		regular V indicates operation This exa	VLAN has b s that two V nal. This in: mple shows	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes.	this N is not
2 302 community 10 community 100 101 isolated	-	regular V indicates operation This exa Switch#	VLAN has b s that two V nal. This in: mple shows show vlan	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes. ws how to display information about all currently configured private VLAN n private-vlan	this N is not
100 101 isolated	-	regular V indicates operation This exa Switch# Primary	VLAN has b that two V nal. This in: mple shows show vlan Secondary	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes. vs how to display information about all currently configured private VLAN n private-vlan y Type Ports	this N is not
	-	regular V indicates operation This exa Switch# Primary 2	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes. As how to display information about all currently configured private VLAN in private-vlan y Type Ports community Fa5/3, Fa5/25	this N is not
	-	regular V indicates operation This exa Switch# Primary 2 2	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes. vs how to display information about all currently configured private VLAN n private-vlan y Type Ports 	this N is not
-	-	regular V indicates operation This exa Switch# Primary 2 2 100	VLAN has be that two V nal. This in: mple shows show vlan Secondary 301 302 10 101	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes. ws how to display information about all currently configured private VLAN in private-vlan y Type Ports 	this N is not
	-	regular V indicates operation This exa Switch# Primary 2 2	VLAN has be that two V nal. This in: mple shows show vlan Secondary 301 302 10 101 151	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA nformation is useful for debugging purposes. vs how to display information about all currently configured private VLAN n private-vlan y Type Ports 	this N is not
-	-	regular V indicates operation This exa Switch# Primary 2 2 100	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes.	this N is not
303 community 401 402 non-operational	-	regular V indicates operation This exa Switch# Primary 2 2 100 150	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes.	this N is not
303 community	Usage Guidelines Examples	regular V indicates operation This exa Switch# Primary 2 2 100 150	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes.	this N is not
303 community	-	regular V indicates operation This exa Switch# Primary 2 2 100 150 401	VLAN has be that two V nal. This in: mple shows show vlan Secondary 	been used in the private VLAN configuration. When normal is displayed, VLANs have been associated before the type was set, and the private VLA information is useful for debugging purposes.	this N is not

This example shows how to display information about all currently configured private VLAN types:

Switch# show vlan private-vlan type

Vlan Type 202 primary 303 community 304 community 305 community 306 community 307 community 308 normal 309 community 440 isolated Switch#

Table 2-26 describes the fields in the show vlan private-vlan command output.

Field	Description
Primary	Number of the primary VLAN.
Secondary	Number of the secondary VLAN.
Secondary-Type	Secondary VLAN type is isolated or community.
Ports	Indicates the ports within a VLAN.
Туре	Type of VLAN; possible values are primary, isolated , community, nonoperational, or normal .

Table 2-26show vlan private-vlan Command Output Fields

Related Commands

private-vlan private-vlan mapping

show vlan remote-span

To display a list of Remote SPAN (RSPAN) VLANs, use the show vlan remote-span command.

show vlan remote-span

Syntax Description This command has no arguments or keywords.

Defaults This command has no default settings.

Command Modes Privileged EXEC

Command HistoryReleaseModification12.1(12)EWThis command was introduced on the Catalyst 4500 series switches.

 Examples
 This example shows how to display a list of RSPAN VLANs:

 Router# show vlan remote-span

Related Commands	remote-span	
	vlan (VLAN Database mode)	

show vmps

To display the VLAN Query Protocol (VQP) version, reconfirmation interval, retry count, VLAN Membership Policy Server (VMPS) IP addresses, current servers, and primary servers, use the **show vmps** command.

show vmps [statistics]

Syntax Description	statistics (Optional) Display	s the client-side statistics.			
Defaults	This command has no default settings.				
Command Modes	EXEC				
Command History	Release Modification				
	12.1(13)EW Support for this con	nmand was introduced on the Catalyst 4500 series switch.			
Examples	This is an example of output from th	e show vmps command:			
	Switch# show vmps VQP Client Status:				
	VMPS VQP Version: 1 Reconfirm Interval: 60 min				
	Reconfirm Interval: 60 min Server Retry Count: 3 VMPS domain server: 172.20.50.120 (primary, current) Reconfirmation status				
	VMPS Action: No Dynamic Port				
	Switch#				
	This is an example of output from th	e show vmps statistics command:			
	Switch# show vmps statistics	-			
	VMPS Client Statistics				
	VQP Queries: 0 VQP Responses: 0				
	VMPS Changes: 0				
	VQP Shutdowns: 0				
	VQP Denied: 0				
	VQP Wrong Domain: 0				
	VQP Wrong Version: 0				
	VQP Insufficient Resource: 0 Switch#				

Related Commands vmps reconfirm (privileged EXEC)

show vtp

To display VTP statistics and domain information, use the show vtp command.

show vtp {counters | status}

Syntax Description	counters	counters Specifies the VTP statistics.				
- •	status	Specifies the VTP domain status.				
Defaults	This command has no default settings.					
Command Modes	Privileged E2	XEC				
Command History	Release Modification					
	12.1(8a)EWSupport for this command was introduced on the Catalyst 4500 series switch.					
Examples	This example	e shows how to displa	the VTP statistics:			
	VTP statist Summary adv Subset adve Request adve Subset adve Request adve Number of c Number of C	Switch# show vtp counters VTP statistics: Summary advertisements received : 1 Subset advertisements received : 0 Summary advertisements transmitted : 31 Subset advertisements transmitted : 1 Request advertisements transmitted : 0 Number of config revision errors : 0 Number of config digest errors : 0 Number of V1 summary errors : 0 VTP pruning statistics:				
	Trunk	Join Transmit	ted Join Received	Summary advts received from non-pruning-capable device		
	Fa5/9 Switch#	1555	1564	0		
	This example shows how to display the VTP domain status:					
	Switch# sho VTP Version	w vtp status	: 2			
	Configurati		: 250			
		Ns supported locall xisting VLANs	Ly : 1005 : 33			
	VTP Operati		: Server			
	VTP Domain 1	-	: Lab_Network			
	VTP Pruning		: Enabled			
	VTP V2 Mode		: Enabled			
	VTP Traps G		: Disabled			

```
MD5 digest : 0xE6 0xF8 0x3E 0xDD 0xA4 0xF5 0xC2 0x0E
Configuration last modified by 172.20.52.18 at 9-22-99 11:18:20
Local updater ID is 172.20.52.18 on interface V11 (lowest numbered VLAN interfac
e found)
Switch#
```

This example shows how to display only those lines in the **show vtp** output that contain the word Summary:

```
Switch# show vtp counters | include Summary
Summary advertisements received : 1
Summary advertisements transmitted : 32
Trunk Join Transmitted Join Received Summary advts received from
Switch#
```

Table 2-27 describes the fields in the show vtp command output.

Field	Description		
Summary advertisements received	Total number of summary advertisements received.		
Subset advertisements received	Total number of subset advertisements received.		
Request advertisements received	Total number of request advertisements received.		
Summary advertisements transmitted	Total number of summary advertisements transmitted.		
Subset advertisements transmitted	Total number of subset advertisements transmitted.		
Request advertisements transmitted	Total number of request advertisements transmitted.		
Number of config revision errors	Number of config revision errors.		
Number of config digest errors	Number of config revision digest errors.		
Number of V1 summary errors	Number of V1 summary errors.		
Trunk	Trunk port participating in VTP pruning.		
Join Transmitted	Number of VTP-Pruning Joins transmitted.		
Join Received	Number of VTP-Pruning Joins received.		
Summary advts received from	Number of Summary advertisements received from		
non-pruning-capable device	nonpruning-capable devices.		
Number of existing VLANs	Total number of VLANs in the domain.		
Configuration Revision	VTP revision number used to exchange VLAN information.		
Maximum VLANs supported locally	Maximum number of VLANs allowed on the device.		
Number of existing VLANs	Number of existing VLANs.		
VTP Operating Mode	Indicates whether VTP is enabled or disabled.		
VTP Domain Name	Name of the VTP domain.		
VTP Pruning Mode	Indicates whether VTP pruning is enabled or disabled.		
VTP V2 Mode	Indicates the VTP V2 mode as server, client, or transparent.		
VTP Traps Generation	Indicates whether VTP trap generation mode is enabled or disabled.		
MD5 digest	Checksum values.		

Table 2-27show vtp Command Output Fields

Related Commands vtp (global configuration mode) vtp client vtp domain vtp password vtp pruning vtp server vtp transparent

vtp v2-mode