

Command-Line Interface

This chapter provides information for understanding and using the Cisco IOS command-line interface (CLI) on the Catalyst 4500 series switch. This chapter includes the following sections:

- [Getting Help, page 1-1](#)
 - [How to Find Command Options, page 1-2](#)
 - [Understanding Command Modes, page 1-5](#)
 - [Using the No and Default Forms of Commands, page 1-6](#)
 - [Using the CLI String Search, page 1-6](#)
 - [Saving Configuration Changes, page 1-11](#)

For an overview of the Catalyst 4500 series switch Cisco IOS configuration, refer to the *Catalyst 4500 Series Switch Cisco IOS Software Configuration Guide*

Getting Help

To display a list of commands that you can use within a command mode, enter a question mark (?) system prompt. You also can display keywords and arguments for each command with this context-sensitive help feature.

Table 1-1 lists commands you can enter to get help that is specific to a command mode, a command, a keyword, or an argument.

Table 1-1 **Getting Help**

Command	Purpose
<i>abbreviated-command-entry</i>	
<i>abbreviated-command-entry</i> <Tab>	Completes a partial command name.
?	Lists all commands for the command mode.
?	Lists all keywords for the command. Leave a space between the command and the question mark.
<i>keyword</i>	

How to Find Command Options

arap ?	arap
?	
interface gigabitethernet 1/1	
channel-group 1 mode auto	

Table 1-2 How to Find Command Options

Switch> enable Password: <password> Switch#	Enter the command and password to access privileged EXEC commands. You are in privileged EXEC mode when the prompt changes to .
configure terminal Enter configuration commands, one per line. End with CNTL/Z. Switch(config)#	Switch(config)#.
Switch(config)# interface gigabitethernet ? <1-9> GigabitEthernet interface number Switch(config)# interface gigabitethernet 1/1	interface number from 1 to 9 in the format /port-number. You are in interface configuration mode when the prompt changes to

How to Find Command Options (continued)

Interface configuration commands: <table border="0"> <tr><td>access-expression</td><td>Build a bridge boolean access expression</td></tr> <tr><td>apollo</td><td>Apollo interface subcommands</td></tr> <tr><td>appletalk</td><td>Appletalk interface subcommands</td></tr> <tr><td>arp</td><td>Set arp type (arpa, probe, snap) or timeout</td></tr> <tr><td>backup</td><td>Modify backup parameters</td></tr> <tr><td>bandwidth</td><td>Set bandwidth informational parameter</td></tr> <tr><td>bgp-policy</td><td>Apply policy propagated by bgp community string</td></tr> <tr><td>bridge-group</td><td>Transparent bridging interface parameters</td></tr> <tr><td>carrier-delay</td><td>Specify delay for interface transitions</td></tr> <tr><td>cdp</td><td>CDP interface subcommands</td></tr> <tr><td>channel-group</td><td>Etherchannel/port bundling configuration</td></tr> <tr><td>clns</td><td>CLNS interface subcommands</td></tr> <tr><td>cmns</td><td>OSI CMNS</td></tr> <tr><td>custom-queue-list</td><td>Assign a custom queue list to an interface</td></tr> <tr><td>decnet</td><td>Interface DECnet config commands</td></tr> <tr><td>default</td><td>Set a command to its defaults</td></tr> <tr><td>delay</td><td>Specify interface throughput delay</td></tr> <tr><td>description</td><td>Interface specific description</td></tr> <tr><td>dls</td><td>DLSw interface subcommands</td></tr> <tr><td>dspu</td><td>Down Stream PU</td></tr> <tr><td>exit</td><td>Exit from interface configuration mode</td></tr> <tr><td>fair-queue</td><td>Enable Fair Queuing on an Interface</td></tr> <tr><td>flowcontrol</td><td>Configure flow operation.</td></tr> <tr><td>fras</td><td>DLC Switch Interface Command</td></tr> <tr><td>help</td><td>Description of the interactive help system</td></tr> <tr><td>hold-queue</td><td>Set hold queue depth</td></tr> <tr><td>ip</td><td>Interface Internet Protocol config commands</td></tr> <tr><td>ipx</td><td>Novell/IPX interface subcommands</td></tr> <tr><td>isis</td><td>IS-IS commands</td></tr> <tr><td>iso-igrp</td><td>ISO-IGRP interface subcommands</td></tr> <tr><td>.</td><td></td></tr> <tr><td>.</td><td></td></tr> <tr><td>.</td><td></td></tr> </table> Switch(config-if)#	access-expression	Build a bridge boolean access expression	apollo	Apollo interface subcommands	appletalk	Appletalk interface subcommands	arp	Set arp type (arpa, probe, snap) or timeout	backup	Modify backup parameters	bandwidth	Set bandwidth informational parameter	bgp-policy	Apply policy propagated by bgp community string	bridge-group	Transparent bridging interface parameters	carrier-delay	Specify delay for interface transitions	cdp	CDP interface subcommands	channel-group	Etherchannel/port bundling configuration	clns	CLNS interface subcommands	cmns	OSI CMNS	custom-queue-list	Assign a custom queue list to an interface	decnet	Interface DECnet config commands	default	Set a command to its defaults	delay	Specify interface throughput delay	description	Interface specific description	dls	DLSw interface subcommands	dspu	Down Stream PU	exit	Exit from interface configuration mode	fair-queue	Enable Fair Queuing on an Interface	flowcontrol	Configure flow operation.	fras	DLC Switch Interface Command	help	Description of the interactive help system	hold-queue	Set hold queue depth	ip	Interface Internet Protocol config commands	ipx	Novell/IPX interface subcommands	isis	IS-IS commands	iso-igrp	ISO-IGRP interface subcommands	.		.		.		
access-expression	Build a bridge boolean access expression																																																																		
apollo	Apollo interface subcommands																																																																		
appletalk	Appletalk interface subcommands																																																																		
arp	Set arp type (arpa, probe, snap) or timeout																																																																		
backup	Modify backup parameters																																																																		
bandwidth	Set bandwidth informational parameter																																																																		
bgp-policy	Apply policy propagated by bgp community string																																																																		
bridge-group	Transparent bridging interface parameters																																																																		
carrier-delay	Specify delay for interface transitions																																																																		
cdp	CDP interface subcommands																																																																		
channel-group	Etherchannel/port bundling configuration																																																																		
clns	CLNS interface subcommands																																																																		
cmns	OSI CMNS																																																																		
custom-queue-list	Assign a custom queue list to an interface																																																																		
decnet	Interface DECnet config commands																																																																		
default	Set a command to its defaults																																																																		
delay	Specify interface throughput delay																																																																		
description	Interface specific description																																																																		
dls	DLSw interface subcommands																																																																		
dspu	Down Stream PU																																																																		
exit	Exit from interface configuration mode																																																																		
fair-queue	Enable Fair Queuing on an Interface																																																																		
flowcontrol	Configure flow operation.																																																																		
fras	DLC Switch Interface Command																																																																		
help	Description of the interactive help system																																																																		
hold-queue	Set hold queue depth																																																																		
ip	Interface Internet Protocol config commands																																																																		
ipx	Novell/IPX interface subcommands																																																																		
isis	IS-IS commands																																																																		
iso-igrp	ISO-IGRP interface subcommands																																																																		
.																																																																			
.																																																																			
.																																																																			
Switch(config-if)# channel-group ?	Because a is not displayed, it indicates that you must enter more information to complete the command.																																																																		

<pre> <1-256> Channel group number Switch(config-if)#channel-group </pre>	After you enter the <code>channel-group</code> keyword, enter a <code><1-256></code> to display what you must enter next on the command line. In this example, you must enter a channel group number from 1 to 256. Because a <code><cr></code> is not displayed, it indicates that you must enter more information to complete the command.
<pre> Switch(config-if)# mode Etherchannel Mode of the interface Switch(config-if)# </pre>	After you enter the channel group number, enter a <code>mode</code> to display what you must enter next on the command line. In this example, you must enter the <code>mode</code> keyword. Because a <code><cr></code> is not displayed, it indicates that you must enter more information to complete the command.
<pre> Switch(config-if)# channel-group 1 mode ? </pre>	desirable on
	auto ? auto indicates that you can press Return to complete the command. If additional keywords are listed, you can enter more keywords or press Return to complete the command.
	In this example, press Return to complete the command.

Understanding Command Modes

When you start a session on the Catalyst 4500 series switch, you begin in user mode, often called EXEC mode. Only a limited subset of the commands are available in EXEC mode. In order to have access to all commands, you must enter privileged EXEC mode. Normally, you must enter a password to enter privileged EXEC mode. From privileged EXEC mode, you can enter any EXEC command or enter global configuration mode. Most EXEC commands are one-time commands, such as **show**
clear

Table 1-3 provides a summary of the main command modes.

Table 1-3 Summary of Main Command Modes

Command Mode	Access Method	Prompt	Exit Method
Privileged EXEC mode	From user EXEC mode, enter the EXEC command.		To exit to user EXEC mode, enter the command. To enter global configuration mode, enter the privileged EXEC command.
Global configuration mode	From privileged EXEC mode, enter the privileged EXEC command.		To exit to privileged EXEC mode, enter the exit end Ctrl-Z interface
	interface		exit exit Ctrl-Z interface

Subinterface configuration	From interface configuration mode, specify a subinterface with an command.		To exit to global configuration mode, enter the command. To enter privileged EXEC mode, enter the command or press .
ROM monitor	From privileged EXEC mode, enter the EXEC command. Press the Break key during the first 60 seconds while the system is booting.		To exit ROM-monitor mode, you must reload the image by entering the command. If you use the command without specifying a file or any other boot instructions, the system boots from the default Flash image (the first image in onboard Flash memory). Otherwise, you can instruct the system to boot from a specific Flash image (using the boot system flash command).

For more information on command modes, refer to the “Using the Command Line Interface” chapter of the *Configuration Fundamentals Configuration Guide*

Using the No and Default Forms of Commands

Using the CLI String Search

matching requirements. Examples of simple regular expressions are Serial, misses, and 138. Examples of complex regular expressions are 00210..., (is), and [Oo]utput.

-
-
-

**Note**

The CLI string search function does not allow you to search or filter backward through previous output; filtering cannot be specified using HTTP access to the CLI.

Regular Expressions

Single-Character Patterns

command output. You can use any letter (A-Z, a-z) or digit (0-9) as a single-character pattern. You can also use other keyboard characters (such as ! or ~) as single-character patterns, but certain keyboard characters have special meaning when used in regular expressions. [Table 1-4](#) lists the keyboard characters that have special meaning.

Table 1-4 *Characters with Special Meaning*

	Special Meaning
*	Matches 0 or more sequences of the pattern.
+	Matches 1 or more sequences of the pattern.
?	Matches 0 or 1 occurrences of the pattern.
^	Matches the beginning of the string.
\$	Matches the end of the string.
_ (underscore)	Matches a comma (,), left brace ({), right brace (}), left parenthesis ((), right parenthesis ()), the beginning of the string, the end of the string, or a space.

To enter these special characters as single-character patterns, remove the special meaning by preceding each character with a backslash (\). These examples are single-character patterns matching a dollar sign, an underscore, and a plus sign, respectively.

```
\$ \_ \+
```

You can specify a range of single-character patterns to match against command output. For example, you can create a regular expression that matches a string containing one of the following letters: a, e, i, o, or u. One and only one of these characters must exist in the string for pattern matching to succeed. To specify a range of single-character patterns, enclose the single-character patterns in square brackets ([]). For example,

[aeiou]

[abcdABCD]

[a-dA-D]

[a-dA-D\ -]

[a-dA-D\-\]]

[^a-dqsv]

[^\]d]

Multiple-Character Patterns

create multiple-character regular expressions by joining letters, digits, or keyboard characters that do not have special meaning. For example, a4% is a multiple-character regular expression. Put a backslash in front of the keyboard characters that have special meaning when you want to remove their special meaning.

With multiple-character patterns, order is important. The regular expression a4% matches the character a followed by a 4 followed by a % sign. If the string does not have a4%, in that order, pattern matching fails. This multiple-character regular expression:

a.

a\.

Table 1-5 Special Characters Used as Multipliers

	Description

a*

a+

ba?b

**

(ab)*

([A-Za-z][0-9])+

Alternation

alternative patterns with a vertical bar (`|`). Exactly one of the alternatives can match the string. For example, the regular expression

1

matches the string codex or the string telebit, but not both codex and telebit.

Anchoring

Table 1-6 **Special Characters Used for Anchoring**

matches any string that has 1300 somewhere in the string. The string's 1300 can be preceded by or end with a space, brace, comma, or underscore. For example:

{1300_

$$^{1300} \$ ^{1300} (\text{space}) (\text{space}) 1300 \{1300, ,1300, \{1300\} ,1300, (1300$$

1300

Parentheses for Recall

Saving Configuration Changes

```
copy system:running-config nvram:startup-config
```

```
[OK]  
Switch#
```

On most platforms, this step saves the configuration to NVRAM. On the Class A Flash file system platforms, this step saves the configuration to the location specified by the CONFIG_FILE environment variable. The CONFIG_FILE environment variable defaults to NVRAM.

You should use these commands only when you are working directly with your technical support representative, while troubleshooting a problem. Do not use these commands unless your technical support representative asks you to do so.



The _____ commands are not described in this document.

