rmon collection stats

Use the **rmon collection stats** interface configuration command to collect Ethernet group statistics, which include usage statistics about broadcast and multicast packets, and error statistics about cyclic redundancy check (CRC) alignment errors and collisions. Use the **no** form of this command to return to the default setting.

rmon collection stats index [owner name]

no rmon collection stats index [owner name]

Syntax Description

index	Remote Network Monitoring (RMON) collection control index. The range is 1 to 65535.
owner name	(Optional) Owner of the RMON collection.

Defaults

The RMON statistics collection is disabled.

Command Modes

Interface configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The RMON statistics collection command is based on hardware counters. If the port is a user network interface (UNI), you must use the **no shutdown** interface configuration command to enable it before using the **rmon collection stats** command. UNIs are disabled by default. Network node interfaces (NNIs) are enabled by default.

Examples

This example shows how to collect RMON statistics for the owner root:

Switch(config) # interface gigabitethernet0/1
Switch(config-if) # rmon collection stats 2 owner root

You can verify your setting by entering the **show rmon statistics** privileged EXEC command.

Command	Description
show rmon statistics	Displays RMON statistics.
	For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > System Management Commands > RMON Commands.

service password-recovery

Use the **service password-recovery** global configuration command to enable the password-recovery mechanism (the default). This mechanism allows an end user with physical access to the switch to press the break key on the console terminal to interrupt the boot process while the switch is powering up and to assign a new password.

Use the **no** form of this command to disable part of the password-recovery functionality. When the password-recovery mechanism is disabled, interrupting the boot process is allowed only if the user agrees to set the system back to the default configuration.

service password-recovery

no service password-recovery

Syntax Description

This command has no arguments or keywords.

Defaults

The password-recovery mechanism is enabled.

Command Modes

Global configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

As a system administrator, you can use the **no service password-recovery** command to disable some of the functionality of the password recovery feature by allowing an end user to reset a password only by agreeing to return to the default configuration. This provides configuration file security by ensuring that only authenticated and authorized users have access to the configuration file and prevents users from accessing the configuration file by using the password recovery process.

The password recovery procedure requires using a break key. After the switch performs power-on self test (POST), the switch begins the autoboot process. The boot loader prompts the user for a break key character during the boot-up sequence, as shown in this example:

```
***** The system will autoboot in 5 seconds *****
Send a break key to prevent autobooting.
```

You must enter the break key on the console terminal within 5 seconds of receiving the message that the system will autoboot. A user with physical access to the switch presses the break key on the console terminal within 5 seconds of receiving the message that flash memory is initializing. The System LED flashes green until the **break key** is accepted. After the **break key** is accepted, the System LED turns off until after the switch boots.

If the password-recovery mechanism is disabled, this message appears:

The password-recovery mechanism has been triggered, but is currently disabled. Access to the boot loader prompt through the password-recovery mechanism is disallowed at this point. However, if you agree to let the system be reset back to the default system configuration, access to the boot loader prompt can still be allowed.

Would you like to reset the system back to the default configuration (y/n)?

If the user chooses not to reset the system to the default configuration, the normal boot process continues as if the **break key** had not been pressed. If you choose to reset the system to the default configuration, the configuration file in flash memory is deleted, and the VLAN database file, *flash:vlan.dat* (if present), is deleted.



If you use the **no service password-recovery** command to control end user access to passwords, we recommend that you save a copy of the configuration file in a location away from the switch in case the end user uses the password recovery procedure and sets the system back to default values. Do not keep a backup copy of the configuration file on the switch.

You can enter the **show version** privileged EXEC command to determine if password recovery is enabled or disabled.

Examples

This example shows how to disable password recovery on a switch so that a user can only reset a password by agreeing to return to the default configuration.

```
Switch(config) # no service-password recovery
Switch(config) # exit
```

Command	Description
show version	Displays version information for the hardware and firmware.

service-policy (interface configuration)

Use the **service-policy** interface configuration command to apply a policy map defined by the **policy-map** command to the incoming or outgoing traffic of a physical port. Use the **no** form of this command to remove the policy map and port association.

service-policy {input | output} policy-map-name

no service-policy {**input** | **output**} *policy-map-name*

Syntax Description

input	Apply the policy map to the input of a physical port.
output	Apply the policy map to the output of a physical port.
policy-map-name	The specified policy map to be applied.



Though visible in the command-line help strings, the **history** keyword is not supported, and you should ignore the statistics that it gathers.

Defaults

No policy maps are attached to the port.

Command Modes

Interface configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Only one input policy map and one output policy map can be attached to an interface.

You can attach input or output policy maps to a Fast Ethernet or Gigabit Ethernet port. You cannot attach policy maps to switch virtual interfaces (SVIs) and EtherChannel interfaces.

Examples

This example shows how to apply *plcmap1* as an output policy map:

Switch(config)# interface gigabitethernet0/1
Switch(config-if)# service-policy output plcmap1

This example shows how to remove *plcmap2* from the port:

Switch(config)# interface gigabitethernet0/2
Switch(config-if)# no service-policy output plcmap2

You can verify your settings by entering the **show running-config** privileged EXEC command.

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays quality of service (QoS) policy maps.
show policy-map interface [interface-id]	Displays policy maps configured on the specified interface or on all interfaces.
show running-config	Displays the running configuration on the switch. For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands.

service-policy (policy-map class configuration)

Use the **service-policy** policy-map class configuration command to configure a quality of service (Q0S) service policy for an output policy map. Use the **no** form of this command to disable a service policy as a QoS policy within a policy map.

service-policy policy-map-name

no service-policy policy-map-name

Syntax Description

policy-map-name	Name of the service policy map (created by using the policy-map global
	configuration command) to be used in a QoS hierarchical service policy.

Defaults

No service policies are defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You attach a service policy created in policy-map class configuration to a parent output policy map. This creates hierarchical policy mapping. Use the **service-policy** *policy-map-name* policy-map class configuration command to enter a second-level (child) policy map.

When **shape average** is also configured on the class **class-default**, you can configure hierarchical policy maps by attaching a single **service-policy** policy-map class command to the class **class-default**. This policy map specifies the service policy for the port-shaped traffic on the port and is the parent policy map.

You can configure the child policy with class-based queuing actions by using the **queue-limit** policy map class command and with scheduling actions (by using the **bandwidth**, **shape average**, or **priority** command).

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to define the service policy and to attach it to a parent policy map to set the maximum bandwidth (shape) for an output queue at 90000000 bits per second:

```
Switch(config)# policy-map out-policy-parent
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# shape average 90000000
Switch(config-pmap-c)# service-policy out-policy
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays quality of service (QoS) policy maps.

set cos

Use the **set cos** policy-map class configuration command to set a Layer 2 class of service (CoS) value in the packet. Use the **no** form of this command to remove traffic marking.

set cos {cos_value | from-field [table table-map-name]}

no set cos {cos value | from-field [table table-map-name]}

Syntax Description

cos_value	Enter an IEEE 802.1Q class of service/user priority value with which to classify traffic. The range is from 0 to 7.
from-field	Specific a packet-marking category to be used to set the CoS value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
	These options are supported:
	• cos—CoS value
	• dscp —Differentiated Services Code Point (DSCP) value.
	• precedence —IP-precedence value
table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the CoS value
table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the CoS value. The table map name can be a maximum of 64 alphanumeric characters.

Defaults

No traffic marking is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use the **set cos** command if you want to mark a packet that is being sent to a switch. Switches can leverage Layer 2 header information including a CoS value marking.

You can use the **match cos** class-map configuration command and the **set cos** policy-map class configuration command together to allow switches to interoperate and provide quality of service (QoS) based on the CoS markings. You can also configure Layer 2 to Layer 3 mapping by matching on the CoS value because switches can already match and set CoS values.

If you are using this command to perform enhanced packet marking, you can use the *from-field* packet marking option for mapping and setting the CoS value. The supported *from-field* marking categories are: CoS, DSCP, and IP precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the CoS value. For example, if you enter the **set cos precedence** command, the precedence value is copied and used as the CoS value. If you enter the **set cos dscp** command, the DSCP value is copied and used as the CoS value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

Examples

This example shows how to set all FTP traffic to cos 3:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set cos 3
Switch(config-pmap-c)# exit
```

This example shows how to assign a DSCP to CoS table map to a class:

```
Switch(config) # policy-map inpolicy
Switch(config-pmap) # class class-default
Switch(config-pmap-c) # set cos dscp table dscp-cos-tablemap
Switch(config-pmap) # exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays QoS policy maps.

set dscp

Use the **set** [**ip**] **dscp** policy-map class configuration command to mark IPv4 traffic by setting a Differentiated Services Code Point (DSCP) value in the type of service (ToS) byte of the packet. Use the **no** form of this command to remove traffic marking.

set [ip] dscp {dscp_value | from-field [table table-map-name]}

no set [ip] dscp {dscp_value | from-field [table table-map-name]}



Entering **ip dscp** is the same as entering **dscp**.

Syntax Description

dscp-value	Enter a DSCP value with which to classify traffic. The range is from 0 to 63. You also can enter a mnemonic name for a commonly used
	value.
from-field	Specific a packet-marking category to be used to set the DSCP value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
	These options are supported:
	• cos—class of service (CoS) value
	• dscp —DSCP value.
	• precedence —IP-precedence value
table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the DSCP value
table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the DSCP value. The table map name can be a maximum of 64 alphanumeric characters.

Defaults

No traffic marking is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You cannot use the **set dscp** command with the **set precedence** command to mark the same packet. DSCP values and IP precedence values are mutually exclusive. A packet can have one value of the other, but not both.

After DSCP bits are set, other quality of service (QoS) features can then operate on the bit settings.

The network gives priority (or some type of expedited handling) to marked traffic. Typically, you set the DSCP value at the edge of the network (or administrative domain) and data is then queued according to the precedence. Class-based weighted fair queuing (CBWFQ) can speed up handling for high-precedence traffic at congestion points. Weighted Tail Drop (WTD) ensures that high-precedence traffic has lower loss rates than other traffic during times of congestion.

Instead of using numeric values, you can also specify the *dscp-value* by using the reserved keywords **EF**, **AF11**, and **AF12**.

If you are using this command to perform enhanced packet marking, you can use the *from-field* packet marking option for mapping and setting the DSCP value. The supported *from-field* marking categories are: CoS, DSCP, and IP precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the DSCP value. For example, if you enter the **set dscp cos** command, the CoS value is copied and used as the DSCP value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

Examples

This example shows how to set all FTP traffic to DSCP 10:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set dscp 10
Switch(config-pmap-c)# exit
```

This example shows how to assign a CoS to DSCP table map to a class:

```
Switch(config)# policy-map inpolicy
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# set dscp cos table cos-dscp-tablemap
Switch(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays QoS policy maps.

set precedence

Use the **set** [**ip**] **precedence** policy-map class configuration command to mark IPv4 traffic by setting an IP-precedence value in the packet. Use the **no** form of this command to remove traffic marking.

set [ip] precedence {precedence_value | from-field [table table-map-name]}

no set [ip] precedence {precedence_value | from-field [table table-map-name]}



Entering **ip precedence** is the same as entering **precedence**.

Syntax Description

precedence_value	Enter an IPv4 precedence value with which to classify traffic. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
from-field	Specific a packet-marking category to be used to set the precedence value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
	These options are supported:
	• cos—class of service (CoS) value
	• dscp —Differentiated Services Code Point (DSCP) value.
	• precedence —IP-precedence value
table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the precedence value
table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the precedence value. The table map name can be a maximum of 64 alphanumeric characters.

Defaults

No traffic marking is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You cannot use the **set precedence** command with the **set dscp** command to mark the same packet. DSCP values and IP precedence values are mutually exclusive. A packet can have one value of the other, but not both.

After precedence bits are set, other quality of service (QoS) features can then operate on the bit settings.

The network gives priority (or some type of expedited handling) to marked traffic. Typically, you set the precedence value at the edge of the network (or administrative domain) and data is then queued according to the precedence. Class-based weighted fair queuing (CBWFQ) can speed up handling for high-precedence traffic at congestion points. Weighted Tail Drop (WTD) ensures that high-precedence traffic has lower loss rates than other traffic during times of congestion.

Instead of using numeric values, you can also specify the *dscp-value* by using the reserved keywords **EF**, **AF11**, and **AF12**.

If you are using this command to perform enhanced packet marking, you can use the *from-field* packet marking option for mapping and setting the precedence value. The supported *from-field* marking categories are: CoS, DSCP, and IP precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the precedence value. For example, if you enter the **set precedence cos** command, the CoS value is copied and used as the precedence value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

Examples

This example shows how to give all FTP traffic an IP precedence value of 5:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set precedence 5
Switch(config-pmap-c)# exit
```

This example shows how to assign a CoS to precedence table map to a class:

```
Switch(config) # policy-map inpolicy
Switch(config-pmap) # class class-default
Switch(config-pmap-c) # set precedence cos table cos-prec-tablemap
Switch(config-pmap) # exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays QoS policy maps.

set qos-group

Use the **set qos-group** policy-map class configuration command to set a a quality of service (QoS) group identifier that can be used later to classify packets. Use the **no** form of this command to remove the group identifier.

set qos-group value

no set qos-group value

Syntax Description

value	Set the QoS group value to use to classify traffic. The range is from 0
	to 15.

Defaults

No traffic marking is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use this command to associate a QoS group value with a traffic flow as it enters the switch, which can then be used in an output policy map to identify the flow.

When a **set qos-group** is configured in a class in an input policy map, no other **set** operations are allowed in the class.

A maximum of 16 QoS groups (0 through 15) is supported on the switch.

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to set all FTP traffic to QoS group 5:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set qos-group 5
Switch(config-pmap-c)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays QoS policy maps.

setup

Use the setup privileged EXEC command to configure the switch with its initial configuration.

setup

Syntax Description

This command has no arguments or keywords.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

When you use the **setup** command, make sure that you have this information:

- · IP address and network mask
- Password strategy for your environment

When you enter the **setup** command, an interactive dialog, called the System Configuration Dialog, appears. It guides you through the configuration process and prompts you for information. The values shown in brackets next to each prompt are the default values last set by using either the **setup** command facility or the **configure** privileged EXEC command.

Help text is provided for each prompt. To access help text, press the question mark (?) key at a prompt.

To return to the privileged EXEC prompt without making changes and without running through the entire System Configuration Dialog, press **Ctrl-C**.

When you complete your changes, the setup program shows you the configuration command script that was created during the setup session. You can save the configuration in NVRAM or return to the setup program or the command-line prompt without saving it.

Examples

This is an example of output from the **setup** command:

```
Switch# setup
--- System Configuration Dialog ---
Continue with configuration dialog? [yes/no]: yes

At any point you may enter a question mark '?' for help.
Use ctrl-c to abort configuration dialog at any prompt.
Default settings are in square brackets '[]'.

Basic management setup configures only enough connectivity for management of the system, extended setup will ask you to configure each interface on the system.

Would you like to enter basic management setup? [yes/no]: yes Configuring global parameters:
```

```
Enter host name [Switch]:host-name
  The enable secret is a password used to protect access to
  privileged EXEC and configuration modes. This password, after
  entered, becomes encrypted in the configuration.
  Enter enable secret: enable-secret-password
  The enable password is used when you do not specify an
  enable secret password, with some older software versions, and
  some boot images.
  Enter enable password: enable-password
  The virtual terminal password is used to protect
  access to the router over a network interface.
  Enter virtual terminal password: terminal-password
  Configure SNMP Network Management? [no]: yes
  Community string [public]:
Current interface summary
Any interface listed with OK? value "NO" does not have a valid configuration
Interface
                           IP-Address
                                           OK? Method Status
                                                                             Protocol
Vlan1
                           172.20.135.202 YES NVRAM up
                                                                             uр
GigabitEthernet0/1
                           unassigned
                                           YES unset up
                                                                             up
GigabitEthernet0/2
                           unassigned
                                                                             down
                                           YES unset up
<output truncated>
Port-channel1
                           unassigned
                                           YES unset. up
                                                                             down
Enter interface name used to connect to the
management network from the above interface summary: vlan1
Configuring interface vlan1:
Configure IP on this interface? [yes]: yes
IP address for this interface: ip_address
Subnet mask for this interface [255.0.0.0]: subnet_mask
The following configuration command script was created:
hostname host-name
enable secret 5 $1$LiBw$0Xc1wyT.PXPkuhFwqyhVi0
enable password enable-password
line vty 0 15
password terminal-password
snmp-server community public
no ip routing
interface GigabitEthernet0/1
no ip address
interface GigabitEthernet0/2
no ip address
end
```

Use this configuration? [yes/no]: yes

- [0] Go to the IOS command prompt without saving this config.
- [1] Return back to the setup without saving this config.
- [2] Save this configuration to nvram and exit.

Enter your selection [2]:

Command	Description
show running-config	Displays the running configuration on the switch. For syntax information, select Cisco IOS Configuration Fundamentals
	Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands.
show version	Displays version information for the hardware and firmware.

shape average

Use the **shape average** policy-map class configuration command to configure class-based shaping by specifying the average traffic shaping rate. Use the command with the class class-default to set port shaping. Use the **no** form of this command to remove traffic shaping.

shape average target bps

no shape average target bps

Syntax Description

target bps	Target average bit rate in bits per second (bps). The range is from
	64000 to 1000000000.

Defaults

No traffic shaping is defined.

Command Modes

Policy-map class configuration

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You use the **shape average** policy-map class command to control output traffic. Shaping is not supported in input policy maps.

Traffic shaping limits the rate of transmission of data. Configuring traffic shaping for a user-defined class for class-based shaping sets the peak information rate (PIR) for that class. Configuring traffic shaping for the class **class-default** when it is the only class in the policy map that is attached to an interface sets the PIR for the interface (port shaping).

You cannot configure **shape average** in a class that includes priority queueing (configured with the **priority** policy-map class configuration command).

The **shape average** command uses a default queue limit for the class. You can change the queue limit by using the **queue-limit** policy-map class command, overriding the default that is set by the **shape average** command.

You cannot use the **bandwidth** policy-map class configuration command to configure class-based weighted fair queuing (CBWFQ) and the **shape average** command to configure traffic shaping for the same class.

You can configure hierarchical policy maps by attaching the **service-policy** policy-map class command to the class **class-default** only when **shape average** is also configured on the class **class-default**.

In the default class (**class-default**), only output shaping configuration is allowed. You cannot configure any other queuing or scheduling actions.

To return to policy-map configuration mode, use the **exit** command. To return to privileged EXEC mode, use the **end** command.

Examples

This example shows how to configure traffic shaping for outgoing traffic on a Fast Ethernet port so that *outclass1*, *outclass2*, and *outclass3* get a maximum of 50, 20, and 10 Mbps of the buffer size. The class **class-default** gets the remaining bandwidth.

```
Switch(config)# policy-map out-policy
Switch(config-pmap)# class classout1
Switch(config-pmap-c)# shape average 50000000
Switch(config-pmap-c)# exit
Switch(config-pmap)# class classout2
Switch(config-pmap-c)# shape average 20000000
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# shape average 10000000
Switch(config-pmap-c)# shape average 10000000
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
Switch(config-pmap)# exit
Switch(config-pmap)# exit
```

This example shows how to configure port shaping by configuring a hierarchical policy map that shapes a port to 90 Mbps, allocated according to the *out-policy* policy map configured in the previous example.

```
Switch(config)# policy-map out-policy-parent
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# shape average 90000000
Switch(config-pmap-c)# service-policy out-policy
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
```

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Command	Description
class	Defines a traffic classification match criteria for the specified class-map name.
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
show policy-map	Displays QoS policy maps.
show policy-map interface [interface-id]	Displays policy maps configured on the specified interface or on all interfaces.

show access-lists

Use the **show access-lists** privileged EXEC command to display access control lists (ACLs) configured on the switch.

show access-lists [name | number | hardware counters | ipc] [| {begin | exclude | include} expression]

Syntax Description

name	(Optional) Name of the ACL.
number	(Optional) ACL number. The range is 1 to 2699.
hardware counters	(Optional) Display global hardware ACL statistics for switched and routed packets.
ipc	(Optional) Display Interprocess Communication (IPC) protocol access-list configuration download information.
begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.



Though visible in the command-line help strings, the **rate-limit** keywords are not supported.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The switch supports only IP standard and extended access lists. Therefore, the allowed numbers are only 1 to 199 and 1300 to 2699.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show access-lists** command:

```
Switch# show access-lists

Standard IP access list 1

10 permit 1.1.1.1

20 permit 2.2.2.2

30 permit any

40 permit 0.255.255.255, wildcard bits 12.0.0.0

Standard IP access list videowizard_1-1-1-1

10 permit 1.1.1.1

Standard IP access list videowizard_10-10-10-10

10 permit 10.10.10.10

Extended IP access list 121

10 permit ahp host 10.10.10.10 host 20.20.10.10 precedence routine
```

This is an example of output from the show access-lists hardware counters command:

```
Switch# show access-lists hardware counters
L2 ACL INPUT Statistics
                         All frame count: 855
    Drop:
    Drop:
                        All bytes count: 94143
                       All frame count: 0
    Drop And Log:
                        All bytes count: 0
     Drop And Log:
     Bridge Only:
                        All frame count: 0
     Bridge Only:
                        All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
     Forwarding To CPU: All frame count: 0
     Forwarding To CPU: All bytes count: 0
     Forwarded:
                        All frame count: 2121
                        All bytes count: 180762
     Forwarded:
     Forwarded And Log: All frame count: 0
     Forwarded And Log: All bytes count: 0
 L3 ACL INPUT Statistics
                         All frame count: 0
    Drop:
                        All bytes count: 0
    Drop:
    Drop And Log:
                       All frame count: 0
     Drop And Log:
                        All bytes count: 0
    Bridge Only:
                        All frame count: 0
     Bridge Only:
                        All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
    Forwarding To CPU: All frame count: 0 Forwarding To CPU: All bytes count: 0
    Forwarded:
                        All frame count: 13586
     Forwarded:
                        All bytes count: 1236182
     Forwarded And Log: All frame count: 0
     Forwarded And Log: All bytes count: 0
 L2 ACL OUTPUT Statistics
             All frame count: 0
    Drop:
                        All bytes count: 0
     Drop:
     Drop And Log:
                        All frame count: 0
                        All bytes count: 0
     Drop And Log:
                        All frame count: 0
     Bridge Only:
     Bridge Only:
                        All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
     Forwarding To CPU: All frame count: 0
     Forwarding To CPU: All bytes count: 0
                All frame count: 232983
     Forwarded:
     Forwarded:
                         All bytes count: 16825661
     Forwarded And Log: All frame count: 0
```

```
Forwarded And Log: All bytes count: 0
L3 ACL OUTPUT Statistics
   Drop:
                      All frame count: 0
   Drop:
                     All bytes count: 0
   Drop And Log:
                     All frame count: 0
   Drop And Log:
                     All bytes count: 0
   Bridge Only:
                     All frame count: 0
                     All bytes count: 0
   Bridge Only:
   Bridge Only And Log: All frame count: 0
   Bridge Only And Log: All bytes count: 0
   Forwarding To CPU: All frame count: 0
   Forwarding To CPU: All bytes count: 0
   Forwarded:
                     All frame count: 514434
   Forwarded:
                     All bytes count: 39048748
   Forwarded And Log: All frame count: 0
   Forwarded And Log: All bytes count: 0
```

Command	Description
access-list	Configures a standard or extended numbered access list on the switch. For syntax information, select Cisco IOS IP Command Reference, Volume 1 of 3:Addressing and Services, Release 12.2 > IP Services Commands.
ip access list	Configures a named IP access list on the switch. For syntax information, select Cisco IOS IP Command Reference, Volume 1 of 3:Addressing and Services, Release 12.2 > IP Services Commands.
mac access-list extended	Configures a named or numbered MAC access list on the switch.

show archive status

Use the **show archive status** privileged EXEC command to display the status of a new image being downloaded to a switch with the HTTP or the TFTP protocol.

show archive status [|{ begin | exclude | include}} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you use the **archive download-sw** privileged EXEC command to download an image to a TFTP server, the output of the **archive download-sw** command shows the status of the download.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

These are examples of output from the show archive status command:

Switch# show archive status
IDLE: No upgrade in progress
Switch# show archive status
LOADING: Upgrade in progress
Switch# show archive status
EXTRACT: Extracting the image
Switch# show archive status
VERIFY: Verifying software
Switch# show archive status

RELOAD: Upgrade completed. Reload pending

Command	Description
archive download-sw	Downloads a new image from a TFTP server to the switch.

show boot

Use the **show boot** privileged EXEC command to display the settings of the boot environment variables.

show boot [| {begin | exclude | include} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show boot** command. Table 2-4 describes each field in the display.

Switch# show boot

5d05h: %SYS-5-CONFIG_I: Configured from console by console

BOOT path-list

Config file : flash:/config.text

Private Config file : flash:/private-config.text

Enable Break : no
Manual Boot : yes
HELPER path-list :
Auto upgrade : yes

Table 2-4 show boot Field Descriptions

Field	Description
BOOT path-list	Displays a semicolon separated list of executable files to try to load and execute when automatically booting.
	If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash file system. In a depth-first search of a directory, each encountered subdirectory is completely searched before continuing the search in the original directory.
	If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash file system.
Config file	Displays the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.

Table 2-4 show boot Field Descriptions (continued)

Field	Description
Private Config file	Displays the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.
Enable Break	Displays whether a break during booting is enabled or disabled. If it is set to yes, on, or 1, you can interrupt the automatic boot process by pressing the Break key on the console after the flash file system is initialized.
Manual Boot	Displays whether the switch automatically or manually boots. If it is set to no or 0, the boot loader attempts to automatically boot the system. If it is set to anything else, you must manually boot the switch from the boot loader mode.
Helper path-list	Displays a semicolon separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.

Command	Description
boot config-file	Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.
boot enable-break	Enables interrupting the automatic boot process.
boot manual	Enables manually booting the switch during the next boot cycle.
boot private-config-file	Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the private configuration.
boot system	Specifies the Cisco IOS image to load during the next boot cycle.

show cable-diagnostics tdr

Use the **show cable-diagnostics tdr** privileged EXEC command to display the Time Domain Reflector (TDR) results.

show cable-diagnostics tdr interface interface-id [| {begin | exclude | include} | expression]



TDR is supported only on the copper Ethernet 10/100 ports on the Cisco ME switch.

Syntax Description

interface-id	Specify the interface on which TDR was run.
begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

TDR is supported only on copper Ethernet 10/100 ports on the Cisco ME switch. It is not supported on small form-factor pluggable (SFP)-module ports. For more information about TDR, see the software configuration guide for this release.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show cable-diagnostics tdr interface** *interface-id* command on a Cisco ME switch:

 ${\tt Switch\#\ show\ cable-diagnostics\ tdr\ interface\ fastethernet0/1}$

TDR test last run on: March 01 18:14:44

Interface	Speed	Local	pair	Pair	leng	gth		Remot	e pair	Pair status
Fa0/1	100M	Pair	 А	4	+/-	5	meters	Pair	A	Normal
		Pair	В	4	+/-	5	meters	Pair	В	Normal
		Pair	C	N/A				Pair	C	N/A
		Pair	D	N/A				Pair	D	N/A

Table 2-5 lists the descriptions of the fields in the **show cable-diagnostics tdr** command output.

Table 2-5 Fields Descriptions for the show cable-diagnostics tdr Command Output

Field	Description
Interface	Interface on which TDR was run.
Speed	Speed of connection.
Local pair	Name of the pair of wires that TDR is testing on the local interface.
Pair length	Location on the cable where the problem is, with respect to your switch. TDR can only find the location in one of these cases:
	• The cable is properly connected, the link is up, and the interface speed is 100 Mbps.
	• The cable is open.
	• The cable has a short.
Remote pair	Name of the pair of wires to which the local pair is connected. TDR can learn about the remote pair only when the cable is properly connected and the link is up.
Pair status	The status of the pair of wires on which TDR is running:
	• Normal—The pair of wires is properly connected.
	• Not completed—The test is running and is not completed.
	• Not supported—The interface does not support TDR.
	• Open—The pair of wires is open.
	• Shorted—The pair of wires is shorted.

This is an example of output from the **show interface** *interface-id* command when TDR is running:

Switch# show interface fastethernet0/1

 $fastethernet 0/1 \ is \ up, \ line \ protocol \ is \ up \ (connected: \ TDR \ in \ Progress)$

This is an example of output from the **show cable-diagnostics tdr interface** *interface-id* command when TDR is not running:

Switch# show cable-diagnostics tdr interface fastethernet0/1

% TDR test was never issued on fa0/1 $\,$

If an interface does not support TDR, this message appears:

% TDR test is not supported on switch 1

Command	Description
test cable-diagnostics tdr	Enables and runs TDR on an interface.

show class-map

Use the **show class-map** user EXEC command to display quality of service (QoS) class maps, which define the match criteria to classify traffic.

show class-map [class-map-name] [| {begin | exclude | include}} expression]

Syntax Description

class-map-name	(Optional) Display the contents of the specified class map.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show class-map** command:

```
Switch> show class-map
```

Class Map match-all videowizard_10-10-10-10 (id 2)
Match access-group name videowizard_10-10-10-10

Class Map match-any class-default (id 0)
Match any
Class Map match-all dscp5 (id 3)
Match ip dscp 5

Command Description	
class-map	Creates a class map to be used for matching packets to the class whose name you specify.
match access-group	Defines the match criteria to classify traffic.

show controllers cpu-interface

Use the **show controllers cpu-interface** privileged EXEC command to display the state of the CPU network interface ASIC and the send and receive statistics for packets reaching the CPU.

show controllers cpu-interface [| {begin | exclude | include} | expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
linclude	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

This display provides information that might be useful for Cisco technical support representatives troubleshooting the switch.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is a partial output example from the **show controllers cpu-interface** command:

Switch# show controllers cpu-interface

cpu-queue-frames	_	dropped	invalid	hol-block
rpc	4523063	0	0	0
stp	1545035	0	0	0
ipc	1903047	0	0	0
routing protocol	96145	0	0	0
L2 protocol	79596	0	0	0
remote console	0	0	0	0
sw forwarding	5756	0	0	0
host	225646	0	0	0
broadcast	46472	0	0	0
cbt-to-spt	0	0	0	0
igmp snooping	68411	0	0	0
icmp	0	0	0	0
logging	0	0	0	0
rpf-fail	0	0	0	0
queue14	0	0	0	0
cpu heartbeat	1710501	0	0	0

```
Supervisor ASIC receive-queue parameters
_____
 queue 0 maxrecevsize 5EE pakhead 1419A20 paktail 13EAED4
 queue 1 maxrecevsize 5EE pakhead 15828E0 paktail 157FBFC
 queue 2 maxrecevsize 5EE pakhead 1470D40 paktail 1470FE4
 queue 3 maxrecevsize 5EE pakhead 19CDDD0 paktail 19D02C8
<output truncated>
Supervisor ASIC Mic Registers
______
                              80000800
MicDirectPollInfo
MicIndicationsReceived
                              00000000
                              00000000
MicInterruptsReceived
MicPcsInfo
                              0001001F
                              00000000
MicPlbMasterConfiguration
MicRxFifosAvailable
                              00000000
MicRxFifosReady
                              0000BFFF
MicTimeOutPeriod:
                      FrameTOPeriod: 00000EA6 DirectTOPeriod: 00004000
<output truncated>
MicTransmitFifoInfo:
Fifo0:
       StartPtrs:
                      038C2800
                                      ReadPtr:
                                                     038C2C38
       WritePtrs:
                      038C2C38
                                      Fifo_Flag:
                                                     8A800800
                      001E001E
       Weights:
Fifol: StartPtr:
                      03A9BC00
                                      ReadPtr:
                                                     03A9BC60
                                      Fifo_Flag:
                                                     89800400
       WritePtrs:
                      03A9BC60
       writeHeaderPtr: 03A9BC60
                   038C88E0
Fifo2: StartPtr:
                                      ReadPtr:
                                                     038C88E0
                                                     88800200
                                      Fifo_Flag:
       WritePtrs:
       writeHeaderPtr: 038C88E0
Fifo3: StartPtr:
                    03C30400
                                      ReadPtr:
                                                     03C30638
       WritePtrs:
                     03C30638
                                      Fifo_Flag:
                                                     89800400
       writeHeaderPtr: 03C30638
Fifo4: StartPtr:
                      03AD5000
                                      ReadPtr:
                                                     03AD50A0
       WritePtrs:
                      03AD50A0
                                      Fifo_Flag:
                                                     89800400
       writeHeaderPtr: 03AD50A0
Fifo5: StartPtr:
                      03A7A600
                                      ReadPtr:
                                                     03A7A600
                                                     88800200
       WritePtrs:
                      03A7A600
                                      Fifo_Flag:
       writeHeaderPtr: 03A7A600
Fifo6: StartPtr:
                      03BF8400
                                      ReadPtr:
                                                     03BF87F0
       WritePtrs:
                       03BF87F0
                                      Fifo_Flag:
                                                     89800400
<output truncated>
```

Command	Description
show controllers ethernet-controller	Displays per-interface send and receive statistics read from the hardware or the interface internal registers.
show interfaces	Displays the administrative and operational status of all interfaces or a specified interface.

show controllers ethernet-controller

Use the **show controllers ethernet-controller** privileged EXEC command without keywords to display per-interface send and receive statistics read from the hardware. Use with the **phy** keyword to display the interface internal registers or the **port-asic** keyword to display information about the port ASIC.

show controllers ethernet-controller [interface-id] [phy [detail]] [port-asic {configuration | statistics}] [| {begin | exclude | include} | expression]

Syntax Description

interface-id	The physical interface (including type, module, and port number).
phy	(Optional) Display the status of the internal registers on the switch physical layer device (PHY) for the device or the interface. This display includes the operational state of the automatic medium-dependent interface crossover (Auto-MDIX) feature on an interface.
detail	(Optional) Display details about the PHY internal registers.
port-asic	(Optional) Display information about the port ASIC internal registers.
configuration	Display port ASIC internal register configuration.
statistics	Display port ASIC statistics, including the Rx/Sup Queue and miscellaneous statistics.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC (only supported with the interface-id keywords in user EXEC mode)

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

This display without keywords provides traffic statistics, basically the RMON statistics for all interfaces or for the specified interface.

When you enter the **phy** or **port-asic** keywords, the displayed information is useful primarily for Cisco technical support representatives troubleshooting the switch.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show controllers ethernet-controller** command for an interface. Table 2-6 describes the *Transmit* fields, and Table 2-7 describes the *Receive* fields.

Switch# show controllers ethernet-controller gigabitethernet0/1

Transmit GigabitEthernet0/1 Receive 0 Bytes 0 Bytes 0 Unicast frames 0 Unicast frames 0 Multicast frames 0 Multicast frames 0 Broadcast frames 0 Broadcast frames 0 Too old frames 0 Unicast bytes 0 Deferred frames 0 Multicast bytes 0 MTU exceeded frames 0 Broadcast bytes 0 1 collision frames 0 Alignment errors 0 2 collision frames 0 FCS errors 0 3 collision frames 0 Oversize frames 0 4 collision frames 0 Undersize frames 0 5 collision frames O Collision fragments 0 6 collision frames 0 7 collision frames 0 Minimum size frames 0 8 collision frames 0 65 to 127 byte frames 0 9 collision frames 0 128 to 255 byte frames 0 10 collision frames 0 256 to 511 byte frames 0 11 collision frames 0 512 to 1023 byte frames 0 12 collision frames 0 1024 to 1518 byte frames 0 13 collision frames 0 Overrun frames 0 14 collision frames 0 Pause frames 0 15 collision frames 0 Symbol error frames 0 Excessive collisions 0 Late collisions 0 Invalid frames, too large 0 VLAN discard frames 0 Valid frames, too large 0 Excess defer frames 0 Invalid frames, too small 0 64 byte frames 0 Valid frames, too small 0 127 byte frames 0 255 byte frames 0 Too old frames 0 511 byte frames 0 Valid oversize frames 0 1023 byte frames 0 System FCS error frames 0 RxPortFifoFull drop frame 0 1518 byte frames O Too large frames 0 Good (1 coll) frames

Table 2-6 Transmit Field Descriptions

Field	Description
Bytes	The total number of bytes sent on an interface.
Unicast Frames	The total number of frames sent to unicast addresses.
Multicast frames	The total number of frames sent to multicast addresses.
Broadcast frames	The total number of frames sent to broadcast addresses.
Too old frames	The number of frames dropped on the egress port because the packet aged out.
Deferred frames	The number of frames that are not sent after the time exceeds 2*maximum-packet time.
MTU exceeded frames	The number of frames that are larger than the maximum allowed frame size.
1 collision frames	The number of frames that are successfully sent on an interface after one collision occurs.
2 collision frames	The number of frames that are successfully sent on an interface after two collisions occur.
3 collision frames	The number of frames that are successfully sent on an interface after three collisions occur.
4 collision frames	The number of frames that are successfully sent on an interface after four collisions occur.

Table 2-6 Transmit Field Descriptions (continued)

Field	Description
5 collision frames	The number of frames that are successfully sent on an interface after five collisions occur.
6 collision frames	The number of frames that are successfully sent on an interface after six collisions occur.
7 collision frames	The number of frames that are successfully sent on an interface after seven collisions occur.
8 collision frames	The number of frames that are successfully sent on an interface after eight collisions occur.
9 collision frames	The number of frames that are successfully sent on an interface after nine collisions occur.
10 collision frames	The number of frames that are successfully sent on an interface after ten collisions occur.
11 collision frames	The number of frames that are successfully sent on an interface after 11 collisions occur.
12 collision frames	The number of frames that are successfully sent on an interface after 12 collisions occur.
13 collision frames	The number of frames that are successfully sent on an interface after 13 collisions occur.
14 collision frames	The number of frames that are successfully sent on an interface after 14 collisions occur.
15 collision frames	The number of frames that are successfully sent on an interface after 15 collisions occur.
Excessive collisions	The number of frames that could not be sent on an interface after 16 collisions occur.
Late collisions	After a frame is sent, the number of frames dropped because late collisions were detected while the frame was sent.
VLAN discard frames	The number of frames dropped on an interface because the CFI ¹ bit is set.
Excess defer frames	The number of frames that are not sent after the time exceeds the maximum-packet time.
64 byte frames	The total number of frames sent on an interface that are 64 bytes.
127 byte frames	The total number of frames sent on an interface that are from 65 to 127 bytes.
255 byte frames	The total number of frames sent on an interface that are from 128 to 255 bytes.
511 byte frames	The total number of frames sent on an interface that are from 256 to 511 bytes.
1023 byte frames	The total number of frames sent on an interface that are from 512 to 1023 bytes.
1518 byte frames	The total number of frames sent on an interface that are from 1024 to 1518 bytes.
Too large frames	The number of frames sent on an interface that are larger than the maximum allowed frame size.
Good (1 coll) frames	The number of frames that are successfully sent on an interface after one collision occurs. This value does not include the number of frames that are not successfully sent after one collision occurs.

^{1.} CFI = Canonical Format Indicator

Table 2-7 Receive Field Descriptions

Field	Description
Bytes	The total amount of memory (in bytes) used by frames received on an interface, including the FCS ¹ value and the incorrectly formed frames. This value excludes the frame header bits.
Unicast frames	The total number of frames successfully received on the interface that are directed to unicast addresses.
Multicast frames	The total number of frames successfully received on the interface that are directed to multicast addresses.
Broadcast frames	The total number of frames successfully received on an interface that are directed to broadcast addresses.

Table 2-7 Receive Field Descriptions (continued)

Field	Description
Unicast bytes	The total amount of memory (in bytes) used by unicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
Multicast bytes	The total amount of memory (in bytes) used by multicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
Broadcast bytes	The total amount of memory (in bytes) used by broadcast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.
Alignment errors	The total number of frames received on an interface that have alignment errors.
FCS errors	The total number of frames received on an interface that have a valid length (in bytes) but do not have the correct FCS values.
Oversize frames	The number of frames received on an interface that are larger than the maximum allowed frame size.
Undersize frames	The number of frames received on an interface that are smaller than 64 bytes.
Collision fragments	The number of collision fragments received on an interface.
Minimum size frames	The total number of frames that are the minimum frame size.
65 to 127 byte frames	The total number of frames that are from 65 to 127 bytes.
128 to 255 byte frames	The total number of frames that are from 128 to 255 bytes.
256 to 511 byte frames	The total number of frames that are from 256 to 511 bytes.
512 to 1023 byte frames	The total number of frames that are from 512 to 1023 bytes.
1024 to 1518 byte frames	The total number of frames that are from 1024 to 1518 bytes.
Overrun frames	The total number of overrun frames received on an interface.
Pause frames	The number of pause frames received on an interface.
Symbol error frames	The number of frames received on an interface that have symbol errors.
Invalid frames, too large	The number of frames received that were larger than maximum allowed MTU ² size (including the FCS bits and excluding the frame header) and that have either an FCS error or an alignment error.
Valid frames, too large	The number of frames received on an interface that are larger than the maximum allowed frame size.
Invalid frames, too small	The number of frames received that are smaller than 64 bytes (including the FCS bits and excluding the frame header) and that have either an FCS error or an alignment error.
Valid frames, too small	The number of frames received on an interface that are smaller than 64 bytes (or 68 bytes for VLAN-tagged frames) and that have valid FCS values. The frame size includes the FCS bits but excludes the frame header bits.
Too old frames	The number of frames dropped on the ingress port because the packet aged out.
Valid oversize frames	The number of frames received on an interface that are larger than the maximum allowed frame size and have valid FCS values. The frame size includes the FCS value but does not include the VLAN tag.

Table 2-7 Receive Field Descriptions (continued)

Field	Description
•	The total number of frames received on an interface that have a valid length (in bytes) but that do not have the correct FCS values.
RxPortFifoFull drop frames	The total number of frames received on an interface that are dropped because the ingress queue is full.

- 1. FCS = frame check sequence
- 2. MTU = maximum transmission unit

This is an example of output from the **show controllers ethernet-controller phy** command for a specific interface. Note that the last line of the display is the setting for Auto-MDIX for the interface.

```
Switch# show controllers ethernet-controller gigabitethernet0/2 phy
Control Register
                                                                                                                                                                                                                          : 0001 0001 0100 0000
     Control STATUS
                                                                                                                                                                                                                                 : 0111 1001 0100 1001
                                                                                                                                                                                                                             : 0000 0001 0100 0001
     Phy ID 1
                                                                                                                                                                                                                           : 0000 1100 0010 0100
     Phy ID 2

      Phy ID 2
      : 0000 1100 0010 0100

      Auto-Negotiation Advertisement
      : 0000 0011 1110 0001

      Auto-Negotiation Link Partner
      : 0000 0000 0000 0000 0000

      Auto-Negotiation Expansion Reg
      : 0000 0000 0000 0000 0100

      Next Page Transmit Register
      : 0010 0000 0000 0000 0001

      Link Partner Next page Registe
      : 0000 0000 0000 0000 0000

      1000BASE-T Control Register
      : 0000 1111 0000 0000

      1000BASE-T Status Register
      : 0100 0000 0000 0000

      Extended Status Register
      : 0011 0000 0000 0000

      PHY Specific Control Register
      : 0000 0000 0111 1000

      PHY Specific Status Register
      : 1000 0001 0100 0000

      Interrupt Enable
      : 0000 0000 0000 0100 0000

      Interrupt Status
      : 0000 0000 0100 0100 0000

  | 1000 0001 0100 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0000 | 1000 0
    : 0000 0000 0000 1011
     Disable Receiver 1
                                                                                                                                                                                                                             : 1000 0000 0000 0100
: 1000 0100 1000 0000
      Disable Receiver 2
     Extended PHY Specific Status
                                                                                                                                                                                                                                   : On [AdminState=1 Flags=0x00052248]
     Aut.o-MDTX
```

This is an example of output from the **show controllers ethernet-controller port-asic configuration** command:

```
Switch# show controllers ethernet-controller port-asic configuration
______
PortASIC 0 Registers
DeviceType
                                 : 000101BC
Reset
                                 : 00000000
PmadMicConfig
                                : 00000001
PmadMicDiag
                                : 00000003
PmadMicDiag : 0000003
SupervisorReceiveFifoSramInfo : 000007D0 000007D0 40000000
SupervisorTransmitFifoSramInfo : 000001D0 000001D0 40000000
GlobalStatus
                                 : 00000800
IndicationStatus
                                 : 00000000
IndicationStatusMask
                                 : FFFFFFFF
InterruptStatus
                                : 00000000
InterruptStatusMask
                                 : 01FFE800
```

```
SupervisorDiag
                                  : 00000000
SupervisorFrameSizeLimit
                                  : 000007C8
SupervisorBroadcast
                                  · 000A0F01
GeneralIO
                                 : 000003F9 00000000 00000004
                                 : FFFF1000 860329BD 5555FFFF FFFFFFF
StackPcsInfo
                                   FF0FFF00 86020000 5555FFFF 00000000
                                 : 73001630 00000003 7F001644 00000003
StackRacInfo
                                    24140003 FD632B00 18E418E0 FFFFFFF
StackControlStatus
                                  : 18E418E0
stackControlStatusMask
                                  : FFFFFFFF
stackControlStatusMask
TransmitBufferFreeListInfo
                                  : 00000854 00000800 00000FF8 00000000
                                    0000088A 0000085D 00000FF8 00000000
                        : 00000016 00000016 40000000 00000000
TransmitRingFifoInfo
                                   0000000C 0000000C 40000000 00000000
TransmitBufferInfo
                                 : 00012000 00000FFF 00000000 00000030
TransmitBufferCommonCount : 00000F7A
TransmitBufferCommonCountPeak : 0000001E
                                 : 0000001E
TransmitBufferCommonCommonEmpty : 000000FF
NetworkActivity
                                  : 00000000 00000000 00000000 02400000
DroppedStatistics
                                  : 00000000
FrameLengthDeltaSelect
                                  . 00000001
SneakPortFifoInfo
                                  : 00000000
                                  : 0EC0801C 00000001 0EC0801B 00000001
MacInfo
                                    00C0001D 00000001 00C0001E 00000001
```

<output truncated>

This is an example of output from the **show controllers ethernet-controller port-asic statistics** command:

```
Switch# show controllers ethernet-controller port-asic statistics
______
PortASIC 0 Statistics
         0 RxQ-0, wt-0 enqueue frames 0 RxQ-0, wt-0 drop frames 66 RxQ-0, wt-1 enqueue frames 0 RxQ-0, wt-1 drop frames
   4118966 RxQ-0, wt-1 enqueue frames
         0 RxQ-0, wt-2 enqueue frames
                                                    0 RxQ-0, wt-2 drop frames
       0 RxQ-1, wt-0 enqueue frames 0 RxQ-1, wt-0 drop frames 296 RxQ-1, wt-1 enqueue frames 0 RxQ-1, wt-1 drop frames
         0 RxQ-1, wt-0 enqueue frames
                                                   0 RxQ-1, wt-0 drop frames
   2836036 RxQ-1, wt-2 enqueue frames
                                                    0 RxQ-1, wt-2 drop frames
         0 RxQ-2, wt-0 enqueue frames 0 RxQ-2, wt-0 drop frames 0 RxQ-2, wt-1 enqueue frames 0 RxQ-2, wt-1 drop frames
    158377 RxQ-2, wt-2 enqueue frames
                                                    0 RxQ-2, wt-2 drop frames
         0 RxQ-3, wt-0 enqueue frames
0 RxQ-3, wt-1 enqueue frames
0 RxQ-3, wt-2 enqueue frames
                                                    0 RxQ-3, wt-0 drop frames
                                                    0 RxQ-3, wt-1 drop frames
                                                     0 RxQ-3, wt-2 drop frames
         0 TxBufferFull Drop Count
0 TxBufferFrameDesc BadCrc16
0 TxBuffer Bandwidth Drop Coun
        15 TxBufferFull Drop Count
                                                    0 Rx Fcs Error Frames
                                                    0 Rx Invalid Oversize Frames
                                                   0 Rx Invalid Too Large Frames
                                                    0 Rx Invalid Too Large Frames
                                                   0 Rx Invalid Too Small Frames
         0 TxQueue Missed Drop Statist
                                                   0 Rx Too Old Frames
        74 RxBuffer Drop DestIndex Cou
         O SneakQueue Drop Count
                                                   0 Tx Too Old Frames
         O Learning Queue Overflow Fra
                                                    0 System Fcs Error Frames
         0 Learning Cam Skip Count
        15 Sup Queue 0 Drop Frames
                                                    0 Sup Queue 8 Drop Frames
         0 Sup Queue 1 Drop Frames
                                                     0 Sup Queue 9 Drop Frames
```

O Sup Queue 2 Drop Frames

0 Sup Queue 10 Drop Frames

0	Sup	Queue	3	Drop	Fra	ames		0	Sup	Que	ıe	11	Drop	Frames
0	Sup	Queue	4	Drop	Fra	ames		0	Sup	Que	ıe	12	Drop	Frames
0	Sup	Queue	5	Drop	Fra	ames		0	Sup	Que	ıe	13	Drop	Frames
0	Sup	Queue	6	Drop	Fra	ames		0	Sup	Que	ıe	14	Drop	Frames
0	Sup	Queue	7	Drop	Fra	ames		0	Sup	Que	ıe	15	Drop	Frames
========	-===	-====	===	-====	====		======	====	====	====	===	==:	====	======
PortASIC 1	L Sta	atistic	CS											
0	RxQ-	0, wt	-0	enque	eue	frames		0	RxQ-	-0, 7	wt-	0 0	drop	frames
52	RxQ-	0, wt	-1	enque	eue	frames		0	RxQ-	-0, 7	wt-	1 (drop	frames
0	RxQ-	0, wt-	-2	enque	eue	frames		0	RxQ-	-0, 7	wt-	2 (drop	frames

<output truncated>

Command	Description
show controllers cpu-interface	Displays the state of the CPU network ASIC and send and receive statistics for packets reaching the CPU.
show controllers tcam	Displays the state of registers for all ternary content addressable memory (TCAM) in the system and for TCAM interface ASICs that are CAM controllers.

show controllers tcam

Use the **show controllers tcam** privileged EXEC command to display the state of the registers for all ternary content addressable memory (TCAM) in the system and for all TCAM interface ASICs that are CAM controllers.

show controllers team [asic [number]] [detail] [| {begin | exclude | include} | expression]

Syntax Description

asic	(Optional) Display port ASIC TCAM information.
number	(Optional) Display information for the specified port ASIC number. The range is from 0 to 15.
detail	(Optional) Display detailed TCAM register information.
begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

This display provides information that might be useful for Cisco technical support representatives troubleshooting the switch.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show controllers tcam** command:

Switch# show controllers tcam

TCAM-0 Registers REW: 00B30103 SIZE: 00080040 ID: 0000000 CCR: 00000000_F0000020 RPID0: 00000000_00000000 RPID1: 00000000_00000000 RPID2: 00000000_00000000 RPID3: 00000000_00000000 HRRO: 00000000_E000CAFC HRR1: 00000000_00000000 HRR2: 0000000_00000000 HRR3: 00000000_0000000 HRR4: 00000000_0000000 HRR5: 00000000_0000000 HRR6: 00000000_0000000 HRR7: 00000000_0000000

<output truncated>

TCAM related PortASIC 1 registers

LookupType: 89A1C67D_24E35F00

LastCamIndex: 0000FFE0 LocalNoMatch: 000069E0

ForwardingRamBaseAddress:

00022A00 0002FE00 00040600 0002FE00 0000D400 00000000 003FBA00 00009000 00009000 00040600

00000000 00012800 00012900

Command	Description
show controllers cpu-interface	Displays the state of the CPU network ASIC and send and receive statistics for packets reaching the CPU.
show controllers ethernet-controller	Displays per-interface send and receive statistics read from the hardware or the interface internal registers.

show controllers utilization

Use the **show controllers utilization** user EXEC command to display bandwidth utilization on the switch or specific ports.

show controllers [interface-id] utilization [| {begin | exclude | include} | expression]

Syntax Description

interface-id	(Optional) ID of the switch interface.
begin	(Optional) Display begins with the line that matches the specified expression.
exclude	(Optional) Display excludes lines that match the specified expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show controllers utilization** command.

Switch>	show controllers utiliz	ation
Port	Receive Utilization	Transmit Utilization
Fa0/1	0	0
Fa0/2	0	0
Fa0/3	0	0
Fa0/4	0	0
Fa0/5	0	0
Fa0/6	0	0
Fa0/7	0	0
<outnut< td=""><td>truncated></td><td></td></outnut<>	truncated>	

<output truncated>

```
Switch Receive Bandwidth Percentage Utilization : 0
Switch Transmit Bandwidth Percentage Utilization : 0
```

Switch Fabric Percentage Utilization: 0

This is an example of output from the show controllers utilization command on a specific port:

```
Switch> show controllers gigabitethernet0/1 utilization Receive Bandwidth Percentage Utilization : 0 Transmit Bandwidth Percentage Utilization : 0
```

Table 2-8 show controllers utilization Field Descriptions

Field	Description
Receive Bandwidth Percentage Utilization	Displays the received bandwidth usage of the switch, which is the sum of the received traffic on all the ports divided by the switch receive capacity.
Transmit Bandwidth Percentage Utilization	Displays the transmitted bandwidth usage of the switch, which is the sum of the transmitted traffic on all the ports divided it by the switch transmit capacity.
Fabric Percentage Utilization	Displays the average of the transmitted and received bandwidth usage of the switch.

Command	Description
show controllers ethernet-controller	Displays the interface internal registers.

show dot1x

Use the **show dot1x** privileged EXEC command to display IEEE 802.1x statistics, administrative status, and operational status for the switch or for the specified port.

show dot1x [all | interface interface-id | statistics interface interface-id] [| {begin | exclude | include} | expression]

Syntax Description

all	(Optional) Display the IEEE 802.1x status for all ports.
interface interface-id	(Optional) Display the IEEE 802.1x status for the specified port (including type, module, and port number).
statistics interface interface-id	(Optional) Display IEEE 802.1x statistics for the specified port (including type, module, and port number).
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you do not specify a port, global parameters and a summary appear. If you specify a port, details for that port appear.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show dot1x** and the **show dot1x all** privileged EXEC commands:

Switch# show dot1x

Sysauthcontrol = Enabled
Supplicant Allowed In Guest Vlan = Disabled
Dotlx Protocol Version = 1
Dotlx Oper Controlled Directions = Both
Dotlx Admin Controlled Directions = Both

Switch# show dot1x all

Dot1x Info for interface GigabitEthernet0/1

Supplicant MAC 00d0.b71b.35de
AuthSM State = CONNECTING
BendSM State = IDLE
PortStatus = UNAUTHORIZED

MaxReq = 2 HostMode = Single

```
Port Control
Port Control = Auto
QuietPeriod = 60 Seconds
                = Auto
Re-authentication = Disabled
ReAuthPeriod
              = 3600 Seconds
ServerTimeout
               = 30 Seconds
SuppTimeout = 30 Seconds
TxPeriod
               = 30 Seconds
Guest-Vlan
                = 0
Dot1x Info for interface GigabitEthernet0/2
______
PortStatus
               = UNAUTHORIZED
               = 2
MaxReq
nostMode = Multi
Port Control = Auto
QuietPeriod = 60 C
               = 60 Seconds
Re-authentication = Disabled
ReAuthPeriod = 3600 Seconds
ServerTimeout
                = 30 Seconds
             = 30 Seconds
SuppTimeout
TxPeriod
               = 30 Seconds
Guest-Vlan
                = 0
```

This is an example of output from the **show dot1x interface** interface-id privileged EXEC command:

Switch# show dot1x interface gigabitethernet0/1

```
Supplicant MAC 00d0.b71b.35de
   AuthSM State = AUTHENTICATED
  BendSM State
                   = IDLE
PortStatus = AUTHORIZED
MaxReq
                 = 2
HostMode
                 = Single
Port Control = Auto
QuietPeriod = 60 Se
                 = 60 Seconds
{\tt Re-authentication = Disabled}
               = 3600 Seconds
ReAuthPeriod
                = 30 Seconds
ServerTimeout
SuppTimeout = 30 Seconds
TxPeriod
Guest-Vlan
                = 30 Seconds
```

This is an example of output from the **show dot1x statistics interface** *interface-id* command. Table 2-9 describes the fields in the display.

Switch# show dot1x statistics interface gigabitethernet0/1

```
PortStatistics Parameters for Dot1x
-------

TxReqId = 15   TxReq = 0   TxTotal = 15

RxStart = 4   RxLogoff = 0   RxRespId = 1   RxResp = 1

RxInvalid = 0   RxLenErr = 0   RxTotal = 6

RxVersion = 1   LastRxSrcMac 00d0.b71b.35de
```

Table 2-9 show dot1x statistics Field Descriptions

Field	Description	
TxReqId	Number of Extensible Authentication Protocol (EAP)-request/identity frames that have been sent.	
TxReq	Number of EAP-request frames (other than request/identity frames) that have been sent.	
TxTotal	Number of Extensible Authentication Protocol over LAN (EAPOL) frames of any type that have been sent.	
RxStart	Number of valid EAPOL-start frames that have been received.	
RxLogoff	Number of EAPOL-logoff frames that have been received.	
RxRespId	Number of EAP-response/identity frames that have been received.	
RxResp	Number of valid EAP-response frames (other than response/identity frames) that have been received.	
RxInvalid	Number of EAPOL frames that have been received and have an unrecognized frame type.	
RxLenError	Number of EAPOL frames that have been received in which the packet body length field is invalid.	
RxTotal	Number of valid EAPOL frames of any type that have been received.	
RxVersion	Number of received packets in the IEEE 802.1x Version 1 format.	
LastRxSrcMac	Source MAC address carried in the most recently received EAPOL frame.	

Command	Description
dot1x default	Resets the configurable IEEE 802.1x parameters to their default values.

show env

Use the **show env** user EXEC command to display fan, temperature, redundant power system (RPS) availability, and power information for the switch.

show env {all | fan | power} [| {begin | exclude | include} | expression]

Syntax Description

all	Display both fan and temperature environmental status.
fan	Display the switch fan status.
power	Display the switch power status.
rps	Display whether a Cisco RPS 300 Redundant Power System is connected to the switch.
temperature	Display the switch temperature status.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

On a Cisco ME switch, you can use the **show env temperature** command to display the switch temperature status. The command output shows the green and yellow states as *OK* and the red state as *FAULTY*. If you enter the **show env all** command on this switch, the command output is the same as the **show env temperature status** command output.

For more information about the threshold levels, see the software configuration guide for this release.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show env all** command:

Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT

This is an example of output from the show env fan command:

Switch> show env fan FAN is OK

show errdisable detect

Use the **show errdisable detect** user EXEC command to display error-disable detection status.

show errdisable detect [| {begin | exclude | include} | expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

A displayed gbic-invalid error reason refers to an invalid small form-factor pluggable (SFP) module.

Examples

This is an example of output from the **show errdisable detect** command:

Switch> show errdisable detect

ErrDisable Reason	Detection status
udld	Enabled
bpduguard	Enabled
security-violatio	Enabled
channel-misconfig	Enabled
psecure-violation	Enabled
vmps	Enabled
loopback	Enabled
pagp-flap	Enabled
dtp-flap	Enabled
link-flap	Enabled
gbic-invalid	Enabled
dhcp-rate-limit	Enabled
unicast-flood	Enabled
storm-control	Enabled
ilpower	Enabled
community-limit	Enabled



Though visible in the output, the dtp-flap, l2ptguard, ilpower, storm-control, arp-inspection, and unicast-flood fields are not valid.

Command	Description
errdisable detect cause Enables error-disable detection for a specific cause or all	
show errdisable flap-values	Displays error condition recognition information.
show errdisable recovery	Displays error-disable recovery timer information.
show interfaces status	Displays interface status or a list of interfaces in error-disabled state.

show errdisable flap-values

Use the **show errdisable flap-values** user EXEC command to display conditions that cause an error to be recognized for a cause.

show errdisable flap-values [| {begin | exclude | include}} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The *Flaps* column in the display shows how many changes to the state within the specified time interval will cause an error to be detected and a port to be disabled. For example, the display shows that an error will be assumed and the port shut down if three Dynamic Trunking Protocol (DTP)-state (port mode access/trunk) or Port Aggregation Protocol (PAgP) flap changes occur during a 30-second interval, or if 5 link-state (link up/down) changes occur during a 10-second interval.

ErrDisable Reason	Flaps	Time (sec)
pagp-flap	3	30
dtp-flap	3	30
link-flap	5	10



Although visible in the output display, the switch does not support DTP.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show errdisable flap-values** command:

Switch> show errdisable flap-values			
ErrDisable Reason	Flaps	Time (sec)	
pagp-flap	3	30	
dtp-flap	3	30	
link-flap	5	1.0	

Command	Description		
errdisable detect cause	Enables error-disable detection for a specific cause or all causes.		
show errdisable detect	Displays error-disable detection status.		
show errdisable recovery	Displays error-disable recovery timer information.		
show interfaces status	Displays interface status or a list of interfaces in error-disabled state.		

show errdisable recovery

Use the **show errdisable recovery** user EXEC command to display the error-disable recovery timer information.

show errdisable recovery [| {begin | exclude | include}} expression]

Syntax Description

l begin (Optional) Display begins with the line that matches the expression.		
l exclude (Optional) Display excludes lines that match the expression.		
include	(Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification		
12.2(25)EX	This command was introduced.		

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

A *gbic-invalid error-disable* reason refers to an invalid small form-factor pluggable (SFP) module interface.

Examples

This is an example of output from the **show errdisable recovery** command:

Switch> show errdisable recovery

ErrDisable Reason	Timer Status
udld	Disabled
bpduguard	Disabled
security-violatio	Disabled
channel-misconfig	Disabled
vmps	Disabled
pagp-flap	Disabled
dtp-flap	Disabled
link-flap	Enabled
psecure-violation	Disabled
gbic-invalid	Disabled
dhcp-rate-limit	Disabled
unicast-flood	Disabled
storm-control	Disabled
arp-inspection	Disabled
loopback	Disabled

Timer interval:300 seconds

Interfaces that will be enabled at the next timeout:

Interface Errdisable reason Time left(sec)

Gi0/2	link-flap	279



Though visible in the output, the unicast-flood and DTP fields are not valid.

Command	Description		
errdisable recovery	Configures the recover mechanism variables.		
show errdisable detect	Displays error-disabled detection status.		
show errdisable flap-values	Displays error condition recognition information.		
show interfaces status	Displays interface status or a list of interfaces in error-disabled state.		

show etherchannel

Use the **show etherchannel** user EXEC command to display EtherChannel information for a channel.

show etherchannel [channel-group-number {detail | port | port-channel | protocol | summary}]
 {detail | load-balance | port | port-channel | protocol | summary} [| {begin | exclude |
 include} expression]

Syntax Description

channel-group-number (Optional) Number of the channel group. The range is 1 to				
detail	Display detailed EtherChannel information.			
load-balance	Display the load-balance or frame-distribution scheme among ports in the port channel.			
port	Display EtherChannel port information.			
port-channel	Display port-channel information. Display the protocol that is being used in the EtherChannel.			
protocol				
summary	Display a one-line summary per channel-group.			
begin	(Optional) Display begins with the line that matches the expression.			
exclude	(Optional) Display excludes lines that match the <i>expression</i> .			
include	(Optional) Display includes lines that match the specified <i>expression</i> .			
expression	Expression in the output to use as a reference point.			

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you do not specify a *channel-group*, all channel groups are displayed.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the show etherchannel 1 detail command:

```
Switch> show etherchannel 1 detail
Group state = L2
Ports: 2 Maxports = 16
Port-channels: 1 Max Port-channels = 16
Protocol: LACP
             Ports in the group:
Port: Gi0/1
Port state
          = Up Mstr In-Bndl
Channel group = 1 Mode = Active Gcchange = -
Port-channel = Po1 GC = - Pseudo port-channel = Po1
                      Load = 0x00
Port index
          = 0
                                       Protocol = LACP
Flags: S - Device is sending Slow LACPDUS F - Device is sending fast LACPDU
      A - Device is in active mode. P - Device is in passive mode.
Local information:
                        LACP port
                                   Admin
                                             Oper
                                                    Port
                                                            Port
                                   Key
                                                    Number State
Port.
        Flags State
                       Priority
                                             Kev
     SA
              bndl
                       32768
                                                           0x3D
Gi0/1
                                   0x0
                                             0x1
                                                    0x0
Age of the port in the current state: 01d:20h:06m:04s
              Port-channels in the group:
Port-channel: Po1 (Primary Aggregator)
Age of the Port-channel = 01d:20h:20m:26s
Logical slot/port = 10/1 Number of ports = 2
HotStandBy port = null
Port state = Port-channel Ag-Inuse
Protocol
                   LACP
Ports in the Port-channel:
Index Load Port
                   EC state
                                 No of bits
00 Gi0/1 Active 0
 0
       00 Gi0/2 Active
                                   0
Time since last port bundled: 01d:20h:20m:20s Gi0/2
```

This is an example of output from the **show etherchannel 1 summary** command:

```
Switch> show etherchannel 1 summary

Flags: D - down P - in port-channel
    I - stand-alone s - suspended
    H - Hot-standby (LACP only)
    R - Layer3 S - Layer2
    u - unsuitable for bundling
    U - in use f - failed to allocate aggregator d - default port

Number of channel-groups in use: 1

Number of aggregators: 1
```

This is an example of output from the show etherchannel 1 port-channel command:

Switch> show etherchannel 1 port-channel

0 00 Gi0/1 Active 0 0 00 Gi0/2 Active 0

Time since last port bundled: 01d:20h:24m:44s Gi0/2

This is an example of output from **show etherchannel protocol** command:

Switch# show etherchannel protocol

Command	Description		
channel-group	Assigns an Ethernet port to an EtherChannel group.		
channel-protocol	Restricts the protocol used on a port to manage channeling.		
interface port-channel	Accesses or creates the port channel.		

show flowcontrol

Use the **show flowcontrol** user EXEC command to display the flow control status and statistics.

show flowcontrol [interface *interface-id* | **module** *number*] [| {**begin** | **exclude** | **include**} *expression*]

Syntax Description

interface interface-id	(Optional) Display the flow control status and statistics for a specific interface. (Optional) Display the flow control status and statistics for all interfaces on the switch. The only valid module number is 1. This option is not available if you have entered a specific interface ID.		
module number			
begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
include	(Optional) Display includes lines that match the specified expression.		
expression	Expression in the output to use as a reference point.		

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use this command to display the flow control status and statistics on the switch or for a specific interface.

Use the **show flowcontrol** command to display information about all the switch interfaces. The output from the **show flowcontrol** command is the same as the output from the **show flowcontrol module** *number* command.

Use the **show flowcontrol interface** *interface-id* command to display information about a specific interface

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show flowcontrol** command.

Switch> show flowcontrol

SWICCH'S BHOW LIOWCOHCLOI							
	Port	rt Send FlowCo		Receive	FlowControl	RxPause	TxPause
		admin	oper	admin	oper		
	Gi0/1	Unsupp.	Unsupp.	off	off	0	0
	Gi0/2	desired	off	off	off	0	0
	Gi0/3	desired	off	off	off	0	0
	<output th="" tr<=""><th>uncated></th><th></th><th></th><th></th><th></th><th></th></output>	uncated>					

This is an example of output from the **show flowcontrol interface** *interface-id* command:

Switch> s	show	flowcontrol	interface	gigabitethernet0/2
-----------	------	-------------	-----------	--------------------

Port	Send Flo	wControl	Receive 1	FlowControl	RxPause	se TxPause	
	admin	oper	admin	oper			
Gi0/2	desired	off	off	off	0	0	

Command	Description
flowcontrol	Sets the receive flow-control state for an interface.

show idprom

Use the **show idprom** user EXEC command to display the IDPROM information for a Gigabit Ethernet interface.

show idprom {interface interface-id} [detail] [| {begin | exclude | include} | expression]

Syntax Description

interface interface-id	Display the IDPROM information for the specified Gigabit Ethernet interface.
detail	(Optional) Display detailed IDPROM information.
l begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

This command applies only to Gigabit Ethernet interfaces and displays information about SFPs inserted in the SFP module slot.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show idprom interface** command for a Gigabit Ethernet interface:

Switch# show idprom interface gigabitethernet0/1

: 1

General SFP Information Identifier : 0x03 : 0x07 Connector Transceiver Encoding : 0x02 : BR_Nominal 0x01Vendor Name : CISCO-NEC

Vendor Part Number : OD-BP1511-23SL2

Vendor Revision : 0x30 0x30 0x30 0x31 Vendor Serial Number : NEC08440067 Other Information : 0 Port asic num Port asic port num : 0

XCVR init completed

```
Embedded PHY .

SFP presence index : 0

... cnt : 697918
                      : not present
SFP failed oper flag : 0x0
IIC error cnt : 0
IIC error dsb cnt : 0 IIC max sts cnt : 4
Chk for link status : 1
Link Status : 1
Link Status Media : 1
Preferred media : 0
Resolved Media : 1
Resolved Media
                     : 1
Config Media
                     : 1
Access Count
                     : 0
Access Count Max : 2
Port Rx Loss
                     : no
Port Tx Fault
                     : no
Port Tx Disable
Sfp selection asic reg map
_____
stbi
                     : 0x00
                   : 0x4C
sfpControl
                    : 0xF000000
Regs Loc
```

Page 0 Registers

_								
	0000:	1140	Control Register	:	0001	0001	0100	0000
	0001:	6149	Control STATUS	:	0110	0001	0100	1001
	0002:	0141	Phy ID 1	:	0000	0001	0100	0001
	0003:	0C92	Phy ID 2	:	0000	1100	1001	0010
	0004:	01E1	Auto-Negotiation Advertisement	:	0000	0001	1110	0001
	0005:	0000	Auto-Negotiation Link Partner	:	0000	0000	0000	0000
	0006:	0004	Auto-Negotiation Expansion Reg	:	0000	0000	0000	0100
	0007:	2001	Next Page Transmit Register	:	0010	0000	0000	0001
	0008:	0000	Link Partner Next page Registe	:	0000	0000	0000	0000
	0009:	0F00	1000BASE-T Control Register	:	0000	1111	0000	0000
	000A:	0000	1000BASE-T Status Register	:	0000	0000	0000	0000
	000F:	0000	Extended Status Register	:	0000	0000	0000	0000
	0010:	6028	PHY Specific Control Register	:	0110	0000	0010	1000
	0011:	6CC8	PHY Specific Status Register	:	0110	1100	1100	1000
	0012:	0000	Interrupt Enable Register	:	0000	0000	0000	0000
	0013:	0700	PHY Specific Status Register2	:	0000	0111	0000	0000
	0015:	01C0	Receive Error Counter	:	0000	0001	1100	0000
	0016:	0000	Page Address Register	:	0000	0000	0000	0000
	001A:	8040	PHY Specific Control Register2	:	1000	0000	0100	0000

<output truncated>

Command	Description
show controllers	Displays per-interface send and receive statistics read from the
ethernet-controller	hardware, interface internal registers, or port ASIC information.

show interfaces

Use the **show interfaces** privileged EXEC command to display the administrative and operational status of all interfaces or a specified interface.

show interfaces [interface-id | vlan vlan-id] [accounting | capabilities [module number] | counters | description | etherchannel | flowcontrol | stats | status [err-disabled] | switchport [module number] | transceiver [properties | detail] [module number] | trunk] [| {begin | exclude | include} expression]

Syntax Description

interface-id	(Optional) Valid interfaces include physical ports (including type, module, and port number) and port channels. The port-channel range is 1 to 48.
vlan vlan-id	(Optional) VLAN identification. The range is 1 to 4094.
accounting	(Optional) Display accounting information on the interface, including active protocols and input and output packets and octets.
capabilities	(Optional) Display the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
module number	(Optional) Display capabilities , switchport configuration, or transceiver characteristics (depending on preceding keyword) of all interfaces on the switch. The only valid module number is 1. This option is not available if you have entered a specific interface ID.
counters	(Optional) See the show interfaces counters command.
description	(Optional) Display the administrative status and description set for an interface.
etherchannel	(Optional) Display interface EtherChannel information.
flowcontrol	(Optional) Display interface flowcontrol information
stats	(Optional) Display the input and output packets by switching path for the interface.
status	(Optional) Display the status of the interface. A status of <i>unsupported</i> in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.
err-disabled	(Optional) Display interfaces in error-disabled state.
switchport	(Optional) Display the administrative and operational status of a switching port, including port blocking and port protection settings.
transceiver [detail properties]	(Optional) Display the physical properties of a coarse wavelength-division multiplexer (CWDM) or dense wavelength-division multiplexer (DWDM) small form-factor (SFP) module interface. The keywords have these meanings:
	• detail —(Optional) Display calibration properties, including high and low numbers and any alarm information.
	• properties —(Optional) Display speed and duplex settings on an interface.
trunk	Display interface trunk information. If you do not specify an interface, only information for active trunking ports appears.
begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .

include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.



Though visible in the command-line help strings, the backup, crb, fair-queue, irb, mac-accounting, precedence, private-vlan mapping, pruning random-detect, rate-limit, and shape keywords are not supported.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The **show interfaces capabilities** command with different keywords has these results:

- Use the **show interface capabilities module 1** to display the capabilities of all interfaces on the switch. Entering any other number is invalid.
- Use the **show interfaces** *interface-id* **capabilities** to display the capabilities of the specified interface.
- Use the **show interfaces capabilities** (with no module number or interface ID) to display the capabilities of all interfaces on the switch.
- Use the **show interface switchport module 1** to display the switch port characteristics of all interfaces on the switch. Entering any other number is invalid.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show interfaces** command for an interface:

```
Switch# show interfaces gigabitethernet0/2
```

```
GigabitEthernet0/2 is down, line protocol is down
  Hardware is Gigabit Ethernet, address is 0009.43a7.d085 (bia 0009.43a7.d085)
 MTU 1500 bytes, BW 10000 Kbit, DLY 1000 usec,
    reliability 255/255, txload 1/255, rxload 1/255
  Encapsulation ARPA, loopback not set
  Keepalive set (10 sec)
  Auto-duplex, Auto-speed
  input flow-control is off, output flow-control is off
  ARP type: ARPA, ARP Timeout 04:00:00 Last input never, output never, output hang never
  Last clearing of "show interface" counters never
  Input queue: 0/75/0/0 (size/max/drops/flushes); Total output drops: 0
  Queueing strategy: fifo
  Output queue :0/40 (size/max)
  5 minute input rate 0 bits/sec, 0 packets/sec
  5 minute output rate 0 bits/sec, 0 packets/sec
     2 packets input, 1040 bytes, 0 no buffer
    Received 0 broadcasts, 0 runts, 0 giants, 0 throttles
     0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored
```

```
0 watchdog, 0 multicast, 0 pause input
0 input packets with dribble condition detected
4 packets output, 1040 bytes, 0 underruns
0 output errors, 0 collisions, 3 interface resets
0 babbles, 0 late collision, 0 deferred
O lost carrier, O no carrier, O PAUSE output
O output buffer failures, O output buffers swapped out
```

This is an example of output from the **show interfaces accounting** command.

Switch# show interfaces accounting

Vlan1

	Protocol	Pkts In	Chars In	Pkts Out	Chars Out
	IP	1094395	131900022	559555	84077157
Spann	ning Tree	283896	17033760	42	2520
	ARP	63738	3825680	231	13860
Interface Vlan2	is disabled				
Vlan7					
	Protocol	Pkts In	Chars In	Pkts Out	Chars Out
No traffic sent	or received	on this	interface.		
Vlan31					
	Protocol	Pkts In	Chars In	Pkts Out	Chars Out
No traffic sent	or received	on this	interface.		
GigabitEthernet(0/1				
	Protocol	Pkts In	Chars In	Pkts Out	Chars Out
No traffic sent	or received	on this	interface.		
GigabitEthernet(0/2				
	Protocol	Pkts In	Chars In	Pkts Out	Chars Out

<output truncated>

This is an example of output from the show interfaces capabilities command for an interface.

Switch# show interfaces gigabitethernet0/2 capabilities

GigabitEthernet0/2

Model: ME-2400-24T-FA Type: 10/100/1000BaseTX SFP Speed: 10,100,1000,auto Duplex: half, full, auto

No traffic sent or received on this interface.

Trunk encap. type: 802.10

on, off, desirable, nonegotiate Trunk mode:

yes Channel:

Broadcast suppression: percentage(0-100)

Flowcontrol: rx-(off,on,desired),tx-(none)

Fast Start:

QoS scheduling: rx-(not configurable on per port basis),tx-(4q2t)

CoS rewrite: yes ToS rewrite: ves UDLD: yes

SPAN: source/destination

PortSecure: yes Dot1x: yes This is an example of output from the **show interfaces** *interface* **description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command.

```
{\tt Switch\#\ show\ interfaces\ gigabitethernet0/2\ description}
```

```
Interface Status Protocol Description
Gi0/2 up down Connects to Marketing
```

This is an example of output from the **show interfaces etherchannel** command when port channels are configured on the switch:

```
Switch# show interfaces etherchannel
Port-channel1:
Age of the Port-channel = 03d:20h:17m:29s
Logical slot/port = 10/1 Number of ports = 0
                 = 0 \times 000000000
                                   HotStandBy port = null
Port state
                  = Port-channel Ag-Not-Inuse
Port-channel2:
Age of the Port-channel = 03d:20h:17m:29s
Logical slot/port = 10/2 Number of ports = 0
                  = 0 \times 000000000
                                  HotStandBy port = null
Port state
                  = Port-channel Ag-Not-Inuse
Port-channel3:
Age of the Port-channel = 03d:20h:17m:29s
                                 Number of ports = 0
HotStandBy port = null
Logical slot/port = 10/3
GC
                   = 0x00000000
Port state
                   = Port-channel Ag-Not-Inuse
```

This is an example of output from the **show interfaces stats** command for a specified VLAN interface.

Switch# show interfaces vlan 1 stats

Switching path	Pkts In	Chars In I	Pkts Out C	hars Out
Processor	1165354	136205310	570800	91731594
Route cache	C	0	C	0
Total	1165354	136205310	570800	91731594

This is an example of partial output from the **show interfaces status** command. It displays the status of all interfaces.

Switch# show interfaces stat	tus			
Port Name	Status	Vlan	Duplex	Speed Type
Fa0/1	connected	1	a-full	a-100 10/100BaseTX
Fa0/2	connected	1	a-full	a-100 10/100BaseTX
Fa0/3	notconnect	1	auto	auto 10/100BaseTX
Fa0/4	disabled	1	auto	auto 10/100BaseTX
Fa0/5	disabled	1	auto	auto 10/100BaseTX
Fa0/6	disabled	1	auto	auto 10/100BaseTX
Fa0/7	disabled	1	auto	auto 10/100BaseTX
Fa0/8	disabled	1	auto	auto 10/100BaseTX
Fa0/9	disabled	1	auto	auto 10/100BaseTX
Fa0/10	disabled	1	auto	auto 10/100BaseTX
Fa0/11	disabled	1	auto	auto 10/100BaseTX
Fa0/12	disabled	1	auto	auto 10/100BaseTX
Fa0/13	disabled	1	auto	auto 10/100BaseTX
Fa0/14	disabled	1	auto	auto 10/100BaseTX
Fa0/15	disabled	1	auto	auto 10/100BaseTX
Fa0/16	disabled	1	auto	auto 10/100BaseTX
Fa0/17	disabled	1	auto	auto 10/100BaseTX
Fa0/18	disabled	1	auto	auto 10/100BaseTX
Fa0/19	disabled	1	auto	auto 10/100BaseTX
Fa0/20	disabled	1	auto	auto 10/100BaseTX

Fa0/21	disabled	1	auto	auto	10/100BaseTX
Fa0/22	disabled	1	auto	auto	10/100BaseTX
Fa0/23	disabled	1	auto	auto	10/100BaseTX
Fa0/24	disabled	1	auto	auto	10/100BaseTX
Gi0/1	notconnect	1	auto	auto	10/100/1000Ba
seTX SFP					
Gi0/2	notconnect	1	auto	auto	Not Present

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25.

Switch# show interfaces fastethernet0/22 status

Port	Name	Status	Vlan	Duplex	Speed Type
Fa0/22		connected	20.25	a-full	a-100 10/100BaseTX

In this example, port 2 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20.

Switch# show interfaces gigabitethernet0/2 status

Port	Name	Status	Vian	риртех	speed	Type
Gi0/2		connected	20	a-full	a-100	10/100/1000BaseTX

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state.

Switch# show interfaces status err-disabled

Port	Name	Status	Reason
Gi0/2		err-disabled	dtp-flap

This is an example of output from the **show interfaces switchport** command for a single port. Table 2-10 describes the fields in the display.



Private VLAN trunks are not supported in this release, so those fields are not applicable.

Switch# show interfaces gigabitethernet0/1 switchport

Name: Gi0/1

Switchport: Enabled

Administrative Mode: static access Operational Mode: static access

Administrative Trunking Encapsulation: dot1q Operational Trunking Encapsulation: native

Negotiation of Trunking: Off Access Mode VLAN: 1 (default)

Trunking Native Mode VLAN: 1 (default) Administrative Native VLAN tagging: enabled

Administrative private-vlan host-association: none

Administrative private-vlan mapping: none

Administrative private-vlan trunk native VLAN: none

Administrative private-vlan trunk Native VLAN tagging: enabled

Administrative private-vlan trunk encapsulation: dot1q Administrative private-vlan trunk normal VLANs: none Administrative private-vlan trunk private VLANs: none

Operational private-vlan: none Trunking VLANs Enabled: ALL

Capture Mode Disabled
Capture VLANs Allowed: ALL

Unknown unicast blocked: disabled Unknown multicast blocked: disabled

Appliance trust: none

```
Administrative Native VLAN tagging: enabled
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dotlq
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk private VLANs: none
Operational private-vlan: none
Trunking VLANs Enabled: ALL
Capture Mode Disabled
Capture VLANs Allowed: ALL
Unknown unicast blocked: disabled
Unknown multicast blocked: disabled
Appliance trust: none
```

Table 2-10 show interfaces switchport Field Descriptions

Field	Description
Name	Displays the port name.
Switchport	Displays the administrative and operational status of the port. In this display, the port is in switchport mode.
Administrative Mode	Displays the administrative and operational modes.
Operational Mode	
Administrative Trunking Encapsulation	Displays the administrative and operational encapsulation method and whether trunking negotiation is enabled.
Negotiation of Trunking	
Access Mode VLAN	Displays the VLAN ID to which the port is configured.
Trunking Native Mode VLAN	Lists the VLAN ID of the trunk that is in native mode.
Administrative Native VLAN tagging	Displays whether or not VLAN tagging is enabled.
Administrative private-vlan host-association	Displays the administrative VLAN association for private-VLAN host ports.
Administrative private-vlan mapping	Displays the administrative VLAN mapping for private-VLAN promiscuous ports.
Operational private-vlan	Displays the operational private-VLAN status.
Trunking VLANs enabled	Lists the active VLANs on the trunk.
Capture VLANs allowed	Lists the allowed VLANs on the trunk.
Unknown unicast blocked Unknown multicast blocked	Displays whether or not unknown multicast and unknown unicast traffic is blocked on the interface.

This is an example of output from the **show interfaces switchport** command for a port configured as a private VLAN promiscuous port. The primary VLAN 20 is mapped to secondary VLANs 25, 30 and 35:

```
Switch# show interface gigabitethernet0/2 switchport
Name: Gi1/0/2
Switchport: Enabled
Administrative Mode: private-vlan promiscuous
Operational Mode: private-vlan promiscuous
Administrative Trunking Encapsulation: negotiate
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Administrative private-vlan host-association: none
Administrative private-vlan mapping: 20 (VLAN0020) 25 (VLAN0025) 30 (VLAN0030) 35
(VLAN0035)
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dot1q
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk private VLANs: none
Operational private-vlan:
20 (VLAN0020) 25 (VLAN0025)
30 (VLAN0030)
35 (VLAN0035)
<output truncated>
```

This is an example of output from the **show interfaces** *interface-id* **trunk** command. It displays trunking information for the port.

Switch# show	interfaces gi	gabitethernet0/	1 trunk	
Port	Mode	Encapsulation	Status	Native vlan
Gi0/1	auto	negotiate	trunking	1
Port Gi0/1	Vlans allowe 1-4094	d on trunk		
Port Gi0/1	Vlans allowe 1-4	d and active in	management do	main
Port Gi0/1	Vlans in spa 1-4	nning tree forw	arding state a	nd not pruned

This is an example of output from the **show interfaces transceiver properties** command. If you do not specify an interface, the output of the command shows the status on all switch ports:

Switch# show interfaces transceiver properties

Name: Fa0/1 Administrative Speed: auto Administrative Duplex: auto Administrative Auto-MDIX: on Administrative Power Inline: N/A Operational Speed: 100 Operational Duplex: full

Operational Auto-MDIX: on

Name: Fa0/2 Administrative Speed: auto Administrative Duplex: auto Administrative Auto-MDIX: on Administrative Power Inline: N/A Operational Speed: 100 Operational Duplex: full Operational Auto-MDIX: on

<output truncated>

Command	Description
switchport access vlan	Configures a port as a static-access or a dynamic-access port.
switchport block	Blocks unknown unicast or multicast traffic on an interface.
switchport mode	Configures the VLAN membership mode of a port.
switchport mode private-vlan	Configures a port as a private-VLAN host or a promiscuous port.
switchport mode private-vlan	Defines private-VLAN association for a host port or private-VLAN mapping for a promiscuous port.

show interfaces counters

Use the **show interfaces counters** privileged EXEC command to display various counters for the switch or for a specific interface.

show interfaces [interface-id | vlan vlan-id] **counters** [**errors** | **trunk**] [**module** switch- number] | **etherchannel** | **protocol status**] [| {**begin** | **exclude** | **include**} expression]

Syntax Description

interface-id	(Optional) ID of the physical interface, including type, module, and port number.		
errors	(Optional) Display error counters.		
trunk	(Optional) Display trunk counters.		
module switch- number	Note (Optional) Display counters for the specified switch number. The only available value is 1.		
etherchannel	(Optional) Display EtherChannel counters, including octets, broadcast packets, multicast packets, and unicast packets received and sent.		
protocol status	(Optional) Display status of protocols enabled on interfaces.		
begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
include	(Optional) Display includes lines that match the specified expression.		
expression	Expression in the output to use as a reference point.		



Though visible in the command-line help string, the **vlan** vlan-id keyword is not supported.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you do not enter any keywords, all counters for all interfaces are included.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of partial output from the **show interfaces counters** command. It displays all counters for the switch.

Switch# show interfaces counters Port InOctets InUcastPkts InMcastPkts InBcastPkts Fa0/1 0 0 0 0 0 0 0 0 Fa0/2

<output truncated>

This is an example of partial output from the **show interfaces counters protocol status** command for all interfaces.

```
Switch# show interfaces counters protocol status
Protocols allocated:
Vlan1: Other, IP
Vlan20: Other, IP, ARP
Vlan30: Other, IP, ARP
Vlan40: Other, IP, ARP
Vlan50: Other, IP, ARP
Vlan60: Other, IP, ARP
Vlan70: Other, IP, ARP
Vlan80: Other, IP, ARP
Vlan90: Other, IP, ARP
Vlan900: Other, IP, ARP
Vlan3000: Other, IP
Vlan3500: Other, IP
FastEthernet0/1: Other, IP, ARP, CDP
FastEthernet0/2: Other, IP
FastEthernet0/3: Other, IP
FastEthernet0/4: Other, IP
 FastEthernet0/5: Other, IP
 FastEthernet0/6: Other, IP
FastEthernet0/7: Other, IP
FastEthernet0/8: Other, IP
FastEthernet0/9: Other, IP
FastEthernet0/10: Other, IP, CDP
```

This is an example of output from the **show interfaces counters trunk** command. It displays trunk counters for all interfaces.

Switch#	show interfaces co	unters trunk	
Port	TrunkFramesTx	TrunkFramesRx	WrongEncap
Gi0/1	0	0	0
Gi0/2	0	0	0
Gi0/3	80678	4155	0
Gi0/4	82320	126	0
Gi0/5	0	0	0

<output truncated>

<output truncated>

Command	Description
show interfaces	Displays additional interface characteristics.

show inventory

Use the **show inventory** user EXEC command to display all field replaceable units—chassis and small form-factor pluggable (SFP) modules.

show inventory [raw] [| {begin | exclude | include} expression]

Syntax Description

raw	(Optional) Display every entity in the device.					
begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
exclude	(Optional) Display excludes lines that match the expression.					
include	(Optional) Display includes lines that match the specified expression.					
expression	Expression in the output to use as a reference point.					

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The command is case sensitive. With no arguments, the **show inventory** command produces a compact dump of all identifiable entities that have a product identifier (PID).

The compact dump displays the entity location (slot identity), entity description, and the unique device identifier (UDI) (PID, VID, and SN) of that entity.

Many legacy SFPs are not programmed with PIDs and VID.s



If there is no PID, no output appears when you enter the **show inventory** command.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is example output from the **show inventory** command:

```
Switch> show inventory

NAME: "1", DESCR: "ME-2400-24TS-A"

PID: ME-2400-24TS-A , VID:Vo1 , SN: FHH0914002G

NAME: "GigabitEthernet0/1", DESCR: "100BaseBX-10U SFP"

PID: , VID: , SN: NEC08440067

NAME: "GigabitEthernet0/2", DESCR: "10/100/1000BaseTX SFP"

PID: , VID: , SN: 00000MTC0839048G
```

show ip dhcp snooping

Use the **show ip dhcp snooping** user EXEC command to display the DHCP snooping configuration.

show ip dhcp snooping [| {begin | exclude | include} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
exclude	(Optional) Display excludes lines that match the expression.					
include	(Optional) Display includes lines that match the specified expression.					
expression	Expression in the output to use as a reference point.					

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This is an example of output from the **show ip dhcp snooping** command.

Switch> show ip dhcp snooping

Switch DHCP snooping is enabled DHCP snooping is configured on following VLANs:

40-42

Insertion of option 82 is enabled Option 82 on untrusted port is allowed Verification of hwaddr field is enabled

Interface Trusted Rate limit (pps)

GigabitEthernet0/1 yes unlimited GigabitEthernet0/2 yes unlimited

Command	Description			
show ip dhcp snooping binding	Displays the DHCP snooping binding information.			

show ip dhcp snooping binding

Use the **show ip dhcp snooping binding** user EXEC command to display the DHCP snooping binding database and configuration information for all interfaces on a switch.

show ip dhcp snooping binding [ip-address] [mac-address] [**interface** interface-id] [**vlan** vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

ip-address	(Optional) Specify the binding entry IP address.			
mac-address	(Optional) Specify the binding entry MAC address.			
interface interface-id	(Optional) Specify the binding input interface.			
vlan vlan-id	(Optional) Specify the binding entry VLAN.			
begin	Display begins with the line that matches the <i>expression</i> .			
exclude	Display excludes lines that match the <i>expression</i> .			
include	Display includes lines that match the specified expression.			
expression	Expression in the output to use as a reference point.			

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The show ip dhcp snooping binding command output shows the dynamically configured bindings.

If DHCP snooping is enabled and an interface changes to the down state, the switch does not delete the statically configured bindings.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This example shows how to display the DHCP snooping binding entries for a switch:

Switch>	show	ip	dhcp	snooping	binding
---------	------	----	------	----------	---------

MacAddress	IpAddress	Lease(sec)	Type	VLAN	Interface	
01:02:03:04:05:06	10.1.2.150	9837	dhcp-snooping	20	GigabitEthernet0/1	
00:D0:B7:1B:35:DE	10.1.2.151	237	dhcp-snooping	20	GigabitEthernet0/2	
Total number of bindings: 2						

This example shows how to display the DHCP snooping binding entries for a specific IP address:

Switch> show ip dho	p snooping bindin	g 10.1.2.150			
MacAddress	IpAddress	Lease(sec)	Type	VLAN	Interface
01:02:03:04:05:06	10.1.2.150	9810	dhcp-snooping	20	GigabitEthernet0/1
Total number of bir	ndinas: 1				

This example shows how to display the DHCP snooping binding entries for a specific MAC address:

Switch> show ip dho	p snooping bindin	g 0102.0304.	0506		
MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
01:02:03:04:05:06	10.1.2.150	9788	dhcp-snooping	20	GigabitEthernet0/2
Total number of bin	dings: 1				

This example shows how to display the DHCP snooping binding entries on a port:

Switch> show ip dho	p snooping bindir	ng interface	gigabitethernet	0/2	
MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
00:30:94:C2:EF:35	10.1.2.151	290	dhcp-snooping	20	GigabitEthernet0/2
Total number of bindings: 1					

This example shows how to display the DHCP snooping binding entries on VLAN 20:

Switch> show ip dh o	p snooping binding IpAddress	ng vlan 20 Lease(sec)	Туре	VLAN	Interface
01:02:03:04:05:06 00:00:00:00:00:02	10.1.2.150 10.1.2.151	9747 65	dhcp-snooping dhcp-snooping		GigabitEthernet0/1 GigabitEthernet0/2
Total number of bin	ndings: 2				

Table 2-11 describes the fields in the **show ip dhcp snooping binding** command output:

Table 2-11 show ip dhcp snooping binding Command Output

Field	Description	
MacAddress	Client hardware MAC address	
IpAddress	Client IP address assigned from the DHCP server	
Lease(sec)	Remaining lease time for the IP address	
Туре	Binding type	
VLAN	VLAN number of the client interface	
Interface	Interface that connects to the DHCP client host	
Total number of bindings	Total number of bindings configured on the switch	
	Note The command output might not show the total number of bindings. For example, if 200 bindings are configured on the switch and you stop the display before all the bindings appear, the total number does not change.	

Command	Description
ip dhcp snooping binding	Configures the DHCP snooping binding database
show ip dhcp snooping	Displays the DHCP snooping configuration.

show ip dhcp snooping database

Use the **show ip dhcp snooping database** user EXEC command to display the status of the DHCP snooping binding database agent.

show ip dhcp snooping database [detail] [| {begin | exclude | include}} expression]

Syntax Description

detail	(Optional) Display detailed status and statistics information.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Examples

This is an example of output from the **show ip dhcp snooping database** command:

```
Switch> show ip dhcp snooping database
Agent URL :
Write delay Timer: 300 seconds
Abort Timer: 300 seconds
Agent Running: No
Delay Timer Expiry: Not Running
Abort Timer Expiry: Not Running
Last Succeded Time : None
Last Failed Time : None
Last Failed Reason : No failure recorded.
Total Attempts :
                           0
                               Startup Failures :
                                                         0
Successful Transfers :
                         0
                               Failed Transfers :
Successful Reads :
                               Failed Reads :
Failed Writes :
                            0
                          0
Successful Writes
Media Failures
```

This is an example of output from the **show ip dhcp snooping database detail** command:

```
Switch# show ip dhcp snooping database detail
Agent URL: tftp://10.1.1.1/directory/file
Write delay Timer : 300 seconds
Abort Timer: 300 seconds
Agent Running: No
Delay Timer Expiry: 7 (00:00:07)
Abort Timer Expiry : Not Running
Last Succeded Time : None
Last Failed Time: 17:14:25 UTC Sat Jul 7 2001
Last Failed Reason : Unable to access URL.
Total Attempts
                         21 Startup Failures :
                                                       Ω
Successful Transfers :
                         0 Failed Transfers:
                                                      21
Successful Reads :
                          0 Failed Reads :
Successful Writes
                          O Failed Writes :
                                                       21
Media Failures
                          0
First successful access: Read
Last ignored bindings counters :
Binding Collisions : 0
                                Expired leases
                                                         0
                           0
Invalid interfaces
                    :
                                                         0
                                Unsupported vlans :
Parse failures
                   :
Last Ignored Time : None
Total ignored bindings counters:
Binding Collisions : 0
                                Expired leases
                                                         0
Invalid interfaces : 0
Parse failures : 0
                                Unsupported vlans :
```

Command	Description
ip dhcp snooping	Enables DHCP snooping on a VLAN.
ip dhcp snooping database	Configures the DHCP snooping binding database agent or the binding file.
show ip dhcp snooping	Displays DHCP snooping information.

show ip igmp profile

Use the **show ip igmp profile** privileged EXEC command to display all configured Internet Group Management Protocol (IGMP) profiles or a specified IGMP profile.

show ip igmp profile [profile number] [| { begin | exclude | include} | expression]

Syntax Description

profile number	(Optional) The IGMP profile number to be displayed. The range is 1 to 4294967295. If no profile number is entered, all IGMP profiles are displayed.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

These are examples of output from the **show ip igmp profile** privileged EXEC command, with and without specifying a profile number. If no profile number is entered, the display includes all profiles configured on the switch.

```
Switch# show ip igmp profile 40

IGMP Profile 40

permit

range 233.1.1.1 233.255.255.255

Switch# show ip igmp profile

IGMP Profile 3

range 230.9.9.0 230.9.9.0

IGMP Profile 4

permit

range 229.9.9.0 229.255.255.255
```

Command	Description
ip igmp profile	Configures the specified IGMP profile number.

show ip igmp snooping

Use the **show ip igmp snooping** user EXEC command to display the Internet Group Management Protocol (IGMP) snooping configuration of the switch or the VLAN.

show ip igmp snooping [groups | mrouter | querier [vlan vlan-id] [detail]] [vlan vlan-id] [detail] [| {begin | exclude | include} | expression]

Syntax Description

groups	(Optional) See the show ip igmp snooping groups command.	
mrouter	(Optional) See the show ip igmp snooping mrouter command.	
querier	(Optional) See the show ip igmp snooping querier command.	
vlan vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094 (available only in privileged EXEC mode).	
begin	(Optional) Display begins with the line that matches the expression.	
l exclude	(Optional) Display excludes lines that match the expression.	
l include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification	
12.2(25)EX	This command was introduced.	

Usage Guidelines

Use this command to display snooping configuration for the switch or for a specific VLAN.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

Although visible in the output display, output lines for source-only learning are not valid.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show ip igmp snooping vlan 1** command. It shows snooping characteristics for a specific VLAN.

```
Switch# show ip igmp snooping vlan 1
Global IGMP Snooping configuration:

IGMP snooping :Enabled
IGMPv3 snooping (minimal) :Enabled
Report suppression :Enabled
TCN solicit query :Disabled
TCN flood query count :2
Last member query interval : 100
```

```
Vlan 1:
-----
IGMP snooping :Enabled
Immediate leave :Disabled
Multicast router learning mode :pim-dvmrp
Source only learning age timer :10
CGMP interoperability mode :IGMP_ONLY
Last member query interval : 100
```



Source-only learning are not supported, and information appearing for this feature is not valid.

This is an example of output from the **show ip igmp snooping** command. It displays snooping characteristics for all VLANs on the switch.

```
Switch> show ip igmp snooping
Global IGMP Snooping configuration:
IGMP snooping : Enabled
IGMPv3 snooping (minimal) : Enabled
Report suppression : Enabled
                        : Disabled
TCN solicit query
TCN flood query count : 2
Last member query interval : 100
Vlan 1:
IGMP snooping
                                 :Enabled
Immediate leave
                                 :Disabled
Multicast router learning mode
                                :pim-dvmrp
Source only learning age timer
                                :10
                                :IGMP_ONLY
CGMP interoperability mode
Last member query interval
                                 : 100
Vlan 2:
IGMP snooping
                                 :Enabled
Immediate leave
                                 :Disabled
Multicast router learning mode
                                :pim-dvmrp
Source only learning age timer
                                 :10
CGMP interoperability mode
                                 : IGMP_ONLY
Last member query interval
                                 : 333
<output truncated>
```

Command	Description		
ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.		
show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.		
show ip igmp snooping querier	Displays the configuration and operation information for the IGMP querier configured on a switch.		

show ip igmp snooping groups

Use the **show ip igmp snooping groups** privileged EXEC command to display the Internet Group Management Protocol (IGMP) snooping multicast table for the switch or the multicast information. Use with the **vlan** keyword to display the multicast table for a specified multicast VLAN or specific multicast information.

show ip igmp snooping groups [count | dynamic [count] | user [count]] [| {begin | exclude | include} | expression]

show ip igmp snooping groups vlan vlan-id [ip_address | count | dynamic [count] | user [count]] [| {begin | exclude | include} | expression]

Syntax Description

count	(Optional) Display the total number of entries for the specified command options instead of the actual entries.	
dynamic	(Optional) Display entries learned by IGMP snooping.	
user	Optional) Display only the user-configured multicast entries.	
ip_address	(Optional) Display characteristics of the multicast group with the specified group IP address.	
vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.	
begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the expression.	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use this command to display multicast information or the multicast table.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show ip igmp snooping groups** command without any keywords. It displays the multicast table for the switch.

Switch# show ip igmp snooping groups

Vlan	Group	Type	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Gi0/2
104	224.1.4.3	igmp	v2	Gi0/1, Gi0/2

This is an example of output from the **show ip igmp snooping groups count** command. It displays the total number of multicast groups on the switch.

Switch# show ip igmp snooping groups count Total number of multicast groups: 2

This is an example of output from the **show ip igmp snooping groups dynamic** command. It shows only the entries learned by IGMP snooping.

Switch# show ip igmp snooping groups vlan 1 dynamic

Vlan	Group	Type	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Fa0/15
104	224.1.4.3	igmp	v2	Gi0/1, Fa0/15

This is an example of output from the **show ip igmp snooping groups vlan** *vlan-id ip-address* command. It shows the entries for the group with the specified IP address.

Switch# show ip igmp snooping groups vlan 104 224.1.4.2

Vlan	Group	Type	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Fa0/15

Command	Description
ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.
show ip igmp snooping	Displays the IGMP snooping configuration of the switch or the VLAN.
show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.

show ip igmp snooping mrouter

Use the **show ip igmp snooping mrouter** privileged EXEC command to display the Internet Group Management Protocol (IGMP) snooping dynamically learned and manually configured multicast router ports for the switch or for the specified multicast VLAN.

show ip igmp snooping mrouter [vlan vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

vlan vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification	
12.2(25)EX	This command was introduced.	

Usage Guidelines

Use this command to display multicast router ports on the switch or for a specific VLAN.

VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.

When multicast VLAN registration (MVR) is enabled, the **show ip igmp snooping mrouter** command displays MVR multicast router information and IGMP snooping information.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show ip igmp snooping mrouter** command. It shows how to display multicast router ports on the switch.

```
Switch# show ip igmp snooping mrouter
Vlan ports
----
1 Gi0/1(dynamic)
```

Command	Description		
ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.		
ip igmp snooping vlan mrouter	Adds a multicast router port to a multicast VLAN.		
show ip igmp snooping	Displays the IGMP snooping configuration of the switch or the VLAN		
show ip igmp snooping groups	Displays IGMP snooping multicast information for the switch or for the specified parameter.		

show ip igmp snooping querier

Use the **show ip igmp snooping querier** user EXEC command to display the IP address and incoming port for the Internet Group Management Protocol (IGMP) query most recently received by the switch.

show ip igmp snooping querier [vlan vlan-id] [detail] [| {begin | exclude | include} | expression]

Syntax Description

vlan vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.	
detail (Optional) Display querier information as well as configuration and operatinformation pertaining to the querier.		
begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the expression.	
include	include (Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use the **show ip igmp snooping querier** command to display the IGMP version and IP address of a detected device (also called a *querier*) that sends IGMP query message. A subnet can have multiple multicast routers but has only one IGMP querier. In a subnet running IGMPv2, one of the multicast routers is elected as the querier. The querier can be a Layer 3 switch.

The **show ip igmp snooping querier** command output also shows the VLAN and interface on which the querier was detected. If the querier is the switch, the output shows the *Port* field as *Router*. If the querier is a router, the output shows the port number on which the querier is learned in the *Port* field.

The **show ip igmp snooping querier detail** user EXEC command is similar to the **show ip igmp snooping querier** command. However, the **show ip igmp snooping querier detail** command displays the IP address of the most recent device detected by the switch querier along with this additional information:

- The elected IGMP querier in the VLAN
- The configuration and operational information pertaining to the switch querier (if any) that is configured in the VLAN

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show ip igmp snooping querier** command:

Switch> show ip igmp snooping querier

Vlan	IP Address	IGMP Version	Port
1	172.20.50.11	v3	Gi0/1
2	172.20.40.20	v2	Router

This is an example of output from the show ip igmp snooping querier detail command:

Switch> show ip igmp snooping querier detail

V	lan	IP Address	IGMP V∈	ersion	Port
1		1.1.1.1	v2		Fa0/1
Global IGMP switch querier		er statu	ıs		
admin state		:	Enable	d	
admin version		:	2		
s	ource IP	address	:	0.0.0.	0
q	uery-inte	erval (sec)	:	60	

max-response-time (sec) : 10 querier-timeout (sec) : 120 tcn query count : 2 tcn query interval (sec) : 10

Vlan 1: IGMP switch querier status

_____ elected querier is 1.1.1.1 on port Fa0/1

admin state : Enabled

: 2 source IP address : 10.1.1.65 query-interval (sec) : 60 max-response-time (sec) : 10 querier-timeout (sec) : 120 : 10 tcn query count : 2

tcn query interval (sec) : 10
operational state : Nor
operational version : 2 : Non-Querier

: 2 tcn query pending count : 0

Command	Description
ip igmp snooping querier	Enables and configures the IGMP snooping querier on the switch or on a VLAN.
show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.

show lacp

Use the **show lacp** user EXEC command to display Link Aggregation Control Protocol (LACP) channel-group information.

show lacp [channel-group-number] {**counters** | **internal** | **neighbor** | **sys-id**} [| {**begin** | **exclude** | **include**} expression]



LACP is available only on network node interfaces (NNIs).

Syntax Description

channel-group-number	(Optional) Number of the channel group. The range is 1 to 48.
counters	Display traffic information.
internal	Display internal information.
neighbor	Display neighbor information.
sys-id	Display the system identifier that is being used by LACP. The system identifier is made up of the LACP system priority and the switch MAC address.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You can enter any **show lacp** command to display the active channel-group information. To display specific channel information, enter the **show lacp** command with a channel-group number.

If you do not specify a channel group, information for all channel groups appears.

You can enter the *channel-group-number* option to specify a channel group for all keywords except **sys-id**.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show lacp counters** user EXEC command. Table 2-12 describes the fields in the display.

Switch> show lacp counters

	LACP	DUs	Mark	er	Marker R	esponse	LACPDUs
Port	Sent	Recv	Sent	Recv	Sent	Recv	Pkts Err
Channel group	p:1						
Gi0/1	19	10	0	0	0	0	0
Gi0/2	14	6	0	0	0	0	0

Table 2-12 show lacp counters Field Descriptions

Field	Description
LACPDUs Sent and Recv	The number of LACP packets sent and received by a port.
Marker Sent and Recv	The number of LACP marker packets sent and received by a port.
Marker Response Sent and Recv	The number of LACP marker response packets sent and received by a port.
LACPDUs Pkts and Err	The number of unknown and illegal packets received by LACP for a port.

This is an example of output from the **show lacp internal** command:

```
Switch> show lacp 1 internal
Flags: S - Device is requesting Slow LACPDUs
        F - Device is requesting Fast LACPDUs
        A - Device is in Active mode
                                           P - Device is in Passive mode
Channel group 1
                              LACP port
                                             Admin
                                                       Oper
                                                               Port
                                                                        Port
Port
            Flags
                    State
                              Priority
                                             Key
                                                       Key
                                                               Number
                                                                        State
Gi0/1
                              32768
            SA
                    bndl
                                             0x3
                                                       0x3
                                                               0x4
                                                                        0x3D
Gi0/2
            SA
                    bndl
                              32768
                                             0x3
                                                       0x3
                                                               0x5
                                                                        0x3D
```

Table 2-13 describes the fields in the display:

Table 2-13 show lacp internal Field Descriptions

Field	Description	
State	State of the specific port. These are the allowed values:	
	• – —Port is in an unknown state.	
	• bndl —Port is attached to an aggregator and bundled with other ports.	
	• susp —Port is in a suspended state; it is not attached to any aggregator.	
	• hot-sby—Port is in a hot-standby state.	
	• indiv—Port is incapable of bundling with any other port.	
	• indep —Port is in an independent state (not bundled but able to switch data traffic. In this case, LACP is not running on the partner port).	
	• down—Port is down.	

Table 2-13 show lacp internal Field Descriptions (continued)

Field	Description		
LACP Port Priority	Port priority setting. LACP uses the port priority to put ports in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.		
Admin Key	Administrative key assigned to this port. LACP automatically generates an administrative key value as a hexadecimal number. The administrative key defines the ability of a port to aggregate with other ports. A port's ability to aggregate with other ports determined by the port physical characteristics (for example, data rate and duplex capability) and configuration restrictions that you establish.		
Oper Key	Runtime operational key that is being used by this port. LACP automatically generates this value as a hexadecimal number.		
Port Number	Port number.		
Port State	State variables for the port, encoded as individual bits within a single octet with these meanings:		
	bit0: LACP_Activity		
	• bit1: LACP_Timeout		
	• bit2: Aggregation		
	• bit3: Synchronization		
	• bit4: Collecting		
	• bit5: Distributing		
	• bit6: Defaulted		
	• bit7: Expired		
	Note In the above list, bit7 is the MSB and bit0 is the LSB.		

This is an example of output from the **show lacp neighbor** command:

```
Switch> show lacp neighbor
Flags: S - Device is sending Slow LACPDUs F - Device is sending Fast LACPDUs
       A - Device is in Active mode
                                         P - Device is in Passive mode
Channel group 3 neighbors
Partner's information:
         Partner
                                                           Partner
                               Partner
Port
         System ID
                               Port Number
                                                           Flags
                                               Age
Gi0/1
         32768,0007.eb49.5e80 0xC
                                               19s
                                                           SP
         LACP Partner
                              Partner
                                              Partner
         Port Priority
                              Oper Key
                                              Port State
         32768
                                              0x3C
                              0x3
Partner's information:
         Partner
                                                           Partner
                               Partner
         System ID
Port
                               Port Number
                                               Age
                                                           Flags
Gi0/2
         32768,0007.eb49.5e80 0xD
                                                15s
                                                           SP
```

LACP Partner Partner Partner

Port Priority Oper Key Port State
32768 0x3 0x3C

This is an example of output from the **show lacp sys-id** command:

Switch> **show lacp sys-id** 32765,0002.4b29.3a00

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

Command	Description
clear lacp	Clears the LACP channel-group information.
lacp port-priority	Configures the LACP port priority.
lacp system-priority	Configures the LACP system priority.

show mac access-group

Use the **show mac access-group** user EXEC command to display the MAC access control lists (ACLs) configured for an interface or a switch.

show mac access-group [interface interface-id] [| {begin | exclude | include} | expression]

Syntax Description

interface interface-id	(Optional) Display the MAC ACLs configured on a specific interface. Valid interfaces are physical ports and port channels; the port-channel range is 1 to 48 (available only in privileged EXEC mode).
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac-access group** user EXEC command. In this display, Fast Ethernet interface 0/2 has the MAC access list *macl_e1* applied to inbound traffic; no MAC ACLs are applied to other interfaces.

Interface FastEthernet0/1:
 Inbound access-list is macl_e1
 Outbound access-list is not set
Interface FastEthernet0/2:
 Inbound access-list is not set
 Outbound access-list is not set
Interface FastEthernet0/3:
 Inbound access-list is not set
 Outbound access-list is not set
 Outbound access-list is not set
Interface FastEthernet0/4:
 Inbound access-list is not set
 Outbound access-list is not set
 Outbound access-list is not set
Interface FastEthernetv0/5:

Switch> show mac access-group

Inbound access-list is not set
 Outbound access-list is not set
<output truncated>

This is an example of output from the show mac access-group interface fastethernet0/1 command:

Switch# show mac access-group interface fastethernet0/1

Interface FastEthernet0/1:

Inbound access-list is macl_e1

Command	Description
mac access-group	Applies a MAC access group to an interface.

show mac address-table

Use the **show mac address-table** user EXEC command to display a specific MAC address table static and dynamic entry or the MAC address table static and dynamic entries on a specific interface or VLAN.

show mac address-table [| {begin | exclude | include} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac address-table** command:

Switch> show mac address-table

	Mac Address Ta	able	
Vlan	Mac Address	Type	Ports
A11	0000.0000.0001	STATIC	CPU
A11	0000.0000.0002	STATIC	CPU
A11	0000.0000.0003	STATIC	CPU
A11	0000.0000.0009	STATIC	CPU
A11	0000.0000.0012	STATIC	CPU
A11	0180.c200.000b	STATIC	CPU
A11	0180.c200.000c	STATIC	CPU
A11	0180.c200.000d	STATIC	CPU
A11	0180.c200.000e	STATIC	CPU
A11	0180.c200.000f	STATIC	CPU
A11	0180.c200.0010	STATIC	CPU
1	0030.9441.6327	DYNAMIC	Gi0/4
Total	Mac Addresses for	this criteri	on: 12

Command	Description
clear mac address-table dynamic	Deletes from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, or all dynamic addresses on a particular VLAN.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table address

Use the **show mac address-table address** user EXEC command to display MAC address table information for the specified MAC address.

show mac address-table address mac-address [interface interface-id] [vlan vlan-id] [| {begin | exclude | include}} expression]

Syntax Description

mac-address	Specify the 48-bit MAC address; the valid format is H.H.H.	
interface interface-id	(Optional) Display information for a specific interface. Valid interfaces include physical ports and port channels.	
vlan vlan-id	(Optional) Display entries for the specific VLAN only. The range is 1 to 4094.	
begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the expression.	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mac address-table address command:

Switch# show mac address-table address 0002.4b28.c482

Mac Address Table

Vlan Mac Address Type Ports
---- All 0002.4b28.c482 STATIC CPU
Total Mac Addresses for this criterion: 1

Command	Description
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table aging-time

Use the **show mac address-table aging-time** user EXEC command to display the aging time of a specific address table instance, all address table instances on a specified VLAN or, if a specific VLAN is not specified, on all VLANs.

show mac address-table aging-time [vlan vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

vlan vlan-id	(Optional) Display aging time information for a specific VLAN. The range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If no VLAN number is specified, the aging time for all VLANs appears.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mac address-table aging-time command:

Switch> show mac address-table aging-time
Vlan Aging Time
---- 1 300

This is an example of output from the show mac address-table aging-time vlan 10 command:

Switch> show mac address-table aging-time vlan 10
Vlan Aging Time
---- 10 300

Command	Description
mac address-table aging-time	Sets the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated.
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table count

Use the **show mac address-table count** user EXEC command to display the number of addresses present in all VLANs or the specified VLAN.

show mac address-table count [vlan vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

vlan vlan-id	(Optional) Display the number of addresses for a specific VLAN. The range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If no VLAN number is specified, the address count for all VLANs appears.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac address-table count** command:

Switch# show mac address-table count

Command	Description
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table dynamic

Use the **show mac address-table dynamic** user EXEC command to display only dynamic MAC address table entries.

show mac address-table dynamic [address mac-address] [interface interface-id] [vlan vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

address mac-address	(Optional) Specify a 48-bit MAC address; the valid format is H.H.H (available in privileged EXEC mode only).
interface interface-id	(Optional) Specify an interface to match; valid <i>interfaces</i> include physical ports and port channels.
vlan vlan-id	(Optional) Display entries for a specific VLAN; the range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mac address-table dynamic command:

Mac Address Table				
Vlan	Mac Address	Туре	Ports	
1	0030.b635.7862	DYNAMIC	Gi0/2	
1	00b0.6496.2741	DYNAMIC	Gi0/2	
Total	Mac Addresses for	this cr	iterion:	2

Switch> show mac address-table dynamic

Command	Description
clear mac address-table dynamic	Deletes from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, or all dynamic addresses on a particular VLAN.
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table interface

Use the **show mac address-table interface** user command to display the MAC address table information for the specified interface in the specified VLAN.

show mac address-table interface *interface-id* [vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description

interface-id	Specify an interface type; valid interfaces include physical ports and port channels.
vlan vlan-id	(Optional) Display entries for a specific VLAN; the range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac address-table interface** command:

Switch> show mac address-table interface gigabitethernet0/2

Mac Address Table

Vlan Mac Address Type Ports
---- 1 0030.b635.7862 DYNAMIC Gi0/2
1 00b0.6496.2741 DYNAMIC Gi0/2
Total Mac Addresses for this criterion: 2

Command	Description
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table notification

Use the **show mac address-table notification** user EXEC command to display the MAC address notification settings for all interfaces or the specified interface.

show mac address-table notification [interface [interface-id]] [| {begin | exclude | include} expression]

Syntax Description

interface	(Optional) Display information for all interfaces. Valid interfaces include physical ports and port channels.
interface-id	(Optional) Display information for the specified interface. Valid interfaces include physical ports and port channels.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Use the **show mac address-table notification** command without any keywords to display whether the feature is enabled or disabled, the MAC notification interval, the maximum number of entries allowed in the history table, and the history table contents.

Use the **interface** keyword to display the flags for all interfaces. If the *interface-id* is included, only the flags for that interface appear.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mac address-table notification command:

```
MAC Addr: 0000.0000.0001 Module: 0
Operation: Added Vlan: 2
                                                                              Port: 1
History Index 1, Entry Timestamp 1038254, Despatch Timestamp 1038254
MAC Changed Message :
Operation: Added Vlan: 2
                                  MAC Addr: 0000.0000.0000 Module: 0
                                                                               Port: 1
Operation: Added Vlan: 2 MAC Addr: 0000.0000.0002 Module: 0
                                                                               Port: 1
Operation: Added Vlan: 2 MAC Addr: 0000.0000.0003 Module: 0
                                                                               Port: 1
History Index 2, Entry Timestamp 1074254, Despatch Timestamp 1074254
MAC Changed Message :
                                   MAC Addr: 0000.0000.0000 Module: 0
Operation: Deleted Vlan: 2
                                                                               Port: 1
Operation: Deleted Vlan: 2 MAC Addr: 0000.0000.0001 Module: 0
Operation: Deleted Vlan: 2 MAC Addr: 0000.0000.0002 Module: 0
Operation: Deleted Vlan: 2 MAC Addr: 0000.0000.0003 Module: 0
                                                                               Port: 1
                                                                               Port: 1
                                                                               Port: 1
```

Command	Description
clear mac address-table notification	Clears the MAC address notification global counters.
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table static

Use the **show mac address-table static** user EXEC command to display only static MAC address table entries.

show mac address-table static [address mac-address] [interface interface-id] [vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description

address mac-address	(Optional) Specify a 48-bit MAC address; the valid format is H.H.H (available in privileged EXEC mode only).
interface interface-id	(Optional) Specify an interface to match; valid <i>interfaces</i> include physical ports and port channels.
vlan vlan-id	(Optional) Display addresses for a specific VLAN. The range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mac address-table static command:

Switch> show mac address-table static

Mac Address Table Vlan Mac Address Туре Ports A11 0100.0ccc.ccc STATIC CPU 0180.c200.0000 STATIC A11 0100.0ccc.cccd STATIC A11 0180.c200.0001 STATIC CPU 0180.c200.0004 STATIC CPU A11 A11 0180.c200.0005 STATIC 0001.0002.0004 STATIC 6 0001.0002.0007 STATIC Drop Total Mac Addresses for this criterion: 8

Command	Description
mac address-table static	Adds static addresses to the MAC address table.
mac address-table static drop	Enables unicast MAC address filtering and configures the switch to drop traffic with a specific source or destination MAC address.
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table vlan

Use the **show mac address-table vlan** user EXEC command to display the MAC address table information for the specified VLAN.

show mac address-table vlan vlan-id [| {begin | exclude | include}} expression]

Syntax Description

vlan-id	(Optional) Display addresses for a specific VLAN. The range is 1 to 4094.	
begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac address-table vlan 1** command:

Switch>	show	mac	addre	ss-	table	vlan	1
			-		-		

Mac Address Table

Vlan	Mac Address	Type	Ports	
1	0100.0ccc.ccc	STATIC	CPU	
1	0180.c200.0000	STATIC	CPU	
1	0100.0ccc.cccd	STATIC	CPU	
1	0180.c200.0001	STATIC	CPU	
1	0180.c200.0002	STATIC	CPU	
1	0180.c200.0003	STATIC	CPU	
1	0180.c200.0005	STATIC	CPU	
1	0180.c200.0006	STATIC	CPU	
1	0180.c200.0007	STATIC	CPU	
Total	Mac Addresses for	this cr	iterion:	9

Command	Description
show mac address-table address	Displays MAC address table information for the specified MAC address.
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.

show monitor

Use the **show monitor** user EXEC command to display information about all Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) sessions on the switch. Use the command with keywords to show a specific session, all sessions, all local sessions, or all remote sessions.

show monitor [session {session_number | all | local | range list | remote} [detail]] [| {begin | exclude | include} expression]

Syntax Description

session	(Optional) Display information about specified SPAN sessions.	
session_number	Specify the number of the SPAN or RSPAN session. The range is 1 to 66.	
all	Display all SPAN sessions.	
local	Display only local SPAN sessions.	
range list	Display a range of SPAN sessions, where <i>list</i> is the range of valid sessions, either a single session or a range of sessions described by two numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated parameters or in hyphen-specified ranges.	
	Note This keyword is available only in privileged EXEC mode.	
remote	Display only remote SPAN sessions.	
detail	(Optional) Display detailed information about the specified sessions.	
begin	Display begins with the line that matches the <i>expression</i> .	
l exclude	Display excludes lines that match the <i>expression</i> .	
include	Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

The output is the same for the show monitor command and the show monitor session all command.

Examples

This is an example of output for the **show monitor** user EXEC command:

```
Switch# show monitor
Session 1
Type
          :Local Session
Source Ports:
   RX Only:
                Fa0/24
   TX Only: None
Both: Fa0/2
                Fa0/1-2,Fa0/1-5
Destination Ports:Fa0/18
   Encapsulation: Replicate
Session 2
Type
         :Remote Source Session
Source Ports:
Source VLANs:
TX Only: 10
                 1-9
   Both:
Dest RSPAN VLAN: 105
```

This is an example of output for the **show monitor** user EXEC command for RSPAN source session 1:

```
Switch# show monitor session 1
-----
Type :Local Session
Source Ports:
    RX Only: Fa0/24
    TX Only: None
    Both: Fa0/1-2,Fa0/1-5
```

Destination Ports:Fa0/18
Encapsulation:Replicate

This is an example of output for the **show monitor session all** user EXEC command when ingress traffic forwarding is enabled:

```
Switch# show monitor session all
Session 1
                 :Local Session
Type
Source Ports
   rce Ports :
Both :Fa0/2
Destination Ports :Fa0/3
    Encapsulation : Replicate
         Ingress: Enabled, default VLAN = 5
    Ingress encapsulation: DOT1Q
Session 2
Type
                  :Local Session
Source Ports
   Bot.h
                 :Fa0/1
Destination Ports :Fa0/4
    Encapsulation : Replicate
         Ingress:Enabled
    Ingress encapsulation:DOT1Q
```

Command	Description
monitor session	Starts or modifies a SPAN or RSPAN session.

show mvr

Use the **show mvr** privileged EXEC command without keywords to display the current Multicast VLAN Registration (MVR) global parameter values, including whether or not MVR is enabled, the MVR multicast VLAN, the maximum query response time, the number of multicast groups, and the MVR mode (dynamic or compatible).

show mvr [| {begin | exclude | include} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the expression.	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mvr** command:

```
Switch# show mvr
MVR Running: TRUE
MVR multicast VLAN: 1
MVR Max Multicast Groups: 256
MVR Current multicast groups: 0
MVR Global query response time: 5 (tenths of sec)
MVR Mode: compatible
```

In the preceding display, the maximum number of multicast groups is fixed at 256. The MVR mode is either compatible (for interoperability with Catalyst 2900 XL and Catalyst 3500 XL switches) or dynamic (where operation is consistent with IGMP snooping operation and dynamic MVR membership on source ports is supported).

Command	Description
mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.
mvr (interface configuration)	Configures MVR ports.
show mvr interface	Displays the configured MVR interfaces, status of the specified interface, or all multicast groups to which the interface belongs when the interface and members keywords are appended to the command.
show mvr members	Displays all ports that are members of an MVR multicast group or, if there are no members, means the group is inactive.

show myr interface

Use the **show mvr interface** privileged EXEC command without keywords to display the Multicast VLAN Registration (MVR) receiver and source ports. Use the command with keywords to display MVR parameters for a specific receiver port.

show mvr interface [interface-id [members [vlan vlan-id]]] [| {begin | exclude | include} expression]

Syntax Description

interface-id	(Optional) Display MVR type, status, and Immediate Leave setting for the interface.	
	Valid interfaces include physical ports (including type, module, and port number.	
members	(Optional) Display all MVR groups to which the specified interface belongs.	
vlan vlan-id	(Optional) Display all MVR group members on this VLAN. The range is 1 to 4094.	
l begin	(Optional) Display begins with the line that matches the expression.	
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
linclude	(Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If the entered port identification is a non-MVR port or a source port, the command returns an error message. For receiver ports, it displays the port type, per port status, and Immediate-Leave setting.

If you enter the **members** keyword, all MVR group members on the interface appear. If you enter a VLAN ID, all MVR group members in the VLAN appear.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show mvr interface command:

Switch#	show mvr interface		
Port	Type	Status	Immediate Leave
Gi0/1	SOURCE	ACTIVE/UP	DISABLED
Gi0/2	RECEIVER	ACTIVE/DOWN	DISABLED

In the preceding display, Status is defined as follows:

- Active means the port is part of a VLAN.
- Up/Down means that the port is forwarding/nonforwarding.
- Inactive means that the port is not yet part of any VLAN.

This is an example of output from the **show mvr interface** command for a specified port:

```
Switch# show mvr interface gigabitethernet0/2
Type: RECEIVER Status: ACTIVE Immediate Leave: DISABLED
```

This is an example of output from the **show mvr interface** interface-id **members** command:

Switch# show mvr interface gigabitethernet0/2 members 239.255.0.0 DYNAMIC ACTIVE 239.255.0.1 DYNAMIC ACTIVE 239.255.0.2 DYNAMIC ACTIVE 239.255.0.3 DYNAMIC ACTIVE 239.255.0.4 DYNAMIC ACTIVE 239.255.0.5 DYNAMIC ACTIVE 239.255.0.6 DYNAMIC ACTIVE 239.255.0.7 DYNAMIC ACTIVE 239.255.0.8 DYNAMIC ACTIVE 239.255.0.9 DYNAMIC ACTIVE

Command	Description
mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.
mvr (interface configuration)	Configures MVR ports.
show mvr	Displays the global MVR configuration on the switch.
show mvr members	Displays all receiver ports that are members of an MVR multicast group.

show myr members

Use the **show mvr members** privileged EXEC command to display all receiver and source ports that are currently members of an IP multicast group.

show mvr members [ip-address] [| {begin | exclude | include} | expression]

Syntax Description

ip-address	(Optional) The IP multicast address. If the address is entered, all receiver and source ports that are members of the multicast group appear. If no address is entered, all members of all Multicast VLAN Registration (MVR) groups are listed. If a group has no members, the group is listed as Inactive.	
begin	(Optional) Display begins with the line that matches the <i>expression</i> .	
exclude	(Optional) Display excludes lines that match the expression.	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

Privileged EXEC

Command History

Release	Modification	
12.2(25)EX	This command was introduced.	

Usage Guidelines

The **show mvr members** command applies to receiver and source ports. For MVR-compatible mode, all source ports are members of all multicast groups.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mvr members** command:

Switch# show	mvr members	
MVR Group IP	Status	Members
239.255.0.1	ACTIVE	Gi0/1(d), $Gi0/2(s)$
239.255.0.2	INACTIVE	None
239.255.0.3	INACTIVE	None
239.255.0.4	INACTIVE	None
239.255.0.5	INACTIVE	None
239.255.0.6	INACTIVE	None
239.255.0.7	INACTIVE	None
239.255.0.8	INACTIVE	None
239.255.0.9	INACTIVE	None
239.255.0.10	INACTIVE	None

<output truncated>

This is an example of output from the **show mvr members** *ip-address* command. It displays the members of the IP multicast group with that address:

Command	Description
mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.
mvr (interface configuration)	Configures MVR ports.
show mvr	Displays the global MVR configuration on the switch.
show mvr interface	Displays the configured MVR interfaces, status of the specified interface, or all multicast groups to which the interface belongs when the members keyword is appended to the command.

show pagp

Use the **show pagp** user EXEC command to display Port Aggregation Protocol (PAgP) channel-group information.

show pagp [channel-group-number] {counters | internal | neighbor} [| {begin | exclude | include} | expression]]



PAgP is available only on network node interfaces (NNIs).

Syntax Description

channel-group-number	(Optional) Number of the channel group. The range is 1 to 48.	
counters	Display traffic information.	
internal	Display internal information.	
neighbor	Display neighbor information.	
begin	(Optional) Display begins with the line that matches the expression.	
exclude	(Optional) Display excludes lines that match the expression.	
include	(Optional) Display includes lines that match the specified expression.	
expression	Expression in the output to use as a reference point.	

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

You can enter any **show pagp** command to display the active channel-group information. To display the nonactive information, enter the **show pagp** command with a channel-group number.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* are appear.

Examples

This is an example of output from the show pagp 1 counters command:

Switch>	show	pagp	1	counters

	Infor	mation	F1	ush
Port	Sent	Recv	Sent	Recv
Channel	group: 1			
Gi0/1	45	42	0	0
Gi0/2	45	41	0	0

This is an example of output from the **show pagp 1 internal** command:

```
Switch> show pagp 1 internal
```

Flags: S - Device is sending Slow hello. C - Device is in Consistent state.

A - Device is in Auto mode.

Timers: H - Hello timer is running. Q - Quit timer is running.

S - Switching timer is running. I - Interface timer is running.

Channel group 1

3	I							
				Hello	Partner	PAgP	Learning	Group
Port	Flags	State	Timers	Interval	Count	Priority	Method	Ifindex
Gi0/1	SC	U6/S7	H	30s	1	128	Any	16
Gi0/2	SC	U6/S7	H	30s	1	128	Any	16

This is an example of output from the **show pagp 1 neighbor** command:

Switch> show pagp 1 neighbor

```
Flags: S - Device is sending Slow hello. C - Device is in Consistent state.
A - Device is in Auto mode. P - Device learns on physical port.
```

Channel group 1 neighbors

	Partner	Partner	Partner		Partner	Group
Port	Name	Device ID	Port	Age	Flags	Cap.
Gi0/1	switch-p2	0002.4b29.4600	Gi0/1	9s	SC	10001
Gi0/2	switch-p2	0002.4b29.4600	Gi0/2	24s	SC	10001

Command	Description
clear pagp	Clears PAgP channel-group information.

show parser macro

Use the **show parser macro** user EXEC command to display the parameters for all configured macros or for one macro on the switch.

show parser macro [{brief | description [interface interface-id] | name macro-name}] [| {begin | exclude | include} | expression]

Syntax Description

brief	(Optional) Display the name of each macro.
description [interface interface-id]	(Optional) Display all macro descriptions or the description of a specific interface.
name macro-name	(Optional) Display information about a single macro identified by the macro name.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is a partial output example from the **show parser macro** command:

```
Switch# show parser macro
Total number of macros = 2

Macro name : sample-macro1
Macro type : customizable
duplex full
speed auto
mdix auto

Macro name : test1
Macro type : customizable
no shutdown
flowcontrol receive on
speed 100
```

This is an example of output from the **show parser macro name** command:

Switch# show parser macro name sample-macro1

Macro name : sample-macro1 Macro type : customizable

duplex full
speed auto
mdix auto

This is an example of output from the show parser macro brief command:

Switch# show parser macro brief

customizable : sample-macro1

customizable : test1

Command	Description
macro apply	Applies a macro on an interface or applies and traces a macro on an interface.
macro description	Adds a description about the macros that are applied to an interface.
macro global	Applies a macro on a switch or applies and traces a macro on a switch.
macro global description	Adds a description about the macros that are applied to the switch.
macro name	Creates a macro.
show running-config	Displays the current operating configuration, including defined macros. For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands.

show policer aggregate

Use the **show policer aggregate** user EXEC command to display quality of service (QoS) aggregate policer information for all aggregate policers or a specific policer.

show policer aggregate [aggregate-policer-name] [| {begin | exclude | include} | expression]

Syntax Description

aggregate-policer- name	(Optional) The name of the aggregate policer.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show policer aggregate** command:

In use by policymap: pin

Command	Description
police aggregate (policy-map class configuration)	Applies an aggregate policer to multiple classes in the same policy map.
policer aggregate (global configuration)	Creates an aggregate policer to police all traffic received on an interface.

show policer cpu uni

Use the **show policer cpu uni** user EXEC command to display control-plane policer information for the switch, including frames dropped or the configured threshold rate for the control-plane security feature on the switch.

show policer cpu uni [drop [policer-number] | rate] [| {begin | exclude | include} | expression]

Syntax Description

drop	(Optional) Display control-plane frame-drop count for the specified policer number or for all control-plane policers (0 to 26).
policer number	(Optional) Display drop statistics for a specific user network interface (UNI) policer number. The range is from 0 to 26.
rate	(Optional) Display the configured threshold rate for CPU policers.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The **show policer cpu uni drop** privileged EXEC command displays the number of accepted and dropped frames for all policers on the switch or for the specified policer number.

The **show policer cpu uni rate** command displays the CPU protection rate-limit threshold on the switch that was configured by entering the **policer cpu uni** *rate* global configuration command or the default rate of 16000 bits per second (bps).

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show policer cpu uni drop** command. Note that CPU protection only uses policers 0 to 26.

Switch> show policer cpu uni drop

========		======
Policer	In	Dropped
Num	Frames	Frames
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
=======		======
Policer	In	Dropped
Num	Frames	Frames
20	0	0
21	0	0
22	0	0
23	0	0

This is an example of output from the **show policer cpu uni rate** command when the default rate is used.

Switch> show policer cpu uni rate
CPU UNI port police rate = 160000 bps

0

0

0

0

Related Commands

24

25

Command	Description
policer cpu uni	Configures a CPU policer threshold rate for the switch.
show platform policer cpu	Displays allocated policer indexes and the corresponding features for all ports or the specified port.

show policy-map

Use the **show policy-map** user EXEC command to display quality of service (QoS) policy maps, which define classification criteria for incoming and outgoing traffic and the actions to be performed on the classified traffic.

show policy-map [policy-map-name | interface [interface-id] [input | output] [class class-name]] [| {begin | exclude | include} expression]

Syntax Description

policy-map-name	(Optional) Display the specified policy-map name.
class class-map-name	(Optional) Display QoS policy actions for an individual class.
interface [interface-id] [input output]	(Optional) Display information and statistics about policy maps applied to all ports or the specified port. If you specify a port, you can specify additional keywords. The keywords have these meanings:
	• <i>interface-id</i> —Display information about policy maps on the specified physical interface.
	• input —Display information about input policy maps on the switch or applied to the specified port.
	 output—Display the information about output policy-maps on the switch or applied to the specified port.
class class-name	(Optional) Display policy-map statistics for an individual class.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show policy-map** command:

Switch> show policy-map
Policy Map videowizard_policy2
 class videowizard_10-10-10-10
police 100000000 2000000 exceed-action drop
Policy Map mypolicy
 class dscp5

This is an example of output from the **show policy-map** command for a specific policy map:

```
Switch> show policy-map top2
Policy Map top2
Class class-default
shape average 11111124
service-policy pout
```

This is an example of output from the **show policy-map** command for an output policy map:

```
Switch> show policy-map pout
 Policy Map pout
   Class ip1
     priority
    police cir percent 10
      conform-action transmit
      exceed-action drop
     queue-limit 250
     queue-limit precedence 1 100
   Class ip2
     Average Rate Traffic Shaping
     cir 5%
   Class ip3
     bandwidth percent 10
     queue-limit 200
     queue-limit precedence 3 100
```

This is an example of output from the **show policy-map** command for an input policy map:

```
Switch> show policy-map pin-police
Policy Map pin-police
Class ip1
police cir 20000000 bc 625000
conform-action transmit
exceed-action drop
```

This is an example of output from the **show policy-map interface** command for an interface with a two-level output policy map applied:

```
Switch> show policy-map interface fastethernet0/3
FastEthernet0/3
 Service-policy output: top2
    Class-map: class-default (match-any)
     209871 packets
     Match: any
       56 packets
     Traffic Shaping
       Average Rate Traffic Shaping
       CIR 11111124 (bps)
     Output Queue:
       Tail Packets Drop: 195421
     Service-policy : pout
       Class-map: ip1 (match-all)
          9309 packets
         Match: ip precedence 1
         Priority
    police cir 20000000 bc 625000
      conform-action transmit
       exceed-action drop
     conform: 4916 (packets) exceed: 4393 (packets)
```

```
Queue Limit
   queue-limit 250 (packets)
   queue-limit precedence 1 100 (packets)
  Output Queue:
   Max Tail Drop Threshold: 250
   Tail Packets Drop: 4393
Class-map: ip2 (match-all)
  0 packets
 Match: ip precedence 2
 Traffic Shaping
   Average Rate Traffic Shaping
   CIR 5%
                555555 (bps)
  Output Queue:
   Max Tail Drop Threshold: 48
   Tail Packets Drop: 0
Class-map: ip3 (match-all)
  0 packets
 Match: ip precedence 3
 Bandwidth percent 10
                               1111110 (bps)
  Oueue Limit
   queue-limit 200 (packets)
   queue-limit precedence 3 100 (packets)
  Output Queue:
   Max Tail Drop Threshold: 200
   Tail Packets Drop: 0
Class-map: class-default (match-any)
  200562 packets
 Match: any
   56 packets
 Output Queue:
   Tail Packets Drop: 191028
```

This is an example of output from the **show policy-map interface** command for an interface with an input policy applied:

```
Switch> show policy-map interface gigabitethernet0/1
GigabitEthernet0/1
  Service-policy input: pin-police
   Class-map: ip1 (match-all)
      0 packets
      5 minute offered rate 0 bps, drop rate 0 bps
     Match: ip precedence 1
     police cir 20000000 bc 625000
      conform-action transmit
      exceed-action drop
     conform: 27927 (packets) exceed: 272073 (packets)
   Class-map: class-default (match-any)
     0 packets
      5 minute offered rate 0 bps, drop rate 0 bps
     Match: any
        0 packets, 0 bytes
        5 minute rate 0 bps
```

Table 2-14 describes the fields in the **show policy-map interface** display. The fields in the table are grouped according to the relevant QoS feature.

Table 2-14 show policy-map interface Field Descriptions

Field	Description	
Fields associated with	Fields associated with classes or service policies	
Service-policy input/output	Name of the input or output service policy applied to the specified interface.	
Class-map	Class of traffic shown. Output appears for each configured class in the policy. The choice for implementing class matches (match-all or match-any) might also appear next to the traffic class.	
packets	Number of packets identified as belonging to the traffic class.	
Match	Match criteria specified for the class of traffic. This includes criteria such as class of service (CoS) value, IP precedence value, Differentiated Services Code Point (DSCP) value, access groups, and QoS groups.	
Fields associated with	policing	
police	Shown when the police command has been configured to enable traffic policing. Displays the specified committed information rate (CIR) and conform burst size (BC) used for policing packets.	
conform-action	Displays the action to be taken on packets marked as conforming to a specified rate.	
conform	Displays the number of packets marked as conforming to the specified rate.	
exceed-action	Displays the actions to be taken on packets marked as exceeding a specified rate.	
exceed	Displays the number of packets marked as exceeding the specified rate.	
Fields associated with	queuing	
Queue Limit	Queue size configured for the class in number of packets.	
Output Queue	The queue created for this class of traffic.	
Tail packets dropped	The number of packets dropped when the mean queue depth is greater than the maximum threshold value.	
Fields associated with	traffic scheduling	
Traffic shaping	The rate used for shaping traffic.	
Bandwidth	Bandwidth configured for this class in kbps or a percentage.	
Priority	Indicates that this class is configured for priority queuing.	

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	specify a service poney.

show port-security

Use the **show port-security** privileged EXEC command to display port-security settings for an interface or for the switch.

show port-security [interface *interface-id*] [address | vlan] [| {begin | exclude | include} expression]

Syntax Description

interface interface-id	(Optional) Display port security settings for the specified interface. Valid interfaces include physical ports (including type, module, and port number).
address	(Optional) Display all secure MAC addresses on all ports or a specified port.
vlan	(Optional) Display port security settings for all VLANs on the specified interface. This keyword is visible only on interfaces that have the switchport mode set to trunk .
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you enter the command without keywords, the output includes the administrative and operational status of all secure ports on the switch.

If you enter an interface-id, the command displays port security settings for the interface.

If you enter the **address** keyword, the command displays the secure MAC addresses for all interfaces and the aging information for each secure address.

If you enter an *interface-id* and the **address** keyword, the command displays all the MAC addresses for the interface with aging information for each secure address. You can also use this command to display all the MAC addresses for an interface even if you have not enabled port security on it.

If you enter the **vlan** keyword, the command displays the configured maximum and the current number of secure MAC addresses for all VLANs on the interface. This option is visible only on interfaces that have the switchport mode set to **trunk**.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of the output from the **show port-security** command:

Switch# show port-security

```
Secure Port MaxSecureAddr CurrentAddr SecurityViolation Security Action
(Count) (Count)

Gi0/1 1 0 0 Shutdown

Total Addresses in System (excluding one mac per port) : 1

Max Addresses limit in System (excluding one mac per port) : 6272
```

This is an example of output from the **show port-security interface** interface-id command:

```
Switch# show port-security interface gigabitethernet0/1
```

```
Port Security: Enabled
Port status: SecureUp
Violation mode: Shutdown
Maximum MAC Addresses: 1
Total MAC Addresses: 0
Configured MAC Addresses: 0
Aging time: 0 mins
Aging type: Absolute
SecureStatic address aging: Disabled
Security Violation count: 0
```

This is an example of output from the **show port-security address** command:

Switch# show port-security address

Secure	Mac Address Table			
Vlan	Mac Address	Туре	Ports	Remaining Age (mins)
1	0006.0700.0800	SecureConfigured	Gi0/2	1
	_	n (excluding one mac stem (excluding one		•

This is an example of output from the **show port-security interface gigabitethernet0/2 address** command:

Switch# show port-security interface gigabitethernet0/2 address
Secure Mac Address Table

Vlan	Mac Address	Type	Ports	Remaining Age (mins)
1	0006.0700.0800	SecureConfigured	Gi0/2	1
Total	Addresses: 1			

This is an example of output from the show port-security interface interface-id vlan command:

Switch# show port-security interface gigabitethernet0/2 vlan

```
Default maximum:not set, using 5120
VLAN Maximum Current
5 default 1
10 default 54
11 default 101
12 default 101
13 default 201
14 default 501
```

Command	Description
clear port-security	Deletes from the MAC address table a specific type of secure address or all the secure addresses on the switch or an interface.
switchport port-security	Enables port security on a port, restricts the use of the port to a user-defined group of stations, and configures secure MAC addresses.

show port-type

Use the **show port-type** privileged EXEC command to display interface type information for the Cisco ME switch.

show port-type [uni | nni] [| {begin | exclude | include} expression]

Syntax Description

uni	User network interface.
l nni	Network node interface.
begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you enter the command without keywords, the output includes the interface type information for all ports on the switch. If you use the **uni** keyword, the output includes only the UNIs. If you use the **nni** keyword, the output includes only the NNIs.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show port-type** command with no keywords:

Switch# show port-type Port Name	Vlan	Port Type
Fa0/1	1	User Network Interface (uni)
Fa0/2	1	User Network Interface (uni)
Fa0/3	1	User Network Interface (uni)
Fa0/4	1	User Network Interface (uni)
Fa0/5	1	User Network Interface (uni)
Fa0/6	1	User Network Interface (uni)
Fa0/7	1	User Network Interface (uni)
Fa0/8	1	User Network Interface (uni)
Fa0/9	1	User Network Interface (uni)
Fa0/10	1	User Network Interface (uni)
Fa0/11	1	User Network Interface (uni)
Fa0/12	1	User Network Interface (uni)
Fa0/13	1	User Network Interface (uni)
Fa0/14	1	User Network Interface (uni)
Fa0/15	1	User Network Interface (uni)
Fa0/16	1	User Network Interface (uni)

Fa0/17	routed	User Network Interface (uni)	
Fa0/18	1	User Network Interface (uni)	
Fa0/19	1	User Network Interface (uni)	
Fa0/20	1	User Network Interface (uni)	
Fa0/21	1	User Network Interface (uni)	
Fa0/22	1	User Network Interface (uni)	
Fa0/23	10	User Network Interface (uni)	
Fa0/24	10	User Network Interface (uni)	
Gi0/1	1	Network Node Interface (nni)	
Gi0/2	1	Network Node Interface (nni)	

This is an example of output from the **show port-type** command using keywords:

Switch#	show port-type nni	exclude Gi	gabitethernet0/1
Port	Name	Vlan	Port Type
Gi0/2		1	Network Node Interface (nni)

Command	Description
port-type	Changes the interface type for a specific port.

show sdm prefer

Use the **show sdm prefer** privileged EXEC command to display the Switch Database Management (SDM) template used to allocate system resources.

show sdm prefer [layer-2] [| {begin | exclude | include}} expression]

Syntax Description

layer-2	(Optional) Display resource allocations for the template that supports Layer 2 features and does not support routing.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

The numbers displayed represent an approximate maximum number for each feature resource. The actual number might vary, depending on the actual number of other features configured.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show sdm prefer** command, displaying the template in use:

Switch# show sdm prefer

```
The current template is ''layer-2'' template. The selected template optimizes the resources in the switch to support this level of features for 8 routed interfaces and 1024 VLANs.
```

```
number of unicast mac addresses: 2K
number of IPv4 IGMP groups: 1K
number of IPv4 multicast routes: 0
number of unicast IPv4 routes: 0
number of IPv4 policy based routing aces: 0
number of IPv4/MAC qos aces: 512
number of IPv4/MAC security aces: 1K
```

show spanning-tree

Use the **show spanning-tree** user EXEC command to display spanning-tree state information.

- show spanning-tree [bridge-group | active [detail] | blockedports | bridge | detail [active] | inconsistentports | interface interface-id | mst | pathcost method | root | summary [totals] | vlan vlan-id] [| {begin | exclude | include} | expression]
- show spanning-tree bridge-group [active [detail] | blockedports | bridge | detail [active] | inconsistentports | interface interface-id | root | summary] [| {begin | exclude | include} | expression]
- show spanning-tree vlan vlan-id [active [detail] | blockedports | bridge | detail [active] | inconsistentports | interface interface-id | root | summary] [| {begin | exclude | include} | expression]
- show spanning-tree {vlan vlan-id | bridge-group} bridge [address | detail | forward-time | hello-time | id | max-age | priority [system-id] | protocol] [| {begin | exclude | include} expression]
- show spanning-tree {vlan vlan-id | bridge-group} root [address | cost | detail | forward-time | hello-time | id | max-age | port | priority [system-id] [| {begin | exclude | include} | expression]
- show spanning-tree interface interface-id [active [detail] | cost | detail [active] | inconsistency | portfast | priority | rootcost | state] [| {begin | exclude | include} | expression]
- show spanning-tree mst [configuration] | [instance-id [detail | interface interface-id [detail]] [| {begin | exclude | include} | expression]

Syntax Description

(Optional) Specify the bridge group number. The range is 1 to 255.
(Optional) Display spanning-tree information only on active interfaces (available only in privileged EXEC mode).
(Optional) Display blocked port information (available only in privileged EXEC mode).
(Optional) Display status and configuration of this switch (optional keywords available only in privileged EXEC mode).
(Optional) Display a detailed summary of interface information (active keyword available only in privileged EXEC mode).
(Optional) Display inconsistent port information (available only in privileged EXEC mode).

interface interface-id [active [detail] cost detail [active] inconsistency portfast priority rootcost state]	(Optional) Display spanning-tree information for the specified interface (all options except portfast and state available only in privileged EXEC mode). Enter each interface separated by a space. Ranges are not supported. Valid interfaces include physical network node interfaces (NNIs), VLANs, and NNI port channels. The VLAN range is 1 to 4094. The port-channel range is 1 to 48.		
	Note Spanning Tree Protocol (STP) is not supported on user node interfaces (UNIs). If you enter a UNI interface ID, no spanning-tree information is displayed.		
mst [configuration [instance-id [detail interface interface-id [detail]]	(Optional) Display the multiple spanning-tree (MST) region configuration and status (available only in privileged EXEC mode). You can specify a single instance ID, a range of IDs separated by a hyphen, or a series of IDs separated by a comma. The range is 1 to 15.		
	Valid interfaces include physical NNIs, VLANs, and NNI port channels. STP is not supported on UNIs.		
	The VLAN range is 1 to 4094. The port-channel range is 1 to 48.		
pathcost method	(Optional) Display the default path cost method (available only in privileged EXEC mode).		
root [address cost detail forward-time hello-time id max-age port priority [system-id]]	(Optional) Display root switch status and configuration (all keywords available only in privileged EXEC mode).		
summary [totals]	(Optional) Display a summary of port states or the total lines of the spanning-tree state section.		
vlan vlan-id [active [detail] backbonefast blockedports bridge [address detail forward-time hello-time id max-age priority	(Optional) Display spanning-tree information for the specified VLAN (some keywords available only in privileged EXEC mode). You can specify a single VLAN identified by VLAN ID number, a range of VLANs separated by a hyphen, or a series of VLANs separated by a comma. The range is 1 to 4094.		
[system-id] protocol]			
begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
include	(Optional) Display includes lines that match the specified <i>expression</i> .		
expression	Expression in the output to use as a reference point.		

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

STP is not supported on UNIs. Valid spanning-tree information is available only for NNIs.

If the *vlan-id* variable is omitted, the command applies to the spanning-tree instance for all VLANs.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show spanning-tree active** command:

```
Switch# show spanning-tree active
VLAN0001
 Spanning tree enabled protocol ieee
          Priority 32768
 Root ID
           Address 0001.42e2.cdd0
           Cost
                     3038
           Port
                     24 (GigabitEthernet0/1)
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority 49153 (priority 49152 sys-id-ext 1)
                    0003.fd63.9580
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
           Aging Time 300
 Uplinkfast enabled
            Role Sts Cost
                               Prio.Nbr Type
Interface
______
      Root FWD 3019
Gi 0 / 1
                              128.24 P2p
<output truncated>
```

This is an example of output from the **show spanning-tree detail** command:

```
Switch# show spanning-tree detail
```

```
VLAN0001 is executing the ieee compatible Spanning Tree protocol
  Bridge Identifier has priority 49152, sysid 1, address 0003.fd63.9580
  Configured hello time 2, max age 20, forward delay 15
  Current root has priority 32768, address 0001.42e2.cdd0
  Root port is 24 (GigabitEthernet0/1), cost of root path is 3038
  Topology change flag not set, detected flag not set
  Number of topology changes 0 last change occurred 1d16h ago
  Times: hold 1, topology change 35, notification 2
         hello 2, max age 20, forward delay 15
  Timers: hello 0, topology change 0, notification 0, aging 300
  Uplinkfast enabled
 Port 1 (GigabitEthernet0/1) of VLAN0001 is forwarding
   Port path cost 3019, Port priority 128, Port Identifier 128.24.
   Designated root has priority 32768, address 0001.42e2.cdd0
   Designated bridge has priority 32768, address 00d0.bbf5.c680
   Designated port id is 128.25, designated path cost 19
   Timers: message age 2, forward delay 0, hold 0
   Number of transitions to forwarding state: 1
   Link type is point-to-point by default
   BPDU: sent 0, received 72364
<output truncated>
```

This is an example of output from the **show spanning-tree interface** interface-id command:

${\tt Switch\#\ show\ spanning-tree\ interface\ gigabitethernet0/1}$

Vlan	Role	Sts	Cost	Prio.Nbr	Туре
VLAN0001	Root	FWD	3019	128.24	P2p

This is an example of output from the show spanning-tree summary command:

```
Switch# show spanning-tree summary
Switch is in pvst mode
Root bridge for: none
EtherChannel misconfiguration guard is enabled
Extended system ID is enabled
Portfast is disabled by default
PortFast BPDU Guard is disabled by default
Portfast BPDU Filter is disabled by default
Loopguard is disabled by default
Pathcost method used is short
```

Name	Blocking	Listening	Learning	Forwarding	STP Active
VLAN0001	1	0	0	11	12
VLAN0002	3	0	0	1	4
VLAN0004	3	0	0	1	4
VLAN0006	3	0	0	1	4
VLAN0031	3	0	0	1	4
VLAN0032	3	0	0	1	4
<pre><output truncated=""></output></pre>					
37 vlans	109	0	0	47	156
Station update rate se	et to 150 j	packets/sec	c.		

This is an example of output from the **show spanning-tree mst configuration** command:

Switch# show spanning-tree mst configuration

```
Name [region1]
Revision 1
Instance Vlans Mapped
-----
0 1-9,21-4094
1 10-20
```

Port-channel1

This is an example of output from the **show spanning-tree mst interface** *interface-id* command:

Switch# show spanning-tree mst interface gigabitethernet0/1

root FWD 200000 128 1,12,14-4094

```
GigabitEthernet0/1 of MST00 is root forwarding

Edge port: no (default) port guard : none (default)

Link type: point-to-point (auto) bpdu filter: disable (default)

Boundary : boundary (STP) bpdu guard : disable (default)

Bpdus sent 5, received 74

Instance role state cost prio vlans mapped
```

This is an example of output from the **show spanning-tree mst 0** command:

Switch# show spanning-tree mst 0 ##### MST00 vlans mapped: 1-9,21-4094 Bridge address 0002.4b29.7a00 priority 32768 (32768 sysid 0) address 0001.4297.e000 priority 32768 (32768 sysid 0) Root port Gi0/1 path cost 200038 IST master *this switch Operational hello time 2, forward delay 15, max age 20, max hops 20 Configured hello time 2, forward delay 15, max age 20, max hops 20 Interface role state cost prio type ____ GigabitEthernet0/1 root FWD 200000 GigabitEthernet0/2 desg FWD 200000 128 P2P bound(STP) 128 P2P bound(STP)

desg FWD 200000 128 P2P bound(STP)

Command	Description
clear spanning-tree counters	Clears the spanning-tree counters.
clear spanning-tree detected-protocols	Restarts the protocol migration process.
spanning-tree bpdufilter	Prevents an interface from sending or receiving bridge protocol data units (BPDUs).
spanning-tree bpduguard	Puts an interface in the error-disabled state when it receives a BPDU.
spanning-tree cost	Sets the path cost for spanning-tree calculations.
spanning-tree extend system-id	Enables the extended system ID feature.
spanning-tree guard	Enables the root guard or the loop guard feature for all the VLANs associated with the selected interface.
spanning-tree link-type	Overrides the default link-type setting for rapid spanning-tree transitions to the forwarding state.
spanning-tree loopguard default	Prevents alternate or root ports from becoming the designated port because of a failure that leads to a unidirectional link.
spanning-tree mst configuration	Enters multiple spanning-tree (MST) configuration mode through which the MST region configuration occurs.
spanning-tree mst cost	Sets the path cost for MST calculations.
spanning-tree mst forward-time	Sets the forward-delay time for all MST instances.
spanning-tree mst hello-time	Sets the interval between hello BPDUs sent by root switch configuration messages.
spanning-tree mst max-age	Sets the interval between messages that the spanning tree receives from the root switch.
spanning-tree mst max-hops	Sets the number of hops in an MST region before the BPDU is discarded and the information held for an interface is aged.
spanning-tree mst port-priority	Configures an interface priority.
spanning-tree mst priority	Configures the switch priority for the specified spanning-tree instance.
spanning-tree mst root	Configures the MST root switch priority and timers based on the network diameter.
spanning-tree port-priority	Configures an interface priority.
spanning-tree portfast (global configuration)	Globally enables the BPDU filtering or the BPDU guard feature on Port Fast-enabled interfaces or enables the Port Fast feature on all nontrunking interfaces.
spanning-tree portfast (interface configuration)	Enables the Port Fast feature on an interface and all its associated VLANs.
spanning-tree vlan	Configures spanning tree on a per-VLAN basis.

show storm-control

Use the **show storm-control** user EXEC command to display broadcast, multicast, or unicast storm control settings on the switch or on the specified interface or to display storm-control history.

show storm-control [interface-id] [**broadcast** | **multicast** | **unicast**] [| {**begin** | **exclude** | **include**} expression]

Syntax Description

interface-id	(Optional) Interface ID for the physical port (including type, module, and port number).
broadcast	(Optional) Display broadcast storm threshold setting.
multicast	(Optional) Display multicast storm threshold setting.
unicast	(Optional) Display unicast storm threshold setting.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

When you enter an *interface-id*, the storm control thresholds appear for the specified interface.

If you do not enter an *interface-id*, settings appear for one traffic type for all ports on the switch.

If you do not enter a traffic type, settings appear for broadcast storm control.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of a partial output from the **show storm-control** command when no keywords are entered. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

Switch> show	storm-control			
Interface	Filter State	Upper	Lower	Current
Gi0/1	Forwarding	20 pps	10 pps	5 pps
Gi0/2	Forwarding	50.00%	40.00%	0.00%
<output td="" trun<=""><td>cated></td><td></td><td></td><td></td></output>	cated>			

This is an example of output from the **show storm-control** command for a specified interface. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

Switch> show	storm-control	gigabitether	net 0/1	
Interface	Filter State	Upper	Lower	Current
Gi0/1	Forwarding	20 pps	10 pps	5 pps

Table 2-15 describes the fields in the **show storm-control** display.

Table 2-15 show storm-control Field Descriptions

Field	Description
Interface	Displays the ID of the interface.
Filter State	Displays the status of the filter:
	Blocking—Storm control is enabled, and a storm has occurred.
	• Forwarding—Storm control is enabled, and no storms have occurred.
	• Inactive—Storm control is disabled.
Upper	Displays the rising suppression level as a percentage of total available bandwidth in packets per second or in bits per second.
Lower	Displays the falling suppression level as a percentage of total available bandwidth in packets per second or in bits per second.
Current	Displays the bandwidth usage of broadcast traffic or the specified traffic type (broadcast, multicast, or unicast) as a percentage of total available bandwidth. This field is only valid when storm control is enabled.

Command	Description
storm-control	Sets the broadcast, multicast, or unicast storm control levels for the switch.

show system mtu

Use the **show system mtu** privileged EXEC command to display the global maximum transmission unit (MTU) or maximum packet size set for the switch.

show system mtu [| {begin | exclude | include}} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.
l exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you have used the **system mtu** or **system mtu jumbo** global configuration command to change the MTU setting, the new setting does not take effect until you reset the switch.

The system MTU refers to ports operating at 10/100 Mbps; the system jumbo MTU refers to Gigabit ports.

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show system mtu** command:

Switch# **show system mtu**System MTU size is 1500 bytes
System Jumbo MTU size is 1500 bytes

Command	Description
system mtu	Sets the MTU size for the Fast Ethernet or Gigabit Ethernet ports.

show table-map

Use the **show table-map** user EXEC command to display quality of service (QoS) table-map information about all configured table maps or the specified table map.

show table-map [table-map-name] [| {begin | exclude | include}} expression]

Syntax Description

table-map-name	(Optional) The name of the table map.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
l exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show table-map** command:

```
Switch> show table-map
tandoori_1>show table-map
Table Map abc
    default copy

Table Map cos2dscp
    from 2 to 16
    default copy

Table Map cos2cos
    from 2 to 5
    from 3 to 6
    default 7

Table Map cos2cos10
    default copy

Table Map cos2cos10
    default copy
```

This is an example of output from the **show table-map** command for a specific table map name:

Switch> show table-map tm

Table Map tm
from 1 to 62
from 2 to 63
default ignore

Command	Description
table-map	Creates quality of service (QoS) mapping tables, such as CoS to DSCP, and so on.

show udld

Use the **show udld** user EXEC command to display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port.

show udld [interface-id] [| {begin | exclude | include} expression]

Syntax Description

interface-id	(Optional) ID of the interface and port number. Valid interfaces include physical ports and VLANs. The VLAN range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

If you do not enter an interface-id, administrative and operational UDLD status for all interfaces appear.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show udld** *interface-id* command. For this display, UDLD is enabled on both ends of the link, and UDLD detects that the link is bidirectional. Table 2-16 describes the fields in this display.

```
Switch> show udld gigabitethernet0/1
Interface qi0/1
Port enable administrative configuration setting: Follows device default
Port enable operational state: Enabled
Current bidirectional state: Bidirectional
Current operational state: Advertisement - Single Neighbor detected
Message interval: 60
Time out interval: 5
   Entry 1
    Expiration time: 146
   Device ID: 1
   Current neighbor state: Bidirectional
    Device name: Switch-A
    Port ID: Gi0/1
   Neighbor echo 1 device: Switch-B
   Neighbor echo 1 port: Gi0/2
   Message interval: 5
   CDP Device name: Switch-A
```

Table 2-16 show udld Field Descriptions

Field	Description
Interface	The interface on the local device configured for UDLD.
Port enable administrative configuration setting	How UDLD is configured on the port. If UDLD is enabled or disabled, the port enable configuration setting is the same as the operational enable state. Otherwise, the enable operational setting depends on the global enable setting.
Port enable operational state	Operational state that shows whether UDLD is actually running on this port.
Current bidirectional state	The bidirectional state of the link. An unknown state appears if the link is down or if it is connected to an UDLD-incapable device. A bidirectional state appears if the link is a normal two-way connection to a UDLD-capable device. All other values mean miswiring.
Current operational state	The current phase of the UDLD state machine. For a normal bidirectional link, the state machine is most often in the Advertisement phase.
Message interval	How often advertisement messages are sent from the local device. Measured in seconds.
Time out interval	The time period, in seconds, that UDLD waits for echoes from a neighbor device during the detection window.
Entry 1	Information from the first cache entry, which contains a copy of echo information received from the neighbor.
Expiration time	The amount of time in seconds remaining before this cache entry is aged out.
Device ID	The neighbor device identification.
Current neighbor state	The neighbor's current state. If both the local and neighbor devices are running UDLD normally, the neighbor state and local state should be bidirectional. If the link is down or the neighbor is not UDLD-capable, no cache entries appear.
Device name	The device name or the system serial number of the neighbor. The system serial number appears if the device name is not set or is set to the default (Switch).
Port ID	The neighbor port ID enabled for UDLD.
Neighbor echo 1 device	The device name of the neighbors' neighbor from which the echo originated.
Neighbor echo 1 port	The port number ID of the neighbor from which the echo originated.
Message interval	The rate, in seconds, at which the neighbor is sending advertisement messages.
CDP device name	The CDP device name or the system serial number. The system serial number appears if the device name is not set or is set to the default (Switch).

Command	Description
udld	Enables aggressive or normal mode in UDLD or sets the configurable message timer time.
udld port	Enables UDLD on an individual interface or prevents a fiber-optic interface from being enabled by the udld global configuration command.
udld reset	Resets all interfaces shutdown by UDLD and permits traffic to begin passing through them again.

show version

Use the **show version** user EXEC command to display version information for the hardware and firmware.

show version [| {begin | exclude | include} expression]

Syntax Description

begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the <i>expression</i> .
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show version command:



Note

Though visible in the **show version** output, the *configuration register* information is not supported on the switch.

Switch> show version

Cisco IOS Software, MEAP Software (MEAP-IPSERVICES-M), Experimental Version 12.2 (20050712:084347) [teresang-meap-bug-fix 109] Copyright (c) 1986-2005 by Cisco Systems, Inc. Compiled Sun 17-Jul-05 13:19 by teresang

ROM: Bootstrap program is C3750 boot loader BOOTLDR: ME3400 Boot Loader (me3400-HBOOT-M), Version 12.2 [mbutts-meap2 103]

tandoori_1 uptime is 1 day, 2 hours, 49 minutes
System returned to ROM by power-on
System image file is "flash:image"

cisco ME-3440-24T-FA (PowerPC405) processor with 118784K/12280K bytes of memory.

Processor board ID FSJC0407862 Last reset from power-on Target IOS Version 12.2(25)SE 3 Virtual Ethernet interfaces 24 FastEthernet interfaces 2 Gigabit Ethernet interfaces The password-recovery mechanism is enabled.

512K bytes of flash-simulated non-volatile configuration memory.

Base ethernet MAC Address : 00:0B:FC:FF:32:80

Power supply part number : 341-0149-01
Motherboard serial number : FHH0848001R
Power supply serial number : DTH0450000T
System serial number : FSJC0407862
Top Assembly Part Number : 800-26552-01

Top Assembly Part Number : 800-26552-01
Top Assembly Revision Number : 05
Hardware Board Revision Number : 0x01

 Switch
 Ports
 Model
 SW Version
 SW Image

 *
 1
 26
 ME-3440-24T-FA
 12.2(20050712:084347)
 MEAP-IPSERVICES-M

Configuration register is 0xF

show vlan

Use the **show vlan** user EXEC command to display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch.

show vlan [access-map | brief | filter | id vlan-id | mtu | name vlan-name | private-vlan [type] | remote-span | summary | uni-vlan [type]] [| {begin | exclude | include} | expression]

Syntax Description

access-map	See the show vlan access-map command.
brief	(Optional) Display one line for each VLAN with the VLAN name, status, and its ports.
filter	See the show vlan filter command.
id vlan-id	(Optional) Display information about a single VLAN identified by VLAN ID number. For <i>vlan-id</i> , the range is 1 to 4094.
mtu	(Optional) Display a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN.
name vlan-name	(Optional) Display information about a single VLAN identified by VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.
private-vlan [type]	(Optional) Display information about configured private VLANs, including primary and secondary VLAN IDs, type (community, isolated, or primary) and ports belonging to the private VLAN. Enter type (optional) to see only the VLAN ID and the type of private VLAN.
remote-span	(Optional) Display information about Remote SPAN (RSPAN) VLANs.
summary	(Optional) Display VLAN summary information.
uni-vlan [type]	(Optional) Display user network interface (UNI) VLAN information. Enter type (optional) to see only the VLAN ID and type of UNI VLAN.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.



Though visible in the command-line help string, the **ifindex** and **internal usage** keywords are not supported.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

In the **show vlan mtu** command output, the MTU_Mismatch column shows whether all the ports in the VLAN have the same MTU. When *yes* appears in this column, it means that the VLAN has ports with different MTUs. Packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have a switch virtual interface (SVI), the hyphen (-) symbol appears in the SVI_MTU column. If the MTU-Mismatch column displays *yes*, the names of the port with the MinMTU and the port with the MaxMTU appear.

If you try to associate a private VLAN secondary VLAN with a primary VLAN before you define the secondary VLAN, the secondary VLAN is not included in the **show vlan private-vlan** command output.

In the **show vlan private-vlan type** command output, a *normal* type means a VLAN has a private VLAN association but is not part of the private VLAN. For example, if you define and associate two VLANs as primary and secondary VLANs and then delete the secondary VLAN configuration but do not remove the association from the primary VLAN, the VLAN that was the secondary VLAN is shown as *normal* in the display. In the **show vlan private-vlan** output, the primary and secondary VLAN pair is shown as *non-operational*.

In the **show vlan uni-vlan type** command output, type is either *community* or *isolated*. User network interfaces (UNIs) in a UNI community VLAN can communicate with each other; UNIs in a UNI isolated VLAN cannot communicate. Network node interfaces (NNIs) can communicate with each other and with UNIs in UNI isolated and community VLANs.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show vlan** command. Table 2-17 describes the fields in the display.



The switch supports only Ethernet VLANs. You can configure parameters for FDDI and Token Ring VLANs and view the results in the vlan.dat file, but these parameters are not supported or used.

Swit		ow vlan w vlan			Stai	tus P	orts			
1	defau	1t			act:	F F F F	a0/5, I a0/9, I a0/13, a0/17,	Fa0/2, Fa0/6, Fa0/6, Fa0/10, Fa0/14, I Fa0/18, I Fa0/22, I Gi0/2	0/7, Fa0 a0/11, I Fa0/15, Fa0/19,	0/8 Fa0/12 Fa0/16 Fa0/20
1002 fddi-default			act	/unsup						
1003	token	-ring-def	ault		act,	/unsup				
1004 fddinet-default			act	act/unsup						
1005	trnet	-default			act,	/unsup				
VLAN	Туре	SAID	MTU	Parent	RingNo	BridgeN	o Stp	BrdgMode	Trans1	Trans2
1	enet	100001	1500	_	_	_	_	_	0	0
1002	fddi	101002	1500	_	_	-	_	_	0	0
1003	tr	101003	1500	-	-	-	-	_	0	0
1004	fdnet	101004	1500	_	-	-	ieee	_	0	0
1005	trnet	101005	1500 -	-	-	ibm -	0	0VLAN	Name	
Remo	te SPAI	N VLANs								




Table 2-17 show vlan Command Output Fields

Field	Description
VLAN	VLAN number.
Name	Name, if configured, of the VLAN.
Status	Status of the VLAN (active or suspend).
Ports	Ports that belong to the VLAN.
Type	Media type of the VLAN.
SAID	Security association ID value for the VLAN.
MTU	Maximum transmission unit size for the VLAN.
Parent	Parent VLAN, if one exists.
RingNo	Ring number for the VLAN, if applicable.
BrdgNo	Bridge number for the VLAN, if applicable.
Stp	Spanning Tree Protocol type used on the VLAN.
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.
Trans1	Translation bridge 1.
Trans2	Translation bridge 2.
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.
Primary/Secondary/ Type/Ports	Includes any configured private VLANs, including the primary VLAN ID, the secondary VLAN ID, the type of secondary VLAN (community or isolated), and the ports that belong to it.
VLAN Type/Ports	Displays any configured UNI VLANs, the type (community or isolated), and the ports that belong to it.

This is an example of output from the **show vlan private-vlan** command:

Switch:	> show vlan	private-vlan	
Primary	y Secondary	Type	Ports
10	501	isolated	Gi0/3
10	502	community	Fa0/11
10	503	non-operational3	-
20	25	isolated	Fa0/13, Fa0/20, Fa0/22, Gi0/1,
20	30	community	Fa0/13, Fa0/20, Fa0/21, Gi0/1,
20	35	community	Fa0/13, Fa0/20, Fa0/23, Fa0/33. Gi0/1,
20	55	non-operational	
2000	2500	isolated	Fa0/5, Fa0/10, Fa0/15

This is an example of output from the **show vlan private-vlan type** command:

```
Switch> show vlan private-vlan type
Vlan Type
----
10 primary
501 isolated
502 community
503 normal
```

This is an example of output from the **show vlan uni-vlan type** command:

```
Switch> show vlan uni-vlan type
Vlan Type
----
1 UNI isolated
20 UNI community
201 UNI isolated
```

Switch> show vlan summary

This is an example of output from the **show vlan summary** command:

```
Number of existing VLANs : 45
Number of existing VTP VLANs : 0
Number of existing extended VLANs : 0
This is an example of output from the show vlan id command.
```

Command	Description
private-vlan	Configures a VLAN as a community, isolated, or primary VLAN or associates a primary VLAN with secondary VLANs.
switchport mode	Configures the VLAN membership mode of a port.
vlan	Enables VLAN configuration mode where you can configure VLANs 1 to 4094.

show vlan access-map

Use the **show vlan access-map** privileged EXEC command to display information about a particular VLAN access map or for all VLAN access maps.

show vlan access-map [mapname] [| {begin | exclude | include} | expression]

Syntax Description

тарпате	(Optional) Name of a specific VLAN access map.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show vlan access-map** command:

```
Switch# show vlan access-map
Vlan access-map "SecWiz" 10
  Match clauses:
    ip address: SecWiz_Fa1_0_3_in_ip
Action:
    forward
```

Command	Description
show vlan filter	Displays information about all VLAN filters or about a particular VLAN or VLAN access map.
vlan access-map	Creates a VLAN map entry for VLAN packet filtering.
vlan filter	Applies a VLAN map to one or more VLANs.

show vlan filter

Use the **show vlan filter** privileged EXEC command to display information about all VLAN filters or about a particular VLAN or VLAN access map.

show vlan filter [access-map name | vlan vlan-id] [| {begin | exclude | include} | expression]

Syntax Description

access-map name	(Optional) Display filtering information for the specified VLAN access map.
vlan vlan-id	(Optional) Display filtering information for the specified VLAN. The range is 1 to 4094.
begin	(Optional) Display begins with the line that matches the expression.
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

Privileged EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show vlan filter** command:

Switch# show vlan filter
VLAN Map map_1 is filtering VLANs: 20-22

Command	Description
show vlan access-map	Displays information about a particular VLAN access map or for all VLAN access maps.
vlan access-map	Creates a VLAN map entry for VLAN packet filtering.
vlan filter	Applies a VLAN map to one or more VLANs.

show vmps

Use the **show vmps** user EXEC command without keywords to display the VLAN Query Protocol (VQP) version, reconfirmation interval, retry count, VLAN Membership Policy Server (VMPS) IP addresses, and the current and primary servers, or use the **statistics** keyword to display client-side statistics.

show vmps [statistics] [| {begin | exclude | include}} expression]

Syntax Description

statistics	(Optional) Display VQP client-side statistics and counters.
begin	(Optional) Display begins with the line that matches the <i>expression</i> .
exclude	(Optional) Display excludes lines that match the expression.
include	(Optional) Display includes lines that match the specified expression.
expression	Expression in the output to use as a reference point.

Command Modes

User EXEC

Command History

Release	Modification
12.2(25)EX	This command was introduced.

Usage Guidelines

Expressions are case sensitive. For example, if you enter I **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show vmps** command:

```
Switch> show vmps

VQP Client Status:
-----

VMPS VQP Version: 1

Reconfirm Interval: 60 min

Server Retry Count: 3

VMPS domain server:

Reconfirmation status
------

VMPS Action: other
```

This is an example of output from the show vmps statistics command. Switch> show vmps statistics

Table 2-18 describes each field in the display.

Table 2-18 show vmps statistics Field Descriptions

Field	Description
VQP Queries	Number of queries sent by the client to the VMPS.
VQP Responses	Number of responses sent to the client from the VMPS.
VMPS Changes	Number of times that the VMPS changed from one server to another.
VQP Shutdowns	Number of times the VMPS sent a response to shut down the port. The client disables the port and removes all dynamic addresses on this port from the address table. You must administratively re-enable the port to restore connectivity.
VQP Denied	Number of times the VMPS denied the client request for security reasons. When the VMPS response denies an address, no frame is forwarded to or from the workstation with that address (broadcast or multicast frames are delivered to the workstation if the port has been assigned to a VLAN). The client keeps the denied address in the address table as a blocked address to prevent more queries from being sent to the VMPS for each new packet received from this workstation. The client ages the address if no new packets are received from this workstation on this port within the aging time period.
VQP Wrong Domain	Number of times the management domain in the request does not match the one for the VMPS. Any previous VLAN assignments of the port are not changed. This response means that the server and the client have not been configured with the same VQP management domain.
VQP Wrong Version	Number of times the version field in the query packet contains a value that is higher than the version supported by the VMPS. The VLAN assignment of the port is not changed. The switches send only VMPS Version 1 requests.
VQP Insufficient Resource	Number of times the VMPS is unable to answer the request because of a resource availability problem. If the retry limit has not yet been reached, the client repeats the request with the same server or with the next alternate server, depending on whether the per-server retry count has been reached.

Command	Description
clear vmps statistics	Clears the statistics maintained by the VQP client.
vmps reconfirm (privileged EXEC)	Sends VQP queries to reconfirm all dynamic VLAN assignments with the VMPS.
vmps retry	Configures the per-server retry count for the VQP client.
vmps server	Configures the primary VMPS and up to three secondary servers.