rmon collection stats

Use the **rmon collection stats** interface configuration command to collect Ethernet group statistics, which include usage statistics about broadcast and multicast packets, and error statistics about cyclic redundancy check (CRC) alignment errors and collisions. Use the **no** form of this command to return to the default setting.

rmon collection stats index [owner name]

no rmon collection stats *index* [**owner** *name*]

Syntax Description	index	Remote Network Monitoring (RMON) collection control index. The range is 1 to 65535.
	owner name	(Optional) Owner of the RMON collection.
Defaults	The RMON statistics of	collection is disabled.
Command Modes	Interface configuration	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	interface (UNI), you m	collection command is based on hardware counters. If the port is a user network nust use the no shutdown interface configuration command to enable it before
Usage Guidelines	interface (UNI), you m	ust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces
-	interface (UNI), you m using the rmon collect (NNIs) are enabled by	ust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces
	interface (UNI), you m using the rmon collect (NNIs) are enabled by This example shows ho Switch(config)# inte	nust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces default.
	interface (UNI), you m using the rmon collect (NNIs) are enabled by This example shows he Switch(config)# inte Switch(config-if)# r	hust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces default.
Examples	interface (UNI), you m using the rmon collect (NNIs) are enabled by This example shows he Switch(config)# inte Switch(config-if)# r	nust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces default. by to collect RMON statistics for the owner <i>root</i> : erface gigabitethernet0/1 mon collection stats 2 owner root
Usage Guidelines Examples Related Commands	interface (UNI), you m using the rmon collect (NNIs) are enabled by This example shows he Switch(config)# inte Switch(config-if)# r You can verify your se	hust use the no shutdown interface configuration command to enable it before tion stats command. UNIs are disabled by default. Network node interfaces default. by to collect RMON statistics for the owner <i>root</i> : erface gigabitethernet0/1 mon collection stats 2 owner root tting by entering the show rmon statistics privileged EXEC command.

sdm prefer

Use the **sdm prefer** global configuration command to configure the template used in Switch Database Management (SDM) resource allocation. If the switch is running the metro IP access image, you can use a template to balance resources between Layer 2 and Layer 3 functionality, or you can maximize system usage to support only Layer 2 features in hardware. Use the **no** form of this command to return to the default template.

sdm prefer {default | layer-2}

no sdm prefer

Syntax Description	default	Give balance to all functions.	
	layer-2	Maximizes system resources for Layer 2 functionality and does not support routing in hardware.	
Defaults	The default templ	ate provides a balance to all features.	
<u>Note</u>	On switches that are running the metro base image or the metro access image, only the layer-2 templa is supported.		
Command Modes	Global configurat	ion	
Command History	Release 12.2(25)EX	Modification This command was introduced.	
Usage Guidelines	You must reload t	he switch for the configuration to take effect. If you enter the show sdm prefer you enter the reload privileged EXEC command, the show sdm prefer command	
	The default templ not have routing e	te currently in use and the template that will become active after a reload. ates balances the use of system resources. Do not use the default template if you do enabled on your switch. Using the balanced template prevents Layer 2 features from allocated to unicast routing in the default template.	
	Do not use the layer-2 template if the switch is routing packets. The layer-2 template does not support routing and forces any routing to be done through software. This overloads the CPU and severely degrades routing performance.		
	running the metro approximately 102	approximate number of each resource supported in each of the templates for a switch IP access image. The values in the template are based on eight routed interfaces and 24 VLANs and represent the approximate hardware boundaries set when a template is on of a hardware resource is full, all processing overflow is sent to the CPU, seriously	

Resource	Layer-2	Default	
Unicast MAC addresses	8 K	1 K	
IPv4 IGMP groups and multicast routes (default only)	_	1 K	
IP v4 IGMP groups (layer-2 template only)	1 K	-	
IPv4 multicast routes (layer-2 template only)	0	-	
IPv4 IGMP groups and multicast routes	1 K	-	
IPv4 unicast routes	0	5 K	
Directly connected IPv4 hosts	_	1 K	
• Indirect IPv4 routes	_	4 K	
IPv4 policy-based routing access control entries (ACEs)	0	512	
IPv4 or MAC quality of service (QoS) ACEs	512	512	
IPv4 or MAC security ACEs	1 K	1 K	

Examples

This example shows how to configure the layer-2 template on a switch:

Switch(config)# sdm prefer layer-2
Switch(config)# exit
Switch# reload

You can verify your settings by entering the **show sdm prefer** privileged EXEC command.

Related Commands	Command	Description
	show sdm prefer	Displays the current SDM template in use or displays the templates that can
		be used, with the approximate resource allocation per feature.

service password-recovery

Use the **service password-recovery** global configuration command to enable the password-recovery mechanism (the default). This mechanism allows an end user with physical access to the switch to press the break key on the console terminal to interrupt the boot process while the switch is powering up and to assign a new password.

Use the **no** form of this command to disable part of the password-recovery functionality. When the password-recovery mechanism is disabled, interrupting the boot process is allowed only if the user agrees to set the system back to the default configuration.

service password-recovery

no service password-recovery

Syntax Description This command has no arguments or keywords.

Defaults The password-recovery mechanism is enabled.

Command Modes Global configuration

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines As a system administrator, you can use the **no service password-recovery** command to disable some of the functionality of the password recovery feature by allowing an end user to reset a password only by agreeing to return to the default configuration. This provides configuration file security by ensuring that only authenticated and authorized users have access to the configuration file and prevents users from accessing the configuration file by using the password recovery process.

The password recovery procedure requires using a break key. After the switch performs power-on self test (POST), the switch begins the autoboot process. The boot loader prompts the user for a break key character during the boot-up sequence, as shown in this example:

***** The system will autoboot in 5 seconds ***** Send a break key to prevent autobooting.

You must enter the break key on the console terminal within 5 seconds of receiving the message that the system will autoboot. A user with physical access to the switch presses the break key on the console terminal within 5 seconds of receiving the message that flash memory is initializing. The System LED flashes green until the **break key** is accepted. After the **break key** is accepted, the System LED turns off until after the switch boots.

If the password-recovery mechanism is disabled, this message appears:

The password-recovery mechanism has been triggered, but is currently disabled. Access to the boot loader prompt through the password-recovery mechanism is disallowed at this point. However, if you agree to let the system be reset back to the default system configuration, access to the boot loader prompt can still be allowed.

Would you like to reset the system back to the default configuration (y/n)?

If the user chooses not to reset the system to the default configuration, the normal boot process continues as if the **break key** had not been pressed. If you choose to reset the system to the default configuration, the configuration file in flash memory is deleted, and the VLAN database file, *flash:vlan.dat* (if present), is deleted.

Note

If you use the **no service password-recovery** command to control end user access to passwords, we recommend that you save a copy of the configuration file in a location away from the switch in case the end user uses the password recovery procedure and sets the system back to default values. Do not keep a backup copy of the configuration file on the switch.

You can enter the **show version** privileged EXEC command to determine if password recovery is enabled or disabled.

Examples

L

This example shows how to disable password recovery on a switch so that a user can only reset a password by agreeing to return to the default configuration.

Switch(config)# no service-password recovery
Switch(config)# exit

Related Commands	Command	Description
	show version	Displays version information for the hardware and firmware.

service-policy (interface configuration)

Use the **service-policy** interface configuration command to apply a policy map defined by the **policy-map** command to the incoming or outgoing traffic of a physical port. Use the **no** form of this command to remove the policy map and port association.

service-policy {input | output} policy-map-name

no service-policy {**input** | **output**} *policy-map-name*

Syntax Description	input	Apply the policy map to the input of a physical port.	
	output	Apply the policy map to the output of a physical port.	
	policy-map-name	The specified policy map to be applied.	
Note	Though visible in the o	ommand-line help strings, the history keyword is not supported, and you should	
Note	ignore the statistics tha		
Defaults	No policy maps are atta	ached to the port.	
Command Modes	Interface configuration		
Command History	Release	Modification	
	12.2(25)EX	This command was introduced.	
Usage Guidelines	You can attach input or	nap and one output policy map can be attached to an interface. output policy maps to a Fast Ethernet or Gigabit Ethernet port. You cannot attach /irtual interfaces (SVIs) and EtherChannel interfaces.	
Examples	-	w to apply <i>plcmap1</i> as an output policy map:	
	Switch(config)# interface gigabitethernet0/1 Switch(config-if)# service-policy output plcmap1		
	This example shows ho	w to remove <i>plcmap2</i> from the port:	
		rface gigabitethernet0/2 o service-policy output plcmap2	
	You can verify your set	tings by entering the show running-config privileged EXEC command.	

Related Commands	Command	Description
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays quality of service (QoS) policy maps.
	<pre>show policy-map interface [interface-id]</pre>	Displays policy maps configured on the specified interface or on all interfaces.
	show running-config	Displays the running configuration on the switch. For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands.

service-policy (policy-map class configuration)

Use the **service-policy** policy-map class configuration command to configure a quality of service (Q0S) service policy for an output policy map. Use the **no** form of this command to disable a service policy as a QoS policy within a policy map.

service-policy *policy-map-name*

no service-policy policy-map-name

Syntax Description	policy-map-name	Name of the service policy map (created by using the policy-map global configuration command) to be used in a QoS hierarchical service policy.
Defaults	No service policies ar	e defined.
Command Modes	Policy-map class conf	figuration
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	creates hierarchical p	olicy created in policy-map class configuration to a parent output policy map. This olicy mapping. Use the service-policy <i>policy-map-name</i> policy-map class nd to enter a second-level (child) policy map.
	maps by attaching a s	is also configured on the class class-default , you can configure hierarchical policy ingle service-policy policy-map class command to the class class-default . This he service policy for the port-shaped traffic on the port and is the parent policy
	•	child policy with class-based queuing actions by using the queue-limit policy map ith scheduling actions (by using the bandwidth , shape average , or priority
	To return to policy-ma use the end command	p configuration mode, use the exit command. To return to privileged EXEC mode,
Examples		now to define the service policy and to attach it to a parent policy map to set the (shape) for an output queue at 90000000 bits per second:
	Switch(config-pmap) Switch(config-pmap-	

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays quality of service (QoS) policy maps.

set cos

Use the **set cos** policy-map class configuration command to set a Layer 2 class of service (CoS) value in the packet. Use the **no** form of this command to remove traffic marking.

set cos {cos_value | from-field [table table-map-name]}

no set cos {*cos_value* | *from-field* [**table** *table-map-name*]}

Syntax Description	cos_value	Enter an IEEE 802.1Q class of service/user priority value with which to classify traffic. The range is from 0 to 7.
	from-field	Specific a packet-marking category to be used to set the CoS value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
		These options are supported:
		• cos —CoS value
		• dscp —Differentiated Services Code Point (DSCP) value.
		• precedence—IP-precedence value
	table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the CoS value
	table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the CoS value. The table map name can be a maximum of 64 alphanumeric characters.
Command Modes	Policy-map class con	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines		mand if you want to mark a packet that is being sent to a switch. Switches can der information including a CoS value marking.
	configuration comma based on the CoS ma	ch cos class-map configuration command and the set cos policy-map class and together to allow switches to interoperate and provide quality of service (QoS) rkings. You can also configure Layer 2 to Layer 3 mapping by matching on the CoS nes can already match and set CoS values.
		command to perform enhanced packet marking, you can use the <i>from-field</i> packet napping and setting the CoS value. The supported <i>from-field</i> marking categories are: precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the CoS value. For example, if you enter the **set cos precedence** command, the precedence value is copied and used as the CoS value. If you enter the **set cos dscp** command, the DSCP value is copied and used as the CoS value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

```
Examples
```

This example shows how to set all FTP traffic to cos 3:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set cos 3
Switch(config-pmap-c)# exit
```

This example shows how to assign a DSCP to CoS table map to a class:

```
Switch(config)# policy-map inpolicy
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# set cos dscp table dscp-cos-tablemap
Switch(config-pmap)# exit
```

You can verify your settings by entering the show policy-map privileged EXEC command.

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays QoS policy maps.

set dscp

Use the **set** [**ip**] **dscp** policy-map class configuration command to mark IPv4 traffic by setting a Differentiated Services Code Point (DSCP) value in the type of service (ToS) byte of the packet. Use the **no** form of this command to remove traffic marking.

set [ip] dscp {dscp_value |from-field [table table-map-name]}

no set [ip] dscp {dscp_value | from-field [table table-map-name]}



Entering **ip dscp** is the same as entering **dscp**.

Syntax Description	dscp-value	Enter a DSCP value with which to classify traffic. The range is from 0 to 63. You also can enter a mnemonic name for a commonly used value.
	from-field	Specific a packet-marking category to be used to set the DSCP value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
		These options are supported:
		• cos —class of service (CoS) value
		• dscp —DSCP value.
		• precedence—IP-precedence value
	table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the DSCP value
	table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the DSCP value. The table map name can be a maximum of 64 alphanumeric characters.
Defaults	No traffic marking i	s defined.
Command Modes	Policy-map class co	nfiguration
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines		set dscp command with the set precedence command to mark the same packet. precedence values are mutually exclusive. A packet can have one value of the other,

After DSCP bits are set, other quality of service (QoS) features can then operate on the bit settings.

The network gives priority (or some type of expedited handling) to marked traffic. Typically, you set the DSCP value at the edge of the network (or administrative domain) and data is then queued according to the precedence. Class-based weighted fair queuing (CBWFQ) can speed up handling for

high-precedence traffic at congestion points. Weighted Tail Drop (WTD) ensures that high-precedence traffic has lower loss rates than other traffic during times of congestion.

Instead of using numeric values, you can also specify the *dscp-value* by using the reserved keywords **EF**, **AF11**, and **AF12**.

If you are using this command to perform enhanced packet marking, you can use the *from-field* packet marking option for mapping and setting the DSCP value. The supported *from-field* marking categories are: CoS, DSCP, and IP precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the DSCP value. For example, if you enter the **set dscp cos** command, the CoS value is copied and used as the DSCP value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

Examples	This example shows how to set all FTP traffic to DSCP 10:			
	<pre>Switch(config)# policy-map policy_ftp Switch(config-pmap)# class ftp_class Switch(config-pmap-c)# set dscp 10 Switch(config-pmap-c)# exit</pre>			
	This example shows how to assign a CoS to DSCP table map to a class:			
	<pre>Switch(config)# policy-map inpolicy Switch(config-pmap)# class class-default Switch(config-pmap-c)# set dscp cos table cos-dscp-tablemap Switch(config-pmap)# exit</pre>			

You can verify your settings by entering the **show policy-map** privileged EXEC command.

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays QoS policy maps.

set precedence

Use the **set [ip] precedence** policy-map class configuration command to mark IPv4 traffic by setting an IP-precedence value in the packet. Use the **no** form of this command to remove traffic marking.

set [ip] precedence {precedence_value | from-field [table table-map-name]}

no set [**ip**] **precedence** {*precedence_value* | *from-field* [**table** *table-map-name*]}



Entering **ip precedence** is the same as entering **precedence**.

\overline{f}		Enter an IPv4 precedence value with which to classify traffic. The range is 0 to 7. You also can enter a mnemonic name for a commonly used value.
	from-field	Specific a packet-marking category to be used to set the precedence value of the packet. If you are using a table map for mapping and converting packet-marking values, this establishes the <i>map-from</i> packet-marking category.
		These options are supported:
		• cos —class of service (CoS) value
		• dscp —Differentiated Services Code Point (DSCP) value.
		• precedence—IP-precedence value
1	table	(Optional) Used in conjunction with the <i>from-field</i> keyword. Indicates that the values set in a specified table map are used to set the precedence value
1	table-map-name	(Optional) Used in conjunction with the table keyword. Name of the table map used to specify the precedence value. The table map name can be a maximum of 64 alphanumeric characters.
Defaults N	No traffic marking is	defined.
Command Modes P	Policy-map class con	figuration
Command History	Release	Modification
-	12.2(25)EX	This command was introduced.

The network gives priority (or some type of expedited handling) to marked traffic. Typically, you set the precedence value at the edge of the network (or administrative domain) and data is then queued according to the precedence. Class-based weighted fair queuing (CBWFQ) can speed up handling for high-precedence traffic at congestion points. Weighted Tail Drop (WTD) ensures that high-precedence traffic has lower loss rates than other traffic during times of congestion.

Instead of using numeric values, you can also specify the *dscp-value* by using the reserved keywords EF, AF11, and AF12.

If you are using this command to perform enhanced packet marking, you can use the *from-field* packet marking option for mapping and setting the precedence value. The supported *from-field* marking categories are: CoS, DSCP, and IP precedence.

If you specify a *from-field* category, but do not specify the **table** keyword and *table-map-name*, the default action is to copy the value associated with the *from-field* category as the precedence value. For example, if you enter the **set precedence cos** command, the CoS value is copied and used as the precedence value.

You can configure only one table-map **set** action for a class. No other **set** action can be configured for a class with a table-map set action.

Examples

This example shows how to give all FTP traffic an IP precedence value of 5:

```
Switch(config)# policy-map policy_ftp
Switch(config-pmap)# class ftp_class
Switch(config-pmap-c)# set precedence 5
Switch(config-pmap-c)# exit
```

This example shows how to assign a CoS to precedence table map to a class:

```
Switch(config)# policy-map inpolicy
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# set precedence cos table cos-prec-tablemap
Switch(config-pmap)# exit
```

You can verify your settings by entering the show policy-map privileged EXEC command.

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays QoS policy maps.

set qos-group

Use the **set qos-group** policy-map class configuration command to set a a quality of service (QoS) group identifier that can be used later to classify packets. Use the **no** form of this command to remove the group identifier.

set qos-group value

no set qos-group value

Syntax Description	value	Set the QoS group value to use to classify traffic. The range is from 0 to 15.	
Defaults	No traffic marking	is defined.	
Command Modes	Policy-map class c	onfiguration	
Command History	Release	Modification	
	12.2(25)EX	This command was introduced.	
Usage Guidelines	Use this command to associate a QoS group value with a traffic flow as it enters the switch, which can then be used in an output policy map to identify the flow. When a set qos-group is configured in a class in an input policy map, no other set operations are allowed in the class.		
	A maximum of 16	QoS groups (0 through 15) is supported on the switch.	
		map configuration mode, use the exit command. To return to privileged EXEC mode,	
Examples	This example show	vs how to set all FTP traffic to QoS group 5:	
	Switch(config-pma	policy-map policy_ftp ap)# class ftp_class ap-c)# set qos-group 5 ap-c)# exit	
	You can verify you	r settings by entering the show policy-map privileged EXEC command.	

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays QoS policy maps.

setup

Use the setup privileged EXEC command to configure the switch with its initial configuration. setup Syntax Description This command has no arguments or keywords. **Command Modes** Privileged EXEC **Command History** Release Modification 12.2(25)EX This command was introduced. **Usage Guidelines** When you use the setup command, make sure that you have this information: • IP address and network mask • Password strategy for your environment When you enter the setup command, an interactive dialog, called the System Configuration Dialog, appears. It guides you through the configuration process and prompts you for information. The values shown in brackets next to each prompt are the default values last set by using either the **setup** command facility or the configure privileged EXEC command. Help text is provided for each prompt. To access help text, press the question mark (?) key at a prompt. To return to the privileged EXEC prompt without making changes and without running through the entire System Configuration Dialog, press Ctrl-C. When you complete your changes, the setup program shows you the configuration command script that was created during the setup session. You can save the configuration in NVRAM or return to the setup program or the command-line prompt without saving it. Examples This is an example of output from the **setup** command: Switch# setup --- System Configuration Dialog ---Continue with configuration dialog? [yes/no]: yes At any point you may enter a question mark '?' for help. Use ctrl-c to abort configuration dialog at any prompt. Default settings are in square brackets '[]'. Basic management setup configures only enough connectivity for management of the system, extended setup will ask you to configure each interface on the system. Would you like to enter basic management setup? [yes/no]: yes Configuring global parameters:

Enter host name [Switch]: host-name The enable secret is a password used to protect access to privileged EXEC and configuration modes. This password, after entered, becomes encrypted in the configuration. Enter enable secret: enable-secret-password The enable password is used when you do not specify an enable secret password, with some older software versions, and some boot images. Enter enable password: enable-password The virtual terminal password is used to protect access to the router over a network interface. Enter virtual terminal password: terminal-password Configure SNMP Network Management? [no]: yes Community string [public]: Current interface summary Any interface listed with OK? value "NO" does not have a valid configuration Interface IP-Address OK? Method Status Protocol Vlan1 172.20.135.202 YES NVRAM up up GigabitEthernet0/1 unassigned YES unset up up GigabitEthernet0/2 unassigned down YES unset up <output truncated> Port-channel1 unassigned YES unset. up down Enter interface name used to connect to the management network from the above interface summary: **vlan1** Configuring interface vlan1: Configure IP on this interface? [yes]: yes IP address for this interface: *ip_address* Subnet mask for this interface [255.0.0.0]: subnet_mask The following configuration command script was created: hostname host-name enable secret 5 \$1\$LiBw\$0Xc1wyT.PXPkuhFwqyhVi0 enable password enable-password line vty 0 15 password terminal-password snmp-server community public 1 no ip routing ! interface GigabitEthernet0/1 no ip address interface GigabitEthernet0/2 no ip address 1 end

Use this configuration? [yes/no]: yes
!
[0] Go to the IOS command prompt without saving this config.
[1] Return back to the setup without saving this config.
[2] Save this configuration to nvram and exit.
Enter your selection [2]:

Related Commands	Command	Description
	show running-config	Displays the running configuration on the switch. For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands.
	show version	Displays version information for the hardware and firmware.

shape average

Use the **shape average** policy-map class configuration command to configure class-based shaping by specifying the average traffic shaping rate. Use the command with the class class-default to set port shaping. Use the **no** form of this command to remove traffic shaping.

shape average target bps

no shape average target bps

Syntax Description	target bps	Target average bit rate in bits per second (bps). The range is from 64000 to 1000000000.	
Defaults	No traffic shaping i	is defined.	
Command Modes	Policy-map class co	onfiguration	
Command History	Release	Modification	
	12.2(25)EX	This command was introduced.	
Usage Guidelines	You use the shape a in input policy map	werage policy-map class command to control output traffic. Shaping is not supported	
	Traffic shaping limits the rate of transmission of data. Configuring traffic shaping for a user-defined class for class-based shaping sets the peak information rate (PIR) for that class. Configuring traffic shaping for the class class-default when it is the only class in the policy map that is attached to an interface sets the PIR for the interface (port shaping).		
	You cannot configure shape average in a class that includes priority queueing (configured with the priority policy-map class configuration command).		
	The shape average command uses a default queue limit for the class. You can change the queue limit by using the queue-limit policy-map class command, overriding the default that is set by the shape average command.		
	You cannot use the bandwidth policy-map class configuration command to configure class-based weighted fair queuing (CBWFQ) and the shape average command to configure traffic shaping for the same class.		
	You can configure hierarchical policy maps by attaching the service-policy policy-map class command to the class class-default only when shape average is also configured on the class class-default .		
		(class-default), only output shaping configuration is allowed. You cannot configure or scheduling actions.	
	To return to policy- use the end comma	map configuration mode, use the exit command. To return to privileged EXEC mode, nd.	

Examples

This example shows how to configure traffic shaping for outgoing traffic on a Fast Ethernet port so that *outclass1*, *outclass2*, and *outclass3* get a maximum of 50, 20, and 10 Mbps of the buffer size. The class **class-default** gets the remaining bandwidth.

```
Switch(config)# policy-map out-policy
Switch(config-pmap)# class classout1
Switch(config-pmap-c)# shape average 50000000
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# shape average 20000000
Switch(config-pmap-c)# shape average 20000000
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# shape average 10000000
Switch(config-pmap-c)# exit
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
Switch(config-pmap)# exit
Switch(config)# interface fastethernet 0/1
Switch(config-if)# service-policy out out-policy
```

This example shows how to configure port shaping by configuring a hierarchical policy map that shapes a port to 90 Mbps, allocated according to the *out-policy* policy map configured in the previous example.

```
Switch(config)# policy-map out-policy-parent
Switch(config-pmap)# class class-default
Switch(config-pmap-c)# shape average 90000000
Switch(config-pmap-c)# service-policy out-policy
Switch(config-pmap-c)# exit
Switch(config-pmap)# exit
```

You can verify your settings by entering the show policy-map privileged EXEC command.

Related Commands	Command	Description
	class	Defines a traffic classification match criteria for the specified class-map name.
	policy-map	Creates or modifies a policy map that can be attached to multiple ports to specify a service policy.
	show policy-map	Displays QoS policy maps.
	<pre>show policy-map interface [interface-id]</pre>	Displays policy maps configured on the specified interface or on all interfaces.

78-17060-01

show access-lists

Use the **show access-lists** privileged EXEC command to display access control lists (ACLs) configured on the switch.

show access-lists [name | number | hardware counters | ipc] [| {begin | exclude | include}
expression]

Syntax Description	name	(Optional) Name of the ACL.
	number	(Optional) ACL number. The range is 1 to 2699.
	hardware counters	(Optional) Display global hardware ACL statistics for switched and routed packets.
	ірс	(Optional) Display Interprocess Communication (IPC) protocol access-list configuration download information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Note

Though visible in the command-line help strings, the **rate-limit** keywords are not supported.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines The switch supports only IP standard and extended access lists. Therefore, the allowed numbers are only 1 to 199 and 1300 to 2699.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show access-lists** command:

```
Switch# show access-lists
Standard IP access list 1
    10 permit 1.1.1.1
    20 permit 2.2.2.2
    30 permit any
    40 permit 0.255.255.255, wildcard bits 12.0.0.0
Standard IP access list videowizard_1-1-1-1
    10 permit 1.1.1.1
Standard IP access list videowizard_10-10-10-10
    10 permit 10.10.10.10
Extended IP access list 121
    10 permit ahp host 10.10.10.10 host 20.20.10.10 precedence routine
```

This is an example of output from the show access-lists hardware counters command:

```
Switch# show access-lists hardware counters
L2 ACL INPUT Statistics
                         All frame count: 855
     Drop:
     Drop:
                        All bytes count: 94143
                        All frame count: 0
     Drop And Log:
                        All bytes count: 0
     Drop And Log:
                         All frame count: 0
     Bridge Only:
     Bridge Only:
                         All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
     Forwarding To CPU: All frame count: 0
     Forwarding To CPU: All bytes count: 0
     Forwarded:
                        All frame count: 2121
     Forwarded:
                        All bytes count: 180762
     Forwarded And Log: All frame count: 0
     Forwarded And Log: All bytes count: 0
 L3 ACL INPUT Statistics
                         All frame count: 0
    Drop:
                        All bytes count: 0
     Drop:
     Drop And Log:
                        All frame count: 0
     Drop And Log:
                        All bytes count: 0
     Bridge Only:
                        All frame count: 0
     Bridge Only:
                        All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
    Forwarding To CPU: All frame count: 0
Forwarding To CPU: All bytes count: 0
     Forwarded:
                         All frame count: 13586
     Forwarded:
                        All bytes count: 1236182
     Forwarded And Log: All frame count: 0
     Forwarded And Log: All bytes count: 0
 L2 ACL OUTPUT Statistics
             All frame count: 0
     Drop:
                         All bytes count: 0
     Drop:
                        All frame count: 0
     Drop And Log:
                        All bytes count: 0
     Drop And Log:
                        All frame count: 0
     Bridge Only:
     Bridge Only:
                        All bytes count: 0
     Bridge Only And Log: All frame count: 0
     Bridge Only And Log: All bytes count: 0
     Forwarding To CPU: All frame count: 0
     Forwarding To CPU: All bytes count: 0
                All frame count: 232983
All bytes count: 16825661
     Forwarded:
     Forwarded:
     Forwarded And Log: All frame count: 0
```

	Forwarded And Log:	A11	bytes	count:	0
L3	ACL OUTPUT Statistics				
	Drop:	A11	frame	count:	0
	Drop:	A11	bytes	count:	0
	Drop And Log:	A11	frame	count:	0
	Drop And Log:	A11	bytes	count:	0
	Bridge Only:	A11	frame	count:	0
	Bridge Only:	A11	bytes	count:	0
	Bridge Only And Log:	A11	frame	count:	0
	Bridge Only And Log:	A11	bytes	count:	0
	Forwarding To CPU:	A11	frame	count:	0
	Forwarding To CPU:	A11	bytes	count:	0
	Forwarded:	A11	frame	count:	514434
	Forwarded:	A11	bytes	count:	39048748
	Forwarded And Log:	A11	frame	count:	0
	Forwarded And Log:	A11	bytes	count:	0

Related Commands	Command	Description
	access-list	Configures a standard or extended numbered access list on the switch. For syntax information, select Cisco IOS IP Command Reference , Volume 1 of 3:Addressing and Services , Release 12.2 > IP Services Commands.
	ip access list	Configures a named IP access list on the switch. For syntax information, select Cisco IOS IP Command Reference, Volume 1 of 3:Addressing and Services, Release 12.2 > IP Services Commands.
	mac access-list extended	Configures a named or numbered MAC access list on the switch.

show archive status

Use the **show archive status** privileged EXEC command to display the status of a new image being downloaded to a switch with the HTTP or the TFTP protocol.

show archive status [|{begin | exclude | include} expression]

	(Optional) Display begins with the line that matches the <i>expression</i> .
	(Optional) Display excludes lines that match the <i>expression</i> .
	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point.
Privileged EX	KEC
Release	Modification
12.2(25)EX	This command was introduced.
•	archive download-sw privileged EXEC command to download an image to a TFTP server, the archive download-sw command shows the status of the download.
-	are case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> ayed, but the lines that contain <i>Output</i> are displayed.
These are exa	amples of output from the show archive status command:
	v archive status grade in progress
	v archive status grade in progress
	w archive status tracting the image
	w archive status ifying software
	v archive status rade completed. Reload pending
Command	Description
	Release12.2(25)EXIf you use the the output of Expressions a are not displaThese are exa switch# show IDLE: No upgSwitch# show LOADING: UpgSwitch# show EXTRACT: Ext Switch# show VERIFY: Veri Switch# show

show arp access-list

Use the **show arp access-list** user EXEC command to display detailed information about Address Resolution Protocol (ARP) access control (lists).

show arp access-list [acl-name] [| {begin | exclude | include} expression]

This command is available only if your switch is running the metro IP access or metro access image.

Syntax Description	acl-name	(Optional) Nam	ne of the ACL.
	begin	(Optional) Disp	play begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Disp	play excludes lines that match the <i>expression</i> .
	include	(Optional) Disp	play includes lines that match the specified expression.
	expression	Expression in t	he output to use as a reference point.
Command Modes	User EXEC		
Command History	Release	Mod	ification
	12.2(25)EX	This	command was introduced.
Examples	This is an example of output from the show arp access-list command:		
	ARP access l permit i		0.0.255 mac any
Related Commands	Command		Description
	arp access-lis	st	Defines an ARP ACL.
	deny (ARP a configuration		Denies an ARP packet based on matches against the Dynamic Host Configuration Protocol (DHCP) bindings.
	ip arp inspec	tion filter vlan	Permits ARP requests and responses from a host configured with a static IP address.
	permit (ARP configuration		Permits an ARP packet based on matches against the DHCP bindings.

show boot

Use the **show boot** privileged EXEC command to display the settings of the boot environment variables.

show boot [| {begin | exclude | include} expression]

I begin I exclude I include expression Privileged EXEC Release 10.00000000	(Optional) Display begins with the line that matches the expression. (Optional) Display excludes lines that match the expression. (Optional) Display includes lines that match the specified expression. Expression in the output to use as a reference point. Modification
l include expression Privileged EXEC Release	(Optional) Display includes lines that match the specified <i>expression</i> . Expression in the output to use as a reference point.
expression Privileged EXEC Release	Expression in the output to use as a reference point.
Privileged EXEC Release	
Release	Modification
	Modification
10.0(05)EX	
12.2(25)EX	This command was introduced.
1	se sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> but the lines that contain <i>Output</i> are displayed.
This is an example	of output from the show boot command. Table 2-5 describes each field in the display.
BOOT path-list Config file	: IFIG_I: Configured from console by console : : flash:/config.text .le : flash:/private-config.text : no
	are not displayed, b This is an example Switch# show boot 5d05h: %SYS-5-CON BOOT path-list

Table 2-5show boot Field Descriptions

Field	Description	
BOOT path-list	Displays a semicolon separated list of executable files to try to load and execute when automatically booting.	
	If the BOOT environment variable is not set, the system attempts to load and execute the first executable image it can find by using a recursive, depth-first search through the flash file system. In a depth-first search of a directory, each encountered subdirectory is completely searched before continuing the search in the original directory.	
	If the BOOT variable is set but the specified images cannot be loaded, the system attempts to boot the first bootable file that it can find in the flash file system.	
Config file	Displays the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.	

Field	Description
Private Config file Displays the filename that Cisco IOS uses to read and write a nonvol system configuration.	
Enable Break	Displays whether a break during booting is enabled or disabled. If it is set to yes, on, or 1, you can interrupt the automatic boot process by pressing the Break key on the console after the flash file system is initialized.
Manual Boot	Displays whether the switch automatically or manually boots. If it is set to no or 0, the boot loader attempts to automatically boot the system. If it is set to anything else, you must manually boot the switch from the boot loader mode.
Helper path-list	Displays a semicolon separated list of loadable files to dynamically load during the boot loader initialization. Helper files extend or patch the functionality of the boot loader.

Table 2-5	show boot Field Descriptions (continued)
-----------	--

Related Commands	Command	Description
	boot config-file	Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the system configuration.
	boot enable-break	Enables interrupting the automatic boot process.
	boot manual	Enables manually booting the switch during the next boot cycle.
	boot private-config-file	Specifies the filename that Cisco IOS uses to read and write a nonvolatile copy of the private configuration.
	boot system	Specifies the Cisco IOS image to load during the next boot cycle.

show cable-diagnostics tdr

Use the **show cable-diagnostics tdr** privileged EXEC command to display the Time Domain Reflector (TDR) results.

show cable-diagnostics tdr interface interface-id [| {begin | exclude | include} expression]

TDR is supported only on the copper Ethernet 10/100 ports on the Cisco ME switch.

Syntax Description	interface-id	Specify the interface on which TDR was run.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines TDR is supported only on copper Ethernet 10/100 ports on the Cisco ME switch. It is not supported on small form-factor pluggable (SFP)-module ports. For more information about TDR, see the software configuration guide for this release.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples	This is an example of output from the show cable-diagnostics tdr interface <i>interface-id</i> command on a Cisco ME switch:
	Switch# show cable-diagnostics tdr interface fastethernet0/1 TDR test last run on: March 01 18:14:44

Interface	Speed	Local pair	Pair	length		Remote pair	Pair status
Fa0/1	100M	Pair A	4	+/- 5	meters	Pair A	Normal
		Pair B	4	+/- 5	meters	Pair B	Normal
		Pair C	N/A			Pair C	N/A
		Pair D	N/A			Pair D	N/A

Table 2-6 lists the descriptions of the fields in the show cable-diagnostics tdr command output.

Field	Description				
Interface	Interface on which TDR was run.				
Speed	Speed of connection.				
Local pair	Name of the pair of wires that TDR is testing on the local interface.				
Pair length	Location on the cable where the problem is, with respect to your switch. TDR can only find the location in one of these cases:				
	• The cable is properly connected, the link is up, and the interface speed is 100 Mbps.				
	• The cable is open.				
	• The cable has a short.				
Remote pair	Name of the pair of wires to which the local pair is connected. TDR can learn about the remote pair only when the cable is properly connected and the link is up.				
Pair status	The status of the pair of wires on which TDR is running:				
	• Normal—The pair of wires is properly connected.				
	• Not completed—The test is running and is not completed.				
	• Not supported—The interface does not support TDR.				
	• Open—The pair of wires is open.				
	• Shorted—The pair of wires is shorted.				

 Table 2-6
 Fields Descriptions for the show cable-diagnostics tdr Command Output

This is an example of output from the **show interface** *interface-id* command when TDR is running:

```
Switch# show interface fastethernet0/1
fastethernet0/1 is up, line protocol is up (connected: TDR in Progress)
```

This is an example of output from the **show cable-diagnostics tdr interface** *interface-id* command when TDR is not running:

Switch# show cable-diagnostics tdr interface fastethernet0/1 % TDR test was never issued on fa0/1

If an interface does not support TDR, this message appears:

% TDR test is not supported on switch 1

Related Commands	Command	Description
	test cable-diagnostics tdr	Enables and runs TDR on an interface.

show class-map

Use the **show class-map** user EXEC command to display quality of service (QoS) class maps, which define the match criteria to classify traffic.

show class-map [class-map-name] [| {begin | exclude | include} expression]

Syntax Description	class-map-name	(Optional) Display the contents of the specified class map.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Examples	This is an example	of output from the show class-map command:
Examples	Switch> show cla	
	Class Map match-	all videowizard_10-10-10 (id 2) group name videowizard_10-10-10-10
	Match any	-any class-default (id 0) -all dscp5 (id 3) 5
Related Commands	Command	Description
	class-map	Creates a class map to be used for matching packets to the class whose name you specify.

Defines the match criteria to classify traffic.

match access-group

show controllers cpu-interface

Use the **show controllers cpu-interface** privileged EXEC command to display the state of the CPU network interface ASIC and the send and receive statistics for packets reaching the CPU.

show controllers cpu-interface [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional)	Display beg	gins with the	line that matches	the expression.	
	exclude	(Optional)	Display exc	cludes lines t	hat match the exp	ression.	
	include	(Optional)	Display inc	ludes lines t	hat match the spe	cified expression	n.
	expression	Expression	in the outp	out to use as	a reference point.		
Command Modes	Privileged EXEC						
Command History	Release	Modif	ication				
-	12.2(25)EX	This c	command w	as introduce	d.		
xamples	Expressions are cas are not displayed, b This is a partial out	out the lines t put example	hat contain from the sh	<i>Output</i> are d	isplayed.		ontain <i>outp</i>
Examples	are not displayed, b	put the lines t put example rollers cpu	hat contain from the sh -interface	<i>Output</i> are d	isplayed.		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont	put the lines t put example rollers cpu	hat contain from the sh -interface	<i>Output</i> are d	lisplayed. ers cpu-interface		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames	put the lines t put example rollers cpu retrieved	hat contain from the sh -interface dropped	Output are d	lisplayed. ers cpu-interface hol-block		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc	put the lines t put example rollers cpu retrieved 4523063 1545035 1903047	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol	put the lines t put example rollers cpu retrieved 4523063 1545035 1903047 96145	hat contain from the sh -interface dropped 0 0 0 0	Output are d now controll invalid 0 0 0 0	lisplayed. ers cpu-interface hol-block 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol	put the lines t put example relieved 4523063 1545035 1903047 96145 79596	hat contain from the sh -interface dropped 0 0 0 0 0 0 0	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console	put the lines t put example relieved 4523063 1545035 1903047 96145 79596 0	hat contain from the sh -interface dropped 0 0 0 0 0 0 0 0 0	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding	put the lines t put example relieved 4523063 1545035 1903047 96145 79596 0 5756	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host	put the lines t put example relieved 	hat contain from the sh -interface dropped 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast	put the lines t put example retrieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast cbt-to-spt	put the lines t put example relieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast cbt-to-spt igmp snooping	put the lines t put example relieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast cbt-to-spt igmp snooping icmp	put the lines t put example relieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast cbt-to-spt igmp snooping icmp logging	put the lines t put example relieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>
xamples	are not displayed, b This is a partial out Switch# show cont cpu-queue-frames rpc stp ipc routing protocol L2 protocol remote console sw forwarding host broadcast cbt-to-spt igmp snooping icmp	put the lines t put example relieved 	hat contain from the sh -interface dropped 	Output are d	lisplayed. ers cpu-interface hol-block 0 0 0 0 0 0 0 0 0 0 0 0 0		ontain <i>outp</i>

Supervisor ASIC receive-queue parameters _____ queue 0 maxrecevsize 5EE pakhead 1419A20 paktail 13EAED4 queue 1 maxrecevsize 5EE pakhead 15828E0 paktail 157FBFC queue 2 maxrecevsize 5EE pakhead 1470D40 paktail 1470FE4 queue 3 maxrecevsize 5EE pakhead 19CDDD0 paktail 19D02C8 <output truncated> Supervisor ASIC Mic Registers 80000800 MicDirectPollInfo MicIndicationsReceived 00000000 00000000 MicInterruptsReceived MicPcsInfo 0001001F MicPlbMasterConfiguration 00000000 MicRxFifosAvailable 00000000 MicRxFifosReady 0000BFFF MicTimeOutPeriod: FrameTOPeriod: 00000EA6 DirectTOPeriod: 00004000 <output truncated> MicTransmitFifoInfo: Fifo0: StartPtrs: 038C2800 ReadPtr: 038C2C38 WritePtrs: 038C2C38 Fifo_Flag: 8A800800 Weights: 001E001E Fifol: StartPtr: 03A9BC00 ReadPtr: 03A9BC60 Fifo_Flag: 89800400 WritePtrs: 03A9BC60 writeHeaderPtr: 03A9BC60 038C8800 038C88E0 Fifo2: StartPtr: ReadPtr: 038C88E0 88800200 WritePtrs: Fifo_Flag: writeHeaderPtr: 038C88E0 Fifo3: StartPtr: 03C30400 ReadPtr: 03C30638 WritePtrs: 03C30638 Fifo_Flag: 89800400 writeHeaderPtr: 03C30638 Fifo4: StartPtr: 03AD5000 ReadPtr: 03AD50A0 WritePtrs: 03AD50A0 Fifo_Flag: 89800400 writeHeaderPtr: 03AD50A0 Fifo5: StartPtr: 03A7A600 ReadPtr: 03A7A600 88800200 WritePtrs: 03A7A600 Fifo_Flag: writeHeaderPtr: 03A7A600 Fifo6: StartPtr: 03BF8400 ReadPtr: 03BF87F0 WritePtrs: 03BF87F0 Fifo_Flag: 89800400

<output truncated>

Related Commands	Command	Description
	show controllers ethernet-controller	Displays per-interface send and receive statistics read from the hardware or the interface internal registers.
	show interfaces	Displays the administrative and operational status of all interfaces or a specified interface.

show controllers ethernet-controller

Use the **show controllers ethernet-controller** privileged EXEC command without keywords to display per-interface send and receive statistics read from the hardware. Use with the **phy** keyword to display the interface internal registers or the **port-asic** keyword to display information about the port ASIC.

show controllers ethernet-controller [interface-id] [phy [detail]] [port-asic {configuration |
 statistics}] [| {begin | exclude | include} expression]

Syntax Description	interface-id	The physical interface (including type, module, and port number).				
Syntax Description						
	phy	(Optional) Display the status of the internal registers on the switch physical layer device (PHY) for the device or the interface. This display includes the operational				
		state of the automatic medium-dependent interface crossover (Auto-MDIX)				
		feature on an interface.				
	detail	(Optional) Display details about the PHY internal registers.				
	port-asic	(Optional) Display information about the port ASIC internal registers.				
	configuration	Display port ASIC internal register configuration.				
	statistics	Display port ASIC statistics, including the Rx/Sup Queue and miscellaneous statistics.				
	begin	(Optional) Display begins with the line that matches the expression.				
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
	include	(Optional) Display includes lines that match the specified expression.				
	<i>expression</i> Expression in the output to use as a reference point.					
Command Modes		(only supported with the <i>interface-id</i> keywords in user EXEC mode)				
Command History	Release	Modification				
	12.2(25)EX	This command was introduced.				
Usage Guidelines		out keywords provides traffic statistics, basically the RMON statistics for all interfaces				
	or for the specified interface.					
	•	he phy or port-asic keywords, the displayed information is useful primarily for Cisco				
	technical support	representatives troubleshooting the switch.				

Examples

This is an example of output from the **show controllers ethernet-controller** command for an interface. Table 2-7 describes the *Transmit* fields, and Table 2-8 describes the *Receive* fields.

Switch# show controllers ethernet-controller gigabitethernet0/1

Switch# sho	ow controllers ethernet-contr	roller g	igabitethernet0/1
Transmit Gi	igabitEthernet0/1	Receive	
0	Bytes	0	Bytes
0	Unicast frames	0	Unicast frames
-	Multicast frames	-	Multicast frames
0	Broadcast frames	0	Broadcast frames
0	Too old frames	0	Unicast bytes
-	Deferred frames	0	Multicast bytes
0	MTU exceeded frames	0	Broadcast bytes
	1 collision frames		Alignment errors
	2 collision frames		FCS errors
0	3 collision frames		Oversize frames
	4 collision frames	0	Undersize frames
-	5 collision frames	0	Collision fragments
	6 collision frames		
	7 collision frames		Minimum size frames
	8 collision frames		65 to 127 byte frames
0	9 collision frames	0	128 to 255 byte frames
0	10 collision frames	0	256 to 511 byte frames
	11 collision frames		512 to 1023 byte frames
	12 collision frames		1024 to 1518 byte frames
	13 collision frames		Overrun frames
	14 collision frames		Pause frames
	15 collision frames	0	Symbol error frames
	Excessive collisions		
	Late collisions		Invalid frames, too large
	VLAN discard frames		Valid frames, too large
	Excess defer frames		Invalid frames, too small
	64 byte frames	0	Valid frames, too small
	127 byte frames		
	255 byte frames		Too old frames
	511 byte frames		Valid oversize frames
	1023 byte frames		System FCS error frames
	1518 byte frames	0	RxPortFifoFull drop frame
	Too large frames		
0	Good (1 coll) frames		

Table 2-7 Transmit Field Descriptions

Field	Description
Bytes	The total number of bytes sent on an interface.
Unicast Frames	The total number of frames sent to unicast addresses.
Multicast frames	The total number of frames sent to multicast addresses.
Broadcast frames	The total number of frames sent to broadcast addresses.
Too old frames	The number of frames dropped on the egress port because the packet aged out.
Deferred frames	The number of frames that are not sent after the time exceeds 2*maximum-packet time.
MTU exceeded frames	The number of frames that are larger than the maximum allowed frame size.
1 collision frames	The number of frames that are successfully sent on an interface after one collision occurs.
2 collision frames	The number of frames that are successfully sent on an interface after two collisions occur.
3 collision frames	The number of frames that are successfully sent on an interface after three collisions occur.
4 collision frames	The number of frames that are successfully sent on an interface after four collisions occur.

Field	Description
5 collision frames	The number of frames that are successfully sent on an interface after five collisions occur.
6 collision frames	The number of frames that are successfully sent on an interface after six collisions occur.
7 collision frames	The number of frames that are successfully sent on an interface after seven collisions occur.
8 collision frames	The number of frames that are successfully sent on an interface after eight collisions occur.
9 collision frames	The number of frames that are successfully sent on an interface after nine collisions occur.
10 collision frames	The number of frames that are successfully sent on an interface after ten collisions occur.
11 collision frames	The number of frames that are successfully sent on an interface after 11 collisions occur.
12 collision frames	The number of frames that are successfully sent on an interface after 12 collisions occur.
13 collision frames	The number of frames that are successfully sent on an interface after 13 collisions occur.
14 collision frames	The number of frames that are successfully sent on an interface after 14 collisions occur.
15 collision frames	The number of frames that are successfully sent on an interface after 15 collisions occur.
Excessive collisions	The number of frames that could not be sent on an interface after 16 collisions occur.
Late collisions	After a frame is sent, the number of frames dropped because late collisions were detected while the frame was sent.
VLAN discard frames	The number of frames dropped on an interface because the CFI ¹ bit is set.
Excess defer frames	The number of frames that are not sent after the time exceeds the maximum-packet time.
64 byte frames	The total number of frames sent on an interface that are 64 bytes.
127 byte frames	The total number of frames sent on an interface that are from 65 to 127 bytes.
255 byte frames	The total number of frames sent on an interface that are from 128 to 255 bytes.
511 byte frames	The total number of frames sent on an interface that are from 256 to 511 bytes.
1023 byte frames	The total number of frames sent on an interface that are from 512 to 1023 bytes.
1518 byte frames	The total number of frames sent on an interface that are from 1024 to 1518 bytes.
Too large frames	The number of frames sent on an interface that are larger than the maximum allowed frame size.
Good (1 coll) frames	The number of frames that are successfully sent on an interface after one collision occurs. This value does not include the number of frames that are not successfully sent after one collision occurs.

Table 2-7 Transmit Field Descriptions (continued)

1. CFI = Canonical Format Indicator

Table 2-8 Receive Field Descriptions

Field	Description
Bytes	The total amount of memory (in bytes) used by frames received on an interface, including the FCS^1 value and the incorrectly formed frames. This value excludes the frame header bits.
Unicast frames	The total number of frames successfully received on the interface that are directed to unicast addresses.
Multicast frames	The total number of frames successfully received on the interface that are directed to multicast addresses.
Broadcast frames	The total number of frames successfully received on an interface that are directed to broadcast addresses.

Field	Description			
Unicast bytes	The total amount of memory (in bytes) used by unicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.			
Multicast bytes	The total amount of memory (in bytes) used by multicast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame head bits.			
Broadcast bytes	The total amount of memory (in bytes) used by broadcast frames received on an interface, including the FCS value and the incorrectly formed frames. This value excludes the frame header bits.			
Alignment errors	The total number of frames received on an interface that have alignment errors.			
FCS errors	The total number of frames received on an interface that have a valid length (in bytes) but do not have the correct FCS values.			
Oversize frames	The number of frames received on an interface that are larger than the maximum allowed fram size.			
Undersize frames	The number of frames received on an interface that are smaller than 64 bytes.			
Collision fragments	The number of collision fragments received on an interface.			
Minimum size frames	The total number of frames that are the minimum frame size.			
65 to 127 byte frames	The total number of frames that are from 65 to 127 bytes.			
128 to 255 byte frames	The total number of frames that are from 128 to 255 bytes.			
256 to 511 byte frames	The total number of frames that are from 256 to 511 bytes.			
512 to 1023 byte frames	The total number of frames that are from 512 to 1023 bytes.			
1024 to 1518 byte frames	The total number of frames that are from 1024 to 1518 bytes.			
Overrun frames	The total number of overrun frames received on an interface.			
Pause frames	The number of pause frames received on an interface.			
Symbol error frames	The number of frames received on an interface that have symbol errors.			
Invalid frames, too large	The number of frames received that were larger than maximum allowed MTU^2 size (including the FCS bits and excluding the frame header) and that have either an FCS error or an alignment error.			
Valid frames, too large	The number of frames received on an interface that are larger than the maximum allowed frame size.			
Invalid frames, too small	The number of frames received that are smaller than 64 bytes (including the FCS bits and excluding the frame header) and that have either an FCS error or an alignment error.			
Valid frames, too small	The number of frames received on an interface that are smaller than 64 bytes (or 68 bytes for VLAN-tagged frames) and that have valid FCS values. The frame size includes the FCS bits but excludes the frame header bits.			
Too old frames	The number of frames dropped on the ingress port because the packet aged out.			
Valid oversize frames The number of frames received on an interface that are larger than the maximum allowed size and have valid FCS values. The frame size includes the FCS value but does not inclu VLAN tag.				

Table 2-8 Receive Field Description	ns (continued)
---	----------------

Field	Description
2	The total number of frames received on an interface that have a valid length (in bytes) but that do not have the correct FCS values.
RxPortFifoFull drop frames	The total number of frames received on an interface that are dropped because the ingress queue is full.

Table 2-8 Receive Field Descriptions (continued)

1. FCS = frame check sequence

2. MTU = maximum transmission unit

This is an example of output from the **show controllers ethernet-controller phy** command for a specific interface. Note that the last line of the display is the setting for Auto-MDIX for the interface.

Switch# show controllers ethernet-c Control Register	ontrol :	
Control STATUS	•	
Phy ID 1		
Phy ID 2	•	
Auto-Negotiation Advertisement		
Auto-Negotiation Link Partner		0000 0000 0000 0000
Auto-Negotiation Expansion Reg		
Next Page Transmit Register		0010 0000 0000 0001
Link Partner Next page Registe		
1000BASE-T Control Register		0000 1111 0000 0000
1000BASE-T Status Register		0100 0000 0000 0000
Extended Status Register	:	
5	•	0000 0000 0111 1000
PHY Specific Control Register		
PHY Specific Status Register		
Interrupt Enable	:	
Interrupt Status	:	
Extended PHY Specific Control		
Receive Error Counter	:	
Reserved Register 1	:	
Global Status	:	
LED Control	:	
Manual LED Override	:	
Extended PHY Specific Control	:	
Disable Receiver 1	:	
Disable Receiver 2	:	
Extended PHY Specific Status	:	
Auto-MDIX	:	On [AdminState=1 Flags=0x00052248

This is an example of output from the **show controllers ethernet-controller port-asic configuration** command:

Switch# show controllers ethernet-controller port-asic configuration _____ PortASIC 0 Registers _____ DeviceType : 000101BC : 00000000 Reset PmadMicConfig : 00000001 PmadMicDiag : 0000003 : 000007D0 000007D0 40000000 : 000001D0 000001D0 40000000 SupervisorReceiveFifoSramInfo SupervisorTransmitFifoSramInfo GlobalStatus : 00000800 IndicationStatus : 00000000 IndicationStatusMask : FFFFFFFF InterruptStatus : 00000000 InterruptStatusMask : 01FFE800

SupervisorDiag	:	00000000			
SupervisorFrameSizeLimit	:	000007C8			
SupervisorBroadcast	:	000A0F01			
GeneralIO	:	000003F9	00000000	00000004	
StackPcsInfo	:	FFFF1000	860329BD	5555FFFF	FFFFFFF
		FF0FFF00	86020000	5555FFFF	00000000
StackRacInfo	:	73001630	0000003	7F001644	0000003
		24140003	FD632B00	18E418E0	FFFFFFFF
StackControlStatus	:	18E418E0			
stackControlStatusMask	:	FFFFFFF			
TransmitBufferFreeListInfo	:	00000854	00800000	00000FF8	00000000
		0000088A	0000085D	00000FF8	00000000
TransmitRingFifoInfo	:	00000016	00000016	4000000	00000000
		0000000C	0000000C	4000000	00000000
TransmitBufferInfo	:	00012000	00000FFF	00000000	00000030
TransmitBufferCommonCount	:	00000F7A			
TransmitBufferCommonCountPeak	:	0000001E			
TransmitBufferCommonCommonEmpty	:	000000FF			
NetworkActivity	:	00000000	00000000	00000000	02400000
DroppedStatistics	:	00000000			
FrameLengthDeltaSelect	:	00000001			
SneakPortFifoInfo	:	00000000			
MacInfo	:	0EC0801C	0000001	0EC0801B	0000001
		00C0001D	0000001	00C0001E	0000001

<output truncated>

This is an example of output from the **show controllers ethernet-controller port-asic statistics** command:

Switch# show controllers ethernet-controller port-asic statistics

=================		
PortASIC	0 Statistics	
0	RxQ-0, wt-0 enqueue frames	0 RxQ-0, wt-0 drop frames
4118966	RxQ-0, wt-1 enqueue frames	0 RxQ-0, wt-1 drop frames
0	RxQ-0, wt-2 enqueue frames	0 RxQ-0, wt-2 drop frames
0	RxQ-1, wt-0 enqueue frames	0 RxQ-1, wt-0 drop frames
296	RxQ-1, wt-1 enqueue frames	0 RxQ-1, wt-1 drop frames
2836036	RxQ-1, wt-2 enqueue frames	0 RxQ-1, wt-2 drop frames
0	RxQ-2, wt-0 enqueue frames	0 RxQ-2, wt-0 drop frames
0	RxQ-2, wt-1 enqueue frames	0 RxQ-2, wt-1 drop frames
158377	RxQ-2, wt-2 enqueue frames	0 RxQ-2, wt-2 drop frames
0	RxQ-3, wt-0 enqueue frames	0 RxQ-3, wt-0 drop frames
0	RxQ-3, wt-1 enqueue frames	0 RxQ-3, wt-1 drop frames
0	RxQ-3, wt-2 enqueue frames	0 RxQ-3, wt-2 drop frames
15	TxBufferFull Drop Count	0 Rx Fcs Error Frames
0	TxBufferFrameDesc BadCrc16	0 Rx Invalid Oversize Frames
0	TxBuffer Bandwidth Drop Cou	0 Rx Invalid Too Large Frames
0	TxQueue Bandwidth Drop Coun	0 Rx Invalid Too Large Frames
0	TxQueue Missed Drop Statist	0 Rx Invalid Too Small Frames
74	RxBuffer Drop DestIndex Cou	0 Rx Too Old Frames
0	SneakQueue Drop Count	0 Tx Too Old Frames
0	Learning Queue Overflow Fra	0 System Fcs Error Frames
0	Learning Cam Skip Count	
15	Sup Queue 0 Drop Frames	0 Sup Queue 8 Drop Frames
0	Sup Queue 1 Drop Frames	0 Sup Queue 9 Drop Frames
0	Sup Queue 2 Drop Frames	0 Sup Queue 10 Drop Frames

Cisco ME 3400 Ethernet Access Switch Command Reference

0	Sup Queue 3	Drop Frames	0	Sup	Queue	11	Drop	Frames
0	Sup Queue 4	Drop Frames	0	Sup	Queue	12	Drop	Frames
0	Sup Queue 5	Drop Frames	0	Sup	Queue	13	Drop	Frames
0	Sup Queue 6	Drop Frames	0	Sup	Queue	14	Drop	Frames
0	Sup Queue 7	Drop Frames	0	Sup	Queue	15	Drop	Frames
0 : 52 :	 RxQ-0, wt-1	enqueue frames enqueue frames enqueue frames enqueue frames	0	-RxQ	0, wt-	-1 ć	drop i	Erames Erames Erames

<output truncated>

Related Commands	Command	Description
	show controllers cpu-interface	Displays the state of the CPU network ASIC and send and receive statistics for packets reaching the CPU.
	show controllers tcam	Displays the state of registers for all ternary content addressable memory (TCAM) in the system and for TCAM interface ASICs that are CAM controllers.

show controllers tcam

Use the **show controllers tcam** privileged EXEC command to display the state of the registers for all ternary content addressable memory (TCAM) in the system and for all TCAM interface ASICs that are CAM controllers.

show controllers tcam [asic [number]] [detail] [| {begin | exclude | include} expression]

Syntax Description	asic	(Optional) Display port ASIC TCAM information.				
	number	(Optional) Display information for the specified port ASIC number. The range is from 0 to 15.				
	detail	(Optional) Display detailed TCAM register information.				
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .				
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
	include	(Optional) Display includes lines that match the specified <i>expression</i> .				
	expression	Expression in the output to use as a reference point.				
Command Modes	Privileged	EXEC				
Command History	Release	Modification				
	12.2(25)E	X This command was introduced.				
Examples	This is an	ear, but the lines that contain <i>Output</i> appear. example of output from the show controllers tcam command:				
	Switch# show controllers tcam TCAM-0 Registers					
	REV: SIZE: ID: CCR:	00B30103 00080040 00000000 00000000_F0000020				
	RPID0: RPID1:	0000000_0000000 0000000_0000000				
	RPID2: RPID3:	0000000_0000000 0000000_0000000				

HRR3:	0000000_00000000	
HRR4:	0000000_00000000	
HRR5:	0000000_00000000	
HRR6:	0000000_00000000	
HRR7:	0000000_00000000	
<output t<="" td=""><td>runcated></td><td></td></output>	runcated>	
GMR31:	FF_FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	FF
GMR32:	FF_FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	FF
GMR33:	FF_FFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFFF	FF
TCAM rel	ated PortASIC 1 reg	isters
LookupTyp		89A1C67D_24E35F00
LastCamIn	dex:	0000FFE0
LocalNoMa	tch:	000069E0
Forwardin	gRamBaseAddress:	
		00022A00 0002FE00 00040600 0002FE00 0000D400
		00000000 003FBA00 00009000 00009000 00040600
		0000000 00012800 00012900

Related Commands	Command	Description
	show controllers cpu-interface	Displays the state of the CPU network ASIC and send and receive statistics for packets reaching the CPU.
	show controllers ethernet-controller	Displays per-interface send and receive statistics read from the hardware or the interface internal registers.

show controllers utilization

Use the **show controllers utilization** user EXEC command to display bandwidth utilization on the switch or specific ports.

show controllers [interface-id] utilization [| {begin | exclude | include} expression]

Syntax Description	interface-id	(Optional) l	ID of the switch interface.		
	begin	 (Optional) Display begins with the line that matches the specified <i>expression</i>. (Optional) Display excludes lines that match the specified <i>expression</i>. (Optional) Display includes lines that match the specified <i>expression</i>. 			
	exclude				
	include				
	expression		in the output to use as a reference point.		
Command Modes	User EXEC				
Command History	Release		Modification		
-	12.2(25)EX		This command was introduced.		
Examples	This is an example of output from the show controllers utilization command. Switch> show controllers utilization				
			ation Transmit Utilization		
	Fa0/1 Fa0/2	0 0	0 0		
	Fa0/3	0	0		
	Fa0/4	0	0		
	Fa0/5	0	0		
	Fa0/6 Fa0/7	0	0		
	<output truncated=""></output>				
	Switch Receive Bandwidth Percentage Utilization : 0 Switch Transmit Bandwidth Percentage Utilization : 0				
	Switch Fabric Percentage Utilization : 0				
	This is an example of output from the show controllers utilization command on a specific port:				
	Switch> show controllers gigabitethernet0/1 utilization Receive Bandwidth Percentage Utilization : 0 Transmit Bandwidth Percentage Utilization : 0				

Field	Description
Receive Bandwidth Percentage Utilization	Displays the received bandwidth usage of the switch, which is the sum of the received traffic on all the ports divided by the switch receive capacity.
Transmit Bandwidth Percentage Utilization	Displays the transmitted bandwidth usage of the switch, which is the sum of the transmitted traffic on all the ports divided it by the switch transmit capacity.
Fabric Percentage Utilization	Displays the average of the transmitted and received bandwidth usage of the switch.

Table 2-9 show controllers utilization Field Descriptions

Related Commands

Command	Description
show controllers	Displays the interface internal registers.
ethernet-controller	

show dot1q-tunnel

Use the **show dot1q-tunnel** user EXEC command to display information about IEEE 802.1Q tunnel ports.

show dot1q-tunnel [interface interface-id] [| {begin | exclude | include} expression]

Note

This command is visible only when the switch is running the metro IP access or metro access image.

Syntax Description	interface interface-id	(Optional) Specify the interface for which to display IEEE 802.1Q tunneling information. Valid interfaces include physical ports and port channels.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples These are examples of output from the **show dot1q-tunnel** command:

Switch> show dot1q-tunnel n	dot1q-tunnel mode LAN Port(s)	
Gi0/1		
Gi0/2		
Gi0/3		
Gi0/6		
Po2		
	dot1q-tunnel interface mode LAN Port(s)	gigabitethernet0/1
Gi0/1		

Related Commands	Command	Description
	show vlan dot1q tag native	Displays 802.1Q native VLAN tagging status.
	switchport mode dot1q-tunnel	Configures an interface as an IEEE 802.1Q tunnel port.

show dot1x

Use the **show dot1x** privileged EXEC command to display IEEE 802.1x statistics, administrative status, and operational status for the switch or for the specified port.

show dot1x [all | interface interface-id | statistics interface interface-id] [| {begin | exclude |
 include} expression]

Syntax Description	all	(Optional) Display the IEEE 802.1x status for all ports.			
	interface interface-id				
		type, module, and port number).			
	statistics interface	(Optional) Display IEEE 802.1x statistics for the specified port (including			
	interface-id	type, module, and port number).			
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .			
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .			
	include	(Optional) Display includes lines that match the specified expression.			
	expression	Expression in the output to use as a reference point.			
Command Modes	Privileged EXEC				
Command History	Release	Modification			
•	12.2(25)EX	This command was introduced.			
	that port appear.				
	-	nsitive. For example, if you enter l exclude output , the lines that contain <i>output</i> ne lines that contain <i>Output</i> appear.			
Examples	are not displayed, but th				
Examples	are not displayed, but th	ne lines that contain <i>Output</i> appear.			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands: = Enabled</pre>			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands:</pre>			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol Supplicant Allowed Ir	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands:</pre>			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol Supplicant Allowed In Dot1x Protocol Version Dot1x Oper Controlled Dot1x Admin Controlled Switch# show dot1x all	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands:</pre>			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol Supplicant Allowed Int Dot1x Protocol Versice Dot1x Oper Controlled Dot1x Admin Controlled Switch# show dot1x all Dot1x Info for interfi- Supplicant MAC 00d0.h AuthSM State BendSM State	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands:</pre>			
Examples	are not displayed, but the This is an example of our Switch# show dot1x Sysauthcontrol Supplicant Allowed Int Dot1x Protocol Versice Dot1x Oper Controlled Dot1x Admin Controlled Switch# show dot1x all Dot1x Info for interfi- Supplicant MAC 00d0.h AuthSM State BendSM State	<pre>he lines that contain Output appear. utput from the show dot1x and the show dot1x all privileged EXEC commands:</pre>			

Port Control = Auto QuietPeriod = 60 Seconds Re-authentication = Disabled ReAuthPeriod = 3600 Seconds ServerTimeout = 30 Seconds SuppTimeout = 30 Seconds = 30 Seconds TxPeriod Guest-Vlan = 0 Dot1x Info for interface GigabitEthernet0/2 _____ PortStatus = UNAUTHORIZED = 2 MaxReq Port Control = Auto QuietPeriod = Co = 60 Seconds Re-authentication = Disabled ReAuthPeriod = 3600 Seconds ServerTimeout = 30 Seconds SuppTimeout = 30 Seconds TxPeriod = 30 Seconds Guest-Vlan = 0

This is an example of output from the **show dot1x interface** *interface-id* privileged EXEC command:

Switch# show dot1x interface gigabitethernet0/1

Supplicant MAC 00d0.	b71b.35de
AuthSM State	= AUTHENTICATED
BendSM State	= IDLE
PortStatus =	AUTHORIZED
MaxReq =	2
HostMode =	Single
Port Control =	Auto
QuietPeriod =	60 Seconds
Re-authentication =	Disabled
ReAuthPeriod =	3600 Seconds
ServerTimeout =	30 Seconds
SuppTimeout =	30 Seconds
TxPeriod =	30 Seconds
Guest-Vlan =	0

This is an example of output from the **show dot1x statistics interface** *interface-id* command. Table 2-10 describes the fields in the display.

Switch# show dot1x statistics interface gigabitethernet0/1

PortStatistics Parameters for Dot1x

TxReqId = 15 TxReq = 0 TxTotal = 15 RxStart = 4 RxLogoff = 0 RxRespId = 1 RxResp = 1 RxInvalid = 0 RxLenErr = 0 RxTotal = 6 RxVersion = 1 LastRxSrcMac 00d0.b71b.35de

Field	Description		
TxReqId	Number of Extensible Authentication Protocol (EAP)-request/identity frames that have been sent.		
TxReq	Number of EAP-request frames (other than request/identity frames) that have been sent.		
TxTotal	Number of Extensible Authentication Protocol over LAN (EAPOL) frames of any type that have been sent.		
RxStart	Number of valid EAPOL-start frames that have been received.		
RxLogoff	Number of EAPOL-logoff frames that have been received.		
RxRespId	Number of EAP-response/identity frames that have been received.		
RxResp	Number of valid EAP-response frames (other than response/identity frames) that have been received.		
RxInvalid	Number of EAPOL frames that have been received and have an unrecognized frame type.		
RxLenError	Number of EAPOL frames that have been received in which the packet body length field is invalid.		
RxTotal	Number of valid EAPOL frames of any type that have been received.		
RxVersion	Number of received packets in the IEEE 802.1x Version 1 format.		
LastRxSrcMac	Source MAC address carried in the most recently received EAPOL frame.		

Table 2-10	show dot1x statistics Field Descriptions
------------	--

Command	Description
dot1x default	Resets the configurable IEEE 802.1x parameters to their default values.

show env

Use the **show env** user EXEC command to display fan, temperature, redundant power system (RPS) availability, and power information for the switch.

show env {all | fan | power} [| {begin | exclude | include} expression]

Image: Switch. switch. Image: The system of the							
power Display the switch power status. rps Display whether a Cisco RPS 300 Redundant Power System i switch. temperature Display the switch temperature status. I begin (Optional) Display begins with the line that matches the expression. I include (Optional) Display excludes lines that match the expression. I include (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status. The command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter l exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FMERERATURE is OK POWER is OK RPG is NOT PRESENT This is an example of output from the show env fan command:	Syntax Description	all	Display both fan and temperature environmental status.				
rps Display whether a Cisco RPS 300 Redundant Power System i switch. temperature Display the switch temperature status. l begin (Optional) Display begins with the line that matches the expression. l include (Optional) Display excludes lines that match the expression. l include (Optional) Display excludes lines that match the expression. l include (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command output shows the green and yellow states as OK FAULTX. If you enter the show envall command on this switch, the command output shows env temperature configuration gue Expressions are case sensitive. For example, if you enter l exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all rPAN is OK rPMERATURE is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		fan Display the switch fan status.					
switch. temperature Display the switch temperature status. I begin (Optional) Display begins with the line that matches the expression. I include (Optional) Display excludes lines that match the expression. I include (Optional) Display includes lines that match the expression. Exclude (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. 12.2(25)EX Isage Guidelines On a Cisco ME switch, you can use the show env temperature command to display temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all PAN is OK POWER is O		power	power Display the switch power status.				
I begin (Optional) Display begins with the line that matches the expr I exclude (Optional) Display excludes lines that match the expression. I include (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Jsage Guidelines On a Cisco ME switch, you can use the show env temperature command to displatemperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all PAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		rps	Display whether a Cisco RPS 300 Redundant Power System is connected to the switch.				
I exclude (Optional) Display excludes lines that match the expression. I include (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Jsage Guidelines On a Cisco ME switch, you can use the show env temperature command to displatemperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all PAN is OK TEMPERATURE is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		temperature	Display the switch temperature status.				
Include (Optional) Display includes lines that match the specified expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Isage Guidelines On a Cisco ME switch, you can use the show env temperature command to displate temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FM is OK POMER is OK POMER is OK POMER is OK PRESENT This is an example of output from the show env fan command:		begin	(Optional) Display begins with the line that matches the expression.				
expression Expression in the output to use as a reference point. Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Isage Guidelines On a Cisco ME switch, you can use the show env temperature command to displatemperature status. The command output shows the green and yellow states as <i>OK FAULTY</i> . If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain <i>Output</i> are displayed. Examples This is an example of output from the show env all command: Switch# show env all FAULTY IS OK TEMPERATURE IS OK POWER IS OK RPS IS NOT PRESENT This is an example of output from the show env fan command:		exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Jsage Guidelines On a Cisco ME switch, you can use the show env temperature command to displetemperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		include	(Optional) Display includes lines that match the specified expression.				
Release Modification 12.2(25)EX This command was introduced. Usage Guidelines On a Cisco ME switch, you can use the show env temperature command to displate temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		expression	Expression in the output to use as a reference point.				
Release Modification 12.2(25)EX This command was introduced. Usage Guidelines On a Cisco ME switch, you can use the show env temperature command to displate temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:							
12.2(25)EX This command was introduced. Usage Guidelines On a Cisco ME switch, you can use the show env temperature command to displate temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gu Expressions are case sensitive. For example, if you enter l exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all PAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:	Command Modes	User EXEC					
12.2(25)EX This command was introduced. Usage Guidelines On a Cisco ME switch, you can use the show env temperature command to displate temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gu Expressions are case sensitive. For example, if you enter l exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:	Command History	Release	Modification				
Usage Guidelines On a Cisco ME switch, you can use the show env temperature command to displic temperature status. The command output shows the green and yellow states as OK FAULTY. If you enter the show env all command on this switch, the command output show env temperature status command output. For more information about the threshold levels, see the software configuration gue Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all PAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:	Sommanu mistory						
For more information about the threshold levels, see the software configuration gu Expressions are case sensitive. For example, if you enter exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all Switch# show env all FAN is OK TEMPERATURE is OK POWER is NOT PRESENT This is an example of output from the show env fan command:	Usage Guidelines	On a Cisco ME switch, you can use the show env temperature command to display the switch temperature status. The command output shows the green and yellow states as <i>OK</i> and the red state as <i>FAULTY</i> . If you enter the show env all command on this switch, the command output is the same as the show env temperature status command output					
Expressions are case sensitive. For example, if you enter I exclude output, the line are not displayed, but the lines that contain Output are displayed. Examples This is an example of output from the show env all command: Switch# show env all Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		For more information about the threshold levels, see the software configuration guide for this release.					
Switch# show env all FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:		Expressions are case sensitive. For example, if you enter exclude output, the lines that contain output					
FAN is OK TEMPERATURE is OK POWER is OK RPS is NOT PRESENT This is an example of output from the show env fan command:	Examples	This is an examp	ble of output from the show env all command:				
		FAN is OK TEMPERATURE is POWER is OK	OK				
		This is an examp	ble of output from the show env fan command:				
FAN is OK		Switch> show er	-				

show errdisable detect

Use the **show errdisable detect** user EXEC command to display error-disable detection status.

show errdisable detect [| {begin | exclude | include} expression]

Syntax Description	l begin (Op	tional) Display begins with the line that matches the <i>expression</i> .
	l exclude (Op	tional) Display excludes lines that match the expression.
	include (Op	tional) Display includes lines that match the specified <i>expression</i> .
	expression Exp	pression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	-	se sensitive. For example, if you enter l exclude output , the lines that contain <i>outpu</i> but the lines that contain <i>Output</i> are displayed.
	A displayed gbic-i	invalid error reason refers to an invalid small form-factor pluggable (SFP) module
Examples	This is an example	of output from the show errdisable detect command:
	Switch> show errd ErrDisable Reason	
	ErrDisable Reason	Detection status
	ErrDisable Reason udld	Detection status Enabled
	ErrDisable Reason udld bpduguard	Detection status Enabled Enabled
	ErrDisable Reason udld bpduguard security-violatic	Detection status Enabled Enabled Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig	Detection status Enabled Enabled b Enabled Enabled Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation	Detection status Enabled Enabled Enabled Enabled Enabled Enabled Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps	Detection status Enabled Enabled b Enabled Enabled Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood storm-control	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood storm-control ilpower	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood storm-control ilpower arp-inspection	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood storm-control ilpower	Detection status Enabled
	ErrDisable Reason udld bpduguard security-violatic channel-misconfig psecure-violation vmps loopback pagp-flap dtp-flap l2ptguard link-flap gbic-invalid dhcp-rate-limit unicast-flood storm-control ilpower arp-inspection	Detection status Enabled

Related Commands C

commands	Command	Description
	errdisable detect cause	Enables error-disable detection for a specific cause or all causes.
	show errdisable flap-values	Displays error condition recognition information.
	show errdisable recovery	Displays error-disable recovery timer information.
	show interfaces status	Displays interface status or a list of interfaces in error-disabled state.

show errdisable flap-values

Use the **show errdisable flap-values** user EXEC command to display conditions that cause an error to be recognized for a cause.

show errdisable flap-values [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Displ	play begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Displ	play excludes lines that match the expression.
	include	(Optional) Displ	play includes lines that match the specified expression.
	expression	Expression in the	he output to use as a reference point.
Command Modes	User EXEC		
Command History	Release	Modif	ification
	12.2(25)EX	This c	command was introduced.
Usage Guidelines	will cause an e will be assume access/trunk)	error to be detected ed and the port shu or Port Aggregatio	by shows how many changes to the state within the specified time intered and a port to be disabled. For example, the display shows that an erhut down if three Dynamic Trunking Protocol (DTP)-state (port modion Protocol (PAgP) flap changes occur during a 30-second interval, changes occur during a 10-second interval.
	ErrDisable R	<u>-</u>	Time (sec)
	pagp-flap dtp-flap link-flap	3 3 5	30 30 10
<u>Note</u>	Although visil	ole in the output d	display, the switch does not support DTP.
	-		For example, if you enter exclude output , the lines that contain <i>out</i> that contain <i>Output</i> are displayed.
Examples	This is an exa	mple of output fro	com the show errdisable flap-values command:
	ErrDisable R	1	Ap-values Time (sec)

Related Commands 0

ommands	Command	Description
	errdisable detect cause	Enables error-disable detection for a specific cause or all causes.
	show errdisable detect	Displays error-disable detection status.
	show errdisable recovery	Displays error-disable recovery timer information.
	show interfaces status	Displays interface status or a list of interfaces in error-disabled state.

show errdisable recovery

Use the **show errdisable recovery** user EXEC command to display the error-disable recovery timer information.

show errdisable recovery [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .			
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .			
	include	e (Optional) Display includes lines that match the specified <i>expression</i> .			
	expression	Expression in the output to use as a reference point.			
Command Modes	User EXEC				
Command History	Release	Modification			
	12.2(25)EX	This command was introduced.			
Usage Guidelines		case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> ed, but the lines that contain <i>Output</i> are displayed.			
	A gbic-invalid e interface.	error-disable reason refers to an invalid small form-factor pluggable (SFP) module			
Examples	This is an exam	ple of output from the show errdisable recovery command:			
	ErrDisable Rea				
	udld	Disabled			
	bpduguard	Disabled			
	security-viola	ntio Disabled			
	channel-miscor	lfig Disabled			
	vmps	Disabled			
	pagp-flap	Disabled			
	dtp-flap	Disabled			
	12ptguard	Disabled			
	link-flap psecure-violat	Enabled			
	gbic-invalid	ion Disabled Disabled			
	dhcp-rate-limi				
	unicast-flood	Disabled			
	storm-control	Disabled			
	arp-inspection				
		Disabled			
	loopback	21042104			
	loopback Timer interval				

Interface	Errdisable reason	Time left(sec)
Gi0/2	link-flap	279



Though visible in the output, the unicast-flood and DTP fields are not valid.

Related Commands

Command	Description
errdisable recovery	Configures the recover mechanism variables.
show errdisable detect	Displays error-disabled detection status.
show errdisable flap-values	Displays error condition recognition information.
show interfaces status	Displays interface status or a list of interfaces in error-disabled state.

show etherchannel

Use the show etherchannel user EXEC command to display EtherChannel information for a channel.

show etherchannel [channel-group-number {detail | port | port-channel | protocol | summary}]
{detail | load-balance | port | port-channel | protocol | summary} [| {begin | exclude |
include} expression]

Syntax Description	channel-group-number	(Optional) Number of the channel group. The range is 1 to 48.				
	detail	Display detailed EtherChannel information.				
	load-balance	Display the load-balance or frame-distribution scheme among ports in the port channel.				
	port	Display EtherChannel port information.				
	port-channel	Display port-channel information.				
	protocol	Display the protocol that is being used in the EtherChannel.				
	summary	Display a one-line summary per channel-group.				
	begin	(Optional) Display begins with the line that matches the expression.				
	exclude	(Optional) Display excludes lines that match the expression.				
	include	(Optional) Display includes lines that match the specified expression.				
Command Modes	<i>expression</i> User EXEC	Expression in the output to use as a reference point.				
		Expression in the output to use as a reference point. Modification				
	User EXEC					
Command History	User EXEC Release 12.2(25)EX	Modification				
Command Modes Command History Usage Guidelines	User EXEC Release 12.2(25)EX If you do not specify a <i>ch</i> In the output, the Passive p	Modification This command was introduced. annel-group, all channel groups are displayed. port list field is displayed only for Layer 3 port channels. This field means that s still not up, is configured to be in the channel group (and indirectly is in the				

are not displayed, but the lines that contain Output are displayed.

Examples

This is an example of output from the **show etherchannel 1 detail** command:

```
Switch> show etherchannel 1 detail
Group state = L2
Ports: 2 Maxports = 16
Port-channels: 1 Max Port-channels = 16
Protocol: LACP
             Ports in the group:
              _____
Port: Gi0/1
_____
Port state
          = Up Mstr In-Bndl
Channel group = 1 Mode = Active Gcchange = -
Port-channel = Po1
                       GC = -
                                        Pseudo port-channel = Pol
                       Load = 0x00
                                         Protocol = LACP
Port index
          = 0
Flags: S - Device is sending Slow LACPDUS F - Device is sending fast LACPDU
      A - Device is in active mode.
                                       P - Device is in passive mode.
Local information:
                         LACP port
                                     Admin
                                               Oper
                                                      Port
                                                              Port
                                                      Number State
        Flags State
Port.
                        Priority
                                     Key
                                              Key
Gi0/1
                        32768
                                                              0x3D
       SA
              bndl
                                     0x0
                                              0x1
                                                      0 \ge 0
Age of the port in the current state: 01d:20h:06m:04s
              Port-channels in the group:
Port-channel: Po1 (Primary Aggregator)
_ _ _ _ _ _ _ _ _ _ _ _ _ _ _
Age of the Port-channel = 01d:20h:20m:26s
Logical slot/port = 10/1 Number of ports = 2
HotStandBy port = null
Port state = Port-channel Ag-Inuse
Protocol
                 = LACP
Ports in the Port-channel:
Index Load Port
                    EC state
                                  No of bits
----+----+----+------+------+---
                                       _____
 0 00 Gi0/1 Active 0
 0
       00 Gi0/2 Active
                                    0
Time since last port bundled: 01d:20h:20m:20s
                                              Gi0/2
This is an example of output from the show etherchannel 1 summary command:
Switch> show etherchannel 1 summary
Flags: D - down P - in port-channel
       I - stand-alone s - suspended
       H - Hot-standby (LACP only)
       R - Layer3 S - Layer2
       u - unsuitable for bundling
       U - in use
                  f - failed to allocate aggregator
       d - default port
```

```
Number of channel-groups in use: 1
Number of aggregators: 1
```

Group Port-channel Protocol Ports LACP Gi0/1(P) Gi0/2(P) 1 Pol(SU) This is an example of output from the show etherchannel 1 port-channel command: Switch> show etherchannel 1 port-channel Port-channels in the group: _____ Port-channel: Po1 (Primary Aggregator) _____ Age of the Port-channel = 01d:20h:24m:50s Logical slot/port = 10/1 Number of ports = 2 HotStandBy port = null Port state = Port-channel Ag-Inuse Protocol = LACP Ports in the Port-channel: Index Load Port EC state No of bits 0 00 Gi0/1 Active 0 00 Gi0/2 Active 0 0 Time since last port bundled: 01d:20h:24m:44s Gi0/2 This is an example of output from show etherchannel protocol command: Switch# show etherchannel protocol Channel-group listing: _____ Group: 1 _____ Protocol: LACP

Group: 2 -----Protocol: PAgP

Related Commands

Command	Description
channel-group	Assigns an Ethernet port to an EtherChannel group.
channel-protocol	Restricts the protocol used on a port to manage channeling.
interface port-channel	Accesses or creates the port channel.

show flowcontrol

Use the show flowcontrol user EXEC command to display the flow control status and statistics.

show flowcontrol [interface interface-id | module number] [| {begin | exclude | include}
expression]

Syntax Description	interface interface-id	(Option interfac	· •	ay the flow c	ontrol stat	tus and statistics for a specific		
	module number	switch.	(Optional) Display the flow control status and statistics for all interfaces on the switch. The only valid module number is 1. This option is not available if you have entered a specific interface ID.					
	begin	(Option	al) Displa	ay begins wit	h the line	that matches the <i>expression</i> .		
	exclude	(Option	al) Displa	ay excludes l	ines that r	match the <i>expression</i> .		
	include	(Option	al) Displa	ay includes li	ines that n	natch the specified expression.		
	expression	Express	ion in the	e output to us	se as a refe	erence point.		
Command Modes	User EXEC							
Command History	Release	Modific	ation					
	12.2(25)EX	This co	mmand w	as introduce	d.			
Usage Guidelines	Use the show flowcont from the show flowcon <i>number</i> command.	a rol comma a trol comm	and to displand is the	play informa e same as the	tion about output fre	on the switch or for a specific interface t all the switch interfaces. The output om the show flowcontrol module play information about a specific		
	Expressions are case se do not appear, but the l		-	•	exclude	e output , the lines that contain <i>output</i>		
Examples	This is an example of output from the show flowcontrol command.							
	admin	Control R oper a	admin	lowControl oper	RxPause			
	Gi0/1 Unsupp. Gi0/2 desired Gi0/3 desired	Unsupp. c off c	off off off	off off off	0 0 0	 0 0 0		
	<output truncated=""></output>							

This is an example of output from the **show flowcontrol interface** *interface-id* command:

Switch> sh	ow flowco	ntrol int	erface gi	gabitetherne	t0/2	
Port	Send Flo	wControl	Receive	FlowControl	RxPause	TxPause
	admin	oper	admin	oper		
Gi0/2	desired	off	off	off	0	0

s	Command	Description
	flowcontrol	Sets the receive flow-control state for an interface.

show idprom

Use the **show idprom** user EXEC command to display the IDPROM information for a Gigabit Ethernet interface.

show idprom {interface interface-id} [detail] [| {begin | exclude | include} expression]

Syntax Description	interface interface-id	Display the IDPROM information for the specified Gigabit Ethernet interface.				
	detail	(Optional) Display detailed IDPROM information.				
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .				
	exclude					
	include					
	expression	Expression in the output to use as a reference point.				
Command Modes	User EXEC					
Command History	Release	Modification				
	12.2(25)EX	This command was introduced.				
Ĵ	in the SFP module slot. Expressions are case sen	nly to Gigabit Ethernet interfaces and displays information about SFPs inserted asitive. For example, if you enter exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear.				
-	in the SFP module slot. Expressions are case sen do not appear, but the lir	sitive. For example, if you enter I exclude output , the lines that contain <i>outpu</i>				
-	in the SFP module slot. Expressions are case sen do not appear, but the lir This is an example of out	asitive. For example, if you enter I exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear. The put from the show idprom interface command for a Gigabit Ethernet interface				
-	in the SFP module slot. Expressions are case sen do not appear, but the lir This is an example of out	asitive. For example, if you enter exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear. The that contain <i>Output</i> appear. The show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1				
	 in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Information Identifier Connector Transceiver 	asitive. For example, if you enter l exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear. tput from the show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1 on : 0x03 : 0x07 : 0x00 0x00 0x00 0x00 0x00 0x00 0x00				
	 in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Information Identifier Connector Transceiver Encoding 	asitive. For example, if you enter exclude output, the lines that contain <i>output</i> hes that contain <i>Output</i> appear. tput from the show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1 on 				
-	 in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Information Identifier Connector Transceiver 	asitive. For example, if you enter exclude output, the lines that contain <i>output</i> hes that contain <i>Output</i> appear. tput from the show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1 on . 0x03 . 0x07 . 0x00 0x00 0x00 0x00 0x00 0x00 0x00				
-	 in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Information Identifier Connector Transceiver Encoding BR_Nominal 	asitive. For example, if you enter exclude output, the lines that contain <i>output</i> appear. tput from the show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1 on 				
-	in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Informatio Identifier Connector Transceiver Encoding BR_Nominal Vendor Name Vendor Part Number Vendor Revision	asitive. For example, if you enter l exclude output , the lines that contain <i>output</i> appear. tput from the show idprom interface command for a Gigabit Ethernet interface nterface gigabitethernet0/1 on 				
	in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Informatio Identifier Connector Transceiver Encoding BR_Nominal Vendor Name Vendor Part Number Vendor Revision Vendor Serial Number	asitive. For example, if you enter exclude output, the lines that contain output hes that contain Output appear. tput from the show idprom interface command for a Gigabit Ethernet interface nterface gigabitethernet0/1 on 				
	in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Informatio Identifier Connector Transceiver Encoding BR_Nominal Vendor Name Vendor Part Number Vendor Revision Vendor Serial Number Other Information	Asitive. For example, if you enter exclude output, the lines that contain output thes that contain Output appear. tput from the show idprom interface command for a Gigabit Ethernet interface interface gigabitethernet0/1 on . 0x03 . 0x07 . 0x00 0x00 0x00 0x00 0x00 0x00 0x00 0x				
Usage Guidelines Examples	in the SFP module slot. Expressions are case sen do not appear, but the lin This is an example of out Switch# show idprom in General SFP Information Identifier Connector Transceiver Encoding BR_Nominal Vendor Name Vendor Part Number Vendor Revision Vendor Serial Number Other Information	<pre>asitive. For example, if you enter exclude output, the lines that contain output hes that contain Output appear. tput from the show idprom interface command for a Gigabit Ethernet interface nterface gigabitethernet0/1 on</pre>				

Embedded PHY	: not present					
SFP presence index	: 0					
SFP iter cnt	: 697918					
SFP failed oper flag	: 0x0					
IIC error cnt	: 0					
IIC error dsb cnt	: 0					
	: 4					
Chk for link status	: 1					
Link Status	: 1					
Link Status Media	: 1					
	: 0					
Resolved Media	: 1					
	: 1					
Access Count	: 0					
Access Count Max						
Port Rx Loss	: no					
Port Tx Fault						
Port Tx Disable	: no					
Sfp selection asic re						
stbi	: 0x00					
sfpControl	: 0x4C					
Regs Loc	: 0xF000000					
Page 0 Registers						
0000: 1140 Control R	5		0001			
0001: 6149 Control S	TATUS		0110			
0002: 0141 Phy ID 1			0000			
0003: 0C92 Phy ID 2	tiation Advertisement		0000			
	tiation Link Partner tiation Expansion Reg		0000			
0007: 2001 Next Page			0010			
0009: 0F00 1000BASE-	ner Next page Registe		0000	1111	0000	0000
0009: 0F00 1000BASE-			0000			
000F: 0000 Extended	-		0000			
	fic Control Register					
0011: 6CC8 PHV Speci	fic Status Register	:	0110			
0012: 0000 Interrupt	Enable Register		0000			
	fic Status Register2					
0015 0100 Para'ara R			0000			

 0012: 0000 Interrupt Enable Register
 : 0000 0000 0000

 0013: 0700 PHY Specific Status Register2
 : 0000 0111 0000 0000

 0015: 01C0 Receive Error Counter
 : 0000 0001 1100 0000

 0016: 0000 Page Address Register
 : 0000 0000 0000 0000

 001A: 8040 PHY Specific Control Register2
 : 1000 0000 0100 0000

<output truncated>

Related Commands	Command	Description
	show controllers	Displays per-interface send and receive statistics read from the
	ethernet-controller	hardware, interface internal registers, or port ASIC information.

show interfaces

Use the **show interfaces** privileged EXEC command to display the administrative and operational status of all interfaces or a specified interface.

show interfaces [interface-id | vlan vlan-id] [accounting | capabilities [module number] |
 counters | description | etherchannel | flowcontrol | private-vlan mapping | stats | status
 [err-disabled] | switchport [backup | module number] | transceiver [properties | detail]
 [module number] | trunk] [| {begin | exclude | include} expression]

Syntax Description	interface-id	(Optional) Valid interfaces include physical ports (including type, module, and port number) and port channels. The port-channel range is 1 to 48.
	vlan vlan-id	(Optional) VLAN identification. The range is 1 to 4094.
	accounting	(Optional) Display accounting information on the interface, including active protocols and input and output packets and octets.
	capabilities	(Optional) Display the capabilities of all interfaces or the specified interface, including the features and options that you can configure on the interface. Though visible in the command line help, this option is not available for VLAN IDs.
	module number	(Optional) Display capabilities , switchport configuration, or transceiver characteristics (depending on preceding keyword) of all interfaces on the switch. The only valid module number is 1. This option is not available if you have entered a specific interface ID.
	counters	(Optional) See the show interfaces counters command.
	description	(Optional) Display the administrative status and description set for an interface.
	etherchannel	(Optional) Display interface EtherChannel information.
	flowcontrol	(Optional) Display interface flowcontrol information
	private-vlan mapping	(Optional) Display private-VLAN mapping information for the VLAN switch virtual interfaces (SVIs) and private VLAN promiscuous ports. A promiscuous port must be a network node interface (NNI). This keyword is visible only when the switch is running the metro access or metro IP access image.
	stats	(Optional) Display the input and output packets by switching path for the interface.
	status	(Optional) Display the status of the interface. A status of <i>unsupported</i> in the Type field means that a non-Cisco small form-factor pluggable (SFP) module is inserted in the module slot.
	err-disabled	(Optional) Display interfaces in error-disabled state.
	switchport	(Optional) Display the administrative and operational status of a switching (nonrouting) port, including port blocking and port protection settings.
	backup	(Optional) Display Flex Link backup interface configuration and status for the specified interface or all interfaces on the switch. This keyword is visible only when the switch is running the metro access or metro IP access image.
	transceiver [detail	(Optional) Display the physical properties of a CWDM ¹ or DWDM ² small form-factor (SFP) module interface. The keywords have these meanings:
	properties]	• detail —(Optional) Display calibration properties, including high and low
		numbers and any alarm information.

	trunk	Display interface trunk information. If you do not specify an interface, only information for active trunking ports appears.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
		h-division multiplexer a-division multiplexer
Note	•	the command-line help strings, the crb , fair-queue , irb , mac-accounting , hing random-detect , rate-limit , and shape keywords are not supported.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
	 switch. Enteri Use the show interface. Use the show capabilities of Use the show 	 interface capabilities module 1 to display the capabilities of all interfaces on the ing any other number is invalid. interfaces interface-id capabilities to display the capabilities of the specified interfaces capabilities (with no module number or interface ID) to display the f all interfaces on the switch. interface switchport module 1 to display the switch port characteristics of all the switch. Entering any other number is invalid.
	_	ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> but the lines that contain <i>Output</i> are displayed.
Examples	This is an example	e of output from the show interfaces command for an interface:
	GigabitEthernetC Hardware is Gi MTU 1500 bytes reliability	

Queueing strategy: fifo Output queue :0/40 (size/max) 5 minute input rate 0 bits/sec, 0 packets/sec 5 minute output rate 0 bits/sec, 0 packets/sec 2 packets input, 1040 bytes, 0 no buffer Received 0 broadcasts, 0 runts, 0 giants, 0 throttles 0 input errors, 0 CRC, 0 frame, 0 overrun, 0 ignored 0 watchdog, 0 multicast, 0 pause input 0 input packets with dribble condition detected 4 packets output, 1040 bytes, 0 underruns 0 output errors, 0 collisions, 3 interface resets 0 babbles, 0 late collision, 0 deferred 0 lost carrier, 0 no carrier, 0 PAUSE output 0 output buffer failures, 0 output buffers swapped out

This is an example of output from the **show interfaces accounting** command.

Switch# **show interfaces accounting** Vlan1

Protocol Pkts In Chars In Pkts Out Chars Out 1094395 131900022 559555 84077157 ΤP Spanning Tree 283896 17033760 42 2520 ARP 63738 3825680 231 13860 Interface Vlan2 is disabled Vlan7 Pkts In Protocol Chars In Pkts Out Chars Out No traffic sent or received on this interface. Vlan31 Protocol Pkts In Chars In Pkts Out Chars Out No traffic sent or received on this interface. GigabitEthernet0/1 Protocol Pkts In Chars In Pkts Out Chars Out No traffic sent or received on this interface. GigabitEthernet0/2 Pkts In Chars In Protocol Pkts Out Chars Out No traffic sent or received on this interface.

<output truncated>

This is an example of output from the **show interfaces capabilities** command for an interface.

Switch# show interfaces gigabitethernet0/2 capabilities

GigabitEthernet0/2	
Model:	ME-3400-24T-FA
Type:	10/100/1000BaseTX SFP
Speed:	10,100,1000,auto
Duplex:	half,full,auto
Trunk encap. type:	802.1Q
Trunk mode:	on,off,desirable,nonegotiate
Channel:	yes
Broadcast suppression:	percentage(0-100)
Flowcontrol:	<pre>rx-(off,on,desired),tx-(none)</pre>
Fast Start:	yes
QoS scheduling:	<pre>rx-(not configurable on per port basis),tx-(4q2t)</pre>
CoS rewrite:	yes
ToS rewrite:	yes
UDLD:	yes
SPAN: s	ource/destination
PortSecure:	yes
Dot1x:	yes

This is an example of output from the **show interfaces** *interface* **description** command when the interface has been described as *Connects to Marketing* by using the **description** interface configuration command.

Switch# show interfaces gigabitethernet0/2 descriptionInterface StatusProtocol DescriptionGi0/2updownConnects to Marketing

This is an example of output from the **show interfaces etherchannel** command when port channels are configured on the switch:

```
Switch# show interfaces etherchannel
Port-channel1:
Age of the Port-channel = 03d:20h:17m:29s
Logical slot/port = 10/1 Number of ports = 0
            = 0 \times 000000000
                                    HotStandBy port = null
GC
Port state
                  = Port-channel Ag-Not-Inuse
Port-channel2:
Age of the Port-channel = 03d:20h:17m:29s
Logical slot/port= 10/2Number of ports = 0GC= 0x00000000HotStandBy port = null
Port state
                  = Port-channel Ag-Not-Inuse
Port-channel3:
Age of the Port-channel = 03d:20h:17m:29s
Logical slot/port = 10/3 Number of ports = 0
GC = 0x00000000 HotStandBy port = null
Port state
                  = Port-channel Ag-Not-Inuse
```

This is an example of output from the **show interfaces private-vlan mapping** command when the private-VLAN primary VLAN is VLAN 10 and the secondary VLANs are VLANs 501 and 502:

Switch# sl	now interfaces p	private-vlan mapping
Interface	Secondary VLAN	Туре
vlan10	501	isolated
vlan10	502	community

This is an example of output from the **show interfaces stats** command for a specified VLAN interface.

```
        Switch# show interfaces vlan 1 stats

        Switching path
        Pkts In
        Chars In
        Pkts
        Out
        Chars Out

        Processor
        1165354
        136205310
        570800
        91731594

        Route cache
        0
        0
        0
        0

        Total
        1165354
        136205310
        570800
        91731594
```

This is an example of partial output from the **show interfaces status** command. It displays the status of all interfaces.

Switch# show interfaces st	atus			
Port Name	Status	Vlan	Duplex	Speed Type
Fa0/1	connected	1	a-full	a-100 10/100BaseTX
Fa0/2	connected	1	a-full	a-100 10/100BaseTX
Fa0/3	notconnect	1	auto	auto 10/100BaseTX
Fa0/4	disabled	1	auto	auto 10/100BaseTX
Fa0/5	disabled	1	auto	auto 10/100BaseTX
Fa0/6	disabled	1	auto	auto 10/100BaseTX
Fa0/7	disabled	1	auto	auto 10/100BaseTX
Fa0/8	disabled	1	auto	auto 10/100BaseTX
Fa0/9	disabled	1	auto	auto 10/100BaseTX
Fa0/10	disabled	1	auto	auto 10/100BaseTX
Fa0/11	disabled	1	auto	auto 10/100BaseTX

Fa0/12	disabled	1	auto	auto	10/100BaseTX
Fa0/13	disabled	1	auto	auto	10/100BaseTX
Fa0/14	disabled	1	auto	auto	10/100BaseTX
Fa0/15	disabled	1	auto	auto	10/100BaseTX
Fa0/16	disabled	1	auto	auto	10/100BaseTX
Fa0/17	disabled	1	auto	auto	10/100BaseTX
Fa0/18	disabled	1	auto	auto	10/100BaseTX
Fa0/19	disabled	1	auto	auto	10/100BaseTX
Fa0/20	disabled	1	auto	auto	10/100BaseTX
Fa0/21	disabled	1	auto	auto	10/100BaseTX
Fa0/22	disabled	1	auto	auto	10/100BaseTX
Fa0/23	disabled	1	auto	auto	10/100BaseTX
Fa0/24	disabled	1	auto	auto	10/100BaseTX
Gi0/1	notconnect	1	auto	auto	10/100/1000Ba
SETX SFP					
Gi0/2	notconnect	1	auto	auto	Not Present

These are examples of output from the **show interfaces status** command for a specific interface when private VLANs are configured. Port 22 is configured as a private-VLAN host port. It is associated with primary VLAN 20 and secondary VLAN 25.

Switch#	show interfaces	fastethernet0/22	status		
Port	Name	Status	Vlan	Duplex	Speed Type
Fa0/22		connected	20,25	a-full	a-100 10/100BaseTX

In this example, port 2 is configured as a private-VLAN promiscuous port. The display shows only the primary VLAN 20.

Switch#	show interfaces	gigabitethernet0/	2 status		
Port	Name	Status	Vlan	Duplex	Speed Type
Gi0/2		connected	20	a-full	a-100 10/100/1000BaseTX

This is an example of output from the **show interfaces status err-disabled** command. It displays the status of interfaces in the error-disabled state.

Switch#	show interfaces	s status err-disable	ed
Port	Name	Status	Reason
Gi0/2		err-disabled	dtp-flap

This is an example of output from the **show interfaces switchport** command for a single port. Table 2-11 describes the fields in the display.

Note

Private VLAN trunks are not supported in this release, so those fields are not applicable.

```
Switch# show interfaces gigabitethernet0/1 switchport
Name: Gi0/1
Switchport: Enabled
Administrative Mode: static access
Operational Mode: static access
Administrative Trunking Encapsulation: dotlq
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Administrative private-vlan host-association: none
Administrative private-vlan mapping: none
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dotlq
Administrative private-vlan trunk normal VLANs: none
```

Administrative private-vlan trunk private VLANs: none Operational private-vlan: none Trunking VLANs Enabled: ALL Capture Mode Disabled Capture VLANs Allowed: ALL

Unknown unicast blocked: disabled Unknown multicast blocked: disabled Appliance trust: none

Administrative Native VLAN tagging: enabled Administrative private-vlan host-association: none Administrative private-vlan mapping: none Administrative private-vlan trunk native VLAN: none Administrative private-vlan trunk Native VLAN tagging: enabled Administrative private-vlan trunk encapsulation: dotlq Administrative private-vlan trunk normal VLANs: none Administrative private-vlan trunk private VLANs: none Operational private-vlan: none Trunking VLANs Enabled: ALL Capture Mode Disabled Capture VLANs Allowed: ALL

Unknown unicast blocked: disabled Unknown multicast blocked: disabled Appliance trust: none

Table 2-11	show interfaces	switchport Fiel	d Descriptions
------------	-----------------	-----------------	----------------

Field	Description		
Name	Displays the port name.		
Switchport	Displays the administrative and operational status of the port. In this display, the port is in switchport mode.		
Administrative Mode	Displays the administrative and operational modes.		
Operational Mode			
Administrative Trunking Encapsulation	Displays the administrative and operational encapsulation method and whether trunking negotiation is enabled.		
Negotiation of Trunking			
Access Mode VLAN	Displays the VLAN ID to which the port is configured.		
Trunking Native Mode VLAN	Lists the VLAN ID of the trunk that is in native mode.		
Administrative Native VLAN tagging	Displays whether or not VLAN tagging is enabled.		
Administrative private-vlan host-association	Displays the administrative VLAN association for private-VLAN host ports.		
Administrative private-vlan mapping	Displays the administrative VLAN mapping for private-VLAN promiscuous ports.		
Operational private-vlan	Displays the operational private-VLAN status.		
Trunking VLANs enabled	Lists the active VLANs on the trunk.		
Capture VLANs allowed	Lists the allowed VLANs on the trunk.		
Unknown unicast blocked	Displays whether or not unknown multicast and unknown		
Unknown multicast blocked	unicast traffic is blocked on the interface.		

This is an example of output from the **show interfaces switchport** command for a port configured as a private VLAN promiscuous port. The primary VLAN 20 is mapped to secondary VLANs 25, 30 and 35:

```
Switch# show interface gigabitethernet0/2 switchport
Name: Gi1/0/2
Switchport: Enabled
Administrative Mode: private-vlan promiscuous
Operational Mode: private-vlan promiscuous
Administrative Trunking Encapsulation: negotiate
Operational Trunking Encapsulation: native
Negotiation of Trunking: Off
Access Mode VLAN: 1 (default)
Trunking Native Mode VLAN: 1 (default)
Administrative Native VLAN tagging: enabled
Administrative private-vlan host-association: none
Administrative private-vlan mapping: 20 (VLAN0020) 25 (VLAN0025) 30 (VLAN0030) 35
(VLAN0035)
Administrative private-vlan trunk native VLAN: none
Administrative private-vlan trunk Native VLAN tagging: enabled
Administrative private-vlan trunk encapsulation: dotlg
Administrative private-vlan trunk normal VLANs: none
Administrative private-vlan trunk private VLANs: none
Operational private-vlan:
20 (VLAN0020) 25 (VLAN0025)
30 (VLAN0030)
35 (VLAN0035)
```

```
<output truncated>
```

This is an example of output from the show interfaces switchport backup command:

Switch# show interfaces switchport backup Switch Backup Interface Pairs: Active Interface Backup Interface State

Fa0/1	Fa0/2	Active Up/Backup Standby
Fa0/3	Fa0/5	Active Down/Backup Up
Pol	Po2	Active Standby/Backup Up

This is an example of output from the **show interfaces** *interface-id* **trunk** command. It displays trunking information for the port.

Switch#	show	interfaces	gigabitethernet0/	1 trunk	
Port		Mode	Encapsulation	Status	Native vlan
Gi0/1		auto	negotiate	trunking	1
Port Gi0/1		Vlans allc 1-4094	wed on trunk		
Port Gi0/1		Vlans allo 1-4	wed and active in	management do	main
Port Gi0/1		Vlans in s 1-4	panning tree forw	arding state a	nd not pruned

This is an example of output from the **show interfaces transceiver properties** command. If you do not specify an interface, the output of the command shows the status on all switch ports:

Switch# **show interfaces transceiver properties** Name : Fa0/1

Administrative Speed: auto Administrative Duplex: auto Administrative Auto-MDIX: on Administrative Power Inline: N/A Operational Speed: 100 Operational Duplex: full Operational Auto-MDIX: on

```
Name : Fa0/2
Administrative Speed: auto
Administrative Duplex: auto
Administrative Auto-MDIX: on
Administrative Power Inline: N/A
Operational Speed: 100
Operational Duplex: full
Operational Auto-MDIX: on
```

<output truncated>

Related Commands	Command	Description
	switchport access vlan	Configures a port as a static-access or a dynamic-access port.
	switchport block	Blocks unknown unicast or multicast traffic on an interface.
	switchport backup interface	Configures Flex Links, a pair of Layer 2 interfaces that provide mutual backup.
	switchport mode	Configures the VLAN membership mode of a port.
	<mark>switchport mode</mark> private-vlan	Configures a port as a private-VLAN host or a promiscuous port.
	switchport mode private-vlan	Defines private-VLAN association for a host port or private-VLAN mapping for a promiscuous port.

show interfaces counters

Use the **show interfaces counters** privileged EXEC command to display various counters for the switch or for a specific interface.

show interfaces [interface-id | vlan vlan-id] counters [errors | trunk] [module switch- number] |
etherchannel | protocol status] [| {begin | exclude | include} expression]

Syntax Description	interface-id	(Optional) ID of the physical interface, including type, module, and port number.				
	errors	(Optional) Display error counters.				
	trunk	(Optional) Display trunk counters.				
	module switch- number	Note (Optional) Display counters for the specified switch number. The only available value is 1.				
	etherchannel	(Optional) Display EtherChannel counters, including octets, broadcast packets, multicast packets, and unicast packets received and sent.				
	protocol status	(Optional) Display status of protocols enabled on interfaces.				
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .				
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
	include	(Optional) Display includes lines that match the specified expression.				
	expression	Expression in the output to use as a reference point.				



Though visible in the command-line help string, the **vlan** vlan-id keyword is not supported.

Command Modes

Privileged EXEC

Command History	Release	Modification	
	12.2(25)EX	This command was introduced.	

Usage Guidelines

If you do not enter any keywords, all counters for all interfaces are included.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of partial output from the **show interfaces counters** command. It displays all counters for the switch.

Switch# show	interfaces co	ounters		
Port	InOctets	InUcastPkts	InMcastPkts	InBcastPkts
Fa0/1	0	0	0	0
Fa0/2	0	0	0	0

<output truncated>

This is an example of partial output from the **show interfaces counters protocol status** command for all interfaces.

Switch# show interfaces counters protocol status Protocols allocated: Vlan1: Other, IP

```
Vlan20: Other, IP, ARP
Vlan30: Other, IP, ARP
Vlan40: Other, IP, ARP
Vlan50: Other, IP, ARP
Vlan60: Other, IP, ARP
Vlan70: Other, IP, ARP
Vlan80: Other, IP, ARP
Vlan90: Other, IP, ARP
Vlan900: Other, IP, ARP
Vlan3000: Other, IP
Vlan3500: Other, IP
FastEthernet0/1: Other, IP, ARP, CDP
FastEthernet0/2: Other, IP
FastEthernet0/3: Other, IP
FastEthernet0/4: Other, IP
FastEthernet0/5: Other, IP
FastEthernet0/6: Other, IP
FastEthernet0/7: Other, IP
FastEthernet0/8: Other, IP
FastEthernet0/9: Other, IP
FastEthernet0/10: Other, IP, CDP
```

<output truncated>

This is an example of output from the **show interfaces counters trunk** command. It displays trunk counters for all interfaces.

Switch#	show interfaces co	unters trunk	
Port	TrunkFramesTx	TrunkFramesRx	WrongEncap
Gi0/1	0	0	0
Gi0/2	0	0	0
Gi0/3	80678	4155	0
Gi0/4	82320	126	0
Gi0/5	0	0	0

<output truncated>

Related Commands

 Command
 Description

 show interfaces
 Displays additional interface characteristics.

show inventory

Use the **show inventory** user EXEC command to display all field replaceable units—chassis and small form-factor pluggable (SFP) modules.

show inventory [raw] [| {begin | exclude | include} expression]

Syntax Description		
-,	raw	(Optional) Display every entity in the device.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	dump of all identif The compact dump	ase sensitive. With no arguments, the show inventory command produces a compact Table entities that have a product identifier (PID). In displays the entity location (slot identity), entity description, and the unique device (ID, VID, and SN) of that entity.
		are not programmed with PIDs and VID.s
▲		
Note	If there is no PID,	no output appears when you enter the show inventory command.
Note	Expressions are ca	
Note Examples	Expressions are cas are not displayed, l	se sensitive. For example, if you enter exclude output , the lines that contain <i>output</i>
	Expressions are cas are not displayed, I This is example ou Switch> show inve NAME: "1", DESCR	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> but the lines that contain <i>Output</i> are displayed.
	Expressions are cas are not displayed, I This is example ou Switch> show inve NAME: "1", DESCR PID: ME-3400-24TS	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> but the lines that contain <i>Output</i> are displayed. Intput from the show inventory command: entory : "ME-3400-24TS-A"

show ip arp inspection

Use the **show ip arp inspection** privileged EXEC command to display the configuration and the operating state of dynamic Address Resolution Protocol (ARP) inspection or the status of this feature for all VLANs or for the specified interface or VLAN.

show ip arp inspection [interfaces [interface-id] | log | statistics [vlan vlan-range] | vlan
vlan-range] [| {begin | exclude | include} expression]

This command is available only if your switch is running the metro IP access or metro access image.

Syntax Description	interfaces [interface-id]	(Optional) Display the trust state and the rate limit of ARP packets for the specified interface or all interfaces. Valid interfaces include physical ports and port channels.
	log	(Optional) Display the configuration and contents of the dynamic ARP inspection log buffer.
	statistics [vlan vlan-range]	(Optional) Display statistics for forwarded, dropped, MAC validation failure, IP validation failure, access control list (ACL) permitted and denied, and DHCP permitted and denied packets for the specified VLAN. If no VLANs are specified or if a range is specified, display information only for VLANs with dynamic ARP inspection enabled (active).
		You can specify a single VLAN identified by VLAN ID number, a range of VLANs separated by a hyphen, or a series of VLANs separated by a comma. The range is 1 to 4094.
	vlan vlan-range	(Optional) Display the configuration and the operating state of dynamic ARP inspection for the specified VLAN. If no VLANs are specified or if a range is specified, display information only for VLANs with dynamic ARP inspection enabled (active).
		You can specify a single VLAN identified by VLAN ID number, a range of VLANs separated by a hyphen, or a series of VLANs separated by a comma. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression
	expression	Expression in the output to use as a reference point.

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines

L

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples This is an example of output from the **show ip arp inspection interfaces** command:

Switch# show :	p arp inspection	interfaces	
Interface	Trust State	Rate (pps)	Burst Interval
Gi0/1	Untrusted	15	1
Gi0/2	Untrusted	15	1
Gi0/3	Untrusted	15	1

This is an example of output from the **show ip arp inspection interfaces** interface-id command:

Switch# show ip	arp inspection	interfaces gigab	itethernet0/1
Interface	Trust State	Rate (pps)	Burst Interval
Gi0/1	Untrusted	15	1

This is an example of output from the **show ip arp inspection log** command. It shows the contents of the log buffer before the buffers are cleared:

Switch# **show ip arp inspection log** Total Log Buffer Size : 32 Syslog rate : 10 entries per 300 seconds.

Interface	Vlan	Sender MAC	Sender IP	Num Pkts	Reason	Time
Gi0/1	5	0003.0000.d673	192.2.10.4	5	DHCP Deny	 19:39:01 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.0000.d774	128.1.9.25	6	DHCP Deny	19:39:02 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.c940.1111	10.10.10.1	7	DHCP Deny	19:39:03 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.c940.1112	10.10.10.2	8	DHCP Deny	19:39:04 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.c940.1114	173.1.1.1	10	DHCP Deny	19:39:06 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.c940.1115	173.1.1.2	11	DHCP Deny	19:39:07 UTC
Mon Mar 1 1	1993					
Gi0/1	5	0001.c940.1116	173.1.1.3	12	DHCP Deny	19:39:08 UTC
Mon Mar 1 1	1993					

If the log buffer overflows, it means that a log event does not fit into the log buffer, and the display for the **show ip arp inspection log** privileged EXEC command is affected. A -- in the display appears in place of all data except the packet count and the time. No other statistics are provided for the entry. If you see this entry in the display, increase the number of entries in the log buffer, or increase the logging rate in the **ip arp inspection log-buffer** global configuration command.

This is an example of output from the **show ip arp inspection statistics** command. It shows the statistics for packets that have been processed by dynamic ARP inspection for all active VLANs.

Switch#	show ip arp insp	ection statist	ics	
Vlan	Forwarded	Dropped	DHCP Drops	ACL Drops
5	3	4618	4605	4
2000	0	0	0	0

Vlan	DHCP Permits	ACL Permits	Source MAC Fai	lures
5	0	12		0
2000	0	0		0
Vlan	Dest MAC Failure	e TP Valid	ation Failures	
vian	Dest inte i utituite	5 II Valia	acton fattates	
5		0	9	
2000		0	0	

For the **show ip arp inspection statistics** command, the switch increments the number of forwarded packets for each ARP request and response packet on a trusted dynamic ARP inspection port. The switch increments the number of ACL or DHCP permitted packets for each packet that is denied by source MAC, destination MAC, or IP validation checks, and the switch increments the appropriate failure count.

This is an example of output from the **show ip arp inspection statistics vlan 5** command. It shows statistics for packets that have been processed by dynamic ARP for VLAN 5.

Switch#	show ip arp in	nspection stati	stics vlan 5			
Vlan	Forwarded	Dropped	DHCP Drops	ACL Drops		
					-	
5	3	4618	4605		4	
Vlan	DHCP Permits	ACL Permits	Source MAC Fa	ilures		
5	0	12		0		
Vlan	Dest MAC Failu	ures IP Valid	ation Failures	Invalid	Protocol	Data
5		0	9			3

This is an example of output from the **show ip arp inspection vlan 5** command. It shows the configuration and the operating state of dynamic ARP inspection for VLAN 5.

Switch# :	show ip arp inspect	tion vlan 5		
Source Ma	ac Validation	:Enabled		
Destinat	ion Mac Validation	:Enabled		
IP Addres	ss Validation	:Enabled		
Vlan	Configuration	Operation	ACL Match	Static ACL
5	Enabled	Active	second	No
Vlan	ACL Logging	DHCP Loggin	g	
			-	
5	Acl-Match	A11		

Related Commands

ommands	Command	Description
	arp access-list	Defines an ARP ACL.
	clear ip arp inspection log	Clears the dynamic ARP inspection log buffer.
	clear ip arp inspection statistics	Clears the dynamic ARP inspection statistics.
	ip arp inspection log-buffer	Configures the dynamic ARP inspection logging buffer.
	ip arp inspection vlan logging	Controls the type of packets that are logged per VLAN.
	show arp access-list	Displays detailed information about ARP access lists.

show ip dhcp snooping

Use the show ip dhcp snooping user EXEC command to display the DHCP snooping configuration.

show ip dhcp snooping [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .						
	exclude	(Optional) Display excludes lines that match the expression.						
	I include (Optional) Display includes lines that match the specified expression							
	expression	Expression in the output to use as a reference point.						
Command Modes	User EXEC							
Command History	Release	Modification						
	12.2(25)EX	This command was introduced.						
Usage Guidelines	-	nsitive. For example, if you enter exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear.						
Usage Guidelines Examples	do not appear, but the lin							
	do not appear, but the lin This is an example of ou Switch> show ip dhcp Switch DHCP snooping DHCP snooping is conf	nes that contain <i>Output</i> appear. utput from the show ip dhcp snooping command. snooping						
	do not appear, but the lin This is an example of ou Switch> show ip dhcp Switch DHCP snooping	nes that contain <i>Output</i> appear. utput from the show ip dhcp snooping command. snooping is enabled Figured on following VLANs: 22 is enabled ad port is allowed						
	do not appear, but the lin This is an example of our Switch> show ip dhcp Switch DHCP snooping DHCP snooping is conf 40-42 Insertion of option 8 Option 82 on untruster Verification of hwadd	nes that contain <i>Output</i> appear. utput from the show ip dhcp snooping command. snooping is enabled figured on following VLANs: 22 is enabled ad port is allowed ar field is enabled Trusted Rate limit (pps)						
	do not appear, but the lin This is an example of ou Switch> show ip dhep Switch DHCP snooping DHCP snooping is conf 40-42 Insertion of option 8 Option 82 on untruste Verification of hwadd Interface GigabitEthernet0/1	nes that contain <i>Output</i> appear. utput from the show ip dhcp snooping command. snooping is enabled Figured on following VLANS: 22 is enabled ad port is allowed ar field is enabled Trusted Rate limit (pps) 						

show ip dhcp snooping binding

Use the **show ip dhcp snooping binding** user EXEC command to display the DHCP snooping binding database and configuration information for all interfaces on a switch.

show ip dhcp snooping binding [ip-address] [mac-address] [interface interface-id] [vlan vlan-id]
 [| {begin | exclude | include} expression]

Syntax Description									
Syntax Description	ip-address	(Optional) Specify the bind	ing entry IP addre	ss.					
	mac-address	(Optional) Specify the bind	ing entry MAC ad	dress.					
	interface interface-id	<i>d</i> (Optional) Specify the binding input interface.							
	vlan vlan-id	vlan <i>vlan-id</i> (Optional) Specify the binding entry VLAN.							
	begin	Display begins with the line	that matches the	express	sion.				
	exclude	Display excludes lines that	match the express	ion.					
	include	Display includes lines that	match the specifie	d expre	ession.				
	expression	Expression in the output to	use as a reference	point.					
	_								
Command Modes	User EXEC								
Command History	Release	Modification							
· · · · · · · · · · · · · · · · · · ·	12.2(25)EX	This command was introdu	red						
Jsage Guidelines	Use the show ip sourc	pping binding command output e binding privileged EXEC co the DHCP snooping binding d	nmand to display						
Usage Guidelines	Use the show ip sourc configured bindings in	e binding privileged EXEC co the DHCP snooping binding d nabled and an interface change	nmand to display atabase.	the dyn	namically and statically				
Usage Guidelines	Use the show ip sourc configured bindings in If DHCP snooping is e statically configured bindings Expressions are case se	e binding privileged EXEC co the DHCP snooping binding d nabled and an interface change	nmand to display atabase. s to the down state ter exclude outp	the dyn	namically and statically vitch does not delete th				
	Use the show ip sourc configured bindings in If DHCP snooping is e statically configured bi Expressions are case so do not appear, but the b	e binding privileged EXEC co the DHCP snooping binding d nabled and an interface change indings. ensitive. For example, if you en	nmand to display atabase. s to the down state ter exclude outp c.	the dyn , the sw ut , the l	namically and statically witch does not delete th lines that contain <i>outpu</i>				
Usage Guidelines Examples	Use the show ip sourc configured bindings in If DHCP snooping is e statically configured bi Expressions are case so do not appear, but the b	e binding privileged EXEC co the DHCP snooping binding d nabled and an interface change indings. ensitive. For example, if you en lines that contain <i>Output</i> appea	nmand to display atabase. s to the down state ter exclude outp c.	the dyn , the sw ut , the l	namically and statically witch does not delete th lines that contain <i>outpu</i>				

This example shows how to display the DHCP snooping binding entries for a specific IP address:

Switch> show ip dhcp snooping binding 10.1.2.150

MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
01:02:03:04:05:06	10.1.2.150	9810	dhcp-snooping	20	GigabitEthernet0/1
Total number of bin	dings: 1				

This example shows how to display the DHCP snooping binding entries for a specific MAC address:

Switch> show ip dho	p snooping bindin	g 0102.0304.	0506		
MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
01:02:03:04:05:06	10.1.2.150	9788	dhcp-snooping	20	GigabitEthernet0/2
Total number of bin	dings: 1				

This example shows how to display the DHCP snooping binding entries on a port:

Switch> show ip dhc	p snooping bindin	g interface	gigabitethernet	0/2	
MacAddress	IpAddress	Lease(sec)	Туре	VLAN	Interface
00:30:94:C2:EF:35	10.1.2.151	290	dhcp-snooping	20	GigabitEthernet0/2
Total number of bin	dings: 1				

This example shows how to display the DHCP snooping binding entries on VLAN 20:

```
Switch> show ip dhcp snooping binding vlan 20MacAddressIpAddressLease(sec)TypeVLANInterface01:02:03:04:05:0610.1.2.1509747dhcp-snooping20GigabitEthernet0/100:00:00:00:00:0210.1.2.15165dhcp-snooping20GigabitEthernet0/2Total number of bindings: 2
```

Table 2-12 describes the fields in the show ip dhcp snooping binding command output:

Table 2-12 show ip dhcp snooping binding Command Output

Field	Description		
MacAddress	Client hardware MAC address		
IpAddress	Client IP address assigned from the DHCP server		
Lease(sec)	Remaining lease time for the IP address		
Туре	Binding type		
VLAN	VLAN number of the client interface		
Interface	Interface that connects to the DHCP client host		
Total number of bindings	Total number of bindings configured on the switch		
	Note The command output might not show the total number of bindings. For example, if 200 bindings are configured on the switch and you stop the display before all the bindings appear, the total number does not change.		

Related Commands

Command	Description
ip dhcp snooping binding	Configures the DHCP snooping binding database
show ip dhcp snooping	Displays the DHCP snooping configuration.

show ip dhcp snooping database

Use the **show ip dhcp snooping database** user EXEC command to display the status of the DHCP snooping binding database agent.

show ip dhcp snooping database [detail] [| {begin | exclude | include} expression]

detail	(Optional) Dis	play de	etailed status and	statistics	information.		
begin	(Optional) Dis	play be	egins with the line	that mat	tches the expression.		
l exclude (Optional) Display excludes lines that match the <i>expression</i> .							
l include (Optional) Display includes lines that match the specified <i>expression</i> .							
expression	Expression in	the out	put to use as a ref	erence p	oint.		
User EXEC							
Release	Mo	dificati	on				
12.2(25)EX	Thi	s comn	nand was introduc	ed.			
Agent URL :		-	tabase				
_		conds					
Agent Runni:	ng : No						
-		-					
		ilure	recorded.				
-	-	0	-		0		
		0		rs :	0		
		0	Failed Reads Failed Writes	:	0 0		
					0		
	I begin I exclude I include expression User EXEC Release 12.2(25)EX This is an example Switch> show Agent URL : Write delay Abort Timer Agent Runnin Delay Timer Abort Timer Last Succede Last Failed Total Attem Successful T	I begin (Optional) Dis I exclude (Optional) Dis I include (Optional) Dis <i>expression</i> Expression in User EXEC Expression Release Mod 12.2(25)EX This Switch> show ip dhcp snoop Agent URL : Write delay Timer : 300 seconds Agent Running : No Delay Timer Expiry : Not R Abort Timer Expiry : Not R Last Succeded Time : None Last Failed Time : None Last Failed Time : None Last Failed Reason : No fa Total Attempts : Successful Transfers : Successful Reads :	I begin (Optional) Display be I exclude (Optional) Display expression I include (Optional) Display expression User EXEC Image: Superson of the system o	I begin (Optional) Display begins with the line I exclude (Optional) Display excludes lines that n I include (Optional) Display includes lines that n expression Expression in the output to use as a refe User EXEC Ease Modification 12.2(25)EX This is an example of output from the show ip dhcp sn Switch> show ip dhcp snooping database Agent URL : Write delay Timer : 300 seconds Abort Timer Expiry : Not Running Abort Timer Expiry : Not Running Last Succeded Time : None Last Failed Time : None Last Failed Reason : No failure recorded. Total Attempts : 0 Startup Failur Successful Transfers : 0 Failed Transfer	Ibegin (Optional) Display begins with the line that math I exclude (Optional) Display excludes lines that match the Include (Optional) Display includes lines that match the expression Expression in the output to use as a reference pression User EXEC Release Modification 12.2(25)EX This command was introduced. This is an example of output from the show ip dhcp snooping Switch> show ip dhcp snooping database Agent URL : Write delay Timer : 300 seconds Abort Timer : 300 seconds Abort Timer Expiry : Not Running Abort Timer Expiry : Not Running Last Succeded Time : None Last Failed Time : None Last Failed Reason : No failure recorded. Total Attempts : 0 Startup Failures : Successful Transfers : 0 Failed Transfers :		

This is an example of output from the show ip dhcp snooping database detail command:

```
Switch# show ip dhcp snooping database detail
Agent URL : tftp://10.1.1.1/directory/file
Write delay Timer : 300 seconds
Abort Timer : 300 seconds
Agent Running : No
Delay Timer Expiry : 7 (00:00:07)
Abort Timer Expiry : Not Running
Last Succeded Time : None
Last Failed Time : 17:14:25 UTC Sat Jul 7 2001
Last Failed Reason : Unable to access URL.
Total Attempts
                         21 Startup Failures :
                                                      0
                  :
Successful Transfers :
                         0 Failed Transfers :
                                                     21
Successful Reads :
                         0 Failed Reads :
                                                      0
Successful Writes
                 :
                         0 Failed Writes :
                                                      21
                         0
Media Failures
                 :
First successful access: Read
Last ignored bindings counters :
Binding Collisions : 0
                               Expired leases
                                               :
                                                        0
                          0
Invalid interfaces
                   :
                                                        0
                               Unsupported vlans :
Parse failures
                          0
                   :
Last Ignored Time : None
Total ignored bindings counters:
Binding Collisions : 0
                               Expired leases
                                                        0
                                                :
                        0
0
Invalid interfaces
                  :
                               Unsupported vlans :
                                                        0
Parse failures
                    :
```

Related Commands

Command	Description
ip dhcp snooping	Enables DHCP snooping on a VLAN.
ip dhcp snooping database	Configures the DHCP snooping binding database agent or the binding file.
show ip dhcp snooping	Displays DHCP snooping information.

show ip igmp profile

Use the **show ip igmp profile** privileged EXEC command to display all configured Internet Group Management Protocol (IGMP) profiles or a specified IGMP profile.

show ip igmp profile [profile number] [| {begin | exclude | include} expression]

Syntax Description	profile number	(Optional) The IGMP profile number to be displayed. The range is 1 to 4294967295. If no profile number is entered, all IGMP profiles are displayed.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Examples	_	es of output from the show ip igmp profile privileged EXEC command, with and g a profile number. If no profile number is entered, the display includes all profiles switch.
	Switch# show ip IGMP Profile 40 permit	
	Switch# show ip	igmp profile
	IGMP Profile 4 permit	9.0 230.9.9.0 9.0 229.255.255.255
Related Commands	range 230.9. IGMP Profile 4 permit	
Related Commands	range 230.9. IGMP Profile 4 permit range 229.9.	9.0 229.255.255.255

show ip igmp snooping

Use the **show ip igmp snooping** user EXEC command to display the Internet Group Management Protocol (IGMP) snooping configuration of the switch or the VLAN.

show ip igmp snooping [groups | mrouter | querier [vlan vlan-id] [detail]] [vlan vlan-id] [detail]
 [| {begin | exclude | include} expression]

Syntax Description	groups	(Optional) See the show ip igmp snooping groups command.		
	mrouter	(Optional) See the show ip igmp snooping mrouter command.		
	querier	(Optional) See the show ip igmp snooping querier command.		
	vlan vlan-id	vlan <i>vlan-id</i> (Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094 (available only in privileged EXEC mode).		
	begin	(Optional) Display begins with the line that matches the expression.		
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
	I include(Optional) Display includes lines that match the specified <i>expression</i> .			
	expression	Expression in the output to use as a reference point.		
Command Modes	User EXEC			
Command History	Release	Modification		
ooniniana mistory	12.2(25)EX	This command was introduced.		
Usage Guidelines	Use this command to display snooping configuration for the switch or for a specific VLAN. VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping.			
	Although visible in the output display, output lines for source-only learning are not valid.			
	-	case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> if the lines that contain <i>Output</i> appear.		
Examples	-	ble of output from the show ip igmp snooping vlan 1 command. It shows snooping or a specific VLAN.		
	Global IGMP Sno	p igmp snooping vlan 1 poping configuration:		
	IGMP snooping IGMPv3 snooping Report suppress TCN solicit que TCN flood query	ery :Disabled		

```
Vlan 1:

------

IGMP snooping :Enabled

Immediate leave :Disabled

Multicast router learning mode :pim-dvmrp

Source only learning age timer :10

CGMP interoperability mode :IGMP_ONLY

Last member query interval : 100
```

```
<u>Note</u>
```

Source-only learning are not supported, and information appearing for this feature is not valid.

This is an example of output from the **show ip igmp snooping** command. It displays snooping characteristics for all VLANs on the switch.

```
Switch> show ip igmp snooping
Global IGMP Snooping configuration:
_____
IGMP snooping : Enabled
IGMPv3 snooping (minimal) : Enabled
Report suppression : Enabled
TCN solicit query
                       : Disabled
TCN flood query count : 2
Last member query interval : 100
Vlan 1:
_____
IGMP snooping
                                :Enabled
Immediate leave
                               :Disabled
Multicast router learning mode
                              :pim-dvmrp
Source only learning age timer
                              :10
                              :IGMP_ONLY
CGMP interoperability mode
Last member query interval
                               : 100
Vlan 2:
_____
IGMP snooping
                                :Enabled
Immediate leave
                                :Disabled
Multicast router learning mode
                              :pim-dvmrp
Source only learning age timer
                               :10
CGMP interoperability mode
                               : IGMP_ONLY
Last member query interval
                                : 333
```

<output truncated>

Related Commands	Command	Description	
	ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.	
	show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.	
	show ip igmp snooping querier	Displays the configuration and operation information for the IGMP querier configured on a switch.	

show ip igmp snooping groups

Use the **show ip igmp snooping groups** privileged EXEC command to display the Internet Group Management Protocol (IGMP) snooping multicast table for the switch or the multicast information. Use with the **vlan** keyword to display the multicast table for a specified multicast VLAN or specific multicast information.

show ip igmp snooping groups [count | dynamic [count] | user [count]] [| {begin | exclude |
include} expression]

show ip igmp snooping groups vlan vlan-id [ip_address | count | dynamic [count] | user [count]]
 [| {begin | exclude | include} expression]

	-				
Syntax Description	count	(Optional) Display the total number of entries for the specified command options instead of the actual entries.			
	dynamic	(Optional) Display entries learned by IGMP snooping.			
	user	Optional) Display only the user-configured multicast entries.			
	ip_address	(Optional) Display characteristics of the multicast group with the specified group IP address.			
	vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.			
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .			
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .			
	include	(Optional) Display includes lines that match the specified <i>expression</i> .			
	<i>expression</i> Expression in the output to use as a reference point.				
Command Modes	Privileged EXE				
Command History	Release	Modification			
	12.2(25)EX	This command was introduced.			
Usage Guidelines	Use this comma	and to display multicast information or the multicast table.			
	VLAN IDs 100 snooping.	2 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP			
	*	case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> put the lines that contain <i>Output</i> appear.			

Examples

This is an example of output from the **show ip igmp snooping groups** command without any keywords. It displays the multicast table for the switch.

Switch# show ip igmp snooping groups

Vlan	Group	Туре	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Gi0/2
104	224.1.4.3	igmp	v2	Gi0/1, Gi0/2

This is an example of output from the **show ip igmp snooping groups count** command. It displays the total number of multicast groups on the switch.

Switch# show ip igmp snooping groups count Total number of multicast groups: 2

This is an example of output from the **show ip igmp snooping groups dynamic** command. It shows only the entries learned by IGMP snooping.

Switch#	show ip igmp	snooping groups	vlan 1 dy	namic
Vlan	Group	Туре	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Fa0/15
104	224.1.4.3	igmp	v2	Gi0/1, Fa0/15

This is an example of output from the **show ip igmp snooping groups vlan** *vlan-id ip-address* command. It shows the entries for the group with the specified IP address.

Switch#	show ip igmp	snooping groups	vlan 104	224.1.4.2
Vlan	Group	Туре	Version	Port List
104	224.1.4.2	igmp	v2	Gi0/1, Fa0/15

Related Commands	Command	Description
	ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.
	show ip igmp snooping	Displays the IGMP snooping configuration of the switch or the VLAN.
	show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.

show ip igmp snooping mrouter

Use the **show ip igmp snooping mrouter** privileged EXEC command to display the Internet Group Management Protocol (IGMP) snooping dynamically learned and manually configured multicast router ports for the switch or for the specified multicast VLAN.

show ip igmp snooping mrouter [vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description	vlan vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.		
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
	exclude	(Optional) Display excludes lines that match the expression.		
	include	(Optional) Display includes lines that match the specified expression.		
	expression	Expression in the output to use as a reference point.		
Command Modes	Privileged EXEC			
Command History	Release	Modification		
	12.2(25)EX	This command was introduced.		
Usage Guidelines	 Use this command to display multicast router ports on the switch or for a specific VLAN. VLAN IDs 1002 to 1005 are reserved for Token Ring and FDDI VLANs and cannot be used in IGMP snooping. When multicast VLAN registration (MVR) is enabled, the show ip igmp snooping mrouter command displays MVR multicast router information and IGMP snooping information. 			
	When multicast VL			
	When multicast VL displays MVR mul Expressions are cas	ticast router information and IGMP snooping information.		
Examples	When multicast VL displays MVR mul Expressions are cas do not appear, but t This is an example	ticast router information and IGMP snooping information. se sensitive. For example, if you enter exclude output , the lines that contain <i>output</i>		
Examples	When multicast VL displays MVR mul Expressions are cas do not appear, but t This is an example display multicast re	ticast router information and IGMP snooping information. se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. of output from the show ip igmp snooping mrouter command. It shows how to		

Related Commands	Command	Description	
	ip igmp snooping	Enables and configures IGMP snooping on the switch or on a VLAN.	
	ip igmp snooping vlan mrouter	Adds a multicast router port to a multicast VLAN.	
	show ip igmp snooping	Displays the IGMP snooping configuration of the switch or the VLAN	
	show ip igmp snooping groups	Displays IGMP snooping multicast information for the switch or for the specified parameter.	

show ip igmp snooping querier

Use the **show ip igmp snooping querier** user EXEC command to display the IP address and incoming port for the Internet Group Management Protocol (IGMP) query most recently received by the switch.

show ip igmp snooping querier [vlan vlan-id] [detail] [| {begin | exclude | include} expression]

Syntax Description	vlan vlan-id	(Optional) Specify a VLAN; the range is 1 to 1001 and 1006 to 4094.		
	detail	(Optional) Display querier information as well as configuration and operational information pertaining to the querier.		
	begin	(Optional) Display begins with the line that matches the expression.		
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
	include	(Optional) Display includes lines that match the specified expression.		
	expression	Expression in the output to use as a reference point.		
Command Modes	User EXEC			
oonnana moues	User EALC			
Command History	Release	Modification		
	12.2(25)EX	This command was introduced.		
Usage Guidelines	detected device multicast router	igmp snooping querier command to display the IGMP version and IP address of a (also called a <i>querier</i>) that sends IGMP query message. A subnet can have multiple s but has only one IGMP querier. In a subnet running IGMPv2, one of the multicast d as the querier. The querier can be a Layer 3 switch.		
	The show ip igmp snooping querier command output also shows the VLAN and interface on which the querier was detected. If the querier is the switch, the output shows the <i>Port</i> field as <i>Router</i> . If the querier is a router, the output shows the port number on which the querier is learned in the <i>Port</i> field.			
	The show ip igmp snooping querier detail user EXEC command is similar to the show ip igmp snooping querier command. However, the show ip igmp snooping querier detail command displays the IP address of the most recent device detected by the switch querier along with this additional information:			
	• The elected	IGMP querier in the VLAN		
		ration and operational information pertaining to the switch querier (if any) that is in the VLAN		
		case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> ut the lines that contain <i>Output</i> appear.		

Examples

This is an example of output from the show ip igmp snooping querier command:

Switch> show ip igmp snooping querier

Vlan	IP Address	IGMP Version	Port
1	172.20.50.11	 v3	Gi0/1
2	172.20.40.20	v2	Router

This is an example of output from the **show ip igmp snooping querier detail** command:

Switch> show ip igmp snooping querier detail

Vlan	IP Address	IGMP V	ersion	Port	
1	1.1.1.1	v2		Fa0/1	
	MP switch queri				
admin sta admin ver source IP query-int max-respo querier-t tcn query tcn query	te sion address erval (sec) nse-time (sec) imeout (sec) count interval (sec)		: Enable : 2 : 0.0.0. : 60 : 10 : 120 : 2 : 10	ed	
	Vlan 1: IGMP switch querier status elected querier is 1.1.1.1 on port Fa0/1				
max-respo querier-t tcn query tcn query operation operation	sion address erval (sec) nse-time (sec) imeout (sec) count interval (sec)		: Enable : 2 : 10.1.1 : 60 : 10 : 120 : 2 : 10 : Non-Qu : 2 : 0	65	

Related Commands

ds	Command	Description			
	ip igmp snooping querier	Enables and configures the IGMP snooping querier on the switch or on a VLAN.			
	show ip igmp snooping mrouter	Displays IGMP snooping multicast router ports for the switch or for the specified multicast VLAN.			

show ip source binding

Use the **show ip source binding** user EXEC command to display the IP source bindings on the switch.

show ip source binding [ip-address] [mac-address] [dhcp-snooping | static] [vlan vlan-id]
[interface interface-id] [| {begin | exclude | include} expression]

This command is available only if your switch is running the metro IP access or metro access image.

Syntax Description	ip-address	(Optional	al) Display IP sour	ce bindings for a	specific	c IP address.	
, ,	mac-address		al) Display IP source	•	-		
	dhcp-snooping		al) Display IP source				
	static	(Optional) Display static IP source bindings.					
	vlan vlan-id	(Optional) Display IP source bindings on a specific VLAN.ce-id(Optional) Display IP source bindings on a specific interface.					
	interface interface-i						
	begin	(Optiona	al) Display begins	with the line that	matche	es the expression.	
	exclude	(Optiona	al) Display exclude	s lines that match	the ex	pression.	
	include	(Optiona	al) Display include	s lines that match	the sp	ecified expression.	
	expression	Express	ion in the output to	use as a reference	e point		
Command Modes	User EXEC						
Command History	Release	Modificat	ion				
				1			
	12.2(25)EX	This com	mand was introduc	ed.			
Usage Guidelines	The show ip source b	inding comma g binding data	and output shows th base. Use the show	e dynamically an ip dhcp snoopi n		ally configured bindings ling privileged EXEC	
	The show ip source h in the DHCP snoopin	binding comma g binding data only the dynan	and output shows th base. Use the show nically configured b	e dynamically an 7 ip dhcp snoopi n bindings.	ng bind		
	The show ip source h in the DHCP snoopin command to display This is an example of Switch> show ip sou MacAddress	binding comma g binding data only the dynan f output from the irce binding IpAddress	and output shows th base. Use the show nically configured b he show ip source Lease(sec)	e dynamically an 7 ip dhcp snoopi n bindings.	n g binc nd:		
Usage Guidelines Examples	The show ip source h in the DHCP snoopin command to display This is an example of Switch> show ip sou	binding comma g binding data only the dynan f output from the arce binding	and output shows th base. Use the show nically configured b he show ip source Lease(sec)	e dynamically and p ip dhcp snoopi bindings. binding commar	n g binc nd:	ling privileged EXEC	
	The show ip source h in the DHCP snoopin command to display This is an example of Switch> show ip sou MacAddress 	binding comma g binding data only the dynam f output from the irce binding IpAddress 	and output shows th base. Use the show nically configured b he show ip source Lease(sec) infinite	e dynamically any p ip dhcp snoopi pindings. binding commar	ng bind nd: VLAN 10	Interface GigabitEthernet0/1	
Examples	The show ip source h in the DHCP snoopin command to display of This is an example of Switch> show ip sou MacAddress 	foutput from the dynamic of the dyna	and output shows th base. Use the show nically configured b the show ip source Lease(sec) infinite 10000	e dynamically and pindings. binding comman Type static dhcp-snooping	ng bind nd: 10 10	Interface GigabitEthernet0/1 GigabitEthernet0/1	

show ip verify source

Use the **show ip verify source** user EXEC command to display the IP source guard configuration on the switch or on a specific interface.

show ip verify source [interface *interface-id*] [| { begin | exclude | include } *expression*]

This command is available only if your switch is running the metro IP access or metro access image.

Syntax Description	interface interface-id	<i>-id</i> (Optional) Display IP source guard configuration on a specific interfac	
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .	
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
	include	(Optional) Display includes lines that match the specified <i>expression</i> .	
	expression	Expression in the output to use as a reference point.	

Command Modes User EXEC

a ! . 1

.

.

. .

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Examples

This is an example of output from the show ip verify source command:

Switch> show ip verify source							
Interface	Filter-type	Filter-mode	IP-address	Mac-address	Vlan		
fa0/1	ip	active	10.0.0.1		10		
fa0/1	ip	active	deny-all		11-20		
fa0/2	ip	inactive-tru	st-port				
fa0/3	ip	inactive-no-	snooping-vlan				
fa0/4	ip-mac	active	10.0.2	aaaa.bbbb.cccc	10		
fa0/4	ip-mac	active	11.0.0.1	aaaa.bbbb.cccd	11		
fa0/4	ip-mac	active	deny-all	deny-all	12-20		
fa0/5	ip-mac	active	10.0.3	permit-all	10		
fa0/5	ip-mac	active	deny-all	permit-all	11-20		

In the previous example, this is the IP source guard configuration:

- On the Fast Ethernet 0/1 interface, dynamic host control protocol (DHCP) snooping is enabled on VLANs 10 to 20. For VLAN 10, IP source guard with IP address filtering is configured on the interface, and a binding is on the interface. For VLANs 11 to 20, the second entry shows that a default port access control list (ACL) is applied on the interface for the VLANs on which IP source guard is not configured.
- The Fast Ethernet 0/2 interface is configured as trusted for DHCP snooping.
- On the Fast Ethernet 0/3 interface, DHCP snooping is not enabled on the VLANs to which the interface belongs.

- On the Fast Ethernet 0/4 interface, IP source guard with source IP and MAC address filtering is enabled, and static IP source bindings are configured on VLANs 10 and 11. For VLANs 12 to 20, the default port ACL is applied on the interface for the VLANs on which IP source guard is not configured.
- On the Fast Ethernet 0/5 interface, IP source guard with source IP and MAC address filtering is enabled and configured with a static IP binding, but port security is disabled. The switch cannot filter source MAC addresses.

This is an example of output on an interface on which IP source guard is disabled:

Switch> show ip verify source gigabitethernet0/6 IP source guard is not configured on the interface gi0/6.

Related Commands	Command	Description
	ip verify source	Enables IP source guard on an interface.

show ipc

Use the **show ipc** user EXEC command to display Interprocess Communications Protocol (IPC) configuration, status, and statistics.

show ipc {mcast {appclass | groups | status } | nodes | ports [open] | queue | rpc | session {all |
 rx | tx } [verbose] | status [cumlulative] | zones } [| {begin | exclude | include } expression]

Syntax Description	mcast {appclass groups status}	Display the IPC multicast routing information. The keywords have these meanings:
		• appclass —Display the IPC multicast application classes.
		• groups—Display the IPC multicast groups.
		• status —Display the IPC multicast routing status.
	nodes	Display participating nodes.
	ports [open]	Display local IPC ports. The keyword has this meaning:
		• open —(Optional) Display only the open ports.
	queue	Display the contents of the IPC transmission queue.
	rpc	Display the IPC remote-procedure statistics.
	session {all rx tx}	Display the IPC session statistics (available only in privileged EXEC mode). The keywords have these meanings:
		• all —Display all the session statistics.
		• rx —Display the sessions statistics for traffic that the switch receives
		• tx—Display the sessions statistics for traffic that the switch forwards.
	verbose	(Optional) Display detailed statistics (available only in privileged EXEC mode).
	status [cumlulative]	Display the status of the local IPC server. The keyword has this meaning:
		• cumlulative —(Optional) Display the status of the local IPC server since the switch was started or restarted.
	zones	Display participating IPC zones. The switch supports one IPC zone.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain output do not appear, but the lines that contain Output appear.

Examples

This example shows how to display the IPC routing status:

IPC Mcast Status

			Tx	Rx
Total Frames			0	0
Total control Frames Total Frames dropped			0	0
Total control Frames dropped			0	0
Total Reliable messages	_	_	0	0
Total Reliable messages acknowl Total Out of Band Messages	edge	ed.	0	0
Total Out of Band messages acknowledged			0	0
Total No Mcast groups			0	0
Total Retries	0	Total Timeouts		0
Total OOB Retries	0	100001 0000 110000	ıts	0
Total flushes	0	Total No ports		0

This example shows how to display the participating nodes:

```
Switch> show ipc nodes
There is 1 node in this IPC realm.
  ID
        Туре
                   Name
                                  Last Last
                                  Sent Heard
```

IPC Master This example shows how to display the local IPC ports:

```
Switch> show ipc ports
There are 8 ports defined.
```

10000 Local

Port ID	Туре	Name	(current/g	peak/total)	
There are 8 po	rts defined				
10000.1	unicast	IPC Master:Zone			
10000.2	unicast	IPC Master:Echo			
10000.3	unicast	IPC Master:Control			
10000.4	unicast	IPC Master:Init			
10000.5	unicast	FIB Master:DFS.process_1	evel.msgs		
10000.6	unicast	FIB Master:DFS.interrupt	.msgs		
10000.7	unicast	MDFS RP:Statistics			
port_inde	x = 0 seat	_id = 0x10000 last sen	nt = 0	last heard = 0	
0/2/159					
10000.8	unicast	Slot 1 :MDFS.control.RIL	L		
port_inde	x = 0 seat	_id = 0x10000 last sen	nt = 0	last heard = 0	
0/0/0					
RPC packets:current/peak/total					
				0/1/4	

0

0

This example shows how to display the contents of the IPC retransmission queue:

Switch> show ipc queue There are 0 IPC messages waiting for acknowledgement in the transmit queue. There are 0 IPC messages waiting for a response. There are 0 IPC messages waiting for additional fragments. There are 0 IPC messages currently on the IPC inboundQ. Messages currently in use 3 : 1000 Message cache size : Maximum message cache usage : 1000 5000 [max] 0 times message cache crossed Emergency messages currently in use : 0 There are 2 messages currently reserved for reply msg. Inbound message queue depth 0 Zone inbound message queue depth 0

This example shows how to display all the IPC session statistics:

```
Switch# show ipc session all
Tx Sessions:
Port ID
              Type
                        Name
  10000.7
             Unicast MDFS RP:Statistics
    port_index = 0 type = Unreliable
                                                          last heard = 0
                                        last sent = 0
    Msgs requested = 180 Msgs returned = 180
            Unicast Slot 1 :MDFS.control.RIL
  10000.8
    port_index = 0 type = Reliable
                                   last sent = 0
                                                          last heard = 0
    Msgs requested = 0
                       Msgs returned = 0
Rx Sessions:
Port ID
             Туре
                        Name
  10000.7
             Unicast
                       MDFS RP:Statistics
    port_index = 0 seat_id = 0x10000
                                      last sent = 0
                                                        last heard = 0
    No of msgs requested = 180 Msgs returned = 180
  10000.8
             Unicast
                        Slot 1 :MDFS.control.RIL
    port_index = 0 seat_id = 0x10000 last sent = 0
                                                        last heard = 0
    No of msgs requested = 0
                             Msgs returned = 0
```

This example shows how to display the status of the local IPC server:

Switch> show ipc status cumulative IPC System Status Time last IPC stat cleared :never This processor is the IPC master server. Do not drop output of IPC frames for test purposes. 1000 IPC Message Headers Cached.

	Rx Side	Tx Side
Total Frames	12916	608
0 0		
Total from Local Ports	13080	574
Total Protocol Control Frames	116	17
Total Frames Dropped	0	0

Service Usage

Total via Unreliable Connection-Less Service	12783	171
Total via Unreliable Sequenced Connection-Less Svc	0	0
Total via Reliable Connection-Oriented Service	17	116

<output truncated>

Related Commands

d Commands	Command	Description
	clear ipc	Clears the IPC multicast routing statistics.

show I2protocol-tunnel

Use the **show l2protocol-tunnel** user EXEC command to display information about Layer 2 protocol tunnel ports. Displays information for interfaces with protocol tunneling enabled.

show l2protocol-tunnel [interface interface-id] [summary] [| {begin | exclude | include}
expression]

```
Note
```

This command is available only when the metro IP access or metro access image is running on the switch.

Syntax Description	interface <i>interface-id</i>	(Optional) Specify the interface for which protocol tunneling information appears. Valid interfaces are physical ports and port channels; the port channel range is 1 to 64.
	summary	(Optional) Display only Layer 2 protocol summary information.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	After enabling Layer 2	protocol tunneling on an access or IEEE 802.1Q tunnel port by using the
osuge duitennes		face configuration command, you can configure some or all of these parameters
	• Protocol type to be	tunneled
	• Shutdown threshold	1
	• Drop threshold	
	If you enter the show l2	protocol-tunnel [interface <i>interface-id</i>] command, only information about the l1 the parameters are configured appears.
	•	Protocol-tunnel summary command, only information about the active ports the parameters are configured appears.
		nsitive. For example, if you enter exclude output, the lines that contain <i>output</i> nes that contain <i>Output</i> appear.

Examples

This is an example of output from the show l2protocol-tunnel command:

```
Switch> show 12protocol-tunnel
```

COS for Encapsulated Packets: 5 Drop Threshold for Encapsulated Packets: 0

Port			-	Encapsulation Counter	n Decapsulation Counter	Drop Counter
 Fa0/3						
ra0/5						
	pagp			0	242500	
	lacp			24268	242640	
	udld			0	897960	
Fa0/4						
, _						
	pagp	1000		24249	242700	1
	lacp			24256	242660	1
	udld			0	897960	1
Gi0/1	cdp			134482	1344820	1
	pagp	1000		0	242500	1
	lacp	500		0	485320	I
	udld	300		44899	448980	1

This is an example of output from the show l2protocol-tunnel summary command:

```
Switch> show 12protocol-tunnel summary
COS for Encapsulated Packets: 5
Drop Threshold for Encapsulated Packets: 0
```

Port	Protocol	Shutdown Threshold (cdp/stp/vtp) (pagp/lacp/udld)		Status
,		//		up
pag	p lacp udld	//	//	
Fa0/3		//	//	up
pag	p lacp udld	1000//	//	
Fa0/4		//	//	up
pag	p lacp udld	1000/ 500/	//	
Fa0/5	cdp stp vt	p//	//	down
		//	//	
Gi0/1		//	//	down
pag	p	//	1000//	
Gi0/2		//	//	down
pag	p	//	1000//	

Related Commands	Command	Description
	clear l2protocol-tunnel counters	Clears counters for protocol tunneling ports.
	l2protocol-tunnel	Enables Layer 2 protocol tunneling for CDP, STP, or VTP packets on an interface.
	l2protocol-tunnel cos	Configures a class of service (CoS) value for tunneled Layer 2 protocol packets.

show lacp

Use the **show lacp** user EXEC command to display Link Aggregation Control Protocol (LACP) channel-group information.

show lacp [channel-group-number] {counters | internal | neighbor | sys-id } [| {begin | exclude | include } expression]

Ø, Note

LACP is available only on network node interfaces (NNIs).

Syntax Description	channel-group-number	(Optional) Number of the channel group. The range is 1 to 48.
	counters	Display traffic information.
	internal	Display internal information.
	neighbor	Display neighbor information.
	sys-id	Display the system identifier that is being used by LACP. The system identifier is made up of the LACP system priority and the switch MAC address.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command Modes	User EXEC	Modification
		Modification This command was introduced.
	Release 12.2(25)EX You can enter any show	
Command History	Release 12.2(25)EX You can enter any show specific channel information	This command was introduced. lacp command to display the active channel-group information. To display
Command History	Release12.2(25)EXYou can enter any showspecific channel informaIf you do not specify a cl	This command was introduced. lacp command to display the active channel-group information. To display tion, enter the show lacp command with a channel-group number.

Examples

This is an example of output from the **show lacp counters** user EXEC command. Table 2-13 describes the fields in the display.

Switch>	show	lacp c	ounters					
		LACP	DUs	Marke	er	Marker R	esponse	LACPDUs
Port		Sent	Recv	Sent	Recv	Sent	Recv	Pkts Err
Channel	group	p:1						
Gi0/1		19	10	0	0	0	0	0
Gi0/2		14	6	0	0	0	0	0

Table 2-13show lacp counters Field Descriptions

Field	Description
LACPDUs Sent and Recv	The number of LACP packets sent and received by a port.
Marker Sent and Recv	The number of LACP marker packets sent and received by a port.
Marker Response Sent and Recv	The number of LACP marker response packets sent and received by a port.
LACPDUs Pkts and Err	The number of unknown and illegal packets received by LACP for a port.

This is an example of output from the show lacp internal command:

```
Switch> show lacp 1 internal
Flags: S - Device is requesting Slow LACPDUs
        F - Device is requesting Fast LACPDUs
        A - Device is in Active mode
                                            P - Device is in Passive mode
Channel group 1
                               LACP port
                                             Admin
                                                       Oper
                                                               Port
                                                                         Port
Port
            Flags
                    State
                               Priority
                                             Key
                                                       Key
                                                               Number
                                                                         State
                                             0x3
                                                       0x3
Gi0/1
                               32768
                                                                         0x3D
            SA
                    bndl
                                                               0x4
Gi0/2
            SA
                    bndl
                               32768
                                             0x3
                                                       0x3
                                                               0x5
                                                                         0x3D
```

Field	Description
State	State of the specific port. These are the allowed values:
	• –—Port is in an unknown state.
	• bndl —Port is attached to an aggregator and bundled with other ports.
	• susp —Port is in a suspended state; it is not attached to any aggregator.
	• hot-sby —Port is in a hot-standby state.
	• indiv —Port is incapable of bundling with any other port.
	• indep —Port is in an independent state (not bundled but able to switch data traffic. In this case, LACP is not running on the partner port).
	• down —Port is down.
LACP Port Priority	Port priority setting. LACP uses the port priority to put ports s in standby mode when there is a hardware limitation that prevents all compatible ports from aggregating.
Admin Key	Administrative key assigned to this port. LACP automatically generates an administrative key value as a hexadecimal number. The administrative key defines the ability of a port to aggregate with other ports. A port's ability to aggregate with other ports is determined by the port physical characteristics (for example, data rate and duplex capability) and configuration restrictions that you establish.
Oper Key	Runtime operational key that is being used by this port. LACP automatically generates this value as a hexadecimal number.
Port Number	Port number.
Port State	State variables for the port, encoded as individual bits within a single octet with these meanings:
	• bit0: LACP_Activity
	• bit1: LACP_Timeout
	• bit2: Aggregation
	• bit3: Synchronization
	• bit4: Collecting
	• bit5: Distributing
	• bit6: Defaulted
	• bit7: Expired
	Note In the above list, bit7 is the MSB and bit0 is the LSB.

Table 2-14show lacp internal Field Descriptions

This is an example of output from the **show lacp neighbor** command:

Flags: S	how lacp neighbor - Device is sending S - Device is in Active			-
Channel g	roup 3 neighbors			
Partner's	information:			
Port Gi0/1	Partner System ID 32768,0007.eb49.5e80	Partner Port Number 0xC	Age 19s	Partner Flags SP
		Partner Oper Key 0x3	Partner Port State 0x3C	
Partner's	information:			
Port Gi0/2	Partner System ID 32768,0007.eb49.5e80	Partner Port Number 0xD	Age 15s	Partner Flags SP
	LACP Partner Port Priority 32768		Partner Port State 0x3C	

This is an example of output from the **show lacp sys-id** command:

Switch> **show lacp sys-id** 32765,0002.4b29.3a00

The system identification is made up of the system priority and the system MAC address. The first two bytes are the system priority, and the last six bytes are the globally administered individual MAC address associated to the system.

Related Commands	Command	Description
	clear lacp	Clears the LACP channel-group information.
	lacp port-priority	Configures the LACP port priority.
	lacp system-priority	Configures the LACP system priority.

show mac access-group

Use the **show mac access-group** user EXEC command to display the MAC access control lists (ACLs) configured for an interface or a switch.

show mac access-group [interface interface-id] [| {begin | exclude | include} expression]

Syntax Description	interface interface-id	(Optional) Display the MAC ACLs configured on a specific interface. Valid interfaces are physical ports and port channels; the port-channel range is 1 to 48 (available only in privileged EXEC mode).
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
Usage Guidelines	-	This command was introduced.
Usage Guidelines Examples	Expressions are case ser do not appear, but the li This is an example of ou	nsitive. For example, if you enter exclude output , the lines that contain <i>outpu</i> nes that contain <i>Output</i> appear. utput from the show mac-access group user EXEC command. In this display, D/2 has the MAC access list <i>macl_e1</i> applied to inbound traffic; no MAC ACLs

This is an example of output from the show mac access-group interface fastethernet0/1 command:

Switch# show mac access-group interface fastethernet0/1
Interface FastEthernet0/1:
 Inbound access-list is macl_e1

Related Commands

Command	Description
mac access-group	Applies a MAC access group to an interface.

show mac address-table

Use the **show mac address-table** user EXEC command to display a specific MAC address table static and dynamic entry or the MAC address table static and dynamic entries on a specific interface or VLAN.

show mac address-table [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) D	isplay begins with the line that matches the <i>expression</i> .
	exclude	(Optional) D	isplay excludes lines that match the <i>expression</i> .
	include	(Optional) D	isplay includes lines that match the specified expression.
	expression	Expression i	n the output to use as a reference point.
ommand Modes	User EXEC		
ommand History	Release	Modification	I
	12.2(25)EX	This comma	nd was introduced.
sage Guidelines	-	case sensitive. For exa at the lines that contain	mple, if you enter exclude output , the lines that contain <i>outp</i> in <i>Output</i> appear.
	do not appear, bu This is an examp Switch> show ma Mac 2	ut the lines that contain ole of output from the s ac address-table Address Table	n <i>Output</i> appear. show mac address-table command:
-	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add	ut the lines that contain the of output from the s ac address-table Address Table dress Type	show mac address-table command:
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add	ut the lines that contain the of output from the s ac address-table Address Table dress Type	<i>Output</i> appear. show mac address-table command:
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00	at the lines that contain the of output from the state ac address-table Address Table Address Type 	h Output appear. show mac address-table command: Ports CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00	at the lines that contain ble of output from the second stable Address Table Address Type 000.0001 STATIC 000.0002 STATIC 000.0003 STATIC	h Output appear. show mac address-table command: Ports CPU CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00	at the lines that contain ble of output from the second stable Address Table Address Type Address Type Addres	h Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00	at the lines that contain ble of output from the second stable address Table dress Type 	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2	at the lines that contain ble of output from the second stable address Table address Type address Type addres	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU
-	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2 All 0180.c2	at the lines that contain a contrast from the second seco	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU
-	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2 All 0180.c2 All 0180.c2	at the lines that contain a contrast from the second seco	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU
lsage Guidelines xamples	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2	at the lines that contain a contrast from the second seco	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2	at the lines that contain a contrast from the second seco	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU
	do not appear, bu This is an examp Switch> show ma Mac A Vlan Mac Add All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0000.00 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2 All 0180.c2	at the lines that contain a contrast from the second seco	A Output appear. show mac address-table command: Ports CPU CPU CPU CPU CPU CPU CPU CPU

Related Commands	Command	Description
	clear mac address-table dynamic	Deletes from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, or all dynamic addresses on a particular VLAN.
	show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
	show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
	show mac address-table dynamic	Displays dynamic MAC address table entries only.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
	show mac address-table static	Displays static MAC address table entries only.
	show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table address

Use the **show mac address-table address** user EXEC command to display MAC address table information for the specified MAC address.

show mac address-table address mac-address [interface interface-id] [vlan vlan-id] [| {begin |
 exclude | include} expression]

Syntax Description		
Syntax Description	mac-address	Specify the 48-bit MAC address; the valid format is H.H.H.
	interface interface-id	(Optional) Display information for a specific interface. Valid interfaces include physical ports and port channels.
	vlan vlan-id	(Optional) Display entries for the specific VLAN only. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
Command History	Release 12.2(25)EX	Modification This command was introduced.
	12.2(25)EX Expressions are case ser	
Usage Guidelines	12.2(25)EX Expressions are case ser do not appear, but the lin	This command was introduced.
Command History Usage Guidelines Examples	12.2(25)EX Expressions are case ser do not appear, but the lin This is an example of ou Switch# show mac addr Mac Address	This command was introduced. Insitive. For example, if you enter I exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear. In the show mac address-table address command: In the show mac address-table address command: In the show mac address 0002.4b28.c482
Usage Guidelines	12.2(25)EX Expressions are case ser do not appear, but the lin This is an example of ou Switch# show mac addr Mac Address	This command was introduced. An an analysis of the second structure of the se

Related Commands C

Command	Description
show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
show mac address-table dynamic	Displays dynamic MAC address table entries only.
show mac address-table interface	Displays the MAC address table information for the specified interface.
show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
show mac address-table static	Displays static MAC address table entries only.
show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table aging-time

Use the **show mac address-table aging-time** user EXEC command to display the aging time of a specific address table instance, all address table instances on a specified VLAN or, if a specific VLAN is not specified, on all VLANs.

show mac address-table aging-time [vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description	vlan vlan-id	(Optional) Display aging time information for a specific VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	Expressions are cas	er is specified, the aging time for all VLANs appears. Se sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.
Examples	Expressions are cas do not appear, but t	se sensitive. For example, if you enter exclude output, the lines that contain <i>output</i>
	Expressions are cas do not appear, but t This is an example Switch> show mac Vlan Aging Tim	of output from the show mac address-table aging-time command: address-table aging-time
	Expressions are cas do not appear, but t This is an example Switch> show mac	of output from the show mac address-table aging-time command: address-table aging-time
	Expressions are cas do not appear, but t This is an example Switch> show mac Vlan Aging Tim 1 300	of output from the show mac address-table aging-time command: address-table aging-time
	Expressions are cas do not appear, but t This is an example Switch> show mac Vlan Aging Tim 1 300 This is an example	The second secon

Related Commands	Command	Description
	mac address-table aging-time	Sets the length of time that a dynamic entry remains in the MAC address table after the entry is used or updated.
	show mac address-table address	Displays MAC address table information for the specified MAC address.
	show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
	show mac address-table dynamic	Displays dynamic MAC address table entries only.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
	show mac address-table static	Displays static MAC address table entries only.
	show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table count

Use the **show mac address-table count** user EXEC command to display the number of addresses present in all VLANs or the specified VLAN.

show mac address-table count [vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description	vlan vlan-id	(Optional) Display the number of addresses for a specific VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	If no VLAN nu	umber is specified, the address count for all VLANs appears.
	-	e case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> but the lines that contain <i>Output</i> appear.
Examples	This is an exam	ple of output from the show mac address-table count command:
	Switch# show r Mac Entries fo	mac address-table count or Vlan : 1
	Dynamic Addres Static Addres Total Mac Addr	ss Count : 0

Related Commands	Command	Description
	show mac address-table address	Displays MAC address table information for the specified MAC address.
	show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
	show mac address-table dynamic	Displays dynamic MAC address table entries only.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
	show mac address-table static	Displays static MAC address table entries only.
	show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table dynamic

Use the **show mac address-table dynamic** user EXEC command to display only dynamic MAC address table entries.

show mac address-table dynamic [address mac-address] [interface interface-id] [vlan vlan-id]
 [| {begin | exclude | include} expression]

Syntax Description	address mac-address	(Optional) Specify a 48-bit MAC address; the valid format is H.H.H (available in privileged EXEC mode only).
	interface interface-id	(Optional) Specify an interface to match; valid <i>interfaces</i> include physical ports and port channels.
	vlan vlan-id	(Optional) Display entries for a specific VLAN; the range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	•	ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear.
Examples	This is an example	e of output from the show mac address-table dynamic command:
		address-table dynamic Ndress Table
	Vlan Mac Addr	ress Type Ports
	1 0030.b63 1 00b0.649	5.7862 DYNAMIC Gi0/2 6.2741 DYNAMIC Gi0/2

Related Commands	Command	Description
	clear mac address-table dynamic	Deletes from the MAC address table a specific dynamic address, all dynamic addresses on a particular interface, or all dynamic addresses on a particular VLAN.
	show mac address-table address	Displays MAC address table information for the specified MAC address.
	show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
	show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table static	Displays static MAC address table entries only.
	show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table interface

Use the **show mac address-table interface** user command to display the MAC address table information for the specified interface in the specified VLAN.

show mac address-table interface interface-id [vlan vlan-id] [| {begin | exclude | include}
expression]

Syntax Description		
Syntax Description	interface-id	Specify an interface type; valid interfaces include physical ports and port channels.
	vlan vlan-id	(Optional) Display entries for a specific VLAN; the range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	-	e sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.
	do not appear, but the	
	do not appear, but the This is an example of Switch> show mac	he lines that contain <i>Output</i> appear.
	do not appear, but the This is an example of Switch> show mac	he lines that contain <i>Output</i> appear. of output from the show mac address-table interface command: address-table interface gigabitethernet0/2 ress Table
Usage Guidelines Examples	do not appear, but the This is an example Switch> show mac Mac Add Vlan Mac Addre	he lines that contain <i>Output</i> appear. of output from the show mac address-table interface command: address-table interface gigabitethernet0/2 ress Table
	do not appear, but the This is an example Switch> show mac Mac Add 	he lines that contain <i>Output</i> appear. of output from the show mac address-table interface command: address-table interface gigabitethernet0/2 ress Table ss Type Ports .7862 DYNAMIC Gi0/2

Related Commands Co

Description
Displays MAC address table information for the specified MAC address.
Displays the aging time in all VLANs or the specified VLAN.
Displays the number of addresses present in all VLANs or the specified VLAN.
Displays dynamic MAC address table entries only.
Displays the MAC address notification settings for all interfaces or the specified interface.
Displays static MAC address table entries only.
Displays the MAC address table information for the specified VLAN.

show mac address-table learning

Use the **show mac address-table learning** user EXEC command to display the status of MAC address learning for all VLANs or the specified VLAN.

show mac address-table learning [vlan vlan-id] [| {begin | exclude | include} expression]

This command is supported only when the metro IP access or metro access image is running on the switch.

begin exclude include expression	 (Optional) Display begins with the line that matches the <i>expression</i>. (Optional) Display excludes lines that match the <i>expression</i>. (Optional) Display includes lines that match the specified <i>expression</i>. Expression in the output to use as a reference point.
include	(Optional) Display includes lines that match the specified <i>expression</i> .
expression	Expression in the output to use as a reference point
	Expression in the output to use as a reference point.
User EXEC	
Release	Modification
12.2(25)EX	This command was introduced.
-	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.
-	of output from the show mac address-table learning user EXEC command showing earning is disabled on VLAN 200:
Switch> show mac VLAN Learning	address-table learning Status
1 yes 100 yes 200 no	
100 yes	
	Release 12.2(25)EX Use the show mac VLANs and whethered address learning is learning status on a Expressions are cased do not appear, but t This is an example of that MAC address I Switch> Switch> Show mac VLAN

show mac address-table notification

Use the **show mac address-table notification** user EXEC command to display the MAC address notification settings for all interfaces or the specified interface.

show mac address-table notification [interface [interface-id]] [| {begin | exclude | include}
expression]

Syntax Description	interface	(Optional) Display information for all interfaces. Valid interfaces include physical ports and port channels.
	interface-id	(Optional) Display information for the specified interface. Valid interfaces include physical ports and port channels.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Jsage Guidelines	feature is enabled of	address-table notification command without any keywords to display whether the or disabled, the MAC notification interval, the maximum number of entries allowed
Usage Guidelines	feature is enabled of in the history table. Use the interface k	or disabled, the MAC notification interval, the maximum number of entries allowed, and the history table contents. eeyword to display the flags for all interfaces. If the <i>interface-id</i> is included, only the
Usage Guidelines	feature is enabled of in the history table. Use the interface k flags for that interf Expressions are cas	or disabled, the MAC notification interval, the maximum number of entries allowed, and the history table contents. eeyword to display the flags for all interfaces. If the <i>interface-id</i> is included, only the
Usage Guidelines Examples	feature is enabled of in the history table. Use the interface k flags for that interf Expressions are cas do not appear, but t	or disabled, the MAC notification interval, the maximum number of entries allowed, and the history table contents. reyword to display the flags for all interfaces. If the <i>interface-id</i> is included, only the face appear. se sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> .

MAC Addr: 0000.0000.0001 Module: 0 Operation: Added Vlan: 2 Port: 1 History Index 1, Entry Timestamp 1038254, Despatch Timestamp 1038254 MAC Changed Message : Operation: Added Vlan: 2 MAC Addr: 0000.0000.0000 Module: 0 Port: 1 Operation: Added Vlan: 2 MAC Addr: 0000.0000.0002 Module: 0 Port: 1 Operation: Added Vlan: 2 MAC Addr: 0000.0000.0003 Module: 0 Port: 1 History Index 2, Entry Timestamp 1074254, Despatch Timestamp 1074254 MAC Changed Message : MAC Addr: 0000.0000.0000 Module: 0 Operation: Deleted Vlan: 2 Port: 1 Operation: Deleted Vlan: 2MAC Addr: 0000.0000.0001 Module: 0Operation: Deleted Vlan: 2MAC Addr: 0000.0000.0002 Module: 0Operation: Deleted Vlan: 2MAC Addr: 0000.0000.0003 Module: 0 Port: 1 Port: 1 Port: 1

Related	Commands
---------	----------

Description
Clears the MAC address notification global counters.
Displays MAC address table information for the specified MAC address.
Displays the aging time in all VLANs or the specified VLAN.
Displays the number of addresses present in all VLANs or the specified VLAN.
Displays dynamic MAC address table entries only.
Displays the MAC address table information for the specified interface.
Displays static MAC address table entries only.
Displays the MAC address table information for the specified VLAN.

show mac address-table static

Use the **show mac address-table static** user EXEC command to display only static MAC address table entries.

show mac address-table static [address mac-address] [interface interface-id] [vlan vlan-id]
 [| {begin | exclude | include} expression]

Syntax Description	address mac-address	(Optional) Specify a 48-bit MAC address; the valid format is H.H.H (available in privileged EXEC mode only).
	interface interface-id	(Optional) Specify an interface to match; valid <i>interfaces</i> include physical ports and port channels.
	vlan vlan-id	(Optional) Display addresses for a specific VLAN. The range is 1 to 4094.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the **show mac address-table static** command:

Switch> show mac address-table static

	Mac Address Ta	able	
Vlan	Mac Address	Туре	Ports
A11	0100.0ccc.cccc	STATIC	CPU
A11	0180.c200.0000	STATIC	CPU
A11	0100.0ccc.cccd	STATIC	CPU
A11	0180.c200.0001	STATIC	CPU
A11	0180.c200.0004	STATIC	CPU
A11	0180.c200.0005	STATIC	CPU
4	0001.0002.0004	STATIC	Drop
6	0001.0002.0007	STATIC	Drop
Total	Mac Addresses for	this cr	iterion: 8

Related Commands	Command	Description
	mac address-table static	Adds static addresses to the MAC address table.
	mac address-table static drop	Enables unicast MAC address filtering and configures the switch to drop traffic with a specific source or destination MAC address.
	show mac address-table address	Displays MAC address table information for the specified MAC address.
	show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
	show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
	show mac address-table dynamic	Displays dynamic MAC address table entries only.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
	show mac address-table vlan	Displays the MAC address table information for the specified VLAN.

show mac address-table vlan

Use the **show mac address-table vlan** user EXEC command to display the MAC address table information for the specified VLAN.

show mac address-table vlan vlan-id [| {begin | exclude | include} expression]

Syntax Description	vlan-id	(Optional) D	Display a	addresses for a specific VLAN. The range is 1 to 4094.
	begin	(Optional) D	Display b	begins with the line that matches the <i>expression</i> .
	exclude	(Optional) D	Display e	excludes lines that match the <i>expression</i> .
	include	(Optional) D	Display i	ncludes lines that match the specified expression.
	expression	Expression i	in the ou	tput to use as a reference point.
Command Modes	User EXEC			
Command History	Release	M	lodificat	tion
	12.2(25)EX	Т	his com	mand was introduced.
Usage Guidelines	-			example, if you enter exclude output , the lines that contain <i>output</i> tain <i>Output</i> appear.
	do not appear	r, but the lines t	that con	tain <i>Output</i> appear.
	do not appear This is an exa Switch> shor Ma	r, but the lines t	that con It from th -table y ble	tain <i>Output</i> appear. he show mac address-table vlan 1 command: vlan 1
	do not appear This is an exa Switch> show Ma 	r, but the lines a ample of outpu w mac address ac Address Tal Address	that con t from the -table ble Type	tain <i>Output</i> appear. he show mac address-table vlan 1 command: vlan 1 Ports
	do not appear This is an exa Switch> show Ma Vlan Mac	r, but the lines a ample of outpu w mac address ac Address Tal Address	that con It from the -table -	tain <i>Output</i> appear. the show mac address-table vlan 1 command: vlan 1 Ports
	do not appear This is an exa Switch> show Ma Mac 1 0100	r, but the lines a ample of output w mac address ac Address Tal Address Tal Address Tal	that con t from th -table ble 	tain <i>Output</i> appear. the show mac address-table vlan 1 command: vlan 1 Ports
	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0100	r, but the lines a ample of output w mac address ac Address Tal Address Tal O.Occc.cccc S 0.0ccc.cccc S 0.0ccc.cccc S 0.0ccc.cccc S	that const t from the -table s ble 	tain Output appear. the show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU
	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0180 1 0180	r, but the lines a ample of output w mac address ac Address Tal Address Tal 0.0ccc.cccc s 0.0ccc.cccc s 0.0ccc.cccc s 0.0ccc.cccd s 0.0ccc.cccd s	that const t from the -table set ble 	tain Output appear. the show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU CPU CPU
	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0180 1 0180 1 0180 1 0180	r, but the lines a ample of output w mac address ac Address Tal Address Tal O.Occc.cccc S 0.0ccc.cccc S 0.0ccc.cccd S 0.0ccc.cccd S 0.0ccc.cccd S 0.0ccc.cccd S 0.0cc0.0001 S 0.0cc0.0001 S	that const t from the -table set ble 	tain Output appear. he show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU CPU CPU CPU
	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180	r, but the lines a ample of output w mac address ac Address Tal Address Tal O.Occc.cccc S 0.0ccc.cccc S 0.0ccc.cccd S 0.0ccc.cccd S 0.0ccc.cccd S 0.0cc0.0001 S 0.0c200.0001 S 0.0c200.0003 S	that const t from the -table set ble 	tain Output appear. he show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU CPU CPU CPU CPU
Usage Guidelines Examples	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180 1 0180	r, but the lines a ample of output w mac address ac Address Tal Address 7 0.0ccc.cccc 8 0.0c200.0000 8 0.0ccc.cccd 8 0.0c200.0001 8 0.0c200.0001 8 0.0c200.0003 8 0.0c200.0003 8	that const t from the -table set ble 	tain Output appear. he show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU CPU CPU CPU CPU
	do not appear This is an exa Switch> show Ma Vlan Mac 1 0100 1 0180 1 0180	r, but the lines a ample of output w mac address ac Address Tal Address Tal 0.0ccc.cccc S 0.c200.0000 S 0.c200.0001 S 0.c200.0001 S 0.c200.0003 S 0.c200.0003 S 0.c200.0005 S	that const t from the -table set ble 	tain Output appear. he show mac address-table vlan 1 command: vlan 1 Ports CPU CPU CPU CPU CPU CPU CPU CPU

Related Commands	Command	Description
	show mac address-table address	Displays MAC address table information for the specified MAC address.
	show mac address-table aging-time	Displays the aging time in all VLANs or the specified VLAN.
	show mac address-table count	Displays the number of addresses present in all VLANs or the specified VLAN.
	show mac address-table dynamic	Displays dynamic MAC address table entries only.
	show mac address-table interface	Displays the MAC address table information for the specified interface.
	show mac address-table notification	Displays the MAC address notification settings for all interfaces or the specified interface.
	show mac address-table static	Displays static MAC address table entries only.

show monitor

Use the **show monitor** user EXEC command to display information about all Switched Port Analyzer (SPAN) and Remote SPAN (RSPAN) sessions on the switch. Use the command with keywords to show a specific session, all sessions, all local sessions, or all remote sessions.

show monitor [session { session_number | all | local | range list | remote } [detail]] [| {begin |
 exclude | include } expression]

Syntax Description	session	(Optional) Display information about specified SPAN sessions.
	session_number	Specify the number of the SPAN or RSPAN session. The range is 1 to 66.
	all	Display all SPAN sessions.
	local	Display only local SPAN sessions.
	range list	Display a range of SPAN sessions, where <i>list</i> is the range of valid sessions, either a single session or a range of sessions described by two numbers, the lower one first, separated by a hyphen. Do not enter any spaces between comma-separated parameters or in hyphen-specified ranges.
		Note This keyword is available only in privileged EXEC mode.
	remote	Display only remote SPAN sessions.
	detail	(Optional) Display detailed information about the specified sessions.
	begin	Display begins with the line that matches the <i>expression</i> .
	exclude	Display excludes lines that match the <i>expression</i> .
	include	Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Lidelines Expressions are case sensitive. For example, if you enter **I exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

The output is the same for the show monitor command and the show monitor session all command.

Examples

This is an example of output for the **show monitor** user EXEC command:

```
Switch# show monitor
Session 1
_____
Туре
          :Local Session
Source Ports:
   RX Only:
                Fa0/24
   TX Only: None
Both: Fa0/2
                Fa0/1-2,Fa0/1-5
Destination Ports:Fa0/18
   Encapsulation:Replicate
Session 2
_____
Type :Remote Source Session
Source Ports:
Source VLANs:
TX Only: 10
Both:
                 1-9
   Both:
Dest RSPAN VLAN: 105
```

This is an example of output for the **show monitor** user EXEC command for RSPAN source session 1:

```
Switch# show monitor session 1
Session 1
------
Type :Local Session
Source Ports:
RX Only: Fa0/24
TX Only: None
Both: Fa0/1-2,Fa0/1-5
Destination Ports:Fa0/18
Encapsulation:Replicate
```

This is an example of output for the **show monitor session all** user EXEC command when ingress traffic forwarding is enabled:

```
Switch# show monitor session all
Session 1
-----
Type :Local Session
Source Ports :
   Both :Fa0/2
Destination Ports :Fa0/3
   Encapsulation :Replicate
        Ingress:Enabled, default VLAN = 5
   Ingress encapsulation:DOT1Q
Session 2
```

```
Type :Local Session
Source Ports :
Both :Fa0/1
Destination Ports :Fa0/4
Encapsulation :Replicate
Ingress :Enabled
Ingress encapsulation:DOT1Q
```

Related Commands	Command	Description
	monitor session	Starts or modifies a SPAN or RSPAN session.

show mvr

Use the **show mvr** privileged EXEC command without keywords to display the current Multicast VLAN Registration (MVR) global parameter values, including whether or not MVR is enabled, the MVR multicast VLAN, the maximum query response time, the number of multicast groups, and the MVR mode (dynamic or compatible).

show mvr [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the expression.				
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .				
	include	(Optional) Display includes lines that match the specified expression.				
	expression	Expression in the output to use as a reference point.				
Command Modes	Privileged EXEC					
Command History	Release	Modification				
	12.2(25)EX	This command was introduced.				
Usage Guidelines	-	e sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.				
	do not appear, but th	he lines that contain <i>Output</i> appear.				
Usage Guidelines Examples	do not appear, but the This is an example of Switch# show mvr MVR Running: TRUE MVR multicast VLAN MVR Max Multicast MVR Current multic	<pre>he lines that contain Output appear. bf output from the show mvr command: U: 1 Groups: 256 cast groups: 0 cesponse time: 5 (tenths of sec)</pre>				

Related Commands	Command	Description
	mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.
	mvr (interface configuration)	Configures MVR ports.
	show mvr interface	Displays the configured MVR interfaces, status of the specified interface, or all multicast groups to which the interface belongs when the interface and members keywords are appended to the command.
	show mvr members	Displays all ports that are members of an MVR multicast group or, if there are no members, means the group is inactive.

show mvr interface

Use the **show mvr interface** privileged EXEC command without keywords to display the Multicast VLAN Registration (MVR) receiver and source ports. Use the command with keywords to display MVR parameters for a specific receiver port.

show mvr interface [interface-id [members [vlan vlan-id]]] [| {begin | exclude | include}
expression]

Syntax Description	interface-id	(Optional) Display MVR type, status, and Immediate Le interface.	eave setting for the					
		Valid interfaces include physical ports (including type, r number.	Valid interfaces include physical ports (including type, module, and port number.					
	members	(Optional) Display all MVR groups to which the specifie	d interface belongs.					
	vlan vlan-id	(Optional) Display all MVR group members on this VL to 4094.	AN. The range is 1					
	begin	(Optional) Display begins with the line that matches the	expression.					
	exclude	(Optional) Display excludes lines that match the express	tion.					
	include	d expression.						
	expression	Expression in the output to use as a reference point.						
Command Modes	Privileged EXEC							
Command History	Release Modification							
	12.2(25)EX This command was introduced.							
Usage Guidelines	1	identification is a non-MVR port or a source port, the command iver ports, it displays the port type, per port status, and Immedia						
	If you enter the members keyword, all MVR group members on the interface appear. If you enter a VLAN ID, all MVR group members in the VLAN appear.							
	Expressions are case sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> do not appear, but the lines that contain <i>Output</i> appear.							
Examples		e of output from the show mvr interface command:						
Examples		*						
Examples	This is an exampl	interface						

In the preceding display, Status is defined as follows:

- Active means the port is part of a VLAN.
- Up/Down means that the port is forwarding/nonforwarding.
- Inactive means that the port is not yet part of any VLAN.

This is an example of output from the **show mvr interface** command for a specified port:

```
Switch# show mvr interface gigabitethernet0/2
Type: RECEIVER Status: ACTIVE Immediate Leave: DISABLED
```

This is an example of output from the **show mvr interface** interface-id **members** command:

Switch# show mvr interface gigabitethernet0/2 members 239.255.0.0 DYNAMIC ACTIVE 239.255.0.1 DYNAMIC ACTIVE 239.255.0.2 DYNAMIC ACTIVE 239.255.0.3 DYNAMIC ACTIVE 239.255.0.4 DYNAMIC ACTIVE 239.255.0.5 DYNAMIC ACTIVE 239.255.0.6 DYNAMIC ACTIVE 239.255.0.7 DYNAMIC ACTIVE 239.255.0.8 DYNAMIC ACTIVE 239.255.0.9 DYNAMIC ACTIVE

Related Commands

Command	Description		
mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.		
mvr (interface configuration)	Configures MVR ports.		
show mvr	Displays the global MVR configuration on the switch.		
show mvr members	Displays all receiver ports that are members of an MVR multicast group.		

show mvr members

Use the **show mvr members** privileged EXEC command to display all receiver and source ports that are currently members of an IP multicast group.

show mvr members [ip-address] [| {begin | exclude | include} expression]

	ip-address	sourc	ptional) The IP multicast address. If the address is entered, all receiver irce ports that are members of the multicast group appear. If no addre ered, all members of all Multicast VLAN Registration (MVR) groups ed. If a group has no members, the group is listed as Inactive.				
	begin		onal) Display begins with the line that matches the <i>expression</i> .				
	exclude	(Opti	onal) Display excludes lines that match the <i>expression</i> .				
	include	I include (Optional) Display includes lines that match the specified <i>expression</i> .					
	expression	Expre	ession in the output to use as a reference point.				
Command Modes	Privileged EXE	С					
Command History	Release	Modi	ication				
-	12.2(25)EX	This	command was introduced.				
-	source ports are Expressions are	members of all case sensitive. I	and applies to receiver and source ports. For MVR-compatible mode, all multicast groups. For example, if you enter I exclude output , the lines that contain <i>output</i>				
Examples	source ports are Expressions are do not appear, b	members of all case sensitive. I ut the lines that	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear.				
Examples	source ports are Expressions are do not appear, b This is an exam	members of all case sensitive. I ut the lines that ple of output fro	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i>				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP	members of all case sensitive. I ut the lines that ple of output fro vr members Status	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. For the show mvr members command:				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP	members of all case sensitive. I ut the lines that ple of output fro vr members Status	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. om the show mvr members command:				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP	members of all case sensitive. I ut the lines that ple of output fro vr members Status	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. Om the show mvr members command: Members				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP 239.255.0.1	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. For the show mvr members command:				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. om the show mvr members command:				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE INACTIVE	multicast groups. For example, if you enter exclude output , the lines that contain <i>output</i> contain <i>Output</i> appear. m the show mvr members command: <u>Members</u> <u></u> Gi0/1(d), Gi0/2(s) None None				
Examples	source ports are Expressions are do not appear, b This is an examp Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE	multicast groups. For example, if you enter exclude output, the lines that contain output contain Output appear. om the show mvr members command: Members Gi0/1(d), Gi0/2(s) None None None None None None None				
Examples	source ports are Expressions are do not appear, b This is an exam Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE	multicast groups. For example, if you enter exclude output, the lines that contain output contain Output appear. om the show mvr members command: Members Gi0/1(d), Gi0/2(s) None None None None None None None None None None None				
Examples	source ports are Expressions are do not appear, b This is an exam Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE	multicast groups. For example, if you enter exclude output, the lines that contain output contain Output appear. om the show mvr members command: Members Gi0/1(d), Gi0/2(s) None None None None None None None None None None None None None None None None None None				
Examples	source ports are Expressions are do not appear, b This is an exam Switch# show m MVR Group IP 	members of all case sensitive. I ut the lines that ple of output fro vr members Status ACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE INACTIVE	multicast groups. For example, if you enter exclude output, the lines that contain output contain Output appear. om the show mvr members command: Members Gi0/1(d), Gi0/2(s) None None None None None None None None None None				

This is an example of output from the **show mvr members** *ip-address* command. It displays the members of the IP multicast group with that address:

Switch# show mvr members 239.255.0.2 239.255.003.--22 ACTIVE Fa0/1(d), Fa0/2(d), Fa0/3(d), Gi0/1(d), Gi0/2(s)

Related Commands

Command	Description		
mvr (global configuration)	Enables and configures multicast VLAN registration on the switch.		
mvr (interface configuration)	Configures MVR ports.		
show mvr Displays the global MVR configuration on the switch.			
show mvr interface	Displays the configured MVR interfaces, status of the specified interface, or all multicast groups to which the interface belongs when the members keyword is appended to the command.		

show pagp

Use the **show pagp** user EXEC command to display Port Aggregation Protocol (PAgP) channel-group information.

show pagp [channel-group-number] {counters | internal | neighbor } [| {begin | exclude | include } expression]]



PAgP is available only on network node interfaces (NNIs).

expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To display the information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0							
internal Display internal information. neighbor Display neighbor information. 1 begin (Optional) Display begins with the line that matches the expression. I exclude (Optional) Display excludes lines that match the expression. I include (Optional) Display includes lines that match the expression. I include (Optional) Display includes lines that match the specified expression expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Command group: 1 Gio/1 45 42 0 0	Syntax Description	channel-group-number	(Optional) Number of the channel group. The range is 1 to 48.				
neighbor Display neighbor information. 1 begin (Optional) Display begins with the line that matches the <i>expression</i> . 1 exclude (Optional) Display excludes lines that match the <i>expression</i> . 1 include (Optional) Display includes lines that match the specified expression expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 0/0		counters	Display traffic information.				
Ibegin (Optional) Display begins with the line that matches the expression. Iexclude (Optional) Display excludes lines that match the expression. Iinclude (Optional) Display includes lines that match the expression expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. 12.2(25)EX Vou can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Reev Channel group: 1 Gi0/1 45 42 0 0		internal	Display internal information.				
Iexclude (Optional) Display excludes lines that match the expression. Iinclude (Optional) Display includes lines that match the specified expression expression Expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0		neighbor	Display neighbor information.				
Include (Optional) Display includes lines that match the specified expression expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain <i>Output</i> are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Sent Recv Channel group: 1 Gi0/1 Gi0/1 45 42 0		begin					
expression Expression in the output to use as a reference point. Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter exclude output, the lines that contain do not appear, but the lines that contain <i>Output</i> are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0		exclude					
Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Jsage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0		include	(Optional) Display includes lines that match the specified expression.				
Release Modification 12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Information Flush Port Sent Channel group: 1 Gi0/1 Gi0/1 45		expression	Expression in the output to use as a reference point.				
12.2(25)EX This command was introduced. Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter I exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Sent Channel group: 1 Gi0/1 Gi0/1 45 42 Suitch> 0	Command Modes	User EXEC					
Usage Guidelines You can enter any show pagp command to display the active channel-group information. To disp nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter l exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0	Command History						
nonactive information, enter the show pagp command with a channel-group number. Expressions are case sensitive. For example, if you enter l exclude output, the lines that contain do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0	Usago Guidalinos		near command to display the active shannel group information. To display the				
do not appear, but the lines that contain Output are appear. Examples This is an example of output from the show pagp 1 counters command: Switch> show pagp 1 counters Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0	Jsaye Guidennes						
Switch> show pagp 1 counters Information Flush Port Sent Recv Sent Recv 		Expressions are case sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> do not appear, but the lines that contain <i>Output</i> are appear.					
Information Flush Port Sent Recv Channel group: 1 Gi0/1 45 42 0 0	Examples	This is an example of ou	tput from the show pagp 1 counters command:				
Port Sent Recv Sent Recv 							
Channel group: 1 Gi0/1 45 42 0 0		Port Sent Re	ecv Sent Recv				

This is an example of output fr	rom the show pagp 1	internal command:
This is an example of output h	form the show page i	mutunai commana.

Switch>	sho	w pagp	1 inter	nal					
Flags:	s -	Devic	e is sen	ding Slo	w hello.	C - Dev	ice is in	Consistent	state.
	A -	Devic	e is in .	Auto mod	e.				
Timers:	Н –	Hello	timer i	s runnin	g.	Q - Quit	t timer is	running.	
	S -	Switc	hing tim	er is ru	nning.	I - Inte	erface tim	er is runn	ning.
Channel	gro	up 1							
					Hello	Partner	PAgP	Learning	Group
Port		Flags	State	Timers	Interval	Count	Priority	Method	Ifindex
Gi0/1		SC	U6/S7	Н	30s	1	128	Any	16
Gi0/2		SC	U6/S7	Н	30s	1	128	Any	16

This is an example of output from the show pagp 1 neighbor command:

Switch> show pagp 1 neighbor

Flags:	S - Device is sending Slow hello.	C - Device is in Consistent state.
	A - Device is in Auto mode.	P - Device learns on physical port.

Channel group 1 neighbors

	Partner	Partner	Partner		Partner	Group
Port	Name	Device ID	Port	Age	Flags	Cap.
Gi0/1	switch-p2	0002.4b29.4600	Gi0/1	9s	SC	10001
Gi0/2	switch-p2	0002.4b29.4600	Gi0/2	24s	SC	10001

Related Commands	Command	Description
	clear pagp	Clears PAgP channel-group information.

show parser macro

Use the **show parser macro** user EXEC command to display the parameters for all configured macros or for one macro on the switch.

Intax Description		
Syntax Description	brief	(Optional) Display the name of each macro.
	description [interface	(Optional) Display all macro descriptions or the description of a specific
	interface-id]	interface.
	name macro-name	(Optional) Display information about a single macro identified by the macro name.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
ommand Modes	User EXEC	
ommand History	Release	Modification
-	12.2(25)EX	This command was introduced.
sage Guidelines		
sage Guidelines	Expressions are case sen	asitive. For example, if you enter exclude output , the lines that contain <i>output</i> hes that contain <i>Output</i> appear.
sage Guidelines camples	Expressions are case sen do not appear, but the lir	nsitive. For example, if you enter exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear.
	Expressions are case sen do not appear, but the lir	nsitive. For example, if you enter exclude output , the lines that contain <i>output</i> nes that contain <i>Output</i> appear.
	Expressions are case sen do not appear, but the lin This is a partial output e Switch# show parser ma Total number of macros	This is straight to be a set of the set of
	Expressions are case sen do not appear, but the lin This is a partial output e Switch# show parser ma Total number of macron Macro name : sample-ma Macro type : customiza duplex full speed auto mdix auto	The second seco

This is an example of output from the show parser macro name command:

```
Switch# show parser macro name sample-macro1
Macro name : sample-macro1
Macro type : customizable
duplex full
speed auto
mdix auto
```

This is an example of output from the show parser macro brief command:

Switch# show parser	macro brief
customizable	: sample-macro1
customizable	: test1

Related Commands	Command	Description
	macro apply	Applies a macro on an interface or applies and traces a macro on an interface.
	macro description	Adds a description about the macros that are applied to an interface.
	macro global	Applies a macro on a switch or applies and traces a macro on a switch.
	macro global description	Adds a description about the macros that are applied to the switch.
	macro name	Creates a macro.
	show running-config	Displays the current operating configuration, including defined macros. For syntax information, select Cisco IOS Configuration Fundamentals Command Reference, Release 12.2 > File Management Commands > Configuration File Management Commands .

show policer aggregate

Use the **show policer aggregate** user EXEC command to display quality of service (QoS) aggregate policer information for all aggregate policers or a specific policer.

show policer aggregate [aggregate-policer-name] [| {begin | exclude | include} expression]

Syntax Description	aggregate-policer- name	(Optional) The r	name of the aggregate policer.
	begin	(Optional) Displ	ay begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Displ	ay excludes lines that match the <i>expression</i> .
	include	(Optional) Displ	ay includes lines that match the specified expression.
	expression	Expression in th	e output to use as a reference point.
Command Modes	User EXEC		
Command History	Release	Modificatio	n
oonmana mistory	12.2(25)EX	This some	
Usage Guidelines	Expressions are case	e sensitive. For ex	and was introduced. ample, if you enter exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
	Expressions are case are not displayed, b	e sensitive. For ex ut the lines that co	ample, if you enter I exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
	Expressions are case are not displayed, b	e sensitive. For ex ut the lines that co of output from the cer aggregate my	ample, if you enter I exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
	Expressions are case are not displayed, b This is an example of Switch> show poli aggregate-policer police cir 1: conform-act	e sensitive. For ex ut the lines that co of output from the cer aggregate my : my-policer 2000000 bc 5000 tion transmit	ample, if you enter I exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
Usage Guidelines Examples	Expressions are case are not displayed, b This is an example of Switch> show poli aggregate-policer police cir 1: conform-act	e sensitive. For ex ut the lines that co of output from the cer aggregate my : my-policer 2000000 bc 5000 cion transmit ion set-cos-trar	ample, if you enter l exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
Examples	Expressions are case are not displayed, b This is an example of Switch> show poli aggregate-policer police cir 1: conform-act exceed-act:	e sensitive. For ex ut the lines that co of output from the cer aggregate my : my-policer 2000000 bc 5000 cion transmit ion set-cos-trar	ample, if you enter l exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed.
	Expressions are case are not displayed, b This is an example of Switch> show polic aggregate-policer police cir 12 conform-act exceed-act In use by policyma	e sensitive. For ex ut the lines that co of output from the cer aggregate my : my-policer 2000000 bc 5000 tion transmit ion set-cos-tran ap: pin	ample, if you enter exclude output , the lines that contain <i>output</i> ontain <i>Output</i> are displayed. e show policer aggregate command: <i>r</i> -policer

show policer cpu uni

Use the **show policer cpu uni** user EXEC command to display control-plane policer information for the switch, including frames dropped or the configured threshold rate for the control-plane security feature on the switch.

show policer cpu uni [drop [policer-number] | rate] [| {begin | exclude | include} expression]

Syntax Description	drop	(Optional) Display control-plane frame-drop count for the specified policer number or for all control-plane policers (0 to 26).
	policer number	(Optional) Display drop statistics for a specific user network interface (UNI) policer number. The range is from 0 to 26.
	rate	(Optional) Display the configured threshold rate for CPU policers.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines The **show policer cpu uni drop** privileged EXEC command displays the number of accepted and dropped frames for all policers on the switch or for the specified policer number.

The **show policer cpu uni rate** command displays the CPU protection rate-limit threshold on the switch that was configured by entering the **policer cpu uni** *rate* global configuration command or the default rate of 16000 bits per second (bps).

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* are not displayed, but the lines that contain *Output* are displayed.

Examples

This is an example of output from the **show policer cpu uni drop** command. Note that CPU protection only uses policers 0 to 26.

===============	=======================================	
Policer	In	Dropped
Num	Frames	Frames
0	0	0
1	0	0
2	0	0
3	0	0
4	0	0
5	0	0
6	0	0
7	0	0
8	0	0
9	0	0
10	0	0
11	0	0
12	0	0
13	0	0
14	0	0
15	0	0
16	0	0
17	0	0
18	0	0
19	0	0
	=======================================	
Policer	In	Dropped
Num	Frames	Frames
20	0	0
21	0	0
22	0	0
23	0	0
24	0	0
25	0	0
26	0	0

This is an example of output from the show policer cpu uni rate command when the default rate is used.

```
Switch> show policer cpu uni rate
CPU UNI port police rate = 160000 bps
```

Related Commands

Command	Description
policer cpu uni	Configures a CPU policer threshold rate for the switch.
show platform policer cpu	Displays allocated policer indexes and the corresponding features for all ports or the specified port.

show policy-map

Use the **show policy-map** user EXEC command to display quality of service (QoS) policy maps, which define classification criteria for incoming and outgoing traffic and the actions to be performed on the classified traffic.

show policy-map [policy-map-name | interface [interface-id] [input | output] [class class-name]]
[| {begin | exclude | include} expression]

Syntax Description	policy-map-name	(Optional) Display the specified policy-map name.		
oyntax bescription	class class-map-name	(Optional) Display QoS policy actions for an individual class.		
	interface [interface-id] [input output]	(Optional) Display Qos policy actions for an individual class. (Optional) Display information and statistics about policy maps applied to all ports or the specified port. If you specify a port, you can specify additional keywords. The keywords have these meanings:		
		• <i>interface-id</i> —Display information about policy maps on the specified physical interface.		
		• input —Display information about input policy maps on the switch or applied to the specified port.		
		• output —Display the information about output policy-maps on the switch or applied to the specified port.		
	class class-name	(Optional) Display policy-map statistics for an individual class.		
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
	include	(Optional) Display includes lines that match the specified <i>expression</i> .		
	expression	Expression in the output to use as a reference point.		
Command Modes	User EXEC	Modification		
,	12.2(25)EX	This command was introduced.		
Usage Guidelines	Expressions are case sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> do not appear, but the lines that contain <i>Output</i> appear.			
Examples	This is an example of output from the show policy-map command:			
	Switch> show policy-ma Policy Map videowizard class videowizard_1 police 100000000 20000	_policy2 0-10-10		
	Policy Map mypolicy class dscp5			

This is an example of output from the **show policy-map** command for a specific policy map:

```
Switch> show policy-map top2
Policy Map top2
Class class-default
shape average 11111124
service-policy pout
```

This is an example of output from the **show policy-map** command for an output policy map:

```
Switch> show policy-map pout
 Policy Map pout
   Class ip1
     priority
    police cir percent 10
      conform-action transmit
      exceed-action drop
     queue-limit 250
     queue-limit precedence 1 100
   Class ip2
     Average Rate Traffic Shaping
     cir 5%
   Class ip3
     bandwidth percent 10
     queue-limit 200
     queue-limit precedence 3 100
```

This is an example of output from the **show policy-map** command for an input policy map:

```
Switch> show policy-map pin-police
Policy Map pin-police
Class ip1
police cir 20000000 bc 625000
conform-action transmit
exceed-action drop
```

This is an example of output from the **show policy-map interface** command for an interface with a two-level output policy map applied:

```
Switch> show policy-map interface fastethernet0/3
FastEthernet0/3
 Service-policy output: top2
    Class-map: class-default (match-any)
     209871 packets
     Match: any
       56 packets
     Traffic Shaping
       Average Rate Traffic Shaping
       CIR 11111124 (bps)
     Output Queue:
       Tail Packets Drop: 195421
     Service-policy : pout
       Class-map: ip1 (match-all)
          9309 packets
         Match: ip precedence 1
         Prioritv
    police cir 20000000 bc 625000
      conform-action transmit
       exceed-action drop
     conform: 4916 (packets) exceed: 4393 (packets)
```

```
Queue Limit
   queue-limit 250 (packets)
   queue-limit precedence 1 100 (packets)
  Output Queue:
   Max Tail Drop Threshold: 250
   Tail Packets Drop: 4393
Class-map: ip2 (match-all)
  0 packets
 Match: ip precedence 2
 Traffic Shaping
   Average Rate Traffic Shaping
   CIR 5%
                555555 (bps)
  Output Queue:
   Max Tail Drop Threshold: 48
   Tail Packets Drop: 0
Class-map: ip3 (match-all)
  0 packets
 Match: ip precedence 3
 Bandwidth percent 10
                               1111110 (bps)
  Oueue Limit
   queue-limit 200 (packets)
   queue-limit precedence 3 100 (packets)
  Output Queue:
   Max Tail Drop Threshold: 200
   Tail Packets Drop: 0
Class-map: class-default (match-any)
  200562 packets
 Match: any
   56 packets
 Output Queue:
```

This is an example of output from the **show policy-map interface** command for an interface with an input policy applied:

```
Switch> show policy-map interface gigabitethernet0/1
GigabitEthernet0/1
  Service-policy input: pin-police
   Class-map: ip1 (match-all)
      0 packets
      5 minute offered rate 0 bps, drop rate 0 bps
     Match: ip precedence 1
     police cir 20000000 bc 625000
      conform-action transmit
      exceed-action drop
     conform: 27927 (packets) exceed: 272073 (packets)
   Class-map: class-default (match-any)
      0 packets, 0 bytes
      5 minute offered rate 0 bps, drop rate 0 bps
     Match: any
        0 packets
        5 minute rate 0 bps
```

Tail Packets Drop: 191028

Table 2-15 describes the fields in the **show policy-map interface** display. The fields in the table are grouped according to the relevant QoS feature.

Field	Description		
Fields associated with	classes or service policies		
Service-policy input/output	Name of the input or output service policy applied to the specified interface		
Class-map	Class of traffic shown. Output appears for each configured class in the policy. The choice for implementing class matches (match-all or match-might also appear next to the traffic class.		
packets	Number of packets identified as belonging to the traffic class.		
Match	Match criteria specified for the class of traffic. This includes criteria such as class of service (CoS) value, IP precedence value, Differentiated Service Code Point (DSCP) value, access groups, and QoS groups.		
Fields associated with	policing		
police	Shown when the police command has been configured to enable traffic policing. Displays the specified committed information rate (CIR) and conform burst size (BC) used for policing packets.		
conform-action	Displays the action to be taken on packets marked as conforming to a specified rate.		
conform	Displays the number of packets marked as conforming to the specified rate		
exceed-action	Displays the actions to be taken on packets marked as exceeding a specific rate.		
exceed	Displays the number of packets marked as exceeding the specified rate.		
Fields associated with	queuing		
Queue Limit	Queue size configured for the class in number of packets.		
Output Queue	The queue created for this class of traffic.		
Tail packets dropped	The number of packets dropped when the mean queue depth is greater than the maximum threshold value.		
Fields associated with	traffic scheduling		
Traffic shaping	The rate used for shaping traffic.		
Bandwidth	Bandwidth configured for this class in kbps or a percentage.		
Priority	Indicates that this class is configured for priority queuing.		

Table 2-15	show policy-map interface Field Descriptions
------------	--

Related Commands

Command	Description
policy-map	Creates or modifies a policy map that can be attached to multiple ports to
	specify a service policy.

show port-security

Use the **show port-security** privileged EXEC command to display port-security settings for an interface or for the switch.

show port-security [interface interface-id] [address | vlan] [| {begin | exclude | include}
expression]

Cuntary Decemintian	•			
Syntax Description	interface interface-id	(Optional) Display port security settings for the specified interface. Valid interfaces include physical ports (including type, module, and port number).		
	address	(Optional) Display all secure MAC addresses on all ports or a specified port.		
	vlan	(Optional) Display port security settings for all VLANs on the specified interface. This keyword is visible only on interfaces that have the switchport mode set to trunk .		
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .		
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .		
	include	(Optional) Display includes lines that match the specified <i>expression</i> .		
	expression	Expression in the output to use as a reference point.		

Command Modes Privileged EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines If you enter the command without keywords, the output includes the administrative and operational status of all secure ports on the switch.

If you enter an *interface-id*, the command displays port security settings for the interface.

If you enter the **address** keyword, the command displays the secure MAC addresses for all interfaces and the aging information for each secure address.

If you enter an *interface-id* and the **address** keyword, the command displays all the MAC addresses for the interface with aging information for each secure address. You can also use this command to display all the MAC addresses for an interface even if you have not enabled port security on it.

If you enter the **vlan** keyword, the command displays the configured maximum and the current number of secure MAC addresses for all VLANs on the interface. This option is visible only on interfaces that have the switchport mode set to **trunk**.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of the output from the **show port-security** command:

Switch# show port-security

Secure Port	-	CurrentAddr (Count)	SecurityViolat (Count)	ion Security Action
Gi0/1	1	0	0	Shutdown
	in System (excl imit in System (5		

This is an example of output from the **show port-security interface** *interface-id* command:

Switch# show port-security interface gigabitethernet0/1

```
Port Security : Enabled
Port status : SecureUp
Violation mode : Shutdown
Maximum MAC Addresses : 1
Total MAC Addresses : 0
Configured MAC Addresses : 0
Aging time : 0 mins
Aging type : Absolute
SecureStatic address aging : Disabled
Security Violation count : 0
```

This is an example of output from the show port-security address command:

Switch# show port-security address

Secure Mac Address Table

Vlan	Mac Address	Туре	Ports	Remaining Age (mins)
1	0006.0700.0800	SecureConfigured	Gi0/2	1
Total	Addresses in System	(excluding one mag	ner port	• 1

Total Addresses in System (excluding one mac per port) : 1 Max Addresses limit in System (excluding one mac per port) : 6272

This is an example of output from the **show port-security interface gigabitethernet0/2 address** command:

Switch# show port-security interface gigabitethernet0/2 address Secure Mac Address Table

	Jecure Mac Aud			
Vlan	Mac Address	Туре	Ports	Remaining Age (mins)
1	0006.0700.0800	SecureConfigured	Gi0/2	1
Total Addresses: 1				

This is an example of output from the **show port-security interface** *interface-id* **vlan** command:

Switch# show port-security interface gigabitethernet0/2 vlan Default maximum:not set, using 5120 VLAN Maximum Current

LAN	Maximum	Current
5	default	1
10	default	54
11	default	101
12	default	101
13	default	201
14	default	501

Related Commands	Command	Description
	clear port-security	Deletes from the MAC address table a specific type of secure address or all the secure addresses on the switch or an interface.
	switchport port-security	Enables port security on a port, restricts the use of the port to a user-defined group of stations, and configures secure MAC addresses.

show port-type

Use the **show port-type** privileged EXEC command to display interface type information for the Cisco ME switch.

show port-type [uni | nni] [| {begin | exclude | include} expression]

Syntax Description	uni	User network interface.
	nni	Network node interface.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	ports on the switch keyword, the outp Expressions are ca	ommand without keywords, the output includes the interface type information for a h. If you use the uni keyword, the output includes only the UNIs. If you use the nn ut includes only the NNIs. asse sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear.
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example	 h. If you use the uni keyword, the output includes only the UNIs. If you use the nn ut includes only the NNIs. as esensitive. For example, if you enter exclude output, the lines that contain <i>outp</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords:
	ports on the switcl keyword, the outp Expressions are ca do not appear, but	 h. If you use the uni keyword, the output includes only the UNIs. If you use the ni ut includes only the NNIs. as esensitive. For example, if you enter exclude output, the lines that contain <i>outp</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords:
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name	 h. If you use the uni keyword, the output includes only the UNIs. If you use the ni ut includes only the NNIs. asse sensitive. For example, if you enter exclude output, the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: ct-type
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	 h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the uni keyword, the output includes only the UNIs. If you use the nature includes only the NNIs. h. If you use the unit includes only the NNIs. h. If you use the unit includes only the NNIs. h. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. h. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. h. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. h. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIs. If you use the unit includes only the UNIS. If you use the use the use of use on the use of use on the use of use of
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name Fa0/1 Fa0/2	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as esensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as esensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name Fa0/1 Fa0/2 Fa0/3	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as esensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name Fa0/1 Fa0/2 Fa0/3 Fa0/4	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as esensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni) 1 User Network Interface (uni) 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name Fa0/1 Fa0/2 Fa0/3 Fa0/4 Fa0/5	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. asse sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name Fa0/1 Fa0/2 Fa0/3 Fa0/4 Fa0/5 Fa0/6	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. asse sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. ase sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the uni ut includes only the NNIs. as esensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
-	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. ase sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
-	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the un ut includes only the NNIs. as essensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
Usage Guidelines Examples	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the un ut includes only the NNIs. as sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
-	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as sensitive. For example, if you enter I exclude output , the lines that contain <i>outp</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)
-	ports on the switch keyword, the outp Expressions are ca do not appear, but This is an example Switch# show por Port Name 	h. If you use the uni keyword, the output includes only the UNIs. If you use the n i ut includes only the NNIs. as sensitive. For example, if you enter I exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear. e of output from the show port-type command with no keywords: rt-type Vlan Port Type 1 User Network Interface (uni) 1 User Network Interface (uni)

Fa0/17	routed	User Network Interface (uni)
Fa0/18	1	User Network Interface (uni)
Fa0/19	1	User Network Interface (uni)
Fa0/20	1	User Network Interface (uni)
Fa0/21	1	User Network Interface (uni)
Fa0/22	1	User Network Interface (uni)
Fa0/23	10	User Network Interface (uni)
Fa0/24	10	User Network Interface (uni)
Gi0/1	1	Network Node Interface (nni)
Gi0/2	1	Network Node Interface (nni)

This is an example of output from the **show port-type** command using keywords:

Switch#	show port-type nni	exclude G	igabitethernet0/1
Port	Name	Vlan	Port Type
Gi0/2		1	Network Node Interface (nni)

Related Commands Command

port-type

DescriptionChanges the interface type for a specific port.

show sdm prefer

Use the **show sdm prefer** privileged EXEC command to display the Switch Database Management (SDM) templates that can be used to allocate system resources for a particular feature, or use the command without a keyword to display the template in use.

show sdm prefer [default | layer-2] [| {begin | exclude | include} expression]



The **default** keyword is visible only when the metro IP access image is installed on the switch.

Syntax Description	default	(Optional) Display the template that balances system resources among features. This template is only available with the metro IP access image.
	layer-2	(Optional) Display resource allocations for the template that supports Layer 2 features and does not support routing.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	reload the switch t you enter the relo	the SDM template by using the sdm prefer global configuration command, you must for the configuration to take effect. If you enter the show sdm prefer command before ad privileged EXEC command, the show sdm prefer command shows the template
	currently in use an	d the template that will become active after a reload
	The numbers disp	
	The numbers disp	d the template that will become active after a reload. layed for each template represent an approximate maximum number for each feature al number might vary, depending on the actual number of other features configured.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples	This is an example of output from the show sdm prefer command, displaying the template in use:				
	Switch# show sdm prefer The current template is ''layer-2'' template. The selected template optimizes the resources in the switch to support this level of features for 8 routed interfaces and 1024 VLANS.				
	number of unicast mac addresses:	8K			
	number of IPv4 IGMP groups:	1K			
	number of IPv4 multicast routes:	0			
	number of unicast IPv4 routes:	0			
	number of IPv4 policy based routing aces:	0			
	number of IPv4/MAC qos aces:	512			
	number of IPv4/MAC security aces:	1K			
	This is an example of output from the show sdm prefer	default command:			
	Switch# show sdm prefer default				
	"default" template:				
	The selected template optimizes the resources in				
	the switch to support this level of features for				
	8 routed interfaces and 1024 VLANs.				
	number of unicast mac addresses:	1K			
	number of IPv4 IGMP groups + multicast routes:	1K			
	number of IPv4 unicast routes:	5К			
	number of directly-connected IPv4 hosts:	1K			
	number of indirect IPv4 routes:	4K			
	number of IPv4 policy based routing aces:	512			

Related Commands	Command	Description
	sdm prefer	Sets the SDM template to maximize resources for Layer 2 functionality or to the default template.

1K

number of IPv4/MAC qos aces:

number of IPv4/MAC security aces:

show spanning-tree

- Use the **show spanning-tree** user EXEC command to display spanning-tree state information.
 - show spanning-tree [bridge-group | active [detail] | blockedports | bridge | detail [active] |
 inconsistentports | interface interface-id | mst | pathcost method | root | summary [totals] |
 vlan vlan-id] [| {begin | exclude | include} expression]
 - show spanning-tree bridge-group [active [detail] | blockedports | bridge | detail [active] |
 inconsistentports | interface interface-id | root | summary] [| {begin | exclude | include}
 expression]
 - show spanning-tree vlan vlan-id [active [detail] | blockedports | bridge | detail [active] |
 inconsistentports | interface interface-id | root | summary] [| {begin | exclude | include}
 expression]
 - show spanning-tree {vlan vlan-id | bridge-group} bridge [address | detail | forward-time | hello-time | id | max-age | priority [system-id] | protocol] [| {begin | exclude | include} expression]
 - show spanning-tree {vlan vlan-id | bridge-group} root [address | cost | detail | forward-time |
 hello-time | id | max-age | port | priority [system-id] [| {begin | exclude | include}
 expression]
 - show spanning-tree interface interface-id [active [detail] | cost | detail [active] | inconsistency |
 portfast | priority | rootcost | state] [| { begin | exclude | include } expression]
 - show spanning-tree mst [configuration] | [instance-id [detail | interface interface-id [detail]]
 [| {begin | exclude | include} expression]

Syntax Description	bridge-group	(Optional) Specify the bridge group number. The range is 1 to 255.
	active [detail]	(Optional) Display spanning-tree information only on active interfaces (available only in privileged EXEC mode).
	blockedports	(Optional) Display blocked port information (available only in privileged EXEC mode).
	bridge [address detail	(Optional) Display status and configuration of this switch (optional
	forward-time hello-time	keywords available only in privileged EXEC mode).
	id max-age priority [system-id] protocol]	
	detail [active]	(Optional) Display a detailed summary of interface information (active
		keyword available only in privileged EXEC mode).
	inconsistentports	(Optional) Display inconsistent port information (available only in privileged EXEC mode).

interface interface-id [active [detail] cost detail [active] inconsistency portfast priority rootcost state]	(Optional) Display spanning-tree information for the specified interface (all options except portfast and state available only in privileged EXEC mode). Enter each interface separated by a space. Ranges are not supported. Valid interfaces include physical network node interfaces (NNIs), VLANs, and NNI port channels. The VLAN range is 1 to 4094. The port-channel range is 1 to 48.	
	Note Spanning Tree Protocol (STP) is not supported on user node interfaces (UNIs). If you enter a UNI interface ID, no spanning-tree information is displayed.	
mst [configuration [instance-id [detail interface interface-id [detail]]	(Optional) Display the multiple spanning-tree (MST) region configuration and status (available only in privileged EXEC mode). You can specify a single instance ID, a range of IDs separated by a hyphen, or a series of IDs separated by a comma. The range is 1 to 15.	
	Valid interfaces include physical NNIs, VLANs, and NNI port channels. STP is not supported on UNIs.	
	The VLAN range is 1 to 4094. The port-channel range is 1 to 48.	
pathcost method	(Optional) Display the default path cost method (available only in privileged EXEC mode).	
root [address cost detail forward-time hello-time id max-age port priority [system-id]]	(Optional) Display root switch status and configuration (all keywords available only in privileged EXEC mode).	
summary [totals]	(Optional) Display a summary of port states or the total lines of the spanning-tree state section.	
vlan vlan-id [active [detail] backbonefast blockedports bridge [address detail forward-time hello-time id max-age priority [system-id] protocol]	(Optional) Display spanning-tree information for the specified VLAN (some keywords available only in privileged EXEC mode). You can specify a single VLAN identified by VLAN ID number, a range of VLANs separated by a hyphen, or a series of VLANs separated by a comma. The range is 1 to 4094.	
begin	(Optional) Display begins with the line that matches the <i>expression</i> .	
exclude	(Optional) Display excludes lines that match the <i>expression</i> .	
include	(Optional) Display includes lines that match the specified <i>expression</i> .	
expression	Expression in the output to use as a reference point.	

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines STP is not supported on UNIs. Valid spanning-tree information is available only for NNIs.

If the *vlan-id* variable is omitted, the command applies to the spanning-tree instance for all VLANs.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of output from the show spanning-tree active command:

```
Switch# show spanning-tree active
VLAN0001
 Spanning tree enabled protocol ieee
 Root ID
          Priority 32768
           Address
                     0001.42e2.cdd0
           Cost
                     3038
           Port
                     24 (GigabitEthernet0/1)
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
 Bridge ID Priority
                     49153 (priority 49152 sys-id-ext 1)
                     0003.fd63.9580
           Address
           Hello Time 2 sec Max Age 20 sec Forward Delay 15 sec
           Aging Time 300
 Uplinkfast enabled
                               Prio.Nbr Type
             Role Sts Cost
Interface
----- ----
                               _____
      Root FWD 3019 128.24 P2p
Gi0/1
<output truncated>
```

This is an example of output from the show spanning-tree detail command:

Switch# show spanning-tree detail

VLAN0001 is executing the ieee compatible Spanning Tree protocol Bridge Identifier has priority 49152, sysid 1, address 0003.fd63.9580 Configured hello time 2, max age 20, forward delay 15 Current root has priority 32768, address 0001.42e2.cdd0 Root port is 24 (GigabitEthernet0/1), cost of root path is 3038 Topology change flag not set, detected flag not set Number of topology changes 0 last change occurred 1d16h ago Times: hold 1, topology change 35, notification 2 hello 2, max age 20, forward delay 15 Timers: hello 0, topology change 0, notification 0, aging 300 Uplinkfast enabled Port 1 (GigabitEthernet0/1) of VLAN0001 is forwarding

Port path cost 3019, Port priority 128, Port Identifier 128.24. Designated root has priority 32768, address 0001.42e2.cdd0 Designated bridge has priority 32768, address 00d0.bbf5.c680 Designated port id is 128.25, designated path cost 19 Timers: message age 2, forward delay 0, hold 0 Number of transitions to forwarding state: 1 Link type is point-to-point by default BPDU: sent 0, received 72364 <output truncated>

This is an example of output from the **show spanning-tree interface** interface-id command:

Switch# show spa	anning-tree interfac	e gigabitethernet0/1	
Vlan	Role Sts Cost	Prio.Nbr Type	
VLAN0001	Root FWD 3019	128.24 P2p	

This is an example of output from the show spanning-tree summary command:

```
Switch# show spanning-tree summary
Switch is in pvst mode
Root bridge for: none
EtherChannel misconfiguration guard is enabled
Extended system ID is enabled
             is disabled by default
Portfast
PortFast BPDU Guard is disabled by default
Portfast BPDU Filter is disabled by default
Loopguard is disabled by default
Pathcost method used is short
               Blocking Listening Learning Forwarding STP Active
Name
                11
VLAN0001
                                            12
VLAN0002
                                            4
VLAN0004
                                            4
                                            4
VLAN0006
VLAN0031
                                            4
                                             4
VLAN0032
<output truncated>
_____ ____
                      _____
                             109 0 0
37 vlans
                                    47
                                             156
```

Station update rate set to 150 packets/sec.

This is an example of output from the **show spanning-tree mst configuration** command:

```
Switch# show spanning-tree mst configuration
Name [region1]
Revision 1
Instance Vlans Mapped
------
0 1-9,21-4094
1 10-20
```

This is an example of output from the **show spanning-tree mst interface** *interface-id* command:

```
Switch# show spanning-tree mst interface gigabitethernet0/1

GigabitEthernet0/1 of MST00 is root forwarding

Edge port: no (default) port guard : none (default)

Link type: point-to-point (auto) bpdu filter: disable (default)

Boundary : boundary (STP) bpdu guard : disable (default)

Bpdus sent 5, received 74

Instance role state cost prio vlans mapped

0 root FWD 200000 128 1,12,14-4094
```

This is an example of output from the **show spanning-tree mst 0** command:

```
Switch# show spanning-tree mst 0
###### MST00 vlans mapped: 1-9,21-4094
Bridge address 0002.4b29.7a00 priority 32768 (32768 sysid 0)
              address 0001.4297.e000 priority 32768 (32768 sysid 0)
Root
                            port Gi0/1
                                                           path cost 200038
IST master *this switch
Operational hello time 2, forward delay 15, max age 20, max hops 20
Configured hello time 2, forward delay 15, max age 20, max hops 20
Interface
                           role state cost
                                                     prio type
                            ____ ____
_____

        GigabitEthernet0/1
        root FWD
        200000
        128
        P2P bound(STP)

        GigabitEthernet0/2
        desg FWD
        200000
        128
        P2P bound(STP)

        Port-channel1
        desg FWD
        200000
        128
        P2P bound(STP)
```

Related Commands Co

Command	Description
clear spanning-tree counters	Clears the spanning-tree counters.
clear spanning-tree detected-protocols	Restarts the protocol migration process.
spanning-tree bpdufilter	Prevents an interface from sending or receiving bridge protocol data units (BPDUs).
spanning-tree bpduguard	Puts an interface in the error-disabled state when it receives a BPDU.
spanning-tree cost	Sets the path cost for spanning-tree calculations.
spanning-tree extend system-id	Enables the extended system ID feature.
spanning-tree guard	Enables the root guard or the loop guard feature for all the VLANs associated with the selected interface.
spanning-tree link-type	Overrides the default link-type setting for rapid spanning-tree transitions to the forwarding state.
spanning-tree loopguard default	Prevents alternate or root ports from becoming the designated port because of a failure that leads to a unidirectional link.
spanning-tree mst configuration	Enters multiple spanning-tree (MST) configuration mode through which the MST region configuration occurs.
spanning-tree mst cost	Sets the path cost for MST calculations.
spanning-tree mst forward-time	Sets the forward-delay time for all MST instances.
spanning-tree mst hello-time	Sets the interval between hello BPDUs sent by root switch configuration messages.
spanning-tree mst max-age	Sets the interval between messages that the spanning tree receives from the root switch.
spanning-tree mst max-hops	Sets the number of hops in an MST region before the BPDU is discarded and the information held for an interface is aged.
spanning-tree mst port-priority	Configures an interface priority.
spanning-tree mst priority	Configures the switch priority for the specified spanning-tree instance.
spanning-tree mst root	Configures the MST root switch priority and timers based on the network diameter.
spanning-tree port-priority	Configures an interface priority.
spanning-tree portfast (global configuration)	Globally enables the BPDU filtering or the BPDU guard feature on Port Fast-enabled interfaces or enables the Port Fast feature on all nontrunking interfaces.
spanning-tree portfast (interface configuration)	Enables the Port Fast feature on an interface and all its associated VLANs.
spanning-tree vlan	Configures spanning tree on a per-VLAN basis.

show storm-control

Use the **show storm-control** user EXEC command to display broadcast, multicast, or unicast storm control settings on the switch or on the specified interface or to display storm-control history.

show storm-control [interface-id] [broadcast | multicast | unicast] [| {begin | exclude | include}
expression]

Syntax Description	interface-id	(Optional) Interface ID for the physical port (including type, module, and port number).
	broadcast	(Optional) Display broadcast storm threshold setting.
	multicast	(Optional) Display multicast storm threshold setting.
	unicast	(Optional) Display unicast storm threshold setting.
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.

Command Modes User EXEC

Command History	Release	Modification
	12.2(25)EX	This command was introduced.

Usage Guidelines When you enter an *interface-id*, the storm control thresholds appear for the specified interface.

If you do not enter an *interface-id*, settings appear for one traffic type for all ports on the switch.

If you do not enter a traffic type, settings appear for broadcast storm control.

Expressions are case sensitive. For example, if you enter | exclude output, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

This is an example of a partial output from the **show storm-control** command when no keywords are entered. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

Switch> show storm-control

Interface	Filter State	Upper	Lower	Current
Gi0/1	Forwarding	20 pps	10 pps	5 pps
Gi0/2	Forwarding	50.00%	40.00%	0.00%
<output td="" trun<=""><td>cated></td><td></td><td></td><td></td></output>	cated>			

This is an example of output from the **show storm-control** command for a specified interface. Because no traffic-type keyword was entered, the broadcast storm control settings appear.

Switch> show	storm-control	gigabitether	net 0/1	
Interface	Filter State	Upper	Lower	Current
Gi0/1	Forwarding	20 pps	10 pps	5 pps

Table 2-16 describes the fields in the **show storm-control** display.

Table 2-16show storm-control Field Descriptions

Field	Description		
Interface	Displays the ID of the interface.		
Filter State	Displays the status of the filter:		
	• Blocking—Storm control is enabled, and a storm has occurred.		
	• Forwarding—Storm control is enabled, and no storms have occurred.		
	• Inactive—Storm control is disabled.		
Upper	Displays the rising suppression level as a percentage of total available bandwidth in packets per second or in bits per second.		
Lower	Displays the falling suppression level as a percentage of total available bandwidth in packets per second or in bits per second.		
Current	Displays the bandwidth usage of broadcast traffic or the specified traffic type (broadcast, multicast, or unicast) as a percentage of total available bandwidth. This field is only valid when storm control is enabled.		

Related Commands

Command	Description
storm-control	Sets the broadcast, multicast, or unicast storm control levels for the switch.

show system mtu

Use the **show system mtu** privileged EXEC command to display the global maximum transmission unit (MTU) or maximum packet size set for the switch.

show system mtu [| {begin | exclude | include} expression]

Syntax Description		
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
Command Modes	Privileged EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
	wite setting, the h	new setting does not take effect until you reset the switch.
	The quotern MTU	refere to parts operating at 10/100 Mbrs, the system jumbe MTU refers to Cigabit
	ports. Expressions are ca	
Examples	ports. Expressions are ca do not appear, but	se sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> the lines that contain <i>Output</i> appear.

Sets the MTU size for the Fast Ethernet or Gigabit Ethernet ports.

system mtu

show table-map

Use the **show table-map** user EXEC command to display quality of service (QoS) table-map information about all configured table maps or the specified table map.

show table-map [table-map-name] [| {begin | exclude | include} expression]

Syntax Description			
	table-map-name	(Optional) The name of the table map.	
	begin	(Optional) Display begins with the line that matches the expression.	
	exclude	(Optional) Display excludes lines that match the expression.	
	include	(Optional) Display includes lines that match the specified expression.	
	expression	Expression in the output to use as a reference point.	
Command Modes	User EXEC		
Command History	Release	Modification	
	12.2(25)EX	This command was introduced.	
Evomploo		af autout from the shore table more assumed.	
Examples	This is an example	of output from the show table-map command:	
Examples	_	Le-map	
Examples	Switch> show tab tandoori_1>show t Table Map abc	Le-map Cable-map	
Examples	Switch> show tab tandoori_1>show t Table Map abc default copy Table Map cos2ds from 2 to 16	le-map cable-map	
Examples	Switch> show tabl tandoori_1>show tabl Table Map abc default copy Table Map cos2ds from 2 to 16 default copy Table Map cos2co from 2 to 5 from 3 to 6	le-map cable-map	

This is an example of output from the **show table-map** command for a specific table map name:

Switch> show table-map tm

Table Map tm from 1 to 62 from 2 to 63 default ignore

Related Commands Co

Command	Description
table-map	Creates quality of service (QoS) mapping tables, such as CoS to DSCP, and
	so on.

show udld

Use the **show udld** user EXEC command to display UniDirectional Link Detection (UDLD) administrative and operational status for all ports or the specified port.

show udld [interface-id] [| {begin | exclude | include} expression]

Syntax Description	interface-id	(Optional) ID of the interface and port number. Valid interfaces include physical ports and VLANs. The VLAN range is 1 to 4094.
Command Modes	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the expression.
	include	(Optional) Display includes lines that match the specified expression.
	expression	Expression in the output to use as a reference point.
	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Examples	This is an example	the lines that contain <i>Output</i> appear. of output from the show udld <i>interface-id</i> command. For this display, UDLD is ids of the link, and UDLD detects that the link is bidirectional. Table 2-17 describes
	the fields in this dis Switch> show udlo Interface gi0/1	splay. d gigabitethernet0/1
	Port enable opera Current bidirecti Current operation Message interval Time out interval Entry 1 Expiration ti Device ID: 1 Current neigh Device name: Port ID: Gi0/ Neighbor echo	<pre>l: 5 ime: 146 hbor state: Bidirectional Switch-A /1 o 1 device: Switch-B o 1 port: Gi0/2</pre>
	Message inter	rval: 5

Field	Description
Interface	The interface on the local device configured for UDLD.
Port enable administrative configuration setting	How UDLD is configured on the port. If UDLD is enabled or disabled, the port enable configuration setting is the same as the operational enable state. Otherwise, the enable operational setting depends on the global enable setting.
Port enable operational state	Operational state that shows whether UDLD is actually running on this port.
Current bidirectional state	The bidirectional state of the link. An unknown state appears if the link is down or if it is connected to an UDLD-incapable device. A bidirectional state appears if the link is a normal two-way connection to a UDLD-capable device. All other values mean miswiring.
Current operational state	The current phase of the UDLD state machine. For a normal bidirectional link, the state machine is most often in the Advertisement phase.
Message interval	How often advertisement messages are sent from the local device. Measured in seconds.
Time out interval	The time period, in seconds, that UDLD waits for echoes from a neighbor device during the detection window.
Entry 1	Information from the first cache entry, which contains a copy of echo information received from the neighbor.
Expiration time	The amount of time in seconds remaining before this cache entry is aged out.
Device ID	The neighbor device identification.
Current neighbor state	The neighbor's current state. If both the local and neighbor devices are running UDLD normally, the neighbor state and local state should be bidirectional. If the link is down or the neighbor is not UDLD-capable, no cache entries appear.
Device name	The device name or the system serial number of the neighbor. The system serial number appears if the device name is not set or is set to the default (Switch).
Port ID	The neighbor port ID enabled for UDLD.
Neighbor echo 1 device	The device name of the neighbors' neighbor from which the echo originated.
Neighbor echo 1 port	The port number ID of the neighbor from which the echo originated
Message interval	The rate, in seconds, at which the neighbor is sending advertisement messages.
CDP device name	The CDP device name or the system serial number. The system serial number appears if the device name is not set or is set to the default (Switch).

Related Commands	Command	Description
	udld	Enables aggressive or normal mode in UDLD or sets the configurable message timer time.
	udld port	Enables UDLD on an individual interface or prevents a fiber-optic interface from being enabled by the udld global configuration command.
	udld reset	Resets all interfaces shutdown by UDLD and permits traffic to begin passing through them again.

show version

Use the **show version** user EXEC command to display version information for the hardware and firmware.

show version [| {begin | exclude | include} expression]

Syntax Description	begin	(Optional) Display begins with the line that matches the <i>expression</i> .
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.
Command Modes	User EXEC	
Command History	Release	Modification
	12.2(25)EX	This command was introduced.
Usage Guidelines	*	e sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> he lines that contain <i>Output</i> appear.
Examples	Note Though visit	of output from the show version command: ible in the show version output, the <i>configuration register</i> information is not on the switch.
	(20050712:084347) Copyright (c) 198 Compiled Sun 17-J ROM: Bootstrap pr	<pre>ion e, MEAP Software (MEAP-IPSERVICES-M), Experimental Version 12.2 [teresang-meap-bug-fix 109] 6-2005 by Cisco Systems, Inc. ul-05 13:19 by teresang ogram is C3750 boot loader oot Loader (me3400-HBOOT-M), Version 12.2 [mbutts-meap2 103]</pre>
	System returned t System image file	e is 1 day, 2 hours, 49 minutes o ROM by power-on is "flash:image" -FA (PowerPC405) processor with 118784K/12280K bytes of memory.
	Processor board I Last reset from p Target IOS Versio 3 Virtual Etherne 24 FastEthernet i 2 Gigabit Etherne	ower-on n 12.2(25)SE t interfaces nterfaces

The password-recovery mechanism is enabled.

512K bytes of flash-simulated	non-volatile configuration memory.
Base ethernet MAC Address	: 00:0B:FC:FF:32:80
Power supply part number	: 341-0149-01
Motherboard serial number	: FHH0848001R
Power supply serial number	: DTH0450000T
System serial number	: FSJC0407862
Top Assembly Part Number	: 800-26552-01
Top Assembly Revision Number	: 05
Hardware Board Revision Number	: 0x01

Swi	tch	Ports	Model	SW Version	SW Image
*	1	26	ME-3440-24T-FA	12.2(20050712:084347)	MEAP-IPSERVICES-M

Configuration register is 0xF

show vlan

Use the **show vlan** user EXEC command to display the parameters for all configured VLANs or one VLAN (if the VLAN ID or name is specified) on the switch.

show vlan [access-map | brief | dot1q tag native | filter | id vlan-id | internal usage | mtu | name vlan-name | private-vlan [type] | remote-span | summary | uni-vlan [type]] [| {begin | exclude | include} expression]

Syntax Description	access-map	See the show vlan access-map command.
	brief	(Optional) Display one line for each VLAN with the VLAN name, status, and its ports.
	dot1q tag native	(Optional) Display the IEEE 802.1Q native VLAN tagging status This keyword is supported only when the switch is running the metro IP access or metro access image.
	filter	See the show vlan filter command.
	id vlan-id	(Optional) Display information about a single VLAN identified by VLAN ID number. For <i>vlan-id</i> , the range is 1 to 4094.
	internal usage	(Optional) Display a list of VLANs being used internally by the switch. These VLANs are always from the extended range (VLAN IDs 1006 to 4094). You cannot create VLANs with these IDS by using the vlan global configuration command until you remove them from internal use. This keyword is supported only when the switch is running the metro IP access image.
	mtu	(Optional) Display a list of VLANs and the minimum and maximum transmission unit (MTU) sizes configured on ports in the VLAN.
	name vlan-name	(Optional) Display information about a single VLAN identified by VLAN name. The VLAN name is an ASCII string from 1 to 32 characters.
	private-vlan [type]	(Optional) Display information about configured private VLANs, including primary and secondary VLAN IDs, type (community, isolated, or primary) and ports belonging to the private VLAN. Enter type (optional) to see only the VLAN ID and the type of private VLAN.
	remote-span	(Optional) Display information about Remote SPAN (RSPAN) VLANs.
	summary	(Optional) Display VLAN summary information.
	uni-vlan [type]	(Optional) Display user network interface (UNI) VLAN information. Enter type (optional) to see only the VLAN ID and type of UNI VLAN.
	begin	(Optional) Display begins with the line that matches the expression.
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .
	include	(Optional) Display includes lines that match the specified <i>expression</i> .
	expression	Expression in the output to use as a reference point.



Though visible in the command-line help string, the ifindex keyword is not supported.

Command Modes User EXEC Command History Release Modification 12.2(25)EX This command was introduced. Usage Guidelines In the show vlan mtu command output, the MTU Misma

In the **show vlan mtu** command output, the MTU_Mismatch column shows whether all the ports in the VLAN have the same MTU. When *yes* appears in this column, it means that the VLAN has ports with different MTUs. Packets that are switched from a port with a larger MTU to a port with a smaller MTU might be dropped. If the VLAN does not have a switch virtual interface (SVI), the hyphen (-) symbol appears in the SVI_MTU column. If the MTU-Mismatch column displays *yes*, the names of the port with the MinMTU and the port with the MaxMTU appear.

If you try to associate a private VLAN secondary VLAN with a primary VLAN before you define the secondary VLAN, the secondary VLAN is not included in the **show vlan private-vlan** command output.

In the **show vlan private-vlan type** command output, a *normal* type means a VLAN has a private VLAN association but is not part of the private VLAN. For example, if you define and associate two VLANs as primary and secondary VLANs and then delete the secondary VLAN configuration but do not remove the association from the primary VLAN, the VLAN that was the secondary VLAN is shown as *normal* in the display. In the **show vlan private-vlan** output, the primary and secondary VLAN pair is shown as *non-operational*.

In the **show vlan uni-vlan type** command output, type is either *community* or *isolated*. User network interfaces (UNIs) in a UNI community VLAN can communicate with each other; UNIs in a UNI isolated VLAN cannot communicate. Network node interfaces (NNIs) can communicate with each other and with UNIs in UNI isolated and community VLANs.

Expressions are case sensitive. For example, if you enter | **exclude output**, the lines that contain *output* do not appear, but the lines that contain *Output* appear.

Examples

Note

The switch supports only Ethernet VLANs. You can configure parameters for FDDI and Token Ring

This is an example of output from the **show vlan** command. Table 2-18 describes the fields in the display.

VLANs and view the results in the vlan.dat file, but these parameters are not supported or used.

Switch> show vlan Switch#show vlan							
VLAN Name	Status Ports						
1 default	active Fa0/1, Fa0/2, Fa0/3, Fa0/4 Fa0/5, Fa0/6, Fa0/7, Fa0/8 Fa0/9, Fa0/10, Fa0/11, Fa0/12 Fa0/13, Fa0/14, Fa0/15, Fa0/16 Fa0/17, Fa0/18, Fa0/19, Fa0/20 Fa0/21, Fa0/22, Fa0/23, Fa0/24 Gi0/1, Gi0/2						
1002 fddi-default 1003 token-ring-default 1004 fddinet-default 1005 trnet-default	act/unsup act/unsup act/unsup Barent BingNo BridgeNo Stp. BrdgMode Trancl Trans?						
VLAN Type SAID MTU	Parent RingNo BridgeNo Stp BrdgMode Trans1 Trans2						

1 enet 100001	1500 -	_	-	-	-	-	0	0
1002 fddi 101002	1500 -	_	-	-	-	-	0	0
1003 tr 101003	1500 -	-	-	-	-	-	0	0
1004 fdnet 101004	1500 -	-	-	-	ieee	-	0	0
1005 trnet 101005 15	500 -	-	-	ibm -	0	0VLAN	Name	
Remote SPAN VLANs								
Primary Secondary Type	e		Ports					
	- ·							
VLAN Type	Ports							

Table 2-18show vlan Command Output Fields

Field	Description	
VLAN	VLAN number.	
Name	Name, if configured, of the VLAN.	
Status	Status of the VLAN (active or suspend).	
Ports	Ports that belong to the VLAN.	
Туре	Media type of the VLAN.	
SAID	Security association ID value for the VLAN.	
MTU	Maximum transmission unit size for the VLAN.	
Parent	Parent VLAN, if one exists.	
RingNo	Ring number for the VLAN, if applicable.	
BrdgNo	Bridge number for the VLAN, if applicable.	
Stp	Spanning Tree Protocol type used on the VLAN.	
BrdgMode	Bridging mode for this VLAN—possible values are source-route bridging (SRB) and source-route transparent (SRT); the default is SRB.	
Trans1	Translation bridge 1.	
Trans2	Translation bridge 2.	
Remote SPAN VLANs	Identifies any RSPAN VLANs that have been configured.	
Primary/Secondary/ Type/Ports	Includes any configured private VLANs, including the primary VLAN ID, the secondary VLAN ID, the type of secondary VLAN (community or isolated), and the ports that belong to it.	
VLAN Type/Ports	Displays any configured UNI VLANs, the type (community or isolated), and the ports that belong to it.	

This is an example of output from the **show vlan dot1q tag native** command:

Switch> **show vlan dotlq tag native** dotlq native vlan tagging is disabled

This is an example of output from the show vlan private-vlan command:

Switch>	show vlan	private-vlan	
Primary	Secondary	Туре	Ports
10	501	isolated	Gi0/3
10	502	community	Fa0/11
10	503	non-operational3	-
20	25	isolated	Fa0/13, Fa0/20, Fa0/22, Gi0/1,
20	30	community	Fa0/13, Fa0/20, Fa0/21, Gi0/1,
20	35	community	Fa0/13, Fa0/20, Fa0/23, Fa0/33. Gi0/1,
20	55	non-operational	
2000 2	2500	isolated	Fa0/5, Fa0/10, Fa0/15

This is an example of output from the **show vlan private-vlan type** command:

Switch> show vlan private-vlan type Vlan Type 10 primary 501 isolated 502 community 503 normal

This is an example of output from the show vlan uni-vlan type command:

This is an example of output from the show vlan summary command:

Switch> show vlan summary

Number of existing VLANs : 45 Number of existing VTP VLANs : 0 Number of existing extended VLANs : 0

This is an example of output from the show vlan id command.

	ch# sh Name	ow vlan id	2		Stat	tus	Роз	rts			
2	VLAN0	200			act:	ive	Gi)/1, (Gi0/2		
VLAN	Туре	SAID	MTU	Parent	RingNo	Bridge	eNo	Stp	BrdgMode	Trans1	Trans2
2	enet	100002	1500	-	-	-		-	-	0	0
Remo	te SPA	N VLAN									

Disabled

This is an example of output from the **show vlan internal usage** command. It shows that VLANs 1025 and 1026 are being used as internal VLANs for Fast Ethernet routed ports 23 and 24. If you want to use one of these VLAN IDs, you must first shut down the routed port, which releases the internal VLAN, and then create the extended-range VLAN. When you start up the routed port, another internal VLAN number is assigned to it.

Switch> **show vlan internal usage** VLAN Usage ---- ------1025 FastEthernet0/23 1026 FastEthernet0/24

Related Commands	Command	Description
	private-vlan	Configures a VLAN as a community, isolated, or primary VLAN or associates a primary VLAN with secondary VLANs.
	switchport mode	Configures the VLAN membership mode of a port.
	vlan	Enables VLAN configuration mode where you can configure VLANs 1 to 4094.

show vlan access-map

Use the **show vlan access-map** privileged EXEC command to display information about a particular VLAN access map or for all VLAN access maps.

show vlan access-map [mapname] [| {begin | exclude | include} expression]

Syntax Description	mapname	(Optional) Name of a specific VLAN access map.					
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
	exclude	(Optional) Display excludes lines that match the expression.					
	include	(Optional) Display includes lines that match the specified expression.					
	expression	Expression in the output to use as a reference point.					
Command Modes	Privileged EXEC						
Command History	Release	Modification					
	12 2(25)EV						
Usage Guidelines		This command was introduced. sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear.					
	Expressions are case do not appear, but the	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear.					
Usage Guidelines Examples	Expressions are case do not appear, but the This is an example o Switch# show vlan Vlan access-map "S Match clauses:	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear. f output from the show vlan access-map command: access-map					
	Expressions are case do not appear, but the This is an example o Switch# show vlan Vlan access-map "S Match clauses: ip address: S Action:	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear. f output from the show vlan access-map command: access-map ecWiz" 10					
Examples	Expressions are case do not appear, but the This is an example o Switch# show vlan Vlan access-map "S Match clauses: ip address: S Action: forward	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear. f output from the show vlan access-map command: access-map ecWiz" 10 ecWiz_Fa1_0_3_in_ip					
Examples	Expressions are case do not appear, but the This is an example o Switch# show vlan Vlan access-map "S Match clauses: ip address: S Action: forward	sensitive. For example, if you enter l exclude output , the lines that contain <i>output</i> e lines that contain <i>Output</i> appear. f output from the show vlan access-map command: access-map ecWiz" 10 ecWiz_Fa1_0_3_in_ip Description Displays information about all VLAN filters or about a particular VLAN or					

show vlan filter

Use the **show vlan filter** privileged EXEC command to display information about all VLAN filters or about a particular VLAN or VLAN access map.

show vlan filter [access-map name | vlan vlan-id] [| {begin | exclude | include} expression]

Syntax Description	access-map name	(Optional) Display filtering information for the specified VLAN access map.					
	vlan vlan-id	(Optional) Display filtering information for the specified VLAN. The range is 1 to 4094.					
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
	exclude	(Optional) Display excludes lines that match the expression.					
	include (Optional) Display includes lines that match the specified <i>expression</i> .						
	expression	Expression in the output to use as a reference point.					
Command Modes	Privileged EXEC						
Command History	Release	Modification					
	12.2(25)EX	This command was introduced.					
Usage Guidelines	1	sensitive. For example, if you enter exclude output , the lines that contain <i>output</i> lines that contain <i>Output</i> appear.					
Examples	This is an example of	output from the show vlan filter command:					
	Switch# show vlan f VLAN Map map_1 is f 20-22						
Related Commands	Command	Description					
	show vlan access-ma	 Displays information about a particular VLAN access map or for all VLAN access maps. 					
	vlan access-map	Creates a VLAN map entry for VLAN packet filtering.					
	vlan filter Applies a VLAN map to one or more VLANs.						
		Creates a VLAN map entry for VLAN packet filtering.					

show vmps

Use the **show vmps** user EXEC command without keywords to display the VLAN Query Protocol (VQP) version, reconfirmation interval, retry count, VLAN Membership Policy Server (VMPS) IP addresses, and the current and primary servers, or use the **statistics** keyword to display client-side statistics.

show vmps [statistics] [| {begin | exclude | include} expression]

Suntax Description		(Ontional) Diantas VOD aliant side statistics and soundary					
Syntax Description	statistics	(Optional) Display VQP client-side statistics and counters.					
	begin	(Optional) Display begins with the line that matches the <i>expression</i> .					
	exclude	(Optional) Display excludes lines that match the <i>expression</i> .					
	l include (Optional) Display includes lines that match the specified <i>expression</i> .						
	expression	Expression in the output to use as a reference point.					
Command Modes	User EXEC						
Command History	Release	Modification					
	12.2(25)EX	This command was introduced.					
Examples	This is an example of Switch> show vmps	f output from the show vmps command:					
	VQP Client Status:						
	VMPS VQP Version: Reconfirm Interval Server Retry Count VMPS domain server	1 : 60 min : 3					
	Reconfirmation sta	tus					
	VMPS Action:	other					
	This is an example of output from the show vmps statistics command. Switch> show vmps statistics						
	VMPS Client Statis						
	VQP Queries: VQP Responses: VMPS Changes:	0 0 0					
	VQP Shutdowns:	0					
	VQP Denied: VQP Wrong Domain:	0 0					
	VQP Wrong Version	: 0					
	VQP Insufficient	Resource: 0					

Table 2-19 describes each field in the display.

Field	escription		
VQP Queries	Number of queries sent by the client to the VMPS.		
VQP Responses	Number of responses sent to the client from the VMPS.		
VMPS Changes	Number of times that the VMPS changed from one server to another.		
VQP Shutdowns	Number of times the VMPS sent a response to shut down the port. The client disables the port and removes all dynamic addresses on this port from the address table. You must administratively re-enable the port to restore connectivity.		
VQP Denied	Number of times the VMPS denied the client request for security reasons. When the VMPS response denies an address, no frame is forwarded to or from the workstation with that address (broadcast or multicast frames are delivered to the workstation if the port has been assigned to a VLAN). The client keeps the denied address in the address table as a blocked address to prevent more queries from being sent to the VMPS for each new packet received from this workstation. The client ages the address if no new packets are received from this workstation on this port within the aging time period.		
VQP Wrong Domain	Number of times the management domain in the request does not match the one for the VMPS. Any previous VLAN assignments of the port are not changed. This response means that the server and the client have not been configured with the same VQP management domain.		
VQP Wrong Version	Number of times the version field in the query packet contains a value that is higher than the version supported by the VMPS. The VLAN assignment of the port is not changed. The switches send only VMPS Version 1 requests.		
VQP Insufficient Resource	Number of times the VMPS is unable to answer the request because of a resource availability problem. If the retry limit has not yet been reached, the client repeats the request with the same server or with the next alternate server, depending on whether the per-server retry count has been reached.		

Table 2-19 show vmps statistics Field Descriptions

Related Commands	Command	Description
	clear vmps statistics	Clears the statistics maintained by the VQP client.
	vmps reconfirm (privileged EXEC)	Sends VQP queries to reconfirm all dynamic VLAN assignments with the VMPS.
	vmps retry	Configures the per-server retry count for the VQP client.
	vmps server	Configures the primary VMPS and up to three secondary servers.