

Cisco TelePresence Profile Series Codec C-series Quick Set C20 SX20 Quick Set MX200 MX300

TC6.3

User Guide

D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents @ 2010-2013 Cisco Systems, Inc. All rights reserved.

cisco.

Contents

What's in this guide



Sharing Content	
Starting and stopping a presentation	
Changing the layout	42
Scheduled Meetings	
Invoking the list of meetings	44
Joining a scheduled meeting	
Parallel meetings	
Managing Contacts	
Managing Contacts History	/19
Directory	
Favorites	
Managing the Settings	_
Gaining access to the Settings	
Ringtone & Sound	
Camera Control	
Main Source Selection	
Selecting a language	
Setting the date and time	
System Information	
Call Status	
Diagnostic Mode	
Restart System	
Administrator Settings-Call Details	
Administrator Settings-Provisioning Wizard	63
Administrator Settings-Multipoint mode	64
Administrator Settings-IP & VLAN	65
Administrator Settings-SIP	66
Administrator Settings-H323	6
Administrator Settings-EMC Resilience Mode	68
Administrator Settings-Web Snapshots	69
Administrator Settings—Factory reset	70

All entries in the table of contents are clickable hyperlinks that will take you to the corresponding article.

To go between chapters, you may also click on any of the icons in the sidebar.





Before you start to use the video system, you may want to ensure that important parts of the equipment are set as you like them to, for example that the camera shows you, and not the whiteboard and that camera presets (if applicable) are working.

If you are new to video conferencing you may want to read through the article *Best practice* on the next page.



D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010–2013 Cisco Systems, Inc. All rights reserved.



cisco.

Best practice



A successful video conference provides a face-to-face meeting, even if the participants are miles or continents apart. Keep in mind that it still is a meeting—normal etiquette and dress code apply even here.

General

- Consider setting the unit to Automatic Answer, but mute the microphone for privacy reasons, if possible.
- Do not forget to rehearse "the noble art of operating a video system" to the extent needed.

In the meeting room

- Make sure the microphone is placed at the front of the table to ensure that all speech will be detected. The best position is at least 2 m (6.5') in front of the system, on a flat surface with at least 0.3 m (1') of table in front.
- Directive microphones should point away from the video system.
- Make sure that no speaking participant experience obstacles blocking the view to the microphone at all times.

- Microphones should always be placed away from noise sources like computer and projector fans placed on the table.
 The noise from such sources is often perceived as surprisingly loud by the remote participants.
- If you use a document camera try to arrange the participants so that the camera is close to the leader of the meeting, or alternatively, close to a designated controller.
- Remember to arrange all the peripherals so that one participant can reach each of them to point, change the display, record or perform other functions during the conference.
- To help ensure the most natural meeting environment, position the camera on the top center of the receiving monitor, if possible. The camera should point directly at the meeting participants to guarantee eye contact with those at the far end. Check this out by means of the self-view feature of your video system. The self-view shows what the remote party can see from your system (the outgoing video).

- If you are going to share content you will normally make use of duo video. That implies the use of two video streams, one showing the presentation and the other showing the presenter—or the group of presenters. Smaller systems may force you to choose between showing the presentation or the presenter.
- For duo video some attention is needed. Duo video is sometimes shown side-by-side with half the screen showing the presentation and the other half showing the presenter. Provide the impression that you seem to look towards the presentation instead of the impression that you sit with your back towards it, when all is viewed on the remote monitor. If in doubt, look straight into the camera to avoid this situation.

Ease of Use

 To help meeting participants dial, add presentations and use other functionality during a call, consider stationing a poster, table tent or other quickreference guide in the room.

Other tips

Use camera presets

Cisco TelePresence systems let you create predefined zoom and camera pointing directions (pan and tilt). Use these to zoom into the person speaking, if appropriate. Do not forget to zoom out again afterwards.

Loudspeaker volume

The audio system will use the loudspeakers built into the monitor or the Cisco Digital Natural Audio Module.

For some systems you can set the default volume level by adjusting the volume on the monitor with the monitor remote.


Brightness control

To adjust brightness, colors or other settings of the monitor, use the monitor's own remote control. Adjust the monitor to suit the conditions of the conference room. The monitors supplied by Cisco have on-screen menus that are very easy to use. For more information on configuring the monitor as such, see the corresponding user guides and administration manuals.





A tour of the touch screen













About Do not disturb

When set to *Do Not Disturb*, ringtones are muted and call attempts made by others to reach you will appear as missed calls.

You may, however, place calls as much as you like.

As default, there is a 60 minutes timeout on the *Do not disturb* (after which the system will return to normal operation), but this may have been changed to a different setting by your Video Support Team.

Using self-view to adjust the camera





Tap **Self-view**, as outlined.



The position of the self-view is indicated as outlined. This position can be changed, see sidebar for more.



The self-view itself (the outgoing video from your system) will be shown to you as a Picture-in-Picture (PiP), as outlined.





If camera adjustments are needed, tap **Camera** to invoke the *Camera* menu, as outlined.



Adjust zoom in and out here.

Use these controls to define the direction in which the camera shall point (also known as *Pan and Tilt* controls).






To exit this menu, putting changes into effect, tap anywhere outside the active menu.







D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

About self-view

Before the meeting starts we recommend that you check the self-

The self-view appears as a PiP

The position of self-view PiP can be changed if you wish—see <u>"Moving</u> the self-view PiP" on page 28 for

(Picture-in-Picture).

details on this.

view of your video system.

The self-view shows what others see from your video system. You will normally use it to confirm that they see what you want them to see.

Adding a camera preset





Tap **Self-view**, if needed, to see the effects of your camera adjustments.





Tap Camera, as outlined, to invoke the camera adjustment menu.





If you have more than one camera, select which camera from the dropdown list above the camera controls, as outlined.

Adjust the pan and zoom, as required (see also the previous page).














About camera presets

Most Cisco TelePresence systems let you create predefined zoom and camera pointing directions (also known as pan and tilt). Use these to zoom into the person speaking, if appropriate. Do not forget to zoom out again afterwards.

This means that if you want to create one or more zoom-in presets you should also create a zoom-out (overview) preset to conveniently switch back to overview mode.

More than one camera?

Some of our video systems support the use of more than one camera.

In this way you may, for example, have one camera providing an overview of the participants and another showing the whiteboard.

Note that when you define a camera preset, the current pan and zoom of every camera connected will be saved as part of that preset.

Consequently, you should make sure that every camera has been set to the required position before you save the camera positions as a new preset.

Editing an existing camera preset

About preset editing





Tap **Self-view**, as outlined, to see the effects of your camera adjustments.



Tap **Camera**, as outlined, to invoke the camera adjustment menu.



If you have more than one camera, select which camera to adjust from the drop-down list, as outlined.



saving it under the same name. If you want to change the name, we recommend that you delete the

Preset editing is all about taking an existing preset, altering it and then

preset and create a new one with the preferred name.



Adjust the pan, tilt and zoom, as required (see also two pages back).




Then tap ▼ next to the preset to be edited, as outlined.



In the submenu tap Update to new position to put your changes into effect, or tap **Remove** to delete the selected preset.








Ringtones





Activate (On) or deactivate (Off) the keytones here. In this example Keytones are set to On.







You may personalize the ring tone and its volume, if you wish. You may also set keytones to *On* (a sound will appear when tapping a "button") or to *Off*.





Logging onto a system with your own credentials

About hot-desking









Video systems located in meeting rooms and quiet rooms running under CUCM (Cisco Unified Communications Manager) may allow you to log in to the video system with your own personal credentials.

CUCM will then route all incoming calls destined for you to that specific video system.



The system will confirm a succesful sign-in. You will now receive calls destined for you.






intentions.







Video meetings between two parties only are often referred to as Point-to-Point video calls, as opposed to video conferences which may involve several parties physically located miles apart.

This part of the user guide deals with point-to-point calls. Video conferencing is outlined in the next chapter of this guide.



Video meetings Point-to-point

D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

cisco.

Placing a call using name, number or address

About placing calls

You may call someone who is not listed in your list of contacts by keying in their name, address or number using the virtual keyboard of the Touch pad.

Anyone you have previously called will appear in the *History* list (until you clear that list) and you may then transfer any of them to your list of *Favorites*. This is described in the section *Managing Contacts*.

How to call someone listed in the *Favorites, Directory* or *History* list is described on the next page.

Calling extensions. Sometimes you may be urged to enter touch tones (DTMF) during a call, typically to reach extensions or to provide a pin code.

Tap **Touch Tones** (this button appears as soon as the call is placed) to invoke the keypad.







alphanumerical mode and the extended numerical mode tap the key in the lower left corner of the keyboard, as outlined.



Calling contacts

To search for someone, tap here to invoke the virtual keyboard and then key in the name or number. Matches will appear as you type. All three lists will be examined for possible matches.



If you are going to look in a specific list only, tap the corresponding tab first.

Any matches will appear here. Tap to select an entry. The selected entry will appear on a blue background.







When an entry has been located and selected the *Call* menu will appear.

Tap **Call** to place the call. There are some options available. These are always context sensitive, which means that meaningless options are not shown. For example **Add to Favorites** is not available for entries already residing in the list of *Favorites*.

You will find more on the options on the following pages.



Your lists of Contacts consist of three parts:

Favorites. These contacts have put there by you. These entries will typically be someone you call frequently or otherwise need to access in a swift and convenient manner from time to time.

Directory will typically be a corporate directory installed on your system by your System Administrator.

History is a list of calls you have placed, received or missed earlier.

You may clear the *History* list for privacy reasons, see <u>"History" on page 48</u>.

The following options apply:

- You may key in a name and number and the system will look in all lists for you.
- You may tap a tab and then scroll through the list or key in a name or number. Your search will then be restricted to that specific list.
- You may add the entry to the list of Favorites; edit aspects of the entry before calling; change the call rate and remove the entry from History, see the following page for more on this.



Adding an entry to Favorites, before placing the call

About the list of Favorites

Favorites are contacts put there by you. These entries will typically be someone you call frequently or otherwise need to access in a swift and convenient manner from time to time.





If the entry may be stored as it is, just tap **Save**.

If you want to edit the entry (typically adding a name), tap the field whose content you want to alter, as outlined.









The list of Favorites will now be displayed confirming successful operation.



Editing an entry, before placing a call







Once changes have been made, tap the green **CALL** button, as outlined, to place the call.





Changing the call rate, before placing a call









Tap **CALL** to place the call, as outlined.

Call rate is the term used to express the amount of bandwidth allocated to the call in kbps (kilobits per second). The higher the call rate is the better the quality will be.

Why would you like to change this? In most cases you will use it to avoid choking the video call when you try to call someone at a higher rate than their system and connection supports.





Removing entries in the History list, before placing a call

Removing a single entry:







Clearing the entire History list:













Tap Clear History, as outlined.

About entries removal

For privacy reasons you may want to remove an entry from the *History* list or clear the entire list.

The same persons may have called you (or you called them) several times. Each such call will create an entry in the *History* list.

Note that if you choose to remove a single entry in the list, any other instances of that entry will not be removed from the list.



Receiving a call



If you set up the system to respond to incoming calls automatically (*Auto Answer*) you may want to mute the system microphone(s), to preserve privacy.

Microphone(s) are muted if this symbol is illuminated in red. To mute/unmute the microphone(s), tap the symbol.



- If someone calls you may accept, decline or ignore the call.
- If you decline the call, busy information will be sent to the calling party.
- If you ignore the call, the calling party will perceive this as if you were absent.
- You may want to set your system to respond automatically to an incoming call (*Auto Answer*). This is described in <u>"Administrator Settings—Call Details" on page</u> <u>62</u>. Observe that your Video Support Team may have password protected this area.
- If you choose to activate Auto
 Answer you may want to mute the microphone to preserve privacy.
 This must be set up manually every time.





CISCO

Being in a call, receiving another call

The one you already are in a call with.

The identity of the new incoming call.

Decline the incoming call and carry on as you have been doing.

If your system is equipped with the MultiSite option you may merge the incoming call with the existing. For details on this see "Being in a call, receiving another call"

For systems without MultiSite installed, the incoming call may still be merged, but as an audio-only call (not shown).

on page 33

Accept the incoming call, while holding the current call or group of calls.

Accept the incoming call, while ending the current call or group of calls.

Ignore the incoming call (you will appear as absent to the one who is calling you).





If you already are in a call, you may accept another incoming call under certain circumstances.

Read more about this in the chapter "Video Conferencing" on page 29.



Transferring a call to someone else













About transfer

Basically, you have two options when transferring calls; viz. unattended and consultative transfer.

The scenario described on this page is the unattended transfer, where you transfer the call to someone else without consulting that person before the transfer is carried out.

If you consult the person first, you will transfer after having used the the swap feature—see the next page for more on this.







The call will now be transferred.



In call with two parties, but one at a time



Assume that

you are in a

as outlined.

call. Tap **Hold**,





Tap + Place New Call, as outlined, or tap Resume to go back to the one you were in call with (to undo your action).







This feature allows you to be in a call with two parties, but one at a time only.

You may swap whom you are in call with, and you may connect the two together, while you leave the call.





Tap **Swap** to change whom to talk to, or tap **Transfer** to connect the two together while you leave the call.



Shared lines

If there is activity on the shared line, this will be indicated as outlined.



If someone on the shared line has put herself on hold, you may pick that call up by tapping **RESUME**, as outlined.



If the current call has not been put on hold, you may barge in by tapping **Barge**.





About this feature

Video systems used in call centers may be set up to share a common line so that anyone of those sharing a line may respond to an incoming call.



Touch tones (DTMF) in a call







In a call you may be prompted to submit numbers to be able to reach an extension or otherwise enter into something (for example with a PINcode).

To be able to submit this you will need a keypad on the Touch screen.

The technical term used with this is DTMF (Dual Tone Multi-Frequency), which describes what actually takes place.



Obtaining more information about the participants





About this feature

Do as outlined to invoke a list of the participants and their status. In a point-to-point call the list will be populated with the two participants only.



Adding the other party to Favorites, while in a call



And Chance

In a call, tap as outlined.

2













Your entry will now appear in the list of *Favorites*.

There are several ways to add someone to the list of Favorites and one of them allows you to do this while in a call.

You may, after a call, realize that you should have added the one you were in call with to the list of Favorites. To do this use *History* and *Add To Favorites* from there.

More on this can be found in the chapter <u>"Managing Contacts" on page 47</u>.



Controlling your own camera in a call

Using your camera presets:









Select the preset to use, as outlined.



Tap anywhere outside the menu to exit.

......

CISCO

Adjusting your camera's pan tilt and zoom:









If your system has more than one camera, select the camera to be adjusted, as outlined.





Adjust pan, tilt and zoom, as outlined.

Tap anywhere outside the menu to exit.

About camera control

Existing camera presets can be used right away during a call.


Your video system may have more than one camera, for example one camera showing the participants, while another shows the whiteboard.

Note that a camera preset will apply to all cameras in use. Consequently, there is no need to select a particular camera before a preset is activated. Read more about this "Adding a camera preset" on page 7.

If you need to add new or modify existing camera presets, this is done in the same way as you do outside a call—turn to <u>"Editing an existing camera preset" on page 8</u> for details.

As an alternative to adding or editing presets, a simple adjustment of your camera's pan til and zoom should also be considered.





Controlling the camera of the other participant



Within video conferencing the term far end is often used to refer to the

Likewise, the term *near end* is often used to refer to your side of the

The ability to control the far end

end system camera is remotely controlable. The feature cannot be applied to systems with a manual

You will not have access to any presets that may exist on the far end

camera requires that the far

one you are talking to.

video meeting.

camera adjustment.

video system.













zoom and tilt.






Tap Back to exit the











menu, as outlined.



Moving the self-view PiP

Why move the self-view?





Tap the **Self-view icon**, as outlined to invoke the self-view, if needed.

2



B



As soon as it turns blue dragthe self-view to the new location. Possible locations are indicated, as outlined.







Once you reach the location you want to have it in, lift your finger from the touch screen.





The self-view will now assume the new location.

The self-view shows what others see from your video system. You will normally use it to confirm that they see what you want them to see.

The self-view appears as a PiP (Picture-in-Picture).

From time to time you may want to have the self-view activated during the meeting. This could, for example, be to ensure that a lecturer in your room remains seen on the screen despite constantly moving around.

It may happen that the current position of the self-view blocks important parts of the image on your screen. You may therefore want to move it.





By adding participants to an ongoing video call, your video meeting will be expanded into a video conference.




D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

cisco.

Creating a video conference

Video conferencing using an external MCU (with or without Multiway)


Any limitations to the number of simultaneous participants will depend entirely on the configuration implemented.





Video conferencing using MultiSite (an equivalent to an embedded MCU)

The maximum number of simultaneous participants is four (yourself included) plus one audio-only call.



Participant 3

Participants 2 and 3 experience this call as a point-to-point call with an MCU. They will therefore not need to have any conferencing abilities built in.



This is an optional feature that may, or may not, be installed on your system.

Video conferencing basics

Cisco video systems capable of video conferencing offer three ways of implementing the ability to be in a call with more than one, viz by means of:

■ Multipoint Control Unit (MCU).

- This is a bridge that interconnects calls from several sources. All parties call the MCU unit, or the MCU unit calls them. This means that all participants will be in a point-to-point call with the MCU. If an MCU is used in your office, consult your System Administrator for operating details.
- MultiSite, an optional built-in MCU in your video system that allows you to call more than one. The video systems that you call will need no conferencing capabilities. The maximum number of participants will be four (yourself included) plus one audio-only call.
- Multiway, an optional feature that transfers your call to an external MCU as soon as you start calling more than one. However, you do control it all directly from your system. You will not have to call an MCU and then do everything from there.

Calling more than one using MultiSite

About MultiSite





Assume that you already are in a call. This call may have been initiated by you or by someone else (someone have called you).









the usual way.







Place the call, in the usual way. You may alter the *Call settings* of that call before you place it—see the side bar on this page.






This new call will now be added to the existing, thus creating a conference. You may cancel this call, as outlined, without terminating the first call you were in.





To add more participants repeat the procedure. A maximum of four video participants (yourself included) and one audio-only may take part in the conference.

If you are the one who initiated the conference initiated the conference you will be able to terminate the entire conference as well. The other participants, however, may only disconnect themselves from the conference.



The MultiSite feature allows you to call three other systems on video plus a fourth system on audio only (for example a mobile phone).

This means that the conference can consist of up to four video participants (yourself included) and one audio participant.

If you want to initiate a video conference, you must call each participant one by one.

Call settings. Those you call may have video systems with different capabilities. One or more of them may, for example, be on an ADSL system with limited bandwidth (compared to those of the other participants). You may then set the Call settings to a (normally lower) call rate suiting his or her system before you call that person. However, that call rate will affect that specific part of the video conference only. Other participants will not experience a lower call rate because of this.



Calling more than one using Multiway or CUCM

About Multiway/CUCM

The maximum number of participants in a Multiway conference depends entirely on the video infrastructure implemented in your organization. If in doubt, consult your System

If you want to initiate a video

participant one by one.

conference, you must call each

Call settings. Those you call may

have video systems with different

capabilities. One of them may, for example, be on an ADSL system with limited bandwidth (compared to the others). You may then set the *Call settings* to a (normally lower) call rate (bandwidth) suiting his

or her system before you call that person. However, that call rate will affect that specific part of the video conference only. Other participants will not suffer from a lower call rate

because of this.

Administrator.

Monthuson

Assume that you already are in a call. This call may have been initiated by you or by someone else (someone have called you). Tap **Hold**.



Tap +Place New Call...



Locate whom to call, in the usual way.





this page.






To add more participants repeat the procedure. The maximum number of participants depends on your video system infrastructure. If in doubt consult your System Administrator.

If you initiated the conference you will be able to terminate the entire conference as well. The other participants, however, may only disconnect themselves from the conference.





Being in a call, receiving another call







¹⁾ If your system is equipped with MultiSite you may merge the incoming with the current call. For systems without MultiSite installed, the incoming call may still be merged, but as an audio-only call.

About the options

Assume that you are already in a call. If you then receive another incoming call, you will have the following options:

- You may decline the call and continue with what you were doing.
- You may put the current call on hold and accept the new call. At any time you may swap between the two. Read more about this in the article "In call with two parties, but one at a time" on page 21.
- You may transfer the incoming call to someone else, including the one you were talking to. This is covered in <u>"Transferring a call to someone else" on page 20.</u>
- You may, after putting the incoming call on hold, later decide to merge this call with the existing (optional feature).
- You may merge the incoming call directly with the ongoing call (ACCEPT & MERGE). This applies to MultiSite equipped systems only.

Layout control in a call

Changing the layout:





To change the existing layout on your video screen, tap **Layout**, as outlined.





3



The new layout will now be put in effect.



Adding a self-view PiP to your layout:



Tap as outlined to include a self-view PiP

Moving the self-view PiP:



Tap **Merge** to create a conference, as outlined.





About the layout options

You may alter the screen layout when you are in a call. The Touch pad will show the options available. The actual options may differ from what is shown here, but the Touch pad will always show you what is available.

The WYSIWYG (what you see is what you get) principle applies even here.



Invoking a list of participants and their status







2

The list will show who is presenting (how to conduct presentations is outlined in the following chapter of this document), who is speaking and if someone has been put on hold, that will be indicated

Swipe towards left or tap the other dot to return to the initial state.



Tapping a participant in this list may grant you more options, see the following pages for details.

Using the list

This is a convenient way to obtain information about all the participants and their current status.

In addition, you may use the list to disconnect participants from the conference or to grant them certain rights, such as to retain the position as prominent speaker even if someone else starts speaking. These features are outlined on the following pages.



Disconnecting someone from the conference





You may also invoke the list of participants (see the previous page) and tap a participant in that list.





Tap **Drop** to disconnect the selected participant, as outlined.





D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

About the feature

Any participant entitled to it may disconnect any of the other participants. Tap the participant, either in the view as shown, or in the list of participants (see the previous page). Then tap **Drop**, as outlined.

Video conferencing

Lock as speaker—remaining the prominent speaker





This is an example of a layout with one of the participants shown as the prominent speaker, i.e. shown larger than the other(s).





Tap **Lock as speaker**, as outlined.

Once activated the name of this field will change to **Unlock as speaker**.

To unlock, repeat the process tapping **Unlock as Speaker**





About Lock as Speaker

Assume you have set your system so that one of the participants is shown larger than the others.

If someone else starts to speak instead of this person, the system will switch to display the image of that person instead. To avoid this, you may lock the current person as speaker. This person will then be shown permanently as the prominent speaker.

Video conferencing

Adding one of the participants to Favorites









Then tap **Add to Favorites**, as outlined.

This will invoke the Add to Favorites dialog box, whose use is shown in "Adding the other party to Favorites, while in a call" on page 25.





About Adding to Favorites

There are several ways to add someone to the list of Favorites and one of them allows you to do this while in a call.

Once you have selected whom to add to your list of favorites, the procedure is identical to the one outlined in the article "Adding the other party to Favorites, while in a call" on page 25 It will therefore not be repeated here.



Video conferencing

Controlling the camera of one of the other participants









Then tap Camera, as outlined.

This will invoke the Camera control dialog box, whose use is explained in "Controlling the camera of the other participant" on page 27.





About camera control

Within video conferencing the term *far end* is often used to refer to the one you are talking to.

Far end is an ambiguous term in video conferencing, since there is more than just one far end.

Consequently, you must start by defining whose camera you are going to control.

Once you have defined this, the procedure is identical to the one explained in "Controlling the camera of the other participant" on page 27.

The ability to control a far end camera requires that the far end system camera is remotely adjustable. The feature cannot be applied to systems with a manual camera adjustment.

You will not have access to any presets that may exist on the far end video system.



Contents can be shared in a call—or outside a call. In the latter case you will be using your video system to share contents in your local meeting room.



D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

cisco.

Sharing content

Starting and stopping a presentation







may be invoked even here, as

For more on the contact card feature, see "Invoking a list of participants and their status"





Most of the Cisco TelePresence video systems support the ability to show presentations in a video call or video conference as well as outside a call. The latter ability allows the system to be used for local presentations in a meeting room, thus extending the use of the video system and the room itself.

Note that you may change the layout of the screen during presentations, see the next page for more on this.



Sharing content

Changing the layout





Tap Layout, as outlined, to invoke the layout options.





Select your preferred layout by tapping it.





About presentation layout

You may change the layout of the screen during presentations. Typical options available will be with or without showing the presenter and showing the presenter as either a PiP (Picture in Picture) or PoP (Picture outside Picture).

The layout options available on your system may differ from those shown here, but the layouts shown are always those you may choose between.



Your video system may be connected to a management system capable of scheduling video meetings for you. Any meetings scheduled will then appear in a *List of Meetings* on your Touch device.





Scheduled meetings

Invoking the list of meetings







The meeting list will typically look like this.

Tap on a meeting in the list to obtain more information about ther meeting.



Tap on the little expansion symbol, as outlined, to get even more information.





Tap again to collapse the information box.

D14582.16 User Guide Cisco TelePresence Profile Series, Codec C Series, Quick Set C20, SX20 Quick Set, MX200, MX300 Produced: October 2013 for TC6.3 All contents © 2010-2013 Cisco Systems, Inc. All rights reserved.

Meeting list basics

in a List of Meetings.

Your video system may be connect-

ed to a management system capable

of scheduling video meetings. Any

meetings scheduled will then appear

The List of Meetings contains a list of

upcoming, meetings scheduled to take place during the next 14 days (this setting may have been changed by your Video Support Team). The list is sorted using grouping headers.

The main grouping category is by

day (e.g.: TODAY, TOMORROW, then

WEDNESDAY, October 20, 2013 etc).

If you tap an item in the list then more information will become avail-

When a scheduled meeting appears as *Private meeting* it will contain information about the organizer only. There will be no title, no expandable

meeting outline as well as no dial-in

information.



Scheduled meetings

Joining a scheduled meeting



If you tap a meeting in the list you will see more about the meeting.

The start and end time of the scheduled meeting.




March 17

Extending an ongoing meeting

Scheduled meetings have a fixed start and end time. You may want to extend an ongoing meeting. This will be accepted by the system if no other meeting is scheduled for any of the video systems involved, during the period of possible extension.

If an extension is sustainable, the *Meeting will end* notification will include an *Extend* and a *Dismiss* option.

To extend a meeting, tap the **Extend** button.




Although the default setting lets you join in up to 10 minutes in advance, your System Administrator may have implemented a different setting.




A scheduled meeting may connect you automatically, or you may have to tap

JOIN MEETING.



When the meeting starts you will be offered to join in, to postpone the offer to join in for 5 minutes, or to just dismiss the offer.



If you are in a call when the meeting starts you will also be offered to join in while at the same time put the current call on hold, just like any other situation where someone calls you while you already are in a call.

About joining

On your video system the *Meeting Reminder* will appear once it is possible to join a meeting. Exactly when that will be depends on the *Start time buffer* setting. Default buffer setting is 10 minutes, but your system administrator may have changed this. It is not possible to join the meeting earlier than the setting dictates.

The meeting reminder contains a time indicator stating when the meeting starts, or alternatively for how long the meeting has been going on (an ongoing meeting is referred to as a *Meeting in progress*).

The text *Starting now* will be shown during a time interval spanning from 30 seconds before to 30 seconds after the scheduled start time of the meeting.



Parallel meetings







Choose your meeting

Whenever Parallel meetings occur (two or more meetings taking place simultaneously), the reminder will be displayed in context of the meeting list, displaying all upcoming meetings. Choose which meeting to join and then join the selected meeting.



Contacts consists of three parts; a *Directory*, which typically is your corporate phone book; *History* which is a list of recent calls and finally *Favorites*, which is your personalized list of people you call frequently or otherwise need to get easy access to.






History

Gaining access to the History list:





Removing a single entry:






For privacy reasons you may want to remove an entry from the History list or clear the entire list.

The same persons may have called you (or you called them) several times. Each such call will create an entry in the History list.

Note that if you choose to remove a single entry in the list, any other instances of that entry will not be removed from the list.

Clearing the entire History list:









Tap **Clear History**, as outlined.

About History

The *History* lists the received, placed and missed calls since the last time the list was cleared.

Tap an entry and you may:

- Call the entry by tapping CALL.
- Add the entry to an ongoing call (optional).
- Add the entry to Favorites.
- Edit the entry information and then place the call.
- Change the call rate settings.
- Remove the entry from the list.
- Clear the entire list.



Directory

Finding an entry in the Directory by scrolling through the list:





Tap **Directory**, if needed.



Finding an entry in the Directory by searching for it:





Tap **Directory**, if needed.



Tap **Search or Dial**, as outlined, to invoke the virtual keyboard and key in a name, number or address. Possible matches will appear as you type.

About Directory

The *Directory* serves as your corporate phone book. This directory cannot be edited by you. You may, however, copy entries to your list of *Favorites* and edit them there.

Tap a folder to show its contents, scroll, if needed, to locate a folder or an entry within a folder.

Once located, tap the entry to call, edit or add to your list of favorites in the same way as with the *History* list (see the previous page for more on this).

When searching within the corporate Directory, the search will apply to the current directory folder and its subfolders only. To go one level up, tap Back. To make the search apply to the entire corporate directory, do not enter (tap) any folder before the search is commenced.

It may happen that an entry copied from the directory to the list of favorites later is updated in the directory. This update will not be reflected in your list of favorites—you must then manually update the entry in the list of favorites.





Favorites

Adding someone from Directory or History to the list of Favorites:



In the Contacts panel, tap **Directory** or **History**, if needed.



entry, as outlined.



4



If any of the fields need to be edited, tap that field, as outlined.



finished.



Tap **Save**, as outlined, to create the new entry in the list of Favorites.

Manually adding someone to the list of Favorites:





Tap **Search or Dial**, as outlined, to invoke the virtual keyboard.





Tap the little arrow, as outlined, and continue from (3) above.

About Favorites


The Favorites is your own shortlist of contacts you frequently call or otherwise want to have easy access to.

Favorites may be populated from the History or Directory lists as well as from manual entries.



.1 1.1 1. CISCO







cisco.



Managing the Settings

Gaining access to the Settings



Tap the **Settings** icon, as outlined.







About Settings

The video endpoints whose use is described in this guide can be configured via the Touch screen controller or via its web interface. For full access to all configurable parameters the web interface must be used—the Touch screen controller provides access to a limited set of parameters only.


Care must be taken when altering the *Settings* to avoid that the system stops working. If in doubt, contact your Video Support Team.

For security reasons, access to some of the Settings may have been password protected by your Video Support Team.

To enter the *Settings*, tap the **Settings** icon (**¥**), as outlined to the left.

Ringtone & Sound





About Ringtone & Sound

The Ringtone & Sound Settings window lets you specify:

- **Keytones** *On* or *Off.* When set to on you will hear a sound every time you tap a field on the Touch controller.
- Ringtone volume. How loud your ringtone shall sound.
- **Ringtone**. Select among several ringtones. You will hear a sample every time you tap a ringtone.

Note how the settings chosen are indicated. In the example shown, **Keytones** is set to *On*.


To exit this menu putting any changes into effect, tap **Exit**. Note that there is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!





Camera Control





About Camera Control

The Camera Control window lets you set the whitebalance and exposure of the camera. If you do not want to tweak this yourself, just leave it up to the system by tapping **Auto**.

Backlight compensation comes in handy when there is much light behind you. Without compensation you will easily appear very dark to the far end.


Note how the settings chosen are indicated. In the example shown, *Backlight compensation* is set to *Off.*





Main Source Selection










About Source Selection

Select what shall be the main source. You may still choose another when working with the system, but what you specify here will be the default setting.

The options available are system dependent, your system may show more options or less options.

Selecting a language








The *Language* page lets you specify the Touch interface menu language.





Setting the date and time









About time setting


This window lets you specify your preferred date and time formats, as well as the time zone.

If you set the *Date and Time Mode* to *Auto* (as has been done in this example), the system will look for an NTP server and get date and time from there.

If you choose to set *NTP mode* to *Manual* (as has been done in this example), you must specify the NTP server address to make things work.

System Information










About System Information

The System Information window contains information on the system's software and hardware versions and connections, SIP and H.323 status etc.

This information is typically what you will be asked by the technical staff to provide in the unlikely event of system malfunction.

Call Status










About Call Status

The *Call Status* window provides information on call rate, encryption, as well as important video and audio parameters.

This information is typically what you may be asked by the technical staff to provide in the unlikely event of system malfunction.

Diagnostic Mode









About Diagnostics


For troubleshooting purposes you may enable additional system logging. Follow the on-screen instructions.

Note that system performance may be influnced by an ongoing system logging.

This information is typically what you may be asked by the technical staff to provide in the unlikely event of system malfunction.

Restart System









About Restart

Use this to restart your system in an orderly and controlled manner. No settings are lost.

Administrator Settings—Call Details



To exit

Administrator


Settings, tap


Back.

To exit Settings as such, tap **Exit**.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.



If you enable *Auto Answer* the system will respond by itself to incoming calls after a delay specified by you. Note that an activated auto answer may not provide you with the privacy desired. In the example shown here *Auto Answer* is set to

On certain occasions you may have to change the bandwidth (and hence the quality) of the call. Some configurations may have different incoming and outgoing bandwidths (typically ADSL connections), and you may specify the default call rate to ensure a stable video quality.

The default protocol may also be specified. In the example shown, the protocol has been set to *SIP*.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!






Administrator Settings-Provisioning Wizard




To exit Administrator Settings, tap Back.
To exit Settings as such, tap

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





About the Wizard

There is a *Provisioning Wizard* available to get your system online. Tap **Start** and follow the on-screen instructions

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!

Administrator Settings-Multipoint mode



To exit

Administrator

Settings, tap

Back.


To exit Settings


as such, tap

Exit.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





About Mulipoint

There are basically two modes of video conferencing; viz. MultiWay and MultiSite.

- To enable MultiWay, a MultiWay address must have been entered.
- If a MultiWay address has been specified and MultiWay is selected, MultiWay will always be used for video conferencing.
- If a MultiWay address has been specified, but MultiSite is selected, MultiSite will be used.
- If set to Auto, MultiWay will be used if a MultiWay address has been specified, otherwise MultiSite will be used.
- If set to Off, no video conferencing will be possible.
- Any use of the MultiSite feature requires the presence of the MultiSite option.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!

Administrator Settings-IP & VLAN





To exit
Administrator
Settings, tap
Back.

To exit Settings as such, tap **Exit**.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





About IP Settings

You may specify whether to use IPv4 or IPv6 and whether to use static IP address or DHCP.

When set to *Static*, applicable addresses must be set accordingly.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!

Administrator Settings-SIP





To exit
Administrator
Settings, tap
Back.

To exit Settings as such, tap **Exit**.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





About SIP Settings

Use this page to set up SIP.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!

Administrator Settings-H323



About H323 Settings

Use this page to set up H323.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!



To exit

Administrator

Settings, tap

Back.


To exit Settings
as such, tap

Exit.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!

Back Administrator Setting	s		Exit
Call Details	H323 Number	5037218	
Provisioning	H323 Id	5037218@itvm.tandberg.com	(+
Multipoint Mode	Gatekeeper Discovery	Auto Manual	
IP & VLAN	Gatekeeper Address	10.47.8.209	
SIP	Authentication Mode	OFF ON	
H323	Login Name		
EMC Resilience	Password		
Web Snapshots	Passwora		
Reset			
			(!



To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





Administrator Settings-EMC Resilience Mode







Settings, tap Back. To exit Settings as such, tap Exit.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the Administrator Settings, you must tap Administrator. located below Restart, as outlined. This will take you to the Administrator Settings right away.

Note that access to these settings may have been password protected by your Video Support Team.



...... CISCO

About FMC Resilience

If the Touch controller is used in environments with considerable amounts of electromagnetic noise present, you may experience an appearance of false signals—as if someone tapped the Touch controller when obviously nobody did so.

To cope with this you may set the EMC Resilience Mode to On. You must then press and hold for a little while, rather than just tap, in order to make the system aware of your tapping. This will prevent the appearance of spurious signals.

Caution! There is no Cancel function letting you exit the menu undoing any changes you have made. Take care!

Administrator Settings—Web Snapshots





To exit Administrator Settings, tap **Back**.

To exit Settings as such, tap **Exit**.

Note that there is no Cancel function letting you exit the menu undoing any changes you have made.

Take care!





To enter the *Administrator Settings*, you must tap **Administrator**, located below **Restart**, as outlined. This will take you to the *Administrator Settings* right away.

Note that access to these settings may have been password protected by your Video Support Team.





About snapshots

You may gain access to your video system through its web interface, see the Administration Guide for more.

From the web interface you may generate snapshots of the video stream from your system. You may also generate snapshots from the outgoing video of the far end system.

However, you cannot take snapshots unless you have set the *Allow Web Snapshots* to *ON*, as shown here.

Snapshots cannot be taken if the call is encrypted. Encryption will disable the snapshot feature at both ends, regardless of the local settings of the *Allow Web Snapshots* parameter.

The web snapshot feature applies to Point-to-Point as well as MultiSite calls (but to unencrypted calls only).

In this context a MultiWay call should be regarded as a variant of Pointto-Point call as it is the MCU who is controlling the call and your system is connected to the MCU as in a Pointto-Point call.

Caution! There is no *Cancel* function letting you exit the menu undoing any changes you have made. Take care!


Administrator Settings—Factory reset




To exit Administrator Settings, tap Back. To exit Settings as such, tap

Note that there is no Cancel function letting you exit the menu undoing any changes you

Take care!





To enter the Administrator Settings, you must tap **Administrator**. located below Restart, as outlined. This will take you to the Administrator Settings right away.

Note that access to these settings may have been password protected by your Video Support Team.





About Factory reset

You may want to perfom a Factory Reset your video system. Note that you will loose all configurations, the call history and your local list of contacts (Favorites and History). Release keys and options installed will be retained.

Caution! There is no Cancel function letting you exit the menu undoing any changes you have made. Take care!



Americas Headquarters Cisco Systems, Inc. San Jose, CA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore Europe Headquarters Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)