

# 2

## Cisco Internet Streamer CDS Release 2.5 Software Commands

This chapter contains an alphabetical listing of all the commands in Cisco Internet Streamer CDS Release 2.5 software. The Internet Streamer CDS software CLI is organized into the following command modes:

- EXEC mode—For setting, viewing, and testing system operations. It is divided into two access levels, user and privileged. To use the privileged access level, enter the **enable** command at the user access level prompt and then enter the privileged EXEC password when you see the password prompt.
- Global configuration (config) mode—For setting, viewing, and testing the configuration of Internet Streamer CDS software features for the entire device. To use this mode, enter the **configure** command from privileged EXEC mode.
- Interface configuration (config-if) mode—For setting, viewing, and testing the configuration of a specific interface. To use this mode, enter the **interface** command from Global configuration mode.
- Other configuration modes—Several configuration modes are available from the Global configuration mode for managing specific features. The commands used to access these modes are marked with a footnote in [Table 2-1](#).

See [Chapter 1, “Using Command Modes,”](#) for a complete discussion of using CLI command modes.

[Table 2-1](#) summarizes the Internet Streamer CDS commands and indicates the command mode for each command. The same command may have different effects when entered in a different command mode, and for this reason, they are listed and documented separately. In [Table 2-1](#), when the first occurrence is entered in EXEC mode, the second occurrence is entered in Global configuration mode. When the first occurrence is entered in Global configuration mode, the second occurrence is entered in interface configuration mode.

The Internet Streamer CDS software device mode determines whether the Internet Streamer CDS device is functioning as a Service Engine (SE), CDS Manager (CDSM), or Service Router (SR). The commands available from a specific CLI mode are determined by the Internet Streamer CDS device mode in effect. [Table 2-1](#) also indicates the device mode for each command. *All* indicates that the command is available for every device mode.



### Note

When viewing this guide online, click the name of the command in the left column of the table to jump to the command page, which provides the command syntax, examples, and usage guidelines.



### Note

See [Appendix A, “Acronyms”](#) for an expansion of all acronyms used in this publication.

**Table 2-1 CLI Commands**

Command	Description	CLI Mode	Device Mode
<a href="#">access-lists</a>	Configures the access control list entries.	Global configuration	SE
<a href="#">acquirer (EXEC)</a>	Configures the content acquirer.	Privileged-level EXEC	SE
<a href="#">acquirer (Global configuration)</a>	Enables authentication when the acquirer obtains content through a proxy server.	Global configuration	SE
<a href="#">acquisition-distribution</a>	Starts and stops the acquisition and distribution database cleanup process and the content acquisition and distribution process.	Privileged-level EXEC	SE
<a href="#">alarm</a>	Configures alarms.	Global configuration	All
<a href="#">area nssa</a>	Configures an area as an NSSA <sup>1</sup> .	OSPF configuration	SR
<a href="#">area stub</a>	Defines an area as a stub area.	OSPF configuration	SR
<a href="#">asset</a>	Configures the CISCO-ENTITY-ASSET-MIB.	Global configuration	All
<a href="#">authentication</a>	Configures the authentication parameters.	Global configuration	All
<a href="#">authentication-check</a>	Enables the checking of received packets on the corresponding level.	IS-IS Configuration	SR
<a href="#">authentication key-chain</a>	Specifies the key chain to be used for the authentication for the corresponding level.	IS-IS Configuration	SR
<a href="#">authentication-type</a>	Specifies the cleartext or MD5 authentication for the corresponding level.	IS-IS Configuration	SR
<a href="#">authsvr</a>	Enables and configures the Authorization server.	Global configuration	SE
<a href="#">bandwidth (Global configuration)</a>	Sets the allowable bandwidth usage and its duration for the Movie Streamer and WMT <sup>2</sup> streaming media.	Global configuration	SE
<a href="#">bandwidth (interface configuration)</a>	Sets the specified interface bandwidth to 10, 100, or 1000 Mbps.	Interface configuration	All
<a href="#">banner</a>	Configures the EXEC, login, and MOTD <sup>3</sup> banners.	Global configuration	All
<a href="#">bitrate</a>	Configures the maximum pacing bit rate for the Movie Streamer and configures WMT bit-rate settings.	Global configuration	SE
<a href="#">bootstrap-node</a>	Configures a bootstrap node IP address.	SRP configuration	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">cache</a>	Specifies the cache commands.	Global configuration	SE
<a href="#">capability</a>	Modifies the capability configuration.	Global configuration	SE
<a href="#">cd</a>	Changes the directory.	User-level EXEC and privileged-level EXEC	All
<a href="#">cdn-select</a>	Enables the CDN Selector for third-party service selection.	Global Configuration	SR
<a href="#">cdnfs</a>	Manages the Internet Streamer CDNFS <sup>4</sup> .	Privileged-level EXEC	SE
<a href="#">cdsm</a>	Configures the CDSM IP address and primary or standby role settings.	Global configuration	All
<a href="#">clear cache</a>	Clears the HTTP object cache.	Privileged-level EXEC	SE, SR
<a href="#">clear content</a>	Clears the URL content.	Privileged-level EXEC	SE, SR
<a href="#">clear ip</a>	Clears the IP configuration.	Privileged-level EXEC	All
<a href="#">clear isis</a>	Clears the IS-IS Routing for IP.	Privileged-level EXEC	SR
<a href="#">clear logging</a>	Clears the syslog messages saved in the disk file.	Privileged-level EXEC	All
<a href="#">clear service-router</a>	Clears the Service Router.	Privileged-level EXEC	SR
<a href="#">clear srp database offline</a>	Clears the SRP database while it is offline.	Privileged-level EXEC	SR
<a href="#">clear srp descriptor</a>	Deletes a single descriptor or all descriptors from the service routing layer.	Privileged-level EXEC	SR
<a href="#">clear srp neighbor</a>	Removes a neighbor Proximity Engine from the neighbor list of the local Proximity Engine.	Privileged-level EXEC	SR
<a href="#">clear srp resource</a>	Deletes a resource from a descriptor in the service routing layer.	Privileged-level EXEC	SR
<a href="#">clear srp route</a>	Deletes a single route entry from the DHT routing table of the local Proximity Engine.	Privileged-level EXEC	SR
<a href="#">clear statistics</a>	Clears the statistics.	Privileged-level EXEC	All
<a href="#">clear transaction-logs</a>	Clears and archives the working transaction logs.	Privileged-level EXEC	SE, SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>clear users</code>	Clears the connections (login) of authenticated users.	Privileged-level EXEC	All
<code>clear wmt</code>	Clears the WMT streams.	Privileged-level EXEC	SR
<code>clock (EXEC)</code>	Manages the system clock.	Privileged-level EXEC	All
<code>clock (Global configuration)</code>	Sets the summer daylight saving time of day and time zone.	Global configuration	All
<code>cms (EXEC)</code>	Configures the CMS <sup>5</sup> -embedded database parameters.	Privileged-level EXEC	All
<code>cms (Global configuration)</code>	Schedules the maintenance and enables the Centralized Management System on a given node.	Global configuration	All
<code>configure<sup>6</sup></code>	Enters configuration mode from privileged EXEC mode.	Privileged-level EXEC	All
<code>copy</code>	Copies the configuration or image files to and from the CD-ROM, flash memory, disk, or remote hosts.	Privileged-level EXEC	All
<code>cpfile</code>	Copies a file.	User-level EXEC and privileged-level EXEC	All
<code>debug</code>	Configures the debugging options.	Privileged-level EXEC	All
<code>debug ip bgp</code>	Displays information related to the BGP process.	Privileged-level EXEC	SR
<code>debug ip ospf</code>	Displays information related to the OSPF process.	Privileged-level EXEC	SR
<code>debug ip rib</code>	Turns on proximity debugging information.	Privileged-level EXEC	SR
<code>debug isis</code>	Displays information related to the IS-IS process.	Privileged-level EXEC	CDSM, SR
<code>debug srp</code>	Turns on SRP debugging information.	Privileged-level EXEC	CDSM, SR
<code>delfile</code>	Deletes a file.	User-level EXEC and privileged-level EXEC	All
<code>deltree</code>	Deletes a directory and its subdirectories.	User-level EXEC and privileged-level EXEC	All
<code>device</code>	Configures the mode of operation on a device.	Global configuration	All

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">dir</a>	Displays the list of files in a directory.	User-level EXEC and privileged-level EXEC	All
<a href="#">direct-server-return</a>	Enables a VIP for direct server return.	Global configuration	SE, SR
<a href="#">disable</a>	Turns off the privileged EXEC commands.	Privileged-level EXEC	All
<a href="#">disk (EXEC)</a>	Allocates the disks among the CDNFS and sysfs file systems.	Privileged-level EXEC	All
<a href="#">disk (Global configuration)</a>	Configures how the disk errors should be handled.	Global configuration	All
<a href="#">distribution</a>	Reschedules and refreshes the content redistribution through multicast for all delivery services or a specified delivery service ID or name.	Privileged-level EXEC	SE, SR
<a href="#">dnslookup</a>	Resolves a host or domain name to an IP address.	User-level EXEC and privileged-level EXEC	All
<a href="#">domain</a>	Sets the domain ID for the SRP.	SRP configuration	CDSM, SR
<a href="#">enable<sup>6</sup></a>	Accesses the privileged EXEC commands.	User-level EXEC and privileged-level EXEC	All
<a href="#">end</a>	Exits configuration and privileged EXEC modes.	Global configuration	All
<a href="#">exec-timeout</a>	Configures the length of time that an inactive Telnet or SSH <sup>7</sup> session remains open.	Global configuration	All
<a href="#">exit</a>	Exits from interface, Global configuration, or privileged EXEC modes.	All	All
<a href="#">expert-mode password</a>	Sets the expert-mode password.	Global configuration	All
<a href="#">external-ip</a>	Configures up to a maximum of eight external IP addresses.	Global configuration	All
<a href="#">find-pattern</a>	Searches for a particular pattern in a file.	Privileged-level EXEC	All
<a href="#">flash-media-streaming</a>	Enables and configures Flash Media Streaming.	Global configuration	SE, SR
<a href="#">flooding</a>	Sets the flooding threshold for SRP multicast.	SRP configuration	SR
<a href="#">geo-location-server</a>	Redirects requests to different CDNs based on the geographic location of the client.	Global configuration	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">gulp</a>	Captures lossless gigabit packets and writes them to disk.	Privileged-level EXEC	SE
<a href="#">help</a>	Obtains online help for the command-line interface.	Global configuration and user-level EXEC	All
<a href="#">hostname</a>	Configures the device network name.	Global configuration	All
<a href="#">http</a>	Configures HTTP-related parameters.	Global configuration	SE, SR
<a href="#">icap</a>	Enables the Internet Content Adaptation Protocol for supporting third-party software applications and plug-ins.	Global configuration	SE
<a href="#">install</a>	Installs a new version of the caching application.	Privileged-level EXEC	All
<a href="#">interface</a> <sup>6</sup>	Configures a Gigabit Ethernet or port channel interface. Provides access to interface configuration mode.	Global configuration	All
<a href="#">ip</a> (Global configuration)	Configures the Internet Protocol.	Global configuration	All
<a href="#">ip</a> (interface configuration)	Configures the interface Internet Protocol.	Interface configuration	All
<a href="#">ip access-list</a> <sup>6</sup>	Creates and modifies the access lists for controlling access to interfaces or applications. Provides access to ACL configuration mode.	Global configuration	All
<a href="#">ip ospf priority</a>	Sets the router priority, which helps determine the designated router for this network.	Interface configuration mode under OSPF configuration	SR
<a href="#">ip router isis</a>	Specifies the interfaces to be used for routing IS-IS.	Interface configuration mode under IS-IS configuration mode	SR
<a href="#">ipv6</a>	Specifies the default gateway's IPv6 address.	Global configuration	SE
<a href="#">isis</a>	Configures IS-IS routing for IP.	Interface configuration mode under IS-IS configuration	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">is-type</a>	Configures a Proximity Engine to act as a Level 1 (intra-area) router, as both a Level 1 router and a Level 2 (interarea) router, or as an inter-area router only.	IS-IS configuration	SR
<a href="#">kernel kdb</a>	Enables the kernel debugger configuration mode.	Global configuration	All
<a href="#">key</a>	Creates a key ID and enters into key ID configuration submode.	Key chain submode	SR
<a href="#">key-string</a>	Creates a key string to be used for authentication.	Key ID configuration submode	SR
<a href="#">key chain</a>	Creates a key chain and enters into key chain configuration submode.	Global configuration	SR
<a href="#">line</a>	Specifies the terminal line settings.	Global configuration	All
<a href="#">lls</a>	Displays the files in a long-list format.	User-level EXEC and privileged-level EXEC	All
<a href="#">location community</a>	Configures the community values that are associated with a Proximity Engine.	BGP configuration	SR
<a href="#">log-adjacency-changes</a>	Configures the router to send a syslog message when an IS-IS neighbor goes up or down.	BGP, IS-IS and OSPF configuration	SR
<a href="#">logging</a>	Configures syslog <sup>8</sup> .	Global configuration	All
<a href="#">log-neighbor-changes</a>	Enables logging of BGP neighbor resets.	BGP configuration	SR
<a href="#">ls</a>	Lists the files and subdirectories in a directory.	User-level EXEC and privileged-level EXEC	All
<a href="#">lsp-mtu</a>	Sets the maximum transmission unit MTU <sup>9</sup> size of IS-IS LSPs.	IS-IS configuration	SR
<a href="#">mkdir</a>	Makes a directory.	User-level EXEC and privileged-level EXEC	All
<a href="#">mkfile</a>	Makes a file (for testing).	User-level EXEC and privileged-level EXEC	All
<a href="#">movie-streamer</a>	Enables and configures the Movie Streamer server.	Global configuration	SE

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">mtu</a>	Sets the interface maximum transmission unit packet size.	Interface configuration	All
<a href="#">neighbor</a>	Configures the BGP neighbors.	BGP configuration	SR
<a href="#">net</a>	Configures an IS-IS NET <sup>10</sup> for a CLNS <sup>11</sup> routing process.	IS-IS configuration	SR
<a href="#">netmon</a>	Displays the transmit and receive activity on an interface.	Privileged-level EXEC	SE
<a href="#">netstat</a>	Displays the rate of change of netstat statistics.	Privileged-level EXEC	SE
<a href="#">network area</a>	Defines the interfaces on which OSPF runs and defines the area ID for those interfaces.	OSPF configuration	SR
<a href="#">no (Global configuration)</a>	Negates a Global configuration command or sets its defaults.	Global configuration	All
<a href="#">no (interface configuration)</a>	Negates an interface command or sets its defaults.	Interface configuration	All
<a href="#">ntp</a>	Configures the Network Time Protocol server.	Global configuration	All
<a href="#">ntpdate</a>	Sets the NTP software clock.	Privileged-level EXEC	All
<a href="#">ping</a>	Sends the echo packets.	User-level EXEC and privileged-level EXEC	All
<a href="#">ping srp</a>	Pings the the SRP ring.	User-level EXEC and privileged-level EXEC	SR
<a href="#">ping6</a>	Pings the IPv6 address.	User-level EXEC and privileged-level EXEC	SE
<a href="#">port-channel</a>	Configures the port channel load balancing options.	Global configuration	All
<a href="#">primary-interface</a>	Configures a primary interface for the Internet Streamer CDS network to be a Gigabit Ethernet or port channel interface.	Global configuration	All
<a href="#">proximity algorithm bgp</a>	Enables a BGP proximity algorithm option for the Proximity Engine.	Global configuration	SR
<a href="#">proximity engine enable</a>	Enables the Proximity Engine.	Global Configuration	SR
<a href="#">pwd</a>	Displays the present working directory.	User-level EXEC and privileged-level EXEC	All



**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">qos</a>	Globally enables QoS functionality on the device.	Global configuration	SE
<a href="#">radius-server</a>	Configures the RADIUS authentication.	Global configuration	All
<a href="#">rcp</a>	Enables RCP.	Global configuration	All
<a href="#">rea</a>	Starts the remote execution agent.	User-level EXEC and privileged-level EXEC	SE
<a href="#">reload</a>	Halts a device and performs a cold restart.	Privileged-level EXEC	All
<a href="#">rename</a>	Renames a file.	User-level EXEC and privileged-level EXEC	All
<a href="#">restore</a>	Restores a device to its manufactured default status.	Privileged-level EXEC	All
<a href="#">rmdir</a>	Removes a directory.	User-level EXEC and privileged-level EXEC	All
<a href="#">router bgp</a>	Configures a BGP routing process.	Global configuration	SR
<a href="#">router isis</a>	Enables the IS-IS routing protocol and specifies an IS-IS process.	Global configuration	SR
<a href="#">router ospf</a>	Enables the OSPF <sup>12</sup> routing process.	Global configuration	SR
<a href="#">router srp</a>	Enters SRP configuration mode.	Global configuration	SR
<a href="#">rtsp</a>	Configures the Real-Time Streaming Protocol-related parameters.	Global configuration	SE
<a href="#">rule</a>	Sets the rules by which the SE filters HTTP, HTTPS, and RTSP traffic.	Global configuration	SE
<a href="#">script</a>	Checks the errors in a script or executes a script.	Privileged-level EXEC	All
<a href="#">service</a>	Specifies the type of service.	Privileged-level EXEC	All
<a href="#">service-router</a>	Configures service routing.	Global configuration	All
<a href="#">setup</a>	Configures the basic configuration settings and a set of commonly used caching services.	Privileged-level EXEC	All
<a href="#">show access-lists 300</a>	Displays the access control list configuration.	User-level EXEC and privileged-level EXEC	SE

**Table 2-1 CLI Commands (continued)**

Command	Description	CLI Mode	Device Mode
<a href="#">show acquirer</a>	Displays the acquirer delivery service information and progress for a specified delivery service number or name.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show alarms</a>	Displays information on various types of alarms, their status, and history.	User-level EXEC and privileged-level EXEC	All
<a href="#">show arp</a>	Displays the Address Resolution Protocol entries.	User-level EXEC and privileged-level EXEC	All
<a href="#">show authentication</a>	Displays the authentication configuration.	User-level EXEC and privileged-level EXEC	All
<a href="#">show authsvr</a>	Displays the Authorization Server status.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show bandwidth</a>	Displays the bandwidth allocated to a particular device.	User-level EXEC and privileged-level EXEC	SE, SR
<a href="#">show banner</a>	Displays information on various types of banners.	User-level EXEC and privileged-level EXEC	All
<a href="#">show bitrate</a>	Displays the SE bit-rate configuration.	User-level EXEC and privileged-level EXEC	SE, SR
<a href="#">show cache</a>	Displays a list of cached contents.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show cache-router</a>	Displays cache-route information for various Protocol Engines.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show capability</a>	Displays information for the Cap-X profile ID.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show cdn-select</a>	Displays the status of the CDN Selector.	User-level EXEC and privileged-level EXEC	SR
<a href="#">show cdnfs</a>	Displays the Internet Streamer CDS network file system information.	User-level EXEC and privileged-level EXEC	CDSM, SE
<a href="#">show clock</a>	Displays the system clock.	User-level EXEC and privileged-level EXEC	All

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>show cms</code>	Displays the Centralized Management System protocol, embedded database content, maintenance status, and other information.	User-level EXEC and privileged-level EXEC	All
<code>show content</code>	Displays all content entries in the CDS.	User-level EXEC and privileged-level EXEC	SE
<code>show debugging</code>	Displays the state of each debugging option.	User-level EXEC and privileged-level EXEC	All
<code>show debugging srp</code>	Displays the debug flags that are turned on for the SRP.	Privileged-level EXEC	SR
<code>show device-mode</code>	Displays the configured or current mode of a CDSM, SE, or SR device.	User-level EXEC and privileged-level EXEC	All
<code>show direct-server-return</code>	Displays the Direct Server return information.	User-level EXEC and privileged-level EXEC	SE, SR
<code>show disks</code>	Displays the disk configurations.	User-level EXEC and privileged-level EXEC	All
<code>show distribution</code>	Displays the distribution information for a specified delivery service.	User-level EXEC and privileged-level EXEC	SE
<code>show flash</code>	Displays the flash memory information.	User-level EXEC and privileged-level EXEC	All
<code>show flash-media-streaming</code>	Displays the Flash Media Streaming information.	User-level EXEC and privileged-level EXEC	SE, SR
<code>show ftp</code>	Displays the caching configuration of the FTP <sup>13</sup> .	User-level EXEC and privileged-level EXEC	All
<code>show hardware</code>	Displays the system hardware information.	Privileged-level EXEC	All
<code>show hosts</code>	Displays the IP domain name, name servers, IP addresses, and host table.	User-level EXEC and privileged-level EXEC	All
<code>show http</code>	Displays the HTTP-related caching configuration.	User-level EXEC and privileged-level EXEC	SE
<code>show icap</code>	Displays the ICAP configurations.	User-level EXEC and privileged-level EXEC	SE

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>show interface</code>	Displays the hardware interface information.	User-level EXEC and privileged-level EXEC	All
<code>show inventory</code>	Displays the system inventory information.	User-level EXEC and privileged-level EXEC	All
<code>show ip access-list</code>	Displays the information about access lists that are defined and applied to specific interfaces or applications.	Privileged-level EXEC	All
<code>show ip bgp</code>	Displays the contents of a particular host in the BGP routing table.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp all</code>	Displays the contents of the BGP routing table.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp community</code>	Displays BGP routes that match a specified BGP community string.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp ipv4 unicast</code>	Displays information relating to all IPV4 unicast routes in the BGP routing table.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp memory</code>	Displays memory usage information of the running BGP daemon.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp neighbors</code>	Displays information about the TCP and BGP connections to neighbors.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp nexthop-database</code>	Displays the next-hop database information in the BGP routing table.	User-level EXEC and privileged-level EXEC	SR
<code>show ip bgp summary</code>	Displays the status of all BGP connections.	User-level EXEC and privileged-level EXEC	SR
<code>show ip interface</code>	Displays the IP interface state and its address and mask for all interfaces.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf</code>	Displays general information about OSPF routing processes.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf border-routers</code>	Displays general information about OSPF border routers.	User-level EXEC and privileged-level EXEC	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>show ip ospf database</code>	Displays information specific to the OSPF database for a specific router.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf interface</code>	Displays OSPF-related interface information.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf memory</code>	Displays memory usage of the OSPF process.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf neighbor</code>	Displays OSPF neighbor information.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf request-list</code>	Displays a list of all LSAs <sup>14</sup> requested by a router.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf retransmission-list</code>	Displays a list of all LSAs waiting to be re-sent.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf route</code>	Displays the OSPF RSPF route for OSPF routes.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf rspf route</code>	Displays OSPF RSPF <sup>15</sup> from specific routers.	User-level EXEC and privileged-level EXEC	SR
<code>show ip ospf traffic</code>	Displays OSPF traffic statistics.	User-level EXEC and privileged-level EXEC	SR
<code>show ip proximity algorithm</code>	Displays the proximity algorithm options currently in use by this Proximity Engine.	User-level EXEC and privileged-level EXEC	SR
<code>show ip proximity servers</code>	Displays the interface addresses and hostnames of the proximity servers currently in use by this Proximity Engine.	User-level EXEC and privileged-level EXEC	SR
<code>show ip rib clients</code>	Displays details of all the routing protocol instances that are clients of the RIB.	User-level EXEC and privileged-level EXEC	SR
<code>show ip rib memory</code>	Displays the memory usage information of the RIB.	User-level EXEC and privileged-level EXEC	SR
<code>show ip rib recursive-next-hop</code>	Displays IP recursive next-hop information from the RIB.	User-level EXEC and privileged-level EXEC	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>show ip rib route</code>	Displays IP RIB route information.	User-level EXEC and privileged-level EXEC	SR
<code>show ip rib unresolved-next-hop</code>	Displays unresolved next-hop information from the RIB.	User-level EXEC and privileged-level EXEC	SR
<code>show ip routes</code>	Displays the IP routing table.	Privileged-level EXEC	All
<code>show isis adjacency</code>	Displays IS-IS adjacencies.	User-level EXEC and privileged-level EXEC	SR
<code>show isis clns route</code>	Displays one or all the destinations to which the router knows how to route CLNS packets.	User-level EXEC and privileged-level EXEC	SR
<code>show isis database</code>	Displays the IS-IS link-state database.	User-level EXEC and privileged-level EXEC	SR
<code>show isis hostname-table</code>	Displays the router-name-to-system-ID mapping table entries for an IS-IS router.	User-level EXEC and privileged-level EXEC	SR
<code>show isis interface</code>	Displays information about the IS-IS interfaces.	User-level EXEC and privileged-level EXEC	SR
<code>show isis ip route</code>	Displays the Intermediate IS-IS RSPF route for IS-IS learned routes.	User-level EXEC and privileged-level EXEC	SR
<code>show isis ip rspf route</code>	Displays the Intermediate IS-IS RSPF route for IS-IS learned routes.	User-level EXEC and privileged-level EXEC	SR
<code>show isis memory</code>	Displays memory usage information for an IS-IS instance.	User-level EXEC and privileged-level EXEC	SR
<code>show isis process</code>	Displays summary information about an IS-IS instance.	User-level EXEC and privileged-level EXEC	SR
<code>show isis rrm</code>	Displays IS-IS RRM <sup>16</sup> information.	User-level EXEC and privileged-level EXEC	SR
<code>show isis spf-log</code>	Displays how often and why the router has run a full SPF <sup>17</sup> calculation.	User-level EXEC and privileged-level EXEC	SR
<code>show isis srm</code>	Displays SRM <sup>18</sup> information for an IS-IS process.	Privileged-level EXEC	SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">show isis ssn</a>	Displays SSN <sup>19</sup> information for an IS-IS process.	User-level EXEC and privileged-level EXEC	SR
<a href="#">show key chain</a>	Displays the key chains in the system.	User-level EXEC and privileged-level EXEC	SR
<a href="#">show logging</a>	Displays the system logging configuration.	User-level EXEC and privileged-level EXEC	All
<a href="#">show movie-streamer</a>	Displays the Movie Streamer configuration.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show ntp</a>	Displays the Network Time Protocol configuration status.	User-level EXEC and privileged-level EXEC	All
<a href="#">show processes</a>	Displays the process status.	User-level EXEC and privileged-level EXEC	All
<a href="#">show programs</a>	Displays the scheduled programs.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show qos</a>	Displays QoS information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show radius-server</a>	Displays the RADIUS server information.	User-level EXEC and privileged-level EXEC	All
<a href="#">show rea</a>	Displays the REA information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show rcp</a>	Displays RCP information	User-level EXEC and privileged-level EXEC	All
<a href="#">show rtsp</a>	Displays the RTSP configurations.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show rule</a>	Displays the Rules Template configuration information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show running-config</a>	Displays the current operating configuration.	User-level EXEC and privileged-level EXEC	All

**Table 2-1 CLI Commands (continued)**

Command	Description	CLI Mode	Device Mode
<code>show service-router</code>	Displays the Service Router configuration.	User-level EXEC and privileged-level EXEC	All
<code>show services</code>	Displays the services-related information.	User-level EXEC and privileged-level EXEC	All
<code>show snmp</code>	Displays the SNMP parameters.	User-level EXEC and privileged-level EXEC	All
<code>show srp database</code>	Displays the descriptor-related information saved in the descriptor database.	Privileged-level EXEC	CDSM, SR
<code>show srp leafset</code>	Displays SRP leafset information.	Privileged-level EXEC	CDSM, SR
<code>show srp memory</code>	Displays SRP memory usage information.	Privileged-level EXEC	CDSM, SR
<code>show srp multicast database</code>	Displays multicast database information for an SRP process.	Privileged-level EXEC	CDSM, SR
<code>show srp neighbor</code>	Displays SRP neighbor information.	Privileged-level EXEC	CDSM, SR
<code>show srp process</code>	Displays the basic configurations for SRP.	Privileged-level EXEC	CDSM, SR
<code>show srp replica-set</code>	Displays the replica-set information for a Proximity Engine.	Privileged-level EXEC	CDSM, SR
<code>show srp route</code>	Displays route information for a Proximity Engine to its neighbor nodes on the same DHT network.	Privileged-level EXEC	CDSM, SR
<code>show srp subscribers</code>	Displays SRP multicast group subscriber information.	Privileged-level EXEC	CDSM, SR
<code>show ssh</code>	Displays the Secure Shell status and configuration.	User-level EXEC and privileged-level EXEC	All
<code>show standby</code>	Displays the information related to the standby interface.	User-level EXEC and privileged-level EXEC	All
<code>show startup-config</code>	Displays the startup configuration.	User-level EXEC and privileged-level EXEC	All
<code>show statistics access-lists 300</code>	Displays the access control list statistics.	User-level EXEC and privileged-level EXEC	SE



**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">show statistics acquirer</a>	Displays the SE acquirer delivery service statistics.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics authentication</a>	Displays the authentication statistics.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics authsvr</a>	Displays the Authentication Server statistics.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics cdn-select</a>	Displays the statistics for the CDN Selector.	User-level EXEC and privileged-level EXEC	SR
<a href="#">show statistics cdnfs</a>	Displays the SE Internet Streamer CDS network file system statistics.	User-level EXEC and privileged-level EXEC	CDSM, SE
<a href="#">show statistics distribution</a>	Displays the simplified statistics for content distribution components.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics flash-media-streaming</a>	Displays the statistics for Flash Media Streaming.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics http</a>	Displays the Hypertext Transfer Protocol statistics.	User-level EXEC and privileged-level EXEC	SE, SR
<a href="#">show statistics icap</a>	Displays the ICAP-related statistics.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics icmp</a>	Displays the Internet Control Message Protocol statistics.	User-level EXEC and privileged-level EXEC	All
<a href="#">show statistics ip</a>	Displays the Internet Protocol statistics.	User-level EXEC and privileged-level EXEC	All
<a href="#">show statistics isis</a>	Displays IS-IS traffic counters.	User-level EXEC and privileged-level EXEC	CDSM, SR
<a href="#">show statistics movie-streamer</a>	Displays statistics for the Movie Streamer.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show statistics netstat</a>	Displays the Internet socket connection statistics.	User-level EXEC and privileged-level EXEC	All

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>show statistics qos</code>	Displays statistics for the QoS policy service.	User-level EXEC and privileged-level EXEC	SE
<code>show statistics radius</code>	Displays the RADIUS authentication statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics replication</code>	Displays the delivery service replication status and related statistical data.	User-level EXEC and privileged-level EXEC	CDSM, SR
<code>show statistics service-router</code>	Displays the Service Router statistics.	User-level EXEC and privileged-level EXEC	SR
<code>show statistics services</code>	Displays the services statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics snmp</code>	Displays the SNMP statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics srp</code>	Displays SRP statistics information.	Privileged-level EXEC	SR
<code>show statistics tacacs</code>	Displays the Service Engine TACACS+ authentication and authorization statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics tcp</code>	Displays the Transmission Control Protocol statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics transaction-logs</code>	Displays the transaction log export statistics.	User-level EXEC and privileged-level EXEC	SE
<code>show statistics udp</code>	Displays the User Datagram Protocol statistics.	User-level EXEC and privileged-level EXEC	All
<code>show statistics web-engine</code>	Displays the Web Engine statistics.	User-level EXEC and privileged-level EXEC	SE
<code>show statistics wmt</code>	Displays the Windows Media Technologies statistics.	User-level EXEC and privileged-level EXEC	SE
<code>show tacacs</code>	Displays TACACS+ authentication protocol configuration information.	User-level EXEC and privileged-level EXEC	All
<code>show tech-support</code>	Displays the system information for Cisco technical support.	User-level EXEC and privileged-level EXEC	All

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">show telnet</a>	Displays the Telnet services configuration.	User-level EXEC and privileged-level EXEC	All
<a href="#">show transaction-logging</a>	Displays the transaction logging information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show url-signature</a>	Displays the URL signature information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show user</a>	Displays the user identification number and username information.	User-level EXEC and privileged-level EXEC	All
<a href="#">show users</a>	Displays the specified users.	User-level EXEC and privileged-level EXEC	All
<a href="#">show version</a>	Displays the software version.	User-level EXEC and privileged-level EXEC	All
<a href="#">show web-engine</a>	Displays the Web Engine information.	User-level EXEC and privileged-level EXEC	SE
<a href="#">show wmt</a>	Displays the WMT configuration.	User-level EXEC and privileged-level EXEC	SE
<a href="#">shutdown (interface configuration)</a>	Shuts down the specified interface.	Interface configuration	All
<a href="#">shutdown (EXEC)</a>	Shuts down the device (stops all applications and operating system).	Privileged-level EXEC	All
<a href="#">snmp-server community</a>	Configures the community access string to permit access to the SNMP.	Global configuration	All
<a href="#">snmp-server contact</a>	Specifies the text for the MIB object sysContact.	Global configuration	All
<a href="#">snmp-server enable traps</a>	Enables the SNMP traps.	Global configuration	All
<a href="#">snmp-server group</a>	Defines a user security model group.	Global configuration	All
<a href="#">snmp-server host</a>	Specifies the hosts to receive SNMP traps.	Global configuration	All
<a href="#">snmp-server location</a>	Specifies the path for the MIB object sysLocation.	Global configuration	All
<a href="#">snmp-server notify inform</a>	Configures the SNMP inform request.	Global configuration	All

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<code>snmp-server user</code>	Defines a user who can access the SNMP engine.	Global configuration	All
<code>snmp-server view</code>	Defines an SNMPv2 <sup>20</sup> MIB view.	Global configuration	All
<code>ss</code>	Dumps socket statistics.	Privileged-level EXEC	SE
<code>sshd</code>	Configures the SSH service parameters.	Global configuration	All
<code>streaming-interface</code>	Configures the streaming interface.	Global configuration	SE
<code>sysreport</code>	Saves the sysreport to a user-specified file.	Privileged-level EXEC	SE
<code>tacacs</code>	Configures TACACS+ server parameters.	Global configuration	All
<code>tcpdump</code>	Dumps the TCP traffic on the network.	Privileged-level EXEC	All
<code>tcpmon</code>	Searches all TCP connections.	Privileged-level EXEC	SE
<code>tcp timestamp</code>	Enables and disables TCP timestamp.	Global configuration	All
<code>telnet</code>	Starts the Telnet client.	User-level EXEC and privileged-level EXEC	All
<code>telnet enable</code>	Enables the Telnet services.	Global configuration	All
<code>terminal</code>	Sets the terminal output commands.	User-level EXEC and privileged-level EXEC	All
<code>test-url</code>	Tests the accessibility of a URL using FTP, HTTP, or HTTPS.	User-level EXEC and privileged-level EXEC	SE, SR
<code>top</code>	Displays a dynamic real-time view of a running CDS.	Privileged-level EXEC	All
<code>traceroute</code>	Traces the route to a remote host.	User-level EXEC and privileged-level EXEC	All
<code>traceroute srp</code>	Traces the route of the SRP ring.	User-level EXEC and privileged-level EXEC	SR
<code>traceroute6</code>	Traces the route to a remote IPv6-enabled host.	User-level EXEC and privileged-level EXEC	SE, SR

**Table 2-1** *CLI Commands (continued)*

Command	Description	CLI Mode	Device Mode
<a href="#">transaction-log force</a>	Forces archiving of the working log file to make a transaction log file.	Privileged-level EXEC	All
<a href="#">transaction-logs</a>	Configures and enables the transaction logging parameters.	Global configuration	SE
<a href="#">type</a>	Displays a file.	User-level EXEC and privileged-level EXEC	All
<a href="#">type-tail</a>	Displays the last several lines of a file.	User-level EXEC and privileged-level EXEC	All
<a href="#">undebug</a>	Disables debugging functions.	Privileged-level EXEC	All
<a href="#">url-signature</a>	Configures the URL signature.	Global configuration	SE
<a href="#">username</a>	Establishes the username authentication.	Global configuration	All
<a href="#">web-engine (EXEC)</a>	Configures the Web Engine.	User-level EXEC	SE
<a href="#">web-engine (Global configuration)</a>	Configures the Web Engine caching parameters and disables revalidation.	Global configuration	SE
<a href="#">whoami</a>	Displays the current user's name.	User-level EXEC and privileged-level EXEC	All
<a href="#">wmt</a>	Configures the WMT.	Global configuration	SE
<a href="#">write</a>	Writes or erases the startup configurations to NVRAM or to a terminal session, or writes the MIB persistence configuration to disk.	Privileged-level EXEC	All

1. NSSA = not-so-stubby area
2. WMT = Windows Media Technologies
3. MOTD = message-of-the-day
4. CDNFS = CDS network file system
5. CMS = centralized management system
6. Commands used to access configuration modes.
7. SSH = secure shell
8. syslog = system logging
9. MTU = maximum transmission unit
10. NET = network entity title
11. CLNS = Connectionless Network Service
12. OSPF = Open Shortest Path First
13. FTP = File Transfer Protocol
14. LSAs = link-state advertisements
15. RSPF = reverse shortest path first
16. RRM = received routing message

- 17. SPF = Shortest Path First
- 18. SRM = send routing message
- 19. SSN = send sequence number
- 20. SNMPv2 = SNMP Version 2

# access-lists

To configure access control list entries, use the **access-lists** command in Global configuration mode. To remove access control list entries, use the **no** form of this command.

```
access-lists {300 {deny groupname {any [position number] | groupname [position number] } } |
```

```
  {permit groupname {any [position number] | groupname [position number] } } | enable}
```

```
no access-lists {300 {deny groupname {any [position number] | groupname [position number] } } |
```

```
  {permit groupname {any [position number] | groupname [position number] } } | enable}
```

Syntax Description	300	Specifies the group name-based access control list (ACL).
	<b>deny</b>	Specifies the rejection action.
	<b>groupname</b>	Defines which groups are granted or denied access to content that is served by this SE.
	<b>any</b>	Specifies any group name.
	<b>position</b>	(Optional) Specifies the position of the ACL record within the access list.
	<i>number</i>	(Optional) Position number within the ACL. The range is from 1 to 4294967294.
	<i>groupname</i>	Name of the group that is permitted or denied from accessing the Internet using an SE.
	<b>permit</b>	Specifies the permission action.
	<b>enable</b>	Enables the ACL.

**Command Defaults** None

**Command Modes** Global configuration (config) mode.

**Usage Guidelines** In the Internet Streamer CDS 2.x software, you can configure group authorization using an ACL only after a user has been authenticated against an LDAP HTTP-request Authentication Server. The use of this list configures group privileges when members of the group are accessing content provided by an SE. You can use the ACL to allow the users who belong to certain groups or to prevent them from viewing specific content. This authorization feature offers more granular access control by specifying that access is only allowed to specific groups.

Use the **access-lists enable** Global configuration command to enable the use of the ACL.

Use the **access-lists 300** command to permit or deny a group from accessing the Internet using an SE. For instance, use the **access-lists 300 deny groupname marketing** command to prevent any user from the marketing group from accessing content through an SE.

At least one login authentication method, such as local, TACACS+, or RADIUS, must be enabled.



## Note

We recommend that you configure the local login authentication method as the primary method.

In Cisco Internet Streamer CDS Release 2.5 software, the ACL contains the following feature enhancements and limitations:

- A user can belong to several groups.
- A user can belong to an unlimited number of groups within group name strings.
- A *group name string* is a case-sensitive string with mixed-case alphanumeric characters.
- Each unique group name string cannot exceed 128 characters.



**Note** If the unique group name string is longer than 128 characters, the group is ignored.

- Group names in a group name string are separated by a comma.
- Total string of individual group names cannot exceed 750 characters.

For Windows-based user groups, append the domain name in front of the group name in the form domain or group as follows:

For Windows NT-based user groups, use the domain NetBIOS name.

## Examples

The following example shows how to display the configuration of the ACL by using the **show access-lists 300** command:

```
ServiceEngine# show access-lists 300
Access Control List Configuration
-----
Access Control List is enabled

Groupname-based List (300)
1. permit groupname techpubs
2. permit groupname acme1
3. permit groupname engineering
4. permit groupname sales
5. permit groupname marketing
6. deny groupname any
```

The following example shows how to display statistical information for the ACL by using the **show statistics access-lists 300** command:

```
ServiceEngine# show statistics access-lists 300
Access Control Lists Statistics
-----
Groupname and username-based List (300)
Number of requests:      1
Number of deny responses: 0
Number of permit responses: 1
```

The following example shows how to reset the statistical information for the ACL by using the **clear statistics access-lists 300** command:

```
ServiceEngine# clear statistics access-lists 300
ServiceEngine(config)# access-lists 300 permit groupname acme1 position 2
```

## Related Commands

Command	Description
<b>show access-lists 300</b>	Displays the ACL configuration.
<b>show statistics access-list 300</b>	Displays the ACL statistics.



## acquirer (EXEC)

To start or stop content acquisition on a specified acquirer delivery service, use the **acquirer** command in EXEC configuration mode. You can also use this command to verify and correct the Last-Modified-Time attribute in content acquired using the Cisco Internet Streamer CDS software.

```
acquirer {check-time-for-old-content [delivery-service-id delivery-service-num |
delivery-service-name delivery-service-name] | [correct [delivery-service-id
delivery-service-num | delivery-service-name delivery-service-name] ] |
start-delivery-service {delivery-service-id delivery-service-num | delivery-service-name
delivery-service-name} | stop-delivery-service {delivery-service-id delivery-service-num |
delivery-service-name delivery-service-name} | test-url url [use-http-proxy url |
use-smb-options smb-options] }
```

Syntax	Description
<b>check-time-for-old-content</b>	Checks the content for the Last-Modified-Time attributes in the local time format.
<b>delivery-service-id</b>	(Optional) Sets the delivery service number identifier.
<i>delivery-service-num</i>	(Optional) Delivery service number. The range is from 0 to 4294967295.
<b>delivery-service-name</b>	(Optional) Sets the delivery service name descriptor.
<i>delivery-service-name</i>	(Optional) Delivery service name.
<b>correct</b>	(Optional) Changes the Last-Modified-Time attributes in the local time format to the Greenwich Mean Time (GMT) format.
<b>start-delivery-service</b>	Starts the content acquisition.
<b>stop-delivery-service</b>	Stops the content acquisition.
<b>test-url</b>	Tests the accessibility of a URL, using HTTP, HTTPS, FTP, or SMB.
<i>url</i>	URL to be tested.
	<b>Note</b> For the SMB protocol, use the Uniform Naming Convention (UNC) path, for example, //host/share/file.
<b>use-http-proxy</b>	(Optional) Specifies the HTTP proxy. The connectivity of the URL (content request over HTTP) through the HTTP proxy server (SE) is tested. Use this option only when the HTTP protocol is used.
<i>url</i>	(Optional) HTTP proxy URL. Use one of the following formats to specify the HTTP proxy URL:  <a href="http://proxyIpAddress:proxyPort">http://proxyIpAddress:proxyPort</a> <a href="http://proxyUser:proxypasswd@proxyIpAddress:proxyPort">http://proxyUser:proxypasswd@proxyIpAddress:proxyPort</a>
<b>use-smb-options</b>	(Optional) Specifies the username, password, port, and domain for the SMB URL.
<i>smb-options</i>	(Optional) Parameters to be specified when an SMB URL is used. Use the following format to specify these parameters:  username=xxx,password=xxx,port=xxx,workgroup=xxx  <b>Note</b> All the comma-separated key=value pairs are optional and need to be specified only if the SMB host requires them.

**Command Defaults**

If you do not specify the delivery service, this command applies to all delivery services assigned to the Content Acquirer.

**Command Modes**

EXEC configuration mode.

**Usage Guidelines**

The *acquirer* is a software agent that gathers delivery service content before it is distributed to the receiver SEs in an Internet Streamer CDS network. The acquirer maintains a task list, which it updates after receiving a notification of changes in its delivery service configuration.

The acquirer stores the Last-Modified-Time attribute in the local time format. Content acquired using earlier software releases has a Last-Modified-Time attribute that is incorrect if used with later versions of the Internet Streamer CDS software, which use GMT format.

With Cisco Internet Streamer CDS Release 2.5 software, correct the Last-Modified-Time attributes for content acquired with earlier releases by entering the following command from the privileged EXEC prompt:

**acquirer check-time-for-old-content correct** [**delivery-service-id** *delivery-service-num*]  
**delivery-service-name** *delivery-service-name*]

This command changes the Last-Modified-Time attributes for content in all delivery services assigned to the Content Acquirer unless you specify the delivery service ID or name.

SEs running Cisco Internet Streamer CDS Release 2.5 software identify changes in the Last-Modified-Time attribute and download content only when changes have occurred.

Use the **acquirer start-delivery-service** command to immediately start acquisition tasks for the selected delivery service. Use the **acquirer stop-delivery-service** command to immediately stop all acquisition tasks for the selected delivery service.

Use the **acquirer test-url** *url* command in EXEC configuration mode to test whether a URL is accessible or not. The actual content is dumped into the /dev/null path.

**Examples**

The following example shows how the acquirer starts acquiring content on delivery service 86:

```
ServiceEngine# acquirer start-delivery-service delivery-service-id 86
```

```
ServiceEngine# acquirer start-delivery-service delivery-service-name corporate
```

The following example shows how the acquirer stops acquiring content on delivery service 86:

```
ServiceEngine# acquirer stop-delivery-service delivery-service-id 86
```

```
ServiceEngine# acquirer stop-delivery-service delivery-service-name corporate
```

The following example shows how the **acquirer test-url** command is used to test a URL:

```
ServiceEngine# acquirer test-url http://172.16.150.26
--05:16:41-- http://10.107.150.26
=> `/dev/null'
Connecting to 10.107.150.26:80... connected.
HTTP request sent, awaiting response... 200 OK
Length: 1,722 [ text/html ]

100% [ =====> ] 1,722          1.64M/s    ETA 00:00

02:45:40 (1.64 MB/s) - `/dev/null' saved [ 1722/1722 ]
```

Related Commands	Command	Description
	<b>show acquirer</b>	Displays the acquirer delivery service information and progress for a specified delivery service number or name.
	<b>show statistics acquirer</b>	Displays the SE acquirer delivery service statistics.

## acquirer (Global configuration)

To provide authentication when the acquirer obtains content through a proxy server, use the **acquirer** command in Global configuration mode. To disable acquirer proxy authentication, use the **no** form of this command.

**acquirer proxy authentication {outgoing {hostname | ip-address} port-num} username | password password}**

**no acquirer proxy authentication {outgoing {hostname | ip-address} port-num} username | password password}**

### Syntax Description

<b>proxy</b>	Configures parameters for outgoing proxy mode requests for content acquisition.
<b>authentication</b>	Enables authentication so that the acquirer can obtain content through a proxy server.
<b>outgoing</b>	Enables authentication for a nontransparent proxy server.
<i>hostname</i>	Hostname of a nontransparent proxy server.
<i>ip-address</i>	IP address of a nontransparent proxy server.
<i>port-num</i>	Port number of a nontransparent proxy server. The range is from 1 to 65535.
<i>username</i>	Username for authentication using a maximum of 256 characters.
<b>password</b>	Allows the use of a password for authentication.
<i>password</i>	Password for authentication using a maximum of 256 characters.

### Command Defaults

None

### Command Modes

Global configuration (config) mode.

### Usage Guidelines

Use the **acquirer proxy authentication outgoing** Global configuration command to configure authentication when you enable content acquisition through a proxy server. First configure the proxy host and the port using the **http proxy outgoing host** Global configuration command. The maximum number of outgoing proxies allowed is eight. When you remove an outgoing proxy using the **no http outgoing proxy** command, the authentication information associated with that proxy is automatically removed.

Use the **acquirer proxy authentication transparent** command for transparent caches in the Internet Streamer CDS network that require authentication.

The *acquirer* supports a proxy with basic authentication. Content acquisition through a proxy server is supported only for HTTP and not for HTTPS or FTP. Also, authentication is only supported for a single proxy server in a chain, so if multiple proxy servers in a chain require authentication, the request fails.

Acquisition through a proxy server can be configured when the Content Acquirer cannot directly access the origin server because the origin server is set up to allow access only by a specified proxy server. When a proxy server is configured for Content Acquirer content acquisition, the acquirer contacts the proxy server instead of the origin server, and all requests to that origin server go through the proxy server.

**Note**

Content acquisition through a proxy server is only supported for HTTP requests. It is not supported for HTTPS, FTP, MMS, or MMS-over-HTTP requests.

There are three ways to configure the proxy server: through the CDSM GUI. If you need to configure the SE to use the proxy for both caching and prepositioned content, use the CLI to configure the proxy. The CLI command is a Global configuration command that configures the entire SE to use the proxy. If only the acquirer portion of the SE needs to use the proxy for acquiring the prepositioned content, use the manifest file or specify the outgoing proxy. When you configure the proxy server in the manifest file, you are configuring the acquirer to use the proxy to fetch the content for a particular delivery service.

**Note**

Proxy configurations in the manifest file take precedence over proxy configurations in the CLI. A *noProxy* attribute configuration in the manifest file takes precedence over the other proxy server configurations in the manifest file.

You can also configure a proxy for fetching the manifest file by using the CDSM GUI (the Creating New Delivery Service or Modifying Delivery Service window). When you configure a proxy server in the CDSM GUI, the proxy configuration is valid only for acquiring the manifest file and not for acquiring the delivery service content. Requests for the manifest file go through the proxy server, and requests for the content go directly to the origin server.

**Tip**

Before configuring a proxy server, verify that the Content Acquirer is able to ping the proxy server. To check whether the proxy server is accepting incoming HTTP traffic at the configured port, use the **acquirer test-url** *http://proxyIP:proxyport* command in Global configuration mode in the Content Acquirer CLI, where the URL in the command is the URL of the proxy server being tested. If the proxy is not servicing the configured port, the message “failed: Connection refused.”

**Examples**

The following example shows the authentication configuration for a transparent proxy server with basic authentication:

```
ServiceEngine(config)# acquirer proxy authentication transparent 192.168.1.1 8080 myname
```

**Related Commands**

Command	Description
<b>http proxy outgoing</b>	Configures an SE to direct all HTTP miss traffic to a parent cache.
<b>show acquirer</b>	Displays the acquirer delivery service information and progress for a specified delivery service number or name.

# acquisition-distribution

To start or stop the content acquisition and distribution process, use the **acquisition-distribution** command in EXEC configuration mode.

**acquisition-distribution {database-cleanup {start | stop} | start | stop}**

## Syntax Description

<b>database-cleanup</b>	Cleans up the acquisition and distribution database to maintain consistency with the file system.
<b>start</b>	Starts the cleanup of the acquisition and distribution database.
<b>stop</b>	Stops the cleanup of the acquisition and distribution database.
<b>start</b>	Starts the acquisition and distribution process.
<b>stop</b>	Stops the acquisition and distribution process.

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Usage Guidelines

When you use the **acquisition-distribution database-cleanup** command, the acquisition and distribution database is checked to ensure that all prepositioned content is available in Cisco Network File System (CDNFS). If any prepositioned content is found to be missing from CDNFS, the content is replicated to all SEs in the Internet Streamer CDS network. Content Acquirers assigned to a delivery service acquire the content directly from the origin server and replicate the content through the delivery service either by unicast or multicast transmission to other SEs in the delivery service. Receiver SEs obtain the content from forwarder SEs either by unicast or multicast. In the case of a disk00 failure, when the database is stored on disk00 in an internal file system (/state), the recovery of the acquisition and distribution database is done automatically. You should run the acquisition and distribution database cleanup if a failure occurs or if you have to replace a disk drive other than disk00.

## Examples

The following example shows how to start the acquisition and distribution database cleanup process:

```
ServiceEngine# acquisition-distribution database-cleanup start
```

The following example shows how to start the acquisition and distribution process:

```
ServiceEngine# acquisition-distribution start
```

The following example shows how to stop the acquisition and distribution process:

```
ServiceEngine# acquisition-distribution stop
```

## Related Commands

Command	Description
<b>cdnfs cleanup</b>	Cleans up the content of deleted channels from the acquisition and distribution database.

<b>show acquirer</b>	Displays the acquirer delivery service information and progress for a specified delivery service number or name.
<b>show distribution</b>	Displays the distribution information for a specified delivery service.

# alarm

To configure alarms, use the **alarm** command in Global configuration mode. To disable alarms, use the **no** form of this command.

**alarm overload-detect {clear 1-999 [raise 10-1000] | enable | raise 10-1000 [clear 1-999] } | temperature enable**

**no alarm overload-detect {clear 1-999 [raise 10-1000] | enable | raise 10-1000 [clear 1-999] } | temperature enable**

Syntax Description		
<b>clear</b>		Specifies the threshold below which the alarm overload state on an SE is cleared and the Simple Network Management Protocol (SNMP) traps and alarm notifications to the Centralized Management System (CMS) resume.
		<b>Note</b> The <b>alarm overload-detect clear</b> command value must be less than the <b>alarm overload-detect raise</b> value.
	<i>1-999</i>	Number of alarms per second that ends an alarm overload condition.
<b>raise</b>		(Optional) Specifies the threshold at which the CDE enters an alarm overload state and SNMP traps and alarm notifications to CMS are suspended.
	<i>10-1000</i>	Number of alarms per second that triggers an alarm overload.
<b>enable</b>		Enables the detection of alarm overload situations.
<b>temperature</b>		Configures temperature alarms on the CDE100 and CDE200.
<b>enable</b>		Enables temperature alarms on the CDE100 and CDE200.

Command Defaults	<b>raise:</b> 10 alarms per second
	<b>clear:</b> 1 alarm per second

Command Modes	Global configuration (config) mode.
---------------	-------------------------------------

Usage Guidelines	When multiple applications running on an SE experience problems at the same time, numerous alarms are set off simultaneously, and an SE may stop responding. In the Internet Streamer CDS 2.2 software and later and later releases, you can use the <b>alarm overload-detect</b> command to set an overload limit for the incoming alarms from the node health manager. If the number of alarms exceeds the maximum number of alarms allowed, an SE enters an alarm overload state until the number of alarms drops down to the number defined in the <b>clear</b> .
------------------	---

When an SE is in the alarm overload state, the following events occur:

- Alarm overload notification is sent to SNMP and the CMS. The **clear** and **raise** values are also communicated to SNMP and the CMS.
- SNMP traps and CMS notifications for subsequent alarm raise and clear operations are suspended.
- Alarm overload clear notification is sent.
- SE remains in the alarm overload state until the rate of incoming alarms decreases to the **clear** value.



**Note**

In the alarm overload state, applications continue to raise alarms and the alarms are recorded within an SE. The **show alarms** and **show alarms history** command in EXEC configuration modes display all the alarms even in the alarm overload state.

In Cisco Internet Streamer CDS Release 2.5.9-b124 software, the temperature alarm support is disabled by default on the CDE100 and CDE200. The **alarm temperature enable** command has been added and is only applicable to the CDE100 and CDE200. When the alarm temperature enable command is entered on the CDE100 and the CDE200, the temperature alarm is visible and `alarm temperature enable` is displayed in the output for the `show running-config` command. When no alarm temperature enable command is entered on these platforms, there are no temperature alarms.

**Examples**

The following example shows how to enable the detection of alarm overload:

```
ServiceEngine(config)# alarm overload-detect enable
```

The following example shows how to set the threshold for triggering the alarm overload at 100 alarms per second:

```
ServiceEngine(config)# alarm overload-detect raise 100
```

The following example shows how to set the level for clearing the alarm overload at 10 alarms per second:

```
ServiceEngine(config)# alarm overload-detect clear 10
```

The following example shows how to enable temperature alarms for a CDE100 or CDE200:

```
ServiceEngine(config)# alarm temperature enable
```

**Related Commands**

Command	Description
<b>show alarms</b>	Displays information on various types of alarms, their status, and history.
<b>show alarm status</b>	Displays the status of various alarms and alarm overload settings.

## area nssa

To configure an area as a not-so-stubby area (NSSA), use the **area nssa** router configuration command. To remove the NSSA distinction from the area, use the **no** form of this command.

**area** *area-id* **nssa**

**no area** *area-id* **nssa**

Syntax Description	<i>area-id</i>	Identifier of the area for which authentication is to be enabled. The identifier can be specified as either a decimal value or an IP address (ID range is from 0 to 4294967295).
--------------------	----------------	--

Command Defaults	No NSSA area is defined.
------------------	--------------------------

Command Modes	OSPF configuration (config-ospf) mode.
---------------	--

Usage Guidelines	This command is used to configure an area as a NSSA. The area ID range is given as 0 to 4294967295, but area 0 cannot be configured as an NSSA area.
------------------	--

Examples	In the following example area 1 is configured as an NSSA area:
----------	--

```
ServiceRouter(config)# router ospf
ServiceRouter(config-ospf)# network 192.168.20.0 0.0.0.255 area 1
ServiceRouter(config-ospf)# area 1 nssa
ServiceRouter(config-ospf)#
```

## area stub

To define an area as a stub area, use the **area stub** router configuration command. To disable this function, use the **no** form of this command

**area** *area-id* **stub**

**no area** *area-id* **stub**

<b>Syntax Description</b>	<i>area-id</i> Identifier for the stub area. The identifier can be specified as either a decimal value or an IP address (ID range is from 0 to 4294967295).
<b>Command Defaults</b>	No stub area is defined.
<b>Command Modes</b>	OSPF configuration (config-ospf) mode.
<b>Usage Guidelines</b>	This command is used to define an area as a stub area. The area ID range is given as 0 to 4294967295, but area 0 cannot be configured as a stub area.
<b>Examples</b>	<p>The following example shows how to configure area 1 as a stub area:</p> <pre>ServiceRouter(config)# <b>router ospf</b> ServiceRouter(config-ospf)# <b>network 192.168.20.0 0.0.0.255 area 1</b> ServiceRouter(config-ospf)# <b>area 1 stub</b> ServiceRouter(config-ospf)#</pre>

# asset

To configure the CISCO-ENTITY-ASSET-MIB, use the **asset** command in Global configuration mode. To remove the asset tag name, use the **no** form of this command.

**asset tag** *name*

**no asset tag** *name*

## Syntax Description

<b>tag</b>	Sets the asset tag.
<i>name</i>	Asset tag name string.

## Command Defaults

None

## Command Modes

Global configuration (config) mode.

## Examples

The following example shows how to configure a tag name for the asset tag string:

```
ServiceEngine(config)# asset tag entitymib
```

# authentication

To specify authentication and authorization methods, use the **authentication** command in Global configuration mode. To selectively disable options, use the **no** form of this command.

```
authentication { configuration { local | radius | tacacs } enable [primary | secondary] | fail-over
server-unreachable | login { local | radius | tacacs } enable [primary | secondary] }
```

```
no authentication { configuration { local | radius | tacacs } enable [primary | secondary] |
fail-over server-unreachable | login { local | radius | tacacs } enable [primary | secondary] }
```



## Note

This command is only available on Cisco Internet Streamer CDS Release 2.5.3 software.

## Syntax Description

<b>configuration</b>	Sets configuration authentication (authorization).
<b>local</b>	Selects the local database for authentication or authorization.
<b>radius</b>	Selects a RADIUS server for authentication or authorization.
<b>tacacs</b>	Selects TACACS+ server authentication.
<b>enable</b>	Enables the source of authorization information.
<b>primary</b>	(Optional) Sets the first authentication method used.
<b>secondary</b>	(Optional) Sets the second authentication method used.
<b>fail-over</b>	Sets the condition to use the next authentication scheme, when primary authentication fails.
<b>server-unreachable</b>	Specifies that a failover to the secondary authentication scheme should occur only if the primary Authentication Server is unreachable.
<b>login</b>	Selects the local method for authentication.

## Command Defaults

The local authentication method is enabled by default.

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

Authentication, also referred to as login, is the act of verifying usernames and passwords. Authorization is the action of determining what a user is allowed to do. It permits or denies privileges for authenticated users in the network. For example, if you log in to an SE with a superuser administrator account (for example, the predefined admin account), you have the highest level of access privileges and can perform any administrative task, such as:

- Configure the standalone SE.
- Obtain statistical information that the standalone SE has collected.
- Reload the device.

Generally, authentication precedes authorization in a network.

The **authentication** command configures both the authentication and authorization methods that govern login and configuration access to an SE. Login and configuration privileges can be maintained in two different databases in the Cisco Internet Streamer CDS 2.5 software: the local database, TACACS+ database, and RADIUS database. If all databases are enabled, then all three databases are queried. If the user data cannot be found in the first database queried, then the second and third databases are queried.

When an administrator can log in to an SE through the console or the GUI, an SE checks the specified authentication database to verify the user's username and password to process these administrative login requests and to determine the access rights that this particular administrator should be granted during this login session. When an SE receives an administrative login request, an SE can check its local database or a remote third-party database (the TACACS+ database or the RADIUS database) to verify the username with the password and to determine the access privileges of the administrator.

**Note**

If you are going to use different servers for authentication and authorization (for example, local for authentication login and RADIUS for authentication configuration) , then the username and password must be the same for both servers.

When defining or modifying the authentication configuration method for an SE, follow these guidelines:

- Use the **authentication** command to choose between using an external access server or the internal (local) SE-based AAA system for user access management.
- Configure any combination of these authentication and authorization methods to control access and set privileges on an SE:
  - Local authentication and authorization
  - RADIUS authentication and authorization
  - TACACS+ authentication and authorization
- Authentication configuration applies to the following:
  - Console and Telnet connection attempts
  - Secure FTP (SFTP), SSH (SSH Version 1 and Version 2), and Websense server access
- If you configure a RADIUS or TACACS+ key on an SE (the RADIUS client), make sure that you configure an identical key on the RADIUS or TACACS+ server.
- If you configure multiple RADIUS or TACACS+ servers, the first server configured is the primary server, and authentication requests are sent to this server first. You can also specify secondary servers for authentication and authorization purposes.
- By default, the SE uses the local database to authenticate and authorize administrative login requests. The SE verifies whether all authentication databases are disabled and if so, sets the system to the default state. For information on this default state, see the [“Default Administrative Login Authentication and Authorization Configuration”](#) section on page 2-39.

The **authentication login** command determines whether the user has any level of permission to access the SE. The **authentication configuration** command authorizes the user with privileged access (configuration access) to the SE.

The **authentication login local** and the **authentication configuration local** commands use a local database for authentication and authorization.

The **authentication login tacacs** and **authentication configuration tacacs** commands use a remote TACACS+ server to determine the level of user access.

The TACACS+ database validates users before they gain access to the SE. TACACS+ is derived from the United States Department of Defense (RFC 1492) and is used by Cisco as an additional control of non-privileged and privileged mode access. The Cisco Internet Streamer CDS Release 2.4 software and later support TACACS+ only and not TACACS or Extended TACACS.

To configure TACACS+, use the **authentication** and **tacacs** commands. To enable TACACS+, use the **tacacs enable** command.

For more information on TACACS+ authentication, see the [“tacacs” section on page 2-660](#).

The authentication login radius and authentication configuration radius commands use a remote RADIUS server to determine the level of user access.

The **authentication login tacacs** and **authentication configuration tacacs** commands use a remote TACACS+ server to determine the level of user access.

By default, the local method is enabled, with TACACS+ and RADIUS both disabled for login and configuration. Whenever TACACS+ and RADIUS are disabled, local is automatically enabled. TACACS+, RADIUS and local methods can be enabled at the same time. The **primary** option specifies the first method to attempt for both login and configuration; the **secondary** option specifies the method to use if the primary method fails. If all methods of an **authentication login** or **authentication configuration** commands are configured as primary or secondary, local is attempted first, then TACACS+ and then RADIUS.



#### Note

Use the **tacacs** Global configuration command to configure a TACACS+ server for the TACACS+ authentication and authorization method. For information about configuring a TACACS+ server, see the [“Specifying RADIUS Authentication and Authorization Settings” section on page 2-40](#).

Use the **radius-server** Global configuration command to configure a RADIUS server for the RADIUS authentication and authorization method. For information about configuring a RADIUS server, see the [“Specifying RADIUS Authentication and Authorization Settings” section on page 2-40](#).

### Default Administrative Login Authentication and Authorization Configuration

By default, the SE uses the local database to obtain login authentication and authorization privileges for administrative users.



#### Note

Use the **authentication** command to configure the authentication methods that govern administrative login and configuration access to the SE.

[Table 2-2](#) lists the default configuration for administrative login authentication and authorization.

**Table 2-2 Default Configuration for Administrative Login Authentication and Authorization**

Feature	Default Value
Administrative login authentication	Enabled
Administrative configuration authorization	Enabled
Authentication Server failover because the Authentication Server is unreachable	Disabled
TACACS+ login authentication (console and Telnet)	Disabled
TACACS+ authorization (console and Telnet)	Disabled
TACACS+ key	None specified

**Table 2-2** *Default Configuration for Administrative Login Authentication and Authorization (continued)*

Feature	Default Value
TACACS+ server timeout	5 seconds
TACACS+ retransmit attempts	2 times
RADIUS login authentication (console and Telnet)	Disabled
RADIUS authorization (console and Telnet)	Disabled
RADIUS server IP address	None specified
RADIUS server UDP authorization port	Port 1645
RADIUS key	None specified
RADIUS server timeout	5 seconds
RADIUS retransmit attempts	2 times

**Enforcing Authentication with the Primary Method**

The **authentication fail-over server-unreachable** command allows you to specify that failover to the secondary authentication method should occur only if the primary Authentication Server is unreachable. This feature ensures that users gain access to the SE using the local database only when nonlocal Authentication Servers (TACACS+ or RADIUS) are unreachable. For example, when a TACACS+ server is enabled for authentication with user authentication failover configured and the user tries to log in to the SE using an account defined in the local database, login fails. Login succeeds only when the TACACS+ server is unreachable.

**Server Redundancy**

You can specify Authentication Servers with the corresponding Authentication Server (LDAP, or RADIUS) **host** command options, or in the case of TACACS+ servers, with the server hostname command option to configure additional servers. These additional servers provide authentication redundancy and improved throughput, especially when SE load balancing schemes distribute the requests evenly between the servers. If the SE cannot connect to any of the Authentication Servers, no authentication takes place and users who have not been previously authenticated are denied access.

**Login Authentication and Authorization Through the Local Database**

Local authentication and authorization use locally configured login and passwords to authenticate administrative login attempts. The login and passwords are local to each SE and are not mapped to individual usernames.

By default, local login authentication is enabled first. You can disable local login authentication only after enabling one or more of the other administrative login authentication methods. However, when local login authentication is disabled, if you disable all other administrative login authentication methods, local login authentication is reenabled automatically.

**Specifying RADIUS Authentication and Authorization Settings**

RADIUS authentication clients reside on the SE running Cisco Internet Streamer CDS Release 2.5 software. When enabled, these clients send authentication requests to a central (remote) RADIUS server, which contains login authentication and network service access information.

To configure RADIUS authentication on the SE, configure a set of RADIUS Authentication Server settings on the SE. You can use the GUI or the CLI to configure this set of RADIUS Authentication Server settings for the SE.

[Table 2-3](#) describes the RADIUS authentication settings.



**Table 2-3 RADIUS Authentication Settings**

Setting	Description
RADIUS server	RADIUS servers that the SE is to use for RADIUS authentication. To enable the SE to use a specific RADIUS server, enter the IP address or hostname of the RADIUS server and port information. Up to five different hosts are allowed. Early deployment of RADIUS was done using port number 1645, although the official port number for RADIUS is now 1812. Up to five different ports are allowed.
RADIUS key	Key used to encrypt and authenticate all communication between the RADIUS client (the SE) and the RADIUS server. The maximum number of characters in the key is 15. There is no default.  <b>Tip</b> Make sure that the same RADIUS key is enabled on the RADIUS server.
RADIUS timeout interval	Number of seconds the SE waits for a response from the specified RADIUS Authentication Server before declaring a timeout. The range is 1 to 20 seconds. The default value is 5 seconds.
RADIUS retransmit count	Number of times the SE is to retransmit its connection to the RADIUS if the RADIUS timeout interval is exceeded. The range is one to three attempts. The default value is two attempts.

After configuring these RADIUS authentication settings on the SE, you can enable RADIUS login authentication and authorization on the SE.

### Specifying TACACS+ Authentication and Authorization Settings

TACACS+ controls access to network devices by exchanging Network Access Server (NAS) information between a network device and a centralized database to determine the identity of a user or an entity. TACACS+ is an enhanced version of TACACS, a UDP-based access control protocol specified by RFC 1492. TACACS+ uses TCP to ensure reliable delivery and encrypt all traffic between the TACACS+ server and the TACACS+ daemon on a network device.

TACACS+ works with many authentication types, including fixed password, one-time password, and challenge-response authentication.

When a user requests restricted services, TACACS+ encrypts the user password information using the MD5 encryption algorithm and adds a TACACS+ packet header. This header information identifies the packet type being sent (for example, an authentication packet), the packet sequence number, the encryption type used, and the total packet length. The TACACS+ protocol then forwards the packet to the TACACS+ server.

A TACACS+ server can provide authentication, authorization, and accounting functions. These services, while all part of TACACS+, are independent of one another. A TACACS+ configuration can use any or all of the three services.

When the TACACS+ server receives a packet, it does the following:

- Authenticates the user information and notifies the client that the login authentication has either succeeded or failed.
- Notifies the client that authentication will continue and that the client must provide additional information. This challenge-response process can continue through multiple iterations until login authentication either succeeds or fails.

You can configure a TACACS+ key on the client and server. If you configure a key on the SE, it must be the same as the one configured on the TACACS+ servers. The TACACS+ clients and servers use the key to encrypt all TACACS+ packets transmitted. If you do not configure a TACACS+ key, packets are not encrypted.

TACACS+ authentication is disabled by default. You can enable TACACS+ authentication and local authentication at the same time.

In order to configure TACACS+ authentication on SEs, configure a set of TACACS+ authentication settings on the SE. You can use the SE CLI or GUI to configure this set of TACACS+ authentication settings for an SE.

Table 2-4 describes the TACACS+ authentication settings.


**Note**

No TACACS+ authentication will be performed if no TACACS+ servers are configured on the SE.

**Table 2-4 TACACS+ Authentication Settings**

Setting	Description
TACACS+ server	TACACS+ servers that the SE uses for TACACS+ authentication. Explicitly specify the primary TACACS+ server; otherwise, the SE makes its own decision. You can configure one primary TACACS+ server and two backup TACACS+ servers. TACACS+ uses the standard port (port 49) for communication, based on the specified service.
TACACS+ key	Secret key that the SE uses to communicate with the TACACS+ server. The maximum number of characters in the TACACS+ key should not exceed 99 printable ASCII characters (except tabs). An empty key string is the default. All leading spaces are ignored; spaces within and at the end of the key string are not ignored. Double quotes are not required even if there are spaces in the key, unless the quotes themselves are part of the key. There is no default.  <b>Tip</b> Make sure that the same TACACS+ key is specified on the TACACS+ server.
TACACS+ timeout interval	Number of seconds the SE waits for a response from the specified TACACS+ Authentication Server before declaring a timeout. The range is 1 to 20 seconds. The default value is 5 seconds.
TACACS+ retransmit count	Number of times the SE retransmits its connection to the TACACS+ if the TACACS+ timeout interval is exceeded. The range is one to three attempts. The default value is two attempts.
TACACS+ password authentication method	Mechanism for password authentication. By default, the Password Authentication Protocol (PAP) is the mechanism for password authentication. The other option is to use ASCII cleartext as the password authentication mechanism.

#### TACACS+ Enable Password Attribute

The CLI EXEC mode is used for setting, viewing, and testing system operations. It is divided into two access levels, user and privileged. To access privileged-level EXEC mode, enter the **enable** EXEC command at the user access level prompt and specify a privileged EXEC password (superuser or admin-equivalent password) when prompted for a password.

In TACACS+, an enable password feature allows an administrator to define a different enable password per administrative-level user. If an administrative-level user logs in to the SE with a normal-level user account (privilege level of 0) instead of an admin or admin-equivalent user account (privilege level of 15), that user must enter the admin password in order to access privileged-level EXEC mode. This requirement applies even if these users are using TACACS+ for login authentication.

```
ServiceEngine> enable
Password:
```

## Examples

The following example shows how to enable local and TACACS+ authentication and authorization, setting TACACS+ as the first method used and local as the secondary method to use if TACACS+ fails:

```
ServiceEngine(config)# authentication login tacacs enable primary
ServiceEngine(config)# authentication login local enable secondary
ServiceEngine(config)# authentication configuration local enable secondary
ServiceEngine(config)# authentication configuration tacacs enable primary
```

The following example shows the output of the **show authentication user** command:

```
ServiceEngine# show authentication user
Login Authentication: Console/Telnet Session
-----
local enabled (secondary)
radius disabled
tacacs enabled (primary)
Configuration Authentication: Console/Telnet Session
-----
local enabled (secondary)
radius disabled
tacacs enabled (primary)
Configuration Authentication: Console/Telnet Session
-----
local enabled (secondary)
radius enabled (tertiary)
tacacs enabled (primary)
```

The following example shows the output of the **show authentication user** command:

```
ServiceEngine# show authentication user
Login Authentication: Console/Telnet/Ftp/SSH Session
-----
local disabled
Radius disabled
Tacacs+ disabled

Configuration Authentication: Console/Telnet/Ftp/SSH Session
-----
local disabled
Radius disabled
Tacacs+ disabled
```

The following example shows the output of the **show statistics authentication** command:

```
ServiceEngine# show statistics authentication
Authentication Statistics
-----
Number of access requests: 37
Number of access deny responses: 14
Number of access allow responses: 23
```

The following example shows how to enable local, TACACS+, and RADIUS authentication and authorization, setting TACACS+ as the first method used, local as the secondary method if the TACACS+ method fails, and RADIUS as the tertiary method if both local and TACACS+ fail:

```
ServiceEngine(config)# authentication login tacacs enable primary
ServiceEngine(config)# authentication login local enable secondary
ServiceEngine(config)# authentication login radius enable tertiary
ServiceEngine(config)# authentication configuration tacacs enable primary
ServiceEngine(config)# authentication configuration local enable secondary
ServiceEngine(config)# authentication configuration radius enable tertiary
```

#### Related Commands

Command	Description
<b>radius-server</b>	Configures the RADIUS authentication.
<b>show authentication</b>	Displays the authentication configuration.
<b>show statistics authentication</b>	Displays the authentication statistics.
<b>username</b>	Establishes the username authentication.

# authentication-check

To enable the checking of received packets on the corresponding level, use the **authentication-check** command in Intermediate System -to-Intermediate System (IS-IS) configuration mode. To disable the checking of received packets, use the **no** form of this command.

**authentication-check {level-1 | level-2}**

**no authentication-check**

**Note**

This command is only available on Cisco Internet Streamer CDS Release 2.5.3 software.

**Syntax Description**

<b>level-1</b>	Specifies authentication type for level-1 LSP, CSNP and PSNP.
<b>level-2</b>	Specifies authentication type for level-2 LSP, CSNP and PSNP.

**Command Defaults**

The default is On.

**Command Modes**

IS-IS configuration (config-isis) mode.

**Usage Guidelines**

This command enables and disables the checking of received packets on the corresponding level. When authentication-check is disabled, IS-IS adds authentication to the outgoing packets, but does not check authentication on incoming packets. This feature allows smooth transition of enabling authentication without disrupting the network operation.

**Examples**

The following example shows how to disable the checking of packets on a level-1:

```
ServiceRouter# configure
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# no authentication-check level-1
ServiceRouter(config-isis)#
```

**Related Commands**

Command	Description
<b>authentication key-chain</b>	Specifies the key chain to be used for the authentication for the corresponding level.
<b>authentication-type</b>	Specifies the cleartext or MD5 authentication for the corresponding level.

# authentication key-chain

To specify the key chain to be used for the authentication for the corresponding level, use the **authentication key-chain** command in IS-IS configuration mode. To disable the authentication, use the **no** form of this command.

**authentication key-chain** *name* {**level-1** | **level-2**}

**no authentication key-chain** *name* {**level-1** | **level-2**}



## Note

This command is only available on Cisco Internet Streamer CDS Release 2.5.3 software.

## Syntax Description

<i>name</i>	Authentication key chain name.
<b>level-1</b>	Specifies authentication type for level-1 LSP, CSNP and PSNP.
<b>level-2</b>	Specifies authentication type for level-2 LSP, CSNP and PSNP.

## Command Defaults

None

## Command Modes

IS-IS configuration (config-isis) mode.

## Usage Guidelines

If no key chain is configured with the **authentication key-chain** command, no key chain authentication is performed. Key chain authentication can apply to cleartext authentication or MD5 authentication. The mode is determined by the authentication mode command.

Only one authentication key chain is applied to IS-IS at one time. For example, if you configure a second authentication key-chain command, the first authentication key chain is overridden. You can specify authentication for an individual IS-IS interface by using the **isis authentication key-chain** command.

This command requires the Proximity Engine license.

A key chain string cannot exceed 63 characters.

## Examples

The following example shows how to specify MD5 authentication for a level 1:

```
ServiceRouter# configure
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# authentication key-chain my-key level-1
ServiceRouter(config-isis)#
```

## Related Commands

Command	Description
<b>authentication-check</b>	Enables the checking of received packets on the corresponding level.
<b>authentication-type</b>	Specifies the cleartext or MD5 authentication for the corresponding level.

# authentication-type

To specify the cleartext or MD5 authentication for the corresponding level, use the **authentication-type** command in IS-IS configuration mode. To disable the authentication, use the **no** form of this command.

**authentication-type {cleartext {level-1 | level-2} | md5 {level-1 | level-2}}**

**no authentication-type {cleartext {level-1 | level-2} | md5 {level-1 | level-2}}**



## Note

This command is only available on Cisco Internet Streamer CDS Release 2.5.3 software.

## Syntax Description

<b>cleartext</b>	Specifies cleartext authentication.
<b>md5</b>	Specifies HMAC-MD5 authentication.
<b>level-1</b>	Specifies authentication type for level-1 LSP, CSNP and PSNP.
<b>level-2</b>	Specifies authentication type for level-2 LSP, CSNP and PSNP.

## Command Defaults

None

## Command Modes

IS-IS configuration (config-isis) mode.

## Usage Guidelines

You can specify the type of authentication and the level to which it applies for a single IS-IS interface, rather than per IS-IS instance, by using the **authentication-type** command.

You can specify authentication type for an individual IS-IS interface by using the **isis authentication-type {cleartext | md5} [level-1 | level-2] interface configuration mode** command.

This command requires the Proximity Engine license.

## Examples

The following example shows how to specify MD5 authentication for a level 1:

```
ServiceRouter# configure
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# authentication-type md5 level-1
ServiceRouter(config-isis)#
```

## Related Commands

Command	Description
<b>authentication-check</b>	Enables the checking of received packets on the corresponding level.
<b>authentication key-chain</b>	Specifies the key chain to be used for the authentication for the corresponding level.

# authsvr

To enable and configure the Authorization server, use the **authsvr** command in Global configuration mode. To disable the Authorization server, use the **no** form of this command.

**authsvr** {**enable** | **location-server** {**primary** *ip addr port num* | **secondary** *ip addr port num*} | **unknown-server allow**}

**no authsvr** {**enable** | **location-server** {**primary** *ip addr port num* | **secondary** *ip addr port num*} | **unknown-server allow**}

## Syntax Description

<b>enable</b>	Enables the Authorization server.
<b>location-server</b>	Configures the geo location server IP address and port.
<b>primary</b>	Configures the primary geo location server IP address and port.
<i>ip addr</i>	IP address of the primary geo location server.
<i>port num</i>	Port number of the primary geo location server.
<b>secondary</b>	Configures the secondary geo location server IP address and port.
<i>ip addr</i>	IP address of the secondary geo location server.
<i>port num</i>	Port number of the secondary geo location server.
<b>unknown-server</b>	Configures the Authorization server unknown server or domain.
<b>allow</b>	Allows requests for an unknown server or domain.

## Command Defaults

**authsvr**: enabled  
**unknown-server**: blocked

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

Changing the primary or secondary Geo-Location server configuration requires a restart of the authsvr for the configuration change to take effect. To restart the authsvr, disable it by entering the **no authsvr enable** and then re-enable it by entering the **authsvr enable** command.

## Examples

The following example shows how to enable the Authorization server:

```
ServiceEngine(config)# authsvr enable
Authserver is enabled
```



**Related Commands**

Command	Description
<b>debug authsvr</b>	Debugs the Authentication Server.
<b>debug authsvr error</b>	Sets the debug level to error.
<b>debug authsvr trace</b>	Sets the debug level to trace.
<b>show statistics authsvr</b>	Displays the Authentication Server statistics.

## bandwidth (Global configuration)

To set an allowable bandwidth usage limit and its duration for Cisco Streaming Engine Windows Media Technology (WMT) streaming media, use the **bandwidth** command in Global configuration mode. To remove individual options, use the **no** form of this command.

```
bandwidth {movie-streamer {incoming bandwidth | outgoing bandwidth {default |
```

```
    max-bandwidth start-time day hour end-time day hour } } | wmt {incoming bandwidth |
```

```
    outgoing bandwidth } }
```

```
no bandwidth {movie-streamer {incoming bandwidth | outgoing bandwidth {default |
```

```
    max-bandwidth start-time day hour end-time day hour } } | wmt {incoming bandwidth |
```

```
    outgoing bandwidth } }
```

### Syntax Description

<b>movie-streamer</b>	Configures the maximum pacing bit rate, in kilobits per second (kbps), for the Movie Streamer.
<b>incoming</b>	Configures the duration of allowable incoming bandwidth settings for WMT.
<i>bandwidth</i>	Bandwidth size for the Movie Streamer, in kbps. The range is from 0 to 2147483647.
<b>outgoing</b>	Configures the duration of allowable outgoing bandwidth settings for WMT.
<b>default</b>	Specifies the default value for bandwidth if the scheduled bandwidth is not configured.
<b>max-bandwidth</b>	Specifies the maximum value of bandwidth, in kbps.
<b>start-time</b>	Specifies the start time for this bandwidth setting.
<i>day</i>	Day of the week.
<i>hour</i>	Time to start (hh:mm) (00 to 23:00 to 59)
<b>end-time</b>	Specifies the end time for this bandwidth setting.
<b>wmt</b>	Configures the duration of allowable bandwidth settings for WMT. For more information, see the <a href="#">“Configuring Incoming and Outgoing WMT Bandwidth”</a> section on page 2-51.

### Command Defaults

None

### Command Modes

Global configuration (config) mode.

### Usage Guidelines

With the various types of traffic originating from a device, every type of traffic, such as streaming media, HTTP, and metadata, consumes network resources. Use the **bandwidth** command to limit the amount of network bandwidth used by the WMT streaming media.

The content services bandwidth includes the bandwidth allocation for WMT. WMT bandwidth settings apply to WMT streaming of live, cached, and prepositioned content.

For each type of bandwidth, you can specify the amount of bandwidth to be used for a particular time period. This type is called *scheduled bandwidth*. The *default bandwidth* is the amount of bandwidth associated with each content service type when there is no scheduled bandwidth. In centrally managed deployments (the SEs are registered with a CDSM), if the SE is assigned to a device group and no default bandwidth has been configured for the SE itself, the device group default bandwidth settings are applied. However, if the default bandwidth has been configured for the SE, then that setting overrides the device group settings. If the SE is a member of multiple device groups, the most recently updated default bandwidth settings are applied.

The *maximum bandwidth* specifies the upper limit for the allowable bandwidth. The total bandwidth configured for all content services must not exceed the bandwidth limits specified for any SE platform model in the Internet Streamer CDS network. In addition, the license keys configured for WMT further restrict the maximum bandwidth available for each SE model.

### Configuring Incoming and Outgoing WMT Bandwidth

The bandwidth between the WMT proxy server (the SE) and the WMT client is called the *WMT outgoing bandwidth*.

The bandwidth between the WMT proxy and the origin streaming server is called the *incoming bandwidth*. Because the bandwidth from the edge to the outside IP WAN is limited, you must specify a per session limit (the maximum bit rate per request) for each service that is running on the SE and that consumes the incoming bandwidth (for example, the WMT streaming service), and an aggregate limit (the maximum incoming bandwidth.) You need to control the outgoing bandwidth based on the WMT license that is configured on the SE.

The **bandwidth wmt outgoing** and **bandwidth incoming** commands enable you to specify a WMT incoming and an outgoing bandwidth as follows:

- Use the **bandwidth wmt outgoing** *kbits* command in Global configuration mode to specify the outgoing WMT bandwidth in kbps. This command sets the maximum bandwidth for the WMT content that can be delivered to a client that is requesting WMT content. The range of values is between 0 and 2,147,483,647 kbps.

If the specified outgoing bandwidth is above the limit specified by the WMT license, then a warning message is displayed. However, the specified outgoing bandwidth setting is applied to the SE because the outgoing bandwidth may be configured before the WMT licenses are enabled or an enabled WMT license may be changed to a higher value at a later time.

- Use the **bandwidth wmt incoming** *kbits* command in Global configuration mode to specify the incoming WMT bandwidth in kbps. This command sets the maximum bandwidth for the WMT content that can be delivered to the SE from the origin streaming server or another SE in the case of a cache miss. The specified bit rate is the maximum incoming WMT per session bit rate. The range of values is between 0 and 2,147,483,647 kbps. The incoming bandwidth applies to VoD content from the origin server for a cache miss.

**bandwidth (Global configuration)**

Related Commands	Command	Description
	<b>bandwidth</b> (interface configuration)	Sets the specified interface bandwidth to 10, 100, or 1000 Mbps.
	<b>interface</b>	Configures a Gigabit Ethernet or port channel interface. Provides access to interface configuration mode.
	<b>show bandwidth</b>	Displays the bandwidth allocated to a particular device.
	<b>show interface</b>	Displays the hardware interface information.
	<b>show running-config</b>	Displays the current operating configuration.
	<b>show startup-config</b>	Displays the startup configuration.

## bandwidth (interface configuration)

To configure an interface bandwidth, use the **bandwidth** command in interface configuration mode. To restore default values, use the **no** form of this command.

**bandwidth {10 | 100 | 1000}**

**no bandwidth {10 | 100 | 1000}**

Syntax Description	10	Sets the bandwidth to 10 megabits per second (Mbps).
	100	Sets the bandwidth to 100 Mbps.
	1000	Sets the bandwidth to 1000 Mbps. This option is not available on all ports.

Command Defaults	None
------------------	------

Command Modes	Interface configuration (config-if) mode.
---------------	---

**Usage Guidelines**

The bandwidth is specified in Mbps. The **1000** Mbps option is not available on all ports. On an SE model that has an optical Gigabit Ethernet interface, you cannot change the bandwidth of this interface. Therefore, Gigabit Ethernet interfaces run only at 1000 Mbps. For newer models of the SE that have a Gigabit Ethernet interface over copper, this restriction does not apply; you can configure these Gigabit Ethernet interfaces to run at 10, 100, or 1000 Mbps.

You can configure the Gigabit Ethernet interface settings (bandwidth, and duplex settings) if the Gigabit-over-copper-interface is up or down. If the interface is up, it applies the specific interface settings. If the interface is down, the specified settings are stored and then applied when the interface is brought up. For example, you can specify any of the following commands for a Gigabit-over-copper-interface, which is currently down, and have these settings automatically applied when the interface is brought up:

```
ServiceEngine(config-if)# bandwidth 10
ServiceEngine(config-if)# bandwidth 100
ServiceEngine(config-if)# bandwidth 1000
```

You cannot configure the Gigabit Ethernet interface settings on an optical Gigabit Ethernet interface.

**Examples**

The following example shows how to set an interface bandwidth to 10 Mbps:

```
ServiceEngine(config-if)# bandwidth 10
```

The following example shows how to restore default bandwidth values on an interface:

```
ServiceEngine(config-if)# no bandwidth
```

■ bandwidth (interface configuration)

Related Commands

Command	Description
<b>interface</b>	Configures a Gigabit Ethernet or port channel interface. Provides access to interface configuration mode.

# banner

To configure the EXEC, login, and message-of-the-day (MOTD) banners, use the **banner** command in Global configuration mode. To disable the banner feature, use the **no** form of this command.

```
banner {enable | exec {message line | message_text} | login {message line | message_text} | motd
{message line | message_text} }
```

```
no banner {enable | exec [message] | login [message] | motd [message] }
```

## Syntax Description

<b>enable</b>	Enables banner support on the SE.
<b>exec</b>	Configures an EXEC banner.
<b>message</b>	Specifies a message to be displayed when an EXEC process is created.
<i>line</i>	EXEC message text on a single line. The SE translates the \n portion of the message to a new line when the EXEC banner is displayed to the user.
<i>message_text</i>	EXEC message text on one or more lines. Press the <b>Return</b> key or enter delimiting characters (\n) to specify an EXEC message to appear on a new line. Supports up to a maximum of 980 characters, including new line characters (\n). Enter a period (.) at the beginning of a new line to save the message and return to the prompt for the Global configuration mode.  <b>Note</b> The EXEC banner content is obtained from the command-line input that the user enters after being prompted for the input.
<b>login</b>	Configures a login banner.
<b>message</b>	Specifies a message to be displayed before the username and password login prompts.
<i>line</i>	Login message text on a single line. The SE translates the \n portion of the message to a new line when the login banner is displayed to the user.
<i>message_text</i>	Login message text on one or more lines. Press the <b>Return</b> key or enter delimiting characters (\n) to specify a login message to appear on a new line. Supports up to a maximum of 980 characters, including new line characters (\n). Enter a period (.) at the beginning of a new line to save the message and return to the prompt for the Global configuration mode.  <b>Note</b> The login banner content is obtained from the command-line input that the user enters after being prompted for the input.
<b>motd</b>	Configures an MOTD banner.
<b>message</b>	Specifies an MOTD message.
<i>line</i>	MOTD message text on a single line. The SE translates the \n portion of the message to a new line when the MOTD banner is displayed to the user.
<i>message_text</i>	MOTD message text on one or more lines. Press the <b>Return</b> key or enter delimiting characters (\n) to specify an MOTD message to appear on a new line. Supports up to a maximum of 980 characters, including new-line characters (\n). Enter a period (.) at the beginning of a new line to save the message and return to the prompt for the Global configuration mode.  <b>Note</b> The MOTD banner content is obtained from the command line input that the user enters after being prompted for the input.

**Command Defaults**

Banner support is disabled by default.

**Command Modes**

Global configuration (config) mode.

**Usage Guidelines**

You can configure the following three types of banners in any Internet Streamer CDS software device mode:

- MOTD banner sets the message of the day. This message is the first message that is displayed when a login is attempted.
- Login banner is displayed after the MOTD banner but before the actual login prompt appears.
- EXEC banner is displayed after the EXEC CLI shell has started.

**Note**

All these banners are effective on a console, Telnet, or a Secure Shell (SSH) Version 2 session.

After you configure the banners, enter the **banner enable** command to enable banner support on the SE. Enter the **show banner** command in EXEC configuration mode to display information about the configured banners.

**Note**

When you run an SSH Version 1 client and log in to the SE, the MOTD and login banners are not displayed. You need to use SSH Version 2 to display the banners when you log in to the SE.

**Examples**

The following example shows how to enable banner support on the SE:

```
ServiceEngine(config)# banner enable
```

The following example shows how to use the **banner motd message** command to configure the MOTD banner. In this example, the MOTD message consists of a single line of text.

```
ServiceEngine(config)# banner motd message This is an Internet Streamer CDS 2.3 device
```

The following example shows how to use the **banner motd message** global command to configure a MOTD message that is longer than a single line. In this case, the SE translates the \n portion of the message to a new line when the MOTD message is displayed to the user.

```
ServiceEngine(config)# banner motd message "This is the motd message.
\nThis is an Internet Streamer CDS 2.3 device\n"
```

The following example shows how to use the **banner login message** command to configure a MOTD message that is longer than a single line. In this case, SE A translates the \n portion of the message to a new line in the login message that is displayed to the user.

```
ServiceEngine(config)# banner login message "This is login banner.
\nUse your password to login\n"
```



The following example shows how to use the **banner exec** command to configure an interactive banner. The **banner exec** command is similar to the **banner motd message** commands except that for the **banner exec** command, the banner content is obtained from the command-line input that the user enters after being prompted for the input.

```
ServiceEngine(config)# banner exec
Please type your MOTD messages below and end it with '.' at beginning of line:
(plain text only, no longer than 980 bytes including newline)
This is the EXEC banner.\nUse your Internet Streamer CDS username and password to log in
to this SE.\n
.
Message has 99 characters.
ServiceEngine(config)#
```

Assume that the SE has been configured with the MOTD, login, and EXEC banners as shown in the previous examples. When a user uses an SSH session to log in to the SE, the user sees a login session that includes a MOTD banner and a login banner that asks the user to enter a login password as follows:

```
This is the motd banner.
This is an Internet Streamer CDS 2.3 device
This is login banner.
Use your password to login.
```

```
Cisco SE
```

```
admin@ce's password:
```

After the user enters a valid login password, the EXEC banner is displayed, and the user is asked to enter the Internet Streamer CDS username and password as follows:

```
Last login: Fri Oct 1 14:54:03 2004 from client
System Initialization Finished.
This is the EXEC banner.
Use your Internet Streamer CDS username and password to log in to this SE.
```

After the user enters a valid Internet Streamer CDS username and password, the SE CLI is displayed. The CLI prompt varies depending on the privilege level of the login account. In the following example, because the user entered a username and password that had administrative privileges (privilege level of 15), the EXEC configuration mode CLI prompt is displayed:

```
ServiceEngine#
```

#### Related Commands

Command	Description
<b>show banner</b>	Enables banner support on the SE.

# bitrate

To configure the maximum pacing bit rate for large files for the Movie Streamer and to separately configure WMT bit-rate settings, use the **bitrate** command in Global configuration mode. To remove the bit-rate settings, use the **no** form of this command.

**bitrate** {**movie-streamer** *bitrate* | **wmt** {**incoming** *bitrate* | **outgoing** *bitrate*} }

**no bitrate** {**movie-streamer** *bitrate* | **wmt** {**incoming** | **outgoing**} }

## Syntax Description

<b>movie-streamer</b>	Configures the maximum pacing bit rate, in kbps, for the Movie Streamer.
<i>bitrate</i>	Bit rate in kbps. The range is from 1 to 2147483647.
<b>wmt</b>	Configures the bit rate, in kbps, for large files sent using the WMT protocol.
<b>incoming</b>	Sets the incoming bit-rate settings.
<i>bitrate</i>	Incoming bit rate, in kbps. The range is from 0 to 2147483647.
<b>outgoing</b>	Sets the outgoing bit-rate settings.
<i>bitrate</i>	Outgoing bit rate, in kbps. The range is from 0 to 2147483647.

## Command Defaults

**movie-streamer** *bitrate*: 1500 kbps

**wmt incoming** *bitrate*: 0 (no limit)

**wmt outgoing** *bitrate*: 0 (no limit)

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

The Internet Streamer CDS 2.x software includes the WMT proxy, which has the ability to cache on-demand media files when the user requests these files for the first time. All subsequent requests for the same file are served by the WMT proxy using the RTSP protocol. The WMT proxy can also live-split a broadcast, which causes only a single unicast stream to be requested from the origin server in response to multiple client requests for the stream.

The bit rate between the proxy and the origin server is called the *incoming bit rate*. Use the **bitrate** command to limit the maximum bit rate per session for large files. The **bitrate wmt incoming** and **bitrate wmt outgoing** commands enable you to specify a WMT incoming and outgoing per session bit rate as follows:

- Use the **bitrate wmt incoming** *bitrate* command to specify the maximum incoming streaming bit rate per session that can be delivered to the WMT proxy server (the SE) from the origin streaming server or another SE in the case of a cache miss. The specified bit rate is the maximum incoming WMT per session bit rate. The range of values is between 0 and 2,147,483,647 kbps. The default value is 0 (no bit-rate limit).
- Use the **bitrate wmt outgoing** *bitrate* command to set the maximum outgoing streaming bit rate per session that can be delivered to a client requesting WMT content. The specified bit rate is the maximum outgoing WMT per session bit rate. The range of values is between 0 and 2,147,483,647 kbps. The default value is 0 (no bit-rate limit). The outgoing bandwidth applies to VoD content from the WMT proxy server on the SE in the case of a cache miss.

**Note**

The aggregate bandwidth used by all concurrent users is still limited by the default device bandwidth or by the limit configured using the **bandwidth** command.

**Variable WMT Bit Rates**

A content provider can create streaming media files at different bit rates to ensure that different clients who have different connections—for example, modem, DSL, or LAN—can choose a particular bit rate. The WMT caching proxy can cache multiple bit-rate files or variable bit-rate (VBR) files, and based on the bit rate specified by the client, it serves the appropriate stream. Another advantage of creating variable bit-rate files is that you only need to specify a single URL for the delivery of streaming media.

**Note**

In the case of multiple bit-rate files, the SE that is acting as the WMT proxy server retrieves only the bit rate that the client has requested.

**Examples**

The following example shows how to configure an incoming bit rate for the Movie Streamer:

```
ServiceEngine(config)# bitrate movie-streamer incoming 100
```

The following example shows how to configure an incoming bit rate for a file sent using WMT. Use the **show wmt** command to verify that the incoming bit rate has been modified.

```
ServiceEngine(config)# bitrate wmt incoming 300000
ServiceEngine(config)# exit
ServiceEngine# show wmt
----- WMT Server Configurations -----
WMT is enabled
WMT disallowed client protocols: none
WMT bandwidth platform limit: 1000000 Kbits/sec
WMT outgoing bandwidth configured is 500000 Kbits/sec
WMT incoming bandwidth configured is 500000 Kbits/sec
WMT max sessions configured: 14000
WMT max sessions platform limit: 14000
WMT max sessions enforced: 14000 sessions
WMT max outgoing bit rate allowed per stream has no limit
WMT max incoming bit rate allowed per stream has no limit
WMT cache is enabled
WMT cache max-obj-size: 25600 MB
WMT cache revalidate for each request is not enabled
WMT cache age-multiplier: 30%
WMT cache min-ttl: 60 minutes
WMT cache max-ttl: 1 days
WMT debug client ip not set
WMT debug server ip not set
WMT accelerate live-split is enabled
WMT accelerate proxy-cache is enabled
WMT accelerate VOD is enabled
WMT fast-start is enabled
WMT fast-start max. bandwidth per player is 3500 (Kbps)
WMT fast-cache is enabled
WMT fast-cache acceleration factor is 5
WMT maximum data packet MTU (TCP) enforced is 1472 bytes
WMT maximum data packet MTU (UDP) is 1500 bytes
WMT client idle timeout is 60 seconds
WMT forward logs is enabled
WMT server inactivity-timeout is 65535
WMT Transaction Log format is Windows Media Services 4.1 logging
RTSP Gateway incoming port 554
```

```

----- WMT HTTP Configurations -----
WMT http extensions allowed:
asf none nsc wma wmv nsclog

----- WMT Proxy Configurations -----
Outgoing Proxy-Mode:
-----
MMS-over-HTTP Proxy-Mode:
is not configured.
RTSP Proxy-Mode:
is not configured. ServiceEngine#

```

**Related Commands**

Command	Description
<b>show wmt</b>	Displays the WMT configuration.

# bootstrap-node

To configure a bootstrap node IP address, use the **bootstrap-node** Service Routing Protocol (SRP) configuration command.

To remove a bootstrap node address, use the **no** or **default** form of the command.

**bootstrap-node** *ip-address*

**[no | default] bootstrap-node** *ip-address*

## Syntax Description

<i>ip-address</i>	Valid IP address for the bootstrap node. IP addresses 0.0.0.0 and 255.255.255.255 are not valid addresses for a bootstrap node.
-------------------	---

## Command Defaults

No bootstrap node address is configured.

## Command Modes

SRP configuration (config-srp) mode.

## Usage Guidelines

This command is used to set bootstrap nodes for an SRP. A Proximity Engine specifies one or more bootstrap nodes to join a DHT network. In a DHT network, the domain ID of the bootstrap nodes and the Proximity Engine must be the same.

The first Proximity Engine in the network, which acts as the bootstrap node for others, does not have to configure the bootstrap node address itself. This is the only exception to configuring bootstrap nodes. All other nodes need to configure a bootstrap node address before they can join any network.

The **no** and **default** forms of the command remove a given bootstrap node from the list of available bootstrap nodes of a Proximity Engine. The port number for bootstrap node is 9000. The **show srp process** command lists configured bootstrap nodes.

A Proximity Engine cannot be its own bootstrap node. A maximum 25 bootstrap nodes are allowed.

## Examples

The following example shows how to configure a bootstrap node address with the **bootstrap-node** command.

```
ServiceRouter# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ServiceRouter(config)# router srp
ServiceRouter(config-srp)# bootstrap-node 192.168.6.91
ServiceRouter(config-srp)# end
ServiceRouter#
```

The following example shows how the **show srp process** command displays configured bootstrap nodes:

```
ServiceRouter# show srp process

Process:
  Domain: 0
  Node Id: 6b05858ab28345e62e9e614a48e1206445ec9ca0884fa0e827c1072f5fe8c5f5
  Port: 9000
  Interfaces running SRP:
```

■ bootstrap-node

```

      *GigabitEthernet 1/0
Database Mirroring: Disabled
  # of storages requested for mirroring: 2
  # of storages used for mirroring      : 1
...

ServiceRouter#

```

**Related Commands**

Command	Description
<b>domain</b>	Sets the domain ID for the SRP.
<b>router srp</b>	Enters SRP configuration mode.
<b>show srp process</b>	Displays the basic configurations for SRP.

# cache

To restrict the maximum number of contents in the CDS, use the **cache** command in Global configuration mode.

**cache content max-cached-entries** *num*

## Syntax Description

<b>content</b>	Browses the CDNFS directories and files.
<b>max-cached-entries</b>	Cleans up the unwanted entries in the CDNFS.
<i>num</i>	Max cached entries. The range is from 1 to 10000000.

## Command Defaults

The max-cached-entries default is 3000000 entries.

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

The ucache process, also known as the cache content manager, manages the caching, storage, and deletion of content.

Previously, the Internet Streamer CDS software did not restrict adding new content to CDNFS as long as there was enough disk space for the asset. The cache content max-cached-entries command restricted the number of assets, but it was not a hard limit. New content was always added and the CDS would delete old content in attempt to keep within the limits configured. The CDS could actually have more content than the configured limit, because the process to delete content is slower than the process to add content. The same situation applies to disk-usage based deletion, where deletion occurs when 90 percent of the CDNFS is used.

In Cisco Internet Streamer CDS Release 2.5.9-b126 software, content addition is stopped at 105 percent of the maximum object count or 95 percent of the CDNFS capacity (disk usage). For example, if the maximum number of objects has been configured as 3,000,000 (which is the default value), the CDS starts deleting content if the object count reaches 3,000,000, but adding content is still allowed. Adding content stops when the maximum number of content objects reaches 3,150,000 (105 percent of 3,000,000), which allows time for the content deletion process to reduce the number of objects in the CDS to the configured limit. Adding content resumes only after the number of objects is 3,000,000 or less. The same logic applies to disk usage. The deletion process starts when disk usage reaches 90 percent, adding content stops when disk usage reaches 95 percent, and adding content resumes only after the disk usage percentage reaches 90 percent or less.

If adding content has been stopped because either the content count reached 105 percent of the limit or the disk usage reached 95 percent of capacity, a UCACHE BUSY error message is sent to the Web Engine, Windows Media Streaming, or Movie Streamer, and the protocol engine performs a cut-through or a bypass.



### Note

When the CDS is just started or the ucache process (which is the cache content manager) is just restarted, it performs a scan of the entire CDNFS. During this period, the deletion starts at 94 percent (not 90 percent) and adding content stops at 95 percent.

**Examples**

The following example shows how to configure the cache content:

```
ServiceEngine# cache content max-cached-entries 1000
```

The **show cdnfs usage** command shows the current status of whether the content is able to be cached or not. Following is an example of the output:

```
# show cdnfs usage
Total number of CDNFS entries : 2522634
Total space : 4656.3 GB
Total bytes available : 4626.0 GB
Total cache size : 2.4 GB
Total cached entries : 2522634
Cache-content mgr status : Cachable
Units: 1KB = 1024B; 1MB = 1024KB; 1GB = 1024MB
```

If the maximum object count is reached, the following is displayed:

```
Cache-content mgr status : caching paused[ max count 105% of configured reached ]
```

If the disk usage reaches more than 95 percent, the following is displayed:

```
Cache-content mgr status : caching paused[ disk max 95% of disk usage reached ]
```

**Note**

When the CDS is just started or the ucache process (which is cache content manager) is just restarted, it performs a scan of the entire CDNFS. During this period, the deletion starts at 94 percent (not 90 percent) and adding content stops at 95 percent.

**Related Commands**

Command	Description
<b>show cache</b>	Displays a list of cached contents.



# capability

To modify the capability configuration, use the **capability** command in Global configuration mode. To disable capability, use the **no** form of this command.

**capability config profile** *number* [**add attrib** { **capability-url** *url* | **user-agent** *name* } | **description**]

**no capability config**

## Syntax Description

<b>config</b>	Enters the capability exchange submode.
<b>profile</b>	Populates the profile database.
<i>number</i>	The profile ID. The range is from 1 to 65535.
<b>add</b>	(Optional) Adds the capability attributes.
<b>attrib</b>	Adds the capability attributes.
<b>capability-url</b>	Specifies the capability URL.
<i>url</i>	The capability URL string.
<b>user-agent</b>	Specifies the user-agent.
<i>name</i>	The user-agent name.
<b>description</b>	(Optional) Specifies the profile description.

## Command Defaults

None

## Command Modes

Global configuration (config) mode.

## Related Commands

Command	Description
<b>show capability</b>	Displays information for the Cap-X profile ID.

# cd

To change from one directory to another directory, use the **cd** command in EXEC configuration mode.

**cd** *directoryname*

<b>Syntax Description</b>	<i>directoryname</i>	Directory name.
---------------------------	----------------------	-----------------

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

<b>Usage Guidelines</b>	Use this command to maneuver between directories and for file management. The directory name becomes the default prefix for all relative paths. Relative paths do not begin with a slash (/). Absolute paths begin with a slash (/).
-------------------------	--

<b>Examples</b>	<p>The following example shows how to use a relative path:</p> <pre>ServiceEngine(config)# <b>cd local1</b></pre> <p>The following example shows how to use an absolute path:</p> <pre>ServiceEngine(config)# <b>cd /local1</b></pre>
-----------------	---

<b>Related Commands</b>	Command	Description
	<b>deltree</b>	Deletes a directory and its subdirectories.
	<b>dir</b>	Displays the files in a long list format.
	<b>lls</b>	Displays the files in a long list format.
	<b>ls</b>	Lists the files and subdirectories in a directory.
	<b>mkdir</b>	Makes a directory.
	<b>pwd</b>	Displays the present working directory.

# cdn-select

To enable the CDN Selector for third-party service selection, use the **cdn-select** command in Global configuration mode. To disable the CDN Selector, use the **no** form of this command.

**cdn-select enable**

**no cdn-select enable**

Syntax Description	<table><tr><td>enable</td><td>Enables the CDN Selector.</td></tr></table>		enable	Enables the CDN Selector.
enable	Enables the CDN Selector.			
Command Defaults	None			
Command Modes	Global configuration (config) mode.			
Usage Guidelines	The <b>cdn-select</b> command enables the CDN Selector, which provides a method to do third-party service selection based on parameters like content type and geographic location.			
Examples	The following example shows how to enable the CDN Selector:  ServiceRouter(config)# <b>cdn-select enable</b> ServiceRouter(config)#			
	The following example shows how to disable the CDN Selector:  ServiceRouter(config)# <b>no cdn-select enable</b> ServiceRouter(config)#			
Related Commands	Command	Description		
	geo-location-server	Redirects requests to different Content Delivery Networks based on the geographic location of the client.		
	show cdn-select	Displays the status of the CDN Selector.		
	show statistics cdn-select	Displays the statistics for the CDN Selector.		

# cdnfs

To manage the Internet Streamer CDS network file system (CDNFS), use the **cdnfs** command in EXEC configuration mode.

**cdnfs {browse | cleanup {info | start {force} | stop} database recover}**

## Syntax Description

<b>browse</b>	Browses the CDNFS directories and files.
<b>cleanup</b>	Cleans up the unwanted entries in the CDNFS.
<b>info</b>	Summarizes the information about unwanted entries without starting the cleanup process.
<b>start</b>	Starts the cleanup of unwanted entries in the CDNFS.
<b>force</b>	Removes objects that are in transient states.
<b>stop</b>	Stops the cleanup of unwanted entries in the CDNFS.
<b>database</b>	Commands working with the CDNFS database.
	<b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>recover</b>	Recovers the CDNFS database by doing a re-sync of all content.
	<b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Usage Guidelines

The Internet Streamer CDS CDNFS stores the prepositioned Internet Streamer CDS network content to be delivered by all supported protocols. You can configure the CDNFS size of each SE using the **disk configure** command.

The **cdnfs cleanup** command cleans up the content of deleted channels from the acquisition and distribution database. In certain cases, the acquirer is not notified by the Centralized Management System (CMS) about deleted channels, and it fails to clear all unified name space (UNS) content. In such cases, the **cdnfs cleanup** command in EXEC configuration mode can be used to clean up all UNS content associated with deleted channels.



### Note

You can use the **cdnfs cleanup start** command to clean up the orphan content. The orphan content is content that is not associated with any channel to which the SE is subscribed.

The **cdnfs browse** command is an interactive command and has the following subcommands used to view Internet Streamer CDS network files and directories:

```
ServiceEngine# cdnfs browse

----- CDNFS interactive browsing -----
```

```

dir, ls:    list directory contents
cd, chdir:  change current working directory
info:       display attributes of a file
more:       page through a file
cat:        display a file
exit,quit:  quit CDNFS browse shell

/>dir
                               www.gidtest.com/
/>cd www.gidtest.com
/www.gidtest.com/>dir
764 Bytes      index.html
/www.gidtest.com/>info index.html

CDNFS File Attributes:
  Status              3   (Ready)
  File Size            764 Bytes
  Start Time          null
  End Time             null
  Last-modified Time   Sun Sep  9 01:46:40 2001

Internal path to data file:
/disk06-00/d/www.gidtest.com/05/05d201b7ca6fdd41d491eaec7cfc6f14.0.data.html
  note: data file actual last-modified time: Tue Feb 15 00:47:35 2005

/www.gidtest.com/>

```

Because the CDNFS is empty in this example, the **ls** command does not show any results. Typically, if the CDNFS contains information, it lists the websites as directories, and file attributes and content could be viewed using these subcommands.

The **cdnfs cleanup** command synchronizes the state of the acquisition and distribution database with the content stored on the CDNFS. Use this command after replacing a failed disk drive.

The **cdnfs database recover** command must be run when the **cdnfs\_db\_corrupt** alarm is raised. This alarm is raised when the Total Cached entries is more than Total CDNFS entries in the output for the **show cdnfs usage** command:

```

ServiceEngine# show cdnfs usage
Total number of CDNFS entries :      202
Total space                   :    5037.9 GB
Total bytes available         :    5019.5 GB
Total cache size              :      21.0 GB
Total cached entries          :       218
Cache-content mgr status      : Cachable
Units: 1KB = 1024B; 1MB = 1024KB; 1GB = 1024MB

```

This occurs generally when an internal bookkeeping file is corrupted. With the server in the offloading status, enter the **cdnfs database recover** command to remove this inconsistency, then reload the server.

## Examples

The following example shows the output of the **cdnfs cleanup info** command:

```

ServiceEngine# cdnfs cleanup info
Gathering cleanup information. This may take some time....
(Use Ctrl+C or 'cdnfs cleanup stop' to interrupt)
.....

Summary of garbage resource entries found
-----
Number of entries      : 605

```

Size of entries (KB) : 60820911

The following example shows the output for the **cdnfs database recover** command:

```
ServiceEngine# cdnfs database recover
CDNFS database inconsistency issue found.
CDNFS database recovery operation would impact existing and new client sessions.
Recovering database would need device in offloaded state.
Do you want to recover the CDNFS database now (y/n)?
y
Recovering CDNFS database. It may take few minutes.
Please wait...
CDNFS database recovery is complete. Please reload the device now.
ServiceEngine# reload
Proceed with reload?[confirm]yes
Shutting down all services, will timeout in 15 minutes.
reload in progress ..
```

#### Related Commands

Command	Description
<b>show cdnfs</b>	Displays the Internet Streamer CDS network file system information.
<b>show statistics cdnfs</b>	Displays the SE Internet Streamer CDS network file system statistics.

# cdsm

To configure the Content Delivery System (CDSM) IP address to be used for the SEs or SRs, or to configure the role and GUI parameters on a CDSM device, use the **cdsm** command in Global configuration mode. To negate these actions, use the **no** form of this command.

```
cdsm {ip {hostname | ip-address | role {primary | standby} | ui port port-num} }
```

```
no cdsm {ip | role {primary | standby} | ui port}
```

## Syntax Description

<b>ip</b>	Configures the CDSM hostname or IP address.
<i>hostname</i>	Hostname of the CDSM.
<i>ip-address</i>	IP address of the CDSM.
<b>role</b>	Configures the CDSM role to either primary or standby (available only from the CDSM CLI).
<b>primary</b>	Configures the CDSM to be the primary CDSM.
<b>standby</b>	Configures the CDSM to be the standby CDSM.
<b>ui</b>	Configures the CDSM GUI port address (available only from the CDSM CLI).
<b>port</b>	Configures the CDSM GUI port.
<i>port-num</i>	Port number. The range is from 1 to 65535.

## Command Defaults

None

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

You can use the **cdsm ui port** command to change the CDSM GUI port from the standard number 8443 as follows:

```
CDSM(config)# cdsm ui port 35535
```



### Note

The **role** and **ui** options are only available on CDSM devices. Changing the CDSM GUI port number automatically restarts the Centralized Management System (CMS) service if this has been enabled.

The **cdsm ip** command associates the device with the CDSM so that the device can be approved as a part of the network.

After the device is configured with the CDSM IP address, it presents a self-signed security certificate and other essential information, such as its IP address or hostname, disk space allocation, and so forth, to the CDSM.

### Configuring Devices Inside a NAT

In an Internet Streamer CDS network, there are two methods for a device registered with the CDSM (SEs, SRs, or standby CDSM) to obtain configuration information from the primary CDSM. The primary method is for the device to periodically poll the primary CDSM on port 443 to request a configuration update. You cannot configure this port number. The backup method is when the CDSM pushes configuration updates to a registered device as soon as possible by issuing a notification to the registered device on port 443. This method allows changes to take effect in a timelier manner. You cannot configure this port number even when the backup method is being used. Internet Streamer CDS networks do not work reliably if devices registered with the CDSM are unable to poll the CDSM for configuration updates. Similarly, when a receiver SE requests content and content metadata from a forwarder SE, it contacts the forwarder SE on port 443.

All the above methods become complex in the presence of Network Address Translation (NAT) firewalls. When a device (SEs at the edge of the network, SRs, and primary or standby CDSMs) is inside a NAT firewall, those devices that are inside the same NAT use one IP address (the inside local IP address) to access the device and those devices that are outside the NAT use a different IP address (the inside global IP address) to access the device. A centrally managed device advertises only its inside local IP address to the CDSM. All other devices inside the NAT use the inside local IP address to contact the centrally managed device that resides inside the NAT. A device that is not inside the same NAT as the centrally managed device is not able to contact it without special configuration.

If the primary CDSM is inside a NAT, you can allow a device outside the NAT to poll it for `getUpdate` requests by configuring a *static translation* (inside global IP address) for the CDSM's inside local IP address on its NAT, and using this address, rather than the CDSM's inside local IP address, in the **cdsm ip ip-address** command when you register the device to the CDSM. If the SE or SR is inside a NAT and the CDSM is outside the NAT, you can allow the SE or SR to poll for `getUpdate` requests by configuring a static translation (inside global IP address) for the SE or SR's inside local address on its NAT and specifying this address in the Use IP Address field under the NAT Configuration heading in the Device Activation window.



#### Note

Static translation establishes a one-to-one mapping between your inside local address and an inside global address. Static translation is useful when a host on the inside must be accessible by a fixed address from the outside.

### Standby CDSMs

The Cisco Internet Streamer CDS software implements a standby CDSM. This process allows you to maintain a copy of the Internet Streamer CDS network configuration. If the primary CDSM fails, the standby can be used to replace the primary.

For interoperability, when a standby CDSM is used, it must be at the same software version as the primary CDSM to maintain the full CDSM configuration. Otherwise, the standby CDSM detects this status and does not process any configuration updates that it receives from the primary CDSM until the problem is corrected.



#### Note

We recommend that you upgrade your standby CDSM first and then upgrade your primary CDSM. We also recommend that you create a database backup on your primary CDSM and copy the database backup file to a safe place before you upgrade the software.



### Switching a CDSM from Warm Standby to Primary

If your primary CDSM becomes inoperable for some reason, you can manually reconfigure one of your warm standby CDSMs to be the primary CDSM. Configure the new role by using the Global configuration **cdsm role primary** command as follows:

```
ServiceEngine# configure
ServiceEngine(config)# cdsm role primary
```

This command changes the role from standby to primary and restarts the management service to recognize the change.



#### Note

Check the status of recent updates from the primary CDSM. Use the **show cms info** command in EXEC configuration mode and check the time of the last update. To be current, the update time should be between 1 and 5 minutes old. You are verifying that the standby CDSM has fully replicated the primary CDSM configuration. If the update time is not current, check whether there is a connectivity problem or if the primary CDSM is down. Fix the problem, if necessary, and wait until the configuration has replicated as indicated by the time of the last update. Make sure that both CDSMs have the same Coordinated Universal Time (UTC) configured.

If you switch a warm standby CDSM to primary while your primary CDSM is still online and active, both CDSMs detect each other, automatically shut themselves down, and disable management services. The CDSMs are switched to halted, which is automatically saved in flash memory.

### Examples

The following example shows how to configure an IP address and a primary role for a CDSM:

```
CDSM(config)# cdsm ip 10.1.1.1
CDSM(config)# cdsm role primary
```

The following example shows how to configure a new GUI port to access the CDSM GUI:

```
CDSM(config)# cdsm ui port 8550
```

The following example shows how to configure the CDSM as the standby CDSM:

```
CDSM(config)# cdsm role standby
Switching CDSM to standby will cause all configuration settings made on this CDSM
to be lost.
Please confirm you want to continue [ no ] ?yes
Restarting CMS services
```

The following example shows how to configure the standby CDSM with the IP address of the primary CDSM by using the **cdsm ip ip-address** command. This command associates the device with the primary CDSM so that it can be approved as a part of the network.

```
CDSM# cdsm ip 10.1.1.1
```

# clear cache

To clear the HTTP object cache use the **clear** command in EXEC configuration mode.


```
clear cache [all | content 1-1000000 | flash-media-streaming]
```

Syntax Description	all	(Optional) Clears all cached objects.
	content	(Optional) Clears cached content.
	1-1000000	Free space, in MBs.
	flash-media-streaming	Clears the Flash Media Streaming edge server cached content and DVR cached content.

Command Defaults	None
------------------	------

Command Modes	EXEC configuration mode.
---------------	--------------------------

Usage Guidelines	The <b>clear cache</b> command removes all cached contents from the currently mounted cache volumes. Objects being read or written are removed when they stop being busy.
------------------	---

 Caution	This command is irreversible, and all cached content is erased. Cisco does not recommend using this command on production systems.
--	--

# clear content

To clear the content of a Uniform Resource Locator (URL), use the **clear content** command in EXEC configuration mode.

**clear content url** *url*

Syntax Description	url	Clears cached content with its original URL.
	<i>url</i>	The URL for the content object to delete.

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Examples** The following example shows how to clear the content URL:

1. Verify the URL that is to be deleted from the SE.

```
ServiceEngine# show cache
Max-cached-entries is set as 10000000
Number of cal cached assets: 10
-----
Priority    Size      URL
-----
1.87390e+01 64000    http://7.1.200.200/file-1961503
1.87390e+01 64000    http://7.1.200.200/file-1961548
1.87390e+01 64000    http://7.1.200.200/file-1961450
1.87390e+01 64000    http://7.1.200.200/file-1961495
1.87390e+01 64000    http://7.1.200.200/file-1961540
1.87390e+01 64000    http://7.1.200.200/file-1961399
1.87390e+01 64000    http://7.1.200.200/file-1961349
1.87390e+01 64000    http://7.1.200.200/file-1961395
1.87390e+01 64000    http://7.1.200.200/file-1961302
1.87390e+01 64000    http://7.1.200.200/file-1961575
ServiceRouter#
```

2. Clear the URL content from that SE:

```
ServiceEngine# clear content url http://7.1.200.200/file-1961503
```

3. Verify the content is removed from SE:

```
ServiceEngine# show cache
Max-cached-entries is set as 10000000
Number of cal cached assets: 10
-----
Priority    Size      URL
-----
1.87390e+01 64000    http://7.1.200.200/file-1961548
1.87390e+01 64000    http://7.1.200.200/file-1961450
1.87390e+01 64000    http://7.1.200.200/file-1961495
1.87390e+01 64000    http://7.1.200.200/file-1961540
1.87390e+01 64000    http://7.1.200.200/file-1961399
1.87390e+01 64000    http://7.1.200.200/file-1961349
```

```
1.87390e+01 64000      http://7.1.200.200/file-1961395
1.87390e+01 64000      http://7.1.200.200/file-1961302
1.87390e+01 64000      http://7.1.200.200/file-1961575
1.87390e+01 64000      http://7.1.200.200/file-1961529
ServiceEngine#
```

# clear ip

To clear the IP configuration, use the **clear ip** command in EXEC configuration mode.

On the SE:

```
clear ip access-list counters [acl-num | acl-name]
```

On the SR:

```
clear ip access-list counters [acl-num | acl-name] | bgp {ip address | all} | ospf {neighbor {all |
GigabitEthernet slot/port num | PortChannel num} | rspf route [router-id] | traffic}
```

Syntax Description		
<b>access-list</b>		Clears the IP access list statistical information.
<b>counters</b>		Clears the IP access list counters.
<i>acl-name</i>		(Optional) Counters for the specified access list, identified using an alphanumeric identifier up to 30 characters, beginning with a letter.
<i>acl-num</i>		(Optional) Counters for the specified access list, identified using a numeric identifier (standard access list: 1 to 99; extended access list: 100 to 199).
<b>bgp</b>		Clears the BGP <sup>1</sup> neighbors.
<b>all</b>		Specifies that all current BGP sessions are reset.
<i>ip-address</i>		Specifies that only the identified BGP neighbor is reset.
<b>ospf</b>		Clears the OSPF <sup>2</sup> tables.
<b>neighbor</b>		Neighbor statistics per interface.
<b>all</b>		Clears all neighbors.
<b>GigabitEthernet</b>		Selects a GigabitEthernet interface.
<i>slot/port num</i>		Slot and port number for the selected interface. The slot range is 0 to 14, and the port is 0. The slot number and port number are separated with a forward slash character (/).
<b>PortChannel</b>		Selects the Ethernet Channel of interfaces.
<i>num</i>		Specifies the Ethernet Channel interface number. The range is from 1 to 4.
<b>rspf</b>		OSPF rspf.
<b>route</b>		Internal OSPF rspf routes.
<i>router-id</i>		(Optional) Specifies the ID of a router for clear routing information.
<b>traffic</b>		OSPF traffic counters.

1. BGP = Border Gateway Protocol

2. OSPF = Open Shortest Path First

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Usage Guidelines**

Use the **clear ip bgp** command whenever any of the following changes occur:

- Additions or changes to the BGP-related access lists
- Changes to BGP-related weights
- Changes to BGP-related distribution lists
- Changes to BGP-related route maps

**Examples**

The **clear ip bgp all** command is used to clear all routes in the local routing table. In the following example, the Proximity Engine has only one neighbor, 192.168.86.3:

```
ServiceRouter# clear ip bgp all
ServiceRouter# show ip bgp summary
```

```
BGP router identifier 172.20.168.47, local AS number 23
BGP table version is 815342, IPv4 Unicast config peers 2, capable peers 1
4021 network entries and 4021 paths using 852452 bytes of memory
BGP attribute entries [ 7/1120 ], BGP AS path entries [ 0/0 ]
BGP community entries [ 0/0 ], BGP clusterlist entries [ 0/0 ]
```

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd
192.168.86.3	4	23	172	8	0	0	0	00:00:04	Closing

```
ServiceRouter# show ip bgp summary
```

```
BGP router identifier 172.20.168.47, local AS number 23
BGP table version is 815342, IPv4 Unicast config peers 2, capable peers 1
4021 network entries and 4021 paths using 852452 bytes of memory
BGP attribute entries [ 7/1120 ], BGP AS path entries [ 0/0 ]
BGP community entries [ 0/0 ], BGP clusterlist entries [ 0/0 ]
```

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd
192.168.86.3	4	23	172	8	0	0	0	00:00:06	Idle

```
ServiceRouter# show ip bgp summary
```

```
BGP router identifier 172.20.168.47, local AS number 23
BGP table version is 815342, IPv4 Unicast config peers 2, capable peers 1
4021 network entries and 4021 paths using 852452 bytes of memory
BGP attribute entries [ 7/1120 ], BGP AS path entries [ 0/0 ]
BGP community entries [ 0/0 ], BGP clusterlist entries [ 0/0 ]
```

Neighbor	V	AS	MsgRcvd	MsgSent	TblVer	InQ	OutQ	Up/Down	State/PfxRcd
192.168.86.3	4	23	218	11	25680		0	19	00:00:06 8516

```
ServiceRouter#
```

The following example shows how to clear OSPF of all neighbors:

```
ServiceRouter# clear ip ospf neighbor *
ServiceRouter#
```

The following example shows how to clear OSPF of all neighbors in the GigabitEthernet 1/0 interface:

```
ServiceRouter# clear ip ospf neighbor GigabitEthernet 1/0
ServiceRouter#
```

The following example shows how to clear OSPF RSPF information for all routers:

```
ServiceRouter# clear ip ospf rspf route  
ServiceRouter#
```

The following example shows how to clear OSPF RSPF information for the router with the ID 172.20.168.41:

```
ServiceRouter# clear ip ospf rspf route 172.20.168.41  
ServiceRouter#
```

# clear isis

To clear IS-IS Routing for an IP, use the **clear isis** command in EXEC configuration mode.

```
clear isis {adjacency {all | GigabitEthernet slot/port num | PortChannel num } | ip rspf route
[ LSP-ID ] }
```

## Syntax Description

<b>adjacency</b>	Clears the IS-IS adjacency information.
<b>all</b>	Clears IS-IS adjacencies on all interfaces.
<b>GigabitEthernet</b>	Selects a GigabitEthernet interface.
<i>slot/port num</i>	Slot and port number for the selected interface. The slot range is 0 to 14; the port is 0. The slot number and port number are separated with a forward slash character (/).
<b>PortChannel</b>	Selects the Ethernet Channel of interfaces.
<i>num</i>	Specifies the Ethernet Channel interface number. The range is from 1 to 4.
<b>ip</b>	IS-IS IP information.
<b>rspf</b>	IS-IS Reverse SPF <sup>1</sup> routing information.
<b>route</b>	Specifies the IS-IS route.
<i>LSP_ID</i>	(Optional) Clears information for LSPs <sup>2</sup> ID in the form of xxxx.xxxx.xxxx.xxxx or name.

1. SPF = Shortest Path First

2. LSP = link-state packet

## Command Defaults

If no LSP ID is specified in the **clear isis ip rspf route** command, IS-IS RSPF information is cleared for all LSP IDs.

## Command Modes

EXEC configuration mode.

## Usage Guidelines

The **clear isis ip rspf route** command is used to clear IS-IS RSPF routing information. IS-IS RSPF routing information is displayed only with the **show isis ip rspf route** command when a new proximity request has been received.

## Examples

The following is sample output from the **show isis adjacency** command before and after running the **clear isis adjacency** command:

```
ServiceRouter# show isis adjacency
```

```
IS-IS adjacency database:
```

System ID	SNPA	Level	State	Hold Time	Interface
0200.c0a8.5401	0000.a1e8.e019	1	UP	00:00:21	GigabitEthernet 3/0
7301-7-core	001d.a1e9.c41b	1	UP	00:00:08	GigabitEthernet 3/0
7301-7-core	001d.a1e9.c41b	2	UP	00:00:08	GigabitEthernet 3/0



```

ServiceRouter#

ServiceRouter# clear isis adjacency *

ServiceRouter# show isis adjacency

IS-IS adjacency database:
System ID      SNPA              Level  State  Hold Time  Interface
7301-7-core    001d.a1e9.c41b  1      UP     00:00:09   GigabitEthernet 3/0
7301-7-core    001d.a1e9.c41b  2      UP     00:00:09   GigabitEthernet 3/0

ServiceRouter#

ServiceRouter# show isis adjacency

IS-IS adjacency database:
System ID      SNPA              Level  State  Hold Time  Interface
7301-7-core    001d.a1e9.c41b  1      UP     00:00:08   GigabitEthernet 3/0
7301-7-core    001d.a1e9.c41b  2      UP     00:00:07   GigabitEthernet 3/0

ServiceRouter#

ServiceRouter# show isis adjacency

IS-IS adjacency database:
System ID      SNPA              Level  State  Hold Time  Interface
0200.c0a8.5401 0000.a1e8.e019   1      UP     00:00:31   GigabitEthernet 3/0
7301-7-core    001d.a1e9.c41b  1      UP     00:00:10   GigabitEthernet 3/0
7301-7-core    001d.a1e9.c41b  2      UP     00:00:08   GigabitEthernet 3/0

ServiceRouter#

```

The following is a sample from the **show isis ip rspf route** command before and after running the **show isis ip rspf route** command:

```

ServiceRouter# show isis ip rspf route

LSP ID          SPF Time  Cache Hit  Level  Age Max range
0200.c0a8.0a01.00-00  3d22h      0      1      3d22h 10

ServiceRouters# clear isis ip rspf route

ServiceRouter# show isis ip rspf route

LSP ID          SPF Time  Cache Hit  Level  Age Max range

```

## Related Commands

Command	Description
<b>show isis adjacency</b>	Displays IS-IS adjacencies.
<b>show isis ip rspf route</b>	Displays the Intermediate IS-IS RSPF route for IS-IS learned routes.

# clear logging

To clear the syslog messages saved in the disk file, use the **clear logging** command in EXEC configuration mode.

## clear logging

---

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

---

<b>Command Defaults</b>	None
-------------------------	------

---

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

---

<b>Usage Guidelines</b>	The <b>clear logging</b> command removes all current entries from the syslog.txt file, but does not make an archive of the file. It puts a “Syslog cleared” message in the syslog.txt file to indicate that the syslog has been cleared, as shown in the following example:
-------------------------	---

```
Feb 14 12:17:18 ServiceEngine# exec_clear_logging:Syslog cleared
```

---

<b>Examples</b>	The following example shows how to clear the syslogs:
-----------------	---

```
ServiceRouter# clear logging  
U11-CDE220-2#
```

# clear service-router

To clear the proximity-based routing proximity cache , use the **clear service-router** command in EXEC configuration mode.

**clear service-router proximity-based-routing proximity-cache**

## Syntax Description

<b>proximity-based-routing</b>	Clears proximity-based routing.
<b>proximity-cache</b>	Clears proximity cache.

## Command Defaults

Clears the cache for all proximity ratings.

## Command Modes

EXEC configuration mode.

## Usage Guidelines

When an SR receives a redirect request from a client network 1 with proximity-based routing enabled, the SR queries the proximity server for the proximity rating of the SEs. The ratings returned from the proximity server are cached, and the default timeout for the cache is 1800 seconds . If there is any network or proximity rating change within this period, the SR does not know as it redirects based on the ratings cached for that network. The **clear service-router** command is used to force clear cache.

## Examples

The following example shows how to clear the Service Router.

```
ServiceRouter# clear service-router proximity-based-routing proximity-cache
ServiceRouter#
```

## Related Commands

Command	Description
<b>show service-router</b>	Shows the cache timeout period.

# clear srp database offline

To clear the SRP database while it is offline, use the **clear srp database offline** command in privileged EXEC mode.

**clear srp database offline**

---

**Syntax Description** This command has no keywords or arguments.

---

**Command Defaults** None

---

**Command Modes** Privileged EXEC configuration mode.

---

**Usage Guidelines** The **clear srp database offline** command is used to clear the SRP database while it is offline.



**Note**

---

You must turn off SRP before executing this command by entering the **no router srp** command.

---



---

**Examples** The following example shows how to clear the SRP database offline:


```
ServiceRouter# clear srp database offline
Clearing database offline
ServiceRouter#
```

---

Related Commands	Command	Description
	<b>show srp database</b>	Displays the descriptor-related information saved in the descriptor database.
	<b>show srp multicast database</b>	Displays multicast database information.

---



 `clear srp descriptor`

Related Commands	Command	Description
	<code>show srp database</code>	Displays the descriptor-related information saved in the descriptor database.
	<code>show srp multicast database</code>	Displays multicast database information.

# clear srp neighbor

To remove a neighbor Proximity Engine from the neighbor list of the local Proximity Engine, use the **clear srp neighbor** command in privileged EXEC mode.

**clear srp neighbor** *key*

## Syntax Description

<i>key</i>	The DHT key in hexadecimal format for the node to be removed from the neighbor list. A valid DHT key has 1 to 64 hexadecimal digits.
------------	--

## Command Defaults

None

## Command Modes

Privileged EXEC configuration mode.

## Usage Guidelines

The **clear srp neighbor** command is used to delete a single neighbor in the service routing layer from the local Proximity Engine neighbor list. After a small interval, the neighbor list is refreshed and the deleted neighbor may be included in the neighbor list again if it is still a neighbor of the local Proximity Engine in the service routing layer.

A valid DHT key should be specified in *key* to identify the neighbor. Keys with less than 64 hexadecimal characters are appended with zeroes.

If you attempt to delete a neighbor that does not appear in the neighbor list of the local Proximity Engine, **clear srp neighbor** displays an error message stating that the neighbor could not be found.

## Examples

The following example shows how to use Proximity Engine sn-sj85 with one neighbor sn-sj81 as seen in the following **show srp neighbor** command output. The neighbor sn-sj81 is also in the leafset of sn-sj85 as can be seen in the **show srp leafset** output. All commands are issued from Proximity Engine sn-sj85.

```
ServiceRouter# show srp neighbor
```

```
Codes: T - local node, L - leafset, P - primary, S - secondary, B - backup
       I - Intransitive, D - delay, H - hold time
```

```
Number of neighbors in the database: 1
```

```
PL  8886822171add71887d54107c266d814b605eaa0d5cc9b54b9160a137f4355d1
    via sn-sj81 [ 172.20.168.81 ] :9000, D=0.389864 ms,
    H=00:00:09
```

```
ServiceRouter# show srp leafset
```

```
Codes: T - local node, L - leafset, P - primary, S - secondary, B - backup
       I - Intransitive, W - wrapped
```

```
Leafset count: total 3, left 1, right 1
```

```
PL  8886822171add71887d54107c266d814b605eaa0d5cc9b54b9160a137f4355d1
```

The **clear srp neighbor** command is used to remove sn-sj81 from the neighbor list.

Neighbor is found and cleared

- Output from **show srp neighbor** shows that the neighbor sn-sj81 is in the intransitive state (I). The intransitive state means node sn-sj85 cannot reach node sn-sj81.

```
I 8886822171add71887d54107c266d814b605eaa0d5cc9b54b9160a137f4355d1
   via sn-sj81 [ 172.20.168.81 ] :9000, D=0.000 ms,
   H=00:00:07
```

- Output from **show srp leafset** shows that there are no leafset entries (PL or WPL) for the Proximity Engine sn-sj85.

```
T      9f752f56f347ca8fcc40a4e09b645f9b4c9b71c73401083f4c04920b30215b0a
via sn-sj85 [ 172.20.168.85, 192.168.20.85, 192.168.86.85 ] :9000
```

ServiceRouter# #

The following example shows how to use the **clear srp resource** command to delete a resource having resource ID 456 from a descriptor with the key 123. The **show srp database** command is used to verify that the resource exists before the delete operation and that it has been deleted after the delete operation.

```
Entity key:  
123000000000000000000000000000000000000000000000000000000000000000000000000000  
Entity rec type:          101      Entity total length: 175  
Entity type:              38b73479   Entity flags:          0  
----- Element 0           (main)-----  
Element ID: main
```



Related Commands	Command	Description
	<b>show srp leafset</b>	Displays SRP leafset information.
	<b>show srp neighbors</b>	Displays SRP neighbor information.



[illegible]

Related Commands	Command	Description
	<b>clear srp descriptor</b>	Deletes a single descriptor or all descriptors from the service routing layer
	<b>show srp database</b>	Displays the descriptor-related information saved in the descriptor database.

# clear srp route

To delete a single route entry from the DHT routing table of the local Proximity Engine, use the **clear srp route** command in privileged EXEC mode.

**clear srp route** *prefix*/*length*

## Syntax Description

<i>prefix</i>	The prefix of the DHT key of the route entry to delete.
<i>length</i>	The length of the prefix (in multiples of 4).

## Command Defaults

None

## Command Modes

Privileged EXEC configuration mode.

## Usage Guidelines

The **clear srp route** command deletes a single routing table entry from the local DHT routing table. Similar to other routing protocols, the DHT routing table entries consist of a prefix and length that index the DHT ID of the next-hop Proximity Engine. A valid DHT key prefix (1 to 64 hexadecimal characters) and valid prefix length (multiples of four) must be supplied to identify the neighbor to be deleted.

The **clear srp route** command provides a manual way to delete routing table entries. After a small interval, the DHT routing table is refreshed and the deleted next-hop Proximity Engine may be included in the DHT routing table again if it is still a viable neighbor.

The **clear srp route** command can be used to test the presence and persistence of neighbors. Deleting a routing entry that does not exist results in an error message.

## Examples

In the following example, Proximity Engine sn-sj85 has four routing table entries. The example shows how to use the **clear srp route** command to clear the routing table entry that has 8/4 as its *prefix/length*. The **show srp route** command is used to verify the deletion of the route.

```
ServiceRouter# show srp route
```

```
Codes: T - local node, L - leafset, P - primary, S - secondary, B - backup
       I - Intransitive
```

```
PL 8/4 via 8886822171add71887d54107c266d814b605eaa0d5cc9b54b9160a137f4355d1
    sn-sj81 [ 172.20.168.81 ] :9000, 0.389525 ms, 00:00:08
PL a/4 via ad3a659121442210a68b79348e9a42eaebfb229f388afb2628fa871f26bc750c
    sn-sj67 [ 172.20.168.67, 192.168.20.41, 192.168.20.44, 192.168.22.41, 192.168
    .22.42 ] :9000, 1.825903 ms, 00:00:09
PL b/4 via b5ca21563f5b938e46e2cb8f33a148ae00a1f6666f2a5eb735b7ed90c012c882
    sn-sj82 [ 172.20.168.82 ] :9000, 0.333920 ms, 00:00:08
PL d/4 via d2fc632c53c9ff1de8683e265386b09502791aedd65f28025fe7f64ad8cab2d9
    sn-sj87 [ 172.20.168.87 ] :9000, 0.642357 ms, 00:00:09
```

```
ServiceRouter# clear srp route 8/4
```

```
Clearing entry 8/4
```

```
The entry is found and cleared
```

```
ServiceRouter# show srp route
```

```
Codes: T - local node, L - leafset, P - primary, S - secondary, B - backup
       I - Intransitive
```

```
PL  a/4 via ad3a659121442210a68b79348e9a42eaebfb229f388afb2628fa871f26bc750c
      sn-sj67 [ 172.20.168.67, 192.168.20.41, 192.168.20.44, 192.168.22.41, 192.168
.22.42 ] :9000, 1.846593 ms, 00:00:09
PL  b/4 via b5ca21563f5b938e46e2cb8f33a148ae00a1f6666f2a5eb735b7ed90c012c882
      sn-sj82 [ 172.20.168.82 ] :9000, 0.333920 ms, 00:00:09
PL  d/4 via d2fc632c53c9ff1de8683e265386b09502791aedd65f28025fe7f64ad8cab2d9
      sn-sj87 [ 172.20.168.87 ] :9000, 0.572056 ms, 00:00:09
```

```
ServiceRouter#
```

## Related Commands

Command	Description
<b>show srp route</b>	Displays route information for a Proximity Engine to its neighbor nodes on the same DHT network.

# clear statistics

To clear the statistics, use the **clear statistics** command in EXEC configuration mode.

On the SE:

```
clear statistics {access-lists 300 | all | authentication | authsvr | distribution {all |
metadata-receiver | metadata-sender | unicast-data-receiver | unicast-data-sender} |
flash-media-streaming | history | icap | icmp | ip | movie-streamer | qos policy-service |
radius | rule {action action-type | all | pattern {1-512 | all} | rtsp} | running | snmp | tacacs
| tcp | transaction-logs | udp | web-engine [force] | web-engine [force] | wmt}
```

On the SR:

```
clear statistics {all | authentication | history | http requests | icmp | ip [ospf | proximity {rib |
server}} | isis [GigabitEthernet slot/port num | PortChannel num] | radius | running |
service-registry | service-router | snmp | srp | tacacs | tcp | udp}
```

## Syntax Description

<b>statistics</b>	Clears the statistics as specified.
<b>access-lists</b>	Clears the ACL statistics.
<b>300</b>	Clears the group name-based ACL.
<b>all</b>	Clears all statistics.
<b>authentication</b>	Clears the authentication statistics.
<b>authsvr</b>	Clears the Authorization Server statistics.
<b>distribution</b>	Clears the distribution statistics.
<b>all</b>	Clears the distribution statistics for every component.
<b>metadata-receiver</b>	Clears the distribution statistics for the metadata receiver.
<b>metadata-sender</b>	Clears the distribution statistics for the metadata sender.
<b>unicast-data-receiver</b>	Clears the distribution statistics for the unicast data receiver.
<b>unicast-data-sender</b>	Clears the distribution statistics for the unicast data sender.
<b>flash-media-streaming</b>	Clears the Flash Media Streaming statistics.
<b>history</b>	Clears the statistics history.
<b>icap</b>	Clears the ICAP <sup>1</sup> statistics.
<b>icmp</b>	Clears the ICMP statistics.
<b>ip</b>	Clears the IP statistics.
<b>ospf</b>	Clears the OSPF statistics.
<b>proximity</b>	Clears the proximity statistics.
<b>rib</b>	Clears the RIB proximity statistics.
<b>server</b>	Clears the Proximity Server statistics.
<b>isis</b>	Clears counters for an IS-IS instance.
<b>GigabitEthernet</b>	(Optional) Selects a GigabitEthernet interface.
<i>slot/port num</i>	Slot and port number for the selected interface. The slot range is 0 to 14; the port is 0. The slot number and port number are separated with a forward slash character (/).
<b>PortChannel</b>	(Optional) Selects the Ethernet Channel of interfaces.

<i>num</i>	Specifies the Ethernet Channel interface number (1 to 4).
<b>movie-streamer</b>	Clears the Movie Streamer statistics.
<b>qos</b>	Clears the QoS statistics.
<b>policy-service</b>	Specifies the Camiant cdn-am service.
<b>radius</b>	Clears the RADIUS statistics.
<b>rule</b>	Clears the rules statistics.
<b>action</b>	Clears the statistics of all the rules with the same action.
<i>action-type</i>	Specifies one of the following actions:  <b>allow</b> <b>block</b> <b>generate-url-signature</b> <b>no-cache</b> <b>redirect</b> <b>rewrite</b> <b>use-icap-service</b> <b>validate-url-signature</b>
<b>all</b>	Clears the statistics of all the rules.
<b>pattern</b>	Clears the statistics of the pattern lists.
<b>1-512</b>	Pattern list number.
<b>all</b>	Clears the statistics for all the pattern lists.
<b>rtsp</b>	Clears the statistics for the configured RTSP rules (rules configured for RTSP requests from RealMedia players [the RTSP rules] and rules configured for RTSP requests from Windows Media 9 players [the WMT-RTSP rules] ).
<b>running</b>	Clears the running statistics.
<b>snmp</b>	Clears the SNMP statistics.
<b>srp</b>	Resets to zero all statistics counters kept by the local DHT service
<b>tacacs</b>	Clears the TACACS+ statistics.
<b>tcp</b>	Clears the TCP statistics.
<b>transaction-logs</b>	Clears the transaction log export statistics.
<b>udp</b>	Clears the UDP statistics.
<b>web-engine</b>	Clears the Web Engine statistics.
<b>force</b>	Clears the Web Engine detail statistics.
<b>web-engine</b>	Clears Web Engine statistics.
<b>force</b>	(Optional) Clears Web Engine detail statistics.
<b>wmt</b>	Clears all WMT statistics.

1. ICAP = Internet Content Adaptation Protocol

**Command Defaults**

None

**Command Modes**

EXEC configuration mode.

**Usage Guidelines**

The **clear statistics** command clears all statistical counters from the parameters given. Use this command to monitor fresh statistical data for some or all features without losing cached objects or configurations.

This command is used to reset to zero proximity statistics related to the Proximity Engine components that are used for the proximity function. Use the **show statistics ip proximity** command to display proximity statistics.

The DHT service keeps several counters, such as the number of requests and responses for DHT lookups. These counters can be displayed using the **show statistics srp** command.

The **clear statistics web-engine** and **clear statistics all** commands clear only normal statistics, not the Web Engine statistics details. To clear all Web Engine statistics, use the **clear statistics web-engine force** command.

**Note**

The **clear statistics web-engine** and **clear statistics all** commands clear only normal statistics, not the Web Engine statistics details. To clear all Web Engine statistics, use the **clear statistics web-engine force** command. We do not recommend using the **clear statistics web-engine force** command, but if it is used, restart the Web Engine service by entering the **web-engine stop** and **web-engine start** commands.

**Examples**

The following example shows how to clear proximity statistics with the **clear statistics ip proximity** command:

```
ServiceRouter# clear statistics ip proximity server
ServiceRouter# show statistics ip proximity server

Proximity server: Requests received = 0
Proximity server: Responses sent = 0
Proximity server: Faults sent = 0
ServiceRouter#

ServiceRouter# show statistics ip proximity rib
Total number of proximity requests received from applications: 0
Total number of proximity replies sent to applications: 0
Proximity msg exchanges between urib and routing protocols:
      Sent Prox Req      Received Prox Resp
isis-p1                  0                  0
ospf-p1                  0                  0
isis-p1-te               0                  0
ospf-p1-te               0                  0
bgp-123                  0                  0
mbgp-123                 0                  0
Local proximity requests from applications: 0
Invalid proximity requests from applications: 0
PSA non-rankable proximity requests from applications: 0
Failed proximity requests to routing protocols: 0
Failed PSA lookups: 0
Failed PTA lookups: 0
ServiceRouter#
```

The following is sample output from the **show statistics isis** command before and after running **clear statistics isis** command:



```
ServiceRouter# show statistics isis
```

```
IS-IS statistics:
PDU          Received          Sent   RcvAuthErr  OtherRcvErr
LAN-IIH      51             14      0            0
P2P-IIH      0              0      0            0
CSNP         67            0      0            0
PSNP         0              0      0            0
PDU          Received          Flooded RcvAuthErr  OtherRcvErr  ReTransmit
LSP          69             4       0            0            0
DIS elections: 10
SPF calculations: 82
LSPs sourced: 0
LSPs refreshed: 8
LSPs purged: 0
ServiceRouter#
```

```
ServiceRouter# clear statistics isis *
```

```
ServiceRouter# show statistics isis
```

```
IS-IS statistics:
PDU          Received          Sent   RcvAuthErr  OtherRcvErr
LAN-IIH      1              0      0            0
P2P-IIH      0              0      0            0
CSNP         4              0      0            0
PSNP         0              0      0            0
PDU          Received          Flooded RcvAuthErr  OtherRcvErr  ReTransmit
LSP          1              0       0            0            0
DIS elections: 0
SPF calculations: 1
LSPs sourced: 0
LSPs refreshed: 0
LSPs purged: 0
ServiceRouter#
```

The following example shows the use of the **clear statistics srp** command. The **show statistics srp** command is used to verify that the SRP counters have been reset to zero:

```
ServiceRouter# show statistics srp
```

	Sent	Received	Neighbors
Join request	0	22	1
Join response	22	0	0
LS exchange request	309	310	0
LS exchange response	310	309	0
Route exchange request	65	0	0
Route exchange response	0	64	0
Ping request	410	412	1
Ping response	412	410	0
Lookup request	34	867	3
Lookup response	867	34	0
Ping traceroute request	0	0	0
Ping traceroute response	0	0	0

```
ServiceRouter# clear statistics srp
```

```
Clearing all statistics counters
```

```
ServiceRouter# show statistics srp
```

	Sent	Received	Neighbors
Join request	0	0	0

clear statistics

```
Join response          0          0          0
LS exchange request    1          1          0
LS exchange response   1          1          0
Route exchange request 1          0          0
Route exchange response 0          1          0
Ping request           2          2          0
Ping response          2          2          0
Lookup request         0          2          0
Lookup response        2          0          0
Ping traceroute request 0          0          0
Ping traceroute response 0          0          0
ServiceRouter#
```

Related Commands

Command	Description
show statistics srp	Displays SRP statistics information.

# clear transaction-logs

To clear and archive the working transaction log files, use the **clear transaction-log** command in EXEC configuration mode.

## clear transaction-logs

<b>Syntax Description</b>	This command has no keywords or arguments.
---------------------------	--

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

<b>Usage Guidelines</b>	The <b>clear transaction-log</b> command causes the transaction log to be archived immediately to the SE hard disk. This command has the same effect as the <b>transaction-log force archive</b> command.
-------------------------	---

<b>Examples</b>	The following example shows that the <b>clear transaction-log</b> command forces the working transaction log file to be archived:
-----------------	---

```
ServiceEngine# clear transaction-log
```

# clear users

To clear the connections (login) of authenticated users, use the **clear users** command in EXEC configuration mode.

## clear users administrative

<b>Syntax Description</b>	<b>administrative</b>	Clears the connections of administrative users who have been authenticated through a remote login service.
<b>Command Defaults</b>	None	
<b>Command Modes</b>	EXEC configuration mode.	
<b>Usage Guidelines</b>	The <b>clear users administrative</b> command clears the connections for all administrative users who are authenticated through a remote login service, such as TACACS. This command does not affect an administrative user who is authenticated through the local database.	
<b>Examples</b>	<p>The following example shows how to clear the connections of the authenticated users:</p> <pre>ServiceRouter# clear users administrative ServiceRouter#</pre>	

# clear wmt

To clear the WMT streams, use the **clear wmt** command in EXEC configuration mode.

```
clear wmt stream-id 1-999999
```

Syntax Description	<b>wmt</b>	Clears the WMT streams.
	<b>stream-id</b>	Clears the WMT streams that have the specified WMT stream ID. Also stops the SE's WMT process that is associated with the specified stream ID.
	<i>1-999999</i>	WMT stream ID to clear.

Command Defaults	None
------------------	------

Command Modes	EXEC configuration mode.
---------------	--------------------------

Examples	The following example shows how to clear a WMT stream for a stream ID of 22689:
----------	---

```
ServiceEngine# clear wmt stream-id 22689
ServiceEngine#
```

# clock (EXEC)

To set or clear clock functions or update the calendar, use the **clock** command in EXEC configuration mode.

**clock** {**read-calendar** | **set** *time day month year* | **update-calendar**}

## Syntax Description

<b>read-calendar</b>	Reads the calendar and updates the system clock.
<b>set</b>	Sets the time and date.
<i>time</i>	Current time in hh:mm:ss format (hh: 00 to 23; mm: 00 to 59; ss: 00 to 59).
<i>day</i>	Day of the month (1 to 31).
<i>month</i>	Month of the year (January, February, March, April, May, June, July, August, September, October, November, December).
<i>year</i>	Year (1993 to 2035).
<b>update-calendar</b>	Updates the calendar with the system clock.

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Usage Guidelines

If you have an outside source on your network that provides time services (such as a Network Time Protocol [NTP] server), you do not have to set the system clock manually. Enter the local time when setting the clock. The SE calculates the Coordinated Universal Time (UTC) based on the time zone set by the **clock timezone** command.



### Note

We strongly recommend that you configure the SE for the NTP by using the **ntp** command. See the [“ntp” section on page 2-261](#) for more details.



### Note

If you change the local time on the device, you must change the BIOS clock time as well; otherwise, the timestamps on the error logs are not synchronized. Changing the BIOS clock is required because the kernel does not handle time zones.

Two clocks exist in the system: the software clock and the hardware clock. The software uses the software clock. The hardware clock is used only at startup to initialize the software clock. The calendar clock is the same as the hardware clock that runs continuously on the system, even if the system is powered off or rebooted. This clock is separate from the software clock settings that are erased when the system is powered cycled or rebooted.

The **set** keyword sets the software clock. If the system is synchronized by a valid outside timing mechanism, such as a NTP clock source, you do not have to set the system clock. Use this command if no other time sources are available. The time specified in this command is relative to the configured time zone.

To perform a one-time update of the hardware clock (calendar) from the software clock or to copy the software clock settings to the hardware clock (calendar), use the **clock update-calendar** command.

### Examples

The following example shows how to set the software clock on the SE:

```
ServiceEngine# clock set 13:32:00 01 February 2000
```

### Related Commands

Command	Description
<b>clock timezone</b>	Sets the clock timezone.
<b>ntp</b>	Configures the Network Time Protocol server.
<b>show clock detail</b>	Displays the UTC and local time.

## clock (Global configuration)

To set the summer daylight saving time and time zone for display purposes, use the **clock** command in Global configuration mode. To disable this function, use the **no** form of this command.

**clock** {**summertime** *timezone* {**date** *startday startmonth startyear starthour endday endmonth endyear offset* | **recurring** {**1-4** *startweekday startmonth starthour endweekday endmonth endhour offset* | **first** *startweekday startmonth starthour endweekday endmonth endhour offset* | **last** *startweekday startmonth starthour endweekday endmonth endhour offset* } } | **timezone** {*timezone houroffset minutesoffset*} }

**no clock** {**summertime** *timezone* {**date** *startday startmonth startyear starthour endday endmonth endyear offset* | **recurring** {**1-4** *startweekday startmonth starthour endweekday endmonth endhour offset* | **first** *startweekday startmonth starthour endweekday endmonth endhour offset* | **last** *startweekday startmonth starthour endweekday endmonth endhour offset* } } | **timezone** {*timezone houroffset minutesoffset*} }

### Syntax Description

<b>summertime</b>	Configures the summer or daylight saving time.
<i>timezone</i>	Name of the summer time zone.
<b>date</b>	Configures the absolute summer time.
<i>startday</i>	Date (1 to 31) to start.
<i>startmonth</i>	Month (January through December) to start.
<i>startyear</i>	Year (1993–2032) to start.
<i>starthour</i>	Hour (0 to 23) to start in (hh:mm) format.
<i>endday</i>	Date (1 to 31) to end.
<i>endmonth</i>	Month (January through December) to end.
<i>endyear</i>	Year (1993 to 2032) to end.
<i>endhour</i>	Hour (0 to 23) to end in (hh:mm) format.
<i>offset</i>	Minutes offset (see <a href="#">Table B-1</a> ) from Coordinated Universal Time (UTC) (0–59).
<b>recurring</b>	Configures the recurring summer time.
<b>1-4</b>	Configures the starting week number, the range is from 1 to 4.
<b>first</b>	Configures the summer time to recur beginning the first week of the month.
<b>last</b>	Configures the summer time to recur beginning the last week of the month.
<i>startweekday</i>	Day of the week (Monday to Friday) to start.
<i>startmonth</i>	Month (January to December) to start.
<i>starthour</i>	Hour (0 to 23) to start in hh:mm format.
<i>endweekday</i>	Weekday (Monday to Friday) to end.
<i>endmonth</i>	Month (January to December) to end.
<i>endhour</i>	Hour (0 to 23) to end in hour:minute (hh:mm) format.
<i>offset</i>	Minutes offset (see <a href="#">Table B-1</a> ) from UTC (0 to 59).
<b>timezone</b>	Configures the standard time zone.
<i>timezone</i>	Name of the time zone.



<i>hoursoffset</i>	Hours offset (see <a href="#">Table B-1</a> ) from UTC (–23 to +23).
<i>minutesoffset</i>	Minutes offset (see <a href="#">Table B-1</a> ) from UTC (0–59).

**Command Defaults** None

**Command Modes** Global configuration (config) mode.

**Usage Guidelines** To set and display the local and UTC current time of day without an NTP server, use the **clock timezone** command with the **clock set** command. The **clock timezone** parameter specifies the difference between UTC and local time, which is set with the **clock set** command in EXEC configuration mode. The UTC and local time are displayed with the **show clock detail** command in EXEC configuration mode.

Use the **clock timezone offset** command to specify a time zone, where *timezone* is the desired time zone entry from [Table B-1](#) and *0 0* is the offset (ahead or behind) Coordinated Universal Time (UTC) in hours and minutes. UTC was formerly known as *Greenwich Mean Time* (GMT).

```
SE(config)# clock timezone timezone 0 0
```



**Note**

The time zone entry is case sensitive and must be specified in the exact notation listed in the time zone table as shown in [Appendix B, “Standard Time Zones.”](#) When you use a time zone entry from [Table B-1](#), the system is automatically adjusted for daylight saving time.



**Note**

If you change the local time on the device, you must change the BIOS clock time as well; otherwise, the timestamps on the error logs are not synchronized. Changing the BIOS clock is required because the kernel does not handle time zones.

The offset (ahead or behind) UTC in hours, as displayed in [Table B-1](#), is in effect during winter time. During summer time or daylight saving time, the offset may be different from the values in the table and are calculated and displayed accordingly by the system clock.



**Note**

An accurate clock and timezone setting is required for the correct operation of the HTTP proxy caches.

**Examples**

The following example shows how to specify the local time zone as Pacific Standard Time with an offset of 8 hours behind UTC:

```
ServiceEngine(config)# clock timezone PST -8
Custom Timezone: PST will be used.
```

The following example shows how to configure a standard time zone on the SE:

```
ServiceEngine(config)# clock timezone US/Pacific 0 0
Resetting offset from 0 hour(s) 0 minute(s) to -8 hour(s) 0 minute(s)
Standard Timezone: US/Pacific will be used.
ServiceEngine(config)#
```

The following example negates the time zone setting on the SE:

**clock (Global configuration)**

```
ServiceEngine(config)# no clock timezone
```

The following example shows how to configure daylight saving time:

```
ServiceEngine(config)# clock summertime PDT date 10 October 2001 23:59 29 April 2002 23:59  
60
```

**Related Commands**

Command	Description
<b>clock</b>	To set the summer daylight saving time and time zone for display purposes.
<b>show clock detail</b>	Displays the UTC and local time.

## cms (EXEC)

To configure the Centralized Management System (CMS) embedded database parameters, use the **cms** command in EXEC configuration mode.

```
cms {config-sync | database {backup | create | delete | downgrade [script filename] |
    maintenance {full | regular} | restore filename | validate} | deregister [force] | recover {
    identity word} }
```

Syntax Description		
<b>config-sync</b>		Sets the node to synchronize configuration with the CDSM.
<b>database</b>		Creates, backs up, deletes, restores, or validates the CMS-embedded database management tables or files.
<b>backup</b>		Backs up the database management tables.
<b>create</b>		Creates the embedded database management tables.
<b>delete</b>		Deletes the embedded database files.
<b>downgrade</b>		Downgrades the CMS database.
<b>script</b>		(Optional) Downgrades the CMS database by applying a downgrade script.
<i>filename</i>		Downgraded script filename.
<b>maintenance</b>		Cleans and reindexes the embedded database tables.
<b>full</b>		Specifies a full maintenance routine for the embedded database tables.
<b>regular</b>		Specifies a regular maintenance routine for the embedded database tables.
<b>restore</b>		Restores the database management tables using the backup local filename.
<i>filename</i>		Database local backup filename.
<b>validate</b>		Validates the database files.
<b>deregister</b>		Removes the registration of the CMS proto device.
<b>force</b>		(Optional) Forces the removal of the node registration.
<b>recover</b>		Recovers the identity of an CDS network device.
<b>identity</b>		Specifies the identity of the recovered device.
<i>word</i>		Identity of the recovered device.

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Usage Guidelines** The *CDS network* is a collection of SR, SE, and CDSM nodes. One primary CDSM retains the CDS network settings and provides other CDS network nodes with updates. Communication between nodes occurs over secure channels using the Secure Shell Layer (SSL) protocol, where each node on the CDS network uses a Rivest, Shamir, Adelman (RSA) certificate-key pair to communicate with other nodes.

Use the **cms config-sync** command to enable registered SRs, SEs, and standby CDSM to contact the primary CDSM immediately for a getUpdate (get configuration poll) request before the default polling interval of 5 minutes. For example, when a node is registered with the primary CDSM and activated, it

appears as Pending in the CDSM GUI until it sends a getUpdate request. The **cms config-sync** command causes the registered node to send a getUpdate request at once, and the status of the node changes as Online.

Use the **cms database create** command to initialize the CMS database. Before a node can join a CDS network, it must first be registered and then activated. The **cms enable** command automatically registers the node in the database management tables and enables the CMS. The node sends its attribute information to the CDSM over the SSL protocol and then stores the new node information. The CDSM accepts these node registration requests without admission control and replies with registration confirmation and other pertinent security information required for getting updates. Activate the node using the CDSM GUI.

Once the node is activated, it automatically receives configuration updates and the necessary security RSA certificate-key pair from the CDSM. This security key allows the node to communicate with any other node in the CDS network. The **cms deregister** command removes the node from the CDS network by deleting registration information and database tables.



#### Note

The **cms deregister** command cleans up the database automatically. You do not need to use the **cms database delete** command. If the deregistration fails, the best practice is to resolve any issues that caused the deregistration failure; for example, the Service Engine is the Content Acquirer of a delivery service and cannot be deleted or deactivated. Assign a different SE as the Content Acquirer in each delivery service where this SE is assigned as the Content Acquirer and try the **cms deregister** command again.

To back up the existing management database for the CDSM, use the **cms database backup** command. For database backups, specify the following items:

- Location, password, and user ID
- Dump format in PostgreSQL plain text syntax

The naming convention for backup files includes the time stamp.

When you use the **cms recover identity word** command when recovering lost registration information, or replacing a failed node with a new node that has the same registration information, specify the device recovery key that you configured in the Modifying Config Property, System.device.recovery.key window of the CDSM GUI.

Use the **lcm** command to configure local or central management (LCM) on an CDS network device. The LCM feature allows settings configured using the device CLI or GUI to be stored as part of the CDS network-wide configuration data (enable or disable).

When you enter the **cms lcm enable** command, the CMS process running on SEs, SRs, and the standby CDSM detects the configuration changes that you made on these devices using CLIs and sends the changes to the primary CDSM.

When you enter the **cms lcm disable** command, the CMS process running on SEs, SRs, and the standby CDSM does not send the CLI changes to the primary CDSM. Settings configured using the device CLIs are not sent to the primary CDSM.

If LCM is disabled, the settings configured through the CDSM GUI overwrite the settings configured from the SE or SR; however, this rule applies only to those local device settings that have been overwritten by the CDSM when you have configured the local device settings. If you (as the local CLI user) change the local device settings after the particular configuration has been overwritten by the CDSM, the local device configuration is applicable until the CDSM requests a full-device statistics update from the SE or SR (clicking the **Force full database update** button from the Device Home window of the CDSM GUI triggers a full update). When the CDSM requests a full update from the device, the CDSM settings overwrite the local device settings.

The **cms deregister force** command should be used only as the last option, because the CDSM does not know about the device being removed. When executing the **cms deregister force** command, take note of any messages stating that the deregistration failed and make sure to resolve them before reregistering the device with the same CDSM or registering the device to another CDSM. The **cms deregister force** command forces the deregistration to continue.

## Examples

The following example shows how to back up the database management tables:

```
CDSM# cms database backup
creating backup file with label `backup'
backup file local1/CDS-db-9-22-2002-17-36.dump is ready. use `copy' commands to move the
backup file to a remote host.
```

The following example shows how to validate the database management tables:

```
CDSM# cms database validate
Management tables are valid
```

In the following example, the CMS deregistration process has problems deregistering the SE, but it proceeds to deregister it from the CMS database when the **force** option is used:

```
ServiceEngine# cms deregister force
Deregistration requires management service to be stopped.
You will have to manually start it. Stopping management service on this node...
This operation needs to restart http proxy and streaming proxies/servers (if running) for
memory reconfiguration. Proceed? [ no ] yes
management services stopped
Thu Jun 26 13:17:34 UTC 2003 [ I ] main: creating 24 messages
Thu Jun 26 13:17:34 UTC 2003 [ I ] main: creating 12 dispatchers
Thu Jun 26 13:17:34 UTC 2003 [ I ] main: sending eDeRegistration message to CDSM
10.107.192.168
...
ServiceEngine#
```

The following example shows the use of the **cms recover identity** command when the recovery request matches the SE record, and the CDSM updates the existing record and sends a registration response to the requesting SE:

```
ServiceEngine# cms recover identity default
Registering this node as Service Engine...
Sending identity recovery request with key default
Thu Jun 26 12:54:42 UTC 2003 [ I ] main: creating 24 messages
Thu Jun 26 12:54:42 UTC 2003 [ I ] main: creating 12 dispatchers
Thu Jun 26 12:54:42 UTC 2003 [ I ] main: Sending registration message to CDSM
10.107.192.168
Thu Jun 26 12:54:44 UTC 2003 [ W ] main: Unable to load device info file in TestServer
Thu Jun 26 12:54:44 UTC 2003 [ I ] main: Connecting storeSetup for SE.
Thu Jun 26 12:54:44 UTC 2003 [ I ] main: Instantiating AStore
'com.cisco.unicorn.schema.PSqlStore'...
Thu Jun 26 12:54:45 UTC 2003 [ I ] main: Successfully connected to database
Thu Jun 26 12:54:45 UTC 2003 [ I ] main: Registering object factories for persistent
store...
Thu Jun 26 12:54:51 UTC 2003 [ I ] main: Dropped Sequence IDSET.
Thu Jun 26 12:54:51 UTC 2003 [ I ] main: Successfully removed old management tables
Thu Jun 26 12:54:51 UTC 2003 [ I ] main: Registering object factories for persistent
store...
.
.
.
Thu Jun 26 12:54:54 UTC 2003 [ I ] main: Created Table FILE_CDSM.
Thu Jun 26 12:54:55 UTC 2003 [ I ] main: Created SYS_MESS_TIME_IDX index.
```

```

Thu Jun 26 12:54:55 UTC 2003 [ I ] main: Created SYS_MESS_NODE_IDX index.
Thu Jun 26 12:54:55 UTC 2003 [ I ] main: No Consistency check for store.
Thu Jun 26 12:54:55 UTC 2003 [ I ] main: Successfully created management tables
Thu Jun 26 12:54:55 UTC 2003 [ I ] main: Registering object factories for persistent
store...
Thu Jun 26 12:54:55 UTC 2003 [ I ] main: AStore Loading store data...
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: ExtExpiresRecord Loaded 0 Expires records.
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: Skipping Construction RdToClusterMappings on
non-CDSM node.
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: AStore Done Loading. 327
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: Created SYS_MESS_TIME_IDX index.
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: Created SYS_MESS_NODE_IDX index.
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: No Consistency check for store.
Thu Jun 26 12:54:56 UTC 2003 [ I ] main: Successfully initialized management tables
Node successfully registered with id 103
Registration complete.
ServiceEngine#

```

The following example shows the use of the **cms recover identity** command when the hostname of the SE does not match the hostname configured in the CDSM GUI:

```

ServiceEngine# cms recover identity default
Registering this node as Service Engine...
Sending identity recovery request with key default
Thu Jun 26 13:16:09 UTC 2003 [ I ] main: creating 24 messages
Thu Jun 26 13:16:09 UTC 2003 [ I ] main: creating 12 dispatchers
Thu Jun 26 13:16:09 UTC 2003 [ I ] main: Sending registration message to CDSM
10.107.192.168
There are no SE devices in CDN
register: Registration failed.
ServiceEngine#

```

## Related Commands

Command	Description
<b>cms enable</b>	Enables the CMS.
<b>show cms</b>	Displays the CMS protocol, embedded database content, maintenance status, and other information.

## cms (Global configuration)

To schedule maintenance and enable the Centralized Management System (CMS) on a given node, use the **cms** command in Global configuration mode. To negate these actions, use the **no** form of this command.

```
cms {database maintenance {full {enable | schedule weekday at time} | regular {enable |
schedule weekday at time} } | enable | rpc timeout {connection 5-1800 | incoming-wait
10-600 | transfer 10-7200} }
```

```
no cms {database maintenance {full {enable | schedule weekday at time} | regular {enable |
schedule weekday at time} } | enable | rpc timeout {connection 5-1800 | incoming-wait
10-600 | transfer 10-7200} }
```

Syntax Description	
<b>database maintenance</b>	Configures the embedded database, clean, or reindex maintenance routine.
<b>full</b>	Configures the full maintenance routine and cleans the embedded database tables.
<b>enable</b>	Enables the full maintenance routine to be performed on the embedded database tables.
<b>schedule</b>	Sets the schedule for performing the maintenance routine.
<i>weekday</i>	Day of the week to start the maintenance routine. every-day—Every day Fri—every Friday Mon—every Monday Sat—every Saturday Sun—every Sunday Thu—every Thursday Tue—every Tuesday Wed—every Wednesday
<b>at</b>	Sets the maintenance schedule time of day to start the maintenance routine.
<i>time</i>	Time of day to start the maintenance routine (0 to 23:0 to 59) in hh:mm format.
<b>regular</b>	Configures the regular maintenance routine and reindexes the embedded database tables.
<b>enable</b>	Enables the node CMS process.
<b>rpc timeout</b>	Configures the timeout values for remote procedure call connections.
<b>connection</b>	Specifies the maximum time to wait for when making a connection.
<i>5-1800</i>	Timeout period, in seconds. The default for the CDSM is 30; the default for the SE and the SR is 180.
<b>incoming-wait</b>	Specifies the maximum time to wait for a client response.
<i>10-600</i>	Timeout period, in seconds. The default is 30.
<b>transfer</b>	Specifies the maximum time to allow a connection to remain open.
<i>10-7200</i>	Timeout period, in seconds. The default is 300.

**Command Defaults****database maintenance regular:** enabled**database maintenance full:** enabled**connection:** 30 seconds for CDSM; 180 seconds for the SE and the SR**incoming wait:** 30 seconds**transfer:** 300 seconds**Command Modes**

Global configuration (config) mode.

**Usage Guidelines**

Use the **cms database maintenance** command to schedule routine, full-maintenance cleaning (vacuuming) or a regular maintenance reindexing of the embedded database. The full maintenance routine runs only when the disk is more than 90 percent full and runs only once a week. Cleaning the tables returns reusable space to the database system.

The **cms enable** command automatically registers the node in the database management tables and enables the CMS process. The **no cms enable** command stops only the management services on the device and does not disable a primary sender. You can use the **cms deregister** command to remove a primary or backup sender SE from the CDS network and to disable communication between two multicast senders.

**Examples**

The following example shows how to schedule a regular (reindexing) maintenance routine to start every Friday at 11:00 p.m.:

```
ServiceEngine(config)# cms database maintenance regular schedule Fri at 23:00
```

The following example shows how to enable the CMS process on an SE:

```
ServiceEngine(config)# cms enable
This operation needs to restart http proxy and streaming proxies/servers (if running) for
memory reconfiguration. Proceed? [ no ] yes
Registering this node as Service Engine...
Thu Jun 26 13:18:24 UTC 2003 [ I ] main: creating 24 messages
Thu Jun 26 13:18:25 UTC 2003 [ I ] main: creating 12 dispatchers
Thu Jun 26 13:18:25 UTC 2003 [ I ] main: Sending registration message to CDSM
10.107.192.168
Thu Jun 26 13:18:27 UTC 2003 [ I ] main: Connecting storeSetup for SE.
Thu Jun 26 13:18:27 UTC 2003 [ I ] main: Instantiating AStore
'com.cisco.unicorn.schema.PSqlStore'...
Thu Jun 26 13:18:28 UTC 2003 [ I ] main: Successfully connected to database
Thu Jun 26 13:18:28 UTC 2003 [ I ] main: Registering object factories for persistent
store...
Thu Jun 26 13:18:35 UTC 2003 [ I ] main: Dropped Sequence IDSET.
Thu Jun 26 13:18:35 UTC 2003 [ I ] main: Dropped Sequence GENSET.
Thu Jun 26 13:18:35 UTC 2003 [ I ] main: Dropped Table USER_TO_DOMAIN.
.
.
.
Thu Jun 26 13:18:39 UTC 2003 [ I ] main: Created Table FILE_CDSM.
Thu Jun 26 13:18:40 UTC 2003 [ I ] main: Created SYS_MESS_TIME_IDX index.
Thu Jun 26 13:18:40 UTC 2003 [ I ] main: Created SYS_MESS_NODE_IDX index.
Thu Jun 26 13:18:40 UTC 2003 [ I ] main: No Consistency check for store.
Thu Jun 26 13:18:40 UTC 2003 [ I ] main: Successfully created management tables
Thu Jun 26 13:18:40 UTC 2003 [ I ] main: Registering object factories for persistent
store...
```



```

Thu Jun 26 13:18:40 UTC 2003 [ I ] main: AStore Loading store data...
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: ExtExpiresRecord Loaded 0 Expires records.
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: Skipping Construction RdToClusterMappings on
non-CDSM node.
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: AStore Done Loading. 336
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: Created SYS_MESS_TIME_IDX index.
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: Created SYS_MESS_NODE_IDX index.
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: No Consistency check for store.
Thu Jun 26 13:18:41 UTC 2003 [ I ] main: Successfully initialized management tables
Node successfully registered with id 28940
Registration complete.
Warning: The device will now be managed by the CDSM. Any configuration changes
made via CLI on this device will be overwritten if they conflict with settings on the
CDSM.
Please preserve running configuration using 'copy running-config startup-config'.
Otherwise management service will not be started on reload and node will be shown
'offline' in CDSM UI.
management services enabled
ServiceEngine(config)#

```

## Related Commands

Command	Description
<b>cms database</b>	Creates, backs up, deletes, restores, or validates the CMS-embedded database management tables or files.
<b>show cms</b>	Displays the CMS protocol, embedded database content, maintenance status, and other information.

# configure

To enter Global configuration mode, use the **configure** command in EXEC configuration mode.

## configure

To exit Global configuration mode, use the **end** or **exit** commands. In addition, you can press **Ctrl-Z** to exit from Global configuration mode.

### Syntax Description

This command has no arguments or keywords.

### Command Defaults

None

### Command Modes

EXEC configuration mode.

### Examples

The following example shows how to enable Global configuration mode:

```
ServiceEngine# configure
ServiceEngine(config)#
```

### Related Commands

Command	Description
<b>end</b>	Exits configuration and privileged EXEC configuration modes.
<b>exit</b>	Exits from interface, Global configuration, or privileged EXEC configuration modes.
<b>show running-config</b>	Displays the current operating configuration.
<b>show startup-config</b>	Displays the startup configuration.

# copy

To copy the configuration or image data from a source to a destination, use the **copy** command in EXEC configuration mode.

**copy cdnfs disk** *url sysfs-filename*

**copy cdrom install** *filedir filename*

**copy disk** {**ftp** {*hostname* | *ip-address*} *remotefile* *remotefilename* *localfilename* | **startup-config** *filename*}

**copy ftp** {**disk** {*hostname* | *ip-address*} *remotefile* *remotefilename* *localfilename* | **install** {*hostname* | *ip-address*} *remotefile* *remotefilename*}

**copy http install** { {*hostname* | *ip-address*} *remotefile* *remotefilename*} [**port** *port-num*] [**proxy** {*hostname* | *ip-address*} {*hostname* | *ip-address*} | **username** *username* *password* [**proxy** {*hostname* | *ip-address*} *proxy\_portnum* | **username** *username* *password* [**proxy** {*hostname* | *ip-address*} *proxy\_portnum*] ]

**copy running-config** {**disk** *filename* | **startup-config**}

**copy startup-config** {**disk** *filename* | **running-config**}

**copy system-status disk** *filename*

**copy tech-support** {**disk** *filename* | *remotefilename*}

## Syntax Description

<b>cdnfs</b>	Copies a file from the CDNFS to the sysfs.
<b>disk</b>	Copies a file to the disk.
<i>url</i>	URL of the CDNFS file to be copied to the sysfs.
<i>sysfs-filename</i>	Filename to be copied in the sysfs.
<b>cdrom</b>	Copies a file from the CD-ROM.
<b>install</b>	Installs the software release file.
<i>filedir</i>	Directory location of the software release file.
<i>filename</i>	Filename of the software release file.
<b>disk</b>	Copies a local disk file.
<b>ftp</b>	Copies to a file on an FTP server.
<i>hostname</i>	Hostname of the FTP server.
<i>ip-address</i>	IP address of the FTP server.
<i>remotefile</i>	Directory on the FTP server to which the local file is copied.
<i>remotefilename</i>	Name of the local file after it has been copied to the FTP server.
<i>localfilename</i>	Name of the local file to be copied.
<b>startup-config</b>	Copies the configuration file from the disk to startup configuration (NVRAM).
<i>filename</i>	Name of the existing configuration file.

<b>ftp</b>	Copies a file from an FTP server.
<b>disk</b>	Copies a file to a local disk.
<i>hostname</i>	Hostname of the FTP server.
<i>ip-address</i>	IP address of the FTP server.
<i>remotefile</i>	Directory on the FTP server where the file to be copied is located.
<i>remotefilename</i>	Name of the file to be copied to the local disk.
<i>localfilename</i>	Name of the copied file as it appears on the local disk.
<b>install</b>	Copies the file from an FTP server and installs the software release file to the local device.
<i>hostname</i>	Name of the FTP server.
<i>ip-address</i>	IP address of the FTP server.
<i>remotefile</i>	Remote file directory.
<i>remotefilename</i>	Remote filename.
<b>http install</b>	Copies the file from an HTTP server and installs the software release file on a local device.
<i>hostname</i>	Name of the HTTP server.
<i>ip-address</i>	IP address of the HTTP server.
<i>remotefile</i>	Remote file directory.
<i>remotefilename</i>	Remote filename.
<b>port</b>	(Optional) Specifies the port to connect to the HTTP server. The default is 80.
<i>port-num</i>	HTTP server port number. The range is from 1 to 65535.
<b>proxy</b>	Allows the request to be redirected to an HTTP proxy server.
<i>hostname</i>	Name of the HTTP server.
<i>ip-address</i>	IP address of the HTTP server.
<i>proxy_portnum</i>	HTTP proxy server port number. The range is from 1 to 65535.
<b>username</b>	Specifies the username to access the HTTP proxy server.
<i>username</i>	User login name.
<b>running-config</b>	Copies the current system configuration.
<b>disk</b>	Copies the current system configuration to a disk file.
<i>filename</i>	Name of the file to be created on disk.
<b>startup-config</b>	Copies the running configuration to the startup configuration (NVRAM).
<b>disk</b>	Copies the startup configuration to a disk file.
<i>filename</i>	Name of the startup configuration file to be copied to the local disk.
<b>running-config</b>	Copies the startup configuration to a running configuration.
<b>system-status disk</b>	Copies the system status to a disk file.
<i>filename</i>	Name of the file to be created on the disk.
<b>tech-support</b>	Copies system information for technical support.
<b>disk</b>	Copies system information for technical support to a disk file.
<i>filename</i>	Name of the file to be created on disk.
<i>remotefilename</i>	Remote filename of the system information file to be created on the TFTP server. Use the complete pathname.

**Command Defaults****HTTP server port:** 80**Default working directory for sysfs files:** /local1**Command Modes**

EXEC configuration mode.

**Usage Guidelines**

The **copy cdnfs** command in EXEC configuration mode copies data files from of the CDNFS to the sysfs for further processing. For example, you can use the **install imagefilename** command in EXEC configuration mode to provide the copied files to the command.

The **copy cdrom install** command is only supported on the CDE100 and the CDE200.

The **copy disk ftp** command copies files from a sysfs partition to an FTP server. The **copy disk startup-config** command copies a startup configuration file to NVRAM.

The **copy ftp disk** command copies a file from an FTP server to a sysfs partition.

Use the **copy ftp install** command to install an image file from an FTP server. Part of the image goes to the disk and part goes to the flash memory.

Use the **copy http install** command to install an image file from an HTTP server and install it on a local device. It transfers the image from an HTTP server to the SE using HTTP as the transport protocol and installs the software on the device. Part of the image goes to the disk and part goes to the flash memory. You can also use this command to redirect your transfer to a different location or HTTP proxy server, by specifying the **proxy hostname | ip-address** option. A username and a password have to be authenticated with the remote HTTP server if the server is password protected and requires authentication before the transfer of the software release file to the SE is allowed.

Use the **copy cdrom install** command to install the image from the rescue CD:

```
ServiceEngine# copy cdrom install /images CDS24.bin
```

Use the **copy running-config** command to copy the running system configuration to a sysfs partition or flash memory. The **copy running-config startup-config** command is equivalent to the **write memory** command.

The **copy startup-config** command copies the startup configuration file to a sysfs partition.

The **copy system-status** command creates a file on a sysfs partition containing hardware and software status information.

The **copy tech-support tftp** command copies technical support information to a a sysfs partition.

**Related Commands**

Command	Description
<b>install</b>	Installs a new version of the caching application.
<b>reload</b>	Halts a device and performs a cold restart.
<b>show running-config</b>	Displays the current operating configuration.
<b>show startup-config</b>	Displays the startup configuration.
<b>write</b>	Writes or erases the startup configurations to NVRAM or to a terminal session, or writes the MIB persistence configuration to disk.

# cpfile

To make a copy of a file, use the **cpfile** command in EXEC configuration mode.

**cpfile** *oldfilename* *newfilename*

## Syntax Description

<i>oldfilename</i>	Name of the file to be copied.
<i>newfilename</i>	Name of the copy to be created.

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Usage Guidelines

Use this command to create a copy of a file. Only sysfs files can be copied.

## Examples

The following example shows how to create a copy of a file:

```
ServiceEngine# cpfile syslog.txt syslog.txt.save
```

## Related Commands

Command	Description
<b>copy</b>	Copies the configuration or image files to and from the CD-ROM, flash memory, disk, or remote hosts.
<b>dir</b>	Displays the files in a long-list format.
<b>lls</b>	Displays the files in a long-list format.
<b>ls</b>	Lists the files and subdirectories in a directory.
<b>mkfile</b>	Makes a file (for testing).
<b>rename</b>	Renames a file.
<b>rmdir</b>	Removes a directory.

# debug

To monitor and record caching application functions, use the **debug** command in EXEC configuration mode. To disable these functions, use the **no** form of this command.

**debug** *option*

**no debug** *option*

<b>Syntax Description</b>	<i>option</i>	Specifies the debugger type; see the <a href="#">Usage Guidelines</a> section for valid values.
---------------------------	---------------	---

<b>Command Defaults</b>	<b>debug all:</b> default logging level is ERROR.
-------------------------	---

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

<b>Usage Guidelines</b>	<p>We recommend that you use the <b>debug</b> command only at the direction of Cisco TAC because the SE performance is affected when you enter the <b>debug</b> command.</p> <p>You can use the <b>logging disk priority debug</b> command with the <b>debug</b> command. This configuration causes the debugging messages to be logged in the syslog file, which is available in the /local1 directory by default. You can then download the messages from the SE, copy them to a local disk file (for example, using the <b>copy disk ftp</b> command), and forward the logs to Cisco TAC for further investigation.</p> <p>By default, system log messages are logged to the console and you need to copy and paste the output to a file. However, this method of obtaining logs is more prone to errors than capturing all messages in the syslog.txt file. When you use system logging to a disk file instead of system logging to a console, there is no immediate feedback that debug logging is occurring, except that the syslog.txt file gets larger (you can track the lines added to the syslog.txt file by entering the <b>type-tail syslog.txt follow</b> command).</p> <p>When you have completed downloading the system logs to a local disk, disable the debugging functions by using the <b>undebug</b> command (see the “<a href="#">undebug</a>” section on page 2-820 section for more details), and reset the level of logging disk priority to any other setting that you want (for example, <b>notice</b> priority).</p> <p><a href="#">Table 2-5</a> shows valid values for the <b>debug</b> command options.</p>
-------------------------	--

**Table 2-5** *debug Command Options*

<b>access-lists 300</b>	Debugs the ACL.
<b>dump</b>	Dumps the ACL contents.
<b>query</b>	Queries the ACL configuration.
<b>username username</b>	Queries the ACL username.
<b>groupname groupnames</b>	Queries the ACL group name or names of groups of which the user is a member. Each group name must be separated by a comma.

**Table 2-5** *debug Command Options*

<b>acquirer</b>	Debugs the acquirer.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>all</b>	Enables all debugging.
<b>authentication</b>	Debugs authentication.
<b>user</b>	Debugs the user login against the system authentication.
<b>authsvr</b>	Debugs the Authentication Server.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>bandwidth</b>	Debugs the bandwidth module.
<b>advanced</b>	Advanced bandwidth controller debug commands.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>buf</b>	Debugs the buffer manager.
<b>all</b>	Debugs all buffer manager functions.
<b>dmbuf</b>	Debugs the buffer manager dmbuf.
<b>dmsg</b>	Debugs the buffer manager dmsg.
<b>cache-content</b>	Debugs the caching service.
<b>all</b>	(Optional) Sets the debug level to all.
<b>error</b>	(Optional) Sets the debug level to error.
<b>trace</b>	(Optional) Sets the debug level to trace.
<b>cache-router</b>	Debugs the caching router.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>cdnfs</b>	Debugs the CNNFS.
<b>cli</b>	Debugs the CLI command.
<b>all</b>	Debugs all CLI commands.
<b>bin</b>	Debugs the CLI command binary program.
<b>parser</b>	Debugs the CLI command parser.
<b>cms</b>	Debugs the CMS.
<b>content-mgr</b>	Debugs the Content Manager.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.



**Table 2-5** *debug Command Options*

<b>dataserver</b>	Debugs the data server.
<b>all</b>	Debuts all data server functions.
<b>clientlib</b>	Debugs the data server client library module.
<b>server</b>	Debugs the data server module.
<b>dfs</b>	Debugs the DFS.
<b>all</b>	Sets the debug level to all.
<b>api</b>	Debugs the DFS application API.
<b>diskcache</b>	Debugs the DFS in-memory disk-directory cache management.
<b>memcache</b>	Debugs the DFS in-memory cache.
<b>rawio</b>	Debugs the DFS raw disk I/O.
<b>dhcp</b>	Debugs the DHCP.

**Table 2-5** *debug Command Options*

<b>distribution</b>	Debugs the distribution components.
<b>all</b>	Debugs all distribution components.
<b>error</b>	Debugs all distribution components to error level 1 (show error).
<b>trace</b>	Debugs all distribution components to trace level 2 (show error and trace).
<b>metadata-receiver</b>	Debugs the metadata receiver distribution component.
<b>error</b>	Debugs the metadata receiver distribution component to error level 1.
<b>trace</b>	Debugs the metadata receiver distribution component to trace level 2.
<b>metadata-sender</b>	Debugs the metadata sender distribution component.
<b>error</b>	Debugs the metadata sender distribution component to error level 1.
<b>trace</b>	Debugs the metadata sender distribution component to trace level 2.
<b>mcast-receiver</b>	Debugs the multicast receiver distribution component.
<b>error</b>	Debugs the multicast receiver distribution component to error level 1.
<b>trace</b>	Debugs the multicast receiver distribution component to trace level 2.
<b>mcast-sender</b>	Debugs the multicast sender distribution component.
<b>error</b>	Debugs the multicast sender distribution component to error level 1.
<b>trace</b>	Debugs the multicast sender distribution component to trace level 2.
<b>unicast-data-receiver</b>	Debugs the unicast receiver distribution component.
<b>error</b>	Debugs the unicast receiver distribution component to error level 1.
<b>trace</b>	Debugs the unicast receiver distribution component to trace level 2.
<b>unicast-data-sender</b>	Debugs the unicast sender distribution component.
<b>error</b>	Debugs the unicast sender distribution component to error level 1.
<b>trace</b>	Debugs the unicast sender distribution component to trace level 2.
<b>emdb</b>	Debugs the embedded database.
<b>level</b>	(Optional) Debug level.
<b>(0-16)</b>	Debug level 0 through 16.
<b>flash-media-streaming</b>	Debugs Flash Media Streaming.
<b>error</b>	Debugs the Flash Media Streaming log level error.
<b>trace</b>	Debugs the Flash Media Streaming log level debug.

**Table 2-5** *debug Command Options*

<b>http</b>	Debugs HTTP.
<b>service-router</b>	Debugs the HTTP Service Router.
<b>icap</b>	Debugs ICAP.
<b>all</b>	Debugs both ICAP client and ICAP daemon processing.
<b>client</b>	Debugs the ICAP client (caching proxy) processing.
<b>daemon</b>	Debugs the ICAP daemon processing.
<b>isis</b>	Debugs IS-IS Routing for IP.
<b>adjacency</b>	Debugs IS-IS adjacency information.
<b>all</b>	Debugs all IS-IS debugging.
<b>csnp</b>	Debugs IS-IS Complete Sequence Number PDU (CSNP) information.
<b>dis</b>	Debugs IS-IS DIS election information.
<b>esis</b>	Debugs IS-IS ESIS information.
<b>event</b>	Debugs IS-IS event information.
<b>hello</b>	Debugs IS-IS hello information.
<b>lsp</b>	Debugs IS-IS timer LSP information.
<b>mpls</b>	Debugs IS-IS MPLS information.
<b>psnp</b>	Debugs IS-IS PSNP information.
<b>spf</b>	Debugs IS-IS SPF information.
<b>timer</b>	Debugs IS-IS timer information.
<b>logging</b>	Debugs logging.
<b>all</b>	Debugs all logging functions.

Table 2-5 *debug Command Options*

<b>malloc</b>	Debug commands for memory allocation.
<b>cache-app</b>	Debugging commands for cache application memory allocation.
<b>all</b>	Sets the debug level to all.
<b>caller-accounting</b>	Collects statistics for every distinct allocation call-stack.
<b>catch-double-free</b>	Alerts if application attempts to release the same memory twice.
<b>check-boundaries</b>	Checks boundary over and under run scribble.
<b>check-free-chunks</b>	Checks if free chunks are over-written after release.
<b>clear-on-alloc</b>	Ensures all allocations are zero-cleared.
<b>statistics</b>	Allocator use statistical summary.
<b>dns-server</b>	DNS Caching Service memory allocation debugging.
<b>all</b>	Sets the debug level to all.
<b>caller-accounting</b>	Collects statistics for every distinct allocation call-stack.
<b>catch-double-free</b>	Alerts if application attempts to release the same memory twice.
<b>check-boundaries</b>	Checks boundary over and under run scribble.
<b>icap</b>	ICAP Service memory allocation debugging.
<b>caller-accounting</b>	Collects statistics for every distinct allocation call-stack.
<b>catch-double-free</b>	Alerts if application attempts to release the same memory twice.
<b>check-boundaries</b>	Checks boundary over and under run scribble.
<b>log-directory</b>	Memory allocation debugging log directory.
<b>word</b>	Directory path name.
<b>movie-streamer</b>	Debug commands for the Movie Streamer.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>ntp</b>	Debugs NTP.
<b>qos</b>	Debug commands for the QoS component.
<b>policy service</b>	Debug commands for the policy service.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>rbcp</b>	Debugs the RBCP (Router Blade Configuration Protocol) functions.
<b>rpc</b>	Displays the remote procedure call (RPC) logs.
<b>detail</b>	Displays the RPC logs of priority <i>detail</i> level or higher.
<b>trace</b>	Displays the RPC logs of priority <i>trace</i> level or higher.

**Table 2-5** *debug Command Options*

<b>rtsp</b>	Debugs the RTSP functions.
<b>gateway</b>	Debugs the RTSP gateway.
<b>error</b>	Debugs the RTSP gateway to level 1 (show error).
<b>trace</b>	Debugs the RTSP gateway to level 2 (show error and trace).
<b>rule</b>	Debugs the Rules Template.
<b>action</b>	Debugs the rule action.
<b>all</b>	Debugs all rule functions.
<b>pattern</b>	Debugs the rule pattern.
<b>service-router</b>	Debug commands for the Service Router.
<b>servicemonitor</b>	Debug commands for the service monitor.
<b>session-manager</b>	Session manager debug commands.
<b>critical</b>	Sets the debug level to critical.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>snmp</b>	Debugs SNMP.
<b>all</b>	Debugs all SNMP functions.
<b>cli</b>	Debugs the SNMP CLI.
<b>main</b>	Debugs the SNMP main.
<b>mib</b>	Debugs the SNMP MIB.
<b>traps</b>	Debugs the SNMP traps.

**Table 2-5** *debug Command Options*

<b>srp</b>	Debugs the Service Routing Protocols.
<b>all</b>	Debugs all SRP.
<b>api</b>	Debugs the SRP API.
<b>configuration</b>	Debugs the SRP configuration.
<b>database</b>	Debugs the SRP database.
<b>error</b>	Debugs the SRP error.
<b>function</b>	Debugs the SRP function.
<b>host</b>	Debugs the SRP host.
<b>internal</b>	Debugs the SRP internal.
<b>ippc</b>	Debugs the SRP ippc (inter process command).
<b>ippc-dump</b>	Debugs the SRP ippc (pkt) dump.
<b>key</b>	Debugs the SRP key.
<b>leafset</b>	Debugs the SRP leafset.
<b>lock</b>	Debugs the SRP lock.
<b>multicast</b>	Debugs the SRP multicast.
<b>neighbor</b>	Debugs the SRP neighbor.
<b>packet</b>	Debugs the SRP packet.
<b>private</b>	Debugs the SRP private.
<b>replica</b>	Debugs the SRP replica.
<b>route</b>	Debugs the SRP route.
<b>session</b>	Debugs the SRP session.
<b>srhp-packet</b>	Debugs the SRP srhp packet.
<b>startup</b>	Debugs the SRP startup.
<b>sync</b>	Debugs the SRP sync.
<b>standby</b>	Debugs standby functions.
<b>all</b>	(Optional) Debugs all standby functions.
<b>stats</b>	Debugs the statistics.
<b>all</b>	Debugs all statistics functions.
<b>collection</b>	Debugs the statistics collection.
<b>computation</b>	Debugs the statistics computation.
<b>history</b>	Debugs the statistics history.

**Table 2-5** *debug Command Options*

<b>svc</b>	Debugs the Service Registration Daemon and Descriptor Interpreter.
<b>all</b>	Debugs all SVCREG and Descriptor Interpreter Library (DESCI). DESCI debug commands.
<b>desci</b>	Debugs DESCi desc.
<b>desc</b>	DESCi internal error.
<b>err</b>	Debugs DESCi ippc (inter process comm).
<b>ippc</b>	Debugs DESCi xml.
<b>xml</b>	Service Registry Daemon (SVCREG) debug commands.
<b>registry</b>	SVCREG internal error.
<b>err</b>	Debugs SVCREG interface.
<b>if</b>	Debugs SVCREG ippc (inter process comm).
<b>ippc</b>	Debugs SVCREG svc.
<b>svc</b>	Debugs SVCREG ven.
<b>ven</b>	
<b>translog</b>	Debugs the transaction logging.
<b>all</b>	Debugs all transaction logging.
<b>archive</b>	Debugs the transaction log archive.
<b>export</b>	Debugs the transaction log FTP export.
<b>uns</b>	Unified naming service debug commands.
<b>all</b>	(Optional) Sets the debug level to all.
<b>error</b>	(Optional) Sets the debug level to error.
<b>trace</b>	(Optional) Sets the debug level to trace.
<b>webengine</b>	WebEngine debug commands.
<b>error</b>	Sets the debug level to error.
<b>trace</b>	Sets the debug level to trace.
<b>wi</b>	Debugs the web interface.

**Table 2-5** *debug Command Options*

<b>wmt</b>	Debugs the WMT component.
<b>error</b>	Debugs the WMT level 1 functionality. For more information, see the <a href="#">“Using WMT Error Logging” section on page 2-130</a> .
<b>client-ip</b> <i>cl-ip-address</i>	(Optional) Debugs the request from a specific client IP address to level 1 (show error).
<b>server-ip</b> <i>sv-ip-address</i>	(Optional) Debugs the request to a specific server IP address to level 1 (show error).
<b>trace</b>	Debugs the WMT level 2 functionality.
<b>client-ip</b> <i>cl-ip-address</i>	(Optional) Debugs the request from a specific client IP address to level 2 (show error and trace).
<b>server-ip</b> <i>sv-ip-address</i>	(Optional) Debugs the request to a specific server IP address to level 2 (show error and trace).

**Debugging Keywords**

All modules have **debug error** as the default level if they support the **error** keyword; however, when you execute the **show debug** command, the error does not display.

Some modules have two debugging keywords (**error** and **trace**), but you cannot enable both at the same time. See the table above to identify commands with only the **error** and **trace** keywords.

Some modules have the **all** keyword through which you can enable both the **error** and **trace** keywords at the same time. This results in *debug set to everything*. See [Table 2-5](#) to identify commands with the **all** keyword.

**Debugging the Authsvr**

When reloading the Authsvr, the **show debugging** command displays `Debug Authsvr Error is On`, because the Authsvr’s default debugging level = Error. This applies only to the Authsvr and not to other modules. [Table 2-6](#) shows the authsvr debugging commands and provides the corresponding log and error display information.

**Table 2-6** *Debug Authsvr Command Chart*

Command	Debug Log Levels Printed	Show Debugging
undebg authsvr trace	error log	—
undebg authsvr error	error log	—
undebg all	error log	—
debug all	error log	Debug Authsvr error is on.
no debug all	error log	—
debug authsvr error	error log	Debug Authsvr error is on.



**Table 2-6** *Debug Authsvr Command Chart*

Command	Debug Log Levels Printed	Show Debugging
debug authsvr trace	trace error log	Debug Authsvr trace is on.
no debug authsvr trace	error log	—
no debug authsvr error	error log	—

**Debugging Cdnfs**

You can use the **debug cdnfs** command to monitor the lookup and serving of prepositioned files. If prepositioned files are available in CDNFS but are not served properly, you can use the **debug cdnfs** command.

**Using WMT Error Logging**

In Cisco Internet Streamer CDS Release 2.5 software, WMT error logging was enhanced. Additional information is now logged about the following events:

- When a WMT client is abruptly disconnected
- When any WMT streams are cleared on the SE

Error logs are in the same format and location as syslogs. The WMT log messages are logged to /local1/errorlog/wmt\_errorlog.current.

You can configure the SE for WMT error logging by using the **debug wmt error** command in EXEC configuration mode. This command debugs WMT level 1 functionality.

**Logging WMT Client Disconnects**

When a WMT client is disconnected abruptly, the reasons for the client disconnect (for example, the request was blocked by the rules, the maximum incoming or outgoing bit-rate limit was reached, the maximum incoming or outgoing bandwidth limit was reached) are logged in Internet Streamer CDS software error logs.

The client information includes the client IP address, the server IP address, the requested URL, the client protocol, the version of the client media player, the number of packets that the client received, and the number of packets that the server sent.

**Related Commands**

Command	Description
<b>logging</b>	Configures system logging (syslog).
<b>show debugging</b>	Displays the state of each debugging option.
<b>undebug</b>	Disables the debugging functions (see also <b>debug</b> ).

# debug ip bgp

To display information relating to the BGP process, use the **debug ip bgp** command in privileged EXEC configuration mode. To disable the display of BGP information, use the **undebug** form of this command.

```
debug ip bgp {A.B.C.D. | all | brib | events | internal | io | keepalives | list | packets | rib | updates
}
```

```
undebug ip bgp {A.B.C.D. | all | brib | events | internal | io | keepalives | list | packets | rib |
updates}
```

## Syntax Description

<b>A.B.C.D.</b>	Displays the BGP neighbor IP address.
<b>all</b>	Displays all BGP debugging information.
<b>brib</b>	Displays the BGP BRIB.
<b>dampening</b>	Displays the BGP dampening.
<b>events</b>	Displays BGP events.
<b>internal</b>	Displays BGP internal information.
<b>io</b>	Displays BGP IO information.
<b>keepalives</b>	Displays BGP keepalives.
<b>list</b>	Displays the BGP list.
<b>packets</b>	Displays the BGP packets.
<b>rib</b>	Displays the BGP RIB.
<b>updates</b>	Displays BGP updates.

## Command Defaults

Debugging of the keepalives is turned on upon the start of the BGP daemon.

## Command Modes

Privileged EXEC configuration mode.

## Usage Guidelines

This command turns on BGP debugging information. When **debug ip bgp** is turned on, the performance of the Proximity Engine may be impacted slightly.

## Examples

The following example shows sample output displayed before and after running the **debug ip bgp all** command:

```
ServiceRouter# show debugging ip bgp
Debugs Enabled: Keepalives
ServiceRouter# debug ip bgp all
BGP all information debug is on
ServiceRouter# show debugging ip bgp
Debugs Enabled: Events Internal RIB BRIB Updates Keepalives Packets IO List

ServiceRouter#
```

When the **undebug ip bgp all** command is run, the following output is displayed:

```
ServiceRouter# undebug ip bgp all
BGP all information debug is off
```

**Related Commands**

Command	Description
<b>show debugging ip bgp</b>	Displays the debugging flags that have been set for BGP.

# debug ip ospf

To display information related to OSPF process, use the **debug ip ospf** command in privileged EXEC configuration mode. To disable the display of OSPF information, use the **undebug** form of this command.

```
debug ip ospf {adjacency [detail | terse] | all [detail | terse] | database [detail | terse] |
database-timers | events [detail | terse] | flooding [detail | terse] | hello | lsa-generation
[detail | terse] | packets | retransmission | spf [detail | terse] | spf-trigger [detail] }
```

```
undebug ip ospf {adjacency [detail | terse] | all [detail | terse] | database [detail | terse] |
database-timers | events [detail | terse] | flooding [detail | terse] | hello | lsa-generation
[detail | terse] | packets | retransmission | spf [detail | terse] | spf-trigger [detail] }
```

## Syntax Description

<b>adjacency</b>	Specifies the adjacency events.
<b>detail</b>	Displays detailed neighbor events.
<b>terse</b>	Displays only major events.
<b>all</b>	All OSPF debugging.
<b>database</b>	OSPF LSDB <sup>1</sup> changes.
<b>database-timers</b>	OSPF LSDB timers.
<b>events</b>	OSPF related events.
<b>flooding</b>	LSAs <sup>2</sup> flooding.
<b>hello</b>	Hello packet and DR elections.
<b>lsa-generation</b>	Local OSPF LSA generation.
<b>packets</b>	OSPF packets.
<b>retransmission</b>	OSPF retransmission events.
<b>spf</b>	SPF calculation.
<b>spf-trigger</b>	Show SPF triggers

1. LSDB = link-state database

2. LSAs = link-state advertisement

## Command Defaults

Display of information related to the OSPF process is disabled.

## Command Modes

Privileged EXEC configuration mode.

## Usage Guidelines

When **debug ip ospf** is turned on, the performance of the Proximity Engine may be impacted slightly.

## Examples

Add the **detail** or **terse** keywords to each of the following commands to enable detailed or major events respectively.

The following example shows how to enable neighbor adjacency events:

```
ServiceRouter# debug ip ospf adjacency  
  
ServiceRouter#
```

The following example shows how to enable all OSPF debugging:

```
ServiceRouter# debug ip ospf all  
  
ServiceRouter#
```

The following example shows how to enable debugging for OSPF LSDB changes:

```
ServiceRouter# debug ip ospf database  
  
ServiceRouter#
```

The following example shows how to enable debugging for OSPF LSDB timers:

```
ServiceRouter# debug ip ospf database-timers  
  
ServiceRouter#
```

The following example shows how to enable debugging for OSPF-related events:

```
ServiceRouter# debug ip ospf events  
  
ServiceRouter#
```

The following example shows how to enable debugging for LSA flooding events:

```
ServiceRouter# debug ip ospf flooding  
  
ServiceRouter#
```

The following example shows how to enable debugging for hello packets and DR elections:

```
ServiceRouter# debug ip ospf hello  
  
ServiceRouter#
```

The following example shows how to enable debugging for local OSPF LSA generation events:

```
ServiceRouter# debug ip ospf lsa-generation  
  
ServiceRouter#
```

The following example shows how to enable debugging for of OSPF packets:

```
ServiceRouter# debug ip ospf packets  
  
ServiceRouter#
```

The following example shows how to enable debugging for OSPF retransmission events:

```
ServiceRouter# debug ip ospf retransmission  
  
ServiceRouter#
```

The following example shows how to enable debugging for SPF calculations:

```
ServiceRouter# debug ip ospf spf  
  
ServiceRouter#
```

The following example shows how to enable debugging for SPF triggers:

**■ debug ip ospf**

```
ServiceRouter# debug ip ospf spf-trigger  
ServiceRouter#
```

**Related Commands**

Command	Description
<b>show debugging ip ospf</b>	Displays the state of each debugging option for the OSPF process.

# debug ip rib

To display RIB information, use the **debug ip rib** command in privileged EXEC mode. To disable the display of RIB information, use the **no** form of this command.

**debug ip rib** [**add-route** | **all** | **delete-route** | **detail** | **mod-route** | **proximity** | **rnih** | **summary**]

**no debug ip rib** [**add-route** | **all** | **delete-route** | **detail** | **mod-route** | **proximity** | **rnih** | **summary**]

## Syntax Description

<b>add-route</b>	Adds route events.
<b>all</b>	Displays all IP routing table events.
<b>delete-route</b>	Deletes route events.
<b>detail</b>	Enables detailed debugging for IP routing.
<b>mod-route</b>	Modifies route events.
<b>proximity</b>	Turns on proximity debugging information.
<b>rnih</b>	Turns on recursive next hop events.
<b>summary</b>	Displays a one-line summary of URIB I/O events.

## Command Defaults

None

## Command Modes

Privileged EXEC configuration mode.

## Usage Guidelines

This command is used to display debug information related to the routing information base (RIB).

## Examples

The following example shows how to display the RIB information:

```
ServiceRouter# debug ip rib
```

```
ServiceRouter#
```

The following example shows how to add routes:

```
ServiceRouter# debug ip rib add-route
```

```
ServiceRouter#
```

The following example shows how to turn on all IP routing table events:

```
ServiceRouter# debug ip rib all
```

```
ServiceRouter#
```

The following example shows how to remove routes:

```
ServiceRouter# debug ip rib delete-route
```

```
ServiceRouter#
```

The following example shows how to enable detailed debugging for IP routing:

```
ServiceRouter# debug ip rib detail
```

```
ServiceRouter#
```

The following example shows how to modify IP routing events:

```
ServiceRouter# debug ip rib mod-route
```

```
ServiceRouter#
```

The following example shows how to turn on proximity debugging information:

```
ServiceRouter# debug ip rib proximity
```

```
URIB proximity routing information debug is on
```

```
ServiceRouter#
```

The following example shows how to enable recursive next hop events:

```
ServiceRouter# debug ip rib rnh
```

```
ServiceRouter#
```

The following example shows how to display a one-line summary or URIB I/O events:

```
ServiceRouter# debug ip rib summary
```

```
ServiceRouter#
```

#### Related Commands

Command	Description
<b>show debugging ip rib</b>	Displays the debug options that are enabled for the RIB process.



# debug isis

To display information related to IS-IS process, use the **debug isis** command in privileged EXEC configuration mode. To disable the display of IS-IS information, use the **undebug** form of this command.

```
debug isis [adjacency | all | csnp | dis | esis | event | hello | lsp | mpls | psnp | route-map | spf |
timer]
```

```
undebug isis [adjacency | all | csnp | dis | esis | event | hello | lsp | mpls | psnp | route-map | spf
| timer]
```

Syntax Description		
<b>adjacency</b>		Displays IS adjacency information.
<b>all</b>		Displays all IS-IS debugging information.
<b>csnp</b>		Displays IS-IS CSNP information.
<b>dis</b>		Displays IS-IS DIS election information.
<b>esis</b>		Displays IS-IS ESIS information.
<b>event</b>		Displays IS-IS event information.
<b>hello</b>		Displays IS-IS hello information.
<b>lsp</b>		Displays IS-IS LSP information.
<b>mpls</b>		Displays IS-IS MPLS information.
<b>psnp</b>		Displays IS-IS PSNP information.
<b>route-map</b>		Displays IS-IS route-map policy information.
<b>spf</b>		Displays IS-IS SPF information.
<b>timer</b>		Displays IS-IS timer information.

**Command Defaults** Display of debugging information is disabled.

**Command Modes** Privileged EXEC configuration mode.

**Usage Guidelines** When **debug isis** is turned on, the performance of the Proximity Engine may be impacted slightly.

**Examples** The following example shows how to turn on the debug information for the interaction between IS-IS and the RPM API library:

```
ServiceRouter# debug isis route-map
ServiceRouter#
```

Related Commands	Command	Description
	<b>show debugging isis</b>	Displays the debug options that are enabled for the IS-IS process.

# debug srp

To turn on SRP debugging information, use the **debug srp** command in Privileged EXEC configuration mode. To turn off the debugging information, use the **no** form of this command.

**debug srp** *option*

**no debug srp** *option*

<b>Syntax Description</b>	<i>option</i>	Specifies the category of SRP debugging information to turn on. See <a href="#">Table 2-7</a> for a list of <i>option</i> values.
---------------------------	---------------	---

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	Privileged EXEC configuration mode.
----------------------	-------------------------------------

<b>Usage Guidelines</b>	<p>This command turns on SRP debugging information logging either in the trace file or log file.</p> <p>The log file for SRP is /local/local1/errorlog/srp_log.current. The <i>option</i> argument to the <b>debug srp</b> command specifies a keyword indicating the category of SRP debugging information logging to turn on. <a href="#">Table 2-7</a> lists the values that can be specified in the <i>option</i> argument.</p> <p>Each debugging information message includes a tag that indicates the debugging category. For example, the SRP API debug messages include the tag SRP_DEBUG_API. <a href="#">Table 2-7</a> lists the tags that are used for each category of debugging information.</p> <p>To turn off SRP debugging information, use the <b>undebug srp</b> command in privileged EXEC configuration mode.</p>
-------------------------	---

**Table 2-7** *debug SRP Options*

Option	Tag	Description
<b>all</b>	not applicable	Turns on all categories of SRP debugging information.
<b>api</b>	SRP_DEBUG_API	Turns on SRP API debugging information.
<b>configuration</b>	SRP_DEBUG_CONFIG	Turns on SRP configuration debugging information.
<b>database</b>	SRP_DEBUG_DATABASE	Turns on SRP database debugging information.
<b>error</b>	SRP_DEBUG_ERROR	Turns on SRP error debugging information. Usually, thread creation errors, no memory, key not found, and so forth are reported by this log information.
<b>function</b>	SRP_DEBUG_FUNC	Turns on SRP function debugging information.
<b>host</b>	SRP_DEBUG_HOST	Turns on SRP host debugging information.
<b>internal</b>	SRP_DEBUG_INT_DUMP	Turns on SRP internal debugging information.
<b>ippc</b>	SRP_DEBUG_IPPC	Turns on SRP inter-process procedure (IPPC) call debugging information.
<b>ippc-dump</b>	SRP_DEBUG_IPPC_DUMP	Turns on SRP complete IPPC packet debugging information.

**Table 2-7** *debug SRP Options (continued)*

Option	Tag	Description
<b>key</b>	SRP_DEBUG_KEY	Turns on SRP key-related debugging information.
<b>leafset</b>	SRP_DEBUG_LEAFSET	Turns on SRP leafset debugging information.
<b>lock</b>	SRP_DEBUG_LOCK	Turns on SRP lock and unlock debugging information.
<b>multicast</b>	SRP_DEBUG_MCAST	Turns on SRP multicast debugging information.
<b>neighbor</b>	SRP_DEBUG_NEIGHBOR	Turns on SRP neighbor debugging information.
<b>packet</b>	SRP_DEBUG_PACKET	Turns on SRP packet debugging information (for example, packet type, key, and so forth).
<b>private</b>	SRP_DEBUG_PRIVATE	Turns on SRP debugging information related to private variables and operations.
<b>replica</b>	SRP_DEBUG_REPLICA	Turns on SRP replica debugging information.
<b>route</b>	SRP_DEBUG_ROUTE	Turns on SRP route debugging information.
<b>session</b>	SRP_DEBUG_SESSION	Turns on SRP session debugging information.
<b>srhp-packet</b>	SRP_DEBUG_SRHP_PACKET	Turns on SRP service routing host packet (SRHP) debugging information.
<b>startup</b>	SRP_DEBUG_STARTUP	Turns on SRP startup debugging information.
<b>sync</b>	SRP_DEBUG_SYNC	Turns on SRP debugging information related to synchronization among peers.

**Examples**

The following example shows how to use the **debug srp** command to turn on SRP host and neighbor debugging information logging:

```
ServiceRouter# debug srp host
ServiceRouter# debug srp neighbor
```

**Related Commands**

Command	Description
<b>show debugging srp</b>	Displays the debug flags that are turned on for the SRP.
<b>undebg srp</b>	Turns off SRP debugging information.

# delfile

To delete a file, use the **delfile** command in EXEC configuration mode.

**delfile** *filename*

Syntax Description	<i>filename</i>	Name of the file to delete.
--------------------	-----------------	-----------------------------

Command Defaults	None
------------------	------

Command Modes	EXEC configuration mode.
---------------	--------------------------

Usage Guidelines	Use this command to remove a file from a sysfs partition.
------------------	---

Examples	<p>The following example shows how to delete a file:</p> <pre>ServiceEngine# delfile /local1/tempfile</pre>
----------	---

Related Commands	Command	Description
	<b>cpfile</b>	Copies a file.
	<b>deltree</b>	Deletes a directory and its subdirectories.
	<b>mkdir</b>	Creates a directory.
	<b>mkfile</b>	Creates a file (for testing).
	<b>rmdir</b>	Removes a directory.

# deltree

To remove a directory with its subdirectories and files, use the **deltree** command in EXEC configuration mode.

**deltree** *directory*

Syntax Description	<i>directory</i> Name of the directory tree to delete.
--------------------	--

Command Defaults	None
------------------	------

Command Modes	EXEC configuration mode.
---------------	--------------------------

Usage Guidelines	Use this command to remove a directory and all files within the directory from the SE sysfs file system. Do not remove files or directories required for proper SE functioning.
------------------	---

Examples	The following example shows how to delete a directory from the /local1 directory: ServiceEngine# <b>deltree /local1/testdir</b>
----------	--

Related Commands	Command	Description
	<b>delfile</b>	Deletes a file.
	<b>mkdir</b>	Creates a directory.
	<b>mkfile</b>	Creates a file (for testing).
	<b>rmdir</b>	Removes a directory.

# device

To configure the mode of operation on a device as a CDSM, SE or SR, use the **device** command in Global configuration mode. To reset the mode of operation on a device, use the **no** form of this command.

**device mode** {content-delivery-system-manager | service-engine | service-router }

**no device mode** {content-delivery-system-manager | service-engine | service-router }

## Syntax Description

<b>mode</b>	Sets the mode of operation of a device to CDSM, SE or SR.
<b>content-delivery-system-manager</b>	Configures the device operation mode as a CDSM.
<b>service-engine</b>	Configures the device operation mode as an SE.
<b>service-router</b>	Configures the device operation mode as an SR.

## Command Defaults

The default device operation mode is SE.

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

A CDSM is the content management and device management station of an CDS network that allows you to specify what content is to be distributed, and where the content should be distributed. If an SR is deployed in the CDS network, the SR redirects the client based on redirecting policy. An SE is the device that serves content to the clients. There are typically many SEs deployed in an CDS network, each serving a local set of clients. IP/TV brings movie-quality video over enterprise networks to the desktop of the CDS network user.

Because different device modes require disk space to be used in different ways, disk space must also be configured when the device mode changes from being an SE or SR to CDSM (or the other way around). You must reboot the device before the configuration changes to the device mode take effect.

Disks must be configured before device configuration is changed. Use the **disk configure** command to configure the disk before reconfiguring the device to the SE or SR mode. Disk configuration changes using the **disk configure** command takes effect after the next device reboot.

To enable CDS network-related applications and services, use the **cms enable** command. Use the **no** form of this command to disable the CDS network.

All CDS devices ship from the factory as SEs. Before configuring network settings for CDSMs and SRs using the CLI, change the device from an SE to the proper device mode.

Configuring the device mode is not a supported option on all hardware models. However, you can configure some hardware models to operate as any one of the four content networking device types. Devices that can be reconfigured using the **device mode** command are shipped from the factory by default as SEs.

To change the device mode of your SE, you must also configure the disk space allocations, as required by the different device modes, and reboot the device for the new configuration to take effect.

When you change the device mode of an SE to an SR or CDSM, you may need to reconfigure the system file system (sysfs). However, SRs and CDSMs do not require any disk space other than sysfs. When you change the device mode to an SR or a CDSM, disk configuration changes are not required because the device already has some space allotted for sysfs. sysfs disk space is always preconfigured on a factory-fresh CDS network device. See the [“Disk Space Allocation Guidelines for Service Routers” section on page 2-149](#) and [“Disk Space Allocation Guidelines for CDSMs” section on page 2-149](#) for more information.

If you are changing the device mode of an SR or a CDSM back to an SE, configure disk space allocations for the caching, pre-positioning (CDNFS) and system use (sysfs) file systems that are used on the SE. You can configure disk space allocations either before or after you change the device mode to an SE.

---

### Examples

The following examples show the configuration from the default mode, SE, to the CDSM, SR, and SE modes:

```
ServiceEngine(config)# device mode content-delivery-system-manager
```

```
CDSM(config)# device mode service-router
```

```
ServiceRouter(config)# device mode service-engine
```

---

### Related Commands

Command	Description
<b>show device-mode</b>	Displays the configured or current mode of a CDSM, SE, or SR device.

---

# dir

To view a long list of files in a directory, use the **dir** command in EXEC configuration mode.

**dir** [*directory*]

<b>Syntax Description</b>	<i>directory</i> (Optional) Name of the directory to list.						
<b>Command Defaults</b>	None						
<b>Command Modes</b>	EXEC configuration mode.						
<b>Usage Guidelines</b>	Use this command to view a detailed list of files contained within the working directory, including names, sizes, and time created. The equivalent command is <b>lls</b> .						
<b>Examples</b>	<p>The following example shows how to view a list of files in a directory:</p> <pre>ServiceEngine# dir size          time of last change          name ----- 3931934 Tue Sep 19 10:41:32 2000 errlog-cache-20000918-164015 431 Mon Sep 18 16:57:40 2000 ii.cfg 431 Mon Sep 18 17:27:46 2000 ii4.cfg 431 Mon Sep 18 16:54:50 2000 iii.cfg 1453 Tue Sep 19 10:34:03 2000 syslog.txt 1024 Tue Sep 19 10:41:31 2000 &lt;DIR&gt; testdir</pre>						
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>lls</b></td><td>Displays the files in a long list format.</td></tr> <tr> <td><b>ls</b></td><td>Lists the files and subdirectories in a directory.</td></tr> </table>	Command	Description	<b>lls</b>	Displays the files in a long list format.	<b>ls</b>	Lists the files and subdirectories in a directory.
Command	Description						
<b>lls</b>	Displays the files in a long list format.						
<b>ls</b>	Lists the files and subdirectories in a directory.						



# direct-server-return

To enable a VIP for direct server return, use the **direct-server-return** command in Global configuration mode. To disable direct server return, use the **no** form of this command.

**direct-server-return vip ip address**

**no direct-server-return vip ip address**

<b>Syntax Description</b>	<b>vip</b>	Specifies the VIP for direct-server-return.
	<i>ip address</i>	VIP for direct-server-return.

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	Global configuration (config) mode.
----------------------	-------------------------------------

<b>Usage Guidelines</b>	<i>Direct Server Return</i> (DSR) is a method used by load balancer servers in a load balancing configuration. DSR responds directly to the client, bypassing the load balancer in the response path. <a href="#">Table 2-8</a> shows the Direct Server Return flow.
-------------------------	--

**Table 2-8 Direct Server Return Flow**

Step	Process	Source IP	Destination IP	Destination MAC
Step 1	Client to load balancer	171.71.50.140	170.1.1.45	00:30:48:C3:C7:C5
Step 2	Load balancer to SR	171.71.50.140	170.1.1.45	00:14:5E:83:6E:7E
Step 3	SR to client	170.1.1.45	171.71.50.140	Default Gateway MAC

<b>Examples</b>	The following example shows how to enable direct server return:
-----------------	---

```
ServiceEngine(config)# direct-server-return vip 1.1.1.1
ServiceEngine(config)#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show direct-server-return</b>	Displays the Direct Server Return information.

# disable

To turn off privileged command in EXEC configuration mode, use the **disable** command in EXEC configuration mode.

**disable**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Defaults** None

---

**Command Modes** EXEC configuration mode.

---

**Usage Guidelines** The **disable** command places you in the user-level EXEC shell. To turn privileged EXEC configuration mode back on, use the **enable** command.

---

**Examples** The following example shows how to enter the user-level EXEC configuration mode:

```
ServiceEngine# disable
ServiceEngine>
```

---

Related Commands	Command	Description
	<b>enable</b>	Accesses the privileged EXEC commands.

---

## disk (EXEC)

To configure disks and allocate disk space for devices that are using the CDS software, use the **disk** command in EXEC configuration mode.

```
disk {erase diskname | mark diskname {bad | good} | policy apply | recover-cdnfs-volumes |
recover-system-volumes | repair diskname sector sector_address_in_decimal | unuse
diskname}
```

Syntax Description		
<b>erase</b>		Erases drive (DANGEROUS).
<i>diskname</i>		Name of the disk to be erased (disk00, disk01, and so on).
<b>mark</b>		Marks a disk drive as good or bad.
<i>diskname</i>		Name of the disk to be marked (disk01, disk02, and so on).
<b>bad</b>		Marks the disk drive as bad.
<b>good</b>		Marks the disk drive as good.
<b>policy</b>		Applies disk policy management.
<b>apply</b>		Invokes the disk policy manager for a disk.
<b>recover-cdnfs-volumes</b>		Erases all CDNFS volumes and reboots.
<b>recover-system-volumes</b>		Erases all SYSTEM and SYSFS volumes.
<b>repair</b>		Repairs the drive.
<i>diskname</i>		Name of the disk to be repaired (disk00, disk01, and so on).
<b>sector</b>		Repairs an uncorrectable sector.
<i>sector_address_in_decimal</i>		Name of the sector address in decimal.
<b>unuse</b>		Stops applications from using a disk drive.
<i>diskname</i>		Name of the disk to be stopped for application use (disk01, disk02, and so on).

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Usage Guidelines** The disk space in the CDS software is allocated on a per-file system basis, rather than on a per-disk basis. You can configure your overall disk storage allocations according to the kinds of client protocols that you expect to use and the amount of storage that you need to provide for each of the functions.



### Note

For details on the Cisco Internet Streamer CDS software disk storage and configuration requirements for SEs, see the [Cisco Internet Streamer CDS 2.5 Software Configuration Guide](#).

The CDNFS and sysfs partitions use the ext2 file system. With ext2 file systems, if the system crashed or if the system is not shut down cleanly, a file system check of these partitions takes a long time. If there are sector failures on the disk, the time to perform a file system check with an ext2 file system increases.

even more. By migrating to the ext3 file system, the amount of time required to perform a file system check of the cndfs and sysfs partitions is decreased, which increases the availability of the SE. If you are upgrading from an earlier release of the CDS software, the ext2 file system is automatically converted to the ext3 file system.

The CDNFS amounts are reported by the actual usable amounts of storage for applications. Because of the internal file system overhead of approximately 3 percent, the reported amounts may be smaller than what you configured.

To view disk details, use the **show disk details** command.

**Note**

The **show disk details** command shows the amount of disk space that is allocated to system use. This detail is not shown by using the **show disk current** command.

To show the space allocation in each individual file system type, use the **show statistics cndfs** command.

**Note**

For information on disk allocation guidelines for SEs, see the *Cisco Internet Streamer CDS 2.5 Software Configuration Guide*.

For higher-end models that might be used as a dedicated HTTP cache or RealProxy cache, you could give cache storage more disk space.

After upgrading from an earlier release of Internet Streamer CDS software to Cisco Internet Streamer CDS Release 2.5 software and later releases, your disk space allocation remains the same as previously configured.

### Disk Space Allocation Guidelines for Service Routers

In Cisco Internet Streamer CDS Release 2.5 software, SRs are used as DNS servers for the delegated DNS zone used in simplified hybrid routing. The DNS servers do not store any content and do not participate in acquisition or distribution of the prepositioned content. The only disk space that needs to be configured on the SR is the sysfs.

### Disk Space Allocation Guidelines for CDSMs

CDSMs are used to manage content distribution for CDS networks. Because the CDSM does not store the content, the only file system that needs to be configured is the sysfs.

### Remapping of Bad Sectors on Disk Drives

The **disk erase** command in EXEC configuration mode performs a low-level format of the SCSI, IDE, or SATA disks. This command erases all the content on the disk.

If a disk drive continues to report a failure after you have used the **disk erase** command, you must replace the disk drive.

**Caution**

Be careful when using the **disk erase** command because this command causes all content on the specified disk to be deleted.

Starting with Cisco Internet Streamer CDS Release 2.5 software, SCSI and SATA drives can be reformatted.

### Erasing Disk Drives

In Cisco Internet Streamer CDS Release 2.5.7 software, the **disk erase** command replaced the **disk reformat** command. This command erases all the content on the disk. The sequence to erase a disk is to enter the **disk unuse** command first, then enter the **disk erase** and **disk policy apply** commands. If a disk drive continues to report a failure after you have used the **disk erase** command, you must replace the disk drive.



#### Caution

Be careful when using the **disk erase** command because this command causes all content on the specified disk to be deleted.

### Disk Hot Swapping

In Cisco Internet Streamer CDS Release 2.5.7 software and earlier, a new disk is recognized and the RAID is rebuilt when the device is rebooted. Starting with Cisco Internet Streamer CDS Release 2.5.9 software, it is not necessary to reboot the device. After inserting the new disk, enter the **disk policy apply** command to force the Internet Streamer CDS software to detect the new disk and rebuild the RAID.

### Disk Latent Sector Error Handling

Latent Sector Errors (LSEs) are when a particular disk sector cannot be read from or written to, or when there is an uncorrectable ECC error. Any data previously stored in the sector is lost. There is also a high probability that sectors in close proximity to the known bad sector have as yet undetected errors, and therefore are included in the repair process.

The syslog file shows the following disk I/O error message and smartd error message when there are disk sector errors:

```
Apr 28 21:00:26 U11-CDE220-2 kernel: %SE-SYS-4-900000: end_request: I/O error, dev sdd, sector 4660
```

```
Apr 28 21:00:26 U11-CDE220-2 kernel: %SE-SYS-3-900000: Buffer I/O error on device sdd, logical block 582
```

```
Apr 28 21:04:54 U11-CDE220-2 smartd[7396]: %SE-UNKNOWN-6-899999: Device: /dev/sdd, SMART Prefailure Attribute: 1 Raw_Read_Error_Rate changed from 75 to 73
```

```
Apr 28 21:04:54 U11-CDE220-2 smartd[7396]: %SE-UNKNOWN-6-899999: Device: /dev/sdd, SMART Usage Attribute: 187 Reported_Uncorrect changed from 99 to 97
```

```
Apr 28 21:04:54 U11-CDE220-2 smartd[7396]: %SE-UNKNOWN-2-899999: Device: /dev/sdd, ATA error count increased from 1 to 3
```

The **disk repair** command repairs the bad sector, including the proximal sectors and then reformats the drive. All data on the drive is lost, but the sectors are repaired and available for data storage again.



#### Caution

The device should be offline before running the **disk repair** command. Because this command involves complex steps, we recommend you contact Cisco Technical Support before running this command.

The **disk repair** command not only repairs the bad sectors, but reformats the entire drive, so all data on the drive is lost. The difference between the **disk repair** command and the **disk reformat** command is that the **disk format** command only reinitializes the file system and does not repair bad sectors.

A minor alarm is set when an LSE is detected. After the sector is repaired with the disk repair command, the alarm is turned off.

Minor Alarms:

```
-----
Alarm ID           Module/Submodule   Instance
-----
1 badsector        sysmon            disk11
May 19 20:40:38.213 UTC, Equipment Alarm, #000003, 1000:445011
"Device: /dev/sdl, 1 Currently unreadable (pending) sectors"
```

### Stopping Applications from Using a Disk Drive

The **disk unuse** command in EXEC configuration mode allows you to stop applications from using a specific disk drive (for example, disk01) without having to reboot the device.

The **disk unuse** command has the following behavior:

- Cannot be used with sysfs disk if the state of RAID-1 is not “Normal”.
- Cannot be used with the CDNFS disk, which contains the “/uns-symlink-tree” directory.
- Can be used with any disk except as in scenario 1 and 2 above.

## Examples

The following example shows how to repair the sector 4660 on disk 02:

```
ServiceEngine# disk repair disk02 sector 4660
```

The following examples show usage of the **disk unuse** command and the resultant actions:

```
ServiceEngine# disk unuse disk00
disk00 has key CDNFS data and can not be unused!
```

```
ServiceEngine# disk unuse disk01
This will restart applications currently using disk01
and unmount all partitions on disk01.
Do you want to continue? (Yes/No): yes
[WARNING] CDNFS and RAID SYSTEM partitions detected on disk01
To safely remove a RAID SYSTEM disk, the entire drive must be erased. This
operation has little effect on the RAID-ed SYSTEM volumes, as their data can
be resynced. However, because the drive also contains non-RAID CDNFS
data, it will result in loss of all CDNFS data for this drive!
Unuse disk01, erasing all CDNFS data? (Yes/No): yes
disk01 is now unused.
All partitions on disk01 have been erased.
```

```
ServiceEngine# disk unuse disk02
This will restart applications currently using disk02
and unmount all partitions on disk02.
Do you want to continue? (Yes/No): yes
disk02 is now unused
```

The following example shows how to view disk details:

```
ServiceEngine# show disk details
disk00: Normal (h02 c00 i00 100 - mptsas) 476940MB(465.8GB)
disk00/01: SYSTEM 5120MB( 5.0GB) mounted internally
disk00/02: SYSTEM 2560MB( 2.5GB) mounted internally
disk00/04: SYSTEM 1536MB( 1.5GB) mounted internally
disk00/05: SYSFS 32767MB( 32.0GB) mounted at /local1
disk00/06: CDNFS 434948MB(424.8GB) mounted internally
disk01: Normal (h02 c00 i01 100 - mptsas) 476940MB(465.8GB)
Unallocated: 476940MB(465.8GB)
disk02: Normal (h02 c00 i02 100 - mptsas) 476940MB(465.8GB)
disk02/01: CDNFS 476932MB(465.8GB) mounted internally
```

The following example shows how to display the current disk space configuration:

```
ServiceEngine# show disk current
Local disks:
  SYSFS 32.0GB 0.7%
  CDNFS 4616.0GB 99.3%
```

The following examples show how to view space allocation in each file system type:

```
ServiceEngine# show statistics cdnfs

CDNFS Statistics:
-----
Volume on :
  size of physical filesystem:      444740904 KB
  space assigned for CDNFS purposes: 444740904 KB
  number of CDNFS entries:          40 entries
  space reserved for CDNFS entries: 436011947 KB
  available space for new entries:   8728957 KB
  physical filesystem space in use:  435593864 KB
  physical filesystem space free:     9147040 KB
  physical filesystem percentage in use: 98 %

Volume on :
  size of physical filesystem:      444740904 KB
  space assigned for CDNFS purposes: 444740904 KB
  number of CDNFS entries:          43 entries
  space reserved for CDNFS entries: 436011384 KB
  available space for new entries:   8729520 KB
  physical filesystem space in use:  435593720 KB
  physical filesystem space free:     9147184 KB
  physical filesystem percentage in use: 98 %

Volume on :
  size of physical filesystem:      488244924 KB
  space assigned for CDNFS purposes: 488244924 KB
  number of CDNFS entries:          48 entries
  space reserved for CDNFS entries: 479612533 KB
  available space for new entries:   8632391 KB
  physical filesystem space in use:  479152708 KB
  physical filesystem space free:     9092216 KB
  physical filesystem percentage in use: 99 %
```

Related Commands	Command	Description
	<b>disk</b> (Global configuration mode)	Configures how the disk errors should be handled.
	<b>show cdnfs</b>	Displays the Internet Streamer CDS network file system information.
	<b>show disk</b>	Displays the disk configurations.
	<b>show disk details</b>	Displays more detailed SMART disk monitoring information.
	<b>show statistics</b>	Displays statistics by module.

## disk (Global configuration)

To configure how disk errors should be handled and to define a disk device error-handling threshold, use the **disk** command in Global configuration mode. To remove the device error-handling options, use the **no** form of this command.

**disk error-handling {reload | threshold *number*}**

**no disk error-handling {reload | threshold *number*}**

### Syntax Description

<b>error-handling</b>	Configures disk error handling.
<b>reload</b>	Reloads the disk if the system file system (sysfs) (disk00) has problems.
<b>threshold</b>	Sets the number of disk errors allowed before the disk is marked as bad.
<i>number</i>	Number of disk errors allowed before the disk is marked as bad. The range is from 0 to 100. The default is 10. The value 0 means that the disk should never be marked as bad.

### Command Defaults

**error-handling threshold *number*:** 10

### Command Modes

Global configuration (config) mode.

### Usage Guidelines

To operate properly, the SE must have critical disk drives. A critical disk drive is the first disk drive that also contains the first sysfs (system file system) partition. It is referred to as disk00.

The sysfs partition is used to store log files, including transaction logs, system logs (syslogs), and internal debugging logs. It can also be used to store image files and configuration files on an SE.



#### Note

A critical drive is a disk drive that is either disk00 or a disk drive that contains the first sysfs partition. Smaller single disk drive SEs have only one critical disk drive. Higher-end SEs that have more than one disk drive may have more than one critical disk drive.

When an SE is booted and a critical disk drive is not detected at system startup time, the CDS system on the SE runs at a degraded state. If one of the critical disk drives goes bad at run time, the CDS system applications can malfunction, hang, or crash, or the CDS system can hang or crash. Monitor the critical disk drives on an SE and report any disk drive errors to Cisco TAC.

With an CDS system, a disk device error is defined as any of the following events:

- Small Computer Systems Interface (SCSI) or Integrated Drive Electronics (IDE) device error is printed by a Linux kernel.
- Disk device access by an application (for example, an open(2), read(2), or write(2) system call) fails with an EIO error code.
- Disk device that existed at startup time is not accessible at run time.



The disk status is recorded in flash (nonvolatile storage). When an error on an SE disk device occurs, a message is written to the system log (syslog) if the sysfs partition is still intact, and an SNMP trap is generated if SNMP is configured on the SE.

In addition to tracking the state of critical disk drives, you can define a disk device error-handling threshold on the SE. If the number of disk device errors reaches the specified threshold, the corresponding disk device is automatically marked as bad. The CDS system does not stop using the bad disk device immediately; it stops using the bad disk drive after the next reboot.

If the specified threshold is exceeded, the SE either records this event or reboots. If the automatic reload feature is enabled and this threshold is exceeded, then the CDS system automatically reboots the SE. For more information about specifying this threshold, see the [“Specifying the Disk Error-Handling Threshold” section on page 2-154](#).

In Cisco Internet Streamer CDS Release 2.5 software, you can remap bad (but unused) sectors on a SCSI drive and SATA drives.

### Specifying the Disk Error-Handling Threshold

In Cisco Internet Streamer CDS Release 2.5 software, you can configure a disk error-handling threshold. This threshold determines how many disk errors can be detected before the disk drive is automatically marked as bad. By default, this threshold is set to 10.

The **disk error-handling threshold** option determines how many disk errors can be detected before the disk drive is automatically marked as bad. By default, this threshold is set to 10.

To change the default threshold, use the **disk error-handling threshold** command. Specify 0 if you never want the disk drive to be marked as bad.

If the bad disk drive is a critical disk drive, and the automatic reload feature (**disk error-handling reload** command) is enabled, then the Internet Streamer CDS software marks the disk drive as bad and the SE is automatically reloaded. After the SE is reloaded, a syslog message and an SNMP trap are generated.

By default, the automatic reload feature is disabled on an SE. To enable the automatic reload feature, use the **disk error-handling reload** command. After enabling the automatic reload feature, use the **no disk error-handling reload** command to disable it.

### Examples

The following example shows that five disk drive errors for a particular disk drive (for example, disk00) are allowed before the disk drive is automatically marked as bad:

```
ServiceEngine(config)# disk error-handling threshold 5
```

### Related Commands

Command	Description
<b>disk</b> (EXEC mode)	Allocates the disks among the CDNFS and sysfs file systems.
<b>show disk</b>	Displays the disk configurations.
<b>show disk details</b>	Displays currently effective configurations with more details.

# distribution

To reschedule and refresh content redistribution for a specified delivery service ID or name, use the **distribution** command in EXEC configuration mode.

```
distribution {failover {delivery-service-id delivery-service-num | delivery-service-name name}  
[force] | fallback {delivery-service-id delivery-service-num | delivery-service-name name} }
```

```
distribution primary-ip-fallback {forwarder-id forwarder-num | forwarder-name name}
```

```
distribution refresh {meta-data delivery-service-id delivery-service-num | object object-url}
```

Syntax Description		
<b>failover</b>		Triggers the root or forwarder SE to fail over and make this SE the temporary Content Acquirer.
<b>delivery-service-id</b>		Specifies the delivery service ID to be used.
<i>delivery-service-num</i>		Delivery service number. The range is from 0 to 4294967295.
<b>delivery-service-name</b>		Specifies the delivery service name descriptor to be used.
<i>name</i>		Delivery service name.
<b>force</b>		(Optional) Forces a failover regardless of whether the root or forwarder SE is active.
<b>fallback</b>		Forces the temporary Content Acquirer to become a receiver SE.
<b>primary-ip-fallback</b>		Triggers the downstream receiver SEs to contact a forwarder using the forwarder's primary IP address. For more information, see the <a href="#">“distribution primary-ip-fallback Command”</a> section on page 2-156.
<b>forwarder-id</b>		Specifies the forwarder SE ID that is contacted by the receiver SE.
<i>forwarder-num</i>		Forwarder SE ID.
<b>forwarder-name</b>		Specifies the name of the forwarder SE that is contacted by the receiver SE.
<i>name</i>		Forwarder SE name.
<b>refresh</b>		Forces the redistribution of content to be refreshed on every SE.
<b>meta-data</b>		Forces the redistribution of metadata to be refreshed on every SE.
<b>delivery-service-id</b>		Specifies the delivery service ID to be used in the distribution.
<i>delivery-service-num</i>		Delivery service number. The range is from 0 to 4294967295.
<b>object</b>		Forces the distribution of objects to be refreshed on every SE.
<i>object-url</i>		Specifies the object URL that needs to be refreshed on every SE.

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Usage Guidelines** When the Content Acquirer fails, use the **distribution failover** command in EXEC configuration mode on an SE that is going to be the temporary Content Acquirer to trigger an immediate failover to the temporary Content Acquirer if you do not want to wait for the automatic failover process to occur. When

you enter this command, the current SE becomes the temporary Content Acquirer if its forwarder is an inactive Content Acquirer. If the Content Acquirer has not failed, a failover to the temporary Content Acquirer does not occur if you use the **distribution failover** command in EXEC configuration mode. Use the **distribution failover force** command to force a failover even if the Content Acquirer is active.

Use the **distribution fallback** command on an SE that is currently the temporary Content Acquirer to cause it to become a receiver SE.

Use the **distribution refresh meta-data { delivery-service-id delivery-service-num }** command to request that the metadata receiver repeat a previous request for all the content metadata for the specified delivery service from its forwarder SE. This method allows you to start over if the metadata receiver fails to replicate some metadata properly. The content metadata (machine-readable information that describes the characteristics of the content) must be distributed to a receiver first before the content can be replicated. The content metadata helps to define what content to retrieve, how content is retrieved, how recently the content has been updated, how the content is to be prepositioned (for example, expiration time), and so forth. The metadata is always distributed using unicast. The content can also be replicated using unicast.

Use the **distribution refresh object object-url** command to reissue a request for unicast distribution of the specified object. This command lets you obtain a new copy of an object if there is a corrupted copy on the SE. After you enter this command, if the distribution is unicast, the unicast receiver reissues the request to its forwarder SE. The old content on the SE is removed and a new copy is replicated.

### NACK Interval Multiplier

To identify missing content and trigger a resend of a file, receiver SEs send a negative acknowledgement (NACK) message to the sender SE. NACK messages generated by many receiver SEs could generate more traffic than the sender can handle. The Cisco Internet Streamer CDS Release 2.5 software allows you to adjust the average interval between NACKs by configuring a NACK interval multiplier for an individual receiver SE. This value (an integer between 0.1 to 10) adjusts the default average NACK interval (the default is 20 minutes) by the value configured as the interval multiplier. For example, if you set the NACK interval multiplier to 3, the interval between NACKs becomes 20 minutes x 3, or 60 minutes. This adjustment can be made as needed by choosing **Devices > Devices > Prepositioning > Distribution** in the CDSM GUI.

### distribution primary-ip-fallback Command

When downstream receiver SEs at the edge of the network try to access a forwarder SE that is inside a NAT firewall, those receiver SEs that are inside the same NAT use one IP address (called the *inside local IP address*) to access the forwarder, but other receiver SEs that are outside the NAT need to use a different forwarder's IP address (called the *inside global IP address* or *NAT address*) to access the forwarder. A forwarder SE registers the IP address configured on its primary interface with the CDSM, and the CDSM uses the primary IP address for communication with devices in the CDS network. If the registered primary IP address is the inside local IP address and the forwarder is behind a NAT firewall, a receiver that is not inside the same NAT as the forwarder cannot contact it without special configuration. All other receivers inside the NAT use the inside local IP address to contact the forwarder that resides inside the NAT.

Cisco Internet Streamer CDS Release 2.5 software supports NAT for unicast distribution (see the [“NAT Firewall” section on page 2-157](#) for more information). When the receiver SE polls its forwarder from an upstream location for the content metadata or content, the receiver first connects to the forwarder using the forwarder's primary IP address. If it fails and the NAT address of the forwarder has been configured, then the unicast receiver tries to poll the forwarder using the forwarder's NAT address. If the receiver polls the forwarder successfully using the NAT address, the receiver continues to use the forwarder's NAT address during the subsequent polling intervals with the same forwarder. The unicast receiver retries to connect to the forwarder using the forwarder's primary IP address only after one hour. Even if the unicast receiver is able to poll the forwarder using the forwarder's primary IP address, it

would take one hour for the receiver to fall back to the forwarder's primary IP address automatically. You can use the **distribution primary-ip-fallback** command to enable the receiver that is using the NAT address of the forwarder to fall back to the primary IP address immediately, if you are certain that the forwarder's primary IP address is working.

### NAT Firewall

NAT enables private IP internetworks that use nonregistered IP addresses to connect to the Internet. NAT is configured on the firewall at the border of a stub domain (referred to as the inside network) and a public network such as the Internet (referred to as the outside network). NAT translates the internal local addresses to globally unique IP addresses before sending packets to the outside network. You can configure NAT to advertise only one address for the entire network to the outside world. This configuration provides additional security, effectively hiding the entire internal network from the world behind that address. NAT has the dual functionality of security and address conservation and is typically implemented in remote access environments.

In the inside network's domain, hosts have addresses in the one address space. While on the outside, they appear to have addresses in another address space when NAT is configured. The first address space is referred to as the local address space while the second is referred to as the global address space.

Hosts in outside networks can be subject to translation and can have local and global addresses.

NAT uses the following definitions:

- Inside local address—The IP address that is assigned to a host on the inside network. The address is probably not a legitimate IP address assigned by the Network Information Center (NIC) or service provider.
- Inside global address—A legitimate IP address (assigned by the NIC or service provider) that represents one or more inside local IP addresses to the outside world.
- Outside local address—The IP address of an outside host as it appears to the inside network. Not necessarily a legitimate address, it was allocated from an address space routable on the inside.
- Outside global address—The IP address assigned to a host on the outside network by the host's owner. The address was allocated from a globally routable address or network space.

### Related Commands

Command	Description
<b>show statistics distribution</b>	Displays the simplified statistics for content distribution components.

# dnslookup

To resolve a host or domain name to an IP address, use the **dnslookup** command in EXEC configuration mode.

**dnslookup** {*hostname* | *domainname*}

## Syntax Description

<i>hostname</i>	Name of host on the network.
<i>domainname</i>	Name of domain.

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Examples

The following examples show that the **dnslookup** command is used to resolve the hostname *myhost* to IP address 172.31.69.11, *cisco.com* to IP address 192.168.219.25, and an IP address used as a hostname to 10.0.11.0:

```
ServiceEngine# dnslookup myhost  
official hostname: myhost.cisco.com  
address: 172.31.69.11
```

```
ServiceEngine# dnslookup cisco.com  
official hostname: cisco.com  
address: 192.168.219.25
```

```
ServiceEngine# dnslookup 10.0.11.0  
official hostname: 10.0.11.0  
address: 10.0.11.0
```

# domain

To set the domain ID for the SRP, use the **domain** SRP configuration command. To remove a domain ID, use the **no** or **default** form of the command.

**domain** [*id*]

[**no** | **default**] **domain** [*id*]

<b>Syntax Description</b>	<i>id</i> (Optional) A positive 32-bit integer for the domain.
---------------------------	--

<b>Command Defaults</b>	If the <b>no domain</b> command is used, the domain ID is 0.
-------------------------	--

<b>Command Modes</b>	SRP configuration (config-srp) mode.
----------------------	--------------------------------------

<b>Usage Guidelines</b>	This command is used to set the domain ID for an SRP. All Proximity Engines running SRP routing with the same domain ID form a single network if the nodes are found through a bootstrap node. By changing a Proximity Engine's domain, the Proximity Engine leaves its current network.
-------------------------	--

The **no** and **default** forms of the command replace current domain ID with the default domain ID, which is 0.

<b>Examples</b>	The following example shows how to configure a domain ID with <b>domain</b> .
-----------------	---

```
ServiceRouter# configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
ServiceRouter(config)# router srp
ServiceRouter(config-srp)# domain 100
ServiceRouter(config-srp)# end
ServiceRouter#
```

The following example illustrates how **show srp process** command displays the configured domain ID.

```
ServiceRouter# show srp process

Process:
  Domain: 100
  Node Id: 2a2db308fd3dc172940a7902a4db7c16c98c3a32e1b048005bce1e832b6d056f
  Host name: sn-sj88
  Port: 9000
  Interfaces running SRP:
    *GigabitEthernet 1/0, GigabitEthernet 2/0, GigabitEthernet 3/0
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>bootstrap-node</b>	Configures a bootstrap node IP address.
	<b>router srp</b>	Enters SRP configuration mode.
	<b>show srp process</b>	Displays the basic configurations for SRP.

# enable

To access privileged commands in EXEC configuration modes, use the **enable** command in EXEC configuration mode.

**enable**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

<b>Usage Guidelines</b>	To access privileged EXEC configuration mode from EXEC configuration mode, use the <b>enable</b> command. The <b>disable</b> command takes you from privileged EXEC configuration mode to user EXEC configuration mode.
-------------------------	---

<b>Examples</b>	The following example shows how to access privileged EXEC configuration mode:
-----------------	---

```
ServiceEngine> enable
ServiceEngine#
```

Related Commands	Command	Description
	<b>disable</b>	Turns off the privileged EXEC commands.
	<b>exit</b>	Exits from interface, Global configuration, or privileged EXEC configuration modes.

# end

To exit Global configuration mode, use the **end** command in Global configuration mode.

**end**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Defaults** None

---

**Command Modes** Global configuration (config) mode.

---

**Usage Guidelines** Use the **end** command to exit Global configuration mode after completing any changes to the running configuration. To save new configurations to NVRAM, use the **write** command.

In addition, you can press **Ctrl-Z** to exit Global configuration mode.

---

**Examples** The following example shows how to exit Global configuration mode:

```
ServiceEngine(config)# end
ServiceEngine#
```

---

Related Commands	Command	Description
	<b>exit</b>	Exits from interface, Global configuration, or privileged EXEC configuration modes.

---



# exec-timeout

To configure the length of time that an inactive Telnet or Secure Shell (SSH) session remains open, use the **exec-timeout** command in Global configuration mode. To revert to the default value, use the **no** form of this command.

**exec-timeout** *timeout*

**no exec-timeout**

## Syntax Description

<i>timeout</i>	Timeout in minutes. The range is from 0–44640. The default is 15.
----------------	---

## Command Defaults

The default is 15 minutes.

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

A Telnet or SSH session with the SE can remain open and inactive for the interval of time specified by the **exec-timeout** command. When the exec-timeout interval elapses, the SE automatically closes the Telnet or SSH session.

Configuring a timeout interval of 0 minutes by entering the **exec-timeout 0** command is equivalent to disabling the session-timeout feature.

## Examples

The following example shows how to configure a timeout of 100 minutes:

```
ServiceEngine(config)# exec-timeout 100
```

The following example negates the configured timeout of 100 minutes and reverts to the default value of 15 minutes:

```
ServiceEngine(config)# no exec-timeout
```

## Related Commands

Command	Description
<b>sshd</b>	Configures the SSH service parameters.
<b>telnet enable</b>	Enables the Telnet services.

# exit

To access commands in EXEC configuration mode shell from the global, interface, and debug configuration command shells, use the **exit** command.

**exit**

## Syntax Description

This command has no arguments or keywords.

## Command Defaults

None

## Command Modes

EXEC, Global configuration (config), and interface configuration (config-if) modes.

## Usage Guidelines

Use the **exit** command in any configuration mode to return to EXEC configuration mode. Using this command is equivalent to pressing the **Ctrl-Z** key or entering the **end** command.

The **exit** command issued in the user-level EXEC shell terminates the console or Telnet session. You can also use the **exit** command to exit other configuration modes that are available from the Global configuration mode for managing specific features (see the commands marked with a footnote in [Table 2-1](#)).

## Examples

The following example shows how to exit the Global configuration mode and return to the privileged-level EXEC configuration mode:

```
ServiceEngine(config)# exit
ServiceEngine#
```

The following example shows how to exit the privileged-level EXEC configuration mode and return to the user-level EXEC configuration mode:

```
ServiceEngine# exit
ServiceEngine>
```

## Related Commands

Command	Description
<b>end</b>	Exits configuration and privileged EXEC configuration modes.

# expert-mode password

To set the customer configurable password, use the **expert-mode password** command in Global configuration mode.

**expert-mode password** [**encrypted**] *password*

<b>Syntax Description</b>	<b>encrypted</b>	(Optional) Encrypts the password.
	<i>password</i>	The encrypted password.

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	Global configuration (config) mode.
----------------------	-------------------------------------

<b>Usage Guidelines</b>	This is a customer configurable password for allowing to enter engineering mode for troubleshooting purposes. The function prompts the user for the current admin password to verify that the user attempting to set the expert-mode password is authorized to do so. If the user is authenticated, the user is prompted twice to enter the new expert-mode password. The new expert-mode password is encrypted prior to being persisted.
-------------------------	---

<b>Examples</b>	The following example shows how to configure four external NAT IP addresses:
-----------------	--

```
ServiceEngine(config)# expert-mode password encrypted xxxx
New Expert Mode Password: xxxx
Confirm New Expert Mode Password: xxxx
Password successfully changed
```

# external-ip

To configure up to eight external Network Address Translation (NAT) IP addresses, use the **external-ip** command in Global configuration mode. To remove the NAT IP addresses, use the **no** form of this command.

**external-ip** *ip-addresses*

**no external-ip** *ip-addresses*

<b>Syntax Description</b>	<i>ip-addresses</i> A maximum of eight external or NAT IP addresses can be configured.
<b>Command Defaults</b>	None
<b>Command Modes</b>	Global configuration (config) mode.
<b>Usage Guidelines</b>	<p>Use this command to configure up to eight Network Address Translation IP addresses to allow the router to translate up to eight internal addresses to registered unique addresses and translate external registered addresses to addresses that are unique to the private network. If the IP address of the RTSP gateway has not been configured on the SE, then the external IP address is configured as the IP address of the RTSP gateway.</p> <p>In an CDS network, there are two methods for a device registered with the CDSM (SEs, SRs, or the standby CDSM) to obtain configuration information from the primary CDSM. The primary method is for the device to periodically poll the primary CDSM on port 443 to request a configuration update. You cannot configure this port number. The backup method is when the CDSM pushes configuration updates to a registered device as soon as possible by issuing a notification to the registered device on port 443. This method allows changes to take effect in a timelier manner. You cannot configure this port number even when the backup method is being used. CDS networks do not work reliably if devices registered with the CDSM are unable to poll the CDSM for configuration updates. When a receiver SE requests the content and content metadata from a forwarder SE, it contacts the forwarder SE on port 443.</p> <p>When a device (SEs at the edge of the network, SRs, and primary or standby CDSMs) is inside a NAT firewall, those devices that are inside the same NAT use one IP address (the inside local IP address) to access the device and those devices that are outside the NAT use a different IP address (the NAT IP address or inside global IP address) to access the device. A centrally managed device advertises only its inside local IP address to the CDSM. All other devices inside the NAT use the inside local IP address to contact the centrally managed device that resides inside the NAT. A device that is not inside the same NAT as the centrally managed device cannot contact it without a special configuration.</p> <p>If the primary CDSM is inside a NAT, you can allow a device outside the NAT to poll it for getUpdate requests by configuring a static translation (NAT IP address or inside global IP address) for the CDSM's inside local IP address on its NAT, and using this address, rather than the CDSM's inside local IP address in the <b>cdsm ip ip-address</b> command when you register the device to the CDSM. If an SE or SR is inside a NAT and the CDSM is outside the NAT, you can allow the SE or SR to poll for getUpdate requests by configuring a static translation (NAT IP address or inside global IP address) for the SE or SR's inside local address on its NAT.</p>

**Note**

Static translation establishes a one-to-one mapping between your inside local address and an inside global address. Static translation is useful when a host on the inside must be accessible by a fixed address from the outside.

**Examples**

The following example shows how to configure four external NAT IP addresses:

```
ServiceEngine(config)# external-ip 192.168.43.1 192.168.43.2 192.168.43.3 192.168.43.4
```

# find-pattern

To search for a particular pattern in a file, use the **find-pattern** command in EXEC configuration mode.

**find-pattern** {**binary** *filename* | **case** {**binary** *filename* | **count** *filename* | **lineno** *filename* | **match** *filename* | **nomatch** *filename* | **recursive** *filename*} | **count** *filename* | **lineno** *filename* | **match** *filename* | **nomatch** *filename* | **recursive** *filename*}

Syntax Description		
<b>binary</b>		Does not suppress the binary output.
<i>filename</i>		Filename.
<b>case</b>		Matches the case-sensitive pattern.
<b>count</b>		Prints the number of matching lines.
<b>lineno</b>		Prints the line number with output.
<b>match</b>		Prints the matching lines.
<b>nomatch</b>		Prints the nonmatching lines.
<b>recursive</b>		Searches a directory recursively.

**Command Defaults** None

**Command Modes** EXEC configuration mode.

**Usage Guidelines** Use this command to search for a particular regular expression pattern in a file.

**Examples** The following example shows how to search a file recursively for a case-sensitive pattern:

```
ServiceEngine# find-pattern case recursive admin removed_core
-rw----- 1 admin root 95600640 Oct 12 10:27 /local/local1/core_dir/c
ore.2.2.1.b5.eh.2796
-rw----- 1 admin root 97054720 Jan 11 11:31 /local/local1/core_dir/c
ore.cache.5.3.0.b131.cnbuild.14086
-rw----- 1 admin root 96845824 Jan 11 11:32 /local/local1/core_dir/c
ore.cache.5.3.0.b131.cnbuild.14823
-rw----- 1 admin root 101580800 Jan 11 12:01 /local/local1/core_dir/
core.cache.5.3.0.b131.cnbuild.15134
-rw----- 1 admin root 96759808 Jan 11 12:59 /local/local1/core_dir/c
ore.cache.5.3.0.b131.cnbuild.20016
-rw----- 1 admin root 97124352 Jan 11 13:26 /local/local1/core_dir/c
ore.cache.5.3.0.b131.cnbuild.30249
-rw----- 1 admin root 98328576 Jan 11 11:27 /local/local1/core_dir/c
ore.cache.5.3.0.b131.cnbuild.8095
```

The following example searches a file for a pattern and prints the matching lines:

```
ServiceEngine# find-pattern match 10 removed_core
Tue Oct 12 10:30:03 UTC 2004
-rw----- 1 admin root 95600640 Oct 12 10:27 /local/local1/core_dir/c
ore.5.2.1.b5.eh.2796
-rw----- 1 admin root 101580800 Jan 11 12:01 /local/local1/core_dir/
core.cache.5.3.0.b131.cnbuild.15134
```

The following example searches a file for a pattern and prints the number of matching lines:

```
ServiceEngine# find-pattern count 10 removed_core
3
```

#### Related Commands

Command	Description
<b>cd</b>	Changes the directory.
<b>dir</b>	Displays the list of files in a directory.
<b>lls</b>	Displays the files in a long list format.
<b>ls</b>	Lists the files and subdirectories in a directory.

# flash-media-streaming

To enable and configure Flash Media Streaming, use the **flash-media-streaming** command in Global configuration mode. To disable Flash Media Streaming, use the **no** form of this command.

On the SE:

```
flash-media-streaming {admin-api [ip {allow ip address}] | application-virtual-path vod map
mapping string | enable | ignore-query-string enable | max-bandwidth number |
max-sessions number | monitoring enable | non-wholesale-license-bandwidth number |
wholesale-license {install number license-name name bandwidth number start-date date
duration number | no-alerts number} }
```

**no flash-media-streaming**

On the SR:

```
flash-media-streaming {enable | monitoring enable}
```

**no flash-media-streaming**

## Syntax Description

<b>admin-api</b>	Allows accessing admin API from the IP.
<b>ip</b>	Allows an IP Address.
<b>allow</b>	Allows an IP Address.
<i>ip address</i>	IP Address or hostname (input maximum 32 of partial or full IP address or hostname, such as 10.60, 10.60.1.133, or foo.com).
<b>application-virtual-path</b>	Configures the virtual-path for applications.
<b>vod</b>	Configures the virtual-path for VOD applications.
<b>map</b>	Maps to a directory.
<i>mapping string</i>	Mapping string.
<b>enable</b>	Enables Flash Media Streaming.
<b>ignore-query-string</b>	Configures Flash Media Streaming to ignore query strings in requests.
<b>enable</b>	Enables ignoring query string in requests.
<b>max-bandwidth</b>	Configures max bandwidth for Flash Media Streaming.
<i>number</i>	Max bandwidth number (1000 to 8000000) Kbps.
<b>max-sessions</b>	Configures maximum sessions for Flash Media Streaming.
<i>number</i>	Maximum sessions number. The range is from 1 to 15000.
<b>monitoring</b>	Configures Flash Media Streaming monitoring.
<b>enable</b>	Enables monitoring.
<b>non-wholesale-license-bandwidth</b>	Configures non-wholesale license bandwidth for Flash Media Streaming.
<i>number</i>	Non-wholesale-license-bandwidth number (1000 to 8000000) Kbps.
<b>wholesale-license</b>	Adds, modifies, and configures Flash Media Streaming wholesale licenses.
<b>install</b>	Installs wholesale licenses for Flash Media Streaming.
<i>number</i>	License sequence number. The range is from 1 to 200.



<b>license-name</b>	Specifies the wholesale license name.
<i>name</i>	Name of the wholesale license.
<b>bandwidth</b>	Specifies the bandwidth of the wholesale license purchased.
<i>number</i>	Wholesale license bandwidth number (1000 to 4000000) Kbps.
<b>start-date</b>	Specifies the start date of the wholesale license.
<i>date</i>	The start date of the wholesale license in mm-dd-yyyy format, year between 1970 and 2037.
<b>duration</b>	Specifies the duration of the wholesale license, at least 1 month.
<i>number</i>	Duration of the wholesale license.
<b>no-alerts</b>	Disables alerts for Flash Media Streaming wholesale licenses.
<i>number</i>	License sequence number. The range is from 1 to 200.
<b>enable</b>	Enables Flash Media Streaming.
<b>monitoring</b>	Configures Flash Media Streaming monitoring.
<b>enable</b>	Enables monitoring.

**Command Defaults**

The ignore- query-string is disabled.

**Command Modes**

Global configuration (config) mode.

**Usage Guidelines**

Flash Media Streaming needs an application name (vod, live or dvrcast) as part of a client's request. In the case of a VOD application, the origin server should have a first level directory of *vod* for dynamic ingestion. For example, in a Flash Media Streaming VOD cache miss case, the request from the client should be `rtmp://cdnsecure.bbc.co.uk/vod/iplayerstreaming/secure_auth/scifi.flv`, and the origin server should have `http://cdnsecure.bbc.co.uk/vod/iplayerstreaming/secure_auth/scifi.flv`. However, this restricts customer deployments when *vod* is the only folder name they can use. Therefore, Cisco Internet Streamer CDS Release 2.5 software contains an **application-virtual-path vod** command so customers can map to whichever folder they want on the origin server.

**Note**

The dvrcast option is available only on 2.4.3 and earlier releases.

For VOD streams, all RTMP calls in the SWF file must be in the following format:

```
rtmp://rfqdn/vod/path/foo.flv
```

In this format, *rfqdn* is the routing domain name of the Service Router, *vod* is the required directory, and *path* is the directory path to the content file that conforms to the standard URL specification.

If you are unable to store the VOD content in the required “vod” directory on your origin server, you can create a VOD virtual path for all RTMP requests. All client requests for RTMP calls still use the `rtmp://rfqdn/vod/path/foo.flv` format for VOD streams, but the SE replaces the “vod” directory with the string specified in the **flash-media-streaming application-virtual-path vod map** command.

Use the **flash-media-streaming application-virtual-path vod map <mapping string>** command on each SE participating in a Flash Media Streaming delivery service. The mapping string variable accepts all alpha-numeric characters and the slash (/) character, and can be from 1 to 128 characters. For example, to map the “vod” directory to “media” for the go-tv-stream.com origin server, use the

**flash-media-streaming application-virtual-path vod map media** command. If comedy.flv is the content being requested, the RTMP call in the SWF file would be rtmp://go-tv-stream.com/vod/comedy.flv. The SE would replace the “vod” directory and request http://go-tv-stream.com/media/comedy.flv from the upstream SE or origin server. If just the slash (/) character is used to replace the “vod” directory, the SE request would be http://go-tv-stream.com/comedy.flv.

### Editing a Wholesale License

The wholesale license feature has four operations from the CLI—adding and removing licenses and enabling and disabling alerts. Users read license details from the documentation and add them to the CLI and CDSM. If a user enters a license incorrectly, the only way to edit it is to delete the license and add the it again.

### Ignore Query String

Previously, if an RTMP request had a query string in the URL for VOD, the Web Engine could decide whether or not to cache the content based on the Web Engine configuration. However, if the query string in the RTMP URL included the end user and not the stream name, every request would have a different URL because every user has a different query string. This leads to the same content getting cached multiple times.

In Release Cisco Internet Streamer CDS Release 2.5.9-b123 software, the **flash-media-streaming ignore-query-string enable** command has been added, which tells Flash Media Streaming to remove the query string before forwarding the request to the Web Engine in the case of VOD, or before forwarding the request to the forwarder SE in the case of live streaming.

If URL signature verification is required, the sign verification is performed before the query string check is invoked. The URL signing and validation, which adds its own query string to the URL, continues to work independently of this enhancement.

When the **flash-media-streaming ignore-query-string enable** command is entered, for every request in which the query string has been ignored, a message is written to the FMS error log, and the Query String Bypassed counter is incremented in the output of the **show statistics flash-media-streaming** command. The FMS access log on the edge SE contains the original URL before the query string was removed.

The **flash-media-streaming ignore-query-string enable** command affects every VOD and live streaming request and is not applicable to proxy-style requests.

## Examples

The following example shows how to map a vod folder:

```
ServiceEngine(config)# flash-media-streaming application-virtual-path vod map media
```

This means mapping vod folder to media. When client request cache-miss case:

```
rtmp://Tem4.se.cdsfms.com/vod/foo.flv is mapped to rtmp://Temp4.se.cdsfms.com/media/foo.flv
```

```
ServiceEngine(config)# flash-media-streaming application-virtual-path vod map /
```

This means mapping vod folder to /.

When client request cache-miss case: rtmp://Tem4.se.cdsfms.com/vod/abc/foo.flv is mapped to rtmp://Temp4.se.cdsfms.com/abc/foo.flv

When client request cache-miss case: rtmp://Tem4.se.cdsfms.com/vod/bar/foo.flv is mapped to rtmp://Temp4.se.cdsfms.com/bar/foo.flv.

Related Commands	Command	Description
	<b>show flash-media-streaming</b>	Displays the Flash Media Streaming information.
	<b>show statistics flash-media-streaming</b>	Displays the statistics for Flash Media Streaming.

# flooding

To set the flooding threshold for SRP multicast, use the **flooding threshold** SRP configuration command. To restore the default flooding threshold, use the **no** or **default** form of the command.

**flooding threshold** *value*

[**no** | **default**] **flooding threshold** *value*

## Syntax Description

<b>threshold</b>	Configures the flooding threshold.
<i>value</i>	A positive integer for the flooding threshold.

## Command Defaults

If **no flooding** command is issued, the default threshold is 50.

## Command Modes

SRP configuration (config-srp) mode.

## Usage Guidelines

This command is used to set the flooding threshold for SRP multicasting.

SRP protocol uses flooding to send multicast messages for a multicast group if the number of subscribers of the group is equal or more than the value specified in **flooding**. An effective threshold value may improve protocol message overhead. The threshold value depends on the number of nodes in your DHT network. In general, the threshold value should be greater than half and smaller than 3/4 of the total number of DHT nodes in the network.

The **no** or **default** forms of the command replace the current flooding threshold value with the default flooding threshold value (50).

## Examples

The following example shows how use the **flooding** command to set a flooding threshold value of 45.

```
ServiceRouter(config)# router srp
ServiceRouter(config-srp)# flooding threshold 45
ServiceRouter(config-srp)# end
ServiceRouter#
```

## Related Commands

Command	Description
<b>router srp</b>	Enters SRP configuration mode.

# geo-location-server

To redirect requests to different Content Delivery Networks based on the geographic location of the client, use the **geo-location-server** command in Global configuration mode. To cancel the request, use the **no** form of this command.

**geo-location-server** {**primary** *ip address port num* | **secondary** *ip address port num*}

**no geo-location-server** {**primary** *ip address port num* | **secondary** *ip address port num*}

## Syntax Description

<b>primary</b>	Configures the primary geo location server IP address and port.
<b>secondary</b>	Configure secondary geo location server IP address and port.
<i>ip address</i>	IP address of the geo location server.
<i>port num</i>	Port number of the geo location server.

## Command Defaults

None

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

Use the **geo-location-server** command to redirect requests to different CDNs based on the geographic location of the client. You can configure requests from different countries to be redirected to different third party services.



### Note

A Quova server is mandatory to support this feature.

## Examples

The following example shows how to configure a primary geo-location-server:

```
ServiceRouter# geo-location-server primary 171.71.51.140 7000
```

## Related Commands

Command	Description
<b>cdn-select</b>	Enables the CDN Selector for third-party service selection.
<b>show cdn-select</b>	Displays the status of the CDN Selector.
<b>show statistics cdn-select</b>	Displays the statistics for the CDN Selector.

# gulp

To capture lossless gigabit packets and write them to disk, use the **gulp** command in EXEC configuration mode.

**gulp** *line*

<b>Syntax Description</b>	<i>line</i> (Optional) Specifies gulp options, enter <b>-h</b> to get help.
---------------------------	---

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	EXEC configuration mode.
----------------------	--------------------------

<b>Usage Guidelines</b>	The <b>gulp</b> utility captures lossless gigabit packets and writes them to disk, as well as captures packets remotely. The <b>gulp</b> utility has the ability to read directly from the network.
-------------------------	---

To view the list of options, enter **gulp --h**.

```
ServiceEngine# gulp --help
```

```
Usage: /ruby/bin/gulp [--help | options]
--help      prints this usage summary
supported options include:
  -d          decapsulate Cisco ERSPAN GRE packets (sets -f value)
  -f "... "  specify a pcap filter - see manpage and -d
  -i eth#|-  specify ethernet capture interface or '-' for stdin
  -s #       specify packet capture "snapshot" length limit
  -r #       specify ring buffer size in megabytes (1-1024)
  -c         just buffer stdin to stdout (works with arbitrary data)
  -x         request exclusive lock (to be the only instance running)
  -X         run even when locking would forbid it
  -v         print program version and exit
  -Vx...x   display packet loss and buffer use - see manpage
  -p #      specify full/empty polling interval in microseconds
  -q         suppress buffer full warnings
  -z #      specify write blocksize (power of 2, default 65536) for long-term capture
  -o dir     redirect pcap output to a collection of files in dir
  -C #      limit each pcap file in -o dir to # times the (-r #) size
  -W #      overwrite pcap files in -o dir rather than start #+1
  -B         check if select(2) would ever have blocked on write
  -Y         avoid writes which would block
```

Table 2-9 lists the gulp options and provides a description of each.

**Table 2-9** *gulp Options*

Option	Description
-d	Decapsulates packets from a Cisco Encapsulated Remote SPAN Port (ERSPAN). Sets the pcap filter expression to “proto gre” and strips off Cisco GRE headers (50 bytes) from the packets captured. (If used with -f option note that arguments are processed left to right).
-f	Specify a pcap filter expression. This may be useful to select one from many GRE streams if using -d, or if not using -d, because filtering out packets in the kernel is more efficient than passing them first through the <b>gulp</b> utility and then filtering them out.
-i <i>eth#</i>	Specify the network interface to read from. The default is eth1 or the value of the environment variable \$CAP_IFACE, if present. Specifying a hyphen (-) as the interface will read a pcap file from the standard input instead. (If you forget the -d option during a live capture, you can decapsulate offline this way.)
-r #	Specify a ring buffer size (in megabytes). Values from 1–1024 are permitted. The default is 100. If possible, the ring buffer is locked into RAM.
-c	Copy and buffer bytes from stdin to stdout—do not read packets from the network and do not assume anything about the format of the data. This may be useful to improve the real-time performance of another application.
-s #	Specify packet capture snapshot length. By default, complete packets are captured. For efficiency, captured packets can be truncated to a given length during the capture process, which reduces capture overhead and pcap file sizes. (If used with the -d option, it specifies the length after decapsulation.)
-x	Use file locking to request (by way of exclusive lock) that this is the only instance of the <b>gulp</b> utility running. If other instances are already running, they must be stopped before the <b>gulp</b> utility can start with this option.
-X	Override an exclusive lock (-x option) and run anyway. An instance of <b>gulp</b> started this way holds a shared lock if no exclusive locks were broken; otherwise, it holds no locks at all (causing a subsequent attempt to get an exclusive lock to succeed).
-v	Print program version and exit.
-V xxxxxxxx	<p>If the string of Xs is wide enough (10 or more), it is overwritten twice per second with a brief capture status update consisting of one digit followed by two percentages. The digit is the number of decimal digits in the actual count of lost packets (0 indicates no drops). The two percentages are the current and maximum ring buffer utilization. The updated argument string can be seen with the ps -x option (or equivalent).</p> <p>If the string of Xs is too short to hold the information above, a more verbose status line is written, twice per second, to standard error instead. The first method is probably more useful to occasionally check on long captures and the second is more convenient while experimenting and setting up a capture.</p>
-p #	Specify the thread polling interval (in microseconds). The reader and writer threads poll at this interval when the ring buffer is full or empty. Polling (even frequently) on modern hardware consumes immeasurably few resources. The default interval is 1000.
-q	Suppress warnings about the ring buffer being full. If input is not from a live capture, no data is lost when the ring buffer fills so the warning can be safely suppressed. If stdin is actually a file, warning suppression happens automatically.
-z #	Specify output write block size. Any power of two between 4096 and 65536. The default is 65536.

**Table 2-9** *gulp Options (continued)*

Option	Description
-o <i>dir</i>	Redirects pcap output into a collection of files in the specified directory. Pcap files are named pcap###, where ### starts at 000 and increments. The directory must exist and be writable by the user running the <b>gulp</b> utility.
-C #	When using the -o option, start a new pcap file when the old one reaches about # times the size of the ring buffer. The default value is 10 and the default ring buffer size is 100MB; so by default, pcap files grow to about 1000 MB before a new one is started. Since some programs read an entire pcap file into memory when using it, splitting the output into chunks can be helpful.
-W #	Specifies a maximum number of pcap files to create before overwriting them. The default is to never overwrite them. This option allows capturing to occur indefinitely with finite disk space.
-B	This option enables the code to check before each write whether the write would block. When the <b>gulp</b> utility exits, it announces whether any writes would have been blocked.
-Y	This option writes which ones would be blocked, but are deferred until they will not be blocked.

**Examples**

The following example shows how to get a basic capture on eth1 with a pcap filter:

```
ServiceEngine# gulp -i eth1 -f "..." > pcapfile
```

The ellipsis (...) refers to the Berkeley Packet Filter (pcap) expressions, such as “host foo.”

The following example shows how to get a capture of the 10 most recent files of a 200 MB ring buffer to 1000 MB files:

```
ServiceEngine# gulp -i eth1 -r 200 -C 10 -W 10 -o pcapdir
```

**Related Commands**

Command	Description
<b>netmon</b>	Displays the transmit and receive activity on an interface.
<b>netstatr</b>	Displays the rate of change of netstat statistics.
<b>ss</b>	Dumps socket statistics.
<b>tcpmon</b>	Searches all TCP connections.



# help

To obtain online help for the command-line interface, use the **help** command in EXEC and Global configuration modes.

## help

---

**Syntax Description**

This command has no arguments or keywords.

---

**Command Defaults**

None

---

**Command Modes**

EXEC configuration and Global configuration (config) modes.

---

**Usage Guidelines**

You can get help at any point in a command by entering a question mark (?). If nothing matches, the help list is empty, and you must back up until entering a ? shows the available options.

Two styles of help are provided:

- Full help is available when you are ready to enter a command argument (for example, **show ?**). In addition, full help describes each possible argument.
- Partial help is provided when you enter an abbreviated command and you want to know what arguments match the input (for example, **show stat?**).

---

**Examples**

The following example shows the output of the **help** command in EXEC configuration mode:

```
ServiceEngine# help
```

```
Help may be requested at any point in a command by entering a question mark '?'. If nothing matches, the help list will be empty and you must backup until entering a '?' shows the available options.
```

```
Two styles of help are provided:
```

1. Full help is available when you are ready to enter a command argument (e.g. 'show ?') and describes each possible argument.
2. Partial help is provided when an abbreviated argument is entered and you want to know what arguments match the input (e.g. 'show stat?').

# hostname

To configure the device's network hostname, use the **hostname** command in Global configuration mode. To reset the hostname to the default setting, use the **no** form of this command.

**hostname** *name*

**no hostname**

## Syntax Description

<i>name</i>	New hostname for the device; the name is case sensitive. The name may be from 1 to 30 alphanumeric characters.
-------------	--

## Command Defaults

The default hostname is the SE model number.

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

Use this command to configure the hostname for the SE. The hostname is used for the command prompts and default configuration filenames. This name is also used by content routing and conforms to the following rules:

- It can use only alphanumeric characters and hyphens (-).
- Maximum length is 30 characters.
- Following characters are considered invalid and cannot be used when naming a device: @, #, \$, %, ^, &, \*, (), |, \, /, <, >.

## Examples

The following example changes the hostname to Sandbox:

```
ServiceEngine(config)# hostname Sandbox
Sandbox(config)#
```

The following example removes the hostname:

```
ServiceEngine(config)# no hostname
NO-HOSTNAME(config)#
```

## Related Commands

Command	Description
<b>dnslookup</b>	Resolves a host or domain name to an IP address.
<b>ip</b>	Configures the IP.
<b>show hosts</b>	Displays the IP domain name, name servers, IP addresses, and host table.

# http

To configure HTTP-related parameters, use the **http** command in Global configuration mode. To disable HTTP-related parameters, use the **no** form of this command.

```
http add-cookie string | age-multiplier num | cache-cookies | cache-fill-range | cache-on-abort
{enable | percent num} | http max-ttl {days num | hours num | minutes num | seconds num}
| min-ttl minutes | object max-size maxsize | proxy {incoming ports | outgoing {host
{hostname | ip-address} port}} | reval-each-request all
```

```
no http add-cookie string | age-multiplier num | cache-cookies | cache-fill-range | cache-on-abort
{enable | percent num} | http max-ttl {days num | hours num | minutes num | seconds num}
| min-ttl minutes | object max-size maxsize | proxy {incoming ports | outgoing {host
{hostname | ip-address} port}} | reval-each-request all
```



## Note

This command is only available on Cisco Internet Streamer CDS Release 2.5.1 and 2.5.3 software.

## Syntax Description

<b>add-cookie</b>	Add a cookie to going HTTP requests to the origin server.
<i>string</i>	Specifies string to be set as the cookie.
<b>age-multiplier</b>	Specifies the HTTP caching heuristic modifiers.
<i>num</i>	Expiration time of text objects as a percentage of their age. The range is from 0 to 100.
<b>cache-cookies</b>	Caches the web objects with associated cookies. <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>cache-fill-range</b>	Completes cache-fill for a range request starting from 0.
<b>cache-on-abort</b>	Sets the <b>cache-on-abort</b> configuration options. <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>enable</b>	Enables the cache-on-abort feature.
<b>percent</b>	Sets the percent threshold.
<i>num</i>	Percentage value. The range is from 1 to 99.
<b>max-ttl</b>	Sets the maximum Time To Live for objects in the cache.
<b>days</b>	Sets the maximum Time To Live for units, in days.
<i>num</i>	Maximum time to live. The range is from 1 to 1825.
<b>hours</b>	Sets the maximum Time To Live for units, in hours.
<i>num</i>	Maximum time to live. The range is from 1 to 43800.
<b>minutes</b>	Sets the maximum Time To Live for units, in minutes.
<i>num</i>	Maximum time to live. The range is from 1 to 2628000.
<b>seconds</b>	Sets the maximum Time To Live for units, in seconds.
<i>num</i>	Maximum time to live. The range is from 1 to 157680000.
<b>min-ttl</b>	Sets the minimum Time To Live for objects in the cache.
<i>minutes</i>	Minimum Time To Live, in minutes. The range is from 0 to 86400.

<b>object</b>	Configures HTTP objects. <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>max-size</b>	Maximum size of a cacheable object in MBytes, 0 means no limit (0–2047). <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<i>maxsize</i>	Maximum size of a cacheable object in kilobytes. The range is from 1 to 2096128. <b>Note</b> This keyword is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>proxy</b>	Configures the incoming proxy mode requests.
<b>incoming</b>	Configures for incoming proxy mode requests.
<i>ports</i>	Ports on which to listen for incoming HTTP, FTP, and HTTPS proxy requests (1 to 65535). You can specify a maximum of eight ports. The default is no incoming proxy.
<b>outgoing</b>	Configures the direct outgoing requests to another proxy server. <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>host</b>	Uses the outgoing HTTP proxy.
<i>hostname</i>	Hostname of the outgoing proxy.
<i>ip-address</i>	IP address of the outgoing proxy.
<i>port</i>	Port number of the outgoing proxy. The range is from 1 to 65535.
<b>reval-each-request</b>	Configures the revalidation for every request. <b>Note</b> This command is not supported on the Web Engine in Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>all</b>	Revalidates all objects on every request.

**Command Defaults**

**age-multiplier:** 30 percent for text objects and 60 percent for binary objects

*ports:* no incoming proxy

**days:** 1

**hours:** 24

**minutes:** 1440

**seconds:** 86400

**misses number:** 0

**object max-size:** 2

**outgoing monitor:** 60 seconds

The SE strips the hop-to-hop 407 response sent by the Internet proxy by default.

**http cache-on-abort:** disabled

The default is no incoming proxy.

**Command Modes**

Global configuration (config) mode.

**Usage Guidelines**

This command is only available on Cisco Internet Streamer CDS Release 2.5.1 and 2.5.3 software. Use these commands to configure specific parameters for caching HTTP objects.

**Note**

Text objects refer to HTML pages. Binary objects refer to all other web objects (for example, GIFs or JPEGs).

**Configuring Cookies**

Starting in Cisco Internet Streamer CDS Release 2.5 software, users can configure a cookie on a per-delivery service basis. Now there can be more than one cookie added to an SE because each cookie is tied to the delivery service, so the correct cookie is used for each request. To configure a cookie on an edge SE, use the **http add-cookie <cookie-string>** command.

**Transaction Logging**

Once a user has been authenticated through LDAP or a RADIUS server, all transaction logs generated by the SE for that user contain user information. If the SE is acting in proxy mode, the user ID is included in the transaction logs. If the SE is acting in transparent mode, the user IP address is included instead.

The **cache-cookies** option enables the SE to cache the binary content served with HTTP Set-cookie headers and no explicit expiration information.

The **reval-each-request** option enables the SE to revalidate all objects requested from the cache.

Use the **object max-size** option to specify the maximum size in kilobytes of a cacheable object. The default is no maximum size for a cacheable object. The **no** form of the command resets the default value.

The **http proxy** option enables the SE to operate in environments where client browsers have previously been configured to use a legacy proxy server. The SE accepts proxy-style requests when the incoming proxy ports are configured with the **http proxy incoming ports** option. Up to eight incoming proxy ports can be specified on a single command line or on multiple command lines.

To configure the SE to direct all HTTP miss traffic to a parent cache (without using ICP), use the **http proxy outgoing host port** option, where **host** is the system name or IP address of the outgoing proxy server, and **port** is the port number designated by the outgoing (upstream) server to accept proxy requests.

**Caching Policy for Client-Aborted Downloads**

Typically, a client aborts a download of an object by clicking the **Stop** icon on the browser or by closing the browser during a download. By default, the SE continues to download an object to the cache even after a client aborts the download.

The **cache-on-abort** option lets you specify if and when the SE completes the download of a cacheable object after the client aborts the request. However, if the SE determines that there is another client currently requesting the same object, caching is always completed.

If the **cache-on-abort** option is enabled and no thresholds are enabled, the SE always aborts downloading an object to the cache. You can use any combination of the following thresholds, which are specified in the HTTP header. If the option is not enabled, the client receives an error response. Response errors and read errors are returned to the client, because it is not possible to detect whether these errors are generated at the origin server or at the proxy.

**Examples**

The following example shows how to specify that the host 10.1.1.1 on port 8088 is designated as the primary proxy server and host 10.1.1.2 is designated as a backup proxy server:

```
ServiceEngine(config)# http proxy outgoing host 10.1.1.1 8088 primary
ServiceEngine(config)# http proxy outgoing host 10.1.1.2 220
```

The following example shows the output for the **show http proxy** command:

```
ServiceEngine# show http proxy
Incoming Proxy-Mode:
  Servicing Proxy mode HTTP connections on ports:    8080

Outgoing Proxy-Mode:
  Primary proxy server: 172.16.63.150    port 1 Failed
  Backup proxy servers: 172.16.236.151    port 8005
                      172.16.236.152    port 123
                      172.16.236.153    port 65535 Failed
                      172.16.236.154    port 10
Monitor Interval for Outgoing Proxy Servers is 60 seconds
Use of Origin Server upon Proxy Failures is disabled.
```

The following example shows the output for the **show statistics http requests** command:

```
ServiceEngine# show statistics http requests
Statistics - Requests
```

	Total	% of Requests
Total Received Requests:	49103	-
Forced Reloads:	109	0.2
Client Errors:	23	0.0
Server Errors:	348	0.7
URL Blocked:	0	0.0
Sent to Outgoing Proxy:	0	0.0
Failures from Outgoing Proxy:	0	0.0
Excluded from Outgoing Proxy:	0	0.0
ICP Client Hits:	0	0.0
ICP Server Hits:	0	0.0
HTTP 0.9 Requests:	2	0.0
HTTP 1.0 Requests:	49101	100.0
HTTP 1.1 Requests:	0	0.0
HTTP Unknown Requests:	0	0.0
Non HTTP Requests:	0	0.0
Non HTTP Responses:	46	0.1
Chunked HTTP Responses:	0	0.0
Http Miss Due To DNS:	0	0.0
Http Deletes Due To DNS:	0	0.0
Objects cached for min ttl:	2674	5.0

The following example shows the output for the **show statistics http proxy outgoing** command:

```
ServiceEngine# show statistics http proxy outgoing

HTTP Outgoing Proxy Statistics
```

IP	PORT	ATTEMPTS	FAILURES
172.16.23.150	8000	0	0
172.16.23.151	8080	0	0
172.16.23.152	9000	0	0
172.16.23.153	9001	0	0
172.16.23.154	9005	0	0

Requests when all proxies were failed: 0

The following example shows that with the default configuration (all **cache-on-abort** command thresholds disabled), client abort processing is configured to always abort downloading an object to the cache:

```
ServiceEngine(config)# http cache-on-abort enable
```

The following example shows that the SE is configured to always continue downloading an object to the cache (this configuration is the default):

```
ServiceEngine(config)# no http cache-on-abort
```

The following example shows that the SE is configured to use the default minimum threshold when the **cache-on-abort** option has been enabled and the threshold is set to 16 kilobytes:

```
ServiceEngine(config)# http cache-on-abort min 16
```

The following example shows that the SE is configured to ignore the minimum threshold:

```
ServiceEngine(config)# no http cache-on-abort min
```

#### Related Commands

Command	Description
<b>acquirer</b> (EXEC mode)	Configures the content acquirer.
<b>dnslookup</b>	Resolves a host or domain name to an IP address.
<b>ip name-server</b>	Specifies the address of the name server.
<b>show acquirer</b>	Displays the acquirer delivery service information and progress for a specified delivery service number or name.
<b>show http</b>	Displays the HTTP-related caching configuration.
<b>show http proxy</b>	Displays the proxy mode configuration.
<b>show statistics http requests</b>	Displays HTTP request statistics.

# icap

To use the Internet Content Adaptation Protocol (ICAP) to help the Service Engine (SE) interact with third-party software applications and plug-ins, use the **icap** command in Global configuration mode. To disable individual options, use the **no** form of this command.

**icap** { **append-x-headers** { **x-client-ip** | **x-server-ip** } | **apply rules-template** | **service camiant** { **enable** | **error-handling** { **bypass** | **return-error** } | **server url** }

**no icap** { **append-x-headers** { **x-client-ip** | **x-server-ip** } | **apply rules-template** | **service camiant** { **enable** | **error-handling** { **bypass** | **return-error** } | **server url** }



## Note

This command is only available on Cisco Internet Streamer CDS Release 2.5.1 and 2.5.3 software.

## Syntax Description

<b>append-x-headers</b>	Appends x-headers during the ICAP protocol handshake. Disabled by default. Can have multiple entries for various x-headers to be appended.  <b>Note</b> This command is not supported on Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>x-client-ip</b>	Appends x-client-IP headers to the request that is sent to the ICAP server. Disabled by default.
<b>x-server-ip</b>	Appends x-server-IP headers to the request that is sent to the ICAP server. Disabled by default.
<b>apply</b>	Enables ICAP processing for HTTP requests.  <b>Note</b> This command is not supported on Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>rules-template</b>	Enables ICAP processing for HTTP requests that match the <b>rule action use-icap-service</b> command.
<b>service</b>	Configures ICAP service.  <b>Note</b> This command is not supported on Cisco Internet Streamer CDS Release 2.5.7 software and later.
<b>camiant</b>	Policy server for QoS.
<b>enable</b>	Enables ICAP service.
<b>error-handling</b>	Specifies the error handling option for this service.
<b>bypass</b>	Bypasses this service.
<b>return-error</b>	Returns the error to the client and ends the request.
<b>server</b>	Specifies the server for this service.
<b>url</b>	Specifies the server URL for the style.

## Command Defaults

**server url**: Port 1344 is assumed if no explicit port is included in the URL.

## Command Modes

Global configuration (config) mode.



## Usage Guidelines

ICAP is an open standard for content adaptation, typically at the network edge. Content adaptation is the process of modifying the content to improve its usability. The content adaptation can include virus scanning, content translation, content filtering, content insertion, and other ways of improving the value of content for end users. ICAP specifies how an SE, acting as an HTTP proxy server, can communicate with an external device acting as an ICAP server, which filters and adapts the requested content.

ICAP provides two content-processing modes for HTTP services. These modes define the transactions that can occur between an SE acting as an ICAP client and an ICAP server. The two modes are as follows:

- Request modification (reqmod)—Allows modification of requests as they are sent from the SE to the ICAP server on their way to the origin server. The ICAP server can modify these requests depending on the services requested.
- Response modification (respmod)—Allows modification of requests after they return from the origin server. The ICAP server acts only on requested objects, after they return from the origin server.

The following is a complete list of the ICAP vendors that have been certified to interoperate with the SE:

- TrendMicro for reqmod and respmod
- Symantec for respmod

The maximum file size that is supported in the Internet Streamer CDS software is 2 GB. Files that exceed this size limit are not supported for ICAP processing.

Use the **icap append-x-headers** command to specify the ICAP extension headers that are passed to the ICAP server during the session negotiation between the SE and the ICAP server as follows:

- You can configure the SE to append the client and server IP address headers to the request that is passed to the ICAP server. This capability allows you to use your ICAP server to perform URL filtering based on the client IP address and server IP address. To enable this capability, use the **icap append-x-headers x-client-ip** and **icap append-x-headers x-server-ip** command options.
- You can configure the SE to append the username and group name headers to the request that is passed to the ICAP server. This capability allows you to use your ICAP server to perform URL filtering based on username and group name.

Also, you can choose to apply ICAP services on all HTTP requests processed by the SE or apply ICAP processing only to requests that match the Rules Template. Use the **icap apply { all | rules-template }** command to specify which ICAP services should be performed on which requests that are received by the SE. For example, use the **icap apply rules-template** command to instruct the SE to run only the ICAP services that match the **rules action use-icap-service**. Alternatively, you could use the **icap apply all** command to instruct the SE to run all the ICAP services on all the HTTP requests that it receives.

To exclude other traffic from ICAP processing, use the **rule action use-icap-service** command. The Rules Template can be used to turn off ICAP processing for various requests by applying the patterns available in the Rules Template to the incoming request. These patterns can include the following attributes of the incoming request: 7H90C0CH

- User-agent field
- Destination IP address
- Domain name

An ICAP service defines attributes that define the service and one or more servers that provide ICAP services. You can configure a maximum of ten ICAP services on a single SE and a maximum of five ICAP servers for each ICAP service. To select the type of load balancing to use among a cluster of ICAP servers, use the **load-balancing** option.

In the syntax, replace *service-id* with a name of your choice for the current ICAP service. When you enter the **icap service** command and provide a name for the ICAP service, the system displays this ICAP service configuration prompt:

```
ServiceEngine(config-icap-service)#
```

Within ICAP service configuration mode, all commands that you enter apply to the current ICAP service. To return to Global configuration mode, enter the **exit** command.

The point at which ICAP services are applied to content is called the *vectoring point*, specified using the **vector-point** option. The following three vectoring points are supported:

- Client request vectoring point (**reqmod-precache**)—ICAP server performs one of the following actions in response to the client request:
  - Terminates the connection
  - Sends a modified error response
  - Searches the cache using the URL in the request
  - Searches the cache using a modified URL
  - Modifies the request header or request body in the case of a cache miss
- Cache miss vectoring point (**reqmod-postcache**)—ICAP server performs one of the following actions before forwarding the request to the origin server:
  - Terminates the connection
  - Sends a modified error response
  - Sends the request to the origin server using the original URL
  - Sends the request to the origin server using an alternative URL
  - Modifies the request header or request body
- Server response vectoring point (**respmod-precache**)—ICAP server performs one of the following actions after receiving the response from the origin server:
  - Returns the response to the client
  - Modifies the request header or request body
  - Caches the response using the original URL
  - Caches the response using an alternative URL

With the **respmod** vectoring point, which is used by virus-scanning ICAP vendors, the performance of the SE is 300 transactions per second.

With the **reqmod-precache** vectoring point, which is used by URL filtering ICAP vendors, the performance of the SE drops 20 percent from the rated performance.


**Note**

The performance of the SE is limited by the performance of the ICAP server.


**Note**

Different ICAP services assigned to the same vectoring point can use different load balancing options.

ICAP servers process HTTP requests from clients based on the ICAP services configured at various vectoring points. ICAP servers perform content adaptation such as a request or response modification and filtering of requests or responses at the configured vectoring points while processing HTTP requests.

You can configure the maximum number of connections and the weight that can be handled by an ICAP server in a cluster of servers. The weight parameter represents the load percentage that can be redirected to the ICAP server. An ICAP server with a weight of 40 denotes that this server handles 40 percent of the load. If the total weight of all ICAP servers in a load-balanced cluster exceeds 100, the load percentage for each ICAP server is recalculated as a percentage measure represented by the weight parameters.

**Note**

Always locate the ICAP server on a public LAN and configure its public IP address on the SE. The ICAP server should not be located behind a NAT device.

ICAP servers configured at various vectoring points (especially the request modification precache vectoring points) may become overloaded with HTTP requests, because all requests pass through this point. Therefore, a cluster of ICAP servers (a load-balanced collection of ICAP servers) is made available for configuration. At a particular vectoring point, you can choose to load balance requests among the ICAP cluster of servers based on various parameters such as weighted load, client IP and server IP address-based hash, or round-robin format.

More than one ICAP service can be associated with a vectoring point. An ICAP service configured at a vectoring point can have only one load balancing scheme, irrespective of the number of servers. However, multiple ICAP services configured at one or all the vectoring points can have different load balancing schemes.

To identify the specific ICAP server and service, use the **server url** command, where the URL is in the following format:

```
icap://ICAPserverIPAddress/service-name
```

The value used for the *service-name* must match the identifier used by the specific ICAP vendor. For example, one vendor uses the service name REQ-Service for **reqmod-precache** and interscan for **respmod-precache**, while another vendor supports only **respmod-precache** and uses the service name avscan.

When ICAP processing is enabled and an HTTP browser with a streaming Java applet is opened, several undesirable things occur:

- Data for the Java applet is not updated in the browser. For example, when viewing a stock investment website, a user would not see any streaming stock updates.
- ICAP daemon on the SE continues to send updates (from the HTTP response) to the ICAP server, which overloads the ICAP server.

These conditions occur because the ICAP server is set up to inspect the entire data packet before delivering a response to the client. However, because there is a streaming request, the data continues flowing to the ICAP server indefinitely, deadlocking any response to the requesting client.

Two workarounds are available. You can configure the ICAP server to bypass the scanning process, or you can configure rules on the SE to skip ICAP processing on websites that are known to contain streaming Java applets.

To configure the ICAP server to bypass scanning, use rules such as *client\_skip\_content* or *server\_skip\_content* as follows:

- The *client\_skip\_content* rule bypasses scanning because of an HTTP request. The software looks for patterns in the HTTP header and bypasses all requests that exactly match the patterns specified in the *intscan.ini* file as follows:

```
client_skip_content=User Agent: Windows Media Player 9.0.1
```

- The `server_skip_content` rule bypasses scanning because of an HTTP response. The software looks for patterns in the HTTP header and bypasses all responses that exactly match the patterns specified in the `intscan.ini` file as follows:

```
server_skip_content=Content-Type: X-Dave_Content
```

Alternatively, you can configure the SE to bypass ICAP processing based on user agents or any of the patterns available in the Rules Template, by using the **rule** command.

## Examples

The following example applies ICAP processing to all traffic:

```
ServiceEngine(config)# icap apply all
```

The following examples exclude intranet traffic from ICAP processing:

```
ServiceEngine(config)# rule pattern-list 1 domain !cisco.com
ServiceEngine(config)# rule action use-icap-service trend-reqmod 1 protocol all
ServiceEngine(config)# rule action use-icap-service trend-respmod 1 protocol all
ServiceEngine(config)# rule enable
ServiceEngine(config)# icap apply rules-template
```

The following example shows how to use the **icap service service-id** command to configure and enable various ICAP services on this SE:

```
ServiceEngine(config)# icap service trend-reqmod
ServiceEngine(config-icap-service)# enable
ServiceEngine(config-icap-service)# vector-point reqmod-precache
ServiceEngine(config-icap-service)# server icap://172.19.227.150/REQ-Service
ServiceEngine# exit
```

```
ServiceEngine(config)# icap service trend-respmod
ServiceEngine(config-icap-service)# enable
ServiceEngine(config-icap-service)# vector-point respmod-precache
ServiceEngine(config-icap-service)# server icap://172.19.227.150/interscan
ServiceEngine# exit
```

The following examples show a typical configuration for a virus scanning service that requires processing on two vectoring points (**reqmod-precache** and **respmod-precache**):

```
ServiceEngine(config)# icap apply all
ServiceEngine(config)# icap service trend-reqmod
ServiceEngine(config-icap-service)# enable
ServiceEngine(config-icap-service)# vector-point reqmod-precache
ServiceEngine(config-icap-service)# server icap://172.19.227.150/REQ-Service
ServiceEngine# exit
ServiceEngine# icap service trend-respmod
ServiceEngine(config-icap-service)# enable
ServiceEngine(config-icap-service)# vector-point respmod-precache
ServiceEngine(config-icap-service)# server icap://172.19.227.150/interscan
ServiceEngine# exit
```

The following example shows that if an ICAP vendor supports the same service name for more than one vectoring point, you can configure a single service and add the supported vectoring points:

```
ServiceEngine(config)# icap service myicap-service
ServiceEngine(config-icap-service)# enable
ServiceEngine(config-icap-service)# vector-point reqmod-precache
ServiceEngine(config-icap-service)# vector-point respmod-precache
ServiceEngine(config-icap-service)# server icap://172.19.227.150/icap-service-name
ServiceEngine(config-icap-service)# exit
ServiceEngine(config)#
```

The following example shows that the SE is configured to bypass ICAP processing on the intranet site cisco.com and on the trusted Internet site datek.com:

```
SE(config)# rule enable
SE(config)# rule action use-icap-service trend-reqmod pattern-list 1 protocol all
SE(config)# rule action use-icap-service trend-respmod pattern-list 1 protocol all
SE(config)# rule pattern-list 1 domain !(*.cisco\.com | *.datek\.com)!
SE(config)# icap apply rules-template
SE(config)# icap service trend-reqmod
SE(config-icap-service)# enable
SE(config-icap-service)# vector-point reqmod-precache
SE(config-icap-service)# server icap://172.19.227.150/REQ-Service
SE(config-icap-service)# exit
SE(config)# icap service trend-respmod
SE(config-icap-service)# enable
SE(config-icap-service)# vector-point respmod-precache
SE(config-icap-service)# server icap://172.19.227.150/interscan
SE(config-icap-service)# exit
```

#### Related Commands

Command	Description
<b>icap service</b>	Configures ICAP service configurations. Provides access to the ICAP service configuration mode.
<b>rule use-icap-service</b>	Sets the rules by which the SE filters a specific ICAP server.
<b>show icap</b>	Displays the ICAP configurations.
<b>show icap service</b>	Displays the configurations for the specified service.
<b>show rule action use-icap-service</b>	Displays rules configuration information for a certain ICAP service configuration mode.

# install

To install the Internet Streamer CDS software image, use the **install** command in EXEC configuration mode.

**install** *imagefilename*

## Syntax Description

<i>imagefilename</i>	Name of the .bin file that you want to install.
----------------------	---

## Command Defaults

None

## Command Modes

EXEC configuration mode.

## Usage Guidelines

The **install** command loads the system image into flash memory and the disk.

To install a system image, copy the image file to the sysfs directory local1 or local2. Before entering the **install** command, change the present working directory to the directory where the system image resides. When the **install** command is executed, the image file is expanded. The expanded files overwrite the existing files in the SE. The newly installed version takes effect after the system image is reloaded.



### Note

The **install** command does not accept .pax files. Files should be of the .bin type (for example, CDS-2.2.1.7-K9.bin). Also, if the release being installed does not require a new system image, then it may not be necessary to write to flash memory. If the newer version has changes that require a new system image to be installed, then the **install** command may result in a write to flash memory.

## Examples

The following example shows how to install a .bin file on the SE:

```
ServiceEngine# install CDS-2.2.1.7-K9.bin
```

## Related Commands

Command	Description
<b>copy ftp install</b>	Installs an image file from an FTP server onto a local device.
<b>copy http install</b>	Installs an image file from an HTTP server onto a local device.
<b>reload</b>	Halts a device and performs a cold restart.

# interface

To configure a Gigabit Ethernet or port channel interface, use the **interface** command in Global configuration mode. To disable selected options, restore default values, or enable a shutdown interface, use the **no** form of this command.

```
interface {GigabitEthernet slot/port num | PortChannel num [autosense | bandwidth {10 | 100 | 1000} | description line | exit | full-duplex | half-duplex | ip {access-group {num {in | out} | name} | address {ip address netmask | range low-num high-num netmask} | ipv6 address addr/netmask | no | shutdown | standby num {priority num}}] | Standby group number}
```

```
no interface {GigabitEthernet slot/port num | PortChannel num [autosense | bandwidth {10 | 100 | 1000} | description line | exit | full-duplex | half-duplex | ip {access-group {num {in | out} | name} | address {ip address netmask | range low-num high-num netmask} | ipv6 address addr/netmask | no | shutdown | standby num {priority num}}] | Standby group number}
```

Syntax	Description
<b>GigabitEthernet</b>	Selects a Gigabit Ethernet interface to configure.
<i>slot/port num</i>	Slot and port number for the selected interface. The slot range is from 0 to 12; the port range is from 0 to 0. The slot number and port number are separated with a forward slash character (/).
<b>PortChannel</b>	Selects the Ethernet Channel of interfaces to be configured.
<i>num</i>	Sets the Ethernet Channel interface number (1 to 4).
<b>autosense</b>	(Optional) Specifies interface autosense. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>bandwidth</b>	(Optional) Configures the interface bandwidth. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>10</b>	Specifies the interface bandwidth as 10 Mbits per second.
<b>100</b>	Specifies the interface bandwidth as 100 Mbits per second.
<b>1000</b>	Specifies the interface bandwidth as 1000 Mbits per second. <b>Note</b> This option is not available on all ports, the same as autosense.
<b>description</b>	(Optional) Specifies interface specific description. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<i>line</i>	Text describing this interface
<b>exit</b>	(Optional) Exits from this submode. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>full-duplex</b>	(Optional) Specifies full-duplex. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>half-duplex</b>	(Optional) Specifies half-duplex. <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.

<b>ip</b>	(Optional) Interface Internet Protocol configuration commands.  <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>access-group</b>	Specifies access control for packets.
<i>num</i>	IP access list (standard or extended).
<b>in</b>	Specifies inbound packets.
<b>out</b>	Specifies outbound packets.
<i>name</i>	Specifies the access-list name.
<b>address</b>	Sets the IP address of the interface.
<i>ip address</i>	IP address of the interface
<i>netmask</i>	Netmask of the interface.
<i>range</i>	IP address range.
<i>low-num</i>	IP address low range of the interface.
<i>high-num</i>	IP address low range of the interface.
<b>netmask</b>	Netmask of the interface.
<b>ipv6</b>	(Optional) Interface IPv6 configuration commands.  <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<i>address</i>	IPv6 address of the interface.
<i>addr/netmask</i>	IPv6 address/netmask of the interface in format X:X:X:X::X/<0-128>.
<b>no</b>	(Optional) Negates a command or sets its defaults.  <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>shutdown</b>	(Optional) Shuts down the specific portchannel interface.  <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<b>standby</b>	(Optional) Standby interface configuration commands.  <b>Note</b> This command is only available on Cisco Internet Streamer CDS Release 2.5.9 software.
<i>num</i>	Standby group number (1-4).
<b>priority</b>	(Optional) Sets the priority of the interface. Default value is 100.
<i>num</i>	Sets the priority of the interface for the standby group (0-4294967295).
<b>Standby</b>	Sets the standby group for the interface.
<i>group number</i>	Group number for the selected interface (1 to 4).

**Command Defaults**

Standby priority: 100.

**Command Modes**

Global configuration (config) mode.



**Usage Guidelines****Configuring Interfaces for DHCP**

During the initial configuration of an SE, you have the option of configuring a static IP address for the SE or using interface-level DHCP to dynamically assign IP addresses to the interfaces on the SE.

If you do not enable interface-level DHCP on the SE, manually specify a static IP address and network mask for the SE. If the SE moves to another location in another part of the network, manually enter a new static IP address and network mask for this SE.

**Note**

All static route entries are lost when removing the IP configuration from the network interface.

An interface can be enabled for DHCP by using the **ip address dhcp** [*client\_id* \ *hostname*] command in interface configuration mode. The client identifier is an ASCII value. The SE sends its configured client identifier and hostname to the DHCP server when requesting network information. DHCP servers can be configured to identify the client identifier information and the hostname information that the SE is sending and then send back the specific network settings that are assigned to the SE.

**String to Be Set as Cookie Port Channel (EtherChannel) Interface**

EtherChannel for Cisco Internet Streamer CDS Release 2.x software supports the grouping of up to four same- network interfaces into one virtual interface. This grouping allows the setting or removing of a virtual interface that consists of two Gigabit Ethernet interfaces. EtherChannel also provides interoperability with Cisco routers, switches, and other networking devices or hosts supporting EtherChannel, load balancing, and automatic failure detection and recovery based on current link status of each interface.

You can use the Gigabit Ethernet ports to form an EtherChannel. A physical interface can be added to an EtherChannel subject to the device configuration.

**Configuring Multiple IP Addresses**

The Multiple Logical IP Addresses feature supports up to 24 unique IP addresses within the same subnet for the same interface.

When you configure multiple IP addresses on an SE using either the range option or using individual commands, the **show running-config** output displays all the IP addresses individually. The netmask value is unique for each interface, so under a single interface you cannot have multiple IP addresses with different netmask values.

**Examples**

The following example shows how to create an EtherChannel. The port channel is port channel 2 and is assigned an IP address of 10.10.10.10 and a netmask of 255.0.0.0:

```
ServiceEngine# configure
ServiceEngine(config)# interface PortChannel 2
ServiceEngine(config-if)# exit
```

The following example shows how to remove an EtherChannel:

```
ServiceEngine(config)# interface PortChannel 2
ServiceEngine(config-if)# exit
ServiceEngine(config)# no interface PortChannel 2
```

The following example shows a sample output of the **show running-config** command in EXEC configuration mode:

```
ServiceEngine# show running-config
.
.
```

```

.
interface GigabitEthernet 0/0
  description This is an interface to the WAN
  ip address dhcp
  ip address 192.168.1.200 255.255.255.0
bandwidth 100
exit
.

```

The following example shows the sample output of the **show interface** command:

```

ServiceEngine# show interface GigabitEthernet 1/0
Description: This is the interface to the lab
type: Ethernet

```

The following example shows how to create standby groups on SEs:

```

ServiceEngine(config)# interface GigabitEthernet 1/0 standby 2 priority 300
ServiceEngine(config)# interface GigabitEthernet 2/0 standby 2 priority 200
ServiceEngine(config)# interface GigabitEthernet 3/0 standby 2 priority 100
ServiceEngine(config)# interface standby 2 errors 10000

```

The following example shows how to configure multiple IP addresses using a range command:

```

ServiceEngine(config)# interface PortChannel 2
ServiceEngine(config-if)# ip address range 2.2.2.3 2.2.2.6 255.255.255.0

```

The following example shows a sample output of the **show running-config** command in EXEC configuration mode after configuring multiple IP addresses:

```

ServiceEngine# show running-config
.
interface PortChannel 4
  ip address 2.2.2.3 255.255.255.0
  ip address 2.2.2.4 255.255.255.0
  ip address 2.2.2.5 255.255.255.0
  ip address 2.2.2.6 255.255.255.0
exit

```

#### Related Commands

Command	Description
<b>show interface</b>	Displays the hardware interface information.
<b>show running-config</b>	Displays the current operating configuration.
<b>show startup-config</b>	Displays the startup configuration.

# ip (Global configuration)

To change initial network device configuration settings, use the **ip** command in Global configuration mode. To delete or disable these settings, use the **no** form of this command. The **dscp** option allows you to set the global Type of Service (ToS) or differentiated services code point (DSCP) values in IP packets.

**ip access list** (see “[ip access-list](#)” section on page 209)

**ip default-gateway** *ip-address* [*gateway ip addr 2 gateway ip addr 3*]

**ip domain-name** *name1 name2 name3*

**ip dscp** {**client** {**cache-hit** {**match-server** | **set-dscp** *dscp-packets* | **set-tos** *tos-packets*} | **cache-miss** {**match-server** | **set-dscp** *dscp-packets* | **set-tos** *tos-packets*} } | **server** {**match-client** | **set-dscp** *dscp-packets* | **set-tos** *tos-packets*} }

**ip name-server** *ip-addresses*

**ip path-mtu-discovery** **enable**

**ip route** *dest\_IP\_addr dest\_netmask default\_gateway* [**interface** *source\_IP\_addr*]

**no ip** {**default-gateway** [*gateway ip addr 2 gateway ip addr 3*] | **domain-name** | **dscp** {**client** {**cache-hit** | **cache-miss**} | **server**} | **name-server** *ip-addresses* | **path-mtu-discovery** **enable** | **route** *dest\_IP\_addr dest\_netmask default\_gateway* [**interface** *source\_IP\_addr*] }

## Syntax Description

<b>default-gateway</b>	Specifies the default gateway (if not routing IP).
<i>ip-address</i>	IP address of the default gateway.
<i>gateway ip addr</i>	Gateway IP address (maximum of 14).
	<b>Note</b> Starting with Cisco Internet Streamer CDS Release 2.5.7 software, multiple gateways (up to 14) can be configured.
<b>domain-name</b>	Specifies domain names.
<i>name1</i> through <i>name3</i>	Domain name (up to three can be specified).
<b>dscp</b>	Configures IP differentiated services code point (DSCP) and Type of Service (ToS) fields.
<b>client</b>	Configures DSCP for responses to the client.
<b>cache-hit</b>	Configures the cache hit responses to the client.
<b>cache-miss</b>	Configures the cache miss responses to the client.
<b>match-server</b>	Uses the original ToS or DSCP value of the server.
<b>set-dscp</b>	Configures differentiated services code point (DSCP) values.
<i>dscp-packets</i>	DSCP values; see <a href="#">Table 2-10</a> for valid values.
<b>set-tos</b>	Configures Type of Service (ToS).
<i>tos-packets</i>	ToS value; see <a href="#">Table 2-12</a> for valid values.
<b>server</b>	Configures DSCP for outgoing requests.
<b>match-client</b>	Uses the original ToS or DSP value of the client.
<b>name-server</b>	Specifies the address of the name server.
<i>ip-addresses</i>	IP addresses of the name servers (up to a maximum of eight).

<b>path-mtu-discovery</b>	Configures RFC 1191 Path Maximum Transmission Unit (MTU) discovery.
<b>enable</b>	Enables Path MTU discovery.
<b>route</b>	Specifies the net route.
<i>dest_IP_addr</i>	Destination route address.
<i>dest_netmask</i>	Netmask address.
<i>default_gateway</i>	Gateway address.
<b>interface</b>	Configures source policy routing to route outgoing traffic using the same interface where the request was received.  <b>Note</b> This keyword is only available on Cisco Internet Streamer CDS Release 2.5.7 software and later.
<i>source_IP_addr</i>	IP address of the interface configured for source policy routing.

**Command Defaults** None

**Command Modes** Global configuration (config) mode.

### Usage Guidelines

To define a default gateway, use the **ip default-gateway** command. Only one default gateway can be configured. To remove the IP default gateway, use the **no** form of this command. The SE uses the default gateway to route IP packets when there is no specific route found to the destination.

To define a default domain name, use the **ip domain-name** command. To remove the IP default domain name, use the **no** form of this command. Up to three domain names can be entered. If a request arrives without a domain name appended in its hostname, the proxy tries to resolve the hostname by appending *name1*, *name2*, and *name3* in that order until one of these names succeeds.

The SE appends the configured domain name to any IP hostname that does not contain a domain name. The appended name is resolved by the DNS server and then added to the host table. The SE must have at least one domain name server specified for hostname resolution to work correctly.

To specify the address of one or more name servers to use for name and address resolution, use the **ip name-server ip-addresses** command. To disable IP name servers, use the **no** form of this command. For proper resolution of the hostname to the IP address or the IP address to the hostname, the SE uses DNS servers. Use the **ip name-server** command to point the SE to a specific DNS server. You can configure up to eight servers.

Path MTU autodiscovery discovers the MTU and automatically sets the correct value. Use the **ip path-mtu-discovery enable** command to start this autodiscovery utility. By default, this feature is enabled. When this feature is disabled, the sending device uses a packet size that is smaller than 576 bytes and the next hop MTU. Existing connections are not affected when this feature is turned on or off.

The Cisco Internet Streamer CDS software supports IP Path MTU Discovery, as defined in RFC 1191. When enabled, Path MTU Discovery discovers the largest IP packet size allowable between the various links along the forwarding path and automatically sets the correct value for the packet size. By using the largest MTU that the links bear, the sending device can minimize the number of packets that it must send.

**Note**

IP Path MTU Discovery is useful when a link in a network goes down, forcing the use of another, different MTU-sized link. IP Path MTU Discovery is also useful when a connection is first being established and the sender has no information at all about the intervening links.

IP Path MTU Discovery is started by the sending device. If a server does not support IP Path MTU Discovery, the receiving device has no mechanism available to avoid fragmenting datagrams generated by the server.

Use the **ip route** command to add a specific static route for a network or host. Any IP packet designated for the specified destination uses the configured route.

To configure static IP routing, use the **ip route** command. To remove the route, use the **no** form of this command. Do not use the **ip route 0.0.0.0 0.0.0.0** command to configure the default gateway; use the **ip default-gateway** command instead.

In the CDS network, you can configure SEs, SRs, and CDSMs for the Type of Service (ToS) or differentiated services code point (DSCP) using the **ip dscp** command.

**Source Policy Routes**

To configure source policy routing, use the **ip route** command with the interface option. By using source policy routing, the reply packet to a client will leave the SE on the same interface where the request came in. Source policy routing tables are automatically instantiated based on the interface subnets defined on the system. The policy routes are added automatically to the policy routing tables based on the nexthop gateway of the routes in the main routing table.

When configuring multiple ip address you must configure a default gateway in the same subnet.

**Note**

Starting with Cisco Internet Streamer CDS Release 2.5.7 software, multiple gateways (up to 14) can be configured.

Cisco Internet Streamer CDS Release 2.5.7 software supports multiple IP addresses on the CDE220-2S3i, which included specifying the default gateway and IP routes. The IP routes, source policy routes, were added to ensure incoming traffic would go out the same interface it came in on. An IP route was added using the **interface** keyword, which was introduced in Cisco Internet Streamer CDS Release 2.5.7 software, and has the following syntax:

**ip route** *<dest\_IP\_addr> <dest\_netmask> <default\_gateway> interface <source\_IP\_addr>*

In the following example, all destination traffic (IP address of 0.0.0.0 and netmask of 0.0.0.0) sent from the source interface, 8.1.0.2, uses the default gateway, 8.1.0.1. This is a default policy route.

**ip route 0.0.0.0 0.0.0.0 8.1.0.1 interface 8.1.0.2**

A non-default policy route defines a specific destination (IP address and netmask). The following **ip route** command is an example of a non-default policy route:

**ip route 10.1.1.0 255.255.255.0 <gateway> interface <source\_IP\_addr>**

When upgrading to Cisco Internet Streamer CDS Release 2.5.9 software, any source policy routes configured using the Cisco Internet Streamer CDS Release 2.5.7 software interface keyword are rejected and are not displayed when the **show running-config** command is used. However, because you had to define the default gateway for all the interfaces as part of the multi-port support feature, the equivalent source policy route is automatically generated in the routing table. The following example shows the output for the **show ip route** command after upgrading to Cisco Internet Streamer CDS Release 2.5.9 software with the default source policy routes highlighted in bold and the non-default policy routes highlighted in italics:

```
ServiceEngine# show ip route
```

Destination	Gateway	Netmask
172.22.28.0	8.1.0.1	255.255.255.128
6.21.1.0	0.0.0.0	255.255.255.0
8.2.1.0	0.0.0.0	255.255.255.0
8.2.2.0	0.0.0.0	255.255.255.0
171.70.77.0	8.1.0.1	255.255.255.0
8.1.0.0	0.0.0.0	255.255.0.0
0.0.0.0	8.1.0.1	0.0.0.0
0.0.0.0	8.2.1.1	0.0.0.0
0.0.0.0	8.2.2.1	0.0.0.0

Source policy routing table for interface 8.1.0.0/16

172.22.28.0	8.1.0.1	255.255.255.128
171.70.77.0	8.1.0.1	255.255.255.0
8.1.0.0	0.0.0.0	255.255.0.0
<b>0.0.0.0</b>	<b>8.1.0.1</b>	<b>0.0.0.0</b>

Source policy routing table for interface 8.2.1.0/24

8.2.1.0	0.0.0.0	255.255.255.0
<b>0.0.0.0</b>	<b>8.2.1.1</b>	<b>0.0.0.0</b>

Source policy routing table for interface 8.2.2.0/24

8.2.2.0	0.0.0.0	255.255.255.0
<b>0.0.0.0</b>	<b>8.2.2.1</b>	<b>0.0.0.0</b>

If you have a default source policy route where the gateway is not defined as a default gateway, then you must add it after upgrading to Cisco Internet Streamer CDS Release 2.5.9 software. For example, if you had a source policy route with a gateway of 6.23.1.1 for a source interface of 6.23.1.12, and you did not specify the gateway as one of the default gateways, you would need to add it.

If you have a non-default source policy route, then you must add it as a regular static route (without the obsoleted interface keyword) after upgrading to Cisco Internet Streamer CDS Release 2.5.9 software. This route is then added to the main routing table as well as the policy routing table.

### Differentiated Services

The differentiated services (DiffServ) architecture is based on a simple model where traffic entering a network is classified and possibly conditioned at the boundaries of the network. The class of traffic is then identified with a differentiated services (DS) code point or bit marking in the IP header. Within the core of the network, packets are forwarded according to the per-hop behavior associated with the DS code point.

To set the global ToS or DSCP values for the IP header from the CLI, use the **ip dscp** command.

DiffServ describes a set of end-to-end QoS (Quality of Service) capabilities. End-to-end QoS is the ability of the network to deliver service required by specific network traffic from one end of the network to another. QoS in the Internet Streamer CDS software supports differentiated services.

With differentiated services, the network tries to deliver a particular kind of service based on the QoS specified by each packet. This specification can occur in different ways, for example, using the 6-bit DSCP setting in IP packets or source and destination addresses. The network uses the QoS specification to classify, mark, shape, and police traffic, and to perform intelligent queuing.

Differentiated services is used for several mission-critical applications and for providing end-to-end QoS. Typically, differentiated services is appropriate for aggregate flows because it performs a relatively coarse level of traffic classification.

Use the **ip dscp { client | server } { cache-hit | cache-miss } set-dscp dscp-packets** command to set the DSCP values for the IP header. Valid values for *dscp-packets* are listed in [Table 2-10](#).

**Table 2-10** *dscp-packets Values*

Value or Keyword	Description <sup>1</sup>
0–63	Sets DSCP values.
<b>af11</b>	Sets packets with AF11 DSCP (001010).
<b>af12</b>	Sets packets with AF12 DSCP (001100).
<b>af13</b>	Sets packets with AF13 DSCP (001110).
<b>af21</b>	Sets packets with AF21 DSCP (010010).
<b>af22</b>	Sets packets with AF22 DSCP (010100).
<b>af23</b>	Sets packets with AF23 DSCP (010110).
<b>af31</b>	Sets packets with AF31 DSCP (011010).
<b>af32</b>	Sets packets with AF32 DSCP (011100).
<b>af33</b>	Sets packets with AF33 DSCP (011110).
<b>af41</b>	Sets packets with AF41 DSCP (100010).
<b>af42</b>	Sets packets with AF42 DSCP (100100).
<b>af43</b>	Sets packets with AF43 DSCP (100110).
<b>cs1</b>	Sets packets with CS1 (precedence 1) DSCP (001000).
<b>cs2</b>	Sets packets with CS2 (precedence 2) DSCP (010000).
<b>cs3</b>	Sets packets with CS3 (precedence 3) DSCP (011000).
<b>cs4</b>	Sets packets with CS4 (precedence 4) DSCP (100000).
<b>cs5</b>	Sets packets with CS5 (precedence 5) DSCP (101000).
<b>cs6</b>	Sets packets with CS6 (precedence 6) DSCP (110000).
<b>cs7</b>	Sets packets with CS7 (precedence 7) DSCP (111000).
<b>default</b>	Sets packets with the default DSCP (000000).
<b>ef</b>	Sets packets with EF DSCP (101110).

1. The number in parentheses denotes the DSCP value for each per-hop behavior keyword.

### DS Field Definition

A replacement header field, called the *DS field*, is defined by differentiated services. The DS field supersedes the existing definitions of the IPv4 ToS octet (RFC 791) and the IPv6 traffic class octet. Six bits of the DS field are used as the DSCP to select the Per Hop Behavior (PHB) at each interface. A currently unused (CU) 2-bit field is reserved for explicit congestion notification (ECN). The value of the CU bits is ignored by DS-compliant interfaces when determining the PHB to apply to a received packet.

### Per-Hop Behaviors

RFC 2475 defines PHB as the externally observable forwarding behavior applied at a DiffServ-compliant node to a DiffServ Behavior Aggregate (BA).

With the ability of the system to mark packets according to the DSCP setting, collections of packets that have the same DSCP setting and that are sent in a particular direction can be grouped into a BA. Packets from multiple sources or applications can belong to the same BA.

A PHB refers to the packet scheduling, queueing, policing, or shaping behavior of a node on any given packet belonging to a BA, as configured by a service level agreement (SLA) or a policy map.

There are four available standard PHBs:

- Default PHB (as defined in RFC 2474)
- Class-Selector PHB (as defined in RFC 2474)
- Assured Forwarding (AFny) PHB (as defined in RFC 2597)
- Expedited Forwarding (EF) PHB (as defined in RFC 2598)

The following sections describe the PHBs.

### Default PHB

The default PHB specifies that a packet marked with a DSCP value of 000000 (recommended) receives the traditional best-effort service from a DS-compliant node (a network node that complies with all the core DiffServ requirements). Also, if a packet arrives at a DS-compliant node, and the DSCP value is not mapped to any other PHB, the packet gets mapped to the default PHB.

### Class-Selector PHB

To preserve backward compatibility with any IP precedence scheme currently in use on the network, DiffServ has defined a DSCP value in the form *xxx000*, where *x* is either 0 or 1. These DSCP values are called *Class-Selector Code Points*. (The DSCP value for a packet with default PHB 000000 is also called the Class-Selector Code Point.)

The PHB associated with a Class-Selector Code Point is a Class-Selector PHB. These Class-Selector PHBs retain most of the forwarding behavior as nodes that implement IP precedence-based classification and forwarding.

For example, packets with a DSCP value of 110000 (the equivalent of the IP precedence-based value of 110) have preferential forwarding treatment (for scheduling, queueing, and so on), as compared to packets with a DSCP value of 100000 (the equivalent of the IP precedence-based value of 100). These Class-Selector PHBs ensure that DS-compliant nodes can coexist with IP precedence-based nodes.

### Assured Forwarding PHB

Assured Forwarding PHB is nearly equivalent to Controlled Load Service, which is available in the integrated services model. AFny PHB defines a method by which BAs can be given different forwarding assurances.

For example, network traffic can be divided into the following classes:

- Gold—Traffic in this category is allocated 50 percent of the available bandwidth.
- Silver—Traffic in this category is allocated 30 percent of the available bandwidth.
- Bronze—Traffic in this category is allocated 20 percent of the available bandwidth.

The AFny PHB defines four AF classes: AF1, AF2, AF3, and AF4. Each class is assigned a specific amount of buffer space and interface bandwidth according to the SLA with the service provider or policy map.

Within each AF class, you can specify three drop precedence (dP) values: 1, 2, and 3. Assured Forwarding PHB can be expressed as shown in the following example: AFny. In this example, *n* represents the AF class number (1, 2, or 3) and *y* represents the dP value (1, 2, or 3) within the AFn class.

In instances of network traffic congestion, if packets in a particular AF class (for example, AF1) need to be dropped, packets in the AF1 class are dropped according to the following guideline:

$$dP(AFny) \geq dP(AFnz) \geq dP(AFnx)$$

where *dP* (AFny) is the probability that packets of the AFny class are dropped and *y* denotes the dP within an AFn class.



In the following example, packets in the AF13 class are dropped before packets in the AF12 class, which in turn are dropped before packets in the AF11 class:

```
dP(AF13) >= dP (AF12) >= dP(AF11)
```

The dP method penalizes traffic flows within a particular BA that exceed the assigned bandwidth. Packets on these offending flows could be re-marked by a policer to a higher drop precedence.

An AFx class can be denoted by the DSCP value, xyzab0, where xyz can be 001, 010, 011, or 100, and ab represents the dP value.

Table 2-11 lists the DSCP value and corresponding dP value for each AF PHB class.

**Table 2-11 DSCP Values and Corresponding Drop Precedence Values for Each AF PHB Class**

Drop Precedence	Class 1	Class 2	Class 3	Class 4
Low drop precedence	001010	010010	011010	100010
Medium drop precedence	001100	010100	011100	100100
High drop precedence	001110	010110	011110	100110

### Expedited Forwarding PHB

Resource Reservation Protocol (RSVP), a component of the integrated services model, provides a guaranteed bandwidth service. Applications, such as Voice over IP (VoIP), video, and online trading programs, require this type of service. The EF PHB, a key ingredient of DiffServ, supplies this kind of service by providing low loss, low latency, low jitter, and assured bandwidth service.

You can implement EF by using priority queueing (PQ) and rate limiting on the class (or BA). When implemented in a DiffServ network, EF PHB provides a virtual leased line or premium service. For optimal efficiency, however, you should reserve EF PHB for only the most critical applications because, in instances of traffic congestion, it is not feasible to treat all or most traffic as high priority.

EF PHB is suited for applications such as VoIP that require low bandwidth, guaranteed bandwidth, low delay, and low jitter.

### IP Precedence for ToS

IP precedence allows you to specify the class of service (CoS) for a packet. You use the three precedence bits in the IPv4 header's type of service (ToS) field for this purpose.

Using the ToS bits, you can define up to six classes of service. Other features configured throughout the network can then use these bits to determine how to treat the packet. These other QoS features can assign appropriate traffic-handling policies including congestion management strategy and bandwidth allocation. For example, although IP precedence is not a queueing method, queueing methods such as weighted fair queueing (WFQ) and Weighted Random Early Detection (WRED) can use the IP precedence setting of the packet to prioritize traffic.

By setting precedence levels on incoming traffic and using them with the Internet Streamer CDS software QoS queueing features, you can create differentiated service. You can use features, such as policy-based routing (PBR) and Committed Access Rate (CAR), to set the precedence based on an extended access list classification. For example, you can assign the precedence based on the application or user or by destination and source subnetwork.

So that each subsequent network element can provide service based on the determined policy, IP precedence is usually deployed as close to the edge of the network or the administrative domain as possible. IP precedence is an edge function that allows core or backbone QoS features, such as WRED, to forward traffic based on CoS. You can also set IP precedence in the host or network client, but this setting can be overridden by the service provisioning policy of the domain within the network.

The following QoS features can use the IP precedence field to determine how traffic is treated:

- Distributed-WRED
- WFQ
- CAR

#### How the IP Precedence Bits Are Used to Classify Packets

You use the three IP precedence bits in the ToS field of the IP header to specify a CoS assignment for each packet. You can partition traffic into up to six classes—the remaining two classes are reserved for internal network use—and then use policy maps and extended ACLs to define network policies in terms of congestion handling and bandwidth allocation for each class.

Each precedence corresponds to a name. These names, which continue to evolve, are defined in RFC 791. The numbers and their corresponding names, are listed from least to most important.

IP precedence allows you to define your own classification mechanism. For example, you might want to assign the precedence based on an application or an access router. IP precedence bit settings 96 and 112 are reserved for network control information, such as routing updates.

The IP precedence field occupies the three most significant bits of the ToS byte. Only the three IP precedence bits reflect the priority or importance of the packet, not the full value of the ToS byte.

Use the **ip dscp { client | server } { cache-hit | cache-miss } set-tos *tos-packets*** command to specify either of the two arguments—IP precedence or ToS byte value—to set the same ToS. You may specify either the ToS byte value or IP precedence; one is required. IP precedence uses the three precedence bits in the ToS field of the IPv4 header to specify the class of service for each packet. The ToS byte in the IP header defines the three high-order bits as IP precedence bits and the five low-order bits as ToS bits. The ToS byte value is written to the five low-order bits (bits 0 to 4) of the ToS byte in the IP header of a packet. The IP precedence value is written to the three high-order bits (bits 5 to 7) of the ToS byte in the IP header of a packet.

The following is a list of precedence names:

- **critical**
- **flash**
- **flash-override**
- **immediate**
- **internet**
- **network**
- **priority**
- **routine**

The following is a list of ToS names:

- **max-reliability**
- **max-throughput**
- **min-delay**
- **min-monetary-cost**
- **normal**

Table 2-12 lists the valid values for *tos-packets*.

**Table 2-12** *tos-packets Values*

Value, Precedence, or ToS Name	Description <sup>1</sup>
0–127	Sets the ToS value.
<b>critical</b>	Sets packets with critical precedence (80).
<b>flash</b>	Sets packets with flash precedence (48).
<b>flash-override</b>	Sets packets with flash override precedence (64).
<b>immediate</b>	Sets packets with immediate precedence (32).
<b>internet</b>	Sets packets with internetwork control precedence (96).
<b>max-reliability</b>	Sets packets with maximum reliable ToS (2).
<b>max-throughput</b>	Sets packets with maximum throughput ToS (4).
<b>min-delay</b>	Sets packets with minimum delay ToS (8).
<b>min-monetary-cost</b>	Sets packets with minimum monetary cost ToS (1).
<b>network</b>	Sets packets with network control precedence (112).
<b>normal</b>	Sets packets with normal ToS (0).
<b>priority</b>	Sets packets with priority precedence (16).

1. The number in parentheses denotes the ToS value for each IP precedence or ToS name setting.

## Examples

The following example shows how to configure a default gateway for the SE:

```
ServiceEngine(config)# ip default-gateway 192.168.7.18
```

The following example disables the default gateway:

```
ServiceEngine(config)# no ip default-gateway
```

The following example shows how to configure a static IP route for the SE:

```
ServiceEngine(config)# ip route 172.16.227.128 255.255.255.0 172.16.227.250
```

The following example negates the static IP route:

```
ServiceEngine(config)# no ip route 172.16.227.128 255.255.255.0 172.16.227.250
```

The following example shows how to configure a default domain name for the SE:

```
ServiceEngine(config)# ip domain-name cisco.com
```

The following example negates the default domain name:

```
ServiceEngine(config)# no ip domain-name
```

The following example shows how to configure a name server for the SE:

```
ServiceEngine(config)# ip name-server 10.11.12.13
```

The following example disables the name server:

```
ServiceEngine(config)# no ip name-server 10.11.12.13
```

The following example shows how to configure source policy routing for the SE interface assigned with the IP address 192.168.1.5:

```
ServiceEngine(config)# ip route 0.0.0.0 0.0.0.0 192.168.1.1 interface 192.168.1.5
```

**Related Commands**

Command	Description
<b>show ip routes</b>	Displays the IP routing table.

## ip (interface configuration)

To configure the interface Internet Protocol, use the **interface** command in interface configuration mode. To delete or disable these settings, use the **no** form of this command.

```
ip { access-group { num { in | out } } { name { in | out } } | address { ip_addr netmask | range
{ ip_addr_low ip_addr_high netmask } }
```

```
no ip { access-group { num { in | out } } { name { in | out } } | address { ip_addr netmask | range
{ ip_addr_low ip_addr_high netmask } }
```

Syntax Description		
<b>access-group</b>		Specifies access control for incoming or outgoing packets.
<i>num</i>		Specifies an IP access list by number, in standard or extended form. The range is from 1-199.
<b>in</b>		Configures the IP access list that apply to inbound packets.
<b>out</b>		Configures the IP access list that apply to outbound packets.
<i>name</i>		Name of the access list.
<b>in</b>		Configures the access list name inbound packets.
<b>out</b>		Configures the access list name outbound packets.
<b>address</b>		Set the IP address of an interface.
<i>ip-addr</i>		IP address of the interface.
<i>netmask</i>		Netmask of the interface.
<b>range</b>		Specifies the IP address range.
<i>ip_addr_low</i>		IP address low range of an interface.
<i>ip_addr_high</i>		IP address high range of an interface.
<i>netmask</i>		Netmask of the interface.

**Command Defaults** None

**Command Modes** Interface configuration (config-if) mode.

**Usage Guidelines** With Cisco Internet Streamer CDS Release 2.5.9 software, you can now configure multiple IP addresses for Gigabit Ethernet, port channel and Standby interface in the SEs. With multiple IP support, the SEs can stream the content under a specific IP while having another stream with different source IP address under the same interface.

The **ip** command configures up to 24 unique IP addresses within the same subnet for the same Gigabit Ethernet, port channel and Standby interface. You can add and delete IP addresses for each interface without affecting other configured IP addresses.



**Note**

All IP addresses configured in the same interface must be in the same subnet.

The **ip range** command adds and deletes an IP address range per interface without affecting other configured IP addresses, and it notifies the SR and CDSM on the added and deleted IP address. The IP address can only be deleted when it is already disassociated from the delivery service. If the delivery service's IP address has been updated, for example from 10.1.1.1 to 10.1.1.5, the service is not interrupted. The new stream will use the new IP address.

## Examples

### Configuring an IP Address Range

The following example shows how to configure an IP address in a range:

```
ServiceEngine(config)# interface PortChannel 1
ServiceEngine(config-if)# ip address 2.2.2.2 255.255.255.0
ServiceEngine(config-if)# ip address range 2.2.2.3 2.2.2.10 255.255.255.0
ServiceEngine(config-if)# ip address range 2.2.2.12 2.2.2.20 255.255.255.0
```

If the user configures an IP address range but one or more of the IP addresses in the range matched with an already configured IP address, the configuration is still accepted. For example, if interface PortChannel 1 has the following configuration:

```
interface PortChannel 1
ip address 2.2.2.2 255.255.255.0
ip address 2.2.2.3 255.255.255.0
ip address 2.2.2.5 255.255.255.0
ip address 2.2.2.12 255.255.255.0
```

The following configuration is accepted and the IP address in the range (not the same subnet) is rejected:

```
ServiceEngine# configure terminal
ServiceEngine(config)# interface PortChannel 1
ServiceEngine(config-if)# ip address range 2.2.2.3 2.2.2.4 255.255.255.0
ServiceEngine(config-if)# end
```

If the interface PortChannel 1 has the following configuration:

```
interface PortChannel 1
ip address 2.2.2.2 255.255.255.0
ip address 2.2.2.5 255.255.255.0
ip address 2.2.2.12 255.255.255.0
```

And you enter the following commands:

```
ServiceEngine# configure terminal
ServiceEngine(config)# interface PortChannel 1
ServiceEngine(config-if)# ip address range 2.2.3.9 2.2.3.15 255.255.255.0
ServiceEngine(config-if)# end
```

It is an invalid IP address range and an incompatible netmask.

### Configuring an IP Address

The following example shows how to configure an individual IP address:

```
ServiceEngine(config)# interface PortChannel 1
ServiceEngine(config-if)# ip address 2.2.2.2 255.255.255.0
ServiceEngine(config-if)# ip address 2.2.2.3 255.255.255.0
ServiceEngine(config-if)# ip address 2.2.2.10 255.255.255.0
```

### Removing an IP Address

The following example shows how to remove an IP address range configuration:

```
ServiceEngine(config)# interface PortChannel 1
```

```
ServiceEngine(config-if)# no ip address range 2.2.2.3 2.2.2.10 255.255.255.0
```

The following example shows how to remove an IP address configuration:

```
ServiceEngine(config)# interface PortChannel 1
ServiceEngine(config-if)# no ip address 2.2.2.3 255.255.255.
```

#### Related Commands

Command	Description
<b>interface</b>	Configures a Gigabit Ethernet or port channel interface.
<b>show interface</b>	Displays the hardware interface information.
<b>show running-config</b>	Displays the current operating configuration.

## ip access-list

To create and modify access lists for controlling access to interfaces or applications, use the **ip access-list standard** or **ip access-list extended** command in Global configuration modes. To remove access control lists, use the **no** form of this command.

```
ip access-list {extended {acl-name | acl-num {delete num | deny {num {ip address | any | host} |
gre {ip address | any | host} | icmp {ip address | any | host} | ip {ip address | any | host} | tcp
{ip address | any | host} | udp {ip address | any | host} } | insert {num {deny | permit} | list
{start-line-num | end-line-num} | move {old-line-num | new-line-num} | permit {num {ip
address | any | host} | gre {ip address | any | host} | icmp {ip address | any | host} | ip {ip
address | any | host} | tcp {ip address | any | host} | udp {ip address | any | host} } } | {
standard {acl-num | acl-name {delete num | deny {num {ip address | any | host} | gre {ip
address | any | host} | icmp {ip address | any | host} | ip {ip address | any | host} | tcp {ip
address | any | host} | udp {ip address | any | host} } | insert {num {deny | permit} | list {
start-line-num | end-line-num} | move {old-line-num | new-line-num} | permit {ip address |
any | host} } } }
```

```
no ip access-list {extended {acl-name | acl-num {delete num | deny {num {ip address | any | host} |
} | gre {ip address | any | host} | icmp {ip address | any | host} | ip {ip address | any | host} |
tcp {ip address | any | host} | udp {ip address | any | host} } | insert {num {deny | permit} |
list {start-line-num | end-line-num} | move {old-line-num | new-line-num} | permit {num {ip
address | any | host} | gre {ip address | any | host} | icmp {ip address | any | host} | ip {ip
address | any | host} | tcp {ip address | any | host} | udp {ip address | any | host} } } | {
standard {acl-num | acl-name {delete num | deny {num {ip address | any | host} | gre {ip
address | any | host} | icmp {ip address | any | host} | ip {ip address | any | host} | tcp {ip
address | any | host} | udp {ip address | any | host} } | insert {num {deny | permit} | list {
start-line-num | end-line-num} | move {old-line-num | new-line-num} | permit {ip address |
any | host} } } }
```

### Syntax Description

<b>standard</b>	Enables the standard ACL configuration mode.
<i>acl-num</i>	Access list to which all commands entered from access list configuration mode apply, using a numeric identifier. For standard access lists, the valid range is 1 to 99; for extended access lists, the valid range is 100 to 199.
<i>acl-name</i>	Access list to which all commands entered from ACL configuration mode apply, using an alphanumeric string of up to 30 characters, beginning with a letter.
<b>delete</b>	(Optional) Deletes the specified entry.
<i>num</i>	(Optional) Position of condition to delete. The range is from 1 to 500.
<b>deny</b>	(Optional) Causes packets that match the specified conditions to be dropped.
<i>num</i>	IP Protocol Number.
<i>ip address</i>	Source IP address.
<i>any</i>	Any source host.
<i>host</i>	A single host address.
<b>gre</b>	Specifies GRE Tunneling by Cisco.
<b>icmp</b>	Specifies Internet Control Message Protocol.
<b>ip</b>	Specifies Any IP Protocol.



<b>tcp</b>	Specifies Transport Control Protocol.
<b>udp</b>	Specifies User Datagram Protocol.
<b>insert</b>	(Optional) Inserts the conditions following the specified line number into the access list.
<i>num</i>	Identifies the position at which to insert a new condition.
<b>deny</b>	Specifies packets to deny.
<b>permit</b>	Specifies packets to permit.
<b>list</b>	(Optional) Lists the specified entries (or all entries when none are specified).
<i>start-line-num</i>	(Optional) Line number from which the list begins.
<i>end-line-num</i>	(Optional) Last line number in the list.
<b>move</b>	(Optional) Moves the specified entry in the access list to a new position in the list.
<i>old-line-num</i>	Line number of the entry to move.
<i>new-line-num</i>	New position of the entry. The existing entry is moved to the following position in the access list.
<b>permit</b>	(Optional) Causes packets that match the specified conditions to be accepted for further processing.
<b>extended</b>	Enables the extended ACL configuration mode.

**Command Defaults**

An access list drops all packets unless you configure at least one **permit** entry.

**Command Modes**

Global configuration (config) mode.

**Usage Guidelines****Standard ACL Configuration Mode Commands**

To work with a standard access list, enter the **ip access-list standard** command from the Global configuration mode prompt. The CLI enters a configuration mode in which all subsequent commands apply to the current access list.

To add a line to the standard IP ACL, enter the following command. For example, choose a purpose (permit or deny) that specifies whether a packet is to be passed or dropped, enter the source IP address, and enter the source IP wildcard address as follows:

```
[insert line-num] {deny | permit} {source-ip [wildcard] | host source-ip | any}
```

To delete a line from the standard IP ACL, enter the following command:

```
delete line-num
```

To display a list of specified entries within the standard IP ACL, enter the following command:

```
list [start-line-num [end-line-num] ]
```

To move a line to a new position within the standard IP ACL, enter the following command:

```
move old-line-num new-line-num
```

To return to the CLI Global configuration mode prompt, enter the following command:

**exit**

To negate a standard IP ACL, enter the following command:

**no {deny | permit} {source-ip [wildcard] | host source-ip | any}**

### Extended ACL Configuration Mode Commands

To work with an extended access list, enter the **ip access-list extended** command from the Global configuration mode prompt. The CLI enters a configuration mode in which all subsequent commands apply to the current access list.

To delete a line from the extended IP ACL, enter the following command:

**delete line-num**

To move a line to a new position within the extended IP ACL, enter the following command:

**move old-line-num new-line-num**

To display a list of specified entries within the standard IP ACL, enter the following command:

**list [start-line-num [end-line-num] ]**

To return to the CLI Global configuration mode prompt, enter the following command:

**exit**

To add a condition to the extended IP ACL, note that the options depend on the chosen protocol.

For IP, enter the following command to add a condition:

```
[insert line-num] {deny | permit} { gre | ip | proto-num } {source-ip [wildcard] | host source-ip
| any } {dest-ip [wildcard] | host dest-ip | any}

no {deny | permit} {gre | ip | proto-num} {source-ip [wildcard] | host source-ip | any} {dest-ip
[wildcard] | host dest-ip | any}
```

where if you enter *proto-num* is 47 or 0, they represent the equivalent value for GRE or IP.

For TCP, enter the following command to add a condition:

```
[insert line-num] {deny | permit } {tcp | proto-num } {source-ip [wildcard] | host source-ip |
any } [operator port [port] ] { dest-ip [wildcard] | host dest-ip | any } [operator port [port] ]
[established]

no { deny | permit } {tcp | proto-num } { source-ip [wildcard] | host source-ip | any } [operator
port [port] ] { dest-ip [wildcard] | host dest-ip | any } [operator port [port] ] [established]
```

where *proto-num* can be 6, which is the equivalent value for TCP.

For UDP, enter the following command to add a condition:

```
[insert line-num] {deny | permit } {udp | proto-num } {source-ip [wildcard] | host source-ip |
any } [operator port [port] ] {dest-ip [wildcard] | host dest-ip | any } [operator port [port] ]
```

```
no { deny | permit } { udp | proto-num } { source-ip [wildcard] | host source-ip | any } [operator
port [port] ] { dest-ip [wildcard] | host dest-ip | any } [operator port [port] ]
```

where *proto-num* can be 17, which is the equivalent value for UDP.

For ICMP, enter the following command to add a condition:

```
[insert line-num] { deny | permit } { icmp | proto-num } { source-ip [wildcard] | host source-ip
| any } { dest-ip [wildcard] | host dest-ip | any } [icmp-type [code] | icmp-msg]
```

```
no { deny | permit } { icmp | proto-num } { source-ip [wildcard] | host source-ip | any } { dest-ip
[wildcard] | host dest-ip | any } [icmp-type [code] | icmp-msg]
```

where *proto-num* can be 2, which is the equivalent value for ICMP.

For extended IP ACLs, the **wildcard** keyword is required if the **host** keyword is not specified. For a list of the keywords that you can use to match specific ICMP message types and codes, see [Table 2-15](#). For a list of supported UDP and TCP keywords, see [Table 2-13](#) and [Table 2-14](#).

Use access lists to control access to specific applications or interfaces on an SE. An ACL consists of one or more condition entries that specify the kind of packets that the SE drops or accepts for further processing. The SE applies each entry in the order in which it occurs in the access list, which by default, is the order in which you configured the entry.

The following are some examples of how IP ACLs can be used in environments that have SEs:

- SE resides on the customer premises and is managed by a service provider, and the service provider wants to secure the device for its management only.
- SE is deployed anywhere within the enterprise. As with routers and switches, the administrator wants to limit Telnet and SSH access to the IT source subnets.
- Application layer proxy firewall with a hardened outside interface has no ports exposed. (*Hardened* means that the interface carefully restricts which ports are available for access, primarily for security reasons. With an outside interface, many types of security attacks are possible.) The SE's outside address is Internet global, and its inside address is private. The inside interface has an IP ACL to limit Telnet and SSH access to the SE.
- SE is deployed as a reverse proxy in an untrusted environment. The SE administrator wants to allow only port 80 inbound traffic on the outside interface and outbound connections on the back-end interface.

Within ACL configuration mode, you can use the editing commands (**list**, **delete**, and **move**) to display the current condition entries, to delete a specific entry, or to change the order in which the entries are evaluated. To return to Global configuration mode, enter **exit** at the ACL configuration mode prompt.

To create an entry, use a **deny** or **permit** keyword and specify the type of packets that you want the SE to drop or to accept for further processing. By default, an access list denies everything because the list is terminated by an implicit **deny any** entry. You must include at least one **permit** entry to create a valid access list.

After creating an access list, you can include the access list in an access group using the **access-group** command, which determines how the access list is applied. You can also apply the access list to a specific application using the appropriate command. A reference to an access list that does not exist is the equivalent of a **permit any** condition statement.

To work with access lists, enter either the **ip access-list standard** or **ip access-list extended** Global configuration command. Identify the new or existing access list with a name up to 30 characters long beginning with a letter or with a number. If you use a number to identify a standard access list, it must be between 1 and 99; for an extended access list, use a number from 100 to 199. Use a standard access list for providing access to the SNMP server or to the TFTP gateway or server.

After you identify the access list, the CLI enters the appropriate configuration mode and all subsequent commands apply to the specified access list.

#### ip access-list standard Command

You typically use a standard access list to allow connections from a host with a specific IP address or from hosts on a specific network. To allow connections from a specific host, use the **permit host** *source-ip* option and replace *source-ip* with the IP address of the specific host.

To allow connections from a specific network, use the **permit source-ip wildcard** option. Replace *source-ip* with a network ID or the IP address of any host on the network that you want to specify. Replace *wildcard* with the dotted decimal notation for a mask that is the reverse of a subnet mask, where a 0 indicates a position that must be matched and a 1 indicates a position that does not matter. For instance, the wildcard 0.0.0.255 causes the last eight bits in the source IP address to be ignored. Therefore, the **permit 192.168.1.0 0.0.0.255** entry allows access from any host on the 192.168.1.0 network.

#### ip access-list extended Command

Use an extended access list to control connections based on the destination IP address or based on the protocol type. You can combine these conditions with information about the source IP address to create more restrictive conditions. [Table 2-13](#) lists the UDP keywords that you can use with extended access lists.

**Table 2-13 UDP Keywords and Port Numbers**

CLI Keyword	Description	UDP Port Number
<b>bootpc</b>	BOOTP <sup>1</sup> client service	68
<b>bootps</b>	BOOTP server service	67
<b>domain</b>	DNS <sup>2</sup> service	53
<b>netbios-dgm</b>	NetBIOS datagram service	138
<b>netbios-ns</b>	NetBIOS name resolution service	137
<b>netbios-ss</b>	NetBIOS session service	139
<b>nfs</b>	Network File System service	2049
<b>ntp</b>	Network Time Protocol settings	123
<b>snmp</b>	Simple Network Management Protocol service	161
<b>snmptrap</b>	SNMP traps	162
<b>tftp</b>	Trivial File Transfer Protocol service	69

1. BOOTP = bootstrap protocol

2. DNS = Domain Name System

[Table 2-14](#) lists the TCP keywords that you can use with extended access lists.

**Table 2-14 TCP Keywords and Port Numbers**

CLI Keyword	Description	TCP Port Number
<b>domain</b>	Domain Name System	53
<b>exec</b>	Remote process execution	512
<b>ftp</b>	File Transfer Protocol service	21

**Table 2-14 TCP Keywords and Port Numbers (continued)**

CLI Keyword	Description	TCP Port Number
<b>ftp-data</b>	FTP data connections (used infrequently)	20
<b>nfs</b>	Network File System service applications	2049
<b>rtsp</b>	Real-Time Streaming Protocol applications	554
<b>ssh</b>	Secure Shell login	22
<b>telnet</b>	Remote login using telnet	23
<b>www</b>	World Wide Web (HTTP) service	80

Table 2-15 lists the keywords that you can use to match specific ICMP message types and codes.

**Table 2-15 Keywords for ICMP Message Type and Code**

Field	Description
administratively-prohibited	Messages that are administratively prohibited from being allowed access.
alternate-address	Messages that specify alternate IP addresses.
conversion-error	Messages that denote a datagram conversion error.
dod-host-prohibited	Messages that signify a DoD <sup>1</sup> protocol Internet host denial.
dod-net-prohibited	Messages that specify a DoD protocol network denial.
echo	Messages that are used to send echo packets to test basic network connectivity.
echo-reply	Messages that are used to send echo reply packets.
general-parameter-problem	Messages that report general parameter problems.
host-isolated	Messages that indicate that the host is isolated.
host-precedence-unreachable	Messages that have been received with the protocol field of the IP header set to one (ICMP) and the type field in the ICMP header set to three (Host Unreachable). This is the most common response. Large numbers of this datagram type on the network are indicative of network difficulties or hostile actions.
host-redirect	Messages that specify redirection to a host.
host-tos-redirect	Messages that specify redirection to a host for type of service-based (ToS) routing.
host-tos-unreachable	Messages that denote that the host is unreachable for ToS-based routing.
host-unknown	Messages that specify that the host or source is unknown.
host-unreachable	Messages that specify that the host is unreachable.
information-reply	Messages that contain domain name replies.
information-request	Messages that contain domain name requests.
mask-reply	Messages that contain subnet mask replies.
mask-request	Messages that contain subnet mask requests.
mobile-redirect	Messages that specify redirection to a mobile host.

**Table 2-15**      **Keywords for ICMP Message Type and Code (continued)**

Field	Description
net-redirect	Messages that are used for redirection to a different network.
net-tos-redirect	Messages that are used for redirection to a different network for ToS-based routing.
net-tos-unreachable	Messages that specify that the network is unreachable for the ToS-based routing.
net-unreachable	Messages that specify that the network is unreachable.
network-unknown	Messages that denote that the network is unknown.
no-room-for-option	Messages that specify the requirement of a parameter, but that no room is unavailable for it.
option-missing	Messages that specify the requirement of a parameter, but that parameter is not available.
packet-too-big	Messages that specify that the ICMP packet requires fragmentation but the DF <sup>2</sup> bit is set.
parameter-problem	Messages that signify parameter-related problems.
port-unreachable	Messages that specify that the port is unreachable.
precedence-unreachable	Messages that specify that host precedence is not available.
protocol-unreachable	Messages that specify that the protocol is unreachable.
reassembly-timeout	Messages that specify a timeout during reassembling of packets.
redirect	Messages that have been received with the protocol field of the IP header set to one (ICMP) and the type field in the ICMP header set to five (Redirect). ICMP redirect messages are used by routers to notify the hosts on the data link that a better route is available for a particular destination.
router-advertisement	Messages that contain ICMP router discovery messages called <i>router advertisements</i> .
router-solicitation	Messages that are multicast to ask for immediate updates on neighboring router interface states.
source-quench	Messages that have been received with the protocol field of the IP header set to one (ICMP) and the type field in the ICMP header set to four (Source Quench). This datagram may be used in network management to provide congestion control. A source quench packet is issued when a router is beginning to lose packets because of the transmission rate of a source. The source quench is a request to the source to reduce the rate of a datagram transmission.
source-route-failed	Messages that specify the failure of a source route.
time-exceeded	Messages that specify information about all instances when specified times were exceeded.
timestamp-reply	Messages that contain time stamp replies.
timestamp-request	Messages that contain time stamp requests.
traceroute	Messages that specify the entire route to a network host from the source.

**Table 2-15**      **Keywords for ICMP Message Type and Code (continued)**

Field	Description
ttl-exceeded	Messages that specify that ICMP packets have exceeded the Time-To-Live configuration.
unreachable	Messages that are sent when packets are denied by an access list; these packets are not dropped in the hardware but generate the ICMP-unreachable message.

1. DoD = department of defense
2. DF = do not fragment

## Examples

The following example shows how to create an access list to allow all web traffic and to allow only a specific host administrative access using Secure Shell (SSH):

```
ServiceEngine(config)# ip access-list extended example
ServiceEngine(config-ext-nacl)# permit tcp any any eq www
ServiceEngine(config-ext-nacl)# permit tcp host 10.1.1.5 any eq ssh
ServiceEngine(config-ext-nacl)# exit
```

The following example shows how to activate the access list for an interface:

```
ServiceEngine(config)# interface gigabitethernet 1/0
ServiceEngine(config-if)# exit
```

The following example shows how this configuration appears when you enter the **show running-configuration** command:

```
...
!
ip access-list extended example
 permit tcp any any eq www
 permit tcp host 10.1.1.5 any eq ssh
 exit
. . .
```

## Related Commands

Command	Description
<b>clear ip access-list counters</b>	Clears the IP access list statistical information.
<b>show ip access-list</b>	Displays the access lists that are defined and applied to specific interfaces or applications.

# ip ospf priority

To set the router priority, which helps determine the designated router for this network; use the `ip ospf priority` command in interface configuration mode. To return to the default value, use the **no** form of this command.

**ip ospf priority** *number-value*

**no ip ospf priority** *number-value*

<b>Syntax Description</b>	<i>number-value</i> A number value that specifies the priority of the router (the range is 0 to 255).	
<b>Command Defaults</b>	Priority of 1	
<b>Command Modes</b>	Interface configuration (config-if) mode.	
<b>Usage Guidelines</b>	When two routers attached to a network both attempt to become the designated router, the one with the higher router priority takes precedence. If there is a tie, the router with the higher router ID takes precedence. A router with a router priority set to zero is ineligible to become the designated router or backup designated router. Router priority is configured only for interfaces to multi-access networks (that is, not to point-to-point networks).	
<b>Examples</b>	<p>The following example shows how to set the router priority value to 4:</p> <pre>ServiceRouter(config)# <b>router ospf</b> ServiceRouter(config-ospf)# <b>interface GigabitEthernet 2/0</b> ServiceRouter(config-ospf-if)# <b>ip ospf priority 4</b> ServiceRouter(config-ospf-if)</pre>	
<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>router ospf</b>	Enables the Open Shortest Path First (OSPF) routing process.



# ip router isis

To specify the interfaces to be used for routing IS-IS, use the **ip router isis** command in interface sub-configuration mode under IS-IS configuration mode. To detach the IS-IS process from an interface, use the **no** form of the command.

**ip router isis**

**no ip router isis**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Defaults</b>	None
-------------------------	------

<b>Command Modes</b>	Interface configuration mode under IS-IS (config-isis-if) configuration mode.
----------------------	---

<b>Usage Guidelines</b>	This command is used to specify the interfaces to actively route IS-IS. Before an IS-IS routing process can be attached to an interface, you must assign a network entity title (NET) using the <b>net</b> command and enter the interface sub-configuration mode.
-------------------------	--

<b>Examples</b>	The following example shows how to configure an IS-IS process to be attached and form adjacency on Ethernet interface 1:
-----------------	--

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# net 49.0001.aaaa.aaaa.aaaa.00
ServiceRouter(config-isis)# interface GigabitEthernet 1/0
ServiceRouter(config-isis-if)# ip router isis
ServiceRouter(config-isis-if)#
```

Related Commands	Command	Description
	<b>router isis</b>	Enables the IS-IS routing protocol and specifies an IS-IS process.

# ipv6

To specify the default gateway's IPv6 address, use the **ipv6** command in Global configuration mode. To disable the IPv6 address, use the **no** form of this command.

**ipv6 default-gateway** *ip-address*

**no ipv6 default-gateway** *ip-address*

Syntax Description	default-gateway	Specifies the default gateway's IPv6 address.
	<i>ip-address</i>	IPv6 address of the default gateway.

Command Defaults	None
------------------	------

Command Modes	Global configuration (config) mode.
---------------	-------------------------------------

**Examples** The following example shows how to configure an IPv6-related address:

```
ServiceRouter(config)# ipv6 default-gateway fec0::100/64
```

Related Commands	Command	Description
	<b>traceroute6</b>	Traces the route to a remote IPv6-enabled host.

# isis

To configure IS-IS routing for IP, use the **isis** command in interface configuration mode under route IS-IS configuration mode. To turn off this function, use the **no** form of this command.

```
isis { authentication key-chain name { level-1 | level-2 } | authentication-check { level-1 | level-2 }
      | authentication-type { cleartext | md5 } | circuit-type [ level-1 | level-1-2 | level-2 ] | priority
      priority_value { level-1 | level-2 } }
```

```
no isis { authentication key-chain name { level-1 | level-2 } | authentication-check { level-1 |
        level-2 } | authentication-type { cleartext | md5 } | circuit-type [ level-1 | level-1-2 | level-2 ] |
        priority priority_value { level-1 | level-2 } }
```

## Syntax Description

<b>authentication</b>	Sets hello authentication key chain.
<b>key-chain</b>	Sets hello authentication key chain.
<i>name</i>	Authentication key chain name.
<b>level-1</b>	Specifies authentication key chain for level-1 IIHs.
<b>level-2</b>	Specifies authentication key chain for level-2 IIHs.
<b>authentication-check</b>	Checks authentication.
<b>authentication-type</b>	Sets hello authentication type.
<b>cleartext</b>	Specifies cleartext.
<b>md5</b>	Specifies HMAC-MD5.
<b>circuit-type</b>	Configures circuit type for interface.
<b>level-1</b>	(Optional) Configures a router for Level 1 adjacency only.
<b>level-1-2</b>	(Optional) Configures a router for Level 1 and Level 2 adjacency.
<b>level-2</b>	(Optional) Configures a router for Level 2 adjacency only.
<b>priority</b>	Sets the priority for DIS election.
<i>priority_value</i>	Priority setting for interfaces (0 to 127).

## Command Defaults

A Level 1 and Level 2 adjacency is established.

Priority is set to 64 for interfaces.

Authentication-check is on.

## Command Modes

Interface configuration mode under IS-IS (config-isis-if) configuration.

## Usage Guidelines

Use the **isis authentication key-chain** command to specify the key chain to be used for the interface and the corresponding level. The key chain range cannot exceed 63 characters.

Use the **isis authentication-check** command to enable or disable the checking of received packets for the interface on the corresponding level. When authentication-check is disabled, IS-IS adds authentication to the outgoing packets, but it does not check authentication on incoming packets. This feature allows smooth transition of enabling authentication without disrupting the network operation.

Use the **isis authentication-type** command to specify the md5 or cleartext authentication type for the interface and the corresponding level.

Use the **isis circuit-type** command to specify adjacency levels on a specified interface.

Use the **isis priority** configuration command to configure the priority of a specific interface.



#### Note

In Cisco Internet Streamer CDS Release 2.5.7 software and later, it is not possible to configure IS-IS and OSPF simultaneously. If you are running OSPF and try to enter the **router isis** command, you receive the following warning message:

```
%Cannot configure both IS-IS and OSPF together. Please remove 'router ospf' first. (Error number: 1137)
```

If you want to configure IS-IS and you already have OSPF running, you must enter the **no router ospf** command first before entering the **router isis** command.

#### Examples

The following example shows how to specify the key chain to be used for 'GigabitEthernet 3/0', level-1 for the IS-IS process running on that interface:

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# interface GigabitEthernet 3/0
ServiceRouter(config-isis-if)# isis authentication key-chain my-key level-1
ServiceRouter(config-isis-if)#
```

The following example shows how to configure the authentication check of interface 'GigabitEthernet 3/0', level-1 for the IS-IS process running on that interface:

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# interface GigabitEthernet 3/0
ServiceRouter(config-isis-if)# isis authentication-check level-1
ServiceRouter(config-isis-if)SVCREG internal error
  if    SVCREG interface debugs
  ipcc  SVCREG ipcc (inter process comm) debugs
  svc   SVCREG svc debugs
  ven   SVCREG ven debugs
)#
```

The following example shows how to configure the authentication type of interface 'GigabitEthernet 3/0' to be md5 level-1 for the IS-IS process running on that interface:

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# interface GigabitEthernet 3/0
ServiceRouter(config-isis-if)# isis authentication-type md5 level-1
ServiceRouter(config-isis-if)#
```

The following example shows how to configure the circuit type of interface 'GigabitEthernet 3/0' to be level-1-2 for the IS-IS process running on that interface:

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# interface GigabitEthernet 3/0
ServiceRouter(config-isis-if)# isis circuit-type level-1-2
ServiceRouter(config-isis-if)# end
```

```
ServiceRouter#
```

The following example shows how to set the priority of interface 'GigabitEthernet 3/0' to 100 for the IS-IS process running on that interface:

```
ServiceRouter(config)# router isis  
ServiceRouter(config-isis)# interface GigabitEthernet 3/0  
ServiceRouter(config-isis-if)# isis priority 100  
ServiceRouter(config-isis-if)# end  
ServiceRouter#
```

**Related Commands**

Command	Description
<b>router isis</b>	Enables the IS-IS routing protocol and specifies the IS-IS process.

# is-type

To configure a Proximity Engine to act as a Level 1 (intra-area) router, as both a Level 1 router and a Level 2 (interarea) router, or as an inter-area router only, use the **is-type** IS-IS configuration command. To reset the default value, use the **no** form of this command.

**is-type** [level-1 | level-1-2 | level-2]

**no is-type** [level-1 | level-1-2 | level-2]

## Syntax Description

<b>level-1</b>	(Optional) Router performs only Level 1 (intra-area) routing. This router learns only about destinations inside its area. Level 2 (inter-area) routing is performed by the closest Level 1-2 router.
<b>level-1-2</b>	(Optional) Router performs both Level 1 and Level 2 routing. This router runs two instances of the routing process. It has one link-state packet database (LSDB) for destinations inside the area (Level 1 routing) and runs a shortest path first (SPF) calculation to discover the area topology. It also has another LSDB with link state packets (LSPs) of all other backbone (Level 2) routers, and runs another SPF calculation to discover the topology of the backbone, and the existence of all other areas.
<b>level-2</b>	(Optional) Routing process acts as a Level 2 (inter-area) router only. This router is part of the backbone, and does not communicate with Level 1-only routers in its own area.

## Command Defaults

The IS-IS routing process configured is a Level 1-2 (intra-area and inter-area) router.

## Command Modes

IS-IS configuration (config-isis) mode.

## Usage Guidelines

By default, the first instance of the IS-IS routing process that you configure using the **router isis** command is a Level 1-2 router.

If the network has only one area, there is no need to run both Level 1 and Level 2 routing algorithms. If IS-IS is used for Connectionless Network Service (CLNS) routing (and there is only one area), Level 1 only must be used everywhere. If IS-IS is used for IP routing only (and there is only one area), you can run Level 2 only everywhere. Areas you add after the Level 1-2 area exists are, by default, Level 1 areas.

If the router instance has been configured for Level 1-2 (the default for the first instance of the IS-IS routing process in a Cisco device), you can remove Level 2 (inter-area) routing for the area by using the **is-type** command. You can also use the **is-type** command to configure Level 2 routing for an area, but it must be the only instance of the IS-IS routing process configured for Level 2 on the Cisco device.

## Examples

The following example shows how to specify an area router:

```
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# is-type level-2
ServiceRouter(config-isis)#
```

**Related Commands**

Command	Description
<b>router isis</b>	Enables the IS-IS routing protocol and specifies the IS-IS process.

# kernel kdb

To enable access to the kernel debugger (KDB), use the **kernel kdb** command in Global configuration mode. To disable the kernel debugger, use the **no** form of this command.

**kernel kdb**

**no kernel kdb**

---

**Syntax Description** This command has no arguments or keywords.

---

**Command Defaults** Kdb is disabled by default.

---

**Command Modes** Global configuration (config) mode.

---

**Usage Guidelines** Once enabled, KDB is automatically activated when kernel problems occur. Once activated, all normal functioning of the CDS device is suspended until KDB is manually deactivated. The KDB prompt looks like this prompt:

```
[ 0 ] kdb>
```

To deactivate KDB, enter **go** at the KDB prompt. If KDB was automatically activated because of kernel problems, you must reboot to recover from the issue. If you activated KDB manually for diagnostic purposes, the system resumes normal functioning in whatever state it was when you activated KDB. In either case, if you enter **reboot**, the system restarts and normal operation resumes.

With the Internet Streamer CDS software earlier than Release 2.4, KDB is enabled by default and cannot be disabled. In the Release 2.0.3 and later releases, KDB is disabled by default and you must enter the **kernel kdb** command in Global configuration mode to enable it. If KDB has been previously enabled, you can enter the **no kernel kdb** Global configuration command to disable it.

When KDB is enabled, you can activate it manually from the local console. With Cisco Internet Streamer CDS Release 2.4 and later, you can activate it by pressing **Esc-KDB** (press Escape and then press KDB in capitalization).

---

**Examples** The following example shows how to enable KDB:

```
ServiceEngine(config)# kernel kdb
```

The following example shows how to disable KDB:

```
ServiceEngine(config)# no kernel kdb
```



# key

To create a key ID and enter into key configuration submode, use the **key** command in Global configuration mode. To exit key chain configuration submode, use the **no** form of this command.

**key** *keyid*

**no key** *keyid*

<b>Syntax Description</b>	<i>keyid</i> Key identifier. The range is from 0 to 65535.								
<b>Command Defaults</b>	None								
<b>Command Modes</b>	Global configuration (config) mode.								
<b>Usage Guidelines</b>	<p>Multiple key ID's may be configured under the same key chain. The key chain string cannot exceed 63 characters.</p> <p>When IS-IS is configured to use a particular key chain for the authentication and the corresponding key chain is not configured in the system, it causes IS-IS to always reject incoming packets that require the key chain.</p> <p>When a key chain has multiple keys, IS-IS should advertise the first key in the chain. For validation of received packets, it should iterate through all the keys until there is a match.</p> <p>The <b>key</b> command is within the <b>key chain</b> command context, not simply the key chain itself.</p>								
<b>Examples</b>	<p>The following example shows how to create a key ID and enter the key configuration submode:</p> <pre>ServiceRouter(config)# <b>key chain my-key</b> ServiceRouter(config-keychain)#</pre>								
<b>Related Commands</b>	<table> <tr> <th>Command</th><th>Description</th></tr> <tr> <td><b>key chain</b></td><td>Creates a key chain and enter into key chain configuration submode.</td></tr> <tr> <td><b>key-string</b></td><td>Creates a key string to be used for authentication.</td></tr> <tr> <td><b>show key chain</b></td><td>Displays the key chains in the system.</td></tr> </table>	Command	Description	<b>key chain</b>	Creates a key chain and enter into key chain configuration submode.	<b>key-string</b>	Creates a key string to be used for authentication.	<b>show key chain</b>	Displays the key chains in the system.
Command	Description								
<b>key chain</b>	Creates a key chain and enter into key chain configuration submode.								
<b>key-string</b>	Creates a key string to be used for authentication.								
<b>show key chain</b>	Displays the key chains in the system.								

# key-string

To create a key string to be used for authentication, use the **key chain** command in Key ID configuration submode. To remove the key-string, use the **no** form of this command.

**key-string** *keyid*

**no key-string** *keyid*

## Syntax Description

<i>keyid</i>	The unencrypted (cleartext) user password.
--------------	--

## Command Defaults

None

## Command Modes

Key ID configuration submode.

## Usage Guidelines

The **key-string** command creates a key string to be used for authentication.

A key string is always valid upon creation.

The Proximity Engine does not support key-string expiration.

You can only create one key-string per key ID.

Key-chain string cannot exceed 63 characters.

## Examples

The following example shows how to specify terminal line settings:

```
ServiceRouter(config-keychain-key) # key-string topos123
ServiceRouter(config-keychain-key) #
```

## Related Commands

Command	Description
<b>key</b>	Creates a key ID and enters into key configuration submode.
<b>key chain</b>	Creates a key chain and enter into key chain configuration submode.
<b>show key chain</b>	Displays the key chains in the system.

# key chain

To create a key chain and enter into key chain configuration submode, use the **key chain** command in Global configuration mode. To exit key chain configuration submode, use the **no** form of this command.

**key chain** *name*

**no key chain** *name*

## Syntax Description

<i>name</i>	Name of the key chain.
-------------	------------------------

## Command Defaults

None

## Command Modes

Global configuration (config) mode.

## Usage Guidelines

Multiple key ID's may be configured under the same key chain. Key chain string cannot exceed 63 characters.

When IS-IS is configured to use a particular key chain for the authentication and the corresponding key chain is not configured in the system, it results IS-IS to always reject incoming packets that requires the key chain.

When a key chain has multiple keys, IS-IS should advertise the first key in the chain. For validation of received packets, it should iterate through all the keys until there is a match.

## Examples

The following example shows how to create a key and enter into key ID configuration submode:

```
ServiceRouter(config)# key chain my-key
ServiceRouter(config-keychain)#
```

The following example shows a complete sample configuration for IS-IS MD5 authentication:

```
ServiceRouter(config)# key chain lsp-key
ServiceRouter(config-keychain)# key 1
ServiceRouter(config-keychain-key)# key-string lsp
ServiceRouter(config-keychain-key)# exit
ServiceRouter(config-keychain)# exit
ServiceRouter(config)# key chain int-key
ServiceRouter(config-keychain)# key 1
ServiceRouter(config-keychain-key)# key-string topos123
ServiceRouter(config-keychain-key)# exit
ServiceRouter(config-keychain)# exit
ServiceRouter(config)# router isis
ServiceRouter(config-isis)# net 10.1111.1111.1111.00
ServiceRouter(config-isis)# is-type level-1
ServiceRouter(config-isis)# authentication-type md5 level-1
ServiceRouter(config-isis)# authentication key-chain lsp-key level-1
ServiceRouter(config-isis)# interface giagabitethernet 1/0
ServiceRouter(config-isis-if)# isis authentication-type md5 level-1
ServiceRouter(config-isis-if)# isis authentication key-chain int-key level-1
```

Related Commands	Command	Description
	<b>key</b>	Creates a key chain and enters into key chain configuration submode.
	<b>key-string</b>	Creates a key string to be used for authentication.
	<b>show key chain</b>	Displays the key chains in the system.

# line

To specify terminal line settings, use the **line** command in Global configuration mode. To disable terminal line settings, use the **no** form of this command.

**line console carrier-detect**

**no line console carrier-detect**

<b>Syntax Description</b>	<b>console</b>	Configures the console terminal line settings.
	<b>carrier-detect</b>	Sets the device to check the carrier detect signal before writing to the console.

<b>Command Defaults</b>	This feature is disabled by default.
-------------------------	--------------------------------------

<b>Command Modes</b>	Global configuration (config) mode.
----------------------	-------------------------------------

<b>Usage Guidelines</b>	You should enable carrier detection if you connect the SE, SR, or CDSM to a modem for receiving calls. If you are using a null modem cable with no carrier detect pin, the device might appear unresponsive on the console until the carrier detect signal is asserted. To recover from a misconfiguration, you should reboot the device and set the 0x2000 bootflag to ignore the carrier detect setting.
-------------------------	--

<b>Examples</b>	The following example shows how to specify terminal line settings:
-----------------	--

```
ServiceEngine(config)# line console carrier-detect
```

line

