

# Preface

This preface describes the objectives and organization of this document and explains how to find additional information on related products and services. This preface contains the following sections:

- Objectives, page ix
- Document Revision History, page ix
- Document Organization, page x
- Related Documentation, page xi
- Conventions, page xi
- Obtaining Documentation and Submitting a Service Request, page xii

## **Objectives**

This document describes Cisco CDA Visual Quality Experience Application (VQE), Release 3.2, and explains how to set up and use the VQE software.

# **Document Revision History**

Table 1 records technical changes to this document. The table shows the document revision number for the change, the date of the change, and a brief summary of the change.

Revision	Date	Change Summary
OL-14115-05	January, 2009	Document for VQE Release 3.2
OL-14115-04	October, 2008	Document for VQE Release 3.1
OL-14115-03	August, 2008	Document for VQE Release 3.0
OL-14115-02	December, 2007	Document for VQE Release 2.1
OL-14115-01	August, 2007	Document for VQE Release 2.0

 Table 1
 Document Revision History

For information on the content and enhancements of each VQE release, see the relevant VQE release notes.

# **Document Organization**

This publication is	organized	as follows:
---------------------	-----------	-------------

Chapter	Title	Description
Chapter 1	Introduction to Cisco CDA Visual Quality Experience Application	Provides an introduction to Cisco CDA Visual Quality Experience (VQE) Application.
Chapter 2	Getting Started with the VQE Startup Configuration Utility	Explains how to use the Cisco VQE Startup Configuration Utility to perform the initial configuration tasks for the Cisco CDE110 that hosts VQE-S and the CDE110 that hosts VQE Tools.
Chapter 3	Using the VQE Channel Provisioning Tool	Describes how to use Cisco VQE Channel Provisioning Tool (VCPT).
Chapter 4	Using the VQE-S Application Monitoring Tool	Describes how to use Cisco VQE-S Application Monitoring Tool (VQE-S AMT or AMT)
Chapter 5	Troubleshooting VQE Software Components	Describes how to identify and remedy problems related to Cisco VQE Server, VQE-S Application Monitoring Tool, and VQE Channel Provisioning Tool. The chapter also explains how to stop, start, and restart the VQE-S and VQE Client Channel Configuration Delivery Server (VCDS) services.
Chapter 6	Configuring VQE Server and VQE Tools	Describes these VQE Configuration Management System software components: VQE Configuration Tool, Configuration Engine, and the VCDB Parser. The chapter also provides information on using Configuration Tool, manually editing the VCDB file, and using <b>vqe_cfgtool</b> command.
Appendix A	VQE, System, and Network Parameters	Provides descriptions of the VQE-S Configuration Database (VCDB) parameters.
Appendix B	Using Net-SNMP	Gives information about using Net-SNMP on the Cisco CDE110 that hosts VQE-S and on the CDE110 that hosts VQE Tools.
Appendix C	VQE System Messages	Provides information on the Cisco VQE system messages.
Appendix D	Manual Initial VQE System Configuration	Explains how to perform manual initial configuration on the CDE110 that hosts VQE-S and on the CDE110 that hosts VQE Tools.
Appendix E	Configuring DHCP and DNS Servers for VCDS	Provides information on configuring the Dynamic Host Configuration Protocol (DHCP) and Domain Name System (DNS) servers so that they work correctly with VCDS or another RTSP server.
Appendix F	Changing the Boot Sequence to Start from the CD/DVD Drive	Explains how to change the BIOS setting on the Cisco CDE110 server so that the server boots first from the CD/DVD Combo drive.

### **Related Documentation**

The following is a list of documents and URLs for the Cisco CDE110 and the Cisco CDA Visual Quality Experience Application, Release 3.2:

- Release Notes for Cisco CDA Visual Quality Experience Application, Release 3.2 http://www.cisco.com/en/US/docs/video/cds/cda/vqe/3\_2/release/notes/vqe\_notes3\_2.html
- Cisco CDA Visual Quality Experience Application User Guide, Release 3.2 (this document) http://www.cisco.com/en/US/docs/video/cds/cda/vqe/3\_2/user/guide/vqe\_guide3\_2.html
- Cisco Content Delivery Engine 110 Hardware Installation Guide http://www.cisco.com/en/US/docs/video/cds/cde/cde110/installation/guide/cde110\_install.html
- Regulatory Compliance and Safety Information for the Cisco Content Delivery Engine 110 http://www.cisco.com/en/US/docs/video/cds/cde/regulatory/compliance/cde110\_rcsi.pdf

The VQE Client (VQE-C) documentation is included in the VQE-C software TAR file. If you are a registered Cisco.com user, the file can be downloaded from the following location:

http://www.cisco.com/kobayashi/sw-center/content-delivery/cda.shtml

Table 2 lists the VQE Client documentation that is provided.

VQE-C Document	Description
VQE-C Release Notes	Provides release-specific information on VQE-C.
VQE-C System Integration Reference	Provides information on VQE-C components, architecture, integration, and APIs. Also includes a VQE-C quick-start guide.
VQE-C System Configuration Guide	Explains certain factors to consider when configuring and deploying VQE-C. Also provides reference information on the VQE-C configuration file parameters.
VQE-C CLI Command Reference	Provides reference information on the VQE-C command-line interface.

Table 2 VQE Client Documentation

#### **Conventions**

This guide uses the following conventions for command syntax descriptions and textual emphasis:Table 3Command Syntax and Emphasis Conventions

Convention	Description
boldface font	Commands and keywords are in <b>boldface</b> .
italic font	Arguments for which you supply values are in <i>italics</i> .
[]	Elements in square brackets are optional.
$\{x \mid y \mid z\}$	Alternative, mutually exclusive, keywords are grouped in braces and separated by vertical bars.

Convention	Description	
$[x \mid y \mid z]$	Optional alternative keywords are grouped in brackets and separated by vertical bars.	
string	A nonquoted set of characters. Do not use quotation marks around the string or the string will include the quotation marks.	
screen font	Terminal sessions and information the system displays are in screen font.	
boldface screen font	Information you must enter is in <b>boldface</b> screen font.	
italic screen font	Arguments for which you supply values are in <i>italic</i> screen font.	
^	The symbol ^ represents the key labeled Control—for example, the key combination ^D in a screen display means hold down the Control key while you press the D key.	
< >	Nonprinting characters, such as passwords, are in angle brackets in contexts where italics are not available.	
[]	Default responses to system prompts are in square brackets.	
!, #	An exclamation point (!) or a pound sign (#) at the beginning of a line of code indicates a comment line.	

#### Table 3 Command Syntax and Emphasis Conventions (continued)



Means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this publication.

Tip

Means the following information might help you solve a problem.

/!\ Caution

Means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.

# **Obtaining Documentation and Submitting a Service Request**

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.