



## Using the VQE Channel Provisioning Tool

This chapter describes how to use Cisco VQE Channel Provisioning Tool (VCPT). [Table 3-1](#) lists the tasks you perform with the VCPT. When you use VCPT for the first time, the required tasks are performed in the order shown in the table.

**Table 3-1**      **VCPT Tasks**

VCPT Task	Section Where Described
1. Log in to VCPT	<a href="#">Logging into VCPT, page 3-2</a>
2. Create a new VCPT configuration file	<a href="#">Working with VCPT Configuration Files, page 3-3</a>
3. Provision VQE channels	<a href="#">Provisioning VQE Channels, page 3-7</a>
4. Create VQE Servers (VQE-S), VQE Client Configuration Delivery Servers (VCDSs), or Remote Servers	<a href="#">Defining VQE-Ss, VCDSs, or Remote Servers, page 3-14</a>
5. Specify channel associations for the VQE-Ss, VCDSs, or Remote Servers	<a href="#">Defining Channel Associations, page 3-18</a>
6. Send the channel information file to the VQE-Ss, VCDSs, or Remote Servers	<a href="#">Working with VCPT Configuration Files, page 3-3</a>

# Logging into VCPT

Before logging into the VCPT, you need a valid UNIX username and password on the Cisco CDE hosting the VCPT. The username does not have to belong to any special group. Creation of the username is the responsibility of the Cisco CDE system administrator.

The VCPT supports two web browsers: Microsoft Internet Explorer version 6.0 or later, and Mozilla Firefox version 2.0 or later. The VCPT uses secure HTTPS. The minimum screen resolution required for VCPT is 1024 x 768 pixels.

To log in to a VCPT, follow these steps:

- 
- Step 1** Point your web browser to the Cisco CDE that hosts the VCPT using an IP address or fully qualified domain name:

`https://ip_address`

or

`https://fully_qualified_domain_name`

The VQE login dialog box is displayed.

- Step 2** Enter a UNIX username and password.


- Step 3** Click **OK**.

If the username and password are valid, the VCPT main window is displayed.

---

If you log in to the VCPT when another person is using the same VCPT, the message shown in [Figure 3-1](#) is displayed and your access to the VCPT is a read-only view. To get read-write access, wait and try to open a VCPT session at a later time when no one else is using the tool.

**Figure 3-1 Read-only View Message**



With certain versions of Microsoft Internet Explorer 6, if you close a read-write session and try to open it again immediately, you get a read-only view. In this case, wait a minute and open another session to get read-write access.

When you are finished using the VCPT, click the **Logout** button on the right side of the banner so that another user can get read-write access to the tool.

VCPT sessions are timed out after 25 minutes of inactivity. If VCPT detects a network failure or server failure, the session is timed out after one minute.

# Working with VCPT Configuration Files

The VCPT channel, server, and association provisioning information is stored in a persistent local database on the Cisco CDE server. When the Cisco CDE or the VCPT is restarted, channel, server, and association data are read from the local database. The VCPT configuration file can be saved at any time and should be saved frequently to store your work.



## Caution

If a VCPT session times out because of inactivity or because of a server or network failure, unsaved data is lost. Therefore, you should save the VCPT configuration file frequently.

File management tasks for the VCPT are the responsibility of the VCPT user. The directories that the VCPT uses for its data files are as follows:

- VCPT configuration files are stored in the `/etc/opt/vcpt/data` directory.
- SDP-formatted files that the VCPT creates for each valid VCPT configuration are stored in the `/etc/opt/vcpt/data/sdp` directory.

If the `/etc/opt/vcpt/data` or `/etc/opt/vcpt/data/sdp` directory is deleted accidentally and does not exist at startup, VCPT fails to initialize. The missing directory must be recreated. For information on the remedy procedure, see the “[VCPT Fails to Initialize](#)” section on page 6-12.




## Caution

The VCPT configuration files must be backed up in a safe location that is not on the local Cisco CDE disk. If a server or software failure occurs, the latest VCPT configuration file must be retrievable from the backup location.

When the user completes channel and server configuration, and initiates the VCPT send operation, the VCPT sends the channel information in Session Description Protocol (SDP) format to the set of VQE-Ss and VCDSs. As an alternative to the VCDS, the channel information may be sent in SDP format to one or more user-specified remote servers using a password-less secure copy (SCP) mechanism.

[Figure 3-2](#) shows the buttons that you use for working with VCPT configuration files and for sending channel information.

**Figure 3-2 VCPT Configuration File Operations**



The following sections explain the configuration file and channel information operations:

- [Performing Configuration-File Operations](#), page 3-4
- [Sending or Pushing Channel Information to Servers](#), page 3-5
- [Sending Channel Information to a Subset of Servers](#), page 3-7

## Performing Configuration-File Operations

The VCPT configuration file buttons used for non-push operations are:

- **New Config**—Clears the current configuration (if any) so that you can start a new one. The new configuration is not saved until you click **Store**, specify a file name, and click **OK**.
- **Import**—Clears the current configuration (if any), and imports a configuration from a file that you specify that is located on the VQE Tools server. The configuration file is in either XML (Extensible Markup Language) or CSV (text-based, comma-separated values) format.
- **Open Configuration**—Allows you to choose an existing configuration file from the pull-down menu and open it. If needed, you should save the current configuration file before opening another one because any unsaved data in the current configuration file is lost.
- **Store**—Saves the current configuration file on the Cisco CDE that hosts VCPT.
- **Store As**—Saves the current file under a new file name that you specify.
- **Export**—Exports the current configuration to a file in the format you specify. The format is either XML or CSV.
- **Delete**—Deletes the current configuration file and clears the configuration.

When the current VCPT configuration is changed but the changes have not been saved, an asterisk is displayed beside the configuration filename (for example, bellini.xml\*).

### Names for VCPT Configuration Files

The name for a VCPT configuration file can be up to 60 characters long and use lowercase a to z, uppercase A to Z, numeric characters 0 to 9, and the underscore (\_), hyphen (-), and period (.) characters. No spaces are allowed in the name.


## Importing a Configuration

To create a VQE channel configuration in the VCPT without manually entering the data, you can import the required information from an external file. The file can be located in any directory on the VQE Tools server as long as the file has the correct permissions. However, the file must be in a valid format. For information on VCPT configuration file formats, see [Appendix I, “VCPT Configuration Files.”](#)

To import a configuration, do the following:

- 
- Step 1** Click **Import**.
- Step 2** The Import dialog box, shown in [Figure 3-3](#), is displayed.

**Figure 3-3** Import dialog



- Step 3** Enter the full path name and extension (xml or csv) of the configuration file, and click **OK**.

The VCPT clears the current configuration (if any) and displays the contents of the imported file. If the file is in XML format, the VCPT validates the file against the XML schema, *vcpt\_doc.xsd*, prior to importing.

## Exporting a Configuration


A VQE channel configuration can be exported to an external file you specify. The file can be in any directory on the VQE Tools server as long as the file has the correct permissions. Currently only two formats are supported by the VCPT; XML and CSV format. For information on the VCPT configuration file formats, see [Appendix I, “VCPT Configuration Files.”](#)

To export a VCPT configuration, do the following:

**Step 1** Click **Export**.

The Export dialog box, shown in [Figure 3-4](#), is displayed.

**Figure 3-4** Export dialog



**Step 2** Enter a full path, file name and file extension (xml or csv), and click **OK**.

The VCPT exports the VCPT configuration to this file.

## Sending or Pushing Channel Information to Servers

The VCPT buttons used to send or push channel information to VQE-Ss, VCDSs, or remote servers are the **Send** and **Force Update** buttons.

### Send Button

Use the **Send** button to send channel information in the current configuration file to the VQE-Ss, VCDSs, or remote servers that have been defined.



**Note**

Use the **Send** button for “normal” configuration file changes where the changes modify the base file that was most recently pushed to the servers.



**Note**


Using the Send button causes temporary disruption to Unicast Retransmission services for modified channels while the VQE-S cache used for packet retransmission on the modified channels is flushed.

The channel information to send is based on the channel associations that have been defined for the VQE-Ss, VCDSs, or remote servers. When channel information is sent to a set of servers, VCPT saves the current configuration file. The send operation does not succeed if any channel has misconfiguration issues. When channel information is sent to servers, the VCPT displays the following:

- Status line next to the configuration file name is updated (for example, Last update was sent to 1 out of 2 servers at: 5/11/2007 14:47:20).
- Status message is displayed: either “Send Complete” or, if the send operation fails, the message text shown in [Figure 3-5](#).
- On the Servers tab, the Status of Last Send column is updated with information on the send operation. For a description of the status values that can appear in this column, see the [“Viewing or Updating Server Information”](#) section on page 17.

You can get more details on a send failure by examining the VCPT log file, which is located in /usr/share/tomcat5/logs/vcpt.log.

**Figure 3-5** Status Message for Failed Send Operation



## Force Update Button



### Note

Using the **Force Update** button causes temporary disruption to Unicast Retransmission and Rapid Channel Change (RCC) services for all channels while the VQE-S cache used for packet retransmission is flushed.

For the following types of configuration file changes, use the **Force Update** button to send the channel information to the VQE-Ss and VCDSs.

- Configuration file changes where you are reverting to an old version of the configuration file (older than the most recently pushed configuration file)
- Configuration file changes where the changes modify some file other than the base file that was most recently pushed to the servers
- Configuration file changes when you are not certain whether the file used was the base file that was most recently pushed to the servers

If configuration information is sent to the servers and the changes to channel information are not present on the servers after the send, you can use the **Force Update** button to force the channel information changes to be accomplished on the servers.

## Sending Channel Information to a Subset of Servers

To send a channel information file to a subset of servers, follow these steps:

- Step 1** Open an existing VCPT configuration file that has the needed server, channel, and association information.
- Step 2** Click **Save As** to save the VCPT configuration file using a new file name.
- Step 3** On the Servers tab, adjust the servers list by deleting the VQE-Ss, VCDSSs, and remote servers that are not wanted.
- Step 4** Click **Store** to save the VCPT configuration file.
- Step 5** Click **Send** to send the channel information file to the adjusted list of VQE-Ss, VCDSSs, and remote servers.

## Provisioning VQE Channels

In the Cisco VCPT, use the Channels tab to add a new channel, clone an existing channel, delete an existing channel, and get detailed information on an existing channel. The number of channels supported by single VQE-S is determined by the ingest capacity of the CDE server. For VQE-S performance information, see [Appendix H, “VQE Server Performance and Scaling Limits”](#)

When you click the Channels tab, VCPT displays summary information on all channels that have been created. An incomplete channel is displayed in red. The Reduced Size RTCP Reports Enabled column shown in [Figure 3-6](#) is available starting with Cisco VQE Release 3.5.5.

**Figure 3-6 Channels Summary**

Name	Original Multicast	Rtcp Enabled	Feedback Target	Error Repair Options	RCC Enabled	Extended Reports Enabled	Bit Rate (Kbps)	Reduced Size RTCP Reports Enabled
Channel RCC	224.1.1.4 : 1030	yes	1.2.3.4 : 1031	None	yes	no	4000	no
Channel RTCP Disabled	224.1.1.1 : 1024	no	1.2.3.4 : 1025	None	no	no	4000	no
Channel RTCP Enabled	224.1.1.2 : 1026	yes	1.2.3.4 : 1027	None	no	no	4000	no
Channel Unicast ER	224.1.1.3 : 1028	yes	1.2.3.4 : 1029	Unicast Retransmission Only	no	no	4000	no
Channel Unicast xRTCP	224.1.1.5 : 1032	yes	1.2.3.4 : 1033	None	no	yes	4000	yes
Channel Unicast xRTCP RCC ER	224.1.1.6 : 1034	yes	1.2.3.4 : 1035	Unicast Retransmission Only	yes	yes	4000	yes
Channel 14	224.1.1.7 : 1025	yes	10.1.7.1 : 1026	2D FEC Hybrid	yes	yes	4000	yes
Channel 15	224.1.1.8 : 1027	yes	10.1.8.2 : 1028	1D FEC Hybrid	yes	yes	4000	yes

From the Channels tab, you can do the following:

- Click **Incomplete Channels** or **Valid Channels** to display only the corresponding subsets of channels.
- Click a column heading to reorder the channels in the list. For example, clicking **Feedback Target** orders the entries by feedback target: the combination of IP address and RTCP port number.
- Double-click any item in a channel's row to display the full details for the channel in a new window. You can update the channel information.

- Click **Add** to display a dialog box so that you can create a new channel.
- Click a channel to select it and then use one of the following buttons:
  - **Details**—Displays a dialog box with detailed information on an existing channel and allows you to update the information.
  - **Clone**—Displays a dialog box with appropriate cloned information from an existing channel so that you can use the information to create a new channel.
  - **Delete**—Deletes an existing channel.

On the Channels summary, the Error Repair Options column indicates the types of repair that have been configured for the channel. [Table 3-2](#) shows the Error Repair Options column.

**Table 3-2**      **Error Repair Options**

Option	Description
None	No Error Repair.
Unicast Retransmission Only	VQE-S provides selective retransmission of dropped IPTV packets to repair errors.
1-D FEC Only	VQE-C provides 1-dimension FEC.
2-D FEC Only	VQE-C provides 2-dimension FEC.
1-D FEC Hybrid	Unicast retransmission and 1-dimension FEC are provided.
2-D FEC Hybrid	Unicast retransmission and 2-dimension FEC are provided.

The sections that follow provide more information on the tasks that can be performed from the Channels tab.

## Adding a Channel

In the VCPT channel definition, each channel is associated with a unique feedback target (FBT) IP address. The feedback target address is a unique IP anycast address that VQE-S configures on its host Cisco CDE based on the channel information that is sent to it by the VCPT. An anycast address is a unicast address that is assigned to multiple interfaces. With the appropriate routing topology, packets addressed to an anycast address are delivered to a single interface (in this case, the nearest VQE-S's CDE interface that is identified by the address). The use of anycast addresses to identify feedback targets is useful for VQE-S redundancy.



### Note

When channels are configured with VCPT, it is required that you specify a unique feedback target (FBT) address for each channel. The router that is directly attached to the VQE-S host must have a static route configured for the FBT address so that the router can reach the target.

For information on configuring the FBT IP addresses on the router that is attached to the CDE hosting VQE-S, see the [“Enabling OSPF Routing for VQE-S Traffic or VQE-S Services Traffic”](#) section on [page D-10](#).



To add a channel, follow these steps:

**Step 1** On the Channels tab, click **Add**.

The New Channel dialog box, shown in [Figure 3-7](#), is displayed.

**Figure 3-7** *New Channel Dialog Box*

**New Channel**

**Channel Details**  
 Channel Name:  Feedback Target IP:

**Original Stream**  
 Multicast IP:     Source IP:      
 RTP Port:  Bit Rate:  (Kbps)  
 RTCP Port:

**Unicast Retransmission Stream**  
 Source IP:   
 RTP Port:   
 RTCP Port:

**FEC 1 Stream**  
 Source IP:      
 Multicast IP:      
 RTP Port:

**FEC 2 Stream**  
 Source IP:      
 Multicast IP:      
 RTP Port:

**Channel Features**  
☒ **Enable RTCP**  
☒ Enable Error Repair  
☒ Enable Rapid Channel Change  
☒ Enable Extended RTCP Reports  
☒ Enable Reduced Size RTCP  
☒ Enable FEC 1 Stream  
☒ Enable FEC 2 Stream

**Step 2** Fill in the information for the new channel. [Table 3-3](#) has information on the fields that you need to complete.

**Table 3-3 VQE Channel Details**

VCPT Field	Description
Channel Name	String having 1 to 40 alphanumeric characters.
Feedback Target IP	Unique anycast IP address on the VQE-Ss that provide services for this channel. Using the Feedback Target IP address that is sent to it by the VCPT in the channel information, the VQE-S automatically configures the specified address on one of its Cisco CDE interfaces.
<b>Channel Features</b>	
Enable RTCP	RTCP must be enabled to use Error Repair (Unicast Retransmission), RCC, Video-Quality Monitoring (RTCP Exporter and RTCP Extended Reports), or to have VQE-S display video-monitoring statistics.  If Enable RTCP is not checked, the Enable Error Repair, Enable RCC, and Enable RTCP Extended Reports check boxes are grayed out.
Enable Error Repair	Check to enable Error Repair (Unicast Retransmission). You also need to complete the Unicast Retransmission Stream fields.
Enable Rapid Channel Change	Check to enable RCC.
Enable Extended RTCP Reports	Check to enable RTCP Extended Reports.
Enable Reduced Size RTCP	Check to enable sending RTCP NACK compound packets to the VQE-S without Receiver Reports (RRs).
Enable FEC 1 Stream	Check to enable 1-dimension FEC. You also need to complete the FEC 1 Stream fields.
Enable FEC 2 Stream	Check to enable 2-dimension FEC. You also need to complete the FEC 2 Stream fields.
<b>Original Stream</b>	
Multicast IP	Multicast IP address for the original source stream of the channel. The first octet must be within the range of a valid multicast address. The multicast address must be unique for each channel.
RTP Port	RTP port number of the original source stream of the channel.
RTCP Port	The RTCP port number of the original source stream of the channel. By default, RTCP Port is the (RTP/UDP) port number plus one.
Source IP	IP address of the original source stream of the channel.  <b>Note</b> A channel may be defined with a Source IP address of 0.0.0.0 for the Original Stream. When the channel Source IP address is 0.0.0.0 for the Original Stream, the SDP entry for this channel does not include the source-filter line in the original stream section that would be used to perform a Source Specific Multicast (SSM) join. In this case, the VQE-S and VQE-C does not perform a SSM join.
Bit Rate	Bit rate of the original source stream of the channel in kilobits per second. This parameter defines how many packets the VQE-S accepts and sends for this multicast stream.  <b>Note</b> The specified bit rate should be equal to the primary stream bandwidth but <i>should not</i> include bandwidth used for FEC.

**Table 3-3 VQE Channel Details (continued)**

VCPT Field	Description
<b>Unicast Retransmission Stream</b>	
Source IP	IP address of the Unicast Retransmission stream. The IP address must be the same as is defined for Feedback Target IP.
RTP Port	RTP port number of the unicast retransmission stream. By default, RTP Port is a valid port number.
RTCP Port	RTCP port number of the unicast retransmission stream. By default, RTCP Port is a valid port number.
<b>FEC 1 Stream and FEC 2 Stream</b>	
Source IP	<p>IP address of the source stream of the channel. By default, this is the IP address of the Source IP specified for the Original Stream.</p> <p><b>Note</b> A channel may be defined with a Source IP address of 0.0.0.0 for the FEC Stream. When the channel Source IP address is 0.0.0.0 for the FEC Stream, the SDP entry for this channel does not include the source-filter line in the FEC section that would be used to perform a SSM<sup>1</sup> join. In this case, the VQE-S and VQE-C does not perform a SSM join.</p>
Multicast IP	IP address of the multicast stream of the channel. By default, this is the IP address of the Multicast IP specified for the Original Stream.
RTP Port	RTP port number of the FEC stream. The port number specified cannot be the same as the port number used for the RTP or RTCP port for the Original Stream.

1. SSM = source specific multicast.

**Rules When Adding a Channel.** The following rules apply when adding a channel:

- Feedback Target IP address must be unique for each channel.
- For the Original Stream, the Multicast IP address must be unique for each channel. That is, the address cannot be used by another channel as its Original Stream Multicast IP address.
- For the Original Stream, the Source IP address must not be equal to the Feedback Target IP address.
- FEC 1 Stream and FEC 2 Stream RTP port numbers cannot be the same as the port numbers used for the Original Stream RTP or RTCP ports.
- In any given stream, the RTP port number must not be equal to the RTCP port number.
- Configuring a FEC 1 Stream or a FEC 2 Stream provides 1-dimension FEC for the channel.
- Configuring a FEC 1 Stream and a FEC 2 Stream provides 2-dimension FEC for the channel.
- If you enter invalid data, the field name is displayed in red. You must correct the invalid data before creating or updating the channel.
- If you enter incomplete data, you can create or update the channel, but it is marked incomplete.
- Channel configuration file with an incomplete channel definition cannot be sent to VQE-Ss, remote servers, or VCDSs.

**Port Usage Recommendations.** When the STUN Server is enabled on a VQE-S (the default and recommended mode), one set of four unique port numbers can be used for all channels for the following:

- Original Source RTP Port

- Original Source RTCP Port
- Unicast Retransmission Stream RTP Port
- Unicast Retransmission Stream RTCP Port

**Note**

If the STUN Server is not enabled, each channel must be configured with unique port numbers for the each of the preceding items. The STUN server is not enabled only when no set-top boxes (STBs) being serviced by VQE-S are behind NAT devices.

- Step 3** When you have specified all required values, click **Create** to create the new channel, or click **Cancel** to exit the dialog box without creating the new channel.

## Viewing or Updating Channel Information

To view or update channel information, follow these steps:

- Step 1** On the Channels tab, click the channel you want to view or update.

- Step 2** Click **Details**.

The Details dialog box, shown in [Figure 3-8](#), is displayed. The Reduced Size RTCP Reports Enabled column show in [Figure 3-8](#) is available starting with Cisco VQE Release 3.5.5.

**Figure 3-8** Details Dialog Box

- Step 3** If needed, change or add channel information.

- Step 4** Do one of the following:

- Click **Update** to update the channel information.
- Click **Cancel** to close the dialog box without updating the channel information.

## Cloning a Channel

To clone a channel, follow these steps:

- 
- |               |   |
|---------------|---|
| <b>Step 1</b> | On the Channels tab, click the channel you want to clone.   |
| <b>Step 2</b> | Click <b>Clone</b> .<br><br>The Clone dialog box is displayed. Only appropriate information from the existing channel is cloned.  |
| <b>Step 3</b> | Verify that the cloned values are what you require. Where needed, change the values and add channel information.  |
| <b>Step 4</b> | Do one of the following: <ul style="list-style-type: none"><li>• Click <b>Create</b> to create the new channel.</li><li>• Click <b>Cancel</b> to close the dialog box without creating the new channel.</li></ul> |
- 

## Deleting a Channel

To delete a channel, follow these steps:

- 
- |               |   |
|---------------|---|
| <b>Step 1</b> | On the Channels tab, click the channel you want to delete.  |
| <b>Step 2</b> | Click <b>Delete</b> .<br><br>A dialog box asking if you want to delete the channel is displayed.  |
| <b>Step 3</b> | Do one of the following: <ul style="list-style-type: none"><li>• Click <b>Delete</b> to delete the channel.</li><li>• Click <b>Cancel</b> to close the dialog box without deleting the channel.</li></ul> |
| <b>Step 4</b> | If you clicked Delete, a confirmation dialog box is displayed. Click <b>OK</b> .  |
-

## Defining VQE-Ss, VCDSs, or Remote Servers

The Cisco VCPT requires that you provide information on each VQE-S, each VCDS, and each remote server that receives channel configuration information from the VCPT.

If you choose to send channel information to a remote server, you must install a SSH public key in .ssh directory of the authorized user on the remote server. For more information on generating the SSH public key, see the [“Setting-up a SSH Certificate on a Remote Server” section on page 19](#).



### Note

The system integrator must ensure that the generated public key is stored in the authorized\_keys file in .ssh directory of the authorized user for channel configuration files to be transferred successfully to the remote server.

In the VCPT, use the Servers tab to add a new server, delete an existing server, and get information on an existing server. When you click the Servers tab, the VCPT displays summary information, shown in [Figure 3-9](#), on all servers that have been created.

**Figure 3-9 Servers Summary**

Name	Management IP Address	Role	Number of Channels Currently Associated	Status of Last Send	Last Successful Sent Time
jupiter	10.86.21.17	VQE-S	10	Success - Received 2 channels; 0 channels deleted; 0 channels restarted; and 0 new channels created	09/25/2008 14:25:01
server 1	3.4.6.6	VQE-S	0	Failed - The host did not accept the connection within timeout of 3000 ms	09/25/2008 14:16:15

From the Servers tab, you can do the following:

- Click a column heading to reorder the servers in the list. For example, clicking **Status of Last Send** orders the servers by their channel configuration file status.
- Double-click any item in a row representing a server to display the full details for the server in a new window. You can update the server information.
- Click **Add** to display a dialog box so that you can create a new server.
- Click a channel to select it and then use one of the following buttons:
  - **Details**—Displays a dialog box with detailed information on an existing server and allows you to update the information.
  - **Delete**—Deletes an existing server.

On the Servers tab, the following columns provide useful information on the servers.

- **Number of Channels Currently Associated** column shows how many channels are currently associated with a server in the current configuration—whether or not that configuration has been saved. If the current channel information in VCPT has not been sent to the server, the Number of Channels Currently Associated can be different from the number shown as “Received” in the Status of Last Send Column.

- Status of Last Send column provides information on the last attempt by VCPT to send channel configuration information to the server. [Table 3-4](#) lists the possible messages. The result is either Success or Failed plus some additional information. The following examples explain some of the additional information that can be provided in the Status of Last Send column:

Success - Received 4 channels: 0 channels deleted; 1 channels restarted; and 0 new channels created

The preceding Success status indicates the send operation succeeded: A VQE-S received four channel definitions; zero channels were deleted; one channel definition was modified and the channel was restarted; zero new channels were created.

Failed - 0 out of 4 channels failed to validate; 1 channels having the old version; and 0 channels having the same version but contents being changed

The preceding Failed status indicates the send operation failed: all channel definitions have valid SDP format; one channel definition is an older version of the channel; zero channels have the same version (when compared to the VQE-S or the current version of the VCPT server) but with a changed channel definition.



#### Note

The “channels having the same version but contents being changed” error condition is present only when the SDP definition for the channels has been incorrectly coded by manual modifications or by a channel-provisioning tool other than VCPT.

**Table 3-4**      **Status of Last Send Messages**

Message	Explanation
Success - <i>additional_information</i>	Send operation succeeded. The <i>additional_information</i> provides details on the send operation.
Failed - <i>additional_information</i>	Send operation failed. The <i>additional_information</i> provides details on the reasons for the failure.
Failed - Network Error	VCPT did not receive any error message back from the VQE-S, the VCDS, or the remote server.
Failed - Connection refused	See the “ <a href="#">Channel-Provisioning Server Cannot Send Channel Information to VQE-S: Trusted Provisioning Client Problem</a> ” section on page 6-13.
Failed - Unable to find valid certification path to requested target	See the “ <a href="#">Channel-Provisioning Server Cannot Send Channel Information to VQE-S: SSL Certificates Problems</a> ” section on page 6-13.
Failed - Unable to connect with Server	See the “ <a href="#">Unable to Connect Error When VCPT Tries to Send Channel Information</a> ” section on page 6-14.
Failed - Security Exception	Exception occurred while VCPT was authenticating the server SSL certificate.
Failed - Invalid EMS Address	Incorrect server URL format
Failed - VCPT Server Error	Generic internal VCPT coding error has occurred. This may be because of a coding bug or because VCPT failed to read a file.
Failed - Channel config file is not writable	Channel configuration file could not be written to disk on the VQE-S, the VCDS or the remote server host.

**Table 3-4**      **Status of Last Send Messages (continued)**

Message	Explanation
Failed - File failed to open	VQE-S, the VCDS or the remote server could not open the channel configuration file.
Failed - Tomcat Service Unavailable	Tomcat application server has failed on the VCPT host.
Failed - Unable to store the SDP data on VCPT Server	SDP data could not be generated or saved on the VCPT host.
Failed - VCPT:AMT IO Exception: Connection Refused	VCPT was not able to deliver the channel configuration information. One possible cause of the failure is that VQE services were not running on the server to which the information was sent.

- Status of Last Send Time column shows the date and time of the last successful send operation for this server, or shows “None.” None indicates one of the following:
  - Server is new and channel information has never been successfully sent to it
  - VCPT configuration file that is currently open is from a previous version of VQE

The sections that follow provide more information on the tasks that can be performed from the Servers tab.

## Adding a Server

To add a server, follow these steps:

- Step 1**      On the Servers tab, click **Add**.
- The New Server dialog box, shown in [Figure 3-10](#), is displayed.

**Figure 3-10**      **New Server Dialog Box**

**New Server**

**Server Details**

Server Name:

Management IP:  .  .  .

Role:

Transfer Port:

Username:

Remote Path and Filename:

**Server Wide Channel Configuration**

RTCP Interval:  secs

Maximum Receivers:

Warning! Missing data in the fields - Management IP.



- Step 2** Fill in the information for the new server. For descriptions of the fields that you need to fill in, see [Table 3-5](#).

**Table 3-5 VQE-S and VCDS Information**

VCPT Field	Description
<b>Server Details</b>	
Server Name	String having 1 to 40 alphanumeric characters.
Management IP	One of the following: <ul style="list-style-type: none"> <li>IP address of an Ethernet interface on the Cisco CDE server</li> <li>IP address of an Ethernet interface on the remote server.</li> </ul>
Role	One of the following: <ul style="list-style-type: none"> <li>VQE-S</li> <li>VCDS</li> <li>SCP (Secure Copy Protocol)—If chosen, VCPT pushes configuration data to a specified remote server using password-less SCP.</li> </ul>
Transfer Port	SCP port number on the remote server. If role type is not SCP, the Transfer Port field is grayed out.
Username	Username of the person who has the authority to access the path on the remote server specified in the Remote Path and Filename field. If role type is not SCP, the Username field is grayed out.
Remote Path and Filename	Absolute path to the channel configuration file on the remote server and its filename. If role type is not SCP, the Remote Path and Filename field is grayed out.
<b>Server Wide Channel Configuration</b>	
Maximum Receivers	Total number of VQE Clients (VQE-Cs) that are expected to tune in this channel. This value is used by the VQE-S to calculate how often the VQE-S sends an RTCP report to the video source for this channel.
RTCP Interval	Defines how often VQE-Cs send an RTCP report. By default, RTCP Interval is 5 seconds.

- Step 3** Do one of the following:
- Click **Create** to create the new server.
  - Click **Cancel** to close the dialog box without creating the new server.

## Viewing or Updating Server Information

To view or update server information, follow these steps:

- Step 1** On the Servers tab, click the server you want to view or update.
- Step 2** Click **Details**.
- The Details dialog box is displayed.

- Step 3** If needed, change the server information.
- Step 4** Do one of the following:
- Click **Update** to update the server information.
  - Click **Cancel** to close the dialog box without changing server information.

## Deleting a Server

To delete a server, follow these steps:


- Step 1** On the Servers tab, click the server you want to delete.
- Step 2** Click **Delete**.
- A dialog box asking if you want to delete the server is displayed.
- Step 3** Do one of the following:
- Click **Delete** to delete the server.
  - Click **Cancel** to close the server dialog box without deleting the server.
- Step 4** If you clicked Delete, a confirmation dialog box is displayed. Click **OK**.

## Defining Channel Associations

After VQE channels and the VQE-Ss, VCDSs, and Remote Servers have been defined, you associate a set of channels with the servers. When the channel information file is sent to the VQE-Ss, VCDSs or Remote Servers, only the channels associated with the server are included in the file.

In the VCPT, use the Association tab, shown in [Figure 3-11](#), to associate servers with channels or copy an existing channel association.

**Figure 3-11 Association Tab**



The following sections explain how to associate channels with servers:

- [Defining Channel Associations for a Server, page 3-19](#)
- [Copying Channel Associations from Another Server, page 3-19](#)

## Defining Channel Associations for a Server

To define channel associations for a server, follow these steps:

- 
- Step 1** From the Select Server pull-down menu, select the server for which you want to define channel associations.
- The VCPT displays the IP address and role for the server.
- Step 2** Select one or more channels to associate or disassociate with the server by using the arrow buttons. For example:
- The > button moves a single available channel or group of available channels to the Selected group.
  - The >> button moves all available channels to the Selected group.
- The associations for the channel are updated.

## Copying Channel Associations from Another Server

To copy channel associations for a server, follow these steps:

- 
- Step 1** From the Select Server pull-down menu, select the server for which you want to define channel associations.
- The VCPT displays the IP address and role for the server.
- Step 2** From the Copy Association from Server pull-down menu, select the server whose channel associations you want to copy.
- Step 3** Click **OK**.
- The associations for the channel are updated.
- 

## Setting-up a SSH Certificate on a Remote Server

If you choose to export channel configuration data to a remote provisioning server, a secure shell (SSH) certificate should be generated on the VQE Tools server and its public key deployed on the remote server to allow VCPT to securely send encrypted channel configuration files to the remote server. The **scpkey** command is available on the VQE Tools server to assist in generating the SSH public key file. The command also uses a secure copy mechanism to deliver the public key of SSH certificate to the remote server. The system integrator must supply a password for the authorized user when generating the certificates so that VCPT can later send data to the remote server without being prompted to supply a password.

On the VQE Tools server, the **scpkey** executable is located at `/opt/vqes/bin/scpkey`. To have the operating system find the **scpkey** executable, you must set the PATH environment variable to include the location of the `/opt/vqes/bin` directory, or use the full path to **scpkey** when executing the command.

**Note**

You must log in as root to execute the **scpkey** command.

To generate a SSH public key, follow these steps:

**Step 1** From the command prompt, issue the following command:

```
[root@system ~]# scpkey
```

```
Welcome to the SCP key generation and transfer utility.
```

```
Checking for existing SCP key data...
```

```
Generating new keys via Linux ssh-keygen tool...
```

```
spawn ssh-keygen -t dsa
```

```
Generating public/private dsa key pair
```

```
Enter file in which to save the key (/root/.ssh/id_dsa):
```

```
Enter passphrase (empty for no passphrase):
```

```
Enter same passphrase again:
```

```
Your identification has been saved in /root/.ssh/id_dsa.
```

```
Your public key has been saved in /root/.ssh/id_dsa.pub.
```

```
The key fingerprint is:
```

```
f9:2c:89:5a:bf:22:1c:20:b8:08:05:3c:fc:d1:a9:9f root@system
```

```
SCP key generation successfully completed.
```

The **scpkey** command creates a new SSH public key. The key file is named `id_dsa.pub` and is located in `/root/.ssh/`.

**Step 2** The **scpkey** command prompts you to automatically transfer the file to the remote server or to exit the command and manually copy the public key to the remote server at a later time. If you wish to automatically transfer the SSH public key file to the remote server, do the following:

- a. When prompted to transfer the file to the remote server using the secure copy protocol, enter 'y' at the prompt below.

```
Do you wish to SCP transfer the key file to a remote system (y/n)? y
```

```
Gathering info for SCP transfer...
```

- b. Enter the IP address of the remote server at the prompt below.

```
Enter IP address of remote system: 10.22.21.101
```

- c. Enter the username of the person who is authorized to access the channel configuration files on the remote server at the prompt below:

```
Enter remote system username: dmurp
```

- d. Enter a password for the authorized person at the prompt below:

```
Enter remote system username password:
```

- e. By default, the SSH public key file is copied to the `.ssh/authorized_keys` file relative to the authorized users home directory on the remote server. Press Enter to select the default path or enter the absolute path of the SSH key file on the remote server.

```
By default, key file will be copied to .ssh/authorized_keys file relative to
remote users home directory, however you may specify a different fully
qualified path/filename here if desired.
```

```
Enter optional remote path/file (<ENTER> for default file):
```

```
Transferring file, no further user input required...
```

```
spawn scp /root/.ssh/id_dsa.pub test@10.86.21.101:~/.ssh/authorized_keys
```

- Step 3** If you wish to manually transfer the SSH public key file to the remote server, copy the file named `id_dsa.pub` located in `/root/.ssh/` on the VQE Tools server to the `~/.ssh/authorized_keys` file relative to the authorized users home directory on the remote server.
-

