

Cluster Configuration and Administration Guide for Cisco Unity Connection

Release 10.x Published November 2013

Cisco Systems, Inc.

www.cisco.com

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.

Text Part Number:

THE SPECIFICATIONS AND INFORMATION REGARDING THE PRODUCTS IN THIS MANUAL ARE SUBJECT TO CHANGE WITHOUT NOTICE. ALL STATEMENTS, INFORMATION, AND RECOMMENDATIONS IN THIS MANUAL ARE BELIEVED TO BE ACCURATE BUT ARE PRESENTED WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED. USERS MUST TAKE FULL RESPONSIBILITY FOR THEIR APPLICATION OF ANY PRODUCTS.

THE SOFTWARE LICENSE AND LIMITED WARRANTY FOR THE ACCOMPANYING PRODUCT ARE SET FORTH IN THE INFORMATION PACKET THAT SHIPPED WITH THE PRODUCT AND ARE INCORPORATED HEREIN BY THIS REFERENCE. IF YOU ARE UNABLE TO LOCATE THE SOFTWARE LICENSE OR LIMITED WARRANTY, CONTACT YOUR CISCO REPRESENTATIVE FOR A COPY.

The Cisco implementation of TCP header compression is an adaptation of a program developed by the University of California, Berkeley (UCB) as part of UCB's public domain version of the UNIX operating system. All rights reserved. Copyright © 1981, Regents of the University of California.

NOTWITHSTANDING ANY OTHER WARRANTY HEREIN, ALL DOCUMENT FILES AND SOFTWARE OF THESE SUPPLIERS ARE PROVIDED "AS IS" WITH ALL FAULTS. CISCO AND THE ABOVE-NAMED SUPPLIERS DISCLAIM ALL WARRANTIES, EXPRESSED OR IMPLIED, INCLUDING, WITHOUT LIMITATION, THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE.

IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THIS MANUAL, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses and phone numbers used in this document are not intended to be actual addresses and phone numbers. Any examples, command display output, network topology diagrams, and other figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses or phone numbers in illustrative content is unintentional and coincidental.

Cluster Configuration and Administration Guide for Cisco Unity Connection Release 10.x © 2013 Cisco Systems, Inc. All rights reserved.



Preface v

Γ

	Audience and Use v
	Documentation Conventions vi
	Cisco Unity Connection Documentation vi
	Documentation References to Cisco Unified Communications Manager Business Edition vi
	Obtaining Documentation and Submitting a Service Request vii
	Cisco Product Security Overview vii
CHAPTER 1	Configuring a Cisco Unity Connection 10.x Cluster 1-1
	Task List for Configuring a Cisco Unity Connection 10.x Cluster 1-1
	Configuring the Cisco Unity Connection 10.x Cluster 1-2
	Setting Up Alert Notification of Server Status Changes in Cisco Unity Connection 10.x 1-2
	Customizing Cluster Settings in Unity Connection 10.x 1-3
CHAPTER 2	Administering a Cisco Unity Connection 10.x 2-1
	Restarting the Cisco Unity Connection 10.x Servers in Any Order 2-1
	Manually Changing Unity Connection 10.x Server Status 2-1
	Stopping All Ports on an Unity Connection 10.x Server from Taking New Calls 2-3
	Restarting All Ports on an Unity Connection 10.x Server to Take Calls 2-3
	Shutting Down an Unity Connection 10.x Server 2-3
CHAPTER 3	About a Cisco Unity Connection 10.x Cluster 3-1
	How a Cluster Works in Cisco Unity Connection 10.x 3-1
	Licenses for an Unity Connection 10.x Cluster 3-2
	About the Unity Connection Publisher Server 3-3
	Server Status Functions in the Unity Connection 10.x Cluster 3-3
	Server Assignments and Usage of Voice Messaging Ports in Unity Connection 3-5
	Requirements for a Cisco Unity Connection 10.x Cluster 3-7
	Effects on Calls in Progress When Server Status Changes in Unity Connection 3-8
	Effects on Cisco Unity Connection 10.x Web Applications When Server Status Changes 3-8
	Effects of Stopping a Critical Service on an Unity Connection 10.x Server 3-9

Effects of a Split-Brain Condition in Unity Connection 10.x **3-9**

Events When Server Status Changes in Unity Connection 10.x **3-10**

Automatic Change of Server Status Initiated by an Unity Connection Server with Primary Status **3-10**

Automatic Change of Server Status Initiated by an Unity Connection Server with Secondary Status **3-10**

I

1

Manual Change of Unity Connection Server Status Initiated by Administrator 3-11

INDEX



Preface

This preface contains the following sections:

- Audience and Use, page v
- Documentation Conventions, page vi
- Cisco Unity Connection Documentation, page vi
- Obtaining Documentation and Submitting a Service Request, page vii
- Cisco Product Security Overview, page vii

Audience and Use

I

The *Cluster Configuration and Administration Guide for Cisco Unity Connection* is intended for installers, system administrators, and technicians who are installing and configuring, customizing, or administering Cisco Unity Connection clusters.

The guide contains instructions for configuring and using a Unity Connection cluster, as well as information on how a Unity Connection cluster works. You configure a Unity Connection cluster after installing the publisher server according to instructions in the *Installation Guide for Cisco Unity Connection*.

(For information on making changes to the Unity Connection system configuration, see the *Reconfiguration and Upgrade Guide for Cisco Unity Connection Release 10.x* at http://www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/upgrade/guide/10xcucrugx.html.

Documentation Conventions

 Table 1
 Conventions in the Cluster Configuration and Administration Guide for Cisco Unity

 Connection
 Connection

Convention	Description
boldfaced text	Boldfaced text is used for:
	• Key and button names. (Example: Select OK .)
	• Information that you enter. (Example: Enter Administrator in the User Name box.)
<> (angle brackets)	Angle brackets are used around parameters for which you supply a value. (Example: In your browser, go to https:// <cisco connection="" ip<br="" server="" unity="">address>/cuadmin.)</cisco>
- (hyphen)	Hyphens separate keys that must be pressed simultaneously. (Example: Press Ctrl-Alt-Delete .)
> (right angle bracket)	A right angle bracket is used to separate selections that you make in the navigation bar of Cisco Unity Connection Administration. (Example: In Cisco Unity Connection Administration, go to Contacts > System Contacts .)

The *Cluster Configuration and Administration Guide for Cisco Unity Connection* also uses the following conventions:

Note

Means reader take note. Notes contain helpful suggestions or references to material not covered in the document.

<u>/</u> Caution

Means reader be careful. In this situation, you might do something that could result in equipment damage or loss of data.

Cisco Unity Connection Documentation

For descriptions and URLs of Cisco Unity Connection documentation on Cisco.com, see the *Documentation Guide for Cisco Unity Connection Release 10.x.* The document is shipped with Unity Connection and is available at

www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/roadmap/10xcucdg.html.

Documentation References to Cisco Unified Communications Manager Business Edition

The name of the product known as Cisco Unified Communications Manager Business Edition in versions 9.0 and earlier has been changed to Cisco Unified Communications Manager Business Edition 5000 in versions 9.0.

I

Cisco Unity Connection 10.x no longer supports Cisco Unified Communications Manager Business Edition 5000.

Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed and set content to be delivered directly to your desktop using a reader application. The RSS feeds are a free service and Cisco currently supports RSS Version 2.0.

Cisco Product Security Overview

This product contains cryptographic features and is subject to United States and local country laws governing import, export, transfer and use. Delivery of Cisco cryptographic products does not imply third-party authority to import, export, distribute or use encryption. Importers, exporters, distributors and users are responsible for compliance with U.S. and local country laws. By using this product you agree to comply with applicable laws and regulations. If you are unable to comply with U.S. and local laws, return this product immediately

Further information regarding U.S. export regulations may be found at http://www.access.gpo.gov/bis/ear/ear_data.html.

1



Configuring a Cisco Unity Connection 10.x Cluster

This chapter contains the following sections:

- Task List for Configuring a Cisco Unity Connection 10.x Cluster, page 1-1
- Configuring the Cisco Unity Connection 10.x Cluster, page 1-2
- Setting Up Alert Notification of Server Status Changes in Cisco Unity Connection 10.x, page 1-2
- Customizing Cluster Settings in Unity Connection 10.x, page 1-3

Task List for Configuring a Cisco Unity Connection 10.x Cluster



Configure a Cisco Unity Connection cluster only after you have installed the publisher server and set up administrator workstations according to instructions in the *Installation Guide for Cisco Unity Connection Release 10.x*:

http://www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/installation/guide/10xcucig020.htm 1.

Do the following tasks in the order listed to configure a Cisco Unity Connection cluster correctly:

- 1. On the publisher server, configure the Unity Connection cluster by adding the host name or IP address of the subscriber server and enable access to alert logs for when the publisher server is not functioning. See the "Configuring the Cisco Unity Connection 10.x Cluster" section on page 1-2.
- 2. Set up alert notification of server status changes. See the "Setting Up Alert Notification of Server Status Changes in Cisco Unity Connection 10.x" section on page 1-2.
- **3.** *Optional:* Adjust the cluster settings. See the "Customizing Cluster Settings in Unity Connection 10.x" section on page 1-3.
- 4. Continue with the next task in "Part 3: Configuring the Cluster, and Installing and Configuring the Subscriber Connection Server" in the "Task List for Installing a Cisco Unity Connection 10.x System with a Unity Connection Cluster Configured" in the Installation Guide for Cisco Unity Connection Release 10.x.

Configuring the Cisco Unity Connection 10.x Cluster

You configure the cluster after you have installed the publisher server.

Do the two procedures in this section in the order listed.

Note

The Cisco Unity Connection cluster feature is not supported for use with Cisco Unified Communications Manager Business Edition 5000.

To Configure the Cisco Unity Connection 10.x Cluster

- **Step 1** On the publisher server, sign in to Cisco Unity Connection Administration.
- Step 2 In Unity Connection Administration, expand System Settings, then select Cluster.
- **Step 3** On the Find and List Servers page, select **Add New**.
- **Step 4** On the New Server Configuration page, in the Host Name/IP Address field, enter the host name or IP address of the second server in the cluster.
- **Step 5** *Optional:* In the MAC Address field, enter the MAC address of the second server.
- **Step 6** In the Description field, enter **Server 2** or another description for the second server.
- Step 7 Select Save.

To Enable Access to Alert Logs for When the 10.x Publisher Server Is Not Functioning

Step 1	In Unity Connection Administration, expand System Settings, then select Service Parameters.
Step 2	On the Service Parameters page, in the Server field, select the publisher server.
Step 3	In the Service field, select Cisco AMC Service.
Step 4	In the Failover Collector field, select the subscriber server.
Step 5	Select Save.

Setting Up Alert Notification of Server Status Changes in Cisco Unity Connection 10.x

We recommend that you configure the Cisco Unified Real-Time Monitoring Tool to send notifications for the following Cisco Unity Connection alerts:

- AutoFailbackFailed
- AutoFailbackSucceeded
- AutoFailoverFailed
- AutoFailoverSucceeded
- NoConnectionToPeer

• SbrFailed

For instructions on setting up alert notification for Unity Connection alerts, see the "Working with Alerts" chapter (in the "Alerts" part) of the *Cisco Unified Real-Time Monitoring Tool Administration Guide* at http://www.cisco.com/en/US/products/ps6509/prod_maintenance_guides_list.html.

Customizing Cluster Settings in Unity Connection 10.x

To Customize Cluster Settings in 10.x

- **Step 1** On the publisher server, sign in to Cisco Unity Connection Administration.
- Step 2 In Unity Connection Administration, expand System Settings > Advanced, then select Cluster Configuration.
- **Step 3** On the Cluster Configuration page, change the settings as applicable:

Deactivate server with Secondary status when replication is backlogged	When this check box is checked, a replication backlog condition causes the server with Secondary status to change to Deactivated.When this check box is unchecked, a replication backlog condition does not cause the server with Secondary status to change status.The default is unchecked.
Automatically change server status when the publisher server fails	When this check box is checked, a failure of the publisher server causes the server with Secondary status to change automatically to Primary. When this check box is unchecked, a failure of the publisher server does not cause the server with Secondary status to change status. The status of the server must be changed manually. The default is checked.

Step 4 Select Save.

ſ



Administering a Cisco Unity Connection 10.x

This chapter contains the following sections:

- Restarting the Cisco Unity Connection 10.x Servers in Any Order, page 2-1
- Manually Changing Unity Connection 10.x Server Status, page 2-1
- Stopping All Ports on an Unity Connection 10.x Server from Taking New Calls, page 2-3
- Restarting All Ports on an Unity Connection 10.x Server to Take Calls, page 2-3
- Shutting Down an Unity Connection 10.x Server, page 2-3



For information and instructions on removing or replacing a server in a cluster, and on adding a server to create a cluster, see the *Reconfiguration and Upgrade Guide for Cisco Unity Connection Release 10.x*

http://www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/upgrade/guide/10xcucrug040.html.

Restarting the Cisco Unity Connection 10.x Servers in Any Order

You can start clustered Cisco Unity Connection servers in any order. The necessary services will run on the servers with Primary status or Secondary status.

Manually Changing Unity Connection 10.x Server Status

You can manually change the status of servers in the following ways:

- A server with Secondary status can be manually changed to Primary status. (For the server that originally had Primary status, this change automatically causes its status to change to Secondary.) See the "To Manually Change an 10.x Server from Secondary Status to Primary Status" procedure on page 2-2.
- A server with Secondary status can be manually changed to Deactivated status. See the "To Manually Change an 10.x Server from Secondary Status to Deactivated Status" procedure on page 2-2.
- A server with Deactivated status can be manually activated so that its status changes to Primary or Secondary, depending on the status of the other server. See the "To Manually Activate an 10.x Server with Deactivated Status" section on page 2-2.

To Manually Change an 10.x Server from Secondary Status to Primary Status

- **Step 1** Sign in to Cisco Unity Connection Serviceability.
- **Step 2** From the Tools menu, select **Cluster Management**.
- **Step 3** On the Cluster Management page, under Server Manager, in the Change Server Status column for the server with Secondary status, select **Make Primary**.
- **Step 4** When prompted to confirm changing the server status, select **OK**.

The Server Status column displays the changed status when the change is complete.

Note The server

The server that originally had Primary status automatically changes to Secondary status.

To Manually Change an 10.x Server from Secondary Status to Deactivated Status

- **Step 1** Sign in to the Real-Time Monitoring Tool (RTMT).
- **Step 2** From the Cisco Unity Connection menu, select **Port Monitor**. The Port Monitor tool appears in the right pane.
- **Step 3** In the Node field, select the server with Secondary status.
- **Step 4** In the right pane, select **Start Polling**.
- **Step 5** Note whether any voice messaging ports are currently handling calls for the server.
- **Step 6** Sign in to Cisco Unity Connection Serviceability.
- Step 7 From the Tools menu, select Cluster Management.
- **Step 8** If no voice messaging ports are currently handling calls for the server, skip to Step 9.

If there are voice messaging ports that are currently handling calls for the server, on the Cluster Management page, under Change Port Status, select **Stop Taking Calls** for the server, then wait until RTMT shows that all ports for the server are idle.

Step 9 On the Cluster Management page, under Server Manager, in the Change Server Status column for the server with Secondary status, select **Deactivate**.

Caution

on Deactivating a server will terminate all calls that the ports for the server are handling.

Step 10 When prompted to confirm changing the server status, select **OK**.

The Server Status column displays the changed status when the change is complete.

To Manually Activate an 10.x Server with Deactivated Status

- **Step 1** Sign in to Cisco Unity Connection Serviceability.
- **Step 2** From the Tools menu, select **Cluster Management**.
- **Step 3** On the Cluster Management page, under Server Manager, in the Change Server Status column for the server with Deactivated status, select **Activate**.

Step 4 When prompted to confirm changing the server status, select OK.The Server Status column displays the changed status when the change is complete.

Stopping All Ports on an Unity Connection 10.x Server from Taking New Calls

Do the procedure in this section to stop all ports on a server from taking any new calls. Calls in progress continue until the callers hang up.

```
<u>}</u>
Tip
```

Use the Port Monitor page in the Real-Time Monitoring Tool (RTMT) to determine whether any ports are currently handling calls for the server.

To Stop All Ports on an 10.x Server from Taking New Calls

- **Step 1** Sign in to Cisco Unity Connection Serviceability.
- Step 2 From the Tools menu, select Cluster Management.
- Step 3 On the Cluster Management page, under Port Manager, in the Ports in Service column, select Stop Taking Calls for the server.

Restarting All Ports on an Unity Connection 10.x Server to Take Calls

Do the procedure in this section to let ports on a server take calls again after they were stopped.

To Restart All Ports on an 10.x Server to Take Calls

- **Step 1** Sign in to Cisco Unity Connection Serviceability.
- Step 2 From the Tools menu, select Cluster Management.
- **Step 3** On the Cluster Management page, under Port Manager, in the Ports in Service column, select **Take Calls** for the server.

Shutting Down an Unity Connection 10.x Server

When a Cisco Unity Connection server has Primary or Secondary status, it is handling voice messaging traffic and cluster replication. We do not recommend shutting down a Unity Connection server while it is has Primary or Secondary status because calls in progress and replication may be abruptly terminated.

If you want to shut down a server (for example, to perform maintenance), we recommend that you do the procedure in this section during nonbusiness hours when voice messaging traffic will be light. Note that the remaining server, if it has Primary or Secondary status, handles all system voice messaging functions and maintains the Unity Connection database.

To Shut Down an 10.x Server

- **Step 1** On the server that will not be shut down, sign in to Cisco Unity Connection Serviceability.
- Step 2 From the Tools menu, select Cluster Management.
- **Step 3** On the Cluster Management page, locate the server that you want to shut down.
- **Step 4** If the server that you want to shut down has Secondary status, skip to Step 5.

If the server that you want to shut down has Primary status, change the status:

- a. In the Change Server Status column for the server with Secondary status, select Make Primary.
- **b.** When prompted to confirm changing the server status, select **OK**.
- **c.** Confirm that the Server Status column indicates that the server now has Primary status and that the server you want to shut down has Secondary status.
- **Step 5** On the server with Secondary status (the one you want to shut down), change the status:
 - a. Sign in to the Real-Time Monitoring Tool (RTMT).
 - **b.** From the Cisco Unity Connection menu, select **Port Monitor**. The Port Monitor tool appears in the right pane.
 - c. In the Node field, select the server with Secondary status.
 - d. In the right pane, select Start Polling.
 - e. Note whether any voice messaging ports are currently handling calls for the server.
 - f. If no voice messaging ports are currently handling calls for the server, skip to Step 5g.

If there are voice messaging ports that are currently handling calls for the server, on the Cluster Management page, under Change Port Status, select **Stop Taking Calls** for the server, then wait until RTMT shows that all ports for the server are idle.

g. On the Cluster Management page, under Server Manager, in the Change Server Status column for the server with Secondary status, select **Deactivate**.



Caution Deactivating a server will terminate all calls that the ports for the server are handling.

- h. When prompted to confirm changing the server status, select **OK**.
- i. Confirm that the Server Status column indicates that the server now has Deactivated status.
- **Step 6** Shut down the server that you deactivated.

In Cisco Unity Connection Serviceability on the server that is running, the Server Status column shows that the server you shut down has Not Functioning status.



About a Cisco Unity Connection 10.x Cluster

This chapter contains the following sections:

- How a Cluster Works in Cisco Unity Connection 10.x, page 3-1
- Licenses for an Unity Connection 10.x Cluster, page 3-2
- About the Unity Connection Publisher Server, page 3-3
- Server Status Functions in the Unity Connection 10.x Cluster, page 3-3
- Server Assignments and Usage of Voice Messaging Ports in Unity Connection, page 3-5
- Requirements for a Cisco Unity Connection 10.x Cluster, page 3-7
- Effects on Calls in Progress When Server Status Changes in Unity Connection, page 3-8
- Effects on Cisco Unity Connection 10.x Web Applications When Server Status Changes, page 3-8
- Effects of Stopping a Critical Service on an Unity Connection 10.x Server, page 3-9
- Effects of a Split-Brain Condition in Unity Connection 10.x, page 3-9
- Events When Server Status Changes in Unity Connection 10.x, page 3-10

How a Cluster Works in Cisco Unity Connection 10.x

The Cisco Unity Connection cluster feature provides high availability voice messaging through two Unity Connection servers that are configured in a cluster. Under normal conditions, the Unity Connection servers are both active so that:

- The cluster can be assigned a DNS name that is shared by the Unity Connection servers.
- Clients such as email applications and the web tools available through the Cisco Personal Communications Assistant (PCA) can connect to either Unity Connection server.
- Phone systems can send calls to either Unity Connection server.
- Incoming phone traffic load is balanced between the Unity Connection servers by the phone system, PIMG/TIMG units, or other gateways that are required for the phone system integration.

Each server in the cluster is responsible for handling a share of the incoming calls for the cluster (answering phone calls and taking messages). The server with Primary status is responsible for the following functions:

- Homing and publishing the database and message store, which are both replicated to the other server.
- Sending message notifications and MWI requests (the Connection Notifier service is activated).

- Sending SMTP notifications and VPIM messages (the Connection Message Transfer Agent service is activated).
- Synchronizing voice messages in Unity Connection and Exchange mailboxes, if the single-inbox feature is turned on (the Unity Connection Mailbox Sync service and Unity Connection Exchange Notification Web Service are activated).

When one of the servers stops functioning (for example, when it is shut down for maintenance), the remaining server assumes responsibility for handling all incoming calls for the cluster. The remaining server also assumes responsibility for the database and message store, which are both replicated to the other server when the connection and its functionality are restored.

When the server that stopped functioning is able to resume its normal functions and is activated, it resumes responsibility for handling its share of incoming calls for the cluster.

To monitor the status of the servers, the Connection Server Role Manager service runs in Cisco Unity Connection Serviceability on both servers. This service performs the following functions:

- Starts the applicable services on each server, depending on server status.
- Determines whether critical processes (such as voice message processing, database replication, voice message synchronization with Exchange, and message store replication) are functioning normally.
- Initiates changes to server status when the server with Primary status is not functioning or when critical services are not running.

Note the following limitations when the publisher server is not functioning:

- If the Unity Connection cluster is integrated with an LDAP directory, directory synchronization does not occur, although authentication continues to work when only the subscriber server is functioning. When the publisher server is functioning again, directory synchronization resumes.
- If a Digital Network includes the Unity Connection cluster, directory updates do not occur, although messages continue to be sent to and from the cluster when only the subscriber server is functioning. When the publisher server is functioning again, directory updates resume.

The Connection Server Role Manager service sends a keep-alive events between the publisher and subscriber servers to confirm that the servers are functioning and connected. If one of the servers stops functioning or the connection between the servers is lost, the Connection Server Role Manager service waits for the keep-alive events and may require 30 to 60 seconds to detect that the other server is not available. While the Connection Server Role Manager service is waiting for the keep-alive events, users signing in to the server with Secondary status will not be able to access their mailbox or send messages, because the Connection Server Role Manager service has not yet detected that the server with Primary status (which has the active message store) is unavailable. In this situation, callers who attempt to leave a message may hear dead air or may not hear the recording beep.



It is recommended to import and delete the LDAP users from the publisher node only.

Licenses for an Unity Connection 10.x Cluster

A Cisco Unity Connection cluster requires a license for each Unity Connection server. The license that has the MAC address of the publisher server must be installed on the publisher server. The license that has the MAC address of the subscriber server must be installed on the subscriber server.

For information on managing licenses, see the "Managing Licenses in Cisco Unity Connection 10.x" chapter of the *System Administration Guide for Cisco Unity Connection Release 10.x* at http://www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/administration/guide/10xcucsagx.h tml.

About the Unity Connection Publisher Server

The first Cisco Unity Connection server that is configured in the cluster is the publisher server. The Cluster Management page in Cisco Unity Connection Serviceability identifies the publisher server.

The publisher server assumes responsibility for publishing the database and message store when the cluster is functioning normally.

When the publisher server does not have Primary status (for example, when the administrator manually changes the status of the other server to Primary, which automatically changes the status of the publisher server to Secondary), the other server assumes responsibility for publishing the database and message store.

The publisher server cannot be removed from the cluster.

Server Status Functions in the Unity Connection 10.x Cluster

Each server in the cluster has a status that appears on the Cluster Management page of Cisco Unity Connection Serviceability. The status indicates the functions that the server is currently performing in the cluster, as described in Table 3-1.

Server Status	Functions in Unity Connection Cluster
Primary	• Publishes the database and message store, which are both replicated to the other server in the cluster.
	• Receives replicated data from the other server when that server is able to share its data.
	• Displays and accepts changes to the administrative interfaces (such as Unity Connection Administration). This data is replicated to the other server in the cluster.
	• Answers phone calls and takes messages.
	• Sends message notifications and MWI requests (the Connection Notifier service is activated).
	• Sends SMTP notifications and VPIM messages (the Connection Message Transfer Agent service is activated).
	• Synchronizes voice messages in Unity Connection and Exchange mailboxes if single inbox is turned on.
	• Connects with clients such as email applications and the web tools available through the Cisco PCA.
	• When the cluster is functioning normally, the publisher server has Primary status.
	Note A server with Primary status cannot be deactivated.
Secondary	• Receives replicated data from the server with Primary status. Data includes the database and message store.
	• Replicates data to the server with Primary status.
	• Displays and accepts changes to the administrative interfaces (such as Unity Connection Administration). The data is replicated to the server with Primary status.
	• Answers phone calls and takes messages.
	• Connects with clients such as email applications and the web tools available through the Cisco PCA.
	Note Only a server with Secondary status can be deactivated.
Deactivated	• Receives replicated data from the server with Primary status. Data includes the database and message store.
	• Displays and accepts changes to the administrative interfaces (such as Unity Connection Administration). The data is replicated to the server with Primary status.
	• Does not answer phone calls or take messages.
	• Does not connect with clients such as email applications and the web tools available through the Cisco PCA.
Not Functioning	• Does not receive replicated data from the server with Primary status.
	• Does not replicate data to the server with Primary status.
	• Does not display the administrative interfaces (such as Unity Connection Administration).
	• Does not answer phone calls or take messages.
	Note A server with Not Functioning status usually is shut down.

Table 3-1 Server Status Functions in the Cisco Unity Connection 10.x Cluster

I

Server Status	Functions in Unity Connection Cluster
Starting	• Receives replicated data from the server with Primary status. Data includes the database and message store.
	• Replicates data to the server with Primary status.
	• Does not answer phone calls or take messages.
	• Does not synchronize voice messages in Unity Connection and Exchange mailboxes (single inbox).
	Note This status lasts only a few minutes, after which the server takes the applicable status.
Replicating Data	Sends and receives data from the cluster.
	• Temporarily does not answer phone calls or take messages.
	• Temporarily does not connect with clients such as email applications and the web tools available through the Cisco PCA.
	Note This status lasts only a few minutes, after which the previous status resumes for the server.
Split Brain	• After detecting two servers with Primary status: Assigns Primary status to the publisher server.
Recovery	• Updates the database and message store on the server that is determined to have Primary status.
	• Replicates data to the other server.
	• Temporarily does not answer phone calls or take messages.
	• Temporarily does not synchronize voice messages in Unity Connection and Exchange mailboxes if single inbox is turned on.
	• Temporarily does not connect with clients such as email applications and the web tools available through the Cisco PCA.
	Note This status lasts only a few minutes, after which the previous status resumes for the server.

Table 3-1 Server Status Functions in the Cisco Unity Connection 10.x Cluster (continued)

Server Assignments and Usage of Voice Messaging Ports in Unity Connection

In a Cisco Unity Connection cluster, the servers share the same phone system integrations. Each server is responsible for handling a share of the incoming calls for the cluster (answering phone calls and taking messages).

Depending on the phone system integration, each voice messaging port is either assigned to a specific server or used by both servers. Table 3-2 describes the port assignments.

Integration Type	Server Assignments and Usage of Voice Messaging Ports
Integration by Skinny Client Control Protocol (SCCP) with Cisco Unified Communications Manager or Cisco Unified Communications Manager	• The phone system is set up with twice the number of SCCP voicemail port devices that are needed to handle the voice messaging traffic. (For example, if 16 voicemail port devices are needed to handle all voice messaging traffic, 32 voicemail port devices must be set up on the phone system.)
Express	• In Cisco Unity Connection Administration, the voice messaging ports are configured so that half the number of the ports set up on the phone system are assigned to each server in the cluster. (For example, each server in the cluster has 16 voice messaging ports.)
	• On the phone system, a line group, hunt list, and hunt group are configured so that the subscriber server will answer most incoming calls for the cluster.
	• If one of the servers stops functioning (for example, when it is shut down for maintenance), the remaining server assumes responsibility for handling all incoming calls for the cluster.
	• When the server that stopped functioning is able to resume its normal functions and is activated, it resumes responsibility for handling its share of incoming calls for the cluster.
Integration through a SIP Trunk with Cisco Unified Communications Manager or Cisco Unified Communications Manager Express	• In Cisco Unity Connection Administration, half the number of voice messaging ports that are needed to handle voice messaging traffic are assigned to each server in the cluster. (For example, if 16 voice messaging ports are needed to handle all voice messaging traffic for the cluster, each server in the cluster is assigned voice messaging ports.)
	• On the phone system, a route group, route list, and route pattern are configured to distribute calls equally to both servers in the cluster.
	• If one of the servers stops functioning (for example, when it is shut down for maintenance), the remaining server assumes responsibility for handling all incoming calls for the cluster.
	• When the server that stopped functioning is able to resume its normal functions and is activated, it resumes responsibility for handling its share of incoming calls for the cluster.

Table 3-2 Server Assignments and Usage of Voice Messaging Ports in the Cisco Unity Connection 10.x Cluster

I

Integration Type	Server Assignments and Usage of Voice Messaging Ports
Integration through PIMG/TIMG units	• The number of ports set up on the phone system is the same as the number of voice messaging ports on each server in the cluster so that the servers share all the voice messaging ports. (For example, if the phone system is set up with 16 voice messaging ports, each server in the cluster must have the same 16 voice messaging ports.)
	• On the phone system, a hunt group is configured to distribute calls equally to both servers in the cluster.
	• The PIMG/TIMG units are configured to balance the voice messaging traffic between the servers.
	• If one of the servers stops functioning (for example, when it is shut down for maintenance), the remaining server assumes responsibility for handling all incoming calls for the cluster.
	• When the server that stopped functioning is able to resume its normal functions and is activated, it resumes responsibility for handling its share of incoming calls for the cluster.
Other integrations that use SIP	• In Cisco Unity Connection Administration, half the number of voice messaging ports that are needed to handle voice messaging traffic are assigned to each server in the cluster. (For example, if 16 voice messaging ports are needed to handle all voice messaging traffic for the cluster, each server in the cluster has 8 voice messaging ports.)
	• On the phone system, a hunt group is configured to distribute calls equally to both servers in the cluster.
	• If one of the servers stops functioning (for example, when it is shut down for maintenance), the remaining server assumes responsibility for handling all incoming calls for the cluster.
	• When the server that stopped functioning is able to resume its normal functions, it resumes responsibility for handling its share of incoming calls for the cluster.

Table 3-2 Server Assignments and Usage of Voice Messaging Ports in the Cisco Unity Connection 10.x Cluster

Requirements for a Cisco Unity Connection 10.x Cluster

For current Cisco Unity Connection cluster requirements, see *System Requirements for Cisco Unity Connection Release 10.x* at www.cisco.com/en/US/docs/voice_ip_comm/connection/10x/requirements/10xcucsysreqs.html.

Effects on Calls in Progress When Server Status Changes in Unity Connection

When the status of a Cisco Unity Connection server changes, the effects on calls in progress depend on the final status of the server that is handling a call and on the condition of the network. Table 3-3 describes the effects.

Status Change	Effects
Primary to Secondary	When the status change is initiated manually, calls in progress are not affected.
	When the status change is automatic, effects on calls in progress depend on the critical service that stopped.
Secondary to Primary	When the status change is initiated manually, calls in progress are not affected.
	When the status change is automatic, effects on calls in progress depend on the critical service that stopped.
Secondary to Deactivated	Calls in progress are dropped.
	To prevent dropped calls, on the Cluster Management page in Cisco Unity Connection Serviceability, select Stop Taking Calls for the server, wait until all calls have ended, and deactivate the server.
Primary or Secondary to Replicating Data	Calls in progress are not affected.
Primary or Secondary to Split Brain Recovery	Calls in progress are not affected.

Table 3-3Effects on Calls in Progress When Server Status Changes in 9.x

If network connections are lost, then calls in progress may be dropped, depending on the nature of the network problem.

Effects on Cisco Unity Connection 10.x Web Applications When Server Status Changes

Normal functioning of the following web applications are not affected when the server status changes:

- Cisco Unity Connection Administration
- Cisco Unity Connection Serviceability
- Cisco Unity Connection web tools accessed through the Cisco PCA—the Messaging Assistant, Messaging Inbox, and Personal Call Transfer Rules web tools
- Cisco Web Inbox
- Representational state transfer (REST) API clients

Effects of Stopping a Critical Service on an Unity Connection 10.x Server

Critical services are necessary for the normal functioning of the Cisco Unity Connection system. The effects of stopping a critical service depend on the server and its status. Table 3-4 describes the effects.

Table 3-4 Effects of Stopping a Critical Service on an 10.x Server

Server	Effects
Publisher	• When the server has Primary status, stopping a critical service in Cisco Unity Connection Serviceability causes the server status to change to Secondary and degrades the ability of the server to function normally.
	The status of the subscriber server changes to Primary if it does not have the Disabled or Not Functioning status.
	• When the server has Secondary status, stopping a critical service in Cisco Unity Connection Serviceability degrades the ability of the server to function normally. The status of the servers does not change.
Subscriber	When the server has Primary status, stopping a critical service in Cisco Unity Connection Serviceability degrades the ability of the server to function normally. The status of the servers does not change.

Effects of a Split-Brain Condition in Unity Connection 10.x

When the servers in a Cisco Unity Connection cluster have Primary status at the same time (for example, when the servers have lost their connection with each other), both servers handle incoming calls (answer phone calls and take messages), send message notifications, send MWI requests, accept changes to the administrative interfaces (such as Unity Connection Administration), and synchronize voice messages in Unity Connection and Exchange mailboxes if single inbox is turned on. However, the servers do not replicate the database and message store to each other and do not receive replicated data from each other.

When the connection between the servers is restored, the status of the servers temporarily changes to Split Brain Recovery while the data is replicated between the servers and MWI settings are coordinated. During the time when the server status is Split Brain Recovery, the Connection Message Transfer Agent service and the Connection Notifier service (in Cisco Unity Connection Serviceability) are stopped on both servers, so Unity Connection does not deliver any messages and does not send any message notifications. The Unity Connection Mailbox Sync service and Unity Connection Exchange Notification Web Service are also stopped, so Unity Connection does not synchronize voice messages with Exchange (single inbox). The message stores are also briefly dismounted, so that Unity Connection tells users who are trying to retrieve their messages at this point that their mailboxes are temporarily unavailable.

When the recovery process is complete, the Connection Message Transfer Agent service and the Connection Notifier service are started on the publisher server. Delivery of the messages that arrived while during the recovery process may take additional time, depending on the number of messages to be delivered. The Connection Message Transfer Agent service and the Connection Notifier service are started on the subscriber server. Finally, the publisher server has Primary status and the subscriber server has Secondary status. At this point, the Unity Connection Mailbox Sync service and Unity Connection Exchange Notification Web Service are started on the server with Primary status, so that Connection can resume synchronizing voice messages with Exchange if single inbox is turned on.

Events When Server Status Changes in Unity Connection 10.x

This section describes the events that take place when server status changes in the following situations:

- Automatic Change of Server Status Initiated by an Unity Connection Server with Primary Status, page 3-10
- Automatic Change of Server Status Initiated by an Unity Connection Server with Secondary Status, page 3-10
- Manual Change of Unity Connection Server Status Initiated by Administrator, page 3-11

Automatic Change of Server Status Initiated by an Unity Connection Server with Primary Status

- 1. The Unity Connection Server Role Manager service on the server with Primary status detects an unrecoverable failure (for example, the database fails or a critical service is stopped).
- 2. The Unity Connection Server Role Manager service on the server with Primary status notifies the Unity Connection Server Role Manager service on the other server to change its status.
- **3.** The Unity Connection Server Role Manager service on both servers posts alarms that it is initiating a change of status.
- 4. The Unity Connection Server Role Manager service on the server with Primary status sets its status in the database to Secondary.
- **5.** The Unity Connection Server Role Manager service on the other server (the server that originally had Secondary status) sets its status in the database to Primary.
- **6.** The Unity Connection Server Role Manager service on the server that now has Primary status starts the critical services on that server.
- 7. The data connector detects the changed server status and sets the connections to use the database on the server that now has Primary status.
- 8. If possible, database and message store replication continues between the servers.
- **9.** The Unity Connection Server Role Manager service on the server that now has Primary status posts an alarm that the change of status is complete.

Automatic Change of Server Status Initiated by an Unity Connection Server with Secondary Status

- The Unity Connection Server Role Manager service on the server with Secondary status does not receive contact from the Unity Connection Server Role Manager service on the server with Primary status.
- **2.** The Unity Connection Server Role Manager service on the server with Secondary status confirms its network connection by pinging the local host and other known remote servers.
- **3.** If the network connection is confirmed, the Unity Connection Server Role Manager service on the server with Secondary status posts an alarm that it is initiating a change of status.

If the network connection is not available, the status does not change and the remaining events do not occur.

- **4.** The Unity Connection Server Role Manager service on the server with Secondary status sets its status in the database to Primary.
- 5. The Unity Connection Server Role Manager service on the server that now has Primary status starts the critical services on that server.
- 6. The data connector detects the changed status and sets the connections to use the database on the server that now has Primary status.
- 7. If possible, database and message store replication continues between the servers.
- **8.** The Unity Connection Server Role Manager service on the server that now has Primary status posts an alarm that the change of status is complete.

Manual Change of Unity Connection Server Status Initiated by Administrator

- **1.** In Cisco Unity Connection Serviceability, the administrator manually initiates a change of server status.
- 2. The Unity Connection Server Role Manager service on the server with Secondary status notifies the Unity Connection Server Role Manager service on the server with Primary status to initiate change of status.
- **3.** The Unity Connection Server Role Manager service on the both servers posts alarms that the change of status is being initiated.
- 4. The Unity Connection Server Role Manager service on the server with Primary status sets its status in the database to Secondary.
- **5.** The Unity Connection Server Role Manager service on the other server (the server that originally had Secondary status) sets its status in the database to Primary.
- **6.** The Unity Connection Server Role Manager service on the server that now has Primary status starts the critical services on that server.
- 7. The data connector detects the changed status and sets the connections to use the database on the server that now has Primary status.
- 8. Database and file replication continues between the servers.
- **9.** The Unity Connection Server Role Manager service on the server that now has Primary status posts an alarm that the change of status is complete.





A

activating server with Deactivated status 2-1 alerts, setting up notification of server status changes 1-2 automatic status changes

by server with Primary, events 3-10

by server with Secondary, events 3-10

С

calls in progress, effects of changing server status **3-8** changing cluster settings 1-3 server status, manually 2-1 server with Secondary status to Deactivated 2-1 server with Secondary status to Primary 2-1 cluster how one works 3-1 licenses for 3-2 Cluster Configuration page, changing settings 1-3 configuring task list 1-1 the cluster 1-2 Connection Server Role Manager service, about 3-2 critical service, effects of stopping 3-9 customizing cluster settings 1-3

D

ſ

database replication 3-1

Е

effects

of a split-brain condition **3-9** of stopping a critical service **3-9** on calls in progress when server status changes **3-8** on web applications when server status changes **3-8** events when server status changes **3-10**

L

licenses for a cluster **3-2**

Μ

manual status changes, events 3-11message store replication 3-1monitoring server status 3-2

Ν

notification of server status change alerts, setting up 1-2

Ρ

ports

assignments of voice messaging to each server **3-5** restarting to take calls **2-3** stopping from taking new calls **2-3** publisher server, about **3-3**

R

replication of database and message store 3-1 of voice messages 3-1 requirements for a cluster 3-7 restarting all ports to take calls 2-3 servers, order 2-1

Secondary to Primary, changing manually 2-1 server, functions in cluster 3-3 stopping a critical service, effects of 3-9 stopping all ports from taking new calls 2-3

Т

task list for configuring a cluster 1-1

V

voice message replication **3-1** voice messaging ports, assignments to each server **3-5**

1

W

web applications, effects on when server status changes **3-8**

S

servers assignments of voice messaging ports 3-5 cluster requirements 3-7 configuring the cluster 1-2 effects on calls in progress when status changes 3-8 events when status changes 3-10 manually changing status 2-1 order for starting 2-1 publisher, about 3-3 shutting down 2-3 status functions in cluster 3-3 status monitoring 3-2 server status changes, setting up notification of 1-2 settings, customizing cluster 1-3 setting up notification of server status change alerts 1-2 shutting down servers 2-3 split-brain condition, effects of 3-9 starting servers, order 2-1 status automatic change by server with Primary, events 3-10 automatic change by server with Secondary, events 3-10 Deactivated, activating manually 2-1 events when server changes 3-10 manual change, events 3-11 of servers 3-2 Secondary to Deactivated, changing manually 2-1

Cluster Configuration and Administration Guide for Cisco Unity Connection Release 10.x