

IP Communications Required by Cisco Unity Connection

See the following sections:

- Cisco Unity Connection Service Ports, page 1-1
- Outbound Connections Made by the Cisco Unity Connection Server, page 1-6

Cisco Unity Connection Service Ports

I

Table 1-1 lists the TCP and UDP ports that are used for inbound connections to the Cisco Unity Connection server, and ports that are used internally by Unity Connection.

Ports and Protocols ¹	Operating System Firewall Setting	Executable/Service or Application	Service Account	Comments
TCP: 20500, 20501, 20502, 19003, 1935	Open only between servers in a Unity Connection cluster	CuCsMgr/Unity Connection Conversation Manager	cucsmgr	Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 21000–21512	Open	CuCsMgr/Unity Connection Conversation Manager	cucsmgr	IP phones must be able to connect to this range of ports on the Unity Connection server for some phone client applications.
TCP: 5000	Open	CuCsMgr/Unity Connection Conversation Manager	cucsmgr	Opened for port-status monitoring read-only connections. Monitoring must be configured in Connection Administration before any data can be seen on this port (Monitoring is off by default).
				Administration workstations connect to this port.

 Table 1-1
 TCP and UDP Ports That Are Used for Inbound Connections to the Cisco Unity Connection Server

1

Ports and Protocols ¹	Operating System Executable/Service or ols ¹ Firewall Setting Application Service Account		Service Account	Comments
TCP and UDP ports allocated by administrator for SIP traffic.	Open	CuCsMgr/Unity Connection Conversation Manager	cucsmgr	Unity Connection SIP Control Traffic handled by conversation manager. SIP devices must be able to
TCP ports 5001, 5002, 5003 and 5004 are open.				connect to these ports.
Possible ports are 5060–5100				
TCP: 20055	Open only between servers in a Unity Connection cluster	CuLicSvr/Unity Connection License Server	culic	Restricted to localhost only (no remote connections to this service are needed).
TCP: 1502, 1503 ("ciscounity_tcp" in /etc/services)	Open only between servers in a Unity Connection cluster	unityoninit/Unity Connection DB	root	Servers in a Unity Connection cluster must be able to connect to each other on these database ports.
				For external access to the database, use CuDBProxy.
TCP: 143, 993, 7993, 8143, 8993	Open	CuImapSvr/Unity Connection IMAP Server	cuimapsvr	Client workstations must be able to connect to ports 143 and 993 for IMAP inbox access, and IMAP over SSL inbox access.
TCP: 25, 8025	Open	CuSmtpSvr/Unity Connection SMTP Server	cusmtpsvr	Servers delivering SMTP to Unity Connection port 25, such as other servers in a UC Digital Network.
TCP: 4904	Blocked; internal use only	SWIsvcMon (Nuance SpeechWorks Service Monitor)	openspeech	Restricted to localhost only (no remote connections to this service are needed).
TCP: 4900:4904	Blocked; internal use only	OSServer/Unity Connection Voice Recognizer	openspeech	Restricted to localhost only (no remote connections to this service are needed).
UDP: 16384–21511	Open	CuMixer/Unity Connection Mixer	cumixer	VoIP devices (phones and gateways) must be able to send traffic to these UDP ports to deliver inbound audio streams.
UDP: 7774–7900	Blocked; internal use only	CuMixer/ Speech recognition RTP	cumixer	Restricted to localhost only (no remote connections to this service are needed).
TCP: 22000	Open only between	CuSrm/	cusrm	Cluster SRM RPC.
UDP: 22000	servers in a Unity Connection cluster	Unity Connection Server Role Manager		Servers in a Unity Connection cluster must be able to connect to each other on these ports.

Table 1-1 TCP and UDP Ports That Are Used for Inbound Connections to the Cisco Unity Connection Server

Γ

Ports and Protocols ¹	Operating System Executable/Service or orts and Protocols ¹ Firewall Setting Application		Service Account	Comments
TCP: 22001	Open only between	CuSrm/	cusrm	Cluster SRM heartbeat.
UDP: 22001	servers in a Unity Connection cluster	Unity Connection Server Role Manager		Heartbeat event traffic is not encrypted but is MAC secured.
				Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 20532	Open	CuDbProxy/ Unity Connection Database Proxy	cudbproxy	If this service is enabled it allows administrative read/write database connections for off-box clients. For example, some of the ciscounitytools.com tools use this port.
				Administrative workstations would connect to this port.
TCP: 22	Open	Sshd	root	Firewall must be open for TCP 22 connections for remote CLI access and serving SFTP in a Unity Connection cluster.
				Administrative workstations must be able to connect to a Unity Connection server on this port.
				Servers in a Unity Connection cluster must be able to connect to each other on this port.
UDP: 161	Open	Snmpd Platform SNMP Service	root	_
UDP: 500	Open	Raccoon ipsec isakmp (key management) service	root	Using ipsec is optional, and off by default.
				If the service is enabled, servers in a Unity Connection cluster must be able to connect to each other on this port.
TCP: 8500 UDP: 8500	Open	clm/cluster management service	root	The cluster manager service is part of the Voice Operating System.
				Servers in a Unity Connection cluster must be able to connect to each other on these ports.

Table 1-1 TCP and UDP Ports That Are Used for Inbound Connections to the Cisco Unity Connection Server

1

Ports and Protocols ¹	Operating System Firewall Setting	Executable/Service or Application Service Account		Comments
UDP: 123	Open	Ntpd Network Time Service	ntp	Network time service is enabled to keep time synchronized between servers in a Unity Connection cluster.
				The publisher server can use either the operating system time on the publisher server or the time on a separate NTP server for time synchronization. Subscriber servers always use the publisher server for time synchronization.
				Servers in a Unity Connection cluster must be able to connect to each other on this port.
TCP: 5007	Open	Tomcat/Cisco Tomcat (SOAP Service)	tomcat	Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 1500, 1501	Open only between servers in a Unity Connection cluster	cmoninit/Cisco DB	informix	These database instances contain information for LDAP integrated users, and serviceability data. Servers in a Unity Connection
				cluster must be able to connect to each other on these ports.
TCP: 1515	Open only between servers in a Unity Connection cluster	dblrpm/Cisco DB Replication Service	root	Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 8001	Open only between servers in a Unity Connection cluster	dbmon/Cisco DB Change Notification Port	database	Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 2555, 2556	Open only between servers in a Unity Connection cluster	RisDC/Cisco RIS Data Collector	ccmservice	Servers in a Unity Connection cluster must be able to connect to each other on these ports.
TCP: 1090, 1099	Open only between servers in a Unity	Amc/Cisco AMC Service (Alert Manager	ccmservice	Performs back-end serviceability data exchanges
	Connection cluster	Collector)		1090: AMC RMI Object Port 1099: AMC RMI Registry Port
				Servers in a Unity Connection cluster must be able to connect to each other on these ports.

Table 1-1 TCP and UDP Ports That Are Used for Inbound Connections to the Cisco Unity Connection Server

Γ

Ports and Protocols ¹	Operating System Firewall Setting	Executable/Service or Application	Service Account	Comments
TCP: 80, 443, 8080, 8443	Open	tomcat/Cisco Tomcat	tomcat	Both client and administrative workstations need to connect to these ports.
				Servers in a Unity Connection cluster must be able to connect to each other on these ports for communications that use HTTP-based interactions like REST.
				Note These ports support both the IPv4 and IPv6 addresses. However, the IPv6 address works only when Connection platform is configured in Dual (IPv4/IPv6) mode. For more information on Configuring IPv6 settings, see Adding or Changing the IPv6 Addresses of Cisco Unity Connection chapter of <i>Upgrade Guide for</i> <i>Cisco Unity Connection</i> guide at http://www.cisco.com/en/ US/docs/voice_ip_comm/ connection/10x/upgrade/ guide/10xcucrug051.html
				Note Cisco Unity Connection Survivable Remote Site Voicemail SRSV supports
				these ports for IP communication.

TCP and UDP Ports That Are Used for Inbound Connections to the Cisco Unity Connection Server Table 1-1

Ports and Protocols ¹	Operating System Firewall Setting	Executable/Service or Application	Service Account	Comments
TCP: 8081, 8444	Open only between servers in HTTPS Networking	tomcat/Cisco Tomcat	tomcat	Servers in HTTPS Networking must be able to connect to each other on these ports for communications. Unity Connection HTTPS Directory Feeder service uses these ports for directory synchronization.NoteUnity Connection HTTPS
				Directory Feeder service supports only IPv4 mode.
TCP: 5001, 8005	Blocked; internal use only	tomcat/Cisco Tomcat	tomcat	Internal tomcat service control and axis ports.
TCP: 32768–61000 UDP: 32768–61000	Open			Ephemeral port ranges, used by anything with a dynamically allocated client port.
TCP: 7080	Open	jetty/Unity Connection Jetty	jetty	<i>Exchange 2007 and Exchange 2010 only, single inbox only:</i> EWS notifications of changes to Unity Connection voice messages.
UDP: 9291	Open	CuMbxSync/ Unity Connection Mailbox Sync Service	cumbxsync	<i>Exchange 2003 only, single inbox</i> <i>only:</i> WebDAV notifications of changes to Unity Connection voice messages.

1. Bold port numbers are open for direct connections from off-box clients.

Outbound Connections Made by the Cisco Unity Connection Server

Table 1-2 lists the TCP and UDP ports that Cisco Unity Connection uses to connect with other servers in the network.

Table 1-2	TCP and UDP Ports That Cisco Unity Connection Uses to Connect With Other Servers in the Network
-----------	---

Ports and Protocols	Executable	Service Account	Comments
TCP: 2000* (Default SCCP port)	CuCsMgr	cucsmgr	Unity Connection SCCP client connection to Cisco Unified CM when
Optionally TCP port 2443* if you use SCCP over TLS.			they are integrated by using SCCP.
* Many devices and applications allow configurable RTP port allocations.			

Γ

Ports and Protocols	Executable	Service Account	Comments
UDP: 16384–32767* (RTP) * Many devices and applications allow configurable RTP port allocations.	CuMixer	cumixer	Unity Connection outbound audio-stream traffic.
UDP: 69	CuCsMgr	cucsmgr	When you are configuring encrypted SCCP, encrypted SIP, or encrypted media streams, Unity Connection makes a TFTP client connection to Cisco Unified CM to download security certificates.
TCP: 53	any	any	Used by any process that needs to perform
UDP: 53			DNS name resolution.
TCP: 53, and either 389 or 636	CuMbxSync CuCsMgr tomcat	cumbxsync cucsmgr tomcat	Used when Unity Connection is configured for unified messaging with Exchange and one or more unified messaging services are configured to search for Exchange servers.
			Unity Connection uses port 389 when you choose LDAP for the protocol used to communicate with domain controllers.
			Unity Connection uses port 636 when you choose LDAPS for the protocol used to communicate with domain controllers.
TCP: 80, 443 (HTTP and HTTPS)	CuMbxSync	cumbxsync	
	CuCsMgr	cucsmgr	
	tomcat	tomcat	NoteThese ports support both the IPv4 and IPv6 addresses.
TCP: 80, 443, 8080, and 8443 (HTTP and HTTPS)	CuCsMgr tomcat	cucsmgr tomcat	 Unity Connection makes HTTP and HTTPS client connections to: Other Unity Connection servers for Digital Networking automatic joins. Cisco Unified CM for AXL user synchronization.
			Note These ports support both the IPv4 and IPv6 addresses.
			Note Cisco Unity Connection Survivable Remote Site Voicemail SRSV supports these ports for IP communication.

Table 1-2 TCP and UDP Ports That Cisco Unity Connection Uses to Connect With Other Servers in the Network

1

and Protocols	Executable	Service Account	Comments
143, 993 (IMAP and IMAP over	CuCsMgr	cucsmgr	Unity Connection makes IMAP connections to Microsoft Exchange servers to perform text-to-speech conversions of email messages in a Unity Connection user's Exchange mailbox.
25 (SMTP)	CuSmtpSvr	cusmtpsvr	Unity Connection makes client connections to SMTP servers and smart hosts, or to other Unity Connection servers for features such as VPIM networking or Unity Connection Digital Networking.
21 (FTP)	ftp	root	The installation framework performs FTP connections to download upgrade media when an FTP server is specified.
22 (SSH/SFTP)	CiscoDRFMaster sftp	drf root	The Disaster Recovery Framework performs SFTP connections to network backup servers to perform backups and retrieve backups for restoration.
			The installation framework will perform SFTP connections to download upgrade media when an SFTP server is specified.
: 67 (DHCP/BootP)	dhclient	root	Client connections made for obtaining DHCP addressing.
			Although DHCP is supported, Cisco highly recommends that you assign static IP addresses to Unity Connection servers.
123 123 (NTD)	Ntpd	root	Client connections made for NTP clock synchronization.
123 : 123 (NTP)	Ntpd	root	highly recommends that you IP addresses to Unity Conne

Table 1-2	TCP and UDP Ports That Cisco Unity Connection Uses to Connect With Other Servers in the Network
-----------	---