



CHAPTER 6

Security

This chapter describes Certificate Management and IPSec Management and provides procedures for performing the following tasks:

- [Set Internet Explorer Security Options, page 6-1](#)
- [Manage Certificates and Certificate Trust Lists, page 6-1](#)
- [IPSEC Management, page 6-9](#)

Set Internet Explorer Security Options

To download certificates from the server, ensure your Internet Explorer security settings are configured as follows:

Procedure

- Step 1** Start Internet Explorer.
 - Step 2** Navigate to **Tools > Internet Options**.
 - Step 3** Click the **Advanced** tab.
 - Step 4** Scroll down to the Security section on the Advanced tab.
 - Step 5** If necessary, clear the **Do not save encrypted pages to disk** check box.
 - Step 6** Click **OK**.
-

Manage Certificates and Certificate Trust Lists

The following topics describe the functions that you can perform from the Certificate Management menu:

- [Display Certificates](#)
- [Download a Certificate](#)
- [Delete and Regenerate a Certificate](#)
- [Upload a Certificate or Certificate Trust List](#)

- [Using Third-Party CA Certificates](#)

**Note**

To access the Security menu items, you must log in to Cisco Unified Communications Operating System Administration again by using your administrator password.

Display Certificates

To display existing certificates, follow this procedure:

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.
- Step 2** You can use the Find controls to filter the certificate list.
- Step 3** To view details of a certificate or trust store, click its file name.
The Certificate Configuration window displays information about the certificate.
- Step 4** To return to the Certificate List window, select **Back To Find/List** in the Related Links list; then, click **Go**.
-

Download a Certificate

To download a certificate from the Cisco Unified Communications Operating System to your PC, follow this procedure:

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.
- Step 2** You can use the Find controls to filter the certificate list.
- Step 3** Click the file name of the certificate.
The Certificate Configuration window displays.
- Step 4** Click **Download**.
- Step 5** In the File Download dialog box, click **Save**.
-

Delete and Regenerate a Certificate

These sections describe deleting and regenerating a certificate:

- [Deleting a Certificate](#)

- [Regenerating a Certificate](#)

Deleting a Certificate

To delete a trusted certificate, follow this procedure:

**Caution**

Deleting a certificate can affect your system operations. Any existing CSR for the certificate that you choose from the Certificate list gets deleted from the system, and you must generate a new CSR. For more information, see the [“Generating a Certificate Signing Request” procedure on page 6-7](#).

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.
- Step 2** You can use the Find controls to filter the certificate list.
- Step 3** Click the file name of the certificate or CTL.
The Certificate Configuration window displays.
- Step 4** Click **Delete**.
-

Regenerating a Certificate

To regenerate a certificate, follow this procedure:

**Caution**

Regenerating a certificate can affect your system operations.

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.
- Step 2** Click **Generate New**.
The Generate Certificate dialog box opens.
- Step 3** Choose a certificate name from the Certificate Name list. For a description of the certificate names that display, see [Table 6-1](#).
- Step 4** Click **Generate New**.
-

**Note**

After you regenerate certificates in Cisco Unified Communications Operating System, you must perform a backup so that the latest backup contains the regenerated certificates. If your backup does not contain the regenerated certificates and you must perform restoration tasks for any reason, you must manually

unlock each phone in your system so that the phone can register with Cisco Unified Communications Manager. For information on performing a backup, refer to the *Disaster Recovery System Administration Guide*.

Table 6-1 **Certificate Names and Descriptions**

Name	Description
tomcat	This self-signed root certificate gets generated during installation for the HTTPS server.
ipsec	This self-signed root certificate gets generated during installation for IPSec connections with MGCP and H.323 gateways.
CallManager	This self-signed root certificate automatically installs when you install Cisco Unified Communications Manager. This certificate provides server identification, including the server name and the Global Unique Identifier (GUID).
CAPF	The system copies this root certificate to your server or to all servers in the cluster after you complete the Cisco CTL client configuration.

Upload a Certificate or Certificate Trust List



Caution

Uploading a new certificate or certificate trust list (CTL) file can affect your system operations. After you upload a new certificate or certificate trust list, you must restart the CiscoCallManager service by navigating to **Cisco Unified Serviceability > Tools > Service Activation**. For more information, see the *Cisco Unified Serviceability Administration Guide*.



Note

The system does not distribute trust certificates to other cluster nodes automatically. If you need to have the same certificate on more than one node, you must upload the certificate to each node individually.

These sections describe how to upload a CA root certificate, application certificate, or CTL file to the server:

- [Upload a Certificate](#)
- [Upload a Certificate Trust List](#)
- [Upload a Directory Trust Certificate](#)

Upload a Certificate

Procedure

Step 1 Navigate to **Security > Certificate Management**.

The Certificate List window displays.

Step 2 Click **Upload Certificate**.

The Upload Certificate dialog box opens.

Step 3 Select the certificate name from the **Certificate Name** list.

Step 4 If you are uploading an application certificate that was issued by a third-party CA, enter the name of the CA root certificate in the **Root Certificate** text box. If you are uploading a CA root certificate, leave this text box empty.

Step 5 Select the file to upload by doing one of the following steps:

- In the **Upload File** text box, enter the path to the file.
- Click the **Browse** button and navigate to the file; then, click **Open**.

Step 6 To upload the file to the server, click the **Upload File** button.

Upload a Certificate Trust List

Procedure

Step 1 Navigate to **Security > Certificate Management**.

The Certificate List window displays.

Step 2 Click **Upload Certificate**.

The Upload Certificate Trust List dialog box opens.

Step 3 Select the certificate name from the **Certificate Name** list.

Step 4 If you are uploading an application certificate that was issued by a third-party CA, enter the name of the CA root certificate in the **Root Certificate** text box. If you are uploading a CA root certificate, leave this text box empty.

Step 5 Select the file to upload by doing one of the following steps:

- In the **Upload File** text box, enter the path to the file.
- Click the **Browse** button and navigate to the file; then, click **Open**.

Step 6 To upload the file to the server, click the **Upload File** button.

Upload a Directory Trust Certificate

Procedure

Step 1 Navigate to **Security > Certificate Management**.

The Certificate List window displays.

Step 2 Click **Upload Certificate**.

The Upload Certificate Trust List dialog box opens.

Step 3 Select **directory-trust** from the **Certificate Name** list.

- Step 4** Enter the file to upload in the **Upload File** field.
- Step 5** To upload the file, click the **Upload File** button.
- Step 6** Log into Cisco Unified Serviceability.
- Step 7** Navigate to **Tools > Control Center - Feature Services**.
- Step 8** Restart the service **Cisco Dirsync**.
- Step 9** Log in to the Cisco Unified Communications Operating System CLI as an administrator.
- Step 10** To restart the Tomcat service, enter the command **utils service restart Cisco Tomcat**.
- Step 11** After the services have been restarted, you can add the directory agreement for SSL.

Using Third-Party CA Certificates

Cisco Unified Communications Operating System supports certificates that a third-party Certificate Authority (CA) issues with PKCS # 10 Certificate Signing Request (CSR). The following table provides an overview of this process, with references to additional documentation:

	Task	For More Information
Step 1	Generate a CSR on the server.	See the “Generating a Certificate Signing Request” section on page 6-7.
Step 2	Download the CSR to your PC.	See the “Download a Certificate Signing Request” section on page 6-7.
Step 3	Use the CSR to obtain an application certificate from a CA.	Get information about obtaining application certificates from your CA. See “Obtaining Third-Party CA Certificates” section on page 6-8 for additional notes.
Step 4	Obtain the CA root certificate.	Get information about obtaining a root certificate from your CA. See “Obtaining Third-Party CA Certificates” section on page 6-8 for additional notes.
Step 5	Upload the CA root certificate to the server.	See the “Upload a Certificate” section on page 6-4.
Step 6	Upload the application certificate to the server.	See the “Upload a Certificate” section on page 6-4.

	Task	For More Information
Step 7	If you updated the certificate for CAPF or Cisco Unified Communications Manager, generate a new CTL file.	See the <i>Cisco Unified Communications Manager Security Guide</i> .
Step 8	Restart the services that are affected by the new certificate.	<p>For all certificate types, restart the corresponding service (for example, restart the Tomcat service if you updated the Tomcat certificate). In addition, if you updated the certificate for CAPF or Cisco Unified Communications Manager, restart the TFTP service.</p> <p>Note If you updated the Tomcat certificate, you also must restart the Connection IMAP Server service in Cisco Unity Connection Serviceability.</p> <p>See the Cisco Unified Communications Manager <i>Serviceability Administration Guide</i> for information about restarting services.</p>

Generating a Certificate Signing Request

To generate a Certificate Signing Request (CSR), follow these steps:

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.
- Step 2** Click **Generate CSR**.
The Generate Certificate Signing Request dialog box opens.
- Step 3** Select the certificate name from the **Certificate Name** list.



Note For the current release of the Cisco Unified Operating System, the Directory option no longer displays in the list of Certificate Names. However, you can still upload a Directory Trust certificate from a previous release, which is required for the DirSync service to work in Secure mode.

- Step 4** Click **Generate CSR**.
-

Download a Certificate Signing Request

To download a Certificate Signing Request, follow this procedure:

Procedure

-
- Step 1** Navigate to **Security > Certificate Management**.
The Certificate List window displays.

- Step 2** Click **Download CSR**.
The Download Certificate Signing Request dialog box opens.
- Step 3** Select the certificate name from the **Certificate Name** list.
- Step 4** Click **Download CSR**.
- Step 5** In the File Download dialog box, click **Save**.
-

Obtaining Third-Party CA Certificates

To use an application certificate that a third-party CA issues, you must obtain both the signed application certificate and the CA root certificate from the CA. Get information about obtaining these certificates from your CA. The process varies among CAs.

CAPF and Cisco Unified Communications Manager CSRs include extensions that you must include in your request for an application certificate from the CA. If your CA does not support the ExtensionRequest mechanism, you must enable the X.509 extensions that are listed on the final page of the CSR generation process.

Cisco Unified Communications Operating System generates certificates in DER and PEM encoding formats and generates CSRs in PEM encoding format. It accepts certificates in DER and PEM encoding formats.

For all certificate types except CAPF, obtain and upload a CA root certificate and an application certificate on each node.

For CAPF, obtain and upload a CA root certificate and an application certificate only on the first node.

CAPF and Cisco Unified Communications Manager CSRs include extensions that you must include in your request for an application certificate from the CA. If your CA does not support the ExtensionRequest mechanism, you must enable the X.509 extensions, as follows:

- The CAPF CSR uses the following extensions:

```
X509v3 extensions:
X509v3 Key Usage:
Digital Signature, Certificate Sign
X509v3 Extended Key Usage:
TLS Web Server Authentication, IPSec End System
```

- The CSRs for Cisco Unified Communications Manager, Tomcat, and IPSec use the following extensions:

```
X509v3 Key Usage:
Digital Signature, Key Encipherment, Data Encipherment, Key Agreement
X509v3 Extended Key Usage:
TLS Web Server Authentication, TLS Web Client Authentication, IPSec End System
```

Upload the CA root certificate of the CA that signed an application certificate. If a subordinate CA signs an application certificate, you must upload the CA root certificate of the subordinate CA, not the root CA.

You upload CA root certificates and application certificates by using the same Upload Certificate dialog box. When you upload a CA root certificate, choose the certificate name with the format *certificate type-trust*. When you upload an application certificate, choose the certificate name that only includes the certificate type. For example, choose **tomcat-trust** when you upload a Tomcat CA root certificate; choose **tomcat** when you upload a Tomcat application certificate.

When you upload a CAPF CA root certificate, it gets copied to the CallManager-trust store, so you do not need to upload the CA root certificate for CallManager separately.

Monitor Certificate Expiration Dates

The system can automatically send you an e-mail when a certificate is close to its expiration date. To view and configure the Certificate Expiration Monitor, follow this procedure:

Procedure

-
- Step 1** To view the current Certificate Expiration Monitor configuration, navigate to **Security > Certificate Monitor**.
- The Certificate Monitor window displays.
- Step 2** Enter the required configuration information. See [Table 6-2](#) for a description of the Certificate Monitor Expiration fields.
- Step 3** To save your changes, click **Save**.
-

Table 6-2 Certificate Monitor Field Descriptions

Field	Description
Notification Start Time	Enter the number of days before the certificate expires that you want to be notified.
Notification Frequency	Enter the frequency for notification, either in hours or days.
Enable E-mail Notification	Select the check box to enable e-mail notification.
Email IDs	Enter the e-mail address to which you want notifications sent. Note For the system to send notifications, you must configure an SMTP host.

IPSEC Management

The following topics describe the functions that you can perform with the IPsec menu:

- [Set Up a New IPsec Policy](#)
- [Managing Existing IPsec Policies](#)



Note

IPsec does not automatically get set up between nodes in the cluster during installation.

Set Up a New IPsec Policy

To set up a new IPsec policy and association, follow this procedure:

**Note**

Because any changes that you make to an IPsec policy during a system upgrade will get lost, do not modify or create IPsec policies during an upgrade.

**Caution**

IPsec, especially with encryption, will affect the performance of your system.

Procedure

- Step 1** Navigate to **Security > IPSEC Configuration**.
The IPSEC Policy List window displays.
- Step 2** Click **Add New**.
The IPSEC Policy Configuration window displays.
- Step 3** Enter the appropriate information on the IPSEC Policy Configuration window. For a description of the fields on this window, see [Table 6-3](#).
- Step 4** To set up the new IPsec policy, click **Save**.

Table 6-3 *IPSEC Policy and Association Field Descriptions*

Field	Description
Policy Group Name	Specifies the name of the IPsec policy group. The name can contain only letters, digits, and hyphens.
Policy Name	Specifies the name of the IPsec policy. The name can contain only letters, digits, and hyphens.
Authentication Method	Specifies the authentication method.
Preshared Key	<p>Specifies the preshared key if you selected Pre-shared Key in the Authentication Name field.</p> <p>Note Pre-shared IPsec keys can contain alphanumeric characters and hyphens only, not white spaces or any other characters. If you are migrating from a Windows-based version of Cisco Unified Communications Manager, you may need to change the name of your pre-shared IPsec keys, so they are compatible with current versions of Cisco Unified Communications Manager.</p>
Peer Type	Specifies whether the peer is the same type or different.
Destination Address	Specifies the IP address or FQDN of the destination.
Destination Port	Specifies the port number at the destination.
Source Address	Specifies the IP address or FQDN of the source.
Source Port	Specifies the port number at the source.
Mode	Specifies Transport mode.
Remote Port	Specifies the port number to use at the destination.

Table 6-3 *IPSEC Policy and Association Field Descriptions (continued)*

Field	Description
Protocol	Specifies the specific protocol, or Any: <ul style="list-style-type: none"> • TCP • UDP • Any
Encryption Algorithm	From the drop-down list, choose the encryption algorithm. Choices include <ul style="list-style-type: none"> • DES • 3DES
Hash Algorithm	Specifies the hash algorithm <ul style="list-style-type: none"> • SHA1—Hash algorithm that is used in phase 1 IKE negotiation • MD5—Hash algorithm that is used in phase 1 IKE negotiation
ESP Algorithm	From the drop-down list, choose the ESP algorithm. Choices include <ul style="list-style-type: none"> • NULL_ENC • DES • 3DES • BLOWFISH • RIJNDAEL
Phase One Life Time	Specifies the lifetime for phase One, IKE negotiation, in seconds.
Phase One DH	From the drop-down list, choose the phase One DH value. Choices include: 2, 1, and 5.
Phase Two Life Time	Specifies the lifetime for phase Two, IKE negotiation, in seconds.
Phase Two DH	From the drop-down list, choose the phase Two DH value. Choices include: 2, 1, and 5.
Enable Policy	Check the check box to enable the policy.

Managing Existing IPSec Policies

To display, enable or disable, or delete an existing IPSec policy, follow this procedure:



Note

Because any changes that you make to an IPSec policy during a system upgrade will get lost, do not modify or create IPSec policies during an upgrade.

**Caution**

IPSec, especially with encryption, will affect the performance of your system.

**Caution**

Any changes that you make to the existing IPSec policies can impact your normal system operations.

Procedure

Step 1 Navigate to **Security > IPSEC Configuration**.

**Note**

To access the Security menu items, you must log in to Cisco Unified Communications Operating System Administration again by using your Administrator password.

The IPSEC Policy List window displays.

Step 2 To display, enable, or disable a policy, follow these steps:

- a. Click the policy name.

The IPSEC Policy Configuration window displays.

- b. To enable or disable the policy, use the **Enable Policy** check box.
- c. Click **Save**.

Step 3 To delete one or more policies, follow these steps:

- a. Check the check box next to the policies that you want to delete.

You can click **Select All** to select all policies or **Clear All** to clear all the check boxes.

- b. Click **Delete Selected**.