



A

activating services

BPS [51-1](#)

Unified CM Auto-Register Phone Tool [52-6](#)

adding lines

field descriptions for BAT spreadsheet [10-9](#),
[41-3](#)

field descriptions for template [3-22](#)

to existing phones [10-7](#), [41-1](#)

to existing phones using BAT
spreadsheet [10-8](#), [41-2](#)

to existing user device profiles [10-7](#), [41-1](#)

to phone template [3-4](#)

associating file format for text-based CSV
file [4-5](#), [23-1](#), [35-1](#)

auto-registration, enabled for Cisco Unified CallManager

enable auto-registration for Unified CM
Auto-Register Phone Tool [52-2](#)

auto-registration options, configuring [52-8](#)

B

BAT

application overview [1-1](#)

browser requirements [1-11](#)

configuration process overview [1-3](#)

data input files [1-2](#)

error messages [54-3](#)

installation [1-2](#)

log files location [54-3](#)

online help [1-11](#)

scheduling jobs [51-1](#)

troubleshooting [54-3](#)

troubleshooting performance [54-6](#)

version [1-11](#)

BAT.xlt, see BAT spreadsheet

BAT Performance [23](#)

BAT spreadsheet

adding lines to existing phones [10-8](#), [41-2](#)

Catalyst 6000 FXS ports [44-3](#)

field descriptions

adding lines [10-9](#), [41-3](#)

updating users [17-2](#)

user device profile [32-4](#)

IP telephony devices [3-30](#)

manager assistant associations [26-9](#)

overview [1-8](#)

phones [3-30](#)

phones with users [22-1](#)

- Unified CM Assistant custom manager assistant for proxy mode [26-11](#)
- Unified CM Assistant default manager assistant [26-9](#)
- user device profile [32-2](#)
- users [14-2](#)
- using for CSV data file [1-8](#)
- VG200 gateway for T1 CAS or T1/E1 PRI [44-1](#)
- browser requirements [1-11](#)
- Bulk Provisioning Service
 - activating BPS [51-1](#)
 - deactivating BPS [51-2](#)

C

Call Pickup Groups

- BAT considerations [49-1](#)
- BAT settings for inserting CSV file (table) [49-5](#)
- creating a CSV file (BAT.xlt) [49-2](#)
- creating custom CSV file (text-based) [A-19](#)
- CSV file settings (table) [49-4](#)
- inserting CSV file in BAT [49-4](#)
- updating existing CSV file [49-3](#)
- using query to delete call pickup groups [50-1](#)

Catalyst 6000 FXS ports

- creating CSV data file [44-3](#)
- text-based CSV file, creating [A-15](#)
- text-based CSV file format [A-16](#)

Cisco CRS

- configuring Unified CM Auto-Register Phone Tool [52-5](#)
- required for Unified CM Auto-Register Phone Tool [52-2](#)
- troubleshooting Unified CM Auto-Register Phone Tool [54-8](#)

Cisco Customer Response Solutions, see Cisco CRS

Cisco Unified CallManager

- enable auto-registration for Unified CM Auto-Register Phone Tool [52-2](#)
- inserting
 - CTI ports [6-1, 16-1, 37-1, 44-1](#)

- H.323 clients [6-1, 16-1, 37-1, 44-1](#)

- phones [6-1, 16-1, 37-1, 44-1](#)

- phones with users [25-1](#)

- Unified CM Assistant manager-assistant associations [27-1](#)

- users [16-1](#)

- VG200 gateway (FXS or FXO) [44-4](#)

- VG200 gateway (T1 CAS or T1/E1 PRI) [44-4](#)

- overview of inserting records [1-10](#)

Cisco Unified CallManager Assistant, see Unified CM Assistant

Cisco Unified CM Assistant Configuration Wizard [26-2](#)

Cisco Unified IP-IVR

- required for Unified CM Auto-Register Phone Tool [52-2](#)

Client Matter Codes

- BAT considerations [47-2](#)
- BAT settings for inserting CSV file (table) [47-7](#)
- configuration checklist (table) [47-1](#)
- creating a CSV file (BAT.xlt) [47-3](#)
- creating custom CSV file (text-based) [A-16](#)
- CSV file settings (table) [47-5](#)
- deleting code settings (BAT) [48-1](#)
- inserting CSV file in BAT [47-6](#)
- updating existing CSV file [47-4](#)

CMC

- text-based CSV file, updating [A-18](#)

configuring Cisco Unified CallManager records, process [1-3](#)

copying

- file format for text-based CSV [34-3](#)
- file format for text-based CSV file [4-3](#)
- phone template [3-8](#)
- template [33-4](#)
- user template [15-3](#)

CPG

- text-based CSV file, updating [A-20](#)

CSV, comma separated values text file [1-2, A-1](#)

CSV, text-based

- Catalyst 6000 FXS ports, creating [A-15](#)

- Catalyst 6000 FXS ports format [A-16](#)
- CMC
 - options [47-4](#)
 - updating [A-18](#)
- CPG
 - options [49-3](#)
 - updating [A-20](#)
- CTI ports format [A-3](#)
- CTI ports-users format [A-3](#)
- FAC
 - options [47-4](#)
 - updating [A-19](#)
- FXO or FXS ports format [A-14](#)
- H.323 clients format [A-3](#)
- H.323 client-users format [A-3](#)
- manager assistant associations
 - creating [A-12](#)
 - custom format [A-13](#)
- manager assistant default formats [A-12](#)
- overview [A-1](#)
- phones
 - creating [A-1](#)
 - export file, all details [A-4](#)
 - options [4-1](#)
 - tips for creating [A-2](#)
 - with users format [A-2](#)
- T1 CAS, T1/E1 PRI format [A-14](#)
- user device profile format [A-9](#)
- user device profile options [34-1](#)
- user device profiles
 - creating [A-9](#)
 - export file [A-11](#)
 - two lines format [A-10](#)
- users
 - creating [A-6](#)
 - format [A-7](#)
 - updating [A-8](#)
- VG200 gateways, creating [A-13](#)
- CSV data file

- adding new devices [1-5](#)
- overview [1-5](#)
- updating existing devices [1-6](#)
- using BAT spreadsheet (BAT.xlt) [1-8](#)
- CTI ports
 - deleting [8-1, 13-1, 38-1](#)
 - dummy MAC address, using [6-2, 25-1, 37-2](#)
 - text-based CSV format [A-3](#)
- CTI ports-users
 - text-based CSV format [A-3](#)
- custom file
 - deleting phones [8-3, 38-2](#)
 - deleting Unified CM Assistant managers [29-2, 30-2](#)
 - deleting users [18-2](#)
 - updating phones [7-2](#)
 - using [1-6](#)
 - using to reset password and PIN [20-3](#)

D

- deleting
 - call pickup groups [50-1](#)
 - file format for text-based CSV file [4-5, 34-4](#)
 - manager-assistant associations [28-1](#)
 - phones using custom files [8-3, 38-2](#)
 - phones using query [8-1, 13-1](#)
 - phone template [3-9](#)
 - template [33-5](#)
 - Unified CM Assistant assistants [30-1](#)
 - Unified CM Assistant managers [29-1](#)
 - user device profiles [38-1](#)
 - users [18-1](#)
 - user template [15-3](#)
 - VG200 gateway [45-1](#)
- dialed number analyzer
 - trace configuration files [54-1](#)
- directory number
 - finding secure directory numbers from Unified CM Auto-Register Phone Tool [52-9](#)

- lifting restrictions [52-10](#)
- restricting from Unified CM Auto-Register Phone Tool [52-9](#)
- securing from Unified CM Auto-Register Phone Tool [52-9](#)
- downloading phone configuration using Unified CM Auto-Register Phone Tool [53-2](#)
- dummy MAC address [3-31](#), [6-2](#), [25-1](#), [37-2](#)
 - generate a list [12-5](#)

E

- E1 PRI
 - creating CSV file for VG200 gateway [44-1](#)
 - field descriptions for VG200 gateway template [43-19](#)
 - text-based CSV file format [A-14](#)
- E1 PRI ports [43-7](#)
- error messages, BAT [54-3](#)
- exported fields
 - all phone details [9-2](#)
 - all user device profile details [39-1](#)
 - default phone details [9-2](#)
 - default user device profile details [39-2](#)
- exporting
 - fields
 - all phone details [9-2](#)
 - all user device profile details [39-1](#)
 - default phone details [9-2](#)
 - default user device profile details [39-2](#)
 - moving records from one Cisco Unified CallManager to another [9-1](#)
 - phone records options [9-1](#)
 - phones with more than one user [9-5](#)
 - steps for exporting phone records [9-3](#)
 - user device profile options [39-3](#)
 - user device profile records format [39-1](#)
 - user records format [19-1](#)
 - user records options [19-1](#)
 - using export files [1-6](#)

F

- FAC
 - text-based CSV file, updating [A-19](#)
- field descriptions
 - adding or updating lines [3-22](#)
- BAT spreadsheet
 - adding lines [10-9](#), [41-3](#)
 - updating users [17-2](#)
 - user device profile [32-4](#)
- phone template [3-9](#)
- updating lines [10-3](#), [40-3](#)
- updating users with BAT spreadsheet [17-2](#)
- user device profile template [33-2](#)
- user template [15-4](#)
- VG200 gateway - T1/E1 PRI template [43-19](#)
- VG200 gateway - T1 CAS template [43-16](#)
- file format for text-based CSV file
 - associating [4-5](#), [23-1](#), [35-1](#)
 - copying [4-3](#), [34-3](#)
 - creating phone [4-2](#)
 - creating user device profile [34-2](#)
 - deleting [4-5](#), [34-4](#)
 - finding [4-2](#), [34-1](#)
 - modifying [4-4](#), [34-4](#)
 - overview [1-6](#)
- finding
 - file [2-1](#)
 - gateway templates [43-2](#)
 - jobs [51-3](#)
 - phone file format [4-2](#)
 - phone template [3-2](#)
 - secure directory numbers from Unified CM Auto-Register Phone Tool [52-9](#)
 - UDP file format for text-based CSV [34-1](#)
 - UDP template [33-1](#)
 - user template [15-1](#)
- Forced Authorization Codes
 - BAT considerations [47-2](#)

BAT settings for inserting CSV file (table) [47-7](#)
 configuration checklist (table) [47-1](#)
 creating a CSV file (BAT.xlt) [47-3](#)
 creating custom CSV file (text-based) [A-16](#)
 CSV file settings (table) [47-5](#)
 deleting code settings (BAT) [48-1](#)
 inserting CSV file in BAT [47-6](#)
 updating existing CSV file [47-4](#)

FXO

inserting VG200 gateway to Cisco Unified
 CallManager [44-4](#)
 text-based CSV file format for VG200 gateway [A-14](#)

FXO ports [43-6](#)

FXS

Catalyst 6000 ports
 creating CSV data file [44-3](#)
 text-based CSV format [A-16](#)
 creating template for Catalyst 6000 ports [43-8](#)
 VG200 gateways
 inserting to Cisco Unified CallManager [44-4](#)
 text-based CSV file format [A-14](#)

G

gateway template

adding or editing [43-3](#)
 Catalyst 6000 FXS ports
 creating template [43-8](#)
 configuration settings [43-9](#)
 finding [43-2](#)
 port configuration settings (table) [43-32](#)
 POTS port configuration settings (table) [43-33](#)
 VG200 gateway template
 creating template [43-4](#)
 FXO ports, adding [43-6](#)
 T1-CAS ports, adding [43-7](#)
 T1 PRI or E1 PRI ports, adding [43-7](#)

H

H.323 clients

deleting [8-1, 13-1, 38-1](#)
 text-based CSV format [A-3](#)

H.323 client-users

text-based CSV format [A-3](#)

help, online [1-11](#)

I

inserting records to Cisco Unified CallManager,
 overview [1-10](#)

installing

Unified CM Auto-Register Phone Tooloverview [52-4](#)
 Unified CM Auto-Register Phone Tool
 prerequisites [52-4](#)

instructions, Unified CM Auto-Register Phone Tool for
 end-users [53-2](#)

IP telephony devices

supported with BAT [15-1](#)

IP telephony devices, see phones

J

jobs

activating BPS [51-1](#)
 deactivating BPS [51-2](#)
 finding [51-3](#)
 scheduling [51-4](#)
 viewing log files [51-6](#)

L

language prompts for Unified CM Auto-Register Phone
 Tool [52-4](#)

lines

adding or updating on template [3-4](#)
 field descriptions in template for adding or
 updating [3-22](#)

- master phone template [1-4](#)
- maximum number [3-5](#)
- updating to user device profiles [40-1](#)

log files

- BAT [54-3](#)
- file naming convention [54-3](#)
- report log files [12-6, 21-2, 31-2, 46-2](#)
- viewing job log files [51-6](#)

M

- master phone template [1-4](#)

MGCP

- T1-CAS ports [43-7](#)
- T1 PRI or E1 PRI ports, adding [43-7](#)

modifying

- file format for text-based CSV [34-4](#)
- file format for text-based CSV file [4-4](#)
- phone template [3-7](#)
- user template [15-3](#)

N

- NM-1V [43-10](#)
- NM-2V [43-10](#)
- NM-HDV [43-10](#)

O

- overriding template values [1-5](#)

overview

- BAT application [1-1](#)
- BAT spreadsheet [1-8](#)
- Cisco Unified CM Assistant [26-1](#)
- CSV data file [1-5](#)
- data input files [1-2](#)
- file formats for text-based CSV files [1-6](#)
- inserting records to Cisco Unified CallManager [1-10](#)

- installation [1-2](#)
- reports [12-1, 21-1, 42-1](#)
- templates [1-4](#)
- text-based CSV files [A-1](#)
- Unified CM Auto-Register Phone Tool tool [52-1](#)
- user device profiles [32-1](#)
- users [14-1](#)
- validating [1-9](#)

P

passwords

- resetting [20-1](#)

phones

- adding
 - IP services [3-5](#)
 - lines [3-4](#)
 - lines to existing [10-7, 41-1](#)
 - speed dial settings [3-6, 3-7](#)
 - with users [22-1](#)
- configuring CAPF [3-43, 15-6](#)
- creating text-based CSV file [A-1](#)
- deleting [8-1, 13-1, 38-1](#)
- dummy MAC address, using [3-31, 6-2, 25-1, 37-2](#)
- dummy MAC addresses list [12-5](#)
- export file with all details [A-4](#)
- exporting records options [9-1](#)
- exporting records steps [9-3](#)
- generating reports [12-1](#)
- insert to Cisco Unified CallManager [6-1, 16-1, 37-1, 44-1](#)
- proxy mode for Unified CM Assistant [26-2](#)
- reloading configurations [52-3](#)
- report options [12-3](#)
- template
 - copying [3-8](#)
 - creating new [3-4](#)
 - deleting [3-9](#)
 - field descriptions [3-9](#)
 - finding template [3-2](#)

- for IP telephony devices [3-4](#)
- modifying [3-7](#)
- Unified CM Assistant assistant [26-4](#)
- Unified CM Assistant manager configuration [26-4](#)
- updating [7-1, 17-1, 18-1](#)
- updating with custom file [7-2](#)
- updating with query [7-1](#)
- using Unified CM Auto-Register Phone Tool to configure [52-2](#)
 - enable auto-registration [52-2](#)
 - validating records [5-1, 36-1](#)
- phones with users
 - inserting to Cisco Unified CallManager [25-1](#)
 - text-based CSV format [A-2](#)
 - using BAT spreadsheet [22-1](#)
 - validating records [24-1](#)
- PINs
 - resetting [20-1](#)
- prerequisites
 - Unified CM Auto-Register Phone Tool [52-4](#)

Q

- query
 - customizing a filter [1-6](#)
 - deleting call pickup groups [50-1](#)
 - deleting phones [8-1, 13-1](#)
 - deleting Unified CM Assistant managers [29-1, 30-1](#)
 - deleting users [18-1](#)
 - updating lines [40-1](#)
 - updating phones [7-1](#)
 - using to reset password and PIN [20-1](#)

R

- reports
 - dummy MAC addresses [12-5](#)
 - overview [12-1, 21-1, 42-1](#)
 - phone options [12-3](#)

- phones [12-1](#)
- Unified CM Assistant manager assistant [31-1](#)
- user device profile [42-1](#)
- users [21-1](#)
- VG200 gateway [46-1](#)
- resetting password and PIN
 - using custom file [20-3](#)
 - using query [20-1](#)
- resetting phones
 - after update [11-1](#)
 - using custom file [11-2](#)
 - using query [11-1](#)
- restarting phones
 - after update [11-1](#)
 - using custom file [11-2](#)
 - using query [11-1](#)
- retaining user records when updating [17-1](#)

S

- securing directory numbers from Unified CM Auto-Register Phone Tool [52-4, 52-9](#)
- services, adding or updating [3-5](#)
- speed dial settings, adding or updating [3-6, 3-7](#)
- sub-unit [43-4](#)

T

- T1 CAS
 - creating CSV data file for VG200 gateway [44-1](#)
 - field descriptions for VG200 template [43-16](#)
 - text-based CSV file format [A-14](#)
- T1-CAS ports, adding [43-7](#)
- T1 PRI
 - creating CSV file for VG200 gateway [44-1](#)
 - field descriptions for VG200 gateway template [43-19](#)
 - text-based CSV file format [A-14](#)
- T1 PRI ports [43-7](#)
- templates

- adding or updating IP services [3-5](#)
- adding or updating lines [3-4](#)
- adding or updating speed dial settings [3-6, 3-7](#)
- BAT template overview [1-4](#)
- copying [33-4](#)
- copying phone [3-8](#)
- copying users [15-3](#)
- deleting [33-5](#)
- deleting phone [3-9](#)
- deleting users [15-3](#)
- field descriptions
 - adding or updating lines [3-22](#)
 - phone [3-9](#)
 - user device profiles [33-2](#)
 - users [15-4](#)
 - VG200 gateway - T1 CAS gateway [43-16](#)
- finding [33-1](#)
- master phone [1-4](#)
- modifying [33-4](#)
- modifying phone [3-7](#)
- modifying users [15-3](#)
- overriding values [1-5](#)
- template type
 - Catalyst 6000 FXS ports [43-8](#)
 - IP telephony devices [3-4](#)
 - phones [3-4](#)
 - Unified CM Assistant assistant for proxy mode [26-3](#)
 - Unified CM Assistant manager for proxy mode [26-2](#)
 - user device profiles [33-2](#)
 - users [15-2](#)
 - VG200 gateway template [43-4](#)
- trace configuration files
 - viewing [54-1](#)
- troubleshooting
 - BAT [54-3](#)
 - BAT log files [54-3](#)
 - BAT performance [54-6](#)
 - Unified CM Auto-Register Phone Tool [54-7](#)
- troubleshooting message
 - BAT.xlt spreadsheet does not work with Excel XP (Office XP) [54-6](#)
 - BAT excel sheet does not respond to actions [54-4](#)
 - BAT menu does not display in Cisco Unified CallManager [54-3](#)
 - BAT spreadsheet gives a compilation error while exporting data [54-4](#)
 - cannot access complete BAT functionality [54-3](#)
 - CSV data files do not match phone template/sample file [54-4](#)
 - export to BAT does not work in BAT.xlt file [54-4](#)
 - job does not display in find and list job window [54-5](#)
 - jobs remain in hold state [54-5](#)
 - jobs remain in pending state [54-5](#)
 - MAC address values are not allowed in CSV file if dummy MAC address option selected [54-6](#)
 - port number not configured in template [54-6](#)
 - uploaded csv file does not display [54-5](#)
 - when Cisco CRS starts, JTAPI shows partial service or out of service [54-8](#)
 - when dialing Unified CM Auto-Register Phone Tool number, caller hears busy [54-7](#)

U

- UDP, see user device profiles
- Unified CM Assistant
 - assistant template for proxy mode [26-3](#)
 - creating CSV data file [26-9](#)
 - deleting assistants
 - described [30-1](#)
 - using custom file [30-2](#)
 - deleting manager-assistant associations [28-1](#)
 - deleting managers
 - described [29-1](#)
 - using custom file [29-2](#)
 - using query [29-1, 30-1](#)
 - generating reports [31-1](#)
 - inserting manager-assistant associations [27-1](#)
 - manager and assistant line configurations, proxy mode [26-3](#)

- manager and assistant shared line configurations [26-8](#)
- manager template for proxy mode [26-2](#)
- overview [26-1](#)
- phones
 - assistant configuration options [26-4](#)
 - manager configuration options [26-4](#)
 - proxy line example [26-5](#)
 - proxy lines on existing [26-6](#)
 - proxy lines on new [26-6](#)
 - proxy mode [26-2](#)
 - shared line example [26-8](#)
 - shared line mode [26-7](#)
- setting up phones and lines [26-1](#)
- text-based CSV file, creating [A-12](#)
- text-based CSV file custom format [A-13](#)
- Unified CM Assistant Configuration Wizard [26-2](#)
- Unified CM Auto-Register Phone Tool
 - activating Unified CM Auto-Register Phone Tool service [52-6](#)
 - Cisco CRS required [52-2](#)
 - Cisco Unified IP-IVR required [52-2](#)
 - configuring auto-registration options [52-8](#)
 - configuring on Cisco CRS server [52-5](#)
 - finding secure directory numbers [52-9](#)
 - installation overview [52-4](#)
 - instructions for end-users [53-2](#)
 - language prompts [52-4](#)
 - removing [53-2](#)
 - lifting restriction on directory numbers [52-10](#)
 - log files location [54-7](#)
 - overview [52-1](#)
 - reloading configurations [52-3](#)
 - requirements [52-2](#)
 - restarting service [52-7](#)
 - restricting directory numbers [52-9](#)
 - securing directory numbers [52-4, 52-9](#)
 - setting options for using [52-7](#)
 - starting service [52-7](#)
 - stopping service [52-7](#)
 - troubleshooting [54-7](#)
 - uninstalling [52-6](#)
- uninstalling
 - Unified CM Auto-Register Phone Tool [52-6](#)
- updating
 - lines to user device profiles [40-1](#)
 - phone configuration using Unified CM Auto-Register Phone Tool [53-2](#)
- updating lines
 - field descriptions [10-3, 40-3](#)
- uploading/downloading file
 - delete [2-3](#)
 - download [2-2](#)
 - finding [2-1](#)
 - upload [2-3](#)
- user device profiles
 - adding lines to existing [10-7, 41-1](#)
 - BAT spreadsheet
 - field descriptions [32-4](#)
 - using [32-2](#)
 - creating CSV data file [32-2](#)
 - deleting [38-1](#)
 - export file format [39-1](#)
 - export file with all details [A-11](#)
 - exporting record options [39-3](#)
 - overview [32-1](#)
 - removing [38-1](#)
 - reports, generating [42-1](#)
 - steps for adding [32-1](#)
 - template
 - copying [33-4](#)
 - creating [33-2](#)
 - deleting [33-5](#)
 - finding [33-1](#)
 - modifying [33-4](#)
 - text-based CSV file, creating [A-9](#)
 - text-based CSV file format [A-9](#)
 - updating lines [40-1](#)
 - validating records [36-1](#)

- users
 - adding overview [14-1](#)
 - adding with phones [22-1](#)
 - creating CSV data file [14-2](#)
 - deleting [18-1](#)
 - using custom file [18-2](#)
 - using query [18-1](#)
 - exported records format [19-1](#)
 - exporting records [19-1](#)
 - field descriptions for updating with BAT spreadsheet [17-2](#)
 - generating reports [21-1](#)
 - inserting to Cisco Unified CallManager [16-1](#)
 - resetting passwords and PINs [20-1](#)
 - retaining stored values [17-1](#)
 - template
 - copying [15-3](#)
 - creating new [15-2](#)
 - deleting [15-3](#)
 - field descriptions [15-4](#)
 - finding [15-1](#)
 - for users [15-2](#)
 - modifying [15-3](#)
 - text-based CSV file, creating [A-6](#)
 - text-based CSV file, updating [A-8](#)
 - text-based CSV format [A-7](#)
 - updating [17-1](#)
 - updating users field descriptions [17-2](#)
- users with phones
 - inserting to Cisco Unified CallManager [25-1](#)
 - using BAT spreadsheet [22-1](#)
 - validating records [24-1](#)
 - phone records [5-1, 36-1](#)
 - user device profile records [36-1](#)
- version, finding [1-11](#)
- VG200 gateway
 - creating CSV data file for T1 CAS or T1/E1 PRI [44-1](#)
 - creating template [43-4](#)
 - creating text-based CSV file [A-13](#)
 - deleting gateway [45-1](#)
 - field descriptions
 - T1/E1 PRI template [43-19](#)
 - T1 CAS template [43-16](#)
 - generating reports [46-1](#)
 - inserting to Cisco Unified CallManager (FXS or FXO) [44-4](#)
 - inserting to Cisco Unified CallManager (T1 CAS or T1/E1 PRI) [44-4](#)
- VG200 gateway template
 - FXO ports, adding [43-6](#)
- VIC-2FXO [43-5](#)
- VIC-2FXS [43-4](#)
- viewing trace configuration files [54-1](#)
- VWIC-1MFT-E1 [43-5](#)
- VWIC-1MFT-T1 [43-5](#)
- VWIC-2MFT-E1 [43-5](#)
- VWIC-2MFT-T1 [43-5](#)

V

- validating
 - options [1-9](#)
 - overview [1-9](#)
 - phone and user records [24-1](#)