



## Performance Objects and Counters

---

This chapter, which provides an overview of Cisco CallManager-related objects and counters, contains information on the following topics:

- [Working with Performance Objects and Counters, page 6-1](#)
- [Using RTMT for Performance Monitoring, page 6-64](#)
- [Category Tabs, page 6-65](#)
- [Sample Rate, page 6-65](#)
- [Adding Counters to Monitor, page 6-66](#)
- [Alert Notification for Counters, page 6-66](#)
- [Zoom Counter, page 6-66](#)
- [Counter Properties, page 6-66](#)
- [Understanding Perfmon Logs, page 6-67](#)
- [Troubleshooting Guide for Cisco CallManager, page 6-67](#)
- [Where to Find More Information, page 6-67](#)

## Working with Performance Objects and Counters

Cisco CallManager directly updates Performance counters (called PerfMon counters), which are call-processing-related counters. The counters contain simple, useful counts such as number of registered phones, number of active calls, and number of available conference bridge resources.

The Cisco CallManager object contains most of the performance counters, and these counters have only one instance. The instance-based counters that belong to the other objects can have zero or more instances. For example, if two phones are registered to Cisco CallManager, two instances of each counter that belong to the Cisco phones object exist.

For information on specific counters, click the blue text in the following list to go to the object:

- [Cisco Analog Access, page 6-3](#)
- [Cisco Annunciator Device, page 6-4](#)
- [Cisco CallManager, page 6-4](#)
- [Cisco CallManager Attendant Console, page 6-12](#)
- [Cisco CallManager System Performance, page 6-13](#)
- [Cisco CTManager, page 6-16](#)

- Cisco Dual-Mode Mobility, page 6-17
- Cisco Extension Mobility, page 6-18
- Cisco Gatekeeper, page 6-19
- Cisco H.323, page 6-19
- Cisco Hunt Lists, page 6-20
- Cisco HW Conference Bridge Device, page 6-21
- Cisco IP Manager Assistant, page 6-22
- Cisco Lines, page 6-22
- Cisco Locations, page 6-23
- Cisco Media Streaming Application, page 6-24
- Cisco Messaging Interface, page 6-27
- Cisco MGCP FXO Device, page 6-28
- Cisco MGCP FXS Device, page 6-28
- Cisco MGCP Gateways, page 6-29
- Cisco MGCP PRI Device, page 6-29
- Cisco MGCP T1 CAS Device, page 6-30
- Cisco Music On Hold (MOH) Device, page 6-31
- Cisco MTP Device, page 6-32
- Cisco Phones, page 6-33
- Cisco Presence Feature, page 6-33
- Cisco QSIG Features, page 6-34
- Cisco SIP, page 6-34
- Cisco SIP Stack, page 6-35
- Cisco SW Conf Bridge Device, page 6-43
- Cisco TFTP Server, page 6-44
- Cisco Tomcat Connector, page 6-48
- Cisco Tomcat JVM, page 6-50
- Cisco Tomcat Web Application, page 6-51
- Cisco Transcode Device, page 6-52
- Cisco Video Conference Bridge, page 6-52
- Cisco WebDialer, page 6-53
- Cisco WSM Connector, page 6-54
- Database Change Notification Client, page 6-54
- Database Change Notification Server, page 6-55
- Database Change Notification Subscription, page 6-55
- Database Layer Monitor, page 6-55
- Database Local DSN, page 6-56
- DB User Host Information Counters, page 6-56

- [Enterprise Replication DBSpace Monitors, page 6-56](#)
- [Enterprise Replication Perfmon Counters, page 6-56](#)
- [IP, page 6-57](#)
- [Memory, page 6-58](#)
- [Network Interface, page 6-59](#)
- [Number of Replicates Created and State of Replication, page 6-60](#)
- [Partition, page 6-60](#)
- [Process, page 6-61](#)
- [Processor, page 6-62](#)
- [System, page 6-63](#)
- [TCP, page 6-63](#)
- [Thread, page 6-64](#)

**Tip**

For the latest performance monitoring counters, objects, and counter descriptions that are available for Cisco CallManager, access the performance monitoring counters in the Real-Time Monitoring Tool. In RTMT, you can review a counter description, as described in the [“Displaying a Counter Description” section on page 9-9](#).

## Cisco Analog Access

The Cisco Analog Access object provides information about registered Cisco Analog Access gateways. [Table 6-1](#) contains information about Cisco Analog Access counters.

**Table 6-1** *Cisco Analog Access*

Counters	Counter Descriptions
OutboundBusyAttempts	This counter represents the total number of times that Cisco CallManager attempts a call through the Analog Access gateway when all ports were busy.
PortsActive	This counter represents the number of ports that are currently in use (active). A port appears active when a call is in progress on that port.
PortsOutOfService	This counter represents the number of ports that are currently out of service. Counter applies only to loop-start and ground-start trunks.

## Cisco Annunciator Device

The Cisco Annunciator Device object provides information about registered Cisco annunciator devices. [Table 6-2](#) contains information about Cisco Annunciator counters.

**Table 6-2** *Cisco Annunciator Device*

Counters	Counter Descriptions
OutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate an annunciator resource from an annunciator device and failed; for example, because all resources were already in use.
ResourceActive	This counter represents the total number of annunciator resources that are currently active (in use) for an annunciator device.
ResourceAvailable	This counter represents the total number of resources that are not active and are still available to be used at the current time for the annunciator device.
ResourceTotal	This counter represents the total number of annunciator resources that are configured for an annunciator device.

## Cisco CallManager

The Cisco CallManager object provides information about calls, applications, and devices that are registered with the Cisco CallManager. [Table 6-3](#) contains information about Cisco CallManager counters.

**Table 6-3** *Cisco CallManager*

Counters	Counter Descriptions
AnnunciatorOutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate an annunciator resource from those that are registered to a Cisco CallManager when none were available.
AnnunciatorResourceActive	This counter represents the total number of annunciator resources that are currently in use on all annunciator devices that are registered with a Cisco CallManager.
AnnunciatorResourceAvailable	This counter represents the total number of annunciator resources that are not active and are currently available.
AnnunciatorResourceTotal	This counter represents the total number of annunciator resources that are provided by all annunciator devices that are currently registered with Cisco CallManager.
AuthenticatedCallsActive	This counter represents the number of authenticated calls that are currently active (in use) on Cisco CallManager. An authenticated call designates one in which all the endpoints that are participating in the call are authenticated. An authenticated phone uses the Transport Layer Security (TLS) authenticated Skinny protocol signaling with Cisco CallManager.

**Table 6-3 Cisco CallManager (continued)**

Counters	Counter Descriptions
AuthenticatedCallsCompleted	This counter represents the number of authenticated calls that connected and subsequently disconnected through Cisco CallManager. An authenticated call designates one in which all the endpoints that are participating in the call are authenticated. An authenticated phone uses the TLS authenticated Skinny protocol signaling with Cisco CallManager.
AuthenticatedPartiallyRegisteredPhone	This counter represents the number of partially registered, authenticated SIP phones.
AuthenticatedRegisteredPhones	This counter represents the total number of authenticated phones that are registered to Cisco CallManager. An authenticated phone uses the TLS authenticated Skinny protocol signaling with Cisco CallManager.
BRChannelsActive	This counter represents the number of BRI voice channels that are currently in an active call on this Cisco CallManager.
BRISpansInService	This counter represents the number of BRI spans that are currently available for use.
CallManagerHeartBeat	This counter represents the heartbeat of Cisco CallManager. This incremental count indicates that Cisco CallManager is up and running. If the count does not increment, that indicates that Cisco CallManager is down.
CallsActive	This counter represents the number of voice or video streaming connections that are currently in use (active); in other words, the number of calls that actually have a voice path that is connected on Cisco CallManager.
CallsAttempted	This counter represents the total number of attempted calls. An attempted call occurs any time that a phone goes off hook and back on hook, regardless of whether any digits were dialed, or whether it connected to a destination. The system considers some call attempts during feature operations (such as transfer and conference) to be attempted calls.
CallsCompleted	This counter represents the number of calls that were actually connected (a voice path or video stream was established) through Cisco CallManager. This number increases when the call terminates.
CallsInProgress	This counter represents the number of voice or video calls that are currently in progress on Cisco CallManager, including all active calls. When a phone goes off hook, this action creates a call in progress until it goes back on hook. When all voice or video calls that are in progress are connected, the number of CallsInProgress represents the number of CallsActive.
EncryptedCallsActive	This counter represents the number of encrypted calls that are currently active (in use) on this Cisco CallManager. An encrypted call represents one in which all the endpoints that are participating in the call are encrypted.

**Table 6-3** *Cisco CallManager (continued)*

Counters	Counter Descriptions
EncryptedCallsCompleted	This counter represents the number of encrypted calls that were connected and subsequently disconnected through this Cisco CallManager. An encrypted call represents one in which all the endpoints that are participating in the call are encrypted.
EncryptedPartiallyRegisteredPhones	This counter represents the number of partially registered, encrypted SIP phones.
EncryptedRegisteredPhones	This counter represents the total number of encrypted phones that are registered on this Cisco CallManager.
FXOPortsActive	This counter represents the number of FXO ports that are currently in use (active) on a Cisco CallManager.
FXOPortsInService	This counter represents the number of FXO ports that are currently available for use in the system.
FXSPortsActive	This counter represents the number of FXS ports that are currently in use (active) on a Cisco CallManager.
FXSPortsInService	This counter represents the number of FXS ports that are currently available for use in the system.
HuntListsInService	This counter represents the number of hunt lists that are currently in service on Cisco CallManager.
HWConferenceActive	This counter represents the total number of hardware conference resources that are provided by all hardware conference bridge devices that are currently registered with Cisco CallManager.
HWConferenceCompleted	This counter represents the total number of conferences that used a hardware conference bridge (hardware-based conference devices such as Cisco Catalyst 6000, Cisco Catalyst 4000, Cisco VG200, Cisco series 26xx and 36xx) that is allocated from Cisco CallManager and that have completed, which means that the conference bridge has been allocated and released. A conference activates when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.
HWConferenceOutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate a hardware conference resource from those that are registered to a Cisco CallManager when none was available.
HWConferenceResourceActive	This counter represents the total number of conference resources that are in use on all hardware conference devices (such as Cisco Catalyst 6000, Catalyst 4000, Cisco VG200, Cisco series 26xx and 36xx) that are registered with Cisco CallManager. System considers conference to be active when one or more calls are connected to a bridge.

**Table 6-3 Cisco CallManager (continued)**

Counters	Counter Descriptions
HWConferenceResourceAvailable	This counter represents the number of hardware conference resources that are not in use and that are available to be allocated on all hardware conference devices (such as Cisco Catalyst 6000, Cisco Catalyst 4000, Cisco VG200, Cisco series 26xx and 36xx) that are allocated from Cisco CallManager and that have been completed, which means that the conference bridge has been allocated and released. A conference activates when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.
HWConferenceResourceTotal	This counter represents the number of active conferences on all hardware conference devices that are registered with Cisco CallManager.
InitializationState	<p>This counter represents the current initialization state of Cisco CallManager. Cisco CallManager includes the following initialization state values:</p> <p>1-Database; 2-Regions; 3-Locations; 4-Calling Search Space; 5-Time Of Day; 6-AAR Neighborhoods; 7-Digit Analysis; 8-Route Plan; 9-Call Control; 10-Supplementary Services; 11-Directory; 12-SDL Link; 13-Device; 100-Initialization Complete.</p> <p>Not all states displays when this counter is used. This does not indicate that an error occurred; it simply indicates that the state(s) initialized and completed within the refresh period of the performance monitor.</p>
LocationOutOfResources	This counter represents the total number of times that a call through Locations failed due to the lack of bandwidth.
MOHMulticastResourceActive	This counter represents the total number of multicast MOH resources that are currently in use (active) on all MOH servers that are registered with a Cisco CallManager.
MOHMulticastResourceAvailable	This counter represents the total number of active multicast MOH connections that are not being used on all MOH servers that are registered with a Cisco CallManager.
MOHOutOfResources	This counter represents the total number of times that the Media Resource Manager attempted to allocate an MOH resource when all available resources on all MOH servers that are registered with a Cisco CallManager were already active.
MOHTotalMulticastResources	This counter represents the total number of multicast MOH resources or connections that are provided by all MOH servers that are currently registered with a Cisco CallManager.
MOHTotalUnicastResources	This counter represents the total number of unicast MOH resources or streams that are provided by all MOH servers that are currently registered with Cisco CallManager. Each MOH unicast resource uses one stream.

**Table 6-3 Cisco CallManager (continued)**

Counters	Counter Descriptions
MOHUnicastResourceActive	This counter represents the total number of unicast MOH resources that are currently in use (active) on all MOH servers that are registered with Cisco CallManager. Each MOH unicast resource uses one stream.
MOHUnicastResourceAvailable	This counter represents the total number of unicast MOH resources that are currently available on all MOH servers that are registered with Cisco CallManager. Each MOH unicast resource uses one stream.
MTPOutOfResources	This counter represents the total number of times Cisco CallManager attempted but failed to allocate an MTP resource from one MTP device that is registered with Cisco CallManager. This also means that no transcoders were available to act as MTPs.
MTPResourceActive	This counter represents the total number of MTP resources that are currently in use (active) on all MTP devices that are registered with a Cisco CallManager. Each MTP resource uses two streams. An MTP in use represents one MTP resource that has been allocated for use in a call.
MTPResourceAvailable	This counter represents the total number of MTP resources that are not in use and are available to be allocated on all MTP devices that are registered with Cisco CallManager. Each MTP resource uses two streams. An MTP in use represents one MTP resource that has been allocated for use in a call.
MTPResourceTotal	This counter represents the total number of media termination point (MTP) resources that are provided by all MTP devices that are currently registered with Cisco CallManager.
PartiallyRegisteredPhone	This counter represents the number of partially registered SIP phones.
PRChannelsActive	This counter represents the number of PRI voice channels that are in an active call on a Cisco CallManager.
PRISpansInService	This counter represents the number of PRI spans that are currently available for use.
RegisteredAnalogAccess	This counter represents the number of registered Cisco analog access gateways that are registered with system. The count does not include the number of Cisco analog access ports.
RegisteredHardwarePhones	This counter represents the number of Cisco hardware IP phones (for example, Cisco IP Phone models 7960, 7940, 7910, and so on.) that are currently registered in the system.
RegisteredMGCPGateway	This counter represents the number of MGCP gateways that are currently registered in the system.
RegisteredOtherStationDevices	This counter represents the number of station devices other than Cisco hardware IP phones that are currently registered in the system (for example, Cisco IP SoftPhone, CTI port, CTI route point, Cisco voice-mail port).



**Table 6-3 Cisco CallManager (continued)**

Counters	Counter Descriptions
SIPLineServerAuthorizationChallenges	This counter represents the number of authentication challenges for incoming SIP requests that the Cisco CallManager server issued to SIP phones. An authentication challenge occurs when a SIP phone with Digest Authentication enabled sends a SIP line request to Cisco CallManager.
SIPLineServerAuthorizationFailures	This counter represents the number of authentication challenge failures for incoming SIP requests from SIP phones to the Cisco CallManager server. An authentication failure occurs when a SIP phone with Digest Authentication enabled sends a SIP line request with bad credentials to Cisco CallManager.
SIPTrunkApplicationAuthorization	This counter represents the number of application-level authorization checks for incoming SIP requests that the Cisco CallManager server issued to SIP trunks. An application-level authorization check occurs when the Cisco CallManager system compares an incoming SIP request to the application-level settings on the SIP Trunk Security Profile window in Cisco CallManager Administration.
SIPTrunkApplicationAuthorizationFailures	This counter represents the number of application-level authorization failures for incoming SIP requests that occurred on Cisco CallManager SIP trunks. An application-level authorization failure occurs when Cisco CallManager compares an incoming SIP request to the application-level settings on the SIP Trunk Security Profile window in Cisco CallManager Administration and finds that application-level authorization for one or more of the features on that window is not allowed.
SIPTrunkServerAuthorizationChallenges	This counter represents the number of authentication challenges for incoming SIP requests that Cisco CallManager issued to SIP trunks. An authentication challenge occurs when a SIP trunk with Digest Authentication enabled sends a SIP request to Cisco CallManager.
SIPTrunkServerAuthorizationFailures	This counter represents the number of authentication challenge failures that occurred for incoming SIP requests from SIP trunks to Cisco CallManager. An authentication failure occurs when a SIP trunk with Digest Authentication enabled sends a SIP request with bad credentials to Cisco CallManager.
SWConferenceActive	This counter represents the number of active conferences on all software conference devices that are registered with Cisco CallManager.
SWConferenceCompleted	This counter represents the total number of conferences that used a software conference bridge that was allocated from a Cisco CallManager and that have been completed, which means that the conference bridge has been allocated and released. A conference activates when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.

**Table 6-3** *Cisco CallManager (continued)*

Counters	Counter Descriptions
SWConferenceOutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate a software conference resource from those that are registered to Cisco CallManager when none were available. Counter includes failed attempts to add a new participant to an existing conference.
SWConferenceResourceActive	This counter represents the total number of conference resources that are in use on all software conference devices that are registered with Cisco CallManager. The system considers a conference to be active when one or more calls connect to a bridge. One resource is equal to one stream.
SWConferenceResourceAvailable	This counter represents the number of new software-based conferences that can be started at the same time, for Cisco CallManager. You must have a minimum of three streams available for each new conference. One resource is equal to one stream.
SWConferenceResourceTotal	This counter represents the total number of software conference resources that are provided by all software conference bridge devices that are currently registered with Cisco CallManager.
SystemCallsAttempted	This counter represents the total number of server originated calls and attempted calls to the Unity Message waiting indicator (MWI).
T1ChannelsActive	This counter represents the number of T1 CAS voice channels that are in an active call on a Cisco CallManager.
T1SpansInService	This counter represents the number of T1 CAS spans that are currently available for use.
TLSConnectedSIPTrunks	This counter represents the number of SIP trunks that are configured and connected via Transport Layer Security (TLS).
TLSConnectedWSM	This counter represents the number of WSM Connectors that is configured and connected to Motorola WSM via Transport Layer Security (TLS).
TranscoderOutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate a transcoder resource from a transcoder device that is registered to a Cisco CallManager when none was available.
TranscoderResourceActive	This counter represents the total number of transcoders that are in use on all transcoder devices that are registered with Cisco CallManager. A transcoder in use represents one transcoder resource that has been allocated for use in a call. Each transcoder resource uses two streams.
TranscoderResourceAvailable	This counter represents the total number of transcoders that are not in use and that are available to be allocated on all transcoder devices that are registered with Cisco CallManager. Each transcoder resource uses two streams.
TranscoderResourceTotal	This counter represents the total number of transcoder resources that are provided by all transcoder devices that are currently registered with Cisco CallManager.

**Table 6-3 Cisco CallManager (continued)**

Counters	Counter Descriptions
VCBConferenceActive	This counter represents the total number of active video conferences on all video conference bridge devices that are registered with Cisco CallManager.
VCBConferenceAvailable	This counter represents the total number of new video conferences on all video conference bridge devices that are registered with Cisco CallManager.
VCBConferenceCompleted	This counter represents the total number of video conferences that used a video conference bridge that are allocated from Cisco CallManager and that have been completed, which means that the conference bridge has been allocated and released. A conference activates when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.
VCBConferenceTotal	This counter represents the total number of video conferences that are supported on all video conference bridge devices that are registered with Cisco CallManager.
VCBOutOfConferences	This counter represents the total number of times that Cisco CallManager attempted to allocate a video conference resource from those that are registered to Cisco CallManager when none was available.
VCBOutOfResources	This counter represents the total number of failed new video conference requests. A conference request can fail because, for example, the configured number of conferences is already in use.
VCBResourceActive	This counter represents the total number of video conference resources that are currently in use on all video conference devices that are registered with Cisco CallManager.
VCBResourceAvailable	This counter represents the total number of video conference resources that are not active and are currently available.
VCBResourceTotal	This counter represents the total number of video conference resources that are provided by all video conference bridge devices that are currently registered with Cisco CallManager.
VideoCallsActive	This counter represents the number of active video calls with active video streaming connections on all video conference bridge devices that are registered with Cisco CallManager.
VideoCallsCompleted	This counter represents the number of video calls that were actually connected with video streams and then released.
VideoOutOfResources	This counter represents the total number of times that Cisco CallManager attempted to allocate a video-streaming resource from one of the video conference bridge devices that is registered to Cisco CallManager when none was available.

## Cisco CallManager Attendant Console

The Cisco CallManager Attendant Console (Cisco CallManager Attendant Console Server service) object provides information about the Cisco CallManager Attendant Console. [Table 6-4](#) contains information about Cisco CallManager Attendant Console counters.

**Table 6-4** *Cisco CallManager Attendant Console*

Counters	Counter Descriptions
CallsActive	Do not use this counter. Information in this counter may not accurately reflect the total number of active calls.
CallsRedirected	This counter represents the total number of redirected calls for a Cisco CallManager Attendant Console Server service. This number increases every time that a pilot point receives a call and redirects the call to a member of its hunt group.
CallsTotal	This counter represents the total number of all calls that have been made since the Cisco CallManager Attendant Console Server service started.
CcmLineLinkState	This counter represents the line state. Values include 0, 1, 10, or 11. A value of 0 indicates that the Cisco CallManager Attendant Console Server service has not registered or has not received line link state information from Cisco CallManager; 1 indicates that the Cisco CallManager Attendant Console Server service has registered and is receiving line link state information from Cisco CallManager; 10 indicates that the Cisco CallManager Attendant Console Server service has logged into CTI but has not registered or has not received line link state information from Cisco CallManager; 11 indicates that the Cisco CallManager Attendant Console Server service has logged into CTI and has registered and is receiving line link state information.
ClientsOnline	This counter represents the total number of Cisco CallManager attendant console clients that are currently online. Attendant Console clients include all users that are configured in the attendant console User Configuration window in Cisco CallManager Administration that are currently online. This number increases by one for each client that goes online and decreases by one for each client that goes offline.
ClientsRegistered	This counter represents the total number of registered clients for a Cisco CallManager Attendant Console Server service. This number increases by one for each new registration of a Cisco CallManager attendant console client when the client application logs in.
ClientsTotal	This counter represents the total number of Cisco CallManager Attendant Console clients that are currently registered with the Cisco CallManager Attendant Console Server service. Attendant console clients represent all users that are configured in the Attendant Console User Configuration window in Cisco CallManager Administration.

**Table 6-4** *Cisco CallManager Attendant Console (continued)*

Counters	Counter Descriptions
HeartBeat	This counter represents the heartbeat of the Cisco CallManager Attendant Console Server service. This incremental count indicates that Cisco CallManager Attendant Console Server service is up and running. If the count does not increase, this means that the service is down.
LinesActive	Do not use this counter. Information in this counter may not accurately reflect the total number of active lines.
LinesIdle	Do not use this counter. Information in this counter may not accurately reflect the total number of idle lines.
LinesTotal	Do not use this counter. Information in this counter may not accurately reflect the total number of lines.
PilotPointsTotal	This counter represents the total number of pilot points that are configured in Cisco CallManager.
StartTime	This counter represents the time in milliseconds since the Cisco CallManager Attendant Console Server service started. The real-time clock in the computer, which is simply a reference point that indicates the current time and the time that has elapsed, in milliseconds, since the service started provides the basis for this time. The reference point specifies midnight, January 1, 1970.
Version	This counter represents the version of the Cisco CallManager Attendant Console Server service.

## Cisco CallManager System Performance

The Cisco CallManager System Performance object provides system performance information about Cisco CallManager. [Table 6-5](#) contains information about Cisco CallManager system performance counters.

**Table 6-5** *Cisco CallManager System Performance*

Counters	Counter Descriptions
AverageExpectedDelay	This counter represents the current average expected delay before any incoming message gets handled.
CallsRejectedDueToCallThrottling	This counter represents the total number of calls that were rejected since the start of service due to call throttling.
CallThrottlingGenericCounter3	This counter represents a generic counter that is used for call-throttling purpose.
CodeRedEntryExit	This counter indicates whether Cisco CallManager has entered or exited a Code Red state (call-throttling mode). Valid values include 0 (Exit) and 1 (Entry).
CodeYellowEntryExit	This counter indicates whether Cisco CallManager has entered or exited a Code Yellow state (call-throttling mode). Valid values include 0 (Exit) and 1 (Entry).

**Table 6-5 Cisco CallManager System Performance (continued)**

Counters	Counter Descriptions
EngineeringCounter1	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter2	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter3	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter4	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter5	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter6	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter7	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
EngineeringCounter8	Do not use this counter unless directed by a Cisco Engineering Special build. Cisco uses information in this counter for diagnostic purposes.
QueueSignalsPresent 1-High	This counter indicates the number of high-priority signals in the Cisco CallManager queue. High-priority signals include timeout events, internal Cisco CallManager keepalives, certain gatekeeper events, and internal process creation, among other events. A large number of high-priority events will cause degraded performance on Cisco CallManager and result in slow call connection or loss of dial tone. Use this counter in conjunction with the QueueSignalsProcessed 1-High counter to determine the processing delay on Cisco CallManager.
QueueSignalsPresent 2-Normal	This counter indicates the number of normal-priority signals in the Cisco CallManager queue. Normal-priority signals include call-processing functions, key presses, on-hook and off-hook notifications, among other events. A large number of normal-priority events will cause degraded performance on Cisco CallManager, sometimes resulting in delayed dial tone, slow call connection, or loss of dial tone. Use this counter in conjunction with the QueueSignalsProcessed 2-Normal counter to determine the call-processing delay on Cisco CallManager. Remember that high-priority signals must complete before normal-priority signals begin to process, so check the high-priority counters as well to get an accurate picture of the potential delay.

**Table 6-5 Cisco CallManager System Performance (continued)**

Counters	Counter Descriptions
QueueSignalsPresent 3-Low	This counter indicates the number of low-priority signals in the Cisco CallManager queue. Low-priority signals include station device registration (except the initial station registration request message), among other events. A large number of signals in this queue could result in delayed device registration, among other events.
QueueSignalsPresent 4-Lowest	This counter indicates the number of lowest priority signals in the Cisco CallManager queue. Lowest priority signals include the initial station registration request message during device registration, among other events. A large number of signals in this queue could result in delayed device registration, among other events.
QueueSignalsProcessed 1-High	This counter indicates the number of high-priority signals that Cisco CallManager processes for each 1-second interval. Use this counter in conjunction with the QueueSignalsPresent 1-High counter to determine the processing delay on this queue.
QueueSignalsProcessed 2-Normal	This counter indicates the number of normal-priority signals that Cisco CallManager processes for each 1-second interval. Use this counter in conjunction with the QueueSignalsPresent 2-Normal counter to determine the processing delay on this queue. Remember that high-priority signals get processed before normal-priority signals.
QueueSignalsProcessed 3-Low	This counter indicates the number of low-priority signals that Cisco CallManager processes for each 1-second interval. Use this counter in conjunction with the QueueSignalsPresent 3-Low counter to determine the processing delay on this queue. The number of signals processed gives an indication of how much device registration activity is being processed in this time interval.
QueueSignalsProcessed 4-Lowest	This counter indicates the number of lowest priority signals that Cisco CallManager processes for each 1-second interval. Use this counter in conjunction with the QueueSignalsPresent 4-Lowest counter to determine the processing delay on this queue. The number of signals that are processed gives an indication of how many devices began the Cisco CallManager registration process in this time interval.
QueueSignalsProcessed Total	This counter provides a sum total of all queue signals that Cisco CallManager processes for each 1-second period for all queue levels: high, normal, low, and lowest.
SkinnyDevicesThrottled	This counter represents the total number of Skinny devices that are being throttled. A Skinny device gets throttled (asked to shut down and reregister) when the total number of events that the Skinny device generated exceeds the configured maximum threshold value (default value specifies 2000 events) within a 5-second interval.

**Table 6-5 Cisco CallManager System Performance (continued)**

Counters	Counter Descriptions
ThrottlingSampleActivity	This counter indicates how many samples, out of the configured sample size, have non-zero averageExpectedDelay values. This counter gets reset when any sample has an averageExpectedDelay value of zero. This process repeats for each batch of samples. A batch represents the configured sample size.
TotalCodeYellowEntry	This counter indicates the number of times that Cisco CallManager call processing enters the code yellow state. This counter remains cumulative from the start of the Cisco CallManager process.

## Cisco CTIManager

The Cisco CTI Manager object provides information about Cisco CTI Manager. [Table 6-6](#) contains information about Cisco CTIManager counters.

**Table 6-6 Cisco CTI Manager**

Counters	Counter Descriptions
CcmLinkActive	This counter represents the total number of active Cisco CallManager links. CTI Manager maintains links to all active Cisco CallManagers in the cluster.
CTIConnectionActive	This counter represents the total number of CTI clients that are currently connected to the CTIManager. This counter increases by one when new connection is established and decreases by one when a connection is released. The CTIManager service parameter MaxCTIConnections determines the maximum number of active connections.
DevicesOpen	This counter represents the total number of devices that are configured in Cisco CallManager that CTI applications control and/or monitor. Devices include hardware IP phones, CTI ports, CTI route points, and so on.
LinesOpen	This counter represents the total number of lines that are configured in Cisco CallManager that control and/or monitor CTI applications.
QbeVersion	This counter represents the version number of the Quick Buffer Encoding (QBE) interface that the CTIManager uses.



## Cisco Dual-Mode Mobility

The Cisco Dual-Mode Mobility object provides information about the dual-mode mobility application on Cisco CallManager. [Table 6-7](#) contains information about Cisco Dual-Mode Mobility counters.

**Table 6-7** *Cisco Dual-Mode Mobility*

Counters	Counter Descriptions
CallsAnchored	This counter represents the number of calls that are placed or received on dual-mode phones that are anchored in Cisco CallManager. The counter increments when a call is received from or placed to a dual-mode phone. The counter increments twice if a dual-mode phone calls another dual-mode phone.
DMMSRegistered	This counter represents the number of Dual-mode Mobile Station (DMMS) subscribers that are registered in the wireless LAN (WLAN).
FollowMeAborted	This counter represents the number of failed follow-me operations.
FollowMeAttempted	This counter represents the number of follow-me operations that Cisco CallManager attempted. The counter increments when a SIP 302 - Moved Temporarily message is received from the Wireless Service Manager (WSM) and Cisco CallManager redirects the call to the DMMS in WLAN.
FollowMeCompleted	This counter represents the number of follow-me operations that were successfully completed. The counter increments when the DMMS in WLAN answers the call and the media (voice path) is successfully established with the calling device.
FollowMeInProgress	This counter represents the number of follow-me operations that are currently in progress. The counter increments when a follow-me is attempted and it decrements when the follow-me operation is aborted or completed.
H1HandOutAttempted	This counter represents the number of H1 hand-out operations that dual-mode phones attempt. The counter increments when Cisco CallManager processes a call to the H1 number from a DMMS.
H1HandOutCompleted	This counter represents the number of successfully completed H1 hand-out operations. The counter increments when the DMMS in WLAN successfully establishes a media (voice path).
H2HandOutCompleted	This counter represents the number of successfully completed H2 hand-out operations. The counter increments when the DMMS in WLAN successfully establishes a media (voice path).
H2HandOutsAttempted	This counter represents the number of H2 hand-out operations that dual-mode phones attempt. The counter increments when Cisco CallManager receives a call to the H2 number from a DMMS.
HandInAborted	This counter represents the number of hand-in operations that failed.
HandInAttempted	This counter represents the number of hand-in operations that dual-mode phones attempt.

**Table 6-7 Cisco Dual-Mode Mobility (continued)**

Counters	Counter Descriptions
HandInCompleted	This counter represents the number of successfully completed hand-in operations. The counter increments when the DMMS in WLAN successfully establishes a media (voice path).
HandInInProgress	This counter represents the number of hand-in operations that are currently in progress. The counter increments when a hand-in is attempted, and the counter decrements when the hand-in is aborted or completed.
Hand Out Aborted	This counter represents the number of hand-out operations that failed.
Hand Out In Progress	This counter represents the number of H1 and H2 hand-out operations that are currently in progress. The counter increments when a H1 or H2 hand-out is attempted, and it decrements when the hand-out is aborted or completed.

## Cisco Extension Mobility

The Cisco Extension Mobility object provides information about the extension mobility application. [Table 6-8](#) contains information about Cisco CallManager Extension Mobility counters.

**Table 6-8 Cisco Extension Mobility Application**

Counters	Counter Descriptions
RequestsHandled	This counter represents the total number of HTTP requests that the extension mobility application handled since the last restart of the Cisco CallManager service. A typical login would constitute two HTTP requests: one to query the initial login state of the device, and another to log in the user on a device. Similarly, a typical logout also results in two HTTP requests.
RequestsInProgress	This counter represents the number of HTTP requests that the extension mobility application currently is handling. A typical login would constitute two HTTP requests: one to query the initial login state of the device and another to log in the user on a device. Similarly, a typical logout also results in two HTTP requests.
Requests Throttled	This counter represents the total number of Login/Logout Requests that failed due to throttling.
Successful Logins	This counter represents the total number of successful login requests that were completed through EM Service.
Successful Logouts	This counter represents the total number of successful logout requests that were completed through EM Service
Total Attempted Login/Logout Requests	This counter represents the total number of Login and Logout requests that were attempted through this EM Service. This number includes both successful and unsuccessful attempts.

## Cisco Gatekeeper

The Cisco Gatekeeper object provides information about registered Cisco gatekeeper devices. [Table 6-9](#) contains information about Cisco gatekeeper device counters.

**Table 6-9** *Cisco Gatekeeper*

Counters	Counter Descriptions
ACFsReceived	This counter represents the total number of RAS Admission Confirm messages that are received from the configured gatekeeper and its alternate gatekeepers.
ARQsAttempted	This counter represents the total number of RAS Admission Request messages that are attempted by using the configured gatekeeper and its alternate gatekeepers.
RasRetries	This counter represents the number of retries due to loss or delay of all RAS acknowledgement messages on the configured gatekeeper and its alternate gatekeepers.
VideoOutOfResources	This counter represents the total number of video-stream requests to the configured gatekeeper or its alternate gatekeepers that failed, most likely due to lack of bandwidth.

## Cisco H.323

The Cisco H.323 object provides information about registered Cisco H.323 devices. [Table 6-10](#) contains information about Cisco H.323 device counters.

**Table 6-10** *Cisco H.323*

Counters	Counter Descriptions
CallsActive	This counter represents the number of streaming connections that are currently active (in use) on the configured H.323 device; in other words, the number of calls that actually have a voice path that is connected.
CallsAttempted	This counter represents the total number of calls that have been attempted on a device, including both successful and unsuccessful call attempts.
CallsCompleted	This counter represents the total number of successful calls that were made from a device.
CallsInProgress	This counter represents the number of calls that are currently in progress on a device.

**Table 6-10** *Cisco H.323 (continued)*

Counters	Counter Descriptions
VideoCallsActive	This counter represents the number of video calls with video streaming connections that are currently active (in use) on all H.323 trunks that are registered with a Cisco CallManager; in other words, the number of calls that actually have video-streaming connections on a Cisco CallManager.
VideoCallsCompleted	This counter represents the number of video calls that were actually connected with video streams for all H.323 trunks that were registered with a Cisco CallManager. This number increases when the call terminates.

## Cisco Hunt Lists

The Cisco Hunt Lists object provides information about the hunt lists that are defined in Cisco CallManager administration. [Table 6-11](#) contains information about Cisco hunt list counters.

**Table 6-11** *Cisco Hunt Lists*

Counters	Counter Descriptions
CallsAbandoned	This counter represents the number of abandoned calls that occurred through a hunt list. An abandoned call represents one in which a caller hangs up before the call is answered.
CallsActive	This counter represents the number of calls that are currently active (in use) that occurred through a hunt list. An active call represents one that gets distributed and answered, and to which a voice path connects.
CallsBusyAttempts	This counter represents the number of times that calls through a hunt list were attempted when all members of the line and/or route groups were busy.
CallsInProgress	This counter represents the number of calls that are currently in progress through a hunt list. A call in progress represents one that the Call Distributor is attempting to extend to a member of a line or route group and that has not yet been answered. Examples of a hunt list member include a line, a station device, a trunk device, or a port/channel of a trunk device.
CallsRingNoAnswer	This counter represents the total number of calls through a hunt list that rang but that called parties did not answer.

**Table 6-11** *Cisco Hunt Lists (continued)*

Counters	Counter Descriptions
HuntListInService	This counter specifies whether the particular hunt list is currently in service. A value of 0 indicates that the hunt list is out of service; a value of 1 indicates that the hunt list is in service. A hunt list could be out of service because the hunt list is not running on a primary Cisco CallManager based on its Cisco CallManager Group or because the hunt list has been disabled in Cisco CallManager Administration.
MembersAvailable	This counter represents the total number of available or idle members of line and route groups that belong to an in-service hunt list. An available member currently handles a call and will accept a new call. An idle member does not handle any call and will accept a new call. A hunt list member can be a route group, line group, or a combination. A member of a line group represents a directory number of a line on an IP phone or a voice-mail port. A member of a route group represents a station gateway, a trunk gateway, or port/channel of a trunk gateway.

## Cisco HW Conference Bridge Device

The Cisco HW Conference Bridge Device object provides information about registered Cisco hardware conference bridge devices. [Table 6-12](#) contains information about Cisco hardware conference bridge device counters.

**Table 6-12** *Cisco HW Conference Bridge Device*

Counters	Counter Descriptions
HWConferenceActive	This counter represents the number of conferences that are currently active (in use) on a HW conference bridge device. One resource represents one stream.
HWConferenceCompleted	This counter represents the total number of conferences that have been allocated and released on a HW conference device. A conference starts when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.
OutOfResources	This counter represents the total number of times that an attempt was made to allocate a conference resource from a HW conference device and failed, for example, because all resources were already in use.
ResourceActive	This counter represents the number of resources that are currently in use (active) for this HW conference device. One resource represents one stream.

**Table 6-12** *Cisco HW Conference Bridge Device (continued)*

Counters	Counter Descriptions
ResourceAvailable	This counter represents the total number of resources that are not active and are still available to be used now for a HW conference device. One resource represents one stream.
ResourceTotal	This counter represents the total number of resources for a HW conference bridge device. This counter equals the sum of the counters ResourceAvailable and ResourceActive. One resource represents one stream.

## Cisco IP Manager Assistant

The Cisco IP Manager Assistant (IPMA) Service object provides information about the Cisco IP Manager Assistant application. [Table 6-13](#) contains information on Cisco IPMA counters.

**Table 6-13** *Cisco IP Manager Assistant Service*

Counters	Counter Descriptions
AssistantsActive	This counter represents the number of assistant consoles that are currently active. An active assistant console exists when an assistant is logged in from his or her assistant console desktop application.
LinesOpen	This counter represents the number of phone lines that the Cisco IPMA application opened. An open phone line exists when the IPMA application assumes line control from CTI.
ManagersActive	This counter represents the current number of managers that the Cisco IPMA is servicing.
SessionsCurrent	This counter represents the total number of managers assistants that are currently using the Cisco IPMA application. Each manager and each assistant constitutes an active session, so for one manager/assistant pair, this counter would reflect two sessions.

## Cisco Lines

The Cisco Lines object represents the number of Cisco lines (directory numbers) that can dial and connect to a device. Lines represent all directory numbers that terminate on an endpoint. The directory number that is assigned to it identifies the line. The Cisco Lines object does not include directory numbers that include wildcards such as a pattern for a Digital or Analog Access gateway.

The Active counter represents the state of the line, either active or not active. A zero indicates the line is not in use. When the number is greater than zero, this indicates that the line is active, and the number represents the number of calls that are currently in progress on that line. If more than one call is active, this indicates the call is on hold either because of being placed on hold specifically (user hold) or because of a network hold operation (for example, a transfer is in progress, and it is on transfer hold). This applies to all directory numbers that are assigned to any device.

## Cisco Locations

The Cisco Location object provides information about locations that are defined in Cisco CallManager. [Table 6-14](#) contains information on Cisco location counters.

**Table 6-14 Cisco Locations**

Counters	Counter Descriptions
BandwidthAvailable	This counter represents the current bandwidth in a given location. A value of 0 indicates that no bandwidth is available.
BandwidthMaximum	This counter represents the maximum bandwidth that is available in a given location. A value of 0 indicates that infinite bandwidth is available.
CallsInProgress	This counter represents the number of calls that are currently in progress on a particular Cisco CallManager.
OutOfResources	This counter represents the total number of times that a call on a particular Cisco CallManager through the location failed due to lack of bandwidth.
RSVP AudioReservationErrorCounts	This counter represents the number of RSVP reservation errors in the audio stream.
RSVP MandatoryConnectionsInProgress	This counter represents the number of connections with mandatory RSVP that are in progress.
RSVP OptionalConnectionsInProgress	This counter represents the number of connections with optional RSVP that are in progress.
RSVP TotalCallsFailed	This counter represents the number of total calls that failed due to a RSVP reservation failure.
RSVP VideoCallsFailed	This counter represents the number of video calls that failed due to a RSVP reservation failure.
RSVP VideoReservationErrorCounts	This counter represents the number of RSVP reservation errors in the video stream
VideoBandwidthAvailable	This counter represents the bandwidth that is currently available for video in the location where the person who initiated the video conference resides. A value of 0 indicates that no bandwidth is available.
VideoBandwidthMaximum	This counter represents the maximum bandwidth that is available for video in the location where the person who initiated the video conference resides. A value of 0 indicates that no bandwidth is allocated for video.
VideoOutOfResources	This counter represents the total number of failed video-stream requests (most likely due to lack of bandwidth) in the location where the person who initiated the video conference resides.

## Cisco Media Streaming Application

The Cisco IP Voice Media Streaming Application object provides information about the registered MTPs, MOH servers, conference bridge servers, and annunciators. [Table 6-15](#) contains information on Cisco IP Voice Media Streaming Application counters.


**Note**

One object exists for each Cisco CallManager in the Cisco CallManager group that is associated with the device pool that the annunciator device is configured to use.

**Table 6-15** *Cisco Media Streaming Application*

Counter	Counter Descriptions
ANNConnectionsLost	This counter represents the total number of times since the last restart of the Cisco IP Voice Media Streaming Application that a Cisco CallManager connection was lost.
ANNConnectionState	For each Cisco CallManager that is associated with an annunciator, this counter represents the current registration state to Cisco CallManager; 0 indicates no registration to Cisco CallManager; 1 indicates registration to the primary Cisco CallManager; 2 indicates connection to the secondary Cisco CallManager (connected to Cisco CallManager but not registered until the primary Cisco CallManager connection fails).
ANNConnectionsTotal	This counter represents the total number of annunciator instances that have been started since the Cisco IP Voice Media Streaming Application service started.
ANNInstancesActive	This counter represents the number of actively playing (currently in use) announcements.
ANNStreamsActive	This counter represents the total number of currently active simplex (one direction) streams for all connections. Each stream direction counts as one stream. One internal stream provides the audio input and another output stream to the endpoint device.
ANNStreamsAvailable	This counter represents the remaining number of streams that are allocated for the annunciator device that are available for use. This counter starts as 2 multiplied by the number of configured connections (defined in the Cisco IP Voice Media Streaming App service parameter for the Annunciator, Call Count) and is reduced by one for each active stream that started.
ANNStreamsTotal	This counter represents the total number of simplex (one direction) streams that connected to the annunciator device since the Cisco IP Voice Media Streaming Application service started.
CFBConferencesActive	This counter represents the number of active (currently in use) conferences.
CFBConferencesTotal	This counter represents the total number of conferences that started since the Cisco IP Voice Media Streaming Application service started.



**Table 6-15 Cisco Media Streaming Application (continued)**

Counter	Counter Descriptions
CFBConnectionsLost	This counter represents the total number of times since the last restart of the Cisco IP Voice Media Streaming Application that a Cisco CallManager connection was lost.
CFBConnectionState	For each Cisco CallManager that is associated with a SW Conference Bridge, this counter represents the current registration state to Cisco CallManager; 0 indicates no registration to Cisco CallManager; 1 indicates registration to the primary Cisco CallManager; 2 indicates connection to the secondary Cisco CallManager (connected to Cisco CallManager but not registered until the primary Cisco CallManager connection fails).
CFBStreamsActive	This counter represents the total number of currently active simplex (one direction) streams for all conferences. Each stream direction counts as one stream. In a three-party conference, the number of active streams equals 6.
CFBStreamsAvailable	This counter represents the remaining number of streams that are allocated for the conference bridge that are available for use. This counter starts as 2 multiplied by the number of configured connections (defined in the Cisco IP Voice Media Streaming App service parameter for Conference Bridge, Call Count) and is reduced by one for each active stream started.
CFBStreamsTotal	This counter represents the total number of simplex (one direction) streams that connected to the conference bridge since the Cisco IP Voice Media Streaming Application service started.
MOHAudioSourcesActive	<p>This counter represents the number of active (currently in use) audio sources for this MOH server. Some of these audio sources may not be actively streaming audio data if no devices are listening. The exception exists for multicast audio sources, which will always be streaming audio.</p> <p>When an audio source is in use, even after the listener has disconnected, this counter will always have one input stream for each configured MOH codec. For unicast streams, the stream may exist in a suspended state where no audio data is received until a device connects to listen to the stream. Each MOH multicast resource uses one stream for each audio source and codec combination. For example, if the default audio source is configured for multicast, G.711 mu-law and wideband codecs, then two streams get used (default audio source + G.711 mu-law and default audio source + wideband).</p>
MOHConnectionsLost	This counter represents the total number of times since the last restart of the Cisco IP Voice Media Streaming Application that a Cisco CallManager connection was lost.

**Table 6-15 Cisco Media Streaming Application (continued)**

Counter	Counter Descriptions
MOHConnectionState	For each Cisco CallManager that is associated with an MOH, this counter represents the current registration state to Cisco CallManager; 0 indicates no registration to Cisco CallManager; 1 indicates registration to the primary Cisco CallManager; 2 indicates connection to the secondary Cisco CallManager (connected to Cisco CallManager but not registered until the primary Cisco CallManager connection fails).
MOHStreamsActive	<p>This counter represents the total number of active (currently in use) simplex (one direction) streams for all connections. One output stream exists for each device that is listening to a unicast audio source, and one input stream exists for each active audio source, multiplied by the number of MOH codecs.</p> <p>When an audio source has been used once, it will always have one input stream for each configured MOH codec. For unicast streams, the stream may exist in a suspended state where no audio data is received until a device connects to listen to the stream. Each MOH multicast resource uses one stream for each audio source and codec combination. For example, if the default audio source is configured for multicast, G.711 mu-law and wideband codecs, then two streams get used (default audio source + G.711 mu-law and default audio source + wideband).</p>
MOHStreamsAvailable	This counter represents the remaining number of streams that are allocated for the MOH device that are available for use. This counter starts as 408 plus the number of configured half-duplex unicast connections and is reduced by 1 for each active stream that started. The counter gets reduced by 2 for each multicast audio source, multiplied by the number of MOH codecs that are configured. The counter gets reduced by 1 for each unicast audio source, multiplied by the number of MOH codecs configured.
MOHStreamsTotal	This counter represents the total number of simplex (one direction) streams that have connected to the MOH server since the Cisco IP Voice Media Streaming Application service started.
MTPConnectionsLost	This counter represents the total number of times since the last restart of the Cisco IP Voice Streaming Application that a Cisco CallManager connection was lost.
MTPConnectionState	For each Cisco CallManager that is associated with an MTP, this counter represents the current registration state to Cisco CallManager; 0 indicates no registration to Cisco CallManager; 1 indicates registration to the primary Cisco CallManager; 2 indicates connection to the secondary Cisco CallManager (connected to Cisco CallManager but not registered until the primary Cisco CallManager connection fails).
MTPConnectionsTotal	This counter represents the total number of MTP instances that have been started since the Cisco IP Voice Media Streaming Application service started.

**Table 6-15 Cisco Media Streaming Application (continued)**

Counter	Counter Descriptions
MTPInstancesActive	This counter represents the number of active (currently in use) instances of MTP.
MTPStreamsActive	This counter represents the total number of currently active simplex (one direction) streams for all connections. Each stream direction counts as one stream.
MTPStreamsAvailable	This counter represents the remaining number of streams that are allocated for the MTP device that are available for use. This counter starts as 2 multiplied by the number of configured connections (defined in the Cisco IP Voice Media Streaming App service parameter for MTP, Call Count) and is reduced by one for each active stream started.
MTPStreamsTotal	This counter represents the total number of simplex (one direction) streams that connected to the MTP device since the Cisco IP Voice Media Streaming Application service started.

## Cisco Messaging Interface

The Cisco Messaging Interface object provides information about the Cisco Messaging Interface (CMI) service. [Table 6-16](#) contains information on Cisco Messaging Interface (CMI) counters.

**Table 6-16 Cisco Messaging Interface**

Counters	Counter Descriptions
HeartBeat	This counter represents the heartbeat of the CMI service. This incremental count indicates that the CMI service is up and running. If the count does not increase (increment), the CMI service is down.
SMDIMessageCountInbound	This counter represents the running count of inbound SMDI messages since the last restart of the CMI service.
SMDIMessageCountInbound24 Hour	This counter represents the rolling count of inbound SMDI messages in the last 24 hours.
SMDIMessageCountOutbound	This counter represents the running count of outbound SMDI messages since the last restart of the CMI service.
SMDIMessageCountOutbound24Hour	This counter represents the rolling count of outbound SMDI messages in the last 24 hours.
StartTime	This counter represents the time in milliseconds when the CMI service started. The real-time clock in the computer, which simply acts as a reference point that indicates the current time and the time that has elapsed, in milliseconds, since the service started, provides the basis for this time. The reference point specifies midnight, January 1, 1970.

## Cisco MGCP FXO Device

The Cisco Media Gateway Control Protocol (MGCP) Foreign Exchange Office (FXO) Device object provides information about registered Cisco MGCP FXO devices. [Table 6-17](#) contains information on Cisco MGCP FXO device counters.

**Table 6-17** *Cisco MGCP FXO Device*

Counters	Counter Descriptions
CallsCompleted	This counter represents the total number of successful calls that were made from the port on an MGCP FXO device.
OutboundBusyAttempts	This counter represents the total number of times that a call through the port on this MGCP FXO device was attempted when no voice channels were available.
PortStatus	This counter represents the status of the FXO port associated with this MGCP FXO device.

## Cisco MGCP FXS Device

The Cisco MGCP Foreign Exchange Station (FXS) Device object provides information about registered Cisco MGCP FXS devices. One instance of this object gets created for each port on a Cisco Catalyst 6000 24 port FXS Analog Interface Module gateway. For example, a fully configured Catalyst 6000 Analog Interface Module would represent 24 separate instances of this object. [Table 6-18](#) contains information on Cisco MGCP FXS device counters.

**Table 6-18** *Cisco MGCP FXS Device*

Counters	Counter Descriptions
CallsCompleted	This counter represents the total number of successful calls that were made from this port on the MGCP FXS device.
OutboundBusyAttempts	This counter represents the total number of times that a call through this port on the MGCP FXS device was attempted when no voice channels were available.
PortStatus	This counter represents the status of the FXS port that is associated with a MGCP FXS device.

## Cisco MGCP Gateways

The Cisco MGCP Gateways object provides information about registered MGCP gateways. [Table 6-19](#) contains information on Cisco MGCP gateway counters.

**Table 6-19** *Cisco MGCP Gateways*

Counters	Counter Descriptions
BRChannelsActive	This counter represents the number of BRI voice channels that are currently active in a call in the gateway
BRISpansInService	This counter represents the number of BRI spans that are currently available for use in the gateway.
FXOPortsActive	This counter represents the number of FXO ports that are currently active in a call in the gateway.
FXOPortsInService	This counter represents the number of FXO ports that are currently available for use in the gateway.
FXSPortsActive	This counter represents the number of FXS ports that are currently active in a call in the gateway.
FXSPortsInService	This counter represents the number of FXS ports that are currently available for use in the gateway.
PRChannelsActive	This counter represents the number of PRI voice channels that are currently active in a call in the gateway.
PRISpansInService	This counter represents the number of PRI spans that are currently available for use in the gateway.
T1ChannelsActive	This counter represents the number of T1 CAS voice channels that are currently active in a call in the gateway.
T1SpansInService	This counter represents the number of T1 CAS spans that are currently available for use in the gateway.

## Cisco MGCP PRI Device

The Cisco MGCP Primary Rate Interface (PRI) Device object provides information about registered Cisco MGCP PRI devices. [Table 6-20](#) contains information on Cisco MGCP PRI device counters.

**Table 6-20** *Cisco MGCP PRI Device*

Counters	Counter Descriptions
CallsActive	This counter represents the number of calls that are currently active (in use) on this MGCP PRI device.
CallsCompleted	This counter represents the total number of successful calls that were made from this MGCP PRI device.

**Table 6-20** *Cisco MGCP PRI Device (continued)*

Counters	Counter Descriptions
Channel 1 Status through Channel 15 Status (consecutively numbered)	This counter represents the status of the indicated B-Channel that is associated with a MGCP PRI device. Possible values: 0 (Unknown) indicates that the status of the channel could not be determined; 1 (Out of service) indicates that this channel is not available for use; 2 (Idle) indicates that this channel has no active call and is ready for use; 3 (Busy) indicates that an active call exists on this channel; 4 (Reserved) indicates that this channel has been reserved for use as a D-Channel or for use as a Synch-Channel for E-1.
Channel 16 Status	This counter represents the status of the indicated B-Channel that is associated with a MGCP PRI Device. Possible values: 0-Unknown, 1-Out of service, 2-Idle, 3-Busy, 4-Reserved, for an E1 PRI Interface, this channel is reserved for use as a D-Channel.
Channel 17 Status through Channel 31 Status (consecutively numbered)	This counter represents the status of the indicated B-Channel that is associated with the MGCP PRI Device. 0-Unknown, 1-Out of service, 2-Idle, 3-Busy, 4-Reserved.
DatalinkInService	This counter represents the state of the Data Link (D-Channel) on the corresponding digital access gateway. This value will be set to 1 (one) if the Data Link is up (in service) or 0 (zero) if the Data Link is down (out of service).
OutboundBusyAttempts	This counter represents the total number of times that a call through an MGCP PRI device was attempted when no voice channels were available.

## Cisco MGCP T1 CAS Device

The Cisco MGCP T1 Channel Associated Signaling (CAS) Device object provides information about registered Cisco MGCP T1 CAS devices. [Table 6-21](#) contains information on Cisco MGCP T1 CAS device counters.

**Table 6-21** *Cisco MGCP T1 CAS Device*

Counters	Counter Descriptions
CallsActive	This counter represents the number of calls that are currently active (in use) on this MGCP T1 CAS device.
CallsCompleted	This counter represents the total number of successful calls that were made from this MGCP T1 CAS device.

**Table 6-21 Cisco MGCP T1 CAS Device (continued)**

Counters	Counter Descriptions
Channel 1 Status through Channel 24 Status (consecutively numbered)	This counter represents the status of the indicated B-Channel that is associated with an MGCP T1 CAS device. Possible values: 0 (Unknown) indicates the status of the channel could not be determined; 1 (Out of service) indicates that this channel is not available for use; 2 (Idle) indicates that this channel has no active call and is ready for use; 3 (Busy) indicates that an active call exists on this channel; 4 (Reserved) indicates that this channel has been reserved for use as a D-Channel or for use as a Synch-Channel for E-1.
OutboundBusyAttempts	This counter represents the total number of times that a call through the MGCP T1 CAS device was attempted when no voice channels were available.

## Cisco Music On Hold (MOH) Device

The Cisco Music On Hold (MOH) Device object provides information about registered Cisco MOH devices. [Table 6-22](#) contains information on Cisco MOH device counters.

**Table 6-22 Cisco MOH Device**

Counters	Counter Descriptions
MOHHighestActiveResources	This counter represents the largest number of simultaneously active MOH connections for an MOH server. This number includes both multicast and unicast connections.
MOHMulticastResourceActive	<p>This counter represents the number of currently active multicast connections to multicast addresses that are served by an MOH server.</p> <p>Each MOH multicast resource uses one stream for each audio source and codec combination. For example, if the default audio source is configured for multicast, G.711 mu-law and wideband codecs, two streams get used (default audio source + G.711 mu-law and default audio source + wideband).</p>
MOHMulticastResourceAvailable	<p>This counter represents the number of multicast MOH connections to multicast addresses that are served by an MOH server that are not active and are still available to be used now for the MOH server.</p> <p>Each MOH multicast resource uses one stream for each audio source and codec combination. For example, if the default audio source is configured for multicast, G.711 mu-law and wideband codecs, two streams get used (default audio source + G.711 mu-law and default audio source + wideband).</p>
MOHOutOfResources	This counter represents the total number of times that the Media Resource Manager attempted to allocate an MOH resource when all available resources on all MOH servers that are registered with a Cisco CallManager were already active.

**Table 6-22 Cisco MOH Device (continued)**

Counters	Counter Descriptions
MOHTotalMulticastResources	<p>This counter represents the total number of multicast MOH connections that are allowed to multicast addresses that are served by an MOH server.</p> <p>Each MOH multicast resource uses one stream for each audio source and codec combination. For example, if the default audio source is configured for multicast, G.711 mu-law and wideband codecs, two streams get used (default audio source + G.711 mu-law and default audio source + wideband).</p>
MOHTotalUnicastResources	<p>This counter represents the total number of unicast MOH connections that are allowed by an MOH server.</p> <p>Each MOH unicast resource uses one stream.</p>
MOHUnicastResourceActive	<p>This counter represents the number of active unicast MOH connections to an MOH server.</p> <p>Each MOH unicast resource uses one stream.</p>
MOHUnicastResourceAvailable	<p>This counter represents the number of unicast MOH connections that are not active and are still available to be used now for an MOH server.</p> <p>Each MOH unicast resource uses one stream.</p>

## Cisco MTP Device

The Cisco Media Termination Point (MTP) Device object provides information about registered Cisco MTP devices. [Table 6-23](#) contains information on Cisco MTP device counters.

**Table 6-23 Cisco MTP Device**

Counters	Counter Descriptions
OutOfResources	<p>This counter represents the total number of times that an attempt was made to allocate an MTP resource from an MTP device and failed; for example, because all resources were already in use.</p>
ResourceActive	<p>This counter represents the number of MTP resources that are currently in use (active) for an MTP device.</p> <p>Each MTP resource uses two streams. An MTP in use represents one MTP resource that has been allocated for use in a call.</p>
ResourceAvailable	<p>This counter represents the total number of MTP resources that are not active and are still available to be used now for an MTP device.</p> <p>Each MTP resource uses two streams. An MTP in use represents one MTP resource that has been allocated for use in a call.</p>
ResourceTotal	<p>This counter represents the total number of MTP resources that an MTP device provides. This counter equals the sum of the counters ResourceAvailable and ResourceActive.</p>



## Cisco Phones

The Cisco Phones object provides information about the number of registered Cisco IP Phones, including both hardware-based and other station devices.

The CallsAttempted counter represents the number of calls that have been attempted from this phone. This number increases each time that the phone goes off hook and on hook.

## Cisco Presence Feature

The Cisco Presence object provides information about presence subscriptions, such as statistics that are related to the speed dial or call list Busy Lamp Field (BLF) subscriptions. [Table 6-24](#) contains information on Cisco Presence feature.

**Table 6-24**      *Cisco Presence*

Counters	Counter Descriptions
ActiveCallListAndTrunkSubscriptions	This counter represents the active presence subscriptions for the call list feature as well as presence subscriptions through SIP trunk.
ActiveSubscriptions	This counter represents all active incoming and outgoing presence subscriptions.
CallListAndTrunkSubscriptionsThrottled	This counter represents the cumulative number of rejected call list and trunk side presence subscriptions due to throttling for the call list feature.
IncomingLineSideSubscriptions	This counter represents the cumulative number of presence subscriptions that were received on the line side.
IncomingTrunkSideSubscriptions	This counter represents the cumulative number of presence subscriptions that were received on the trunk side.
OutgoingTrunkSideSubscriptions	This counter represents the cumulative number of presence subscriptions that were sent on the trunk side.

## Cisco QSIG Features

The Cisco QSIG Feature object provides information regarding the operation of various QSIG features, such as call diversion and path replacement. [Table 6-25](#) contains information on the Cisco QSIG feature counters.

**Table 6-25** *Cisco QSIG*

Counters	Counter Descriptions
CallForwardByRerouteCompleted	This counter represents the number of successful calls that has been forwarded by rerouting. Call forward by rerouting enables the path for a forwarded call to be optimized (minimizes the number of B-Channels in use) from the originator's perspective. This counter gets reset when the Cisco CallManager service parameter Call Forward by Reroute Enabled is enabled or disabled, or when the Cisco CallManager service restarts.
PathReplacementCompleted	This counter represents the number of successful path replacements that have occurred. Path replacement in a QSIG network optimizes the path between two edge PINX (PBXs) that are involved in a call. This counter resets when the Cisco CallManager service parameter Path Replacement Enabled is enabled or disabled, or when the Cisco CallManager service restarts.

## Cisco SIP

The Cisco Session Initiation Protocol (SIP) object provides information about configured SIP devices. [Table 6-26](#) contains information on the Cisco SIP counters.

**Table 6-26** *Cisco SIP*

Counters	Counter Descriptions
CallsActive	This counter represents the number of calls that are currently active (in use) on this SIP device.
CallsAttempted	This counter represents the number of calls that have been attempted on this SIP device, including both successful and unsuccessful call attempts.
CallsCompleted	This counter represents the number of calls that were actually connected (a voice path was established) from a SIP device. This number increases when the call terminates.
CallsInProgress	This counter represents the number of calls that are currently in progress on a SIP device, including all active calls. When all calls that are in progress are connected, the number of CallsInProgress equals the number of CallsActive.

**Table 6-26 Cisco SIP (continued)**

Counters	Counter Descriptions
VideoCallsActive	This counter represents the number of video calls with streaming video connections that are currently active (in use) on this SIP device.
VideoCallsCompleted	This counter represents the number of video calls that were actually connected with video streams for this SIP device. This number increments when the call terminates.

## Cisco SIP Stack

The Cisco SIP Stack object provides information about Session Initiation Protocol (SIP) stack statistics that are generated or used by SIP devices such as SIP Proxy, SIP Redirect Server, SIP Registrar, and SIP User Agent. [Table 6-27](#) contains information on Cisco SIP Stack counters.

**Table 6-27 Cisco SIP Stack**

Counters	Counter Descriptions
AckIns	This counter represents the total number of ACK requests that the SIP device received.
AckOuts	This counter represents the total number of ACK requests that the SIP device sent.
ByeIns	This counter represents the total number of BYE requests that the SIP device received. This number includes retransmission.
ByeOuts	This counter represents the total number of BYE requests that the SIP device sent. This number includes retransmission.
CancelIns	This counter represents the total number of CANCEL requests that the SIP device received. This number includes retransmission.
CancelOuts	This counter represents the total number of CANCEL requests that the SIP device sent. This number includes retransmission.
GlobalFailedClassIns	This counter represents the total number of 6xx class SIP responses that the SIP device has received. This number includes retransmission. This class of responses indicates that a SIP device, which is providing a client function, received a failure response message. Generally, the responses indicate that a server had definitive information on a particular called party and not just the particular instance in the Request-URI.
GlobalFailedClassOuts	This counter represents the total number of 6xx class SIP responses that the SIP device sent. This number includes retransmission. This class of responses indicates that a SIP device, which is providing a client function, received a failure response message. Generally, the responses indicate that a server had definitive information on a particular called party and not just the particular instance in the Request-URI.

**Table 6-27 Cisco SIP Stack (continued)**

Counters	Counter Descriptions
InfoClassIns	This counter represents the total number of 1xx class SIP responses that the SIP device received. This includes retransmission. This class of responses provides information on the progress of a SIP request.
InfoClassOuts	This counter represents the total number of 1xx class SIP responses that the SIP device sent. This includes retransmission. This class of responses provides information on the progress of processing a SIP request.
InfoIns	This counter represents the total number of INFO requests that the SIP device has received. This number includes retransmission.
InfoOuts	This counter represents the total number of INFO requests that the SIP device has sent. This number includes retransmission.
InviteIns	This counter represents the total number of INVITE requests that the SIP device received. This number includes retransmission.
InviteOuts	This counter represents the total number of INVITE requests that the SIP device has sent. This number includes retransmission.
NotifyIns	This counter represents the total number of NOTIFY requests that the SIP device has received. This number includes retransmission.
NotifyOuts	This counter represents the total number of NOTIFY requests that the SIP device has sent. This number includes retransmission.
OptionsIns	This counter represents the total number of OPTIONS requests that the SIP device received. This number includes retransmission.
OptionsOuts	This counter represents the total number of OPTIONS requests that the SIP device has sent. This number includes retransmission.
PRackIns	This counter represents the total number of PRACK requests that the SIP device has received. This number includes retransmission.
PRackOuts	This counter represents the total number of PRACK requests that the SIP device has sent. This number includes retransmission.
RedirClassIns	This counter represents the total number of 3xx class SIP responses that the SIP device has received. This number includes retransmission. This class of responses provides information about redirections to addresses where the callee may be reachable.
RedirClassOuts	This counter represents the total number of 3xx class SIP responses that the SIP device has sent. This number includes retransmission. This class of responses provides information about redirections to addresses where the callee may be reachable.
ReferIns	This counter represents the total number of REFER requests that the SIP device has received. This number includes retransmission.
ReferOuts	This counter represents the total number of REFER requests that the SIP device has sent. This number includes retransmission.
RegisterIns	This counter represents the total number of REGISTER requests that the SIP device has received. This number includes retransmission.

**Table 6-27 Cisco SIP Stack (continued)**

Counters	Counter Descriptions
RegisterOuts	This counter represents the total number of REGISTER requests that the SIP device has sent. This number includes retransmission.
RequestsFailedClassIns	This counter represents the total number of 4xx class SIP responses that the SIP device has received. This number includes retransmission. This class of responses indicates a request failure by a SIP device that is providing a client function.
RequestsFailedClassOuts	This counter represents the total number of 4xx class SIP responses that the SIP device has sent. This number includes retransmission. This class of responses indicates a request failure by a SIP device that is providing a client function.
RetryByes	This counter represents the total number of BYE retries that the SIP device has sent. To determine the number of first BYE attempts, subtract the value of this counter from the value of the sipStatsByeOuts counter.
RetryCancels	This counter represents the total number of CANCEL retries that the SIP device has sent. To determine the number of first CANCEL attempts, subtract the value of this counter from the value of the sipStatsCancelOuts counter.
RetryInfo	This counter represents the total number of INFO retries that the SIP device has sent. To determine the number of first INFO attempts, subtract the value of this counter from the value of the sipStatsInfoOuts counter.
RetryInvites	This counter represents the total number of INVITE retries that the SIP device has sent. To determine the number of first INVITE attempts, subtract the value of this counter from the value of the sipStatsInviteOuts counter.
RetryNotify	This counter represents the total number of NOTIFY retries that the SIP device has sent. To determine the number of first NOTIFY attempts, subtract the value of this counter from the value of the sipStatsNotifyOuts counter.
RetryPRack	This counter represents the total number of PRACK retries that the SIP device has sent. To determine the number of first PRACK attempts, subtract the value of this counter from the value of the sipStatsPRackOuts counter.
RetryRefer	This counter represents the total number of REFER retries that the SIP device has sent. To determine the number of first REFER attempts, subtract the value of this counter from the value of the sipStatsReferOuts counter.
RetryRegisters	This counter represents the total number of REGISTER retries that the SIP device has sent. To determine the number of first REGISTER attempts, subtract the value of this counter from the value of the sipStatsRegisterOuts counter.
RetryRel1xx	This counter represents the total number of Reliable 1xx retries that the SIP device has sent.

**Table 6-27 Cisco SIP Stack (continued)**

Counters	Counter Descriptions
RetryResponsesFinal	This counter represents the total number of Final Response retries that the SIP device has sent.
RetryResponsesNonFinal	This counter represents the total number of non-Final Response retries the SIP device has sent.
RetrySubscribe	This counter represents the total number of SUBSCRIBE retries that the SIP device has sent. To determine the number of first SUBSCRIBE attempts, subtract the value of this counter from the value of the sipStatsSubscribeOuts counter.
RetryUpdate	This counter represents the total number of UPDATE retries that the SIP device has sent. To determine the number of first UPDATE attempts, subtract the value of this counter from the value of the sipStatsUpdateOuts counter.
ServerFailedClassIns	This counter represents the total number of 5xx class SIP responses that the SIP device has received. This number includes retransmission. This class of responses indicates that failure responses were received by a SIP device that is providing a client function.
ServerFailedClassOuts	This counter represents the total number of 5xx class SIP responses that the SIP device has sent. This number includes retransmission. This class of responses indicates that failure responses were received by a SIP device that is providing a client function.
StatusCode1xxIns	<p>This counter represents the total number of 1xx response messages, including retransmission, that the SIP device has received. This count includes the following 1xx responses:</p> <ul style="list-style-type: none"> <li>• 100 Trying</li> <li>• 180 Ringing</li> <li>• 181 Call is being forwarded</li> <li>• 182 Queued</li> <li>• 183 Session Progress</li> </ul>
StatusCode1xxOuts	<p>This counter represents the total number of 1xx response messages, including retransmission, that the SIP device has sent. This count includes the following 1xx responses:</p> <ul style="list-style-type: none"> <li>• 100 Trying</li> <li>• 180 Ringing</li> <li>• 181 Call is being forwarded</li> <li>• 182 Queued</li> <li>• 183 Session Progress</li> </ul>

**Table 6-27** *Cisco SIP Stack (continued)*

Counters	Counter Descriptions
StatusCode2xxIns	<p>This counter represents the total number of 2xx response messages, including retransmission, that the SIP device has received. This count includes the following 2xx responses:</p> <ul style="list-style-type: none"> <li>• 200 OK</li> <li>• 202 Success Accepted</li> </ul>
StatusCode2xxOuts	<p>This counter represents the total number of 2xx response messages, including retransmission, that the SIP device has sent. This count includes the following 2xx responses:</p> <ul style="list-style-type: none"> <li>• 200 OK</li> <li>• 202 Success Accepted</li> </ul>
StatusCode3xxins	<p>This counter represents the total number of 3xx response messages, including retransmission, that the SIP device has received. This count includes the following 3xx responses:</p> <ul style="list-style-type: none"> <li>• 300 Multiple Choices</li> <li>• 301 Moved Permanently</li> <li>• 302 Moved Temporarily</li> <li>• 303 Incompatible Bandwidth Units</li> <li>• 305 Use Proxy</li> <li>• 380 Alternative Service</li> </ul>
StatusCode302Outs	<p>This counter represents the total number of 302 Moved Temporarily response messages, including retransmission, that the SIP device has sent.</p>

**Table 6-27** *Cisco SIP Stack (continued)*

Counters	Counter Descriptions
StatusCode4xxIns	<p>This counter represents the total number of 4xx response messages, including retransmission, that the SIP device has received. This count includes the following 4xx responses:</p> <ul style="list-style-type: none"> <li>• 400 Bad Request</li> <li>• 401 Unauthorized</li> <li>• 402 Payment Required</li> <li>• 403 Forbidden</li> <li>• 404 Not Found</li> <li>• 405 Method Not Allowed</li> <li>• 406 Not Acceptable</li> <li>• 407 Proxy Authentication Required</li> <li>• 408 Request Timeout</li> <li>• 409 Conflict</li> <li>• 410 Gone</li> <li>• 413 Request Entity Too Large</li> <li>• 414 Request-URI Too Long</li> <li>• 415 Unsupported Media Type</li> <li>• 416 Unsupported URI Scheme</li> <li>• 417 Unknown Resource Priority</li> <li>• 420 Bad Extension</li> <li>• 422 Session Expires Value Too Small</li> <li>• 423 Interval Too Brief</li> <li>• 480 Temporarily Unavailable</li> <li>• 481 Call/Transaction Does Not Exist</li> <li>• 482 Loop Detected</li> <li>• 483 Too Many Hops</li> <li>• 484 Address Incomplete</li> <li>• 485 Ambiguous</li> <li>• 486 Busy Here</li> <li>• 487 Request Terminated</li> <li>• 488 Not Acceptable Here</li> <li>• 489 Bad Subscription Event</li> <li>• 491 Request Pending</li> </ul>



**Table 6-27 Cisco SIP Stack (continued)**

Counters	Counter Descriptions
StatusCode4xxOuts	<p>This counter represents the total number of 4xx response messages, including retransmission, that the SIP device has sent. This count includes the following 4xx responses:</p> <ul style="list-style-type: none"> <li>• 400 Bad Request</li> <li>• 401 Unauthorized</li> <li>• 402 Payment Required</li> <li>• 403 Forbidden</li> <li>• 404 Not Found</li> <li>• 405 Method Not Allowed</li> <li>• 406 Not Acceptable</li> <li>• 407 Proxy Authentication Required</li> <li>• 408 Request Timeout</li> <li>• 409 Conflict</li> <li>• 410 Gone</li> <li>• 413 Request Entity Too Large</li> <li>• 414 Request-URI Too Long</li> <li>• 415 Unsupported Media Type</li> <li>• 416 Unsupported URI Scheme</li> <li>• 417 Unknown Resource Priority</li> <li>• 420 Bad Extension</li> <li>• 422 Session Expires Value Too Small</li> <li>• 423 Interval Too Brief</li> <li>• 480 Temporarily Unavailable</li> <li>• 481 Call/Transaction Does Not Exist</li> <li>• 482 Loop Detected</li> <li>• 483 Too Many Hops</li> <li>• 484 Address Incomplete</li> <li>• 485 Ambiguous</li> <li>• 486 Busy Here</li> <li>• 487 Request Terminated</li> <li>• 488 Not Acceptable Here</li> <li>• 489 Bad Subscription Event</li> <li>• 491 Request Pending</li> </ul>

**Table 6-27** *Cisco SIP Stack (continued)*

Counters	Counter Descriptions
StatusCode5xxIns	<p>This counter represents the total number of 5xx response messages, including retransmission, that the SIP device has received. This count includes the following 5xx responses:</p> <ul style="list-style-type: none"> <li>• 500 Server Internal Error</li> <li>• 501 Not Implemented</li> <li>• 502 Bad Gateway</li> <li>• 503 Service Unavailable</li> <li>• 504 Server Timeout</li> <li>• 505 Version Not Supported</li> <li>• 580 Precondition Failed</li> </ul>
StatusCode5xxOuts	<p>This counter represents the total number of 5xx response messages, including retransmission, that the SIP device has sent. This count includes the following 5xx responses:</p> <ul style="list-style-type: none"> <li>• 500 Server Internal Error</li> <li>• 501 Not Implemented</li> <li>• 502 Bad Gateway</li> <li>• 503 Service Unavailable</li> <li>• 504 Server Timeout</li> <li>• 505 Version Not Supported</li> <li>• 580 Precondition Failed</li> </ul>
StatusCode6xxIns	<p>This counter represents the total number of 6xx response messages, including retransmission, that the SIP device has received. This count includes the following 6xx responses:</p> <ul style="list-style-type: none"> <li>• 600 Busy Everywhere</li> <li>• 603 Decline</li> <li>• 604 Does Not Exist Anywhere</li> <li>• 606 Not Acceptable</li> </ul>
StatusCode6xxOuts	<p>This counter represents the total number of 6xx response messages, including retransmission, that the SIP device has sent. This count includes the following 6xx responses:</p> <ul style="list-style-type: none"> <li>• 600 Busy Everywhere</li> <li>• 603 Decline</li> <li>• 604 Does Not Exist Anywhere</li> <li>• 606 Not Acceptable</li> </ul>
SubscribeIns	<p>This counter represents the total number of SUBSCRIBE requests that the SIP device has received. This number includes retransmission.</p>

**Table 6-27** *Cisco SIP Stack (continued)*

Counters	Counter Descriptions
SubscribeOuts	This counter represents the total number of SUBSCRIBE requests that the SIP device has sent. This number includes retransmission.
SuccessClassIns	This counter represents the total number of 2xx class SIP responses that the SIP device has received. This includes retransmission. This class of responses provides information on the successful completion of a SIP request.
SuccessClassOuts	This counter represents the total number of 2xx class SIP responses that the SIP device has sent. This includes retransmission. This class of responses provides information on the successful completion of a SIP request.
SummaryRequestsIn	This counter represents the total number of SIP request messages that have been received by the SIP device. This number includes retransmissions.
SummaryRequestsOut	This counter represents the total number of SIP request messages that the device sent. This number includes messages that originate on the device and messages that are being relayed by the device. When a particular message gets sent more than once, each transmission gets counted separately; for example, a message that is re-sent as a retransmission or as a result of forking.
SummaryResponsesIn	This counter represents the total number of SIP response messages that the SIP device received. This number includes retransmission.
SummaryResponsesOut	This counter represents the total number of SIP response messages that the SIP device sent (originated and relayed). This number includes retransmission.
UpdateIns	This counter represents the total number of UPDATE requests that the SIP device has received. This number includes retransmission.
UpdateOuts	This counter represents the total number of UPDATE requests that the SIP device has sent. This number includes retransmission.

## Cisco SW Conf Bridge Device

The Cisco SW Conference Bridge Device object provides information about registered Cisco software conference bridge devices. [Table 6-28](#) contains information on the Cisco software conference bridge device counters.

**Table 6-28** *Cisco SW Conf Bridge Device*

Counters	Counter Descriptions
OutOfResources	This counter represents the total number of times that an attempt was made to allocate a conference resource from a SW conference device and failed because all resources were already in use.
ResourceActive	This counter represents the number of resources that are currently in use (active) for a SW conference device. One resource represents one stream.

**Table 6-28 Cisco SW Conf Bridge Device (continued)**

Counters	Counter Descriptions
ResourceAvailable	This counter represents the total number of resources that are not active and are still available to be used now for a SW conference device. One resource represents one stream.
ResourceTotal	This counter represents the total number of conference resources that a SW conference device provides. One resource represents one stream. This counter equals the sum of the ResourceAvailable and ResourceActive counters.
SWConferenceActive	This counter represents the number of software-based conferences that are currently active (in use) on a SW conference device.
SWConferenceCompleted	This counter represents the total number of conferences that have been allocated and released on a SW conference device. A conference starts when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.

## Cisco TFTP Server

The Cisco Trivial File Transfer Protocol (TFTP) Server object provides information about the Cisco TFTP server. [Table 6-29](#) contains information on Cisco TFTP server counters.

**Table 6-29 Cisco TFTP Server**

Counters	Counter Descriptions
BuildAbortCount	This counter represents the number of times that the build process aborted when it received a Build all request. This counter increases when building of device/unit/softkey/dialrules gets aborted as a result of group level change notifications.
BuildCount	This counter represents the number of times since the TFTP service started that the TFTP server has built all the configuration files in response to a database change notification that affects all devices. This counter increases by one every time the TFTP server performs a new build of all the configuration files.
BuildDeviceCount	This counter represents the number of devices that were processed in the last build of all the configuration files. This counter also updates while processing device change notifications. The counter increases when a new device is added and decreases when an existing device is deleted.
BuildDialruleCount	This counter represents the number of dial rules that were processed in the last build of the configuration files. This counter also updates while processing dial rule change notifications. The counter increases when a new dial rule is added and decreases when an existing dial rule is deleted.
BuildDuration	This counter represents the time in seconds that it took to build the last of all the configuration files.

**Table 6-29 Cisco TFTP Server (continued)**

Counters	Counter Descriptions
BuildSignCount	This counter represents the number of security-enabled phone devices for which the configuration file was digitally signed with the Cisco CallManager server key in the last build of all the configuration files. This counter also updates while processing security-enabled phone device change notifications.
BuildSoftKeyCount	This counter represents the number of softkeys that were processed in the last build of the configuration files. This counter increments when a new softkey is added and decrements when an existing softkey is deleted.
BuildUnitCount	This counter represents the number of gateways that were processed in the last build of all the configuration files. This counter also updates while processing unit change notifications. The counter increases when a new gateway is added and decreases when an existing gateway is deleted.
ChangeNotifications	This counter represents the total number of all the Cisco CallManager database change notifications that the TFTP server received. Each time that a device configuration is updated in Cisco CallManager Administration, the TFTP server gets sent a database change notification to rebuild the XML file for the updated device.
DeviceChangeNotifications	This counter represents the number of times that the TFTP server received database change notification to create, update, or delete configuration files for devices.
DialruleChangeNotifications	This counter represents the number of times that the TFTP server received database change notification to create, update, or delete configuration files for dial rules.
EncryptCount	This counter represents the number of configuration files that were encrypted. This counter gets updated each time a configuration file is successfully encrypted
GKFoundCount	This counter represents the number of GK files that were found in the cache. This counter gets updated each time a GK file is found in the cache
GKNotFoundCount	This counter represents the number of GK files that were not found in the cache. This counter gets updated each time a request to get a GK file results in the cache not finding it
HeartBeat	This counter represents the heartbeat of the TFTP server. This incremental count indicates that the TFTP server is up and running. If the count does not increase, this means that the TFTP server is down.
HttpConnectRequests	This counter represents the number of clients that are currently requesting the HTTP GET file request.

**Table 6-29 Cisco TFTP Server (continued)**

Counters	Counter Descriptions
HttpRequests	This counter represents the total number of file requests (such as requests for XML configuration files, phone firmware files, audio files, and so on.) that the HTTP server handled. This counter represents the sum total of the following counters since the HTTP service started: RequestsProcessed, RequestsNotFound, RequestsOverflow, RequestsAborted, and RequestsInProgress.
HttpRequestsAborted	This counter represents the total number of HTTP requests that the HTTP server canceled (aborted) unexpectedly. Requests could get aborted if the requesting device cannot be reached (for instance, the device lost power) or if the file transfer was interrupted due to network connectivity problems.
HttpRequestsNotFound	This counter represents the total number of HTTP requests where the requested file was not found. When the HTTP server does not find the requested file, a message gets sent to the requesting device.
HttpRequestsOverflow	This counter represents the total number of HTTP requests that were rejected when the maximum number of allowable client connections was reached. The requests may have arrived while the TFTP server was building the configuration files or because of some other resource limitation. The Cisco TFTP advanced service parameter, Maximum Serving Count, sets the maximum number of allowable connections.
HttpRequestsProcessed	This counter represents the total number of HTTP requests that the HTTP server successfully processed.
HttpServedFromDisk	This counter represents the number of requests that the HTTP server completed with the files that are on disk and not cached in memory.
LDFoundCount	This counter represents the number of LD files that were found in the cache. This counter gets updated each time a LD file is found in cache memory.
LDNotFoundCount	This counter represents the number of LD files that were not found in cache memory. This counter gets updated each time a request to get an LD file results in the cache not finding it.
MaxServingCount	This counter represents the maximum number of client connections that the TFTP can serve simultaneously. The Cisco TFTP advanced service parameter, Maximum Serving Count, sets this value.
Requests	This counter represents the total number of file requests (such as requests for XML configuration files, phone firmware files, audio files, and so on.) that the TFTP server handles. This counter represents the sum total of the following counters since the TFTP service started: RequestsProcessed, RequestsNotFound, RequestsOverflow, RequestsAborted, and RequestsInProgress.
RequestsAborted	This counter represents the total number of TFTP requests that the TFTP server canceled (aborted) unexpectedly. Requests could be aborted if the requesting device cannot be reached (for instance, the device lost power) or if the file transfer was interrupted due to network connectivity problems.

**Table 6-29 Cisco TFTP Server (continued)**

Counters	Counter Descriptions
RequestsInProgress	This counter represents the number of file requests that the TFTP server currently is processing. This counter increases for each new file request and decreases for each file request that is completed. This counter indicates the current load of the TFTP server.
RequestsNotFound	This counter represents the total number of TFTP requests where the requested file was not found. When the TFTP server does not find the requested file, a message gets sent to the requesting device.
RequestsOverflow	This counter represents the total number of TFTP requests that were rejected because the maximum number of allowable client connections was exceeded, because requests arrived while the TFTP server was building the configuration files, or because of some other resource limitation. The Cisco TFTP advanced service parameter, Maximum Serving Count, sets the maximum number of allowable connections.
RequestsProcessed	This counter represents the total number of TFTP requests that the TFTP server successfully processed.
SegmentsAcknowledged	This counter represents the total number of data segments that the client devices acknowledged. Files get sent to the requesting device in data segments of 512 bytes, and for each 512-byte segment, the device sends the TFTP server an acknowledgment message. Each additional data segment gets sent upon receipt of the acknowledgment for the previous data segment until the complete file is successfully transmitted to the requesting device.
SegmentsFromDisk	This counter represents the number of data segments that the TFTP server reads from the files on disk, while serving files.
SegmentSent	This counter represents the total number of data segments that the TFTP server sent. Files get sent to the requesting device in data segments of 512 bytes.
SEPFoundCount	This counter represents the number of SEP files that were successfully found in the cache. This counter gets updated each time a SEP file is found in the cache.
SEPNotFoundCount	This counter represents the number of SEP files that were not found in the cache. This counter gets updated each time a request to get a SEP file produces a not found in cache memory result.
SIPFoundCount	This counter represents the number of SIP files that were successfully found in the cache. This counter gets updated each time a SIP file is found in the cache.
SIPNotFoundCount	This counter represents the number of SIP files that were not found in the cache. This counter gets updated each time a request to get a SIP file produces a not found in cache memory result.

**Table 6-29 Cisco TFTP Server (continued)**

Counters	Counter Descriptions
SoftkeyChangeNotifications	This counter represents the number of times that the TFTP server has received database change notification to create, update, or delete configuration files for softkeys.
UnitChangeNotifications	This counter represents the number of times that the TFTP server received database change notification to create, update, or delete gateway-related configuration files.

## Cisco Tomcat Connector

The Tomcat Hypertext Transport Protocol (HTTP)/HTTP Secure (HTTPS) Connector object provides information about Tomcat connectors. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related web pages are accessed. The Secure Socket Layer (SSL) status of the URLs for web applications provides the basis for the instance name for each Tomcat HTTP Connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL. [Table 6-30](#) contains information on the Tomcat HTTP connector counters.

**Table 6-30 Cisco Tomcat Connector**

Counters	Counter Description
Errors	This counter represents the total number of HTTP errors (for example, 401 Unauthorized) that the connector encountered. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL.
MBytesReceived	This counter represents the amount of data that the connector received. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL.



**Table 6-30 Cisco Tomcat Connector (continued)**

Counters	Counter Description
MBytesSent	This counter represents the amount of data that the connector sent. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL.
Requests	This counter represents the total number of HTTP errors (for example, 401 Unauthorized) that the connector encountered. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL.
Threads Total	This counter represents the connectors current total number of request processing threads, including available and in-use threads. A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://<IP Address>:8443 for SSL or http://<IP Address>:8080 for non-SSL.
Threads Max	<p>This counter represents the connector's maximum number of request processing threads. Each incoming request on a Cisco CallManager related window requires a thread for the duration of that request. If more simultaneous requests are received than the currently available request processing threads can handle, additional threads will be created up to the configured maximum shown in this counter. If still more simultaneous requests are received, they accumulate within the server socket that the connector created, up to an internally specified maximum number. Any further simultaneous requests will receive connection refused messages until resources are available to process them.</p> <p>A Tomcat HTTP connector represents an endpoint that receives requests and sends responses. The Connector handles HTTP/HTTPS requests and sends HTTP/HTTPS responses that occur when Cisco CallManager related windows are accessed. The Secure Socket Layer (SSL) status of the URLs for the web application provides basis for the instance name for each Tomcat HTTP connector. For example, https://&lt;IP Address&gt;:8443 for SSL or http://&lt;IP Address&gt;:8080 for non-SSL.</p>

# Cisco Tomcat JVM

The Cisco Tomcat Java Virtual Machine (JVM) object provides information about the Tomcat JVM, which represents, among other things, a pool of common resource memory that Cisco CallManager related web applications such as Cisco CallManager Administration, Cisco CallManager Serviceability, and more use. [Table 6-31](#) contains information on the Tomcat JVM counters.

**Table 6-31** *Tomcat JVM*

Counters	Counter Description
KBytes Memory Free	This counter represents the amount of free dynamic memory block (heap memory) in the Tomcat Java Virtual Machine. The dynamic memory block stores all objects that Tomcat and its web applications such as Cisco CallManager Administration and Cisco CallManager Serviceability create. When the amount of free dynamic memory is low, more memory gets automatically allocated, and total memory size (represented by the KbytesMemoryTotal counter) increases but only up to the maximum (represented by the KbytesMemoryMax counter). You can determine the amount of memory in use by subtracting KBytesMemoryFree from KbytesMemoryTotal.
KBytes Memory Max	This counter represents the amount of free dynamic memory block (heap memory) in the Tomcat Java Virtual Machine. The dynamic memory block stores all objects that Tomcat and its web applications such as Cisco CallManager Administration and Cisco CallManager Serviceability create. When the amount of free dynamic memory is low, more memory gets automatically allocated, and total memory size (represented by the KbytesMemoryTotal counter) increases but only up to the maximum (represented by the KbytesMemoryMax counter). You can determine the amount of memory in use by subtracting KBytesMemoryFree from KbytesMemoryTotal.
KBytes Memory Total	This counter represents the Tomcat Java Virtual Machine's current total dynamic memory block size including free and in-use memory.

# Cisco Tomcat Web Application

The Cisco Tomcat Web Application object provides information about how to running Cisco CallManager web applications. The URLs for the web application provide basis for the instance name for each Tomcat Web Application. For example, Cisco CallManager Administration (<https://<IP Address>:8443/ccmadmin>) gets identified by `ccmadmin`, Cisco CallManager Serviceability gets identified by `ccmservice`, Cisco CallManager User Options gets identified by `ccmuser`, and URLs that do not have an extension, such as <https://<IP Address>:8443> or <http://<IP Address>:8080>), get identified by `_root`. [Table 6-32](#) contains information on the Tomcat Web Application counters.

**Table 6-32 Tomcat Web Application**

Counters	Counter Description
Errors	This counter represents the total number of HTTP errors (for example, 401 Unauthorized) that a Cisco CallManager related web application encountered. The URLs for the web application provide the basis instance name for each Tomcat Web Application. For example, Cisco CallManager Administration ( <a href="https://&lt;IP Address&gt;:8443/ccmadmin">https://&lt;IP Address&gt;:8443/ccmadmin</a> ) gets identified by <code>ccmadmin</code> , Cisco CallManager Serviceability gets identified by <code>ccmservice</code> , Cisco CallManager User Options gets identified by <code>ccmuser</code> , and URLs that do not have an extension, such as <a href="https://&lt;IP Address&gt;:8443">https://&lt;IP Address&gt;:8443</a> or <a href="http://&lt;IP Address&gt;:8080">http://&lt;IP Address&gt;:8080</a> ), get identified by <code>_root</code> .
Requests	This counter represents the total number of requests that the web application handles. Each time that a web application is accessed, its Requests counter increments accordingly. The URLs for the web application provide the basis instance name for each Tomcat Web Application. For example, Cisco CallManager Administration ( <a href="https://&lt;IP Address&gt;:8443/ccmadmin">https://&lt;IP Address&gt;:8443/ccmadmin</a> ) gets identified by <code>ccmadmin</code> , Cisco CallManager Serviceability gets identified by <code>ccmservice</code> , Cisco CallManager User Options gets identified by <code>ccmuser</code> , and URLs that do not have an extension, such as <a href="https://&lt;IP Address&gt;:8443">https://&lt;IP Address&gt;:8443</a> or <a href="http://&lt;IP Address&gt;:8080">http://&lt;IP Address&gt;:8080</a> ), get identified by <code>_root</code> .
Sessions Active	This counter represents the number of sessions that the web application currently has active (in use). The URLs for the web application provide the basis instance name for each Tomcat Web Application. For example, Cisco CallManager Administration ( <a href="https://&lt;IP Address&gt;:8443/ccmadmin">https://&lt;IP Address&gt;:8443/ccmadmin</a> ) gets identified by <code>ccmadmin</code> , Cisco CallManager Serviceability gets identified by <code>ccmservice</code> , Cisco CallManager User Options gets identified by <code>ccmuser</code> , and URLs that do not have an extension, such as <a href="https://&lt;IP Address&gt;:8443">https://&lt;IP Address&gt;:8443</a> or <a href="http://&lt;IP Address&gt;:8080">http://&lt;IP Address&gt;:8080</a> ), get identified by <code>_root</code> .

## Cisco Transcode Device

The Cisco Transcode Device object provides information about registered Cisco transcoding devices. [Table 6-33](#) contains information on Cisco transcoder device counters.

**Table 6-33** *Cisco Transcode Device*

Counters	Counter Descriptions
OutOfResources	This counter represents the total number of times that an attempt was made to allocate a transcoder resource from a transcoder device and failed; for example, because all resources were already in use.
ResourceActive	This counter represents the number of transcoder resources that are currently in use (active) for a transcoder device. Each transcoder resource uses two streams.
ResourceAvailable	This counter represents the total number of resources that are not active and are still available to be used now for a transcoder device. Each transcoder resource uses two streams.
ResourceTotal	This counter represents the total number of transcoder resources that a transcoder device provided. This counter equals the sum of the counters ResourceActive and ResourceAvailable.

## Cisco Video Conference Bridge

The Cisco Video Conference Bridge object provides information about registered Cisco video conference bridge devices. [Table 6-34](#) contains information on Cisco video conference bridge device counters.

**Table 6-34** *Cisco Video Conference Bridge*

Counters	Counter Descriptions
ConferenceActive	This counter represents the total number of video conferences that are currently active (in use) on a video conference bridge device. The system specifies a conference as active when the first call connects to the bridge.
ConferenceAvailable	This counter represents the number of video conferences that are not active and are still available on a video conference device.
ConferenceCompleted	This counter represents the total number of video conferences that have been allocated and released on a video conference device. A conference starts when the first call connects to the bridge. The conference completes when the last call disconnects from the bridge.
ConferenceTotal	This counter represents the total number of video conferences that are configured for a video conference device.

**Table 6-34** *Cisco Video Conference Bridge (continued)*

Counters	Counter Descriptions
OutOfConferences	This counter represents the total number of times an attempt was made to initiate a video conference from a video conference device and failed because the device already had the maximum number of active conferences allowed (as specified by the TotalConferences counter).
OutOfResources	This counter represents the total number of times that an attempt was made to allocate a conference resource from a video conference device and failed, for example, because all resources were already in use.
ResourceActive	This counter represents the total number of resources that are currently active (in use) on a video conference bridge device. One resource gets used per participant.
ResourceAvailable	This counter represents the total number of resources that are not active and are still available on a device to handle additional participants for a video conference bridge device.
ResourceTotal	This counter represents the total number of resources that are configured on a video conference bridge device. One resource gets used per participant.

## Cisco WebDialer

The Cisco WebDialer object provides information about the Cisco WebDialer application and the Redirector servlet. [Table 6-35](#) contains information on the Cisco WebDialer counters.

**Table 6-35** *Cisco WebDialer*

Counters	Counter Descriptions
CallsCompleted	This counter represents the number of Make Call and End Call requests that the Cisco WebDialer application successfully completed.
CallsFailed	This counter represents the number of Make Call and End Call requests that were unsuccessful.
RedirectorSessionsHandled	This counter represents the total number of HTTP sessions that the Redirector servlet handled since the last service startup.
RedirectorSessionsInProgress	This counter represents the number of HTTP sessions that are currently being serviced by the Redirector servlet.
RequestsCompleted	This counter represents the number of Make Call and End Call requests that the WebDialer servlet has successfully completed.
RequestsFailed	This counter represents the number of Make Call and End Call requests that failed.
SessionsHandled	This counter represents the total number of CTI sessions that the Cisco WebDialer servlet handled since the last service startup.
SessionsInProgress	This counter represents the number of CTI sessions that the Cisco WebDialer servlet is currently servicing.

## Cisco WSM Connector

The WSM object provides information on WSMConnectors that are configured on Cisco CallManager. Each WSMConnector represents a physical Motorola WSM device. [Table 6-36](#) contains information on the Cisco WSM Connector counters.

**Table 6-36** Cisco WSM Connector

Counters	Counter Description
CallsActive	This counter represents the number of calls that are currently active (in use) on the WSMConnector device.
CallsAttempted	This counter represents the number of calls that have been attempted on the WSMConnector device, including both successful and unsuccessful call attempts.
CallsCompleted	This counter represents the number of calls that are connected (a voice path was established) through the WSMConnector device. The counter increments when the call terminates.
CallsInProgress	This counter represents the number of calls that are currently in progress on the WSMConnector device. This includes all active calls. When the number of CallsInProgress equals the number of CallsActive, this indicates that all calls are connected.
DMMSRegistered	This counter represents the number of DMMS subscribers that are registered to the WSM.

## Database Change Notification Client

The Database Change Notification Client object provides information on change notification clients. [Table 6-37](#) contains information on the Database Change Notification Client counters.

**Table 6-37** Database Change Notification Client

Counters	Counter Descriptions
MessagesProcessed	This counter represents the number of database change notifications that have been processed.
MessagesProcessing	This counter represents the number of change notification messages that are currently being processed or are waiting to be processed in the change notification queue for this client.
QueueHeadPointer	This counter represents the head pointer to the change notification queue. The head pointer acts as the starting point in the change notification queue. To determine the number of notifications in the queue, subtract the tail pointer value from the head pointer value. By default, this counter refreshes every 15 seconds.
QueueMax	This counter represents the largest number of change notification messages that will be processed for this client.

**Table 6-37 Database Change Notification Client (continued)**

Counters	Counter Descriptions
QueueTailPointer	This counter represents the tail pointer to the change notification queue. The tail pointer represents the ending point in the change notification queue. To determine the number of notifications in the queue, subtract the tail pointer value from the head pointer value. By default, this counter refreshes every 15 seconds
TablesSubscribed	This counter represents the number of tables in which this client has subscribed.

## Database Change Notification Server

The Database Change Notification Server object provides information on different change-notification-related statistics. [Table 6-37](#) contains information on the Database Change Notification Server counters.

**Table 6-38 Database Change Notification Server**

Counter	Counter Descriptions
Clients	This counter represents the number of change notification clients (services/servlets) that have subscribed for change notification.
QueuedRequestsInDB	This counter represents the number of change notification records that are in the DBCNQueue (Database Change Notification Queue) table via direct TCP/IP connection (not queued in shared memory). This counter refreshes every 15 seconds.
QueuedRequestsInMemory	This counter represents the number of change notification requests that are queued in the DBCNQueue (Database Change Notification Queue) table in shared memory (rather than via direct TCP/IP connection).

## Database Change Notification Subscription

The Database Change Notification Subscription object displays the names of tables where the client will receive Change Notifications.

The SubscribedTable object displays the database table with the service or servlet that will receive change notifications. Because the counter does not increment, this display occurs for informational purposes only

## Database Layer Monitor

The Database Layer object collects information on the Cisco CallManager database as the Cisco Database Layer Monitor collects it.

The Cisco Database Layer Monitor service has responsibility for device resets. The ResetsQueued counter represents the number of records with devices that are currently resetting or queued to be reset. The counter only includes the resets that administrators invoke when they click on the Reset button on the device configuration window.

## Database Local DSN

The Database Local Data Source Name (DSN) object and LocalDSN counter provide the DSN information for the local machine. [Table 6-39](#) contains information on the Database local DSN.

**Table 6-39 Database Local Data Source Name**

Counters	Counter Descriptions
CcmDbSpace_Used	This counter represents the amount of CcmDbSpace that is being consumed
CcmtempDbSpace_Used	This counter represents the amount of CcmtempDbSpace that is being consumed.
LocalDSN	This counter represents the DSN that is being referenced from the local machine.
RootDbSpace_Used	This counter represents the amount of RootDbSpace that is being consumed.

## DB User Host Information Counters

The DB User Host Information object provides information on DB User Host.

The DB:User:Host Instance object displays the number of connections that are present for each instance of DB:User:Host.

## Enterprise Replication DBSpace Monitors

The enterprise replication DBSpace monitors object displays the usage of various ER DbSpaces. [Table 6-40](#) contains information on the enterprise replication DB monitors.

**Table 6-40 Enterprise Replication DBSpace Monitors**

Counters	Counter Descriptions
ERDbSpace_Used	This counter represents the amount of ERDbSpace that was consumed.
ERSBDbSpace_Used	This counter represents the amount of ERSBDbSpace that was consumed.

## Enterprise Replication Perfmon Counters

The Enterprise Replication Perfmon Counter object provides information on the various replication counters.

The ServerName:ReplicationQueueDepth counter displays information on the Q parameter.



# IP

The IP object provides information on the IP statistics on your system. [Table 6-41](#) contains information on the IP counters.

**Table 6-41** IP

Counters	Counter Descriptions
Frag Creates	This counter represents the number of IP datagrams fragments that have been generated.
Frag Fails	This counter represents the number of IP datagrams that were discarded at this entity because the datagrams could not be fragmented, such as datagrams where the Do not Fragment flag was set.
Frag OKs	This counter represents the number of IP datagrams that were successfully fragmented at this entity.
In Delivers	This counter represents the number of input datagrams that were delivered to IP user protocols (including ICMP).
In Discards	This counter represents the number of input datagrams without errors that were discarded. This counter does not include any datagrams that were discarded while awaiting reassembly.
In HdrErrors	This counter represents the number of input datagrams with header errors that were discarded. This includes bad checksums, version number mismatch, other format errors, time-to-live exceeded, and other errors that were discovered in processing their IP options.
In Receives	This counter represents the number of input datagrams that were received. This counter includes datagrams that were received with errors
In UnknownProtos	This counter represents the number of locally addressed datagrams that were received successfully but discarded because of an unknown or unsupported protocol.
InOut Requests	This counter represents the number of incoming IP datagrams that were received and the number of outgoing IP datagrams that were requested.
Out Discards	This counter represents the number of output IP datagrams that were not transmitted and were discarded. Lack of buffer space provides one possible reason.
Out Requests	This counter represents the number of IP datagrams that were requested by local IP user protocols (including ICMP) to IP requesting transmission.
Reasm Fails	This counter represents the number of IP reassembly failures that the IP reassembly algorithm detected.
Reasm OKs	This counter represents the number of IP datagrams that were successfully reassembled.
Reasm Reqds	This counter represents the number of IP fragments that were received that required reassembly.

# Memory

The memory object provides information about the usage of physical memory and swap memory on the server. [Table 6-42](#) contains information on memory counters.

**Table 6-42**      *Memory*

Counters	Counter Descriptions
% Mem Used	This counter displays the system physical memory utilization as a percentage.
% Page Usage	This counter represents the percentage of active pages.
% VM Used	This counter displays the system virtual memory utilization as a percentage.
Buffered KBytes	This counter represents the capacity of buffers in your system in kilobytes.
Cached KBytes	This counter represents the amount of cached memory in kilobytes.
Free KBytes	This counter represents the total amount of memory that is available in your system in kilobytes.
Free Swap KBytes	This counter represents the amount of free swap space that is available in your system in kilobytes.
Pages	This counter represents the number of pages that the system paged in from the disk plus the number of pages that the system paged out to the disk.
Pages Input	This counter represents the number of pages that the system paged in from the disk.
Pages Output	This counter represents the number of pages that the system paged out to the disk.
Shared KBytes	This counter represents the amount of shared memory in your system in kilobytes.
Total KBytes	This counter represents the total amount of memory in your system in kilobytes.
Total Swap KBytes	This counter represents the total amount of swap space in your system in kilobytes.
Used KBytes	This counter represents the amount of memory that is in use on the system in kilobytes.
Used Swap KBytes	This counter represents the amount of swap space that is in use on your system in kilobytes.

## Network Interface

The network interface object provides information about the network interfaces on the system. [Table 6-43](#) contains information on network interface counters.

**Table 6-43 Network Interface**

Counters	Counter Descriptions
Rx Bytes	This counter represents the number of bytes, including framing characters, that were received on the interface.
Rx Dropped	This counter represents the number of inbound packets that were chosen to be discarded even though no errors had been detected. This prevents the packet from being delivered to a higher layer protocol. Discarding packets to free up buffer space provides one reason.
Rx Errors	This counter represents the number of inbound packets (packet-oriented interfaces) and the number of inbound transmission units (character-oriented or fixed-length interfaces) that contained errors that prevented them from being deliverable to a higher layer protocol.
Rx Multicast	This counter represents the number of multicast packets that were received on this interface.
Rx Packets	This counter represents the number of packets that this sublayer delivered to a higher sublayer. This does not include the packets that were addressed to a multicast or broadcast address at this sublayer.
Total Bytes	This counter represents the total number of Rx bytes and Tx bytes.
Total Packets	This counter represents the total number of Rx packets and Tx packets.
Tx Bytes	This counter represents the total number of octets, including framing characters, that were transmitted out from the interface.
Tx Dropped	This counter represents the number of outbound packets that were chosen to be discarded even though no errors were detected. This action prevents the packet from being delivered to a higher layer protocol. Discarding a packet to free up buffer space. represents one reason.
Tx Errors	This counter represents the number of outbound packets (packet-oriented interfaces) and the number of outbound transmission units (character-oriented or fixed-length interfaces) that could not be transmitted because of errors.
Tx Packets	This counter represents the total number of packets that the higher level protocols requested for transmission, including those that were discarded or not sent. This does not include packets that were addressed to a multicast or broadcast address at this sublayer.
Tx QueueLen	This counter represents the length of the output packet queue (in packets).

## Number of Replicates Created and State of Replication

The Number of Replicates Created and State of Replication object provides information about the replication state on the system. [Table 6-44](#) contains information on replication counters.

**Table 6-44**      *Number of Replicates Created and State of Replication*

Counters	Counter Descriptions
Number of Replicates Created	This counter represents the number of replicates that have been created.
Replicate_State	This counter represents the state of replication. Possible values: 0-Not Started;1-Started; 2-Finished;3-Broken.

## Partition

The partition object provides information about the file system and its usage in the system. [Table 6-45](#) contains information on partition counters.

**Table 6-45**      *Partition*

Counters	Counter Descriptions
% CPU Time	This counter represents the percentage of CPU time that is dedicated to handling IO requests that were issued to the disk.
% Used	This counter represents the percentage of disk space that is in use on this file system.
% Wait in Read	This counter represents the percentage of CPU time that is spent waiting to read from the disk.
% Wait in Write	This counter represents the percentage of CPU time that is waiting to write to the disk.
Queue Length	This counter represents the average queue length for the requests that were issued to the disk.
Read Bytes Per Sec	This counter represents the amount of data that was read from the disk in kilobytes per second.
Total Mbytes	This counter represents the amount of total disk space that is on this file system in megabytes.
Used Mbytes	This counter represents the amount of disk space that is in use on this file system in megabytes.
Write Bytes Per Sec	This counter represents the amount of data that was written to the disk in kilobytes per second.

## Process

The process object provides information about the processes that are running on the system. [Table 6-46](#) contains information on process counters.

**Table 6-46**      **Process**

Counters	Counter Descriptions
% CPU Time	This counter, which is expressed as a percentage of total CPU time, represents the tasks share of the elapsed CPU time since the last update.
% MemoryUsage	This counter represents the percentage of physical memory that a task is currently using.
Data Stack Size	This counter represents the stack size for task memory status.
Nice	This counter represents the nice value of the task. A negative nice value indicates that the process has a higher priority while a positive nice value indicates that the process has a lower priority. If the nice value equals zero, do not adjust the priority when you are determining the dispatchability of a task.
Page Fault Count	This counter represents the number of major page faults that a task encountered that required the data to be loaded into memory.
PID	This counter displays the task-unique process ID. The ID periodically wraps, but the value will never equal zero.
Process Status	This counter displays the process status: <ul style="list-style-type: none"> <li>• 0 - Running</li> <li>• 1 - Sleeping</li> <li>• 2 - Uninterruptible disk sleep</li> <li>• 3 - Zombie</li> <li>• 4 - Traced</li> <li>• 5 - Paging</li> <li>• 6 - Unknown</li> </ul>
Shared Memory Size	This counter displays the amount of shared memory (KB) that a task is using. Other processes could potentially share the same memory.
STime	This counter displays the number of jiffies that this process has scheduled in kernel mode. A jiffy corresponds to a unit of CPU time and gets used as a base of measurement.
Thread Count	This counter displays the number of threads that are currently grouped with a task.
Total CPU Time Used	This counter displays the total CPU time in jiffies that the task used in user mode and kernel mode since the start of the task.
UTime	This counter displays the number of jiffies that this process has scheduled in user mode.

**Table 6-46** *Process (continued)*

Counters	Counter Descriptions
Virtual Image	This counter displays the total amount of virtual memory (KB) that the task is using. It includes all code, data, shared libraries, and pages that have been swapped out: VirtualImage = SwappedSize + ResidentSize.
VmData	This counter displays the virtual memory usage of the heap for the task in kilobytes (KB).
VmRSS	This counter displays the resident set that is currently in physical memory in kilobytes (KB) This includes the code, data, and stack.
VmSize	This counter displays the total virtual memory usage for an entire task in kilobytes (KB).

## Processor

The processor object provides information on different processor time usage in percentages. [Table 6-47](#) contains information on processor counters.

**Table 6-47** *Processor*

Counters	Counter Descriptions
% CPU Time	This counter displays the processors share of the elapsed CPU time since the last update. This share gets expressed as a percentage of total CPU time.
Idle Percentage	This counter displays the percentage of time that the processor is in idle state.
IOwait Percentage	This counter represents the percentage of time that the processor spends executing read or write operations.
Irq Percentage	This counter represents the percentage of time that the processor spends executing the interrupt request that is assigned to devices, including the time that the processor spends sending a signal to the computer.
Nice Percentage	This counter displays the percentage of time that the processor is executing nice processes in user mode.
Softirq Percentage	This counter represents the percentage of time that the processor spends executing the soft IRQ and deferring task switching to get better CPU performance.
System Percentage	This counter displays the percentage of time that the processor is executing processes in kernel mode.
User Percentage	This counter displays the percentage of time that the processor is executing normal processes in user mode.

# System

The System object provides information on file descriptors on your system. [Table 6-48](#) contains information on system counters

**Table 6-48**      **System**

Counters	Counter Descriptions
Allocated FDs	This counter represents the total number of allocated file descriptors.
Being Used FDs	This counter represents the number of file descriptors that are currently in use in the system.
Freed FDs	This counter represents the total number of allocated file descriptors on the system that are freed.
Max FDs	This counter represents the maximum number of file descriptors that are allowed on the system.
Total CPU Time	This counter represents the total time in jiffies that the system has been up and running.
Total Processes	This counter represents the total number of processes on the system.
Total Threads	This counter represents the total number of threads on the system.

# TCP

The TCP object provides information on the TCP statistics on your system. [Table 6-49](#) contains information on the TCP counters.

**Table 6-49**      **TCP**

Counters	Counter Description
Active Opens	This counter displays the number of times that the TCP connections made a direct transition to the SYN-SENT state from the CLOSED state.
Attempt Fails	This counter displays the number of times that the TCP connections made a direct transition to the SYN-RCVD state from the LISTEN state.
Curr Estab	This counter displays the number of TCP connections where the current state is either ESTABLISHED or CLOSE- WAIT.
Estab Resets	This counter displays the number of times that the TCP connections have made a direct transition to the CLOSED state from either the ESTABLISHED state or the CLOSE-WAIT state.
In Segs	This counter displays the total number of segments that were received, including those received in error. This count only includes segments that are received on currently established connections.

**Table 6-49 TCP (continued)**

Counters	Counter Description
InOut Segs	This counter displays the total number of In Segs and Out Segs.
Out Segs	This counter displays the total number of segments that were received, including those received in error. This count only includes segments that are received on currently established connections.
Passive Opens	This counter displays the number of times that TCP connections have made a direct transition to the SYN-RCVD state from the LISTEN state.
RetransSegs	This counter displays the total number of segments that were retransmitted because the segment contains one or more previously transmitted octets.

## Thread

The Thread object provides a list of running threads on your system. [Table 6-50](#) contains information on the Thread counters.

**Table 6-50 Thread**

Counters	Counter Description
% CPU Time	This counter displays the threads share of the elapsed CPU time since the last update. This counter expresses the share as a percentage of the total CPU time.
PID	This counter displays the threads leader process ID.

## Using RTMT for Performance Monitoring

RTMT displays performance information of all Cisco CallManager components in a cluster. The tool integrates with Cisco CallManager administration and serviceability software. RTMT provides alert notification for troubleshooting performance. It also monitors various aspects of Cisco CallManager performance by periodically polling performance counter values. Refer to [“Displaying a Counter Description” section on page 9-9](#) for examples on displaying perfmon counters in a chart or table format.

Perfmon monitoring allows you to perform the following tasks:

- From the Cisco CallManager cluster, monitor performance counters including Cisco CallManager nodes, TFTP servers, and database servers.
- Continuously monitor a set of preconfigured objects and receive notification in the form of an e-mail message.
- Associate counter threshold settings to alert notification. An e-mail or popup message provides notification to the administrator.



- Save and restore settings, such as counters being monitored, threshold settings, and alert notifications, for customized troubleshooting tasks.
- Display up to six perfmon counters in one chart for performance comparisons.

RTMT displays performance counters in chart or table format. Chart format looks like a miniature window of information. Up to six charts display in the RTMT performance monitoring pane for each category tab that you create. You can display a particular counter by double clicking the counter in the perfmon monitoring pane. Because chart view represents the default, you configure the performance counters to display in table format when you create a category.

You can remove a counter chart (table entry) with the Remove Chart/TableEntry menu item in the Perfmon menu in the menu bar.

**Tip**

The polling rate in each precanned monitoring window remains fixed, and the default value specifies 30 seconds. If the collecting rate of the AMC (Alert Manager and Collector) changes for Cisco CallManager Administration service parameters, the polling rate in the precanned window also updates. In addition, the local time of the RTMT client application and not the backend server time, provides the basis for the time stamp in each chart.

See the following sections for configuration options in the RTMT perfmon monitoring pane:

- [Category Tabs, page 6-65](#)
- [Sample Rate, page 6-65](#)
- [Adding Counters to Monitor, page 6-66](#)
- [Alert Notification for Counters, page 6-66](#)

## Category Tabs

A category comprises monitored performance counters. A tab in the RTMT monitoring pane contains the category name. All performance counters that are monitored in this tab belong to a category. The system polls the performance counters in the tab at the same rate, with each category configured to have its own polling rate.

You can create custom categories in the RTMT monitoring pane to view information that helps you troubleshoot specific performance or device problems. If your Cisco CallManager system is experiencing performance problems with specific objects, create custom categories to monitor the performance of the counters within the object. If the system is experiencing problems with specific devices, create custom categories to monitor the devices within the cluster. In addition, you can create alert notifications for counters and gateways in these custom categories.

To create custom categories, you add a new category tab. When the tab is created, you specify the specific performance counters, devices, and alerts within that tab and then save your custom category by using Profile.

## Sample Rate

The Cisco CallManager software polls counters, devices, and gateway ports to gather status information. In the RTMT monitoring pane, you configure the polling intervals for the performance counters, devices, and gateway ports for each category tab that you create.

**Note**

High-frequency polling rate affects Cisco CallManager performance. The minimum polling rate for monitoring a performance counter in chart view equals 5 seconds; the minimum rate for monitoring a performance counter in table view equals 1 second. The default for both specifies 10 seconds.

## Adding Counters to Monitor

To troubleshoot system performance problems, you add the counter that is associated with the perfmon object to the RTMT performance monitoring pane, which displays a chart for the counter. Before you add counters, see the [“Category Tabs” section on page 6-65](#).

Category tabs contain up to six perfmon counter charts.

## Alert Notification for Counters

Using the alert notification feature, Cisco CallManager notifies you of system problems. Perform the following configuration setup to activate alert notifications for a system counter:

- From the RTMT Perfmon Monitoring pane, choose the system perfmon counter.
- Set up an e-mail or a message popup window for alert notification.
- Determine the threshold for the alert (for example, an alert activates when calls in progress exceed the threshold of over 100 calls or under 50 calls).
- Determine the frequency of the alert notification (for example, the alert occurs once or every hour).
- Determine the schedule for when the alert activates (for example, on a daily basis or at certain times of the day).

## Zoom Counter

To get a closer look at performance monitors, zoom the monitor counter in the RTMT perfmon monitoring pane by highlighting the counter chart and choosing Zoom Chart in the Perfmon menu.

## Counter Properties

Counter properties allow you to display a description of the counter and configure data-sampling parameters.

The Counter Property window contains the option to configure data samples for a counter. The performance counters that display in the RTMT performance monitoring pane contain green dots that represent samples of data over time. You can configure the number of data samples to collect and the number of data points to show in the chart. After the data sample is configured, view the information by using the View All Data/View Current Data menu option to view all the data that a perfmon counter collected.

# Understanding Perfmon Logs

The system logs the perfmon data whenever RTMT calls the LogPerfMon API. You can open the file log, which is compatible with the Windows Performance tool csv format, by using the Performance tool for analysis.

When you add new counters, RTMT changes the header to accommodate the new counters and logs the values correspondingly. When data is unavailable for an already existing counter (already added to header), RTMT inserts blank values in the file. If the character length of the new counters that are added is greater than 2000, the new file gets generated with all the counters.

The following file name format for the PerfMon Log applies:  
PerfMonLog\_<NodeName>\_MM\_DD\_YYYY\_hh\_mm.csv.

The following lists comprises the perfmon counters that RTMT logs:

## At System level

- Cisco CallManager System Performance\QueueSignalsPresent 1-High
- Cisco CallManager System Performance\QueueSignalsPresent 2-Normal
- Cisco CallManager System Performance\QueueSignalsPresent 3-Low
- Cisco CallManager System Performance\QueueSignalsPresent 4-Lowest
- Cisco CallManager System Performance\QueueSignalsProcessed 1-High
- Cisco CallManager System Performance\QueueSignalsProcessed 2-Normal
- Cisco CallManager System Performance\QueueSignalsProcessed 3-Low
- Cisco CallManager System Performance\QueueSignalsProcessed 4-Lowest

## For each process that is running on the system

- Process\% Processor Time
- Process\ID Process
- Process\Private Bytes
- Process\Virtual Bytes

## Additional Cisco Documentation

*Troubleshooting Guide for Cisco CallManager*

# Where to Find More Information

## Related Topics

- [Real-Time Monitoring Tool](#), page 5-1
- [Real-Time Monitoring Configuration](#) *Cisco CallManager Serviceability Administration Guide*
- [Trace Collection and Log Central in RTMT](#), *Cisco CallManager Serviceability Administration Guide*

