



Managing the Hosted Unified Communications Services Platform with VisionOSS USM

This chapter explains how to use VisionOSS BVSM to view, configure, and provision the resources and components of the Hosted Unified Communications Services (UCS) platform. It includes the following topics:

- USM GUI Overview, page 3-1
- Loading Bulk Data for Initial Configuration, page 3-2
- Setup Tools, page 3-2
- Dialplan Tools, page 3-4
- Provider Administration, page 3-6
- Network, page 3-7
- Resources, page 3-9
- General Tools, page 3-10
- General Administration, page 3-12
- Location Administration, page 3-13
- My Account, page 3-14

USM GUI Overview

USM provides integrated, hierarchical, role-based administration of Hosted UCS platform components. This is required to support scalable, decentralized administration of a multi-tenant hosted communications service. The administrative hierarchy is as follows, from top to bottom:

Providers

Channels (resellers)

Customers

Division administrators

Location administrators

Users

Each administrator or user has access to lower levels in the hierarchy, but not at higher levels. This allows the secure delegation of authority from provisioning at the provider or reseller level, down to self-care at the level of customer end users.

The following list shows configuration capabilities at various levels:

- Self-care (manual configuration of a specific phone)—Users
- Auto-provisioning and device configuration for each site—Location/division administrators, channel/reseller administrators
- Bulk data loading—Location/division administrators, channel/reseller administrators

Caution

To maintain platform-wide data integrity, use USM for configuring or provisioning all Hosted UCS components whenever possible. If it is necessary to configure Hosted UCS platform components directly, be certain that the changes will not affect system integrity.

Loading Bulk Data for Initial Configuration

Before performing any other configuration, you will typically use the USM Deployment (Bulk Data) Tool to perform the initial configuration of the Hosted UCS platform components.

For information about using bulk data loading for the initial configuration of the Hosted UCS platform components, refer to "Chapter 4, "Using Bulk Loaders for the Initial Configuration of Hosted Unified Communication Services Components."

USM provides a platform-wide view that includes Cisco Unified CM and the Cisco PGW. When administrators enter or edit data using USM, the necessary configuration for Cisco Unified CM and Cisco PGW is performed automatically.

Setup Tools

The **Setup Tools** option lets you set up and configure the USM management platform when establishing the platform for a new deployment. It sets up all the internal capabilities for USM in terms of the services, phones, and features that are presented on the USM GUI.

When you select the **Setup Tools** option on the VisionOSS menu, the system displays the screen shown in Figure 3-1.

Figure 3-1 Setup Tools Options

Menu Setup Tools	C Help	Preference and Settings : System	3arch
Global Settings	User R	ole	
Branding	bvsm In	ternal System SuperUser	
Themes Phone Types	Search by Preference code 🛩	Max results 50 💌 Search	
Button Groups	Search results:-		
Service Types	Name	Description	
Feature Display Policies	AllowPGWexport	Allows a system user to export PGW data to MML file	
VOSS Audit	AllowTransactionReplay	Allow Transactions to be replayed from the transaction inquiry GUI screen	
Bulk Load Samples About VOSS	AnyUserAnyPhone	Allows a user to login to any phone not just to the phones belonging to their customer	
Security Profiles	AuditTransactions	Enable/Disable transaction auditing	
vial Plan Tools			
rovider	AutoccivinewPhoneProvider	This is the default provider when the auto phone registration provider ccm host lookup fails.	
dministration	CCLinePrefix	Contact centre line prefix	
letwork	ConfirmOnDelete	Displays a confirmation box before deleting data	
tesources			
ieneral Tools	DefaultCustomerTimeZone	Use the default Customer TimeZone	
Seneral Administration	DefaultDivisionTimeZone	Use the default Division TimeZone	
ocation	DefaultLocationTimeZone	location time zone	
dministration	Defaultionic Deserves		
ly Account	DefaultLoginPassword	Ose the detault password to reset user passwords	
Help Index	DefaultProviderTimeZone	Use the default Provider TimeZone	
Logout	DefaultBacollerTimeZone	Liss the default Receiver Transform	

Table 3-1 Summarizes the function of each option provided on the Setup Tools menu.

 Table 3-1
 Setup Tools Menu Options

Option	Description		
Global Settings	Sets preferences at the global level for the whole platform. These settings are similar to preferences at the provider, customer, and location levels.		
Images	Loads images, such as logos, used for branding.		
Branding	Lets service providers customize the USM GUI with specific colors, labels, icons, and logo, on a platform-wide basis, or for each customer.		
Theme	The system supports skinning of the web interface via the use of themes. This includes customization of display elements, including Cascading Style Sheets, images and page layout. The themes are managed via a themes archive, a ZIP file containing the styles, images and template files. A system-wide default theme is provided. The default theme can be used as a base for customization but the default them cannot be changed or deleted using the Theme management screens.		
Phone Types	Creates phone types within USM and adds them to the USM menus, whic helps deliver services consistently. After the phone type is added, it appear to users in the USM phone menus.		
Button Groups	Creates service types within USM and adds them to the USM menus, which helps deliver services consistently. After the service type is added, it appears to users in the USM services and feature group menus.		
Service Types	Creates phone types within BVSM and adds them to the BVSM menus, which helps deliver services consistently. After the phone type is added, it appears to users in the BVSM phone menus.		

Option	Description	
Access Profiles	Access profiles are used to manage a users access to various features and functions within the system. Access Profiles enable administrators to control, to a much better granularity, access to features within the predefined security roles.	
Feature Display Policies	Customer administrators must be able to enforce access rules for any phone line and mobility feature setting exposed in Self Care. These access rules are grouped together as policies.	
VOSS Audit	Transaction Auditing is a powerful tool that enables administrators to closely monitor all or specific transaction types processed within the system.	
Bulk Load Samples	Sample bulk loader and configuration model spreadsheets are provided with the default installation.	
About VOSS	The About VOSS page contains two important pieces of information, the VOSS software (system) version and the VOSS Server platform.	
Security Profiles	Security profiles are sets of rules that govern password strength and other security related preferences. Security Profiles can be applied at System level and at various hierarchical levels which are Provider, Reseller, Customer, Division, Location and Users.	

Table 3-1 Setup Tools Menu Options (continued)

Dialplan Tools

The **Dialplan Tools** option lets you create the dial plan configuration for the Hosted UCS platform during initial deployment.

The dial plan tells the Cisco Hosted UCS platform how to route calls against a number plan. USM is responsible for configuring and loading the dial plan into the various components within Hosted UCS, such as the Cisco PGW and Cisco Unified CM. Super users can create and manage the dial plan when first deploying the platform as well as whenever the dial plan is revised.

The dial plan used for Hosted UCS is designed using Excel spreadsheets, which are loaded using the **Deployment** (**Bulk Load Tools**) option from the General Tools menu.

Dial plan templates can be customized for each provider and after loading, can be further customized for specific customers and locations. For example, each location may require a different extension number length.

When you select the **Dialplan Tools** option on the VisionOSS menu, the system displays the screen shown in Figure 3-2.

Menu Ale	^p Dia	l Plan Management
Setup Tools Dial Plan Tools Number Construction	er Role sm Internal System S	iperUser
Hardware Sets Configuration Models Source Sets	Add Search by Dial Plan Name 💌	Max results 50 💌
CCM Model	ame	Description
Provider	UCM-ONLY	CUCMONLY DIAL PLAN
Administration	IUCS	HUCS DIAL PLAN
Resources		
General Tools -		
General Administration		
Location Administration		
My Account		
Help Index		

Figure 3-2 Dialplan Tools Menu Options



Option	Description		
Number Construction	Configures dial plan variables such as the following:		
	• Codec settings (compression and decompression standards)		
	• Site number formats		
	• Site display formats		
	• Multi-tenant capabilities		
	• Dial prefixes		
	• E.164 number formats		
Hardware Sets	Defines the templates for USM to use for hardware configurations and defines the dial plan associated with each hardware set.		
Configuration Models	Provides model loader programs (similar to bulk data loaders) as well as various sample templates.		
	Each model loader is designed for a specific Hosted UCS platform component, including the following:		
	Cisco PGW		
	Cisco Unified CM		
	• Gateways		
	Application services such as voice mail		

Option	DescriptionProviders are able to operate in a multi-country environment. Each country however, has unique dial plan elements and number configurations, so the system needs to apply these different configurations to each location based on the country they are allocated.	
Countries		
CMM Model Management	IodelThe CCM Model Management page enablesmentadmistrators to manage their dial plan configuratmodels, primarily the models route patterns andtranslation patterns	

Table 3-2 Dialplan Tools Options (continued)

Provider Administration

The **Provider Administration** option lets super users create or change provider settings for the entire Hosted UCS platform, including adding or changing provider administrators.



The default super user account is *BVSM*, and the default password is *password*. After accessing USM, change the password for the BVSM super user account to a strong password. For greater security, create a super user account with a less obvious account name and a strong password, and delete the default super user account.

When you select the **Provider Administration** option on the VisionOSS menu, the system displays the screen shown in Figure 3-3.

Figure 3-3 Provider Administration Menu



Table 3-3 summarizes the function of each option provided on the Provider Administration menu.

Option	Description	
Providers	Opens the Provider Management page, where you can access and edit provider preferences.	
Provider Countries	Add or delete countries under a provider.	
Number Type Counters Manage the reserved inventory for lines by line.		
Phone Type Counters	Manage the inventory for phones by type of phone.	
Service Type Counters	Manage the reserved inventory for phones, lines, an services.	
Feature Templates	Manage feature groups, which are a combination of features required for all users or phones.	
PBX Templates	All PBX features and functionality managed by the system are defined as PBX Features. Any single version of the system will support a defined set of PBX features. These features can be grouped into PBX templates, a PBX template being a pre-configured set of PBX features.	

Table 3-3	Provider Administration	Options
14010 0 0	i i o i i a i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a i i a	optione

Network

The **Network** option allows you to set up the network infrastructure so that USM can then perform its management role.

When you select the **Network** option on the VisionOSS menu, the system displays the screen shown in Figure 3-4.





Table 3-4 summarizes the function of each option provided on the Network menu.

Option	Description	
IOS Devices	Add, delete, or modify IOS devices.	
Gatekeepers	Add, delete, or modify gatekeepers.	
Transit Switches	Add, delete, or modify Cisco PGW switches.	
PBX Devices Add, delete, or modify Cisco Unified servers.		
DHCP Servers	Add, delete, or modify DHCP servers.	
TFTP Servers	Add, delete, or modify TFTP servers.	
VoiceMail Gateways	Add, delete, or modify voice mail gateways.	
IP Edge Devices	Add, delete, or modify IP edge devices.	
Console Servers	Add, delete, or modify switchboard servers.	
Music ServersAdd, delete, or modify music on hold servers.		
Conference Servers	Add, delete, or modify conference servers.	
Franscoder Servers Add, delete, or modify transcoder serveused to translate between codecs.		
Annunciator Servers	Add, delete, or modify Annunciator servers.	
Media Termination PointAdd, delete, or modify the media to points.		
VoiceMail Servers	Add, delete, or modify voicemail servers.	
Directory Servers	Add, delete, or modify directory servers.	

Table 3-4 Network Options

Option	Description
Emergency Responder	Add, delete, or modify emergency responders.
IVR	Add, delete, or modify IVR.
Hardware Groups	Add, delete, or modify hardware.
Session Border Controllers	Add, delete, or modify Session Border Controllers.
Contact Centre	Add, delete, or modify Contact Centre.

Table 3-4	Network Options	(continued)
-----------	-----------------	-------------

Resources

The **Resources** option allows you to create the necessary resources and make them available to the relevant location.

When you select the **Resources** option on the VisionOSS menu, the system displays the screen shown in Figure 3-5.



Figure 3-5 summarizes the function of each option provided on the Resources menu.

Option	Description
E164 Inventory	E164 numbers, also called PSTN or DDI numbers, identify the phone to the external PSTN. BVSM ensures that each E164 number is only allocated once.
Authorisation Codes	Authorization Codes or Forced Authorization Codes (FACs) enable you to manage call access and accounting. The codes regulate the type of calls that specific users can make by forcing the user to enter a valid authorization code before they can make a call.
Billing Codes	Provides access to billing codes.
IP Address Inventory	Provides access to the IP address inventory.
Site Code Inventory	Used as the short-code dial prefix before internal direct dial numbers for a location, allowing internal calls between sites to be routed directly over the internal network.
VoiceMail Services	Creates voice-mail services for each customer, which can then be managed by the customer administrator within each location.
AutoAttendant Services	Creates auto attendant services for each customer, which can then be managed by the customer administrator within each location.
Console Services	Creates console services for each customer, which can then be managed by the customer administrator within each location.
Directory Services	Creates directory services for each customer, which can then be managed by the customer administrator within each location.
Conference Services	Creates conference services for each customer, which can then be managed by the customer administrator within each location.
Media Services	Creates media services for each customer, which can then be managed by the customer administrator within each location.
Phone Inventory	Creates, moves, and deletes phones within or between customer locations.
Contact Centre Service	Creates contact centre services for each customer.

Table 3-5	Resources Optior	ıs
-----------	------------------	----

General Tools

The General Tools option provides access to the following menu choices:

- Operations Tools
- Bulk Load

• Transactions

For detailed information about using the **Bulk Load** option for initial configuration of the Hosted UCS platform components, refer to Chapter 5, "Configuring Hosted UCS Components."

When you select the **General Tools** option on the VisionOSS menu, the system displays the screen shown in Figure 3-6.



and the factor of the factor o	Manag	e Tra	nsactions	Qu
Provider HUCS_Telecom		User bvsm	Role Internal System S	SuperUser
Search by Max r My Transactions 🕑 50	results	Any Ti	me 💌	
Search results:-		Transac	lude B∀SMWeb tions	Exclude End-User Transactions
Id User Id Action	Status	Message		
5115 bysm ModPhoneFeature	Y	Phone featu	res for (002290050E3	2] updated
	Provider HUCS_Telecom Search by Max My Transactions V 50 Search results:- Id User Id Action 5115 bvsm ModPhoneFeature	Manag Provider HUCS_Telecom Search by Max results My Transactions Max results 50 V Search results:- Id User Id Action Status 5115 bysm ModPhoneFeature Y	Manage Trail Provider User HUCS_Telecom bysm Search by Max results My Transactions 50 Search results:- Exc Id User Id Action Status Message 5115 bysm	Manage Transactions Provider User Role HUCS_Telecom bvsm Internal System S Search by Max results Any Time My Transactions 50 Any Time Exclude BVSMWeb Transactions Search results:- Id User Id Action Status Message 5115 bvsm ModPhoneFeature Y Phone features for [002290050E3]

Figure 3-6 summarizes the function of each option provided on the General Tools menu.

Table 3-6 General Tools Options

Option	Description
Operations Tools	Automates multi-step processes.
	The operations tools are also used for testing purposes when a 360-degree test needs to be performed, such as adding a location, deleting a location, and then adding the same location again. These options are also useful for refreshing a
	location when adding a new dial plan to legacy locations.

Option	Description		
Bulk Load	Loads bulk data into USM using Excel spreadsheets.		
	Providers must load bulk data, including network elements, channels, customers, users, and CPE resources, before services can be delivered.		
	Loading bulk data speeds up platform configuration, especially during the initial phases or with a large amount of data.		
Transactions	Provides a chronological record of failed and successful activities associated with each user.		
	This feature is useful for troubleshooting USM and for providing an audit trail for administration moves, adds, and changes.		

Table 3-6 General Tools Options (continued)

General Administration

The **General Administration** option lets you navigate between locations, divisions, customers, and resellers. However, the Status menu provides a faster means of changing levels when you are working in the Location Administration menu.

You cannot jump to a lower level because USM does not know which branch of the customer tree you will follow. The best way to jump straight to a location is by selecting the Location key under the **General Administration** option and step down the levels from reseller, customer, and division. This is faster than selecting one level at a time.

When you select the **General Administration** option on the VisionOSS menu, the system displays the screen shown in Figure 3-7.



Figure 3-7 General Administration Menu Options

Table 3-7 summarizes the function of each option provided on the General Administration menu.

Option	Description	
Users	Manage users (repeated in Location Administration).	
Resellers	Manage channels (provider administrator only).	
Buildings	Manage building (building administrator only).	
Customers	Manage customers (reseller administrator only).	
Divisions	Manage divisions (customer administrator only).	
Locations	Manage locations (division administrator only).	
Feature Groups	Manage feature groups (managed at customer level).	
Device Groups	Manage device Groups. Device Groups are an optional administrative sub-division of Locations. They are used for defining a set of resources within location	

 Table 3-7
 General Administration Options

Location Administration

The **Location Administration** option contains links for the main administrative processes. When you select the **Location Administration** option on the VisionOSS menu, the system displays the screen shown in Figure 3-8.

Figure 3-8

Location Administration Menu Options

Netwo	ork	E Help		Lleen M		ant			Qu
Resou	rces			User w	lanagem	ent			
Gener	al Tools								
Gener	al	Provider	Reseller Cr	ustomer	Division	Location	User	Role	
Admir	histration	HUCS_Telecom	Reseller_A Co	ustomer_A	Marketing_A	1402A1loc1	bysm	Internal Sys	tem SuperUs
Locati Admir	ion histration	Add Search	hy Usemame 💙	Max results	50 💙				5
Swit	chboards	- nut occurer	of occurrent of	max recourte					
E Tele	phony	Search results:-							
# Hun	t Groups								
Nun	nber Groups	Username	Name	Role	Device Grou	p Associated	Phone(s)	Voicemail	Conferencing
Pick	up Groups					938			201 2010-201
🖬 Use	rs	emuser1	End User 1402A1loc1	enduser	N/A	N/A		Add	N/A
Pho	ne Inventory	locadmin	1402A1loc1 Administr	ator locationad	min N/A	N/A		N/A	N/A
Pho Pho	ne Registration	locusiiii		ator reconorida					1071
E Pho	ne Management								
🖬 Ana	logue Line Mgt.								
Moh	I Track Mgt.								
	mal Numbers								
Inter									
Exte	ernal Numbers								

Table 3-8 summarizes the function of each option provided on the Location Administration menu.

 Table 3-8
 Location Administration Options

Option	Description
Switchboards	Add and manage switchboards.
Telephony	Manage telephony services.

Option	Description		
Hunt Groups	Add and manage hunt groups.		
Number Groups	Add and manage number groups.		
Pickup Groups	Add and manage pickup groups.		
Users	Add, delete, and modify users.		
Phone Inventory	Add, move, register, associate, and delete phones.		
Phone Registration	Register and un-register phones.		
Phone Management	Manage phones.		
Analogue Line Mgt	Manage analog lines.		
MOH Track Mgt.	Add and manage Music on Hold tracks.		
Internal Numbers	Manage internal numbers.		
External Numbers	Manage external (DDI) numbers.		

Table 3-8	Location Administration	Options	(continued)
			• •

My Account

The Account Settings page is used to manage administrator details, passwords and preferences.

Note

The My Account section of VOSS can only be used to view and modify the details of the administrator that is currently logged in.

When the user selects the **My Account** option on the VisionOSS menu, the system displays the screen shown in Figure 3-9.

Figure 3-9

Self Care Menu Options



Table 3-9 summarizes the function of each option provided on the My Account menu.

Option	Description
Account Settings	The Account Settings page is used to manage administrator details, passwords and preferences.
Directory	Displays the customer user accounts and associated phone numbers, but does not allow these details to be modified.
	When a user account is added to the system, BVSM automatically adds it to the directory.

Table 3-9	My Account Options
-----------	---------------------------