

CLI Commands

The Cisco Wireless LAN solution command-line interface (CLI) enables operators to connect an ASCII console to the Cisco Wireless LAN Controller and configure the controller and its associated access points.

- show Commands, page 1
- config Commands, page 51
- clear Commands, page 270
- debug Commands, page 271
- test Commands, page 286

show Commands

This section lists the show commands to display information about your WLAN configuration settings.

show advanced hotspot

To display the advanced HotSpot parameters, use the show advanced hotspot command.

	show advanced hotspot			
Syntax Description	This command has n	This command has no arguments or keywords.		
Command Default	None			
Command History	Release	Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.		
Fromulas	The fallowing even	ala akanya kanya di mlan di a akama ad HatSa at mamunatara.		
Examples	ple shows how to display the advanced HotSpot parameters:			
	(Cisco Controller) > show advanced hotspot ANQP 4-way state Disabled GARP Broadcast state: Enabled GAS request rate limit Disabled ANQP comeback delay in TUs(TU=1024usec) 50			

show avc statistics wlan

To display the Application Visibility and Control (AVC) statistics of a WLAN, use the **show avc statistics wlan** command.

show avc statistics wlan wlan_id {application application_name | top-app-groups [upstream | downstream]
| top-apps [upstream | downstream]}

Syntax Description	wlan_id	WLAN identifier from 1 to 512.
	application	Displays AVC statistics for an application.
	application_name	Name of the application. The application name can be up to 32 case-sensitive, alphanumeric characters.
	top-app-groups	Displays AVC statistics for top application groups.
	upstream	(Optional) Displays statistics of top upstream applications.
	downstream	(Optional) Displays statistics of top downstream applications.
	top-apps	Displays AVC statistics for top applications.

Command Default

None

Command History	Release	Modification
	7.4	This command was introduced.

Examples

The following is a sample output of the show avc statistics command.

(Cisco Controller) >show avc statistics wlan 1

Application-Name (Up/Down)		Packets (n secs)	Bytes (n secs)	Avg Pkt Size	Packets (Total)	Bytes (Total)
					======	
unclassified	(U)	191464	208627	1	92208613	11138796586
	(D)	63427	53440610	842	16295621	9657054635
ftp	(U)	805	72880	90	172939	11206202
-	(D)	911	58143	63	190900	17418653
http	(U)	264904	12508288	47	27493945	2837672192
-	(D)	319894	436915253	3 1365	29850934	36817587924
gre	(U)	0	0	0	10158872	10402684928
	(D)	0	0	0	0	0
icmp	(U)	1	40	40	323	98476
-	(D)	7262	4034576	555	2888266	1605133372
ipinip	(U)	62565	64066560	1024	11992305	12280120320
	(D)	0	0	0	0	0
imap	(U)	1430	16798	11	305161	3795766

	(D)	1555	576371	370	332290	125799465
irc	(U)	9	74	8	1736	9133
	(D)	11	371	33	1972	173381
nntp	(U)	22	158	7	1705	9612
	(D)	22	372	16	2047	214391

The following is a sample output of the show avc statistics wlan command.

(Cisco Controller) >show avc statistics wlan 1 application ftp

Description	Upstream	Downstream
=========		
Number of Packtes(n secs)	0	0
Number of Bytes(n secs)	0	0
Average Packet size(n secs)	0	0
Total Number of Packtes	32459	64888
Total Number of Bytes	274	94673983

show call-control ap

Note

The **show call-control ap** command is applicable only for SIP based calls.

To see the metrics for successful calls or the traps generated for failed calls, use the **show call-control ap** command.

show call-control ap {802.11a | 802.11b} cisco_ap {metrics | traps}

Syntax Description	802.11a	Specifies the 802.11a network
	802.11b	Specifies the 802.11b/g network.
	cisco_ap	Cisco access point name.
	metrics	Specifies the call metrics information.
	traps	Specifies the trap information for call control.

Command Default

None

Command History	Release	Modification
7.6		This command was introduced in a release earlier than Release 7.6.

Usage Guidelines To aid in troubleshooting, the output of this command shows an error code for any failed calls. This table explains the possible error codes for failed calls.

Table 1: Error Codes for Failed VoIP Calls

Error Code	Integer	Description
1	unknown	Unknown error.
400	badRequest	The request could not be understood because of malformed syntax.
401	unauthorized	The request requires user authentication.
402	paymentRequired	Reserved for future use.

Error Code	Integer	Description
403	forbidden	The server understood the request but refuses to fulfill it.
404	notFound	The server has information that the user does not exist at the domain specified in the Request-URI.
405	methodNotallowed	The method specified in the Request-Line is understood but not allowed for the address identified by the Request-URI.
406	notAcceptable	The resource identified by the request is only capable of generating response entities with content characteristics that are not acceptable according to the Accept header field sent in the request.
407	proxyAuthenticationRequired	The client must first authenticate with the proxy.
408	requestTimeout	The server could not produce a response within a suitable amount of time.
409	conflict	The request could not be completed due to a conflict with the current state of the resource.
410	gone	The requested resource is no longer available at the server, and no forwarding address is known.
411	lengthRequired	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
413	requestEntityTooLarge	The server is refusing to process a request because the request entity-body is larger than the server is willing or able to process.
414	requestURITooLarge	The server is refusing to service the request because the Request-URI is longer than the server is willing to interpret.
415	unsupportedMediaType	The server is refusing to service the request because the message body of the request is in a format not supported by the server for the requested method.
420	badExtension	The server did not understand the protocol extension specified in a Proxy-Require or Require header field.
480	temporarilyNotAvailable	The callee's end system was contacted successfully, but the callee is currently unavailable.
481	callLegDoesNotExist	The UAS received a request that does not match any existing dialog or transaction.
482	loopDetected	The server has detected a loop.

Error Code	Integer	Description
483	tooManyHops	The server received a request that contains a Max-Forwards header field with the value zero.
484	addressIncomplete	The server received a request with a Request-URI that was incomplete.
485	ambiguous	The Request-URI was ambiguous.
486	busy	The callee's end system was contacted successfully, but the callee is currently not willing or able to take additional calls at this end system.
500	internalServerError	The server encountered an unexpected condition that prevented it from fulfilling the request.
501	notImplemented	The server does not support the functionality required to fulfill the request.
502	badGateway	The server, while acting as a gateway or proxy, received an invalid response from the downstream server it accessed in attempting to fulfill the request.
503	serviceUnavailable	The server is temporarily unable to process the request because of a temporary overloading or maintenance of the server.
504	serverTimeout	The server did not receive a timely response from an external server it accessed in attempting to process the request.
505	versionNotSupported	The server does not support or refuses to support the SIP protocol version that was used in the request.
600	busyEverywhere	The callee's end system was contacted successfully, but the callee is busy or does not want to take the call at this time.
603	decline	The callee's machine was contacted successfully, but the user does not want to or cannot participate.
604	doesNotExistAnywhere	The server has information that the user indicated in the Request-URI does not exist anywhere.
606	notAcceptable	The user's agent was contacted successfully, but some aspects of the session description (such as the requested media, bandwidth, or addressing style) were not acceptable.

Examples

The following is a sample output of the **show call-controller ap** command that displays successful calls generated for an access point:

The following is a sample output of the **show call-control ap** command that displays metrics of traps generated for an AP.

(Cisco Controller) >**show call-control ap 802.11a Cisco_AP traps** Number of traps sent in one min...... 2 Last SIP error code...... 404 Last sent trap timestamp...... Jun 20 10:05:06

show call-control client

To see call information for a call-aware client when Voice-over-IP (VoIP) snooping is enabled and the call is active, use the **show call-control client** command

show call-control client callInfo *client_MAC_address*

Syntax Description	callInfo	Specifies the call-control information.
	client_MAC_address	Client MAC address.
Command Default	None	
Commond Illiotom		
Command History	Release M	odification
	7.6 Tł	nis command was introduced in a release earlier than Release 7.6.
Examples	The following example i	s a sample output of the show call-controller client command:
		client callInfo 10.10.10.10.10
		0.0.0.0 / 0 9.47.96.107 / 5006
		6 sip:1021
	Called Party	sip:1000
		given client is 1

show client ccx client-capability

To display the client's capability information, use the show client ccx client-capability command.

show client ccx client-capability client_mac_address

Syntax Description	<i>client_mac_address</i> MAC address of the client.		
Command Default	None		
Command History	Release Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines Examples		displays the client's available capabilities, not the current settings for the capabilities.	
	The following is a sample output of the show client ccx client-capability command:(Cisco Controller) > show client ccx client-capability 00:40:96:a8:f7:98Service Capability		

show client ccx frame-data

To display the data frames sent from the client for the last test, use the show client ccx frame-data command.

show client ccx frame-data client_mac_address

Syntax Description	client_mac_address	MAC address of the client.
Command Default		
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	TI C II · ·	and a second of the strength and the second state of the second state
Examples	The following is a sa	ample output of the show client ccx frame-data command:

xx:xx:xx:xx:xx

show client ccx last-response-status

To display the status of the last test response, use the **show client ccx last-response-status** command.

show client ccx last-response-status *client_mac_address*

Syntax Description	client_mac_address	MAC address of the client.
Command Default Command History	None	
oonnana motory	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following is a sa	ample output of the show client ccx last-response-status command:

(Cisco Controller) >show client ccx .	last-response-status
Test Status	Success
Response Dialog Token	87
Response Status	Successful
Response Test Type	802.1x Authentication Test
Response Time	3476 seconds since system boot

show client ccx last-test-status

To display the status of the last test, use the show client ccx last-test-status command.

	show client ccx last-test-status client_mac_address	
Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following is a sample output of the show client ccx last-test-status command: (Cisco Controller) >show client ccx last-test-status Test Type	

show client ccx log-response

To display a log response, use the **show client ccx log-response** command.

show client ccx log-response {roam | rsna | syslog} client mac address

Syntax Description	roam	(Optional) Displays the CCX client roaming log response.
	rsna	(Optional) Displays the CCX client RSNA log response.
	syslog	(Optional) Displays the CCX client system log response.
	client_mac_address	Inventory for the specified access point.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

```
Examples
```

The following is a sample output of the **show client ccx log-response syslog** command:

```
(Cisco Controller) >show client ccx log-response syslog 00:40:96:a8:f7:98
Tue Jun 26 18:07:48 2007
                               Syslog Response LogID=131: Status=Successful
       Event Timestamp=0d 00h 19m 42s 278987us
      Client SysLog = '<11> Jun 19 11:49:47 unraval13777 Mandatory elements missing in the
OID response
       Event Timestamp=0d 00h 19m 42s 278990us
      Client SysLog = '<11> Jun 19 11:49:47 unraval13777 Mandatory elements missing in the
OID response'
Tue Jun 26 18:07:48 2007
                               Syslog Response LogID=131: Status=Successful
       Event Timestamp=0d 00h 19m 42s 278987us
      Client SysLog = '<11> Jun 19 11:49:47 unraval13777 Mandatory elements missing in the
OID response
       Event Timestamp=0d 00h 19m 42s 278990us
      Client SysLog = '<11> Jun 19 11:49:47 unraval13777 Mandatory elements missing in the
OID response'
```

The following example shows how to display the client roaming log response:

```
(Cisco Controller) >show client ccx log-response roam 00:40:96:a8:f7:98
Thu Jun 22 11:55:14 2007
                          Roaming Response LogID=20: Status=Successful
Event Timestamp=0d 00h 00m 13s 322396us
                                            Source BSSID=00:40:96:a8:f7:98
Target BSSID=00:0b:85:23:26:70,
                                    Transition Time=100 (ms)
Transition Reason: Normal roam, poor link
                                              Transition Result: Success
Thu Jun 22 11:55:14 2007
                           Roaming Response LogID=133: Status=Successful
Event Timestamp=0d 00h 00m 16s 599006us
                                            Source BSSID=00:0b:85:81:06:c2
Target BSSID=00:0b:85:81:06:c2,
                                    Transition Time=3235(ms)
Transition Reason: Normal roam, poor link
                                              Transition Result: Success
Thu Jun 22 18:28:48 2007
                           Roaming Response LogID=133: Status=Successful
Event Timestamp=0d 00h 00m 08s 815477us
                                            Source BSSID=00:0b:85:81:06:c2
```

Target BSSID=00:0b:85:81:06:d2, Transition Time=3281(ms) Transition Reason: First association to WLAN Transition Result: Success

show client ccx manufacturer-info

To display the client manufacturing information, use the show client ccx manufacturer-info command.

show client ccx manufacturer-info client_mac_address

yntax Description	client_mac_ad	<i>client_mac_address</i> MAC address of the client.	
ommand Default	None		
mmand History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	(Cisco Contro Manufacturer Manufacturer Manufacturer Mac Address . Radio Type . ERP(802.11g Antenna Type Antenna Gain Rx Sensitivit Radio Type . Rx Sensitivit Radio Type . Rx Sensitivit Radio Type . Rx Sensitivit Radio Type . Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit Rx Sensitivit	Omni-directional diversity 2 dBi	

show client ccx operating-parameters

To display the client operating-parameters, use the show client ccx operating-parameters command.

show client ccx operating-parameters client_mac_address

Syntax Description	client_mac_add	dress MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	(Cisco Control Client Mac Radio Type Radio Type Radio Channel 116 120 124 12 Tx Power Mode Rate List(MB) Power Save Mod SSID Security Paran Auth Method Key Management Encryption Device Name Device Type OS Version IP Type IP Type Subnet Mask Default Gatewa IPv6 Address	s a sample output of the show client ccx operating-parameters command: <pre> ller) >show client ccx operating-parameters 00:40:96:b2:8d:5e</pre>
	DNS Servers WINS Servers . System Name Firmware Versi	ask

show client ccx profiles

To display the client profiles, use the show client ccx profiles command.

show client ccx profiles client_mac_address

Syntax Description	<i>client_mac_address</i> MAC address of the client.		
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	The following i	is a sample output of the show client ccx profiles command:	
Examples	Number of Pro Current Profil Profile ID Profile Name SSID Security Para Auth Method . Key Managemen Encryption Power Save Mo Radio Configu Radio Type Preamble Typ CCA Method Detect/Correl Data Retries Fragment Thr Radio Channe Tx Power Mod Rate List (M Radio Type Preamble Typ CCA Method Detect/Correl Data Retries Fragment Thr Radio Channe Tx Power Mod Rate List (ME Radio Type Preamble Typ CCA Method Detect/Correl Data Retries Fragment Thr Radio Type Preamble Typ CCA Method Detect/Correl Data Retries Fragment Thr Radio Channe Tx Power Mod	DSSS Dec. Long preamble Energy Detect + Carrier S	

Radio Type	OFDM(802.11a)
Preamble Type	Long preamble
CCA Method	Energy Detect + Carrier
Detect/Correlation	
Data Retries	6
Fragment Threshold	2342
Radio Channels	36 40 44 48 52 56 60 64 149 153 157 161
165	
Tx Power Mode	Automatic
Rate List (MB)	6.0 9.0 12.0 18.0 24.0 36.0 48.0 54.0

show client ccx results

To display the results from the last successful diagnostic test, use the show client ccx results command.

show client ccx results client_mac_address

Syntax Description	client_mac_ad	<i>Idress</i> MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	(Cisco Contro dotlx Complet	as a sample output of the show client ccx results command: Deller) > show client ccx results xx.xx.xx .e

dot1x Status...... 255

show client ccx rm

To display Cisco Client eXtension (CCX) client radio management report information, use the **show client ccx rm** command.

show client ccx rm *client_MAC* {status | {report {chan-load | noise-hist | frame | beacon | pathloss}}}

Syntax Description	client_MAC	Client MAC address.
	status	Displays the client CCX radio management status information.
	report	Displays the client CCX radio management report.
	chan-load	Displays radio management channel load reports.
	noise-hist	Displays radio management noise histogram reports.
	beacon	Displays radio management beacon load reports.
	frame	Displays radio management frame reports.
	pathloss	Displays radio management path loss reports.

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example shows how to display the client radio management status information:

(Cisco Controller) >show client ccx rm 00:40:96:15:21:ac status

Client Mac Address	00:40:96:15:21:ac
Channel Load Request	Enabled
Noise Histogram Request	Enabled
Beacon Request	Enabled
Frame Request	Enabled
Interval	30
Iteration	10

The following example shows how to display the client radio management load reports:

(Cisco Controller) >show client ccx rm 00:40:96:15:21:ac report chan-load

The following example shows how to display the client radio management noise histogram reports:

(Cisco Controller) >show client ccx rm 00:40:96:15:21:ac report noise-hist

Noise Histogram Report

show client ccx stats-report

To display the Cisco Client eXtensions (CCX) statistics report from a specified client device, use the **show client ccx stats-report** command.

show client ccx stats-report client_mac_address

ax Description	<i>client mac address</i> Client MAC address.	
mand Default	None	
mand Default	None	
mand Default mand History	None Release	Modification

Examples The following is a sample output of the **show client ccx stats-report** command:

(Cisco Controller) > show client co Measurement duration = 1	x stats-report 00:0c:41:07:33:a6
dot11TransmittedFragmentCount	= 1
dot11MulticastTransmittedFrameCount	2 = 2
dot11FailedCount	= 3
dot11RetryCount	= 4
dot11MultipleRetryCount	= 5
dot11FrameDuplicateCount	= 6
dot11RTSSuccessCount	= 7
dot11RTSFailureCount	= 8
dot11ACKFailureCount	= 9
dot11ReceivedFragmentCount	= 10
dot11MulticastReceivedFrameCount	= 11
dot11FCSErrorCount	= 12
dot11TransmittedFrameCount	= 13

show client detail

To display detailed information for a client on a Cisco lightweight access point, use the **show client detail** command.

show client detail mac_address

Syntax Description	mac_address	Client MAC address.
Command Default	N	
	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	-	o command may list the status of automatically disabled clients. Use the show exclusionlist y clients on the exclusion list (blacklisted).
Examples	The following example and the following exam	nple shows how to display the client detailed information:
	The following example shows how to display the client detailed information: (Cisco Controller) >show client detail 00:0c:41:07:33:a6 Policy Manager State	

Number o Number of RA Number of RA	f Realtime Bytes Received f Data Bytes Sent f Realtime Bytes Sent f Realtime Packets Received f Realtime Packets Received f Data Packets Sent f Realtime Packets Sent f Interim-Update Sent f EAP Id Request Msg Timeouts f EAP Request Msg Timeouts f EAP Request Msg Timeouts f EAP Request Msg Timeouts f Data Retries f Duplicate Received Packets f Mic Failured Packets f Mic Failured Packets f Mic Missing Packets packets Dropped f Policy Errors g Naice Pacific	23436 23436 23436 292 292 292 292 292 292 293 292 293 293
Signal t	o Noise Ratio	43 dB

. . .

show client location-calibration summary

To display client location calibration summary information, use the **show client location-calibration summary** command.

show client location-calibration summary

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to display the location calibration summary information:

(Cisco Controller) >show client location-calibration summary MAC Address Interval 10:10:10:10:10:10 60 21:21:21:21:21:21 45

show client probing

To display the number of probing clients, use the show client probing command.

show client probing

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to display the number of probing clients:

(Cisco Controller) >**show client probing** Number of Probing Clients...... 0

show client roam-history

To display the roaming history of a specified client, use the show client roam-history command.

show client roam-history mac_address

Syntax Description	mac_address	Client MAC address.
Command Default Command History	None	
Command mistory	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following is a	sample output of the show client roam-history command:

(Cisco Controller) > show client roam-history 00:14:6c:0a:57:77

show client summary

To display a summary of clients associated with a Cisco lightweight access point, use the **show client summary** command.

show client summary [devicetype device]

Syntax Description This command has no arguments or keywords up to Release 7.4.

Syntax Description	devicetype	(Optional) Displays all clients with the specified device type.
	device	Device type such as Samsung-Device, or WindowsXP-Workstation.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines Use **show client ap** command to list the status of automatically disabled clients. Use the **show exclusionlist** command to display clients on the exclusion list (blacklisted).

Examples

The following example shows how to display a summary of the active clients:

) > show client su	-	24			
	Clients AP Name		200 WLAN/GLAN/RLAN	Auth	Protocol	Port
00:00:15:01:00:01 No Yes	NMSP-TalwarSIM1-2	Associated	1	Yes	802.11a	13
00:00:15:01:00:02 No No	NMSP-TalwarSIM1-2	Associated	1	Yes	802.11a	13
00:00:15:01:00:03 No Yes	NMSP-TalwarSIM1-2	Associated	1	Yes	802.11a	13
	NMSP-TalwarSIM1-2	Associated	1	Yes	802.11a	13

Examples

The following example shows how to display all clients that are WindowsXP-Workstation device types:

(Cisco Controller) >**show client devicetype WindowsXP-Workstation** Number of Clients in WLAN..... 0

MAC Address	AP Name	Status	Auth Protocol	Port Wired Mobility Role
Number of Clients	with reque	ested device t	уре О	

show client wlan

To display the summary of clients associated with a WLAN, use the show client wlan command.

show client wlan wlan_id [devicetype device]

Syntax Description	wlan_id	Wireless LAN identifier from 1 to 512.	
	devicetype	(Optional) Displays all clients with the specified device type.	
	device	Device type. For example, Samsung-Device or WindowsXP-Workstation.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	-	sample outputs of the show client wlan command: er) > show client wlan 1	
	Number of Clients in WLAN 0		
	(Cisco Controller) > show client devicetype WindowsXP-Workstation		
	Number of Client	s in WLAN 0	
	MAC Address	AP Name Status Auth Protocol Port Wired Mobility Role	
	Number of Client	s with requested device type 0	

show dhcp

To display the internal Dynamic Host Configuration Protocol (DHCP) server configuration, use the **show dhcp** command.

show dhcp {leases | summary | scope}

Cuntax Description			
Syntax Description	leases	Displays allocated DHCP leases.	
	summary	Displays DHCP summary information.	
	scope	Name of a scope to display the DHCP information for that scope.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	(Cisco Controller) No leases allocate The following examp	<pre>>show to display the allocated DHCP leases: >show dhcp leases ed. le shows how to display the DHCP summary information: >show dhcp summary Enabled Address Range No 0.0.0.0 -> 0.0.0.0</pre>	
	The following example shows how to display the DHCP information for the scope 003:		
	Lease Time Pool Start Pool End Network Netmask. Default Routers DNS Domain DNS	>show dhcp 003 No 0 0.0.0.0.	

show dhcp proxy

To display the status of DHCP proxy handling, use the show dhcp proxy command.

show dhcp proxy

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to display the status of DHCP proxy information: (Cisco Controller) >**show dhcp proxy** DHCP Proxy Behavior: enabled

show dhcp timeout				
	To display the DHC	P timeout value, use the show dhcp timeout command.		
	show dhcp timeou	t		
Syntax Description	This command has	no arguments or keywords.		
Command Default	None			
Command History	Release	Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.		
Examples	The following example shows how to display the DHCP timeout value:			
	(Cisco Controller) >show dhcp timeout			
	DHCP Timeout (seconds) 10			

show guest-lan

To display the configuration of a specific wired guest LAN, use the **show guest-lan** command.

show guest-lan guest_lan_id

Syntax Description	guest_lan_id	ID of the selected wired guest LAN.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	To display all wire	d guest LANs configured on the controller, use the show guest-lan summary command.
Examples	The following is a	sample output of the show guest-lan guest_lan_id command:
	Guest LAN Identi Profile Name Network Name (SS Status AAA Policy Overn Number of Active Exclusionlist Ti Session Timeout Interface Ingress Interfac WLAN ACL DHCP Server DHCP Address Ass Quality of Servi Security Web Based Authe ACL Web-Passthrough Conditional Web	

show ipv6 acl

To display the IPv6 access control lists (ACLs) that are configured on the controller, use the **show ipv6 acl** command.

show ipv6 acl detailed {acl_name | summary}

Syntax Description	acl_name	IPv6 ACL name. The name can be up to 32 alphanumeric characters.
	detailed	Displays detailed information about a specific ACL.
Command Default	None	

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

```
Examples
```

The following example shows how to display the detailed information of the access control lists:

(Cisco Controller) > show ipv6 acl detailed acl6	
Rule Index	1
Direction	Any
IPv6 source prefix	
IPv6 destination prefix	
Protocol	Any
Source Port Range	0-65535
Destination Port Range	0-65535
DSCP	Any
Flow label	0
Action	Permit
Counter	0
Deny Counter 0	
show ipv6 neighbor-binding

To display the IPv6 neighbor binding data that are configured on the controller, use the **show ipv6 neighbor-binding** command.

show ipv6 neighbor-binding {capture-policy| counters | detailed {mac mac_address| port port_number|
vlanvlan_id} | features | policies | ra-throttle {statistics vlan_id | routers vlan_id} | summary}

Syntax Description	capture-policy	Displays IPv6 next-hop message capture policies.
	counters	Displays IPv6 next-hop counters.
	detailed	Displays the IPv6 neighbor binding table.
	mac	Displays the IPv6 binding table entries for a specific MAC address.
	mac_address	Displays the IPv6 binding table entries for a specific MAC address.
	port	Displays the IPv6 binding table entries for a specific port.
	port_number	Port Number. You can enter ap for an access point or LAG for a LAG port.
	vlan	Displays the IPv6 neighbor binding table entries for a specific VLAN.
	vlan_id	VLAN identifier.
	features	Displays IPv6 next-hop registered features.
	policies	Displays IPv6 next-hop policies.
	ra-throttle	Displays RA throttle information.
	statistics	Displays RA throttle statistics.
	routers	Displays RA throttle routers.
	summary	Displays the IPv6 neighbor binding table.

Command Default

None

Command History

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following is the output of the show ipv6 neighbor-binding summary command:

(Cisco Controller) > show ipv6 neighbor-bindi Binding Table has 6 entries, 5 dynamic Codes: L - Local, S - Static, ND - Neighbor	
Preflevel flags (prlvl): 0001:MAC and LLA match 0008:Orig trusted access 0040:Cga authenticated UPv6 address	trunk 0020:DHCP assigned transformed 0100:Statically assigned
state Time left	MAC Address Port VLAN Type prlvl age
ND fe80::216:46ff:fe43:eb01 2 REACHABLE 157	00:16:46:43:eb:01 1 980 wired 0005
ND fe80::9cf9:b009:b1b4:1ed9 2 REACHABLE 157	70:f1:a1:dd:cb:d4 AP 980 wireless 0005
ND fe80::6233:4bff:fe05:25ef 2 REACHABLE 203	60:33:4b:05:25:ef AP 980 wireless 0005
ND fe80::250:56ff:fe8b:4a8f 2 REACHABLE 157	00:50:56:8b:4a:8f AP 980 wireless 0005
ND 2001:410:0:1:51be:2219:56c6:a8ad	70:f1:a1:dd:cb:d4 AP 980 wireless 0005
5 REACHABLE 157 S 2001:410:0:1::9 1 REACHABLE 205	00:00:00:00:00:08 AP 980 wireless 0100

The following is the output of the show ipv6 neighbor-binding detailed command:

(Cisco Controller) >show ipv6 neighbor-binding detailed mac 60:33:4b:05:25:ef macDB has 3 entries for mac 60:33:4b:05:25:ef, 3 dynamic Codes: L - Local, S - Static, ND - Neighbor Discovery, DH - DDCP Preflevel flags (prlvl): 0001:MAC and LLA match 0002:Orig trunk 0004:Orig access 0008:Orig trusted access0010:Orig trusted trunk0020:DHCP assigned0040:Cga authenticated0080:Cert authenticated0100:Statically assigned IPv6 address MAC Address Port VLAN Type prlvl age state Time left -- -----_____ ---- ------ ------ND fe80::6233:4bff:fe05:25ef 60:33:4b:05:25:ef AP 980 wireless 0009 0 REACHABLE 303 ND 2001:420:0:1:6233:4bff:fe05:25ef 60:33:4b:05:25:ef AP 980 wireless 0009 0 REACHABLE 300 ND 2001:410:0:1:6233:4bff:fe05:25ef 60:33:4b:05:25:ef AP 980 wireless 0009 0 REACHABLE 301

show ipv6 ra-guard

To display the RA guard statistics, use the show ipv6 ra-guard command.

show ipv6 ra-guard {ap | wlc} summary

Syntax Description	ар	Displays Cisco access point details.		
	wlc	Displays Cisco controller details.		
	summary	Displays RA guard statistics.		

Command	Dof	ault	
Commanu	DEI	auiu	

None

Command History Release Modification		Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example show the output of the **show ipv6 ra-guard ap summary** command:

	<pre>>show ipv6 ra-gu AP ient:</pre>		
MAC Address	AP Name	WLAN/GLAN	Number of RA Dropped
00:40:96:b9:4b:89	Bhavik_1130_1_p13	2	19
Total RA Dropped	on AP		19

The following example shows how to display the RA guard statistics for a controller:

(Cisco Controller) >**show ipv6 ra-guard wlc summary** IPv6 RA Guard on WLC..... Enabled

show ipv6 summary

To display the IPv6 configuration settings, use the show ipv6 summary command.

	show ipv6 summar	у
Syntax Description	This command has	no arguments or keywords.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example displays the output of the **show ipv6 summary** command:

(Cisco Controller) > show ipv6 summary	
Global Config	Enabled
Reachable-lifetime value	300
Stale-lifetime value	86400
Down-lifetime value	86400
RA Throttling	Enabled
RA Throttling allow at-least	1
RA Throttling allow at-most	no-limit
RA Throttling max-through	no-limit
RA Throttling throttle-period	60
RA Throttling interval-option	throttle
NS Mulitcast CacheMiss Forwarding	Disabled

show macfilter

To display the MAC filter parameters, use the **show macfilter** command.

show macfilter {summary | detail MAC}

Syntax Description	summary	Displays a sumr	nary of all MAC filter entries.
	detail MAC	Displays details	of a MAC filter entry.
Command Default	None		
Command History	Release	Modification	
	7.6	This command was in	troduced in a release earlier than Release 7.6.
Usage Guidelines Examples	MAC filter table	lists the clients that are alw) for MAC addresses sent to RADIUS servers is displayed. The ays allowed to associate with a wireless LAN. y the detailed display of a MAC filter entry:
	MAC Address WLAN Identifier Interface Name.	r	xx:xx:xx:xx:xx Any
	The following exa	ample shows how to displa	y a summary of the MAC filter parameters:
	MAC Filter RADI	ler) > show macfilter s IUS Compatibility mode. imiter er Table	Cisco ACS
	MAC Address	WLAN Id	Description
	xx:xx:xx:xx:xx: xx:xx:xx:xx:xx:xx: xx:xx:	xx Any	RAP PAP2 (2nd hop) PAP1 (1st hop)

	To display information about the pairwise master key (PMK) cache, use the show pmk-cache command.			
	show pmk-cach	e {all MAC}		
Syntax Description	all	Display	/s information about all	entries in the PMK cache.
	МАС	Informa	ation about a single entr	y in the PMK cache.
Command Default	None			
Command History	Release	Modification	1	
	7.6	This comman	nd was introduced in a re	elease earlier than Release 7.6.
Examples	The following e	xample shows how	to display information a	about a single entry in the PMK cache:
	(Cisco Contro	ller) > show pmk-	cache xx:xx:xx:xx:xx	: **
	The following e	xample shows how	to display information a	about all entries in the PMK cache:
	(Cisco Contro PMK Cache	ller) > show pmk-	cache all	
	Station	Entry	VLAN Override	IP Override

show pmk-cache

show remote-lan

To display information about remote LAN configuration, use the show remote-lan command.

show remote-lan { summary | remote-lan-id }

summary	Displays a summary of all remote LANs.
remote-lan-id	Remote LAN identifier.
None	
Roloaso	Modification
	This command was introduced in a release earlier than Release 7.6.
	remote-lan-id

Examples

The following example shows how to display a summary of all remote LANs:

(Cisco C	ontroller) > show remote-lan summary		
Number o	f Remote LANS	2	
RLAN ID	RLAN Profile Name	Status	Interface Name
2	remote	Disabled	management
8	test	Disabled	management

The following example shows configuration information about the remote LAN with the remote-lan-id 2:

(Cisco Controller) >show remote-lan 2	
Remote LAN Identifier	
Profile Name	
Status	Disabled
MAC Filtering	Disabled
AAA Policy Override	Disabled
Network Admission Control	
Radius-NAC State	Disabled
SNMP-NAC State	Disabled
Quarantine VLAN	0
Maximum number of Associated Clients	0
Number of Active Clients	0
Exclusionlist	Disabled
Session Timeout	Infinity
CHD per Remote LAN	Enabled
Webauth DHCP exclusion	Disabled
Interface	management
Remote LAN ACL	unconfigured
DHCP Server	Default
DHCP Address Assignment Required	Disabled
Static IP client tunneling	Disabled
Radius Servers	
Authentication	Global Servers
Accounting	Global Servers
Dynamic Interface	

1

Security Web Based Authentication Enabled
ACL Unconfigured
Web Authentication server precedence:
1 local
2 radius
3 ldap
Web-Passthrough Disabled
Conditional Web Redirect Disabled Splash-Page Web Redirect Disabled

show rf-profile summary

To display a summary of RF profiles in the controller, use the show rf-profile summary command.

show rf-profile summary

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following is the output of the **show rf-profile summary** command:

(Cisco Controller) > show	-	-	
Number of RF Profiles Out Of Box State			
RF Profile Name			Applied
 Tla Tlb	5 GHz 2.4 GHz		NO No

show rf-profile details

To display the RF profile details in the Cisco wireless LAN controller, use the **show rf-profile details** command.

show rf-profile details rf-profile-name

Syntax Description	rf-profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following is th	ne output of the show rf-profile details command::
		er) >show rf-profile details T1a
	-	<none> 5 GHz</none>
		Fhreshold v170 dBm
		Fhreshold v2
		ver10 dBm
	Max Transmit Pow 802.11a Operatio	ver
	-	Rate Mandatory
		RateSupported
		Rate Mandatory
		Rate Supported
		Rate Mandatory Rate Supported
		Rate
		RateSupported
		200
	-	eshold
		Rate0
		d0 dBm 0 dBm
		e: Enabled
	Band Select Prob	be Response Disabled
	Band Select Cycl	Le Count 2 cycles
		Le Threshold 200 milliseconds
		ire Suppression
		ire Dual Band
		Denial
	2	Vindow 5 clients
	-	
	Loverage Excepti	ion

show wlan

To display configuration information for a specified wireless LAN or a foreign access point, or to display wireless LAN summary information, use the **show wlan** command.

show wlan { apgroups | summary | wlan_id | foreignAp }

Syntax Description	apgroups	Displays access point group information.
	summary	Displays a summary of all wireless LANs.
	wlan_id	Wireless LAN identifier from 1 to 512.
	foreignAp	Displays the configuration for support of foreign access points.

Command Default None

Command History

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example shows how to display a summary of wireless LANs for wlan_id 1:

(Cisco Controller) > show wlan 1	
WLAN Identifier	
Profile Name	
Network Name (SSID)	
Status	Enabled
MAC Filtering	
Broadcast SSID	
AAA Policy Override	Disabled
Network Admission Control	
RADIUS Profiling Status	Disabled
DHCP	
HTTP	Disabled
Client Profiling Status Di	sabled
DHCP	
HTTP	
Radius-NAC State	
SNMP-NAC State	Enabled
Quarantine VLAN 0	
Maximum number of Associated Clients	
Maximum number of Clients per AP Radio	
Number of Active Clients	
Exclusionlist Timeout	
Session Timeout	
User Idle Timeout	
User Idle Threshold	1
NAS-identifier	
CHD per WLAN.	
Webauth DHCP exclusion	Disabled

1

Interface	management
Multicast Interface	
WLAN IPv4 ACL	
WLAN IPv6 ACL	
	5
mDNS Status	
mDNS Profile Name	unconfigured
DHCP Server	Default
DHCP Address Assignment Required	Disabled
Static IP client tunneling	
PMIPv6 Mobility Type	
Quality of Service	
Per-SSID Rate Limits	-
Average Data Rate	0 0
Average Realtime Data Rate	0 0
Burst Data Rate	0 0
Burst Realtime Data Rate	0 0
Per-Client Rate Limits	
Average Data Rate	0 0
Average Realtime Data Rate	0 0
Burst Data Rate	0 0
Burst Realtime Data Rate	0 0
Scan Defer Priority	
Scan Defer Time	
WMM	
WMM UAPSD Compliant Client Support	Disabled
Media Stream Multicast-direct	Disabled
CCX - AironetIe Support	
CCX - Gratuitous ProbeResponse (GPR)	
CCX - Diagnostics Channel Capability	
Dot11-Phone Mode (7920)	Disabled
Wired Protocol	None
Passive Client Feature	Disabled
IPv6 Support	
Peer-to-Peer Blocking Action	
Radio Policy	
DTIM period for 802.11a radio	1
DTIM period for 802.11b radio	1
DTIM period for 802.11b radio	1
Radius Servers	
Radius Servers Authentication	Global Servers
Radius Servers Authentication Accounting	Global Servers Global Servers
Radius Servers Authentication Accounting Interim Update Di	Global Servers Global Servers sabled
Radius Servers Authentication Accounting Interim Update Di Dynamic Interface	Global Servers Global Servers sabled Disabled
Radius Servers Authentication Accounting Interim Update Di Dynamic Interface	Global Servers Global Servers sabled Disabled
Radius Servers Authentication Accounting Interim UpdateDi Dynamic Interface Local EAP Authentication	Global Servers Global Servers sabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP')
Radius Servers Authentication	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System
Radius Servers AuthenticationAccounting. Interim UpdateDi Dynamic Interface Local EAP AuthenticationSecurity 802.11 Authentication:FT Support.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled
Radius Servers AuthenticationAccounting Interim UpdateDi Dynamic Interface Local EAP Authentication Security 802.11 Authentication: FT Support Static WEP Keys	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled
Radius Servers AuthenticationAccounting. Interim UpdateDi Dynamic Interface Local EAP AuthenticationSecurity 802.11 Authentication:FT Support.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled
Radius Servers AuthenticationAccounting Interim UpdateDi Dynamic Interface Local EAP Authentication Security 802.11 Authentication: FT Support Static WEP Keys	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Disabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Disabled
Radius Servers Authentication Accounting. Interim Update Di Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X Wi-Fi Protected Access (WPA/WPA2) WPA (SSN IE). TKIP Cipher. AES Cipher.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Disabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Di Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Disabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Di Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. Auth Key Management	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AUTHER SUPPRES.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AUTH Key Management 802.1x. PSK.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2) WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AUTH Key Management 802.1x. PSK. CCKM.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AUTH Key Management 802.1x. PSK.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2) WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AUTH Key Management 802.1x. PSK. CCKM.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1X. PSK. CCKM. FT (802.11r).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK(802.11r). PMF-1X(802.11w).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11w). PMF-PSK (802.11w).	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Enabled Disabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Di Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2) WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. AUTH Key Management 802.1x. FT (802.11r). FT -PSK (802.11r). PMF-1X (802.11w). FT Reassociation Timeout.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Disabled Enabled Disabled Disabled Enabled Disabled Disabled Disabled Enabled Disabled Enabled Disabled Disabled Enabled Disabled Disabled Disabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled Disabled Enabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.12. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.12. WI-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support. CCKM TSF Tolerance.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2) WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support. CCKM TSF Tolerance. Wi-Fi Direct policy configured.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support. CCKM TSF Tolerance. Wi-Fi Direct policy configured. EAP-Passthrough.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. AES Cipher. AES Cipher. AES Cipher. AUTH Key Management 802.1x. FT (802.11r). FT-PSK (802.11r). FT-PSK (802.11r). FT-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support. CCKM TSF Tolerance. Wi-Fi Direct policy configured. EAP-Passthrough. CKIP. Wi-Fi Netation. Store. CKIP. CCKI Space. Di	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled
Radius Servers Authentication. Accounting. Interim Update. Dynamic Interface. Local EAP Authentication. Security 802.11 Authentication: FT Support. Static WEP Keys. 802.1X. Wi-Fi Protected Access (WPA/WPA2). WPA (SSN IE). TKIP Cipher. AES Cipher. WPA2 (RSN IE). TKIP Cipher. AES Cipher. Auth Key Management 802.1x. PSK. CCKM. FT (802.11r). FT-PSK (802.11r). PMF-1X (802.11w). PMF-PSK (802.11w). FT Reassociation Timeout. FT Over-The-Air mode. FT Over-The-Ds mode. GTK Randomization. SKC Cache Support. CCKM TSF Tolerance. Wi-Fi Direct policy configured. EAP-Passthrough.	Global Servers Global Servers sabled Disabled Enabled (Profile 'Controller_Local_EAP') Open System . Disabled Disabled Enabled Enabled Enabled Disabled Enabled Disabled Enabled Disabled

IP Security Passthru..... Disabled Web Based Authentication..... Disabled Web-Passthrough..... Disabled Conditional Web Redirect..... Disabled Splash-Page Web Redirect..... Disabled Auto Anchor..... Disabled FlexConnect Local Switching..... Enabled flexconnect Central Dhcp Flag..... Disabled flexconnect nat-pat Flag..... Disabled flexconnect Dns Override Flag..... Disabled FlexConnect Vlan based Central Switching Disabled FlexConnect Local Authentication..... Disabled FlexConnect Learn IP Address..... Enabled Client MFP..... Optional PMF..... Disabled PMF Association Comeback Time..... 1 PMF SA Query RetryTimeout..... 200 Tkip MIC Countermeasure Hold-down Timer..... 60 Call Snooping..... Disabled Roamed Call Re-Anchor Policy..... Disabled SIP CAC Fail Send-486-Busy Policy..... Enabled SIP CAC Fail Send Dis-Association Policy..... Disabled KTS based CAC Policy..... Disabled Band Select..... Disabled Load Balancing..... Disabled Mobility Anchor List WLAN ID IP Address Status _____ _____ 802.11u..... Enabled Network Access type..... Chargeable Public Network Internet service..... Enabled Network Authentication type..... Not Applicable IP Address Type Configuration IPv4 Address type..... Available IPv6 Address type..... Not Known Roaming Consortium List OUI List Index In Beacon ____ _____ _____ Yes No 1 313131 2 DDBBCC DDDDDD 3 Yes Realm configuration summary Realm index..... 1 Realm name..... jobin EAP index..... 1 EAP method..... Unsupported Index Inner Authentication Authentication Method ____ -----_____ 1 Credential Type SIM 2 Tunneled Eap Credential Type SIM 3 Credential Type SIM 4 Credential Type USIM Hardware Token 5 Credential Type 6 Credential Type SoftToken Domain name configuration summary Index Domain name _____ _____ 1 rom3 2 ram 3 roml Hotspot 2.0..... Enabled Operator name configuration summary Index Language Operator name _____ ____ _____ 1 Robin ros Port config summary Index IP protocol Port number Status

1		1	0	Closed
2		1	0	Closed
3		1	0	Closed
4		1	0	Closed
5		1	0	Closed
6		1	0	Closed
7		1	0	Closed
WAN Metr	ics Info			
Symme Downl Uplin	k speed		· · · · · · · · · ·	No 4 kbps
	-			
Priority	Policy Name			
1	Teacher_ac	ccess_policy		

The following example shows how to display a summary of all WLANs:

The following example shows how to display the configuration for support of foreign access points:

(Cisco Controller) >**show wlan foreignap** Foreign AP support is not enabled.

The following example shows how to display the AP groups:

(Cisco Controller) >show wlan apgroups Total Number of AP Groups..... 1 Site Name..... APuser Site Description...... <none> Venue Name..... Not configured Venue Group Code.....Unspecified Venue Type Code.....Unspecified Language Code..... Not configured RF Profile 2.4 GHz band..... <none> 5 GHz band...... <none> Network Admission Control WLAN ID Interface Radio Policy int_4 Disabled Slots AP Model Ethernet MAC _____ _____ 14 All AP Name Location Port Country Priority _____ ____ _____ ___ 2 AIR-CAP2602I-A-K9 44:2b:03:9a:8a:73 default location 1 Ibiza 1 US 2 AIR-CAP3502E-A-K9 f8:66:f2:ab:23:95 default location 1 Larch 1 US 2 AIR-CAP3502I-A-K9 00:22:90:91:6d:b6 Zest ren 1 US 1 Number of Clients..... 1 AP Name MAC Address Status Device Type _____

24:77:03:89:9b:f8 ap2 Associated Android

config Commands

This section lists the **config** commands to configure WLANs.

config 802.11 dtpc

To enable or disable the Dynamic Transmit Power Control (DTPC) setting for an 802.11 network, use the **config 802.11 dtpc** command.

config 802.11 {a | b} dtpc {enable | disable}

x Description		
	a	Specifies the 802.11a network.
	b	Specifies the 802.11b/g network.
	enable	Enables the support for this command.
	disable	Disables the support for this command.
mand Default	The default DTPC	setting for an 802.11 network is enabled.
	The default DTPC Release 7.6	setting for an 802.11 network is enabled. Modification This command was introduced in a release earlier than Release 7.6.
nmand Default nmand History	Release	Modification
	Release 7.6	Modification

config auto-configure voice

To auto-configure voice deployment in WLANs, use the config auto-configure voice command.

config auto-configure voice cisco *wlan_id* radio {802.11a | 802.11b | all}

Syntax Description	cisco	Auto-configure WLAN for voice deployment of Cisco end points.
	wlan_id	Wireless LAN identifier from 1 to 512 (inclusive).
	radio	Auto-configures voice deployment for a radio in a WLAN.
	802.11a	Auto-configures voice deployment for 802.11a in a WLAN.
	802.11b	Auto-configures voice deployment for 802.11b in a WLAN.
	all	Auto-configures voice deployment for all radios in a WLAN.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
lsage Guidelines	-	figure this command, all WLANs and radios are automatically disabled. After the completion ation, the previous state of the WLANs and radios is restored.
xamples	The following e	example shows how to auto-configure voice deployment for all radios in a WLAN:
	Warning! This It will be r	oller) >config auto-configure voice cisco 2 radio all command will automatically disable all WLAN's and Radio's. ceverted to the previous state once configuration is complete. ce you want to continue? (y/N)y
	Auto-Configur wlan gos 2 p	ing these commands in WLAN for Voice Datinum
	- Success	noop enable 2
	- Success	1
	wlan wmm all - Success	.ow 2
	wlan session - Success	n-timeout 2 86400
		ocking disable 2

```
- Success
wlan exclusionlist 2 disable
```

```
- Success
wlan mac-filtering disable 2
  Success
 wlan dtim 802.11a 2 2
 - Success
wlan dtim 802.11b 2 2
 - Success
wlan ccx aironetIeSupport enabled 2
 - Success
wlan channel-scan defer-priority 4 enable 2
 - Success
wlan channel-scan defer-priority 5 enable 2
  Success
wlan channel-scan defer-priority 6 enable 2
 - Success
wlan channel-scan defer-time 100 2
 - Success
wlan load-balance allow disable 2
 - Success
wlan mfp client enable 2
 - Success
wlan security wpa akm cckm enable 2

    Success

wlan security wpa akm cckm timestamp-tolerance 5000 2
 - Success
wlan band-select allow disable 2
 - Success
* * * * *
      Auto-Configuring these commands for Voice - Radio 802.11a.
advanced 802.11a edca-parameter optimized-voice

    Success

802.11a cac voice acm enable
 - Success
802.11a cac voice max-bandwidth 75
 - Success
802.11a cac voice roam-bandwidth 6
 - Success
802.11a cac voice cac-method load-based
  Success
802.11a cac voice sip disable

    Success

802.11a tsm enable
 - Success
802.11a exp-bwreg enable
 - Success
802.11a txPower global auto
 - Success
802.11a channel global auto

    Success

advanced 802.11a channel dca interval 24
 - Success
advanced 802.11a channel dca anchor-time 0
  - Success
qos protocol-type platinum dot1p
 - Success
 qos dot1p-tag platinum 6
  Success
 qos priority platinum voice voice besteffort
  Success
802.11a beacon period 100
 - Success
 802.11a dtpc enable
  Success
802.11a Coverage Voice RSSI Threshold -70
 - Success
802.11a txPower global min 11
  - Success
advanced eap eapol-key-timeout 250
 - Success
advanced 802.11a voice-mac-optimization disable
 - Success
```

```
802.11h channelswitch enable 1
 - Success
Note: Data rate configurations are not changed.
It should be changed based on the recommended values after analysis.
Auto-Configuring these commands for Voice - Radio 802.11b.
advanced 802.11b edca-parameter optimized-voice
 - Success
 802.11b cac voice acm enable
 - Success
 802.11b cac voice max-bandwidth 75
  Success
 802.11b cac voice roam-bandwidth 6
 - Success
 802.11b cac voice cac-method load-based
 - Success
802.11b cac voice sip disable
 - Success
 802.11b tsm enable
 - Success
 802.11b exp-bwreq enable
 - Success
 802.11b txPower global auto
  - Success
 802.11b channel global auto - Success
advanced 802.11b channel dca interval 24
 - Success
 advanced 802.11b channel dca anchor-time 0
 - Success
 802.11b beacon period 100
 - Success
 802.11b dtpc enable
 - Success
 802.11b Coverage Voice RSSI Threshold -70
 - Success
802.11b preamble short
 - Success
advanced 802.11a voice-mac-optimization disable
 - Success
Note: Data rate configurations are not changed.
It should be changed based on the recommended values after analysis.
```

config client ccx clear-reports

To clear the client reporting information, use the config client ccx clear-reports command.

config client ccx clear-reports client_mac_address

Syntax Description	client_mac_addr	ess MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following ex 00:1f:ca:cf:b6:60	ample shows how to clear the reporting information of the client MAC address

(Cisco Controller) >config client ccx clear-reports 00:1f:ca:cf:b6:60

config client ccx clear-results

To clear the test results on the controller, use the config client ccx clear-results command.

config client ccx clear-results *client_mac_address*

Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config client ccx clear-results 00:1f:ca:cf:b6:60

config client ccx default-gw-ping

To send a request to the client to perform the default gateway ping test, use the **config client ccx default-gw-ping** command.

config client ccx default-gw-ping client_mac_address

Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This test does not rec	quire the client to use the diagnostic channel.
Examples	gateway ping test:	ple shows how to send a request to the client00:0b:85:02:0d:20 to perform the default) >config client ccx default-gw-ping 00:0b:85:02:0d:20

config client ccx dhcp-test

To send a request to the client to perform the DHCP test, use the config client ccx dhcp-test command.

config client ccx dhcp-test client_mac_address

Syntax Description	client_mac_addres.	s MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This test does not re	equire the client to use the diagnostic channel.
Examples	The following exam test:	pple shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DHCP
		<pre>c) >config client ccx dhcp-test 00:E0:77:31:A3:55</pre>

config client ccx dns-ping

To send a request to the client to perform the Domain Name System (DNS) server IP address ping test, use the **config client ccx dns-ping** command.

config client ccx dns-ping client_mac_address

Syntax Description	client_mac_addre	ss MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This test does not r	require the client to use the diagnostic channel.
Examples	The following example address p	mple shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DNS
	-	er) >config client ccx dns-ping 00:E0:77:31:A3:55

config client ccx dns-resolve

To send a request to the client to perform the Domain Name System (DNS) resolution test to the specified hostname, use the **config client ccx dns-resolve** command.

config client ccx dns-resolve client_mac_address host_name

Syntax Description	client mac address	MAC address of the client.
	host_name	Hostname of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This test does not requ	uire the client to use the diagnostic channel.
Examples	• •	le shows how to send a request to the client 00:E0:77:31:A3:55 to perform the DNS o the specified hostname:
	(Cisco Controller)	<pre>>config client ccx dns-resolve 00:E0:77:31:A3:55 host_name</pre>

config client ccx get-client-capability

To send a request to the client to send its capability information, use the **config client ccx get-client-capability** command.

config client ccx get-client-capability client_mac_address

Syntax Description	client_mac_addres	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

ExamplesThe following example shows how to send a request to the client 172.19.28.40 to send its capability information:
(Cisco Controller) >config client ccx get-client-capability 172.19.28.40

config client ccx get-manufacturer-info

To send a request to the client to send the manufacturer's information, use the **config client ccx get-manufacturer-info** command.

config client ccx get-manufacturer-info client_mac_address

Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following examp information:	le shows how to send a request to the client 172.19.28.40 to send the manufacturer's

(Cisco Controller) >config client ccx get-manufacturer-info 172.19.28.40

config client ccx get-operating-parameters

To send a request to the client to send its current operating parameters, use the **config client ccx get-operating-parameters** command.

config client ccx get-operating-parameters client_mac_address

Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following example parameters:	ple shows how to send a request to the client 172.19.28.40 to send its current operating

(Cisco Controller) >config client ccx get-operating-parameters 172.19.28.40

config client ccx get-profiles

To send a request to the client to send its profiles, use the config client ccx get-profiles command.

config client ccx get-profiles *client_mac_address*

ax Description	client_mac_address	MAC address of the client.
nand Default	None	
mand History	Release	Modification
	norouoo	

(Cisco Controller) >config client ccx get-profiles 172.19.28.40

config client ccx log-request

To configure a Cisco client eXtension (CCX) log request for a specified client device, use the **config client ccx log-request** command.

config client ccx log-request {roam | rsna | syslog} client_mac_address

watay Decorintian			
Syntax Description	roam		(Optional) Specifies the request to specify the client CCX roaming log.
	rsna syslog client_mac_address		(Optional) Specifies the request to specify the client CCX RSNA log.(Optional) Specifies the request to specify the client CCX system log.
			MAC address of the client.
command Default	None		
command History	Release	Modification	
	7.6	This command was introduced in	a release earlier than Release 7.6.
xamples	The following example shows how to specify the request to specify the client CCS system log: (Cisco Controller) >config client ccx log-request syslog 00:40:96:a8:f7:98 Tue Oct 05 13:05:21 2006 SysLog Response LogID=1: Status=Successful Event Timestamp=12121212122 Client SysLog = 'This is a test syslog 2' Event Timestamp=12121212122 Client SysLog = 'This is a test syslog 1' Tue Oct 05 13:04:04 2006 SysLog Request LogID=1		
	Tue Oct 05 13 SysLog Respon Event Timesta Client SysLog Event Timesta Client SysLog Tue Oct 05 13	<pre>3:05:21 2006 hse LogID=1: Status=Successful mp=121212121212 g = 'This is a test syslog 2' mp=121212121212 g = 'This is a test syslog 1' 3:04:04 2006</pre>	
	Tue Oct 05 13 SysLog Respor Event Timesta Client SysLog Event Timesta Client SysLog Tue Oct 05 13 SysLog Reques	<pre>3:05:21 2006 hse LogID=1: Status=Successful mp=121212121212 g = 'This is a test syslog 2' mp=121212121212 g = 'This is a test syslog 1' 3:04:04 2006</pre>	st syslog 00:40:96:a8:f7:98

```
Transition Time=100(ms)
Transition Reason: Unspecified Transition Result: Success
Thu Jun 22 11:54:33 2006 Roaming Request LogID=19
```

The following example shows how to specify the client CCX RSNA log:

(Cisco Controller) >config client ccx log-request rsna 00:40:96:a8:f7:98

```
Tue Oct 05 11:06:48 2006
RSNA Response LogID=2: Status=Successful
Event Timestamp=242424242424
Target BSSID=00:0b:85:23:26:70
RSNA Version=1
Group Cipher Suite=00-x0f-ac-01
Pairwise Cipher Suite Count = 2
Pairwise Cipher Suite 0 = 00-0f-ac-02
Pairwise Cipher Suite 1 = 00-0f-ac-04
AKM Suite Count = 2
KM Suite 0 = 00-0f-ac-01
KM Suite 1 = 00-0f-ac-02
SN Capability = 0x1
PMKID Count = 2
PMKID 0 = 01 02 03 04 05 06 07 08 09 10 11 12 13 14 15 16
PMKID 1 = 0a 0b 0c 0d 0e 0f 17 18 19 20 1a 1b 1c 1d 1e 1f
802.11i Auth Type: EAP_FAST
RSNA Result: Success
```

config client ccx send-message

To send a message to the client, use the **config client ccx send-message** command.

config client ccx send-message client_mac_address message_id

Syntax Description

client_mac_address MAC address of the client.

message_id	Message type that involves one of the following:
	• 1—The SSID is invalid.
	• 2—The network settings are invalid.
	• 3—There is a WLAN credibility mismatch.
	• 4—The user credentials are incorrect.
	• 5—Please call support.
	• 6—The problem is resolved.
	• 7—The problem has not been resolved.
	• 8—Please try again later.
	• 9—Please correct the indicated problem.
	• 10—Troubleshooting is refused by the network.
	• 11—Retrieving client reports.
	• 12—Retrieving client logs.
	• 13—Retrieval complete.
	• 14—Beginning association test.
	• 15—Beginning DHCP test.
	• 16—Beginning network connectivity test.
	• 17—Beginning DNS ping test.
	• 18—Beginning name resolution test.
	• 19—Beginning 802.1X authentication test.
	• 20—Redirecting client to a specific profile.
	• 21—Test complete.
	• 22—Test passed.
	• 23—Test failed.
	 24—Cancel diagnostic channel operation or select a WLAN profile to resume normal operation.
	• 25—Log retrieval refused by the client.
	• 26—Client report retrieval refused by the client.
	• 27—Test request refused by the client.
	• 28—Invalid network (IP) setting.
	• 29—There is a known outage or problem with the network.
	• 30—Scheduled maintenance period.
	(continued on next page)

	message_type (cont.)	
		• 31—The WLAN security method is not correct.
		• 32—The WLAN encryption method is not correct.
		• 33—The WLAN authentication method is not correct.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exampl user-action-required:	e shows how to send a message to the client MAC address 172.19.28.40 with the message

(Cisco Controller) >config client ccx send-message 172.19.28.40 user-action-required

config client ccx stats-request

None

To send a request for statistics, use the config client ccx stats-request command.

config client ccx stats-request measurement_duration [dot11 | security] client_mac_address

Syntax Description measurement_duration Measurement duration in seconds. dot11 (Optional) Specifies dot11 counters. security (Optional) Specifies security counters. client_mac_address MAC address of the client.

Command Default

Command	History
oomnunu	motory

Release	Modification	
7.6	This command was introduced in a release earlier than Release 7.6.	

Examples

The following example shows how to specify dot11 counter settings:

```
(Cisco Controller) >config client ccx stats-request 1 dot11 00:40:96:a8:f7:98
Measurement duration = 1
dot11TransmittedFragmentCount
                                     = 1
dot11MulticastTransmittedFrameCount = 2
                                     = 3
dot11FailedCount
                                     = 4
dot11RetryCount
                                     = 5
dot11MultipleRetryCount
dot11FrameDuplicateCount
                                     = 6
dot11RTSSuccessCount
                                     =
                                       7
                                     = 8
dot11RTSFailureCount
dot11ACKFailureCount
                                     = 9
dot11ReceivedFragmentCount
                                     = 10
dot11MulticastReceivedFrameCount
                                     = 11
dot11FCSErrorCount
                                     = 12
                                     = 13
{\tt dot11TransmittedFrameCount}
```

config client ccx test-abort

To send a request to the client to abort the current test, use the config client ccx test-abort command.

config client ccx test-abort client_mac_address

Syntax Description	client_mac_address	MAC address of the client.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines Examples	Only one test can be pending at a time. The following example shows how to send a request to the client 11:11:11:11:11:11 to abort the correct test	
	settings:	
	(Cisco Controller) >config client ccx test-abort 11:11:11:11:11
config client ccx test-association

To send a request to the client to perform the association test, use the **config client ccx test-association** command.

config client ccx test-association client mac address ssid bssid $802.11 \{a \mid b \mid g\}$ channel

Syntax Description	client_mac_address	MAC address of the client.
	ssid	Network name.
	bssid	Basic SSID.
	802.11a	Specifies the 802.11a network.
	802.11b	Specifies the 802.11b network.
	802.11g	Specifies the 802.11g network.
	channel	Channel number.

Command Default	None
-----------------	------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to send a request to the client MAC address 00:0E:77:31:A3:55 to perform the basic SSID association test:

(Cisco Controller) >config client ccx test-association 00:E0:77:31:A3:55 ssid bssid 802.11a

config client ccx test-dot1x

To send a request to the client to perform the 802.1x test, use the **config client ccx test-dot1x** command.

config client ccx test-dot1x client_mac_address profile_id bssid 802.11 {a | b | g} channel

Syntax Description	client_mac_address	MAC address of the client.
	profile_id	Test profile name.
	bssid	Basic SSID.
	802.11a	Specifies the 802.11a network.
	802.11b	Specifies the 802.11b network.
	802.11g	Specifies the 802.11g network.
	channel	Channel number.
Command Default	None	

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to send a request to the client to perform the 802.11b test with the profile name profile_01:

(Cisco Controller) >config client ccx test-dot1x 172.19.28.40 profile_01 bssid 802.11b

config client ccx test-profile

To send a request to the client to perform the profile redirect test, use the **config client ccx test-profile** command.

config client ccx test-profile client_mac_address profile_id

profile_id	Test profile name.
	Note The <i>profile_id</i> should be from one of the client profiles for which client reporting is enabled.
None	
Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.
• 1	e shows how to send a request to the client to perform the profile redirect test with the 1:
	Release 7.6

(Cisco Controller) >config client ccx test-profile 11:11:11:11:11:11 profile_01

config client deauthenticate

To disconnect a client, use the **config client deauthenticate** command.

config client deauthenticate {*MAC* | *IPv4/v6_address* | *user_name*}

Syntax Description	МАС	Client MAC address.	-
	IPv4/v6_address	IPv4 or IPv6 address.	
	user_name	Client user name.	•
			•
Command Default	None		
Command History	Release	Modification	-
	7.6	This command was introduced in a release earlier than Release 7.6.	•
Examples		ple shows how to deauthenticate a client using its MAC address:	

(Cisco Controller) >config client deauthenticate 11:11:11:11:11

config client location-calibration

To configure link aggregation, use the config client location-calibration command.

config client location-calibration {**enable** *mac_address interval* | **disable** *mac_address*}

ntax Description	enable	(Optional) Specifies that client location calibration is enabled.
	mac_address	MAC address of the client.
	interval	Measurement interval in seconds.
	disable	(Optional) Specifies that client location calibration is disabled.

Command Default None

Command History	Release	Modification
7.6This comma		This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable the client location calibration for the client 37:15:85:2a with a measurement interval of 45 seconds:

(Cisco Controller) >config client location-calibration enable 37:15:86:2a:Bc:cf 45

config ipv6 disable

To disable IPv6 globally on the Cisco WLC, use the ${\bf config}\ ipv6\ disable\ command$.

	config ipv6 disable		
Syntax Description	This command has no arguments or keywords.		
Command Default	None		
Command History	Release Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines	When you use this command, the controller drops all IPv6 packets and the clients will not receive any IPv6 address.		
Examples	The following example shows how to disable IPv6 on the controller: (Cisco Controller) >config ipv6 disable		

config ipv6 enable

To enable IPv6 globally on the Cisco WLC, use the config ipv6 enable command.

config ipv6 enable

Syntax Description This command has no arguments or keywords.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable IPv6 on the Cisco WLC: (Cisco Controller) >config ipv6 enable

config ipv6 acl

To create or delete an IPv6 ACL on the Cisco wireless LAN controller, use the config ipv6 acl command.

config ipv6 acl {apply ipv6_acl_name | create ipv6_acl_name | delete ipv6_acl_name | rule {action rule_name rule_index {permit | deny} | add rule_name rule_index | change index rule_name old_index new_index | delete rule_name rule_index | destination address rule_name rule_index ip_address netmask | destination port range rule_name rule_index start_port end_port | direction rule_name rule_index {in | out | any} | dscp rule_name rule_index dscp | protocol rule_name rule_index protocol | source address rule_name rule_index ip_address netmask | source port range rule_name rule_index start_port end_port | swap index rule_name rule_index start_port end_port | swap index rule_name rule_index start_port end_port | swap index rule_name index_1 index_2} }

Syntax Description	apply	Applies an IPv6 ACL.
	ipv6_acl_name	IPv6 ACL name that contains up to 32 alphanumeric characters.
	create	Creates an IPv6 ACL.
	delete	Deletes an IPv6 ACL.
	rule	Configures the IPv6 ACL.
	action	Configures whether to permit or deny access.
	rule_name	ACL name that contains up to 32 alphanumeric characters.
	rule_index	Rule index between 1 and 32.
	permit	Permits the rule action.
	deny	Denies the rule action.
	add	Adds a new rule.
	change	Changes a rule's index.
	index	Specifies a rule index.
	delete	Deletes a rule.
	destination address	Configures a rule's destination IP address and netmask.
	ip_address	IP address of the rule.
	netmask	Netmask of the rule.
	start_port	Start port number (between 0 and 65535).
	end_port	End port number (between 0 and 65535).

Cisco Wireless LAN Controller Command Reference, Release 7.5

	direction		Configures a rule's direction to in, out, or any.
	in		Configures a rule's direction to in.
	out		Configures a rule's direction to out.
	any		Configures a rule's direction to any.
	dscp		Configures a rule's DSCP.
	dscp		Number between 0 and 63, or any .
	protocol		Configures a rule's DSCP.
	protocol		Number between 0 and 255, or any .
	source addres	'S	Configures a rule's source IP address and netmask.
	source port ra	inge	Configures a rule's source port range.
	swap		Swap's two rules' indices.
	destination po	ort range	Configure a rule's destination port range.
mmand Default	None		
mmand History	Release	Modification	
	7.6	This command was	s introduced in a release earlier than Release 7.6.

Usage Guidelines For a Cisco 2100 Series Wireless LAN Controller, you must configure a preauthentication ACL on the wireless LAN for the external web server. This ACL should then be set as a wireless LAN preauthentication ACL under Web Policy. However, you do not need to configure any preauthentication ACL for Cisco 4400 Series Wireless LAN Controllers.

ExamplesThe following example shows how to configure an IPv6 ACL to permit access:
(Cisco Controller) >config ipv6 acl rule action lab1 4 permit

config ipv6 neighbor-binding

To configure the Neighbor Binding table on the Cisco wireless LAN controller, use the **config ipv6 neighbor-binding** command.

config ipv6 neighbor-binding {**timers** {**down-lifetime** *down_time* | **reachable-lifetime** *reachable_time* | **stale-lifetime** *stale_time* } | { **ra-throttle** {**allow at-least** *at_least_value*} | **enable** | **disable** | **interval-option** { **ignore** | **passthrough** | **throttle** } | **max-through** {*no_mcast_RA* | **no-limit**} | **throttle-period** *throttle period*} }

Syntax Description	timers	Configures the neighbor binding table timeout timers.	
	down-lifetime	Configures the down lifetime.	
	down_time	Down lifetime in seconds. The range is from 0 to 86400. The default is 30 seconds.	
	reachable-lifetime	Configures the reachable lifetime.	
	reachable_time	Reachable lifetime in seconds. The range is from 0 to 86400. The default is 300 seconds.	
	stale-lifetime	Configures the stale lifetime.Stale lifetime in seconds. The range is from 0 to 86400. The default is 86400 seconds.Configures IPv6 RA throttling options.	
	stale_time		
	ra-throttle		
	allow	Specifies the number of multicast RAs per router per throttle period.	
	at_least_value	Number of multicast RAs from router before throttling. The range is from 0 to 32. The default is 1.	
	enable	Enables IPv6 RA throttling.	
	disable	Disables IPv6 RA throttling.	
	interval-option	Adjusts the behavior on RA with RFC3775 interval option.	
	ignore	Indicates interval option has no influence on throttling.	
	passthrough	Indicates all RAs with RFC3775 interval option will be forwarded (default).	

throttle	Indicates all RAs with RFC3775 interval option wil be throttled.
max-through	Specifies unthrottled multicast RAs per VLAN per throttle period.
no_mcast_RA	Number of multicast RAs on VLAN by which throttling is enforced. The default multicast RAs or vlan is 10.
no-limit	Configures no upper bound at the VLAN level.
throttle-period	Configures the throttle period.
throttle_period	Duration of the throttle period in seconds. The range is from 10 to 86400 seconds. The default is 600 seconds.

Command Default None

Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	

Examples The following example shows how to configure the Neighbor Binding table: (Cisco Controller) >config ipv6 neighbor-binding ra-throttle

config ipv6 na-mcast-fwd

To configure the Neighbor Advertisement multicast forwarding, use the config ipv6 na-mcast-fwd command.

config ipv6 na-mcast-fwd {enable | disable}

Syntax Description	enable	Enables Neighbor Advertisement multicast forwarding.
	disable	Disables Neighbor Advertisement multicast forwarding.
Command Default	None	
Command History	Release	Modification
	7.5	This command was introduced.
Usage Guidelines		sement multicast forwarding, all the unsolicited multicast Neighbor ireless is not forwarded to wireless.
	If you disable Neighbor Advertation the controller is affected.	sement multicast forwarding, IPv6 Duplicate Address Detection (DAD) of
Examples	The following example shows h	ow to configure an Neighbor Advertisement multicast forwarding:
	(Cisco Controller) > config	ipv6 na-mcast-fwd enable

config ipv6 ns-mcast-fwd

To configure the nonstop multicast cache miss forwarding, use the config ipv6 ns-mcast-fwd command.

config ipv6 ns-mcast-fwd {enable | disable}

Syntax Description	enable	Enables nonstop multicast forwarding on a cache miss.
	disable	Disables nonstop multicast forwarding on a cache miss.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

config ipv6 ra-guard

To configure the filter for Router Advertisement (RA) packets that originate from a client on an AP, use the **config ipv6 ra-guard** command.

config ipv6 ra-guard ap {enable | disable}

Syntax Description	enable	Enchles DA guard on an AD
	enable	Enables RA guard on an AP.
	disable	Disables RA guard on an AP.
Command Default	None	
<u> </u>		
Command History	Release	Modification
Command History	Release 7.6	Modification This command was introduced in a release earlier than Release 7.6.
Command History		
	7.6	This command was introduced in a release earlier than Release 7.6.
Command History Examples	7.6	

config remote-lan

To configure a remote LAN, use the config remote-lan command.

config remote-lan {enable | disable} {remote-lan-id | all}

Syntax Description	enable Enables a remote LAN.		
	disable	Disables a remote LAN.	
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.	
	all	Configures all wireless LANs.	
Command Default	None		

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable a remote LAN with ID 2: (Cisco Controller) >config remote-lan enable 2

config remote-lan aaa-override

To configure user policy override through AAA on a remote LAN, use the **config remote-lan aaa-override** command.

config remote-lan aaa-override {enable | disable} remote-lan-id

Syntax Description	enable	Enables user policy override through AAA on a remote LAN.
	disable	Disables user policy override through AAA on a remote LAN.
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Freemales	The 6-11	
Examples	remote LAN ID is	mple shows how to enable user policy override through AAA on a remote LAN where the 2:
	(Cisco Controll	er) >config remote-lan aaa-override enable 2

config remote-lan acl

To specify an access control list (ACL) for a remote LAN, use the config remote-lan acl command.

config remote-lan acl remote-lan-id acl_name

Syntax Description	<i>remote-lan-id</i> Remote LAN identifier. Valid values are between 1 and 512.		
	acl_name	ACL n	ame.
		Note	Use the show acl summary command to know the ACLs available.
Command Default	None		
Command History	Release	Modification	1
	7.6	This comma	nd was introduced in a release earlier than Release 7.6.
Examples	The following exa	mple shows how	to specify ACL1 for a remote LAN whose ID is 2:
	(Cisco Controlle	er) > config re	mote-lan acl 2 ACL1

config remote-lan create

To configure a new remote LAN connection, use the config remote-lan create command.

config remote-lan create remote-lan-id name

<i>remote-lan-id</i> Remote LAN identifier. Valid values are between 1 and 512.		
name	Remote LAN name. Valid values are up to 32 alphanumeric characters.	
None		
Release	Modification	
7.6	This command was introduced in a release earlier than Release 7.6.	
	name None Release	

(Cisco Controller) >config remote-lan create 3 MyRemoteLAN

config remote-lan custom-web

To configure web authentication for a remote LAN, use the config remote-lan custom-web command.

config remote-lan custom-web {**ext-webauth-url** *URL* } | **global** {**enable** | **disable**} | **login-page** *page-name* | **loginfailure-page** {*page-name* | **none**} | **logout-page** {*page-name* | **none**} | **webauth-type** {**internal** | **customized** | **external**} *} remote-lan-id*

ax Description	ext-webauth-url	Configures an external web authentication URL.
	URL	Web authentication URL for the Login page.
	global	Configures the global status for the remote LAN.
	enable	Enables the global status for the remote LAN.
	disable	Disables the global status for the remote LAN.
	login-page	Configures a login page.
	page-name	Login page name.
	none	Configures no login page.
	logout-page	Configures a logout page.
	none	Configures no logout page.
	webauth-type	Configures the web authentication type for the remote LAN.
	internal	Displays the default login page.
	customized	Displays a downloaded login page.
	external	Displays a login page that is on an external server.
	name	Remote LAN name. Valid values are up to 32 alphanumeric characters.
	remote-lan-id	Remote LAN identifier. Valid values are from 1 to 512.

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines	Follow these guidelines when you use the config remote-lan custom-web command:			
	• When you configure the external Web-Auth URL, do the following:			
	 Ensure that Web-Auth or Web-Passthrough Security is in enabled state. To enable Web-Auth, use the config remote-lan security web-auth enable command. To enable Web-Passthrough, use the config remote-lan security web-passthrough enable command. 			
	• Ensure that the global status of the remote LAN is in disabled state. To enable the global status of the remote LAN, use the config remote-lan custom-web global disable command.			
	 Ensure that the remote LAN is in disabled state. To disable a remote LAN, use the config remote-lan disable command. 			
	• When you configure the Web-Auth type for the remote LAN, do the following:			
	• When you configure a customized login page, ensure that you have a login page configured. To configure a login page, use the config remote-lan custom-web login-page command.			
	 When you configure an external login page, ensure that you have configured preauthentication ACL for external web authentication to function. 			
Examples	The following example shows how to configure an external web authentication URL for a remote LAN with ID 3:			
	(Cisco Controller) >config remote-lan custom-web ext-webauth-url http://www.AuthorizationURL.com/ 3			
	The following example shows how to enable the global status of a remote LAN with ID 3:			
	(Cisco Controller) >config remote-lan custom-web global enable 3			
	The following example shows how to configure the login page for a remote LAN with ID 3:			
	(Cisco Controller) >config remote-lan custom-web login-page custompage1 3 The following example shows how to configure a web authentication type with the default login page for a remote LAN with ID 3:			

(Cisco Controller) >config remote-lan custom-web webauth-type internal 3

config remote-lan delete

To delete a remote LAN connection, use the config remote-lan delete command.

config remote-lan delete remote-lan-id

Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	e	mple shows how to delete a remote LAN with ID 3:
	(Cisco Controlle	er) >config remote-lan delete 3

config remote-lan dhcp_server

To configure a dynamic host configuration protocol (DHCP) server for a remote LAN, use the **config remote-lan dhcp_server** command.

config remote-lan dhcp_server remote-lan-id ip_address

Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	ip_address	IP address of the DHCP server.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	-	mple shows how to configure a DHCP server for a remote LAN with ID 3:

config remote-lan exclusionlist

To configure the exclusion list timeout on a remote LAN, use the config remote-lan exclusionlist command.

config remote-lan exclusionlist remote-lan-id {seconds | disabled | enabled}

Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	seconds	Exclusion list timeout in seconds. A value of 0 requires an administrator override.
	disabled	Disables exclusion listing.
	enabled	Enables exclusion listing.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exa with ID 3:	ample shows how to configure the exclusion list timeout to 20 seconds on a remote LAN

(Cisco Controller) >config remote-lan exclusionlist 3 20

config remote-lan interface

To configure an interface for a remote LAN, use the config remote-lan interface command.

config remote-lan interface remote-lan-id interface_name

Syntax Description	<i>remote-lan-id</i> Remote LAN identifier. Valid values are between 1 and 512.			
	interface_name	Interface name.		
		Note Interface name should not be in upper case characters.		
Command Default	None			
Command History	Release	Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.		
Examples		nple shows how to configure an interface myinterface for a remote LAN with ID 3:		

config remote-lan Idap

To configure a remote LAN's LDAP servers, use the config remote-lan ldap command.

config remote-lan ldap {add | delete} remote-lan-id index

Syntax Description	add	Adds a link to a configured LDAP server (maximum of three).
	delete	Deletes a link to a configured LDAP server.
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	index	LDAP server index.

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to add an LDAP server with the index number 10 for a remote LAN with ID 3:

(Cisco Controller) >config remote-lan ldap add 3 10

config remote-lan mac-filtering

To configure MAC filtering on a remote LAN, use the config remote-lan mac-filtering command.

config remote-lan mac-filtering {enable | disable} remote-lan-id

Syntax Description	enable	Enables MAC filtering on a remote LAN.
	disable	Disables MAC filtering on a remote LAN.
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.

Command Default MAC filtering on a remote LAN is enabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to disable MAC filtering on a remote LAN with ID 3: (Cisco Controller) >config remote-lan mac-filtering disable 3

config remote-lan max-associated-clients

To configure the maximum number of client connections on a remote LAN, use the **config remote-lan max-associated-clients** command.

config remote-lan max-associated-clients remote-lan-id max-clients

Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	max-clients	Configures the maximum number of client connections on a remote LAN.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	-	mple shows how to configure 10 client connections on a remote LAN with ID 3: er) >config remote-lan max-associated-clients 3 10

config remote-lan radius_server

To configure the RADIUS servers on a remote LAN, use the config remote-lan radius_server command.

 $\begin{array}{l} \textbf{config remote-lan radius_server \{acct \{ \{ add \mid delete \} \textit{ server-index} \mid \{ enable \mid disable \} \mid interim-update \\ \{ \textit{interval} \mid enable \mid disable \} \} \mid auth \{ \{ add \mid delete \} \textit{ server-index} \mid \{ enable \mid disable \} \} \mid overwrite-interface \\ \{ enable \mid disable \} \} \textit{ remote-lan-id} \\ \end{array}$

Syntax Description	acct	Configures a RADIUS accounting server.
	add	Adds a link to a configured RADIUS server.
	delete	Deletes a link to a configured RADIUS server.
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	server-index	RADIUS server index.
	enable	Enables RADIUS accounting for this remote LAN.
	disable	Disables RADIUS accounting for this remote LAN.
	interim-update	Enables RADIUS accounting for this remote LAN.
	interval	Accounting interim interval. The range is from 180 to 3600 seconds.
	enable	Enables accounting interim update.
	disable	Disables accounting interim update.
	auth	Configures a RADIUS authentication server.
	enable	Enables RADIUS authentication for this remote LAN.
	disable	Disables RADIUS authentication for this remote LAN.
	overwrite-interface	Configures a RADIUS dynamic interface for the remote LAN.
	enable	Enables a RADIUS dynamic interface for the remote LAN.
	disable	Disables a RADIUS dynamic interface for the remote LAN.

Command Default

The interim update interval is set to 600 seconds.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following	example shows how to enable RADIUS accounting for a remote LAN with ID 3:

config remote-lan security

To configure security policy for a remote LAN, use the config remote-lan security command.

config remote-lan security {{web-auth {enable | disable | acl | server-precedence} remote-lan-id |
{web-passthrough {enable | disable | acl | email-input} remote-lan-id}}

Syntax Description	web-auth	Specifies web authentication.
	enable	Enables the web authentication settings.
	disable	Disables the web authentication settings.
	acl	Configures an access control list.
	server-precedence	Configures the authentication server precedence order for web authentication users.
	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	email-input	Configures the web captive portal using an e-mail address.
	web-passthrough	Specifies the web captive portal with no authentication required.

<u> </u>		
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure the security web authentication policy for remote LAN ID 1:

(Cisco Controller) >config remote-lan security web-auth enable 1

Command Default

None

config remote-lan session-timeout

To configure client session timeout, use the config remote-lan session-timeout command.

config remote-lan session-timeout remote-lan-id seconds

Cuntax Description		
Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	seconds	Timeout or session duration in seconds. A value of zero is equivalent to no timeout.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	with ID 1:	mple shows how to configure the client session timeout to 6000 seconds for a remote LAN

config remote-lan webauth-exclude

To configure web authentication exclusion on a remote LAN, use the **config remote-lan webauth-exclude** command.

config remote-lan webauth-exclude *remote-lan-id* {**enable** | **disable**}

Syntax Description	remote-lan-id	Remote LAN identifier. Valid values are between 1 and 512.
	enable	Enables web authentication exclusion on the remote LAN.
	disable	Disables web authentication exclusion on the remote LAN.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config remote-lan webauth-exclude 1 enable

config rf-profile band-select

To configure the RF profile band selection parameters, use the config rf-profile band-select command.

config rf-profile band-select {**client-rssi** *rssi* | **cycle-count** *cycles* | **cycle-threshold** *value* | **expire** {**dual-band** *value* | **suppression** *value* } | **probe-response** {**enable** | **disable**} } *profile_name*

client-rssi	Configures the client Received Signal Strength Indicator (RSSI) threshold for the RF profile.
rssi	Minimum RSSI for a client to respond to a probe. The range is from -20 to -90 dBm.
cycle-count	Configures the probe cycle count for the RF profile. The cycle count sets the number of suppression cycles for a new client.
cycles	Value of the cycle count. The range is from 1 to 10.
cycle-threshold	Configures the time threshold for a new scanning RF Profile band select cycle period. This setting determines the time threshold during which new probe requests from a client come in a new scanning cycle.
value	Value of the cycle threshold for the RF profile. The range is from 1 to 1000 milliseconds.
expire	Configures the expiration time of clients for band select.
dual-band	Configures the expiration time for pruning previously known dual-band clients. After this time elapses, clients become new and are subject to probe response suppression.
value	Value for a dual band. The range is from 10 to 300 seconds.
suppression	Configures the expiration time for pruning previously known 802.11b/g clients. After this time elapses, clients become new and are subject to probe response suppression.
value	Value for suppression. The range is from 10 to 200 seconds.
probe-response	Configures the probe response for a RF profile.
enable	Enables probe response suppression on clients operating in the 2.4-GHz band for a RF profile.
disable	Disables probe response suppression on clients operating in the 2.4-GHz band for a RF profile.
profile name	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
	rssi cycle-count cycles cycle-threshold value expire dual-band value suppression value probe-response enable disable

Command Default	The default value for	r client RSSI is –80 dBm.
	The default cycle co	unt is 2.
	The default cycle the	reshold is 200 milliseconds.
	The default value for	r dual-band expiration is 60 seconds.
	The default value for	r suppression expiration is 20 seconds.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	When you enable band select on a WLAN, the access point suppresses client probes on 2.4-GHz and moves the dual band clients to the 5-GHz spectrum. The band-selection algorithm directs dual-band clients only from the 2.4-GHz radio to the 5-GHz radio of the same access point, and it only runs on an access point when both the 2.4-GHz and 5-GHz radios are up and running. Band selection can be used only with Cisco Aironet 1040, 1140, and 1250 Series and the 3500 series access points.	
Examples	-	ple shows how to configure the client RSSI:

config rf-profile client-trap-threshold

To configure the threshold value of the number of clients that associate with an access point, after which an SNMP trap is sent to the controller, use the **config rf-profile client-trap-threshold** command.

config rf-profile client-trap-threshold threshold profile_name

Syntax Description	threshold	Threshold value of the number of clients that associate with an access point, after which an SNMP trap is sent to the controller. The range is from 0 to 200. Traps are disabled if the threshold value is configured as zero.
	profile_name	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
Command Default	None	
Command History	Release	Modification
Command History	Release 7.6	Modification This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config rf-profile client-trap-threshold 150

config rf-profile create

To create a RF profile, use the config rf-profile create command.

config rf-profile create {802.11a | 802.11b/g} profile-name

Syntax Description	802.11a	Configures the RF profile for the 2.4GHz band.
	802.11b/g	Configures the RF profile for the 5GHz band.
	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config rf-profile create 802.11a RFtestgroup1

Cisco Wireless LAN Controller Command Reference, Release 7.5
config rf-profile coverage

To configure the RF profile coverage hole detection parameters, use the config rf-profile coverage command.

config rf-profile coverage {**data** *coverage_level* | **exception** *clients* | **level** *value* | **voice** *coverage_level* } *profile_name*

Syntax Description	data	Configures the threshold value of the data RSSI.
	coverage_level	Minimum receive signal strength indication (RSSI) value of data packets received by the access point. The value that you configure is used to identify coverage holes within the network. If the access point receives a packet in the data queue with an RSSI value below the value that you enter here, a potential coverage hole is detected. The range is from -90 to -60 dBm. The access point takes voice RSSI measurements every 5 seconds and reports them to the controller in 90-second intervals.
	exception	Configures the coverage exception per access point.
	clients	Minimum number of clients on an access point with an RSSI value at or below the data or voice RSSI threshold. The range is from 1 to 75. The default value is 3.
	voice	Configures the threshold value of the voice RSSI.
	coverage_level	Minimum receive signal strength indication (RSSI) value of voice packets received by the access point. The value that you configure is used to identify coverage holes within the network. If the access point receives a packet in the data queue with an RSSI value below the value that you enter here, a potential coverage hole is detected. The range is from –90 to –60 dBm. The access point takes voice RSSI measurements every 5 seconds and reports them to the controller in 90-second intervals.
	level	Configures the coverage exception level per AP.
	value	Coverage exception level per AP. Percentage of clients on an access point that are experiencing a low signal level but cannot roam to another access point.
		The controller determines if the coverage hole can be corrected and, if appropriate, mitigates the coverage hole by increasing the transmit power level for that specific access point.
	profile_name	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.

Command Default

The default value of the data coverage level is -80 dBm.

The default value of the minimum number of clients on an access point with an RSSI value at or below the data or voice RSSI threshold is 3.

The default value of the percentage of clients on an access point that are experiencing a low signal level is 25%.

The default value of the voice coverage level is -80 dBm.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example shows how to configure the threshold value of the data RSSI: (Cisco Controller) >config rf-profile coverage data -80 The following example shows how to configure the minimum client coverage exception level:

(Cisco Controller) >config rf-profile coverage exception 10

The following example shows how to configure the coverage exception level per AP: (Cisco Controller) >config rf-profile coverage level 30

config rf-profile data-rates

To configure the data rate on a RF profile, use the **config rf-profile data-rates** command.

config rf-profile data-rates {802.11a |802.11b } {disabled | mandatory | supported} data-rate profile-name

Syntax Description	802.11a		Specifies 802.11a as the radio policy of the RF profile.
	802.11b		Specifies 802.11b as the radio policy of the RF profile.
	disabled		Disables a rate.
	mandatory		Sets a rate to mandatory.
	supported		Sets a rate to supported.
	data-rate		802.11 operational rates, which are 1*, 2*, 5.5*, 6, 9, 11*, 12, 18, 24, 36, 48 and 54, where * denotes 802.11b only rates.
	profile-name		Name of the RF profile.
Command Default	configurations.		from the controller system defaults, the global data rate e's radio policy is mapped to 802.11a then the global 802.11a he time of creation.
	If the data rate i as supported by communicate w	is set to mandatory, the client the Cisco wireless LAN com	bitiated between the client and the Cisco wireless LAN controller. must support it in order to use the network. If a data rate is set troller, any associated client that also supports that rate may ess point using that rate. It is not required that a client is able to associate.
Command History	Release	Modification	
	7.6		troduced in a release earlier than Release 7.6.
Examples	The following e Mbps:	example shows how to set the	802.11b transmission of an RF profile at a mandatory rate at 12
	(Cisco Contro	<pre>ller) >config rf-profile</pre>	802.11b data-rates mandatory 12 RFGroup1

config rf-profile delete

To delete a RF profile, use the **config rf-profile delete** command.

config rf-profile delete profile-name

Syntax Description	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exa	mple shows how to delete a RF profile:
	(Cisco Controlle	er) >config rf-profile delete RFGroup1

config rf-profile description

To provide a description to a RF profile, use the **config rf-profile description** command.

config rf-profile description *description profile-name*

Syntax Description	description	Description of the RF profile.
	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	e	ample shows how to add a description to a RF profile: er) >config rf-profile description This is a demo desciption RFGroup1

config rf-profile load-balancing

To configure load balancing on an RF profile, use the config rf-profile load-balancing command.

config rf-profile load-balancing {**window** *clients* | **denial** *value*} *profile_name*

Syntax Description	window	Configures the client window for load balancing of an RF profile.
	clients	Client window size that limits the number of client associations with an access point. The range is from 0 to 20. The default value is 5.
		The window size is part of the algorithm that determines whether an access point is too heavily loaded to accept more client associations: load-balancing window + client associations on AP with lightest load = load-balancing threshold
		Access points with more client associations than this threshold are considered busy, and clients can associate only to access points with client counts lower than the threshold. This window also helps to disassociate sticky clients.
	denial	Configures the client denial count for load balancing of an RF profile.
	value	Maximum number of association denials during load balancing. The range is from 1 to 10. The default value is 3.
		When a client tries to associate on a wireless network, it sends an association request to the access point. If the access point is overloaded and load balancing is enabled on the controller, the access point sends a denial to the association request. If there are no other access points in the range of the client, the client tries to associate the same access point again. After the maximum denial count is reached, the client is able to associate. Association attempts on an access point from any client before associating any AP is called a sequence of association. The default is 3.
	profile_name	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
Command Default	None	
Commond Illistory		
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

config rf-profile max-clients

To configure the maximum number of client connections per access point of an RF profile, use the **config rf-profile max-clients** commands.

config rf-profile max-clients clients

Syntax Description	clients	Maximum number of client connections per access point of an RF profile. The range is from 1 to 200.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines		is command to configure the maximum number of clients on access points that are in client serving high bandwidth video or mission critical voice applications.
Examples	e	example shows how to set the maximum number of clients at 50:

config rf-profile multicast data-rate

To configure the minimum RF profile multicast data rate, use the **config rf-profile multicast data-rate** command.

config rf-profile multicast data-rate value profile_name

Syntax Description	value	Minimum RF profile multicast data rate. The options are 6, 9, 12, 18, 24, 36, 48,
		54. Enter 0 to specify that access points will dynamically adjust the data rate.
	profile_name	Name of the RF profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
Command Default	The minimum RF	profile multicast data rate is 0.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exa	ample shows how to set the multicast data rate for an RF profile:

(Cisco Controller) >config rf-profile multicast data-rate 24

config rf-profile out-of-box

To create an out-of-box AP group consisting of newly installed access points, use the **config rf-profile out-of-box** command.

config rf-profile out-of-box {enable | disable}

Syntax Description	enable	Enables the creation of an out-of-box AP group. When you enable this command, the following occurs:
		• Newly installed access points that are part of the default AP group will be part of the out-of-box AP group and their radios will be switched off, which eliminates any RF instability caused by the new access points.
		• All access points that do not have a group name become part of the out-of-box AP group.
		• Special RF profiles are created per 802.11 band. These RF profiles have default-settings for all the existing RF parameters and additional new configurations.
	disable	Disables the out-of-box AP group. When you disable this feature, only the subscription of new APs to the out-of-box AP group stops. All APs that are subscribed to the out-of-box AP group remain in this AP group. You can move APs to the default group or a custom AP group upon network convergence.
Command Default	None	
	none	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	group and t	at-of-box AP associates with the controller for the first time, it will be redirected to a special AP he RF profiles applicable to this AP Group will control the radio admin state configuration of the n move APs to the default group or a custom group upon network convergence.
Examples	The follow	ing example shows how to enable the creation of an out-of-box AP group:
	(Cisco Cor	ntroller) >config rf-profile out-of-box enable

config rf-profile tx-power-control-thresh-v1

To configure Transmit Power Control version1 (TPCv1) to an RF profile, use the **config rf-profile tx-power-control-thresh-v1** command.

config rf-profile tx-power-control-thresh-v1 tpc-threshold profile_name

Syntax Description	tpc-threshold	TPC threshold.
	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
Command History	Release 7.6	ModificationThis command was introduced in a release earlier than Release 7.6.

config rf-profile tx-power-control-thresh-v2

To configure Transmit Power Control version 2 (TPCv2) to an RF profile, use the **config rf-profile tx-power-control-thresh-v2** command.

config rf-profile tx-power-control-thresh-v2 tpc-threshold profile-name

Syntax Description	tpc-threshold	TPC threshold.
	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	-	mple shows how to configure TPCv2 on an RF profile: er) >config rf-profile tx-power-control-thresh-v2 RFGroup1

config rf-profile tx-power-max

To configure maximum auto-rf to an RF profile, use the config rf-profile tx-power-max command.

config rf-profile *tx-power-max profile-name*

yntax Description	tx-power-max	Maximum auto-rf tx power.
	profile-name	Name of the RF profile.
ommand Default	None	
ommand Default ommand History	None Release	Modification

Examples

The following example shows how to configure tx-power-max on an RF profile: (Cisco Controller) >config rf-profile tx-power-max RFGroup1

config rf-profile tx-power-min

To configure minimum auto-rf to an RF profile, use the config rf-profile tx-power-min command.

config rf-profile tx-power-min tx-power-min profile-name

Syntax Description	tx-power-min	Minimum auto-rf tx power.
	profile-name	Name of the RF profile.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

config watchlist add

To add a watchlist entry for a wireless LAN, use the config watchlist add command.

config watchlist add {mac MAC | username username}

Description	mac MAC	Specifies the MAC address of the wireless LAN.
	username username	Specifies the name of the user to watch.
Default	None	
Default History		Nodification

Examples The following example shows how to add a watchlist entry for the MAC address a5:6b:ac:10:01:6b:

(Cisco Controller) >config watchlist add mac a5:6b:ac:10:01:6b

config watchlist delete

To delete a watchlist entry for a wireless LAN, use the config watchlist delete command.

config watchlist delete {mac *MAC* | username username}

Cuntax Description		
Syntax Description	mac MAC	Specifies the MAC address of the wireless LAN to delete from the list.
	username username	Specifies the name of the user to delete from the list.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	C 1	e shows how to delete a watchlist entry for the MAC address a5:6b:ac:10:01:6b:

config watchlist disable

To disable the client watchlist, use the **config watchlist disable** command.

	config watchlist dis	able
Syntax Description	This command has n	o arguments or keywords.
Command Default	None	
Command History	Release	Modification This command was introduced in a release earlier than Release 7.6.
Examples		ple shows how to disable the client watchlist:

config watchlist enable

To enable a watchlist entry for a wireless LAN, use the **config watchlist enable** command.

 config watchlist enable

 Syntax Description
 This command has no arguments or keywords.

 Command Default
 None

 Command History
 Release
 Modification

 7.6
 This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable a watchlist entry:

(Cisco Controller) >config watchlist enable

config wlan

To create, delete, enable, or disable a wireless LAN, use the config wlan command.

config wlan {enable | disable | create | delete} wlan_id [name | foreignAp name ssid | all]

Syntax Description	enable	Enables a wireless LAN.
<i>,</i> ,	enable	Liadies a wireless LAN.
	disable	Disables a wireless LAN.
	create	Creates a wireless LAN.
	delete	Deletes a wireless LAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
	name	(Optional) WLAN profile name up to 32 alphanumeric characters.
	foreignAp	(Optional) Specifies the third-party access point settings.
	ssid	SSID (network name) up to 32 alphanumeric characters.
	all	(Optional) Specifies all wireless LANs.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines		a new WLAN using the config wlan create command, it is created in disabled mode. Leave you have finished configuring it.
	If you do not and	wife on SSID, the profile name perspector is used for both the profile name and the SSID

If you do not specify an SSID, the profile name parameter is used for both the profile name and the SSID.

If the management and AP-manager interfaces are mapped to the same port and are members of the same VLAN, you must disable the WLAN before making a port-mapping change to either interface. If the management and AP-manager interfaces are assigned to different VLANs, you do not need to disable the WLAN.

An error message appears if you try to delete a WLAN that is assigned to an access point group. If you proceed, the WLAN is removed from the access point group and from the access point's radio.

Examples The following example shows how to enable wireless LAN identifier 16: (Cisco Controller) >config wlan enable 16

config wlan 7920-support

To configure support for phones, use the config wlan 7920-support command.

config wlan 7920-support {client-cac-limit | ap-cac-limit} {enable | disable} wlan_id

Syntax Description	ap-cac-limit	Supports phones that require client-controlled Call Admission Control (CAC) that expect the Cisco vendor-specific information element (IE).
	client-cac-limit	Supports phones that require access point-controlled CAC that expect the IEEE 802.11e Draft 6 QBSS-load.
	enable	Enables phone support.
	disable	Disables phone support.
	wlan_id	Wireless LAN identifier between 1 and 512.

and History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
e Guidelines	You cannot ena	ble both WMM mode and client-controlled CAC mode on the same WLAN.
e Guidelines	You cannot ena	ble both WMM mode and client-controlled CAC mode on the same WLAN.
e Guidelines	You cannot ena	ble both WMM mode and client-controlled CAC mode on the same WLAN.
e Guidelines ples		ble both WMM mode and client-controlled CAC mode on the same WLAN.
		example shows how to enable the phone support that requires client-controlled CAC

config wlan 802.11e

To configure 802.11e support on a wireless LAN, use the config wlan 802.11e command.

config wlan 802.11e {allow | disable | require} wlan_id

Syntax Description	allow	Allows 802.11e-enabled clients on the wireless LAN.
	disable	Disables 802.11e on the wireless LAN.
	require	Requires 802.11e-enabled clients on the wireless LAN.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines 802.11e provides quality of service (QoS) support for LAN applications, which are critical for delay sensitive applications such as Voice over Wireless IP (VoWIP).

802.11e enhances the 802.11 Media Access Control layer (MAC layer) with a coordinated time division multiple access (TDMA) construct, and adds error-correcting mechanisms for delay sensitive applications such as voice and video. The 802.11e specification provides seamless interoperability and is especially well suited for use in networks that include a multimedia capability.

Examples The following example shows how to allow 802.11e on the wireless LAN with LAN ID 1: (Cisco Controller) >config wlan 802.11e allow 1

config wlan aaa-override

To configure a user policy override via AAA on a wireless LAN, use the config wlan aaa-override command.

config wlan aaa-override {enable | disable} {*wlan id* | foreignAp}

Syntax Description	enable	Enables a policy override.
	disable	Disables a policy override.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.

Command Default AAA is disabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage GuidelinesWhen AAA override is enabled and a client has conflicting AAA and Cisco wireless LAN controller wireless
LAN authentication parameters, client authentication is performed by the AAA server. As part of this
authentication, the operating system will move clients from the default Cisco wireless LAN VLAN to a VLAN
returned by the AAA server and predefined in the controller interface configuration (only when configured
for MAC filtering, 802.1X, and/or WPA operation). In all cases, the operating system will also use QoS,
DSCP, 802.1p priority tag values, and ACLs provided by the AAA server, as long as they are predefined in
the controller interface configuration. (This VLAN switching by AAA override is also referred to as Identity
Networking.)If the corporate wireless LAN uses a management interface assigned to VLAN 2, and if AAA override returns

a redirect to VLAN 100, the operating system redirects all client transmissions to VLAN 100, regardless of the physical port to which VLAN 100 is assigned.

When AAA override is disabled, all client authentication defaults to the controller authentication parameter settings, and authentication is performed by the AAA server if the controller wireless LAN does not contain any client-specific authentication parameters.

The AAA override values might come from a RADIUS server.

Examples The following example shows how to configure user policy override via AAA on WLAN ID 1:

(Cisco Controller) >config wlan aaa-override enable 1

config wlan acl

To configure a wireless LAN access control list (ACL), use the config wlan acl command.

config wlan acl [acl_name | none]

Syntax Description	wlan_id	Wireless LAN identifier (1 to 512).
	acl_name	(Optional) ACL name.
	none	(Optional) Clears the ACL settings for the specified wireless LAN.
Command Default	None	

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure a WLAN access control list with WLAN ID 1 and ACL named office_1:

(Cisco Controller) >config wlan acl 1 office_1

config wlan assisted-roaming

To configure assisted roaming on a WLAN, use the config wlan assisted-roaming command.

config wlan assisted-roaming {neighbor-list | dual-list | prediction} {enable | disable} wlan_id

Syntax Description	neighbor-list	Configures an 802.11k neighbor list for a WLAN.
	dual-list	Configures a dual band 802.11k neighbor list for a WLAN. The default is the band that the client is currently associated with.
	prediction	Configures an assisted roaming optimization prediction for a WLAN.
	enable	Enables the configuration on the WLAN.
	disable	Disables the configuration on the WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512 (inclusive).
Command Default		ighbor list is enabled for all WLANs. band list is enabled if the neighbor list feature is enabled for the WLAN.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	•	le the assisted roaming prediction list, a warning appears and load balancing is disabled for bad balancing is already enabled on the WLAN.
Examples	The following e	example shows how to enable an 802.11k neighbor list for a WLAN:
	(Cisco Contro	ller) >config wlan assisted-roaming neighbor-list enable 1

config wlan avc

To configure Application Visibility and Control (AVC) on a WLAN, use the config wlan avc command.

config wlan avc wlan_id {profile profile_name | visibility} {enable | disable}

Syntax Description	wlan_id	Wireless LAN identifier from 1 to 512.
	profile	Associates or removes an AVC profile from a WLAN.
	profile_name	Name of the AVC profile. The profile name can be up to 32 case-sensitive, alphanumeric characters.
	visibility	Configures application visibility on a WLAN.
	enable	Enables application visibility on a WLAN. You can view the classification of applications based on the Network Based Application Recognition (NBAR) deep packet inspection technology.
		Use the show avc statistics client command to view the client AVC statistics.
	disable	Disables application visibility on a WLAN.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	rule states a Marl	re only one AVC profile per WLAN and each AVC profile can have up to 32 rules. Each k or Drop action for an application, which allows you to configure up to 32 application actions a can configure up to 16 AVC profiles on a controller and associate an AVC profile with s.
Examples	-	xample shows how to associate an AVC profile with a WLAN:

config wlan apgroup

To manage access point group VLAN features, use the config wlan apgroup command.

config wlan apgroup {add apgroup_name [description] | delete apgroup_name | description apgroup_name
description | interface-mapping {add | delete} apgroup_name wlan_id interface_name | nac-snmp {enable
| disable} apgroup_name wlan_id | nasid NAS-ID apgroup_name | profile-mapping {add | delete}
apgroup_name profile_name | wlan-radio-policy apgroup_name wlan-id {802.11a-only | 802.11bg |
802.11g-only | all} | hotspot {venue {type apgroup_name group_codetype_code| name apgroup_name
language_codevenue_name } | operating-class {add | delete} apgroup_name operating_class_value}}

Syntax Description	add	Creates a new access point group (AP group).
	apgroup_name	Access point group name.
	wlan_id	Wireless LAN identifier from 1 to 512.
	delete	Removes a wireless LAN from an AP group.
	description	Describes an AP group.
	description	Description of the AP group.
	interface-mapping	(Optional) Assigns or removes a Wireless LAN from an AP group.
	interface_name	(Optional) Interface to which you want to map an AP group.
	nac-snmp	Configures NAC SNMP functionality on given AP group. Enables or disables Network Admission Control (NAC) out-of-band support on an access point group.
	enable	Enables NAC out-of-band support on an AP group.
	disable	Disables NAC out-of-band support on an AP group.
	NAS-ID	Network Access Server identifier (NAS-ID) for the AP group. The NAS-ID is sent to the RADIUS server by the controller (as a RADIUS client) using the authentication request, which is used to classify users to different groups. You can enter up to 32 alphanumeric characters. Beginning in Release 7.4 and later releases, you can configure the NAS-ID on the interface, WLAN, or an access point group. The order of priority is AP group NAS-ID > WLAN NAS-ID > Interface NAS-ID.
	none	Configures the controller system name as the NAS-ID.

profile-mapping	Configures RF profile mapping on an AP group.
profile_name	RF profile name for a specified AP group.
wlan-radio-policy	Configures WLAN radio policy on an AP group.
802.11a-only	Configures WLAN radio policy on an AP group.
802.11bg	Configures WLAN radio policy on an AP group.
802.11g-only	Configures WLAN radio policy on an AP group.
all	Configures WLAN radio policy on an AP group.
hotspot	Configures a HotSpot on an AP group.
venue	Configures venue information for an AP group.
type	Configures the type of venue for an AP group.
group_code	Venue group information for an AP group.
	The following options are available:
	• 0 : UNSPECIFIED
	• 1 : ASSEMBLY
	• 2 : BUSINESS
	• 3 : EDUCATIONAL
	• 4 : FACTORY-INDUSTRIAL
	• 5 : INSTITUTIONAL
	• 6 : MERCANTILE
	• 7 : RESIDENTIAL
	• 8 : STORAGE
	• 9 : UTILITY-MISC
	• 10 : VEHICULAR
	• 11 : OUTDOOR

135

type_code

Venue type information for an AP group.

For venue group 1 (ASSEMBLY), the following options are available:

- 0 : UNSPECIFIED ASSEMBLY
- 1 : ARENA
- 2 : STADIUM
- 3 : PASSENGER TERMINAL
- 4 : AMPHITHEATER
- 5 : AMUSEMENT PARK
- 6 : PLACE OF WORSHIP
- 7 : CONVENTION CENTER
- 8 : LIBRARY
- 9 : MUSEUM
- 10 : RESTAURANT
- 11 : THEATER
- 12 : BAR
- 13 : COFFEE SHOP
- 14 : ZOO OR AQUARIUM
- 15 : EMERGENCY COORDINATION CENTER

For venue group 2 (BUSINESS), the following options are available:

- 0 : UNSPECIFIED BUSINESS
- 1 : DOCTOR OR DENTIST OFFICE
- 2 : BANK
- 3 : FIRE STATION
- 4 : POLICE STATION
- 6 : POST OFFICE
- 7 : PROFESSIONAL OFFICE
- 8 : RESEARCH AND DEVELOPMENT FACILITY
- 9 : ATTORNEY OFFICE

For venue group 3 (EDUCATIONAL), the following options are available:

• 0 : UNSPECIFIED EDUCATIONAL

- 1 : PRIMARY SCHOOL
- 2 : SECONDARY SCHOOL
- 3 : UNIVERSITY OR COLLEGE

For venue group 4 (FACTORY-INDUSTRIAL), the following options are available:

- 0 : UNSPECIFIED FACTORY AND INDUSTRIAL
- 1 : FACTORY

For venue group 5 (INSTITUTIONAL), the following options are available:

- 0 : UNSPECIFIED INSTITUTIONAL
- 1 : HOSPITAL
- 2 : LONG-TERM CARE FACILITY
- 3 : ALCOHOL AND DRUG RE-HABILITATION CENTER
- 4 : GROUP HOME
- 5 :PRISON OR JAIL

For venue group 6 (MERCANTILE), the following options are available:

- 0 : UNSPECIFIED MERCANTILE
- 1 : RETAIL STORE
- 2 : GROCERY MARKET
- 3 : AUTOMOTIVE SERVICE STATION
- 4 : SHOPPING MALL
- 5 : GAS STATION

For venue group 7 (RESIDENTIAL), the following options are available:

- 0 : UNSPECIFIED RESIDENTIAL
- 1 : PRIVATE RESIDENCE
- 2 : HOTEL OR MOTEL
- 3 : DORMITORY
- 4 : BOARDING HOUSE

For venue group 8 (STORAGE), the following options are available:

• 0 : UNSPECIFIED STORAGE

For venue group 9 (UTILITY-MISC), the following options are available:

• 0 : UNSPECIFIED UTILITY AND MISCELLANEOUS

For venue group 10 (VEHICULAR), the following options are available:

- 0 : UNSPECIFIED VEHICULAR
- 1 : AUTOMOBILE OR TRUCK
- 2 : AIRPLANE
- 3 : BUS
- 4 : FERRY
- 5 : SHIP OR BOAT
- 6 : TRAIN
- 7 : MOTOR BIKE

For venue group 11 (OUTDOOR), the following options are available:

- 0 : UNSPECIFIED OUTDOOR
- 1 : MINI-MESH NETWORK
- 2 : CITY PARK
- 3 : REST AREA
- 4 : TRAFFIC CONTROL
- 5 : BUS STOP
- 6 : KIOSK

name	Configures the name of venue for an AP group.
language_code	An ISO-639 encoded string defining the language used at the venue. This string is a three character language code. For example, you can enter ENG for English.
venue_name	Venue name for this AP group. This name is associated with the basic service set (BSS) and is used in cases where the SSID does not provide enough information about the venue. The venue name is case-sensitive and can be up to 252 alphanumeric characters.

	add		Adds an operating class for an AP group.
	delete		Deletes an operating class for an AP group.
	operating_cla.	ss_value	Operating class for an AP group. The available operating classes are 81, 83, 84, 112, 113, 115, 116, 117, 118, 119, 120, 121, 122, 123, 124, 125, 126, 127.
Command Default	AP Group VLA	AN is disabled.	
Command History	Release	Modification	
	7.6	This comman	d was introduced in a release earlier than Release 7.6.
Usage Guidelines	Before you can group. The acc see the APs, en groupname cise The NAS-ID co	a delete an AP group i ess points are not mo- iter the show wlan ap <i>co_ap</i> command.	to delete an access point group that is used by at least one access point. n controller software release 6.0, move all APs in this group to another ved to the default-group access point group as in previous releases. To ogroups command. To move APs, enter the config ap group-name coller for AP group or WLAN or interface is used for authentication. The ntrollers.
Examples	e	1	to enable the NAC out-of band support on access point group 4: n apgroup nac enable apgroup 4

config wlan band-select allow

To configure band selection on a WLAN, use the config wlan band-select allow command.

config wlan band-select allow {**enable** | **disable**} *wlan_id*

Syntax Description	enable	Enables band selection on a WLAN.
	disable	Disables band selection on a WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	the dual band clip the 2.4-GHz radii the 2.4-GHz and	e band select on a WLAN, the access point suppresses client probes on 2.4-GHz and moves ents to the 5-Ghz spectrum. The band-selection algorithm directs dual-band clients only from to to the 5-GHz radio of the same access point, and it only runs on an access point when both 5-GHz radios are up and running. Band selection can be used only with Cisco Aironet 1040, Series and the 3500 series access points.
Examples	-	xample shows how to enable band selection on a WLAN:

config wlan broadcast-ssid

To configure an Service Set Identifier (SSID) broadcast on a wireless LAN, use the **config wlan broadcast-ssid** command.

config wlan broadcast-ssid {enable | disable} wlan_id

Syntax Description	enable	Enables SSID broadcasts on a wireless LAN.
	disable	Disables SSID broadcasts on a wireless LAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default Command History		SSID is disabled.
	Broadcasting of Release	SSID is disabled. Modification This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure an SSID broadcast on wireless LAN ID 1: (Cisco Controller) >config wlan broadcast-ssid enable 1

config wlan call-snoop

To enable or disable Voice-over-IP (VoIP) snooping for a particular WLAN, use the **config wlan call-snoop** command.

config wlan call-snoop {enable | disable} wlan_id

Syntax Description	enable	Enables VoIP snooping on a wireless LAN.
	disable	Disables VoIP snooping on a wireless LAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	WLAN should	be with Platinum QoS and it needs to be disabled while invoking this CLI
Examples	-	example shows how to enable VoIP snooping for WLAN 3:

config wlan chd

To enable or disable Coverage Hole Detection (CHD) for a wireless LAN, use the config wlan chd command.

config wlan chd wlan_id {enable | disable}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	enable	Enables SSID broadcasts on a wireless LAN.
	disable	Disables SSID broadcasts on a wireless LAN.

Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable CHD for WLAN 3:

(Cisco Controller) >config wlan chd 3 enable
config wlan ccx aironet-ie

To enable or disable Aironet information elements (IEs) for a WLAN, use the **config wlan ccx aironet-ie** command.

config wlan ccx aironet-ie {enable | disable}

Syntax Description	enable	Enables the Aironet information elements.
	disable	Disables the Aironet information elements.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	-	xample shows how to enable Aironet information elements for a WLAN:

config wlan channel-scan defer-priority

To configure the controller to defer priority markings for packets that can defer off channel scanning, use the **config wlan channel-scan defer-priority** command.

config wlan channel-scan defer-priority *priority* **[enable** | **disable**] *wlan_id*

Syntax Description	priority	User priority value (0 to 7).
	enable	(Optional) Enables packet at given priority to defer off channel scanning.
	disable	(Optional) Disables packet at gven priority to defer off channel scanning.
	wlan_id	Wireless LAN identifier (1 to 512).
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	The priority va	lue should be set to 6 on the client and on the WLAN.
Examples	scanning with	example shows how to enable the controller to defer priority markings that can defer off channel user priority value 6 and WLAN id 30: pller) >config wlan channel-scan defer-priority 6 enable 30

config wlan channel-scan defer-time

To assign the channel scan defer time in milliseconds, use the config wlan channel-scan defer-time command.

config wlan channel-scan defer-time *msecs wlan_id*

Syntax Description	msecs	Deferral time in milliseconds (0 to 60000 milliseconds).
	wlan_id	Wireless LAN identifier from 1 to 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	The time value	in milliseconds should match the requirements of the equipment on your WLAN.
Examples	The following e	xample shows how to assign the scan defer time to 40 milliseconds for WLAN with ID 50:
	(Cisco Contro	ller) > config wlan channel-scan defer-time 40 50

config wlan custom-web

To configure the web authentication page for a WLAN, use the config wlan custom-web command.

config wlan custom-web {**ext-webauth-url** *ext-webauth-url wlan_id* | **global** {**enable** | **disable**} **login-page** *page-name* | **loginfailure-page** {*page-name* | **none**} | **logout-page** {*page-name* | **none**} | **sleep-client** {**enable** *wlan_id* | **disable** *wlan_id* | **timeout** *duration* } | **webauth-type** {**internal** | **customized** | **external**} *wlan_id*}

Cuntary Decenintian		
Syntax Description	ext-webauth-url	Configures an external web authentication URL.
	ext-webauth-url	External web authentication URL.
	wlan_id	WLAN identifier from 1 to 512.
	global	Configures the global status for a WLAN.
	enable	Enables the global status for a WLAN.
	disable	Disables the global status for a WLAN.
	login-page	Configures the name of the login page for an external web authentication URL.
	page-name	Login page name for an external web authentication URL.
	loginfailure-page	Configures the name of the login failure page for an external web authentication URL.
	none	Does not configure a login failure page for an external web authentication URL.
	logout-page	Configures the name of the logout page for an external web authentication URL.
	sleep-client	Configures the sleep client feature on the WLAN.
	timeout	Configures the sleep client timeout on the WLAN.
	duration	Maximum amount of time after the idle timeout, in hours, before a sleeping client is forced to reauthenticate. The range is from 1 to 720. The default value is 12. When the sleep client feature is enabled, the clients need not provide the login credentials when they move from one Cisco WLC to another (if Cisco WLCs are in the same mobility group) between the sleep and wake up times.
	webauth-type	Configures the type of web authentication for the WLAN.
	internal	Displays the default login page.

customized	Displays a customized login page.
external	Displays a login page on an external web server.
None	
Release	Modification
	This command was introduced in a release earlier than Release 7.6.

config wlan dhcp_server

To configure the internal DHCP server for a wireless LAN, use the config wlan dhcp_server command.

config wlan dhcp_server {wlan_id | foreignAp} ip_address [required]

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	ip_address	IP address of the internal DHCP server (this parameter is required).
	required	(Optional) Specifies whether DHCP address assignment is required.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	interface instead of	hod for configuring DHCP is to use the primary DHCP address assigned to a particular of the DHCP server override. If you enable the override, you can use the show wlan command DHCP server has been assigned to the WLAN.
Examples	The following exa wireless LAN ID	mple shows how to configure an IP address 10.10.2.1 of the internal DHCP server for 16:
	(Cisco Controll	er) >config wlan dhcp_server 16 10.10.2.1

config wlan diag-channel

To enable the diagnostic channel troubleshooting on a particular WLAN, use the **config wlan diag-channel** command.

config wlan diag-channel [enable | disable] wlan_id

ntax Description	enable	(Optional) Enables the wireless LAN diagnostic channel.
	disable	(Optional) Disables the wireless LAN diagnostic channel.
	wlan_id	Wireless LAN identifier (1 to 512).
nmand Default	None	
nmand Default nmand History	None Release	Modification

(Cisco Controller) >config wlan diag-channel enable 1

config wlan dtim

Syntax

To configure a Delivery Traffic Indicator Message (DTIM) for 802.11 radio network **config wlan dtim** command.

config wlan dtim {802.11a | 802.11b} dtim wlan_id

C Description	802.11a	Configures DTIM for the 802.11a radio network.	
	802.11b	Configures DTIM for the 802.11b radio network.	
	dtim	Value for DTIM (between 1 to 255 inclusive).	
	wlan_id	Number of the WLAN to be configured.	

Command Default The default is DTIM 1.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure DTIM for 802.11a radio network with DTIM value 128 and WLAN ID 1:

(Cisco Controller) >config wlan dtim 802.11a 128 1

config wlan exclusionlist

To configure the wireless LAN exclusion list, use the config wlan exclusionlist command.

 $\label{eq:config} {\ \ ulan \ ulan \ \ \ ulan \$

	wlan_id	Wireless LAN identifier (1 to 512).
	enabled	(Optional) Enables the exclusion list for the specified wireless LAN or foreign access point.
	disabled	(Optional) Disables the exclusion list for the specified wireless LAN or a foreign access point.
	time	(Optional) Exclusion list timeout in seconds. A value of zero (0) specifies infinite time.
	.	
	foreignAp	Specifies a third-party access point.
Command Default Command History	foreignAp None Release	Specifies a third-party access point. Modification

Examples The following example shows how to enable the exclusion list for WLAN ID 1:

(Cisco Controller) >config wlan exclusionlist 1 enabled

config wlan flow

To associate a NetFlow monitor with a WLAN, use the config wlan flow command.

config wlan flow wlan_id monitor monitor_name {enable | disable}

vlan_id	Wireless LAN identifier from 1 to 512 (inclusive).
monitor	Configures a NetFlow monitor.
nonitor_name	Name of the NetFlow monitor. The monitor name can be up to 32 case-sensitive, alphanumeric characters. You cannot include spaces for a monitor name.
enable	Associates a NetFlow monitor with a WLAN.
disable	Dissociates a NetFlow monitor from a WLAN.
Ione	Madification
ielease	Modification This command was introduced in a release earlier than Release 7.6.
	nonitor_name enable lisable

Examples The following example shows how to associate a NetFlow monitor with a WLAN: (Cisco Controller) >config wlan flow 5 monitor monitor1 enable

config wlan flexconnect ap-auth

To configure local authentication of clients associated with FlexConnect on a locally switched WLAN, use the **config wlan flexconnect ap-auth** command.

config wlan flexconnect ap-auth wlan_id {enable | disable}

Syntax Description	ap-auth	Configures local authentication of clients associated with an FlexConnect on a locally switched WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
	enable	Enables AP authentication on a WLAN.
	disable	Disables AP authentication on a WLAN.
Command Default	None	
Command History	Release	Modification
•	nelease	
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	Local switchin associated with	g must be enabled on the WLAN where you want to configure local authentication of clients a FlexConnect.
Examples	The following specified WLA	example shows how to enable authentication of clients associated with FlexConnect on a N:
Examples	specified WLA	

config wlan flexconnect learn-ipaddr

To enable or disable client IP address learning for the Cisco WLAN controller, use the **config wlan flexconnect learn-ipaddr** command.

config wlan flexconnect learn-ipaddr *wlan id* {enable | disable}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	enable	Enables client IP address learning on a wireless LAN.
	disable	Disables client IP address learning on a wireless LAN.

Command DefaultDisabled when the config wlan flexconnect local-switching command is disabled. Enabled when the config
wlan flexconnect local-switching command is enabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines If the client is configured with Layer 2 encryption, the controller cannot learn the client IP address, and the controller will periodically drop the client. Disable this option to keep the client connection without waiting to learn the client IP address.

Note

The ability to disable IP address learning is not supported with FlexConnect central switching.

Examples The following example shows how to disable client IP address learning for WLAN 6:

(Cisco Controller) >config wlan flexconnect learn-ipaddr disable 6

config wlan flexconnect local-switching

To configure local switching, central DHCP, NAT-PAT, or the override DNS option on a FlexConnect WLAN, use the **config wlan flexconnect local switching** command.

 $\begin{array}{l} \mbox{config wlan flexconnect local-switching $wlan_id $enable | disable$ { {central-dhcp {enable | disable} } at-pat {enable | disable} } | {override option dns { enable | disable} } } \\ \end{array}$

Syntax Description	wlan_id	Wireless LAN identifier from 1 to 512.
	enable	Enables local switching on a FlexConnect WLAN.
	disable	Disables local switching on a FlexConnect WLAN.
	central-dhcp	Configures central switching of DHCP packets on the local switching FlexConnect WLAN. When you enable this feature, the DHCP packets received from the AP are centrally switched to the controller and forwarded to the corresponding VLAN based on the AP and the SSID.
	enable	Enables central DHCP on a FlexConnect WLAN.
	disable	Disables central DHCP on a FlexConnect WLAN.
	nat-pat	Configures Network Address Translation (NAT) and Port Address Translation (PAT) on the local switching FlexConnect WLAN.
	enable	Enables NAT-PAT on the FlexConnect WLAN.
	disable	Disables NAT-PAT on the FlexConnect WLAN.
	override	Specifies the DHCP override options on the FlexConnect WLAN.
	option dns	Specifies the override DNS option on the FlexConnect WLAN. When you override this option, the clients get their DNS server IP address from the AP, not from the controller.
	enable	Enables the override DNS option on the FlexConnect WLAN.
	disable	Disables the override DNS option on the FlexConnect WLAN.

Command Default This feature is disabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	2	le the config wlan flexconnect local-switching command, the config wlan flexconnect ommand is enabled by default.
 Note	The ability to d	isable IP address learning is not supported with FlexConnect central switching.
Examples	The following e NAT-PAT:	xample shows how to enable WLAN 6 for local switching and enable central DHCP and
	(Cisco Contro nat-pat enabl e	ller) >config wlan flexconnect local-switching 6 enable central-dhcp enable e
	The following e	xample shows how to enable the override DNS option on WLAN 6:
	(Cisco Contro	ller) >config wlan flexconnect local-switching 6 override option dns enable

config wlan flexconnect vlan-central-switching

To configure central switching on a locally switched WLAN, use the **config wlan flexconnect vlan-central-switching** command.

config wlan flexconnect vlan-central-switching wlan_id { enable | disable }

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	enable	Enables central switching on a locally switched wireless LAN.
	disable	Disables central switching on a locally switched wireless LAN.
Command Default	Central switchin	ng is disabled.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	central switchir 802.1Q link. If t and the controll WLAN central • FlexConn	e Flexconnect local switching to enable VLAN central switching. When you enable WLAN g, the access point bridges the traffic locally if the WLAN is configured on the local IEEE he VLAN is not configured on the access point, the AP tunnels the traffic back to the controller er bridges the traffic to the corresponding VLAN. switching does not support: ect local authentication. paming of local switching client.
Examples	e	example shows how to enable WLAN 6 for central switching: ller) >config wlan flexconnect vlan-central-switching 6 enable

config wlan hotspot

To configure a HotSpot on a WLAN, use the config wlan hotspot command.

config wlan hotspot {clear-all wlan_id | dot11u | hs2 | msap}

Syntax Description	clear-all	Clears the HotSpot configurations on a WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
	dot11u	Configures an 802.11u HotSpot on a WLAN.
	hs2	Configures HotSpot2 on a WLAN.
	msap	Configures the Mobility Services Advertisement Protocol (MSAP) on a WLAN.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	You can configu	ure up to 32 HotSpot WLANs.
Examples	-	example shows how to configure HotSpot2 for a WLAN: ller) >config wlan hotspot hs2 enable 2

config wlan hotspot dot11u

To configure an 802.11u HotSpot on a WLAN, use the config wlan hotspot dot11u command.

config wlan hotspot dot11u {3gpp-info | auth-type | enable | disable | domain | hessid | ipaddr-type | nai-realm | network-type | roam-oi}

Syntax Description	3gpp-info	Configures 3GPP cellular network information.
	auth-type	Configures the network authentication type.
	enable	Enables 802.11u on the HotSpot profile. IEEE 802.11u enables automatic WLAN offload for 802.1X devices at the HotSpot of mobile or roaming partners.
	disable	Disables 802.11u on the HotSpot profile.
	domain	Configures a domain.
	hessid	Configures the Homogenous Extended Service Set Identifier (HESSID). The HESSID is a 6-octet MAC address that uniquely identifies the network.
	ipaddr-type	Configures the IP address availability type.
	nai-realm	Configures a realm for 802.11u enabled WLANs.
	network-type	Configures the 802.11u network type and Internet access.
	roam-oi	Configures the roaming consortium Organizational Identifier (OI) list.

Command Default

None.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example shows how to enable 802.11u on a HotSpot profile: (Cisco Controller) >config wlan hotspot dot11u enable 6

config wlan hotspot dot11u 3gpp-info

To configure 3GPP cellular network information on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u 3gpp-info** command.

config wlan hotspot dot11u 3gpp-info {add | delete} index country_code network_code wlan_id

Syntax Description	add	Adds mobile cellular network information.
	delete	Deletes mobile cellular network information.
	index	Cellular index. The range is from 1 to 32.
	country_code	Mobile Country Code (MCC) in Binary Coded Decimal (BCD) format. The country code can be up to 3 characters. For example, the MCC for USA is 310.
	network_code	Mobile Network Code (MNC) in BCD format. An MNC is used in combination with a Mobile Country Code (MCC) to uniquely identify a mobile phone operator or carrier. The network code can be up to 3 characters. For example, the MNC for T- Mobile is 026.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	Number of mobile	e network codes supported is 32 per WLAN.
Examples	_	mple shows how to configure 3GPP cellular network information on a WLAN: er) >config wlan hotspot dotllu 3gpp-info add

config wlan hotspot dot11u auth-type

To configure the network authentication type on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u auth-type** command.

config wlan hotspot dot11u auth-type network-auth wlan_id

 0—Acceptance of terms and conditions 1—On-line enrollment
• 1—On-line enrollment
• 2—HTTP/HTTPS redirection
• 3—DNS Redirection
• 4—Not Applicable
Wireless LAN identifier between 1 and 512.

Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	The DNS redire	ection option is not supported in Release 7.3.
Examples	e	example shows how to configure HTTP/HTTPS redirection as the network authentication type HotSpot WLAN:
	(Cisco Contro	ller) >config wlan hotspot dotllu auth-type 2 1

config wlan hotspot dot11u disable

To disable an 802.11u HotSpot on a WLAN, use the config wlan hotspot dot11u disable command.

config wlan hotspot dot11u disable wlan_id

-	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan hotspot dotllu disable 6

config wlan hotspot dot11u domain

To configure a domain operating in the 802.11 access network, use the **config wlan hotspot dot11u domain** command.

config wlan hotspot dot11u domain {**add** *wlan_id domain-index domain_name* | **delete** *wlan_id domain-index* | **modify** *wlan id domain-index domain name*}

Syntax Description	add	Adds a domain.
	wlan_id	Wireless LAN identifier between 1 and 512.
	domain-index	Domain index in the range 1 to 32.
	domain_name	Domain name. The domain name is case sensitive and can be up to 255 alphanumeric characters.
	delete	Deletes a domain.
	modify	Modifies a domain.

Command	Defeult
Commano	Deraint

ault	None
auit	None
	1.0110

Command History	Release	Modification
7.6		This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to add a domain in the 802.11 access network: (Cisco Controller) >config wlan hotspot dotllu domain add 6 30 domain1

config wlan hotspot dot11u enable

To enable an 802.11u HotSpot on a WLAN, use the config wlan hotspot dot11u enable command.

config wlan hotspot dot11u enable wlan_id

Modification
This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan hotspot dot11u enable 6

config wlan hotspot dot11u hessid

To configure a Homogenous Extended Service Set Identifier (HESSID) on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u hessid** command.

config wlan hotspot dot11u hessid hessid wlan_id

Syntax Description	hessid	MAC address that can be configured as an HESSID. The HESSID is a 6-octet MAC address that uniquely identifies the network. For example, Basic Service Set Identification (BSSID) of the WLAN can be used as the HESSID.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	example shows how to configure an HESSID on an 802.11u HotSpot WLAN:

(Cisco Controller) >config wlan hotspot dotllu hessid 00:21:1b:ea:36:60 6

config wlan hotspot dot11u ipaddr-type

To configure the type of IP address available on an 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u ipaddr-type** command.

config wlan hotspot dot11u ipaddr-type IPv4Type IPv6Type wlan_id

Syntax Description	IPv4Type	IPv4 type address. Enter one of the following values:
		0—IPv4 address not available.
		1—Public IPv4 address available.
		2—Port restricted IPv4 address available.
		3—Single NAT enabled private IPv4 address available.
		4—Double NAT enabled private IPv4 address available.
		5—Port restricted IPv4 address and single NAT enabled IPv4 address available.
		6—Port restricted IPv4 address and double NAT enabled IPv4 address available.
		7— Availability of the IPv4 address is not known.
	<i>IPv6Type</i>	IPv6 type address. Enter one of the following values:
		0—IPv6 address not available.
		1—IPv6 address available.
		2—Availability of the IPv6 address is not known.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default The default values for IPv4 type address is 1 and for IPv6 type address is 2.

Command History	Release	Modification	
7.6		This command was introduced in a release earlier than Release 7.6.	

ExamplesThe following example shows how to configure the IP address availability type on an 802.11u HotSpot WLAN:
(Cisco Controller) >config wlan hotspot dot11u ipaddr-type 6 2 6

config wlan hotspot dot11u nai-realm

To configure realms for an 802.11u HotSpot WLANs, use the **config wlan hotspot dot11u nai-realm** command.

config wlan hotspot dot11u nai-realm {**add** | **delete** | **modify**} {**auth-method** *wlan_id realm-index eap-index eap-index eap-index eap-index eap-index eap-method* | **realm-name** *wlan id realm-index realm*}

Syntax Description	add	Adds a realm.		
	delete	Deletes a realm.		
	modify	Modifies a realm.		
	auth-method	Specifies the authentication method used.		
	wlan_id	Wireless LAN identifier from 1 to 512.		
	realm-index	Realm index. The range is from 1 to 32.		
	eap-index	EAP index. The range is from 1 to 4.		
	auth-index	Authentication index value. The range is from 1 to 10.		
	auth-method	Authentication method to be used. The range is from 1 to 4. The following options are available:		
		• 1—Non-EAP Inner Auth Method		
		• 2—Inner Auth Type		
		• 3—Credential Type		
		• 4—Tunneled EAP Method Credential Type		
	auth-parameter	Authentication parameter to use. This value depends on the authentication method used. See the following table for more details.		
	eap-method	Specifies the Extensible Authentication Protocol (EAP) method used.		

eap-method	EAP Method. The range is from 0 to 7. The following options are available:
	• 0—Not Applicable
	• 1—Lightweight Extensible Authentication Protocol (LEAP)
	• 2—Protected EAP (PEAP)
	• 3—EAP-Transport Layer Security (EAP-TLS)
	• 4—EAP-FAST (Flexible Authentication via Secure Tunneling)
	• 5—EAP for GSM Subscriber Identity Module (EAP-SIM)
	• 6—EAP-Tunneled Transport Layer Security (EAP-TTLS)
	• 7—EAP for UMTS Authentication and Key Agreement (EAP-AKA)
realm-name	Specifies the name of the realm.
realm	Name of the realm. The realm name should be RFC 4282 compliant. For example Cisco. The realm name is case-sensitive and can be up to 255 alphanumeric characters.

Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines This table lists the authentication parameters.

Non-EAP Inner Method(1)	Inner Authentication EAP Method Type(2)	Credential Type(3)/Tunneled EAP Credential Type(4)
0—Reserved	1—LEAP	1—SIM
1—Password authentication protocol (PAP)	2—PEAP 3—EAP-TLS	2—USIM 3—NFC Secure Element
2—Challenge-Handshake Authentication Protocol (CHAP)	4—EAP-FAST 5—EAP-SIM	4—Hardware Token 5—Soft Token
3—Microsoft Challenge Handshake Authentication Protocol (MS-CHAP)	6—EAP-TTLS 7—EAP-AKA	6—Certificate 7—Username/Password
4—MSCHAPV2		8—Reserver 9—Anonymous
		10—Vendor Specific

Table 2: Authentication Parameters

Examples The following example shows how to add the Tunneled EAP Method Credential authentication method on WLAN 4:

(Cisco Controller) >config wlan hotspot dot11u nai-realm add auth-method 4 10 3 5 4 6

config wlan hotspot dot11u network-type

To configure the network type and internet availability on an 802.11u HotSpot WLAN, use the **config wlan** hotspot dot11u network-type command.

config wlan hotspot dot11u network-type wlan_id network-type internet-access

Syntax Description	wlan id	Wireless LAN identifier from 1 to 512.
	network-type	Network type. The available options are as follows:
		• 0—Private Network
		• 1—Private Network with Guest Access
		2—Chargeable Public Network
		• 3—Free Public Network
		• 4—Personal Device Network
		5—Emergency Services Only Network
		• 14—Test or Experimental
		• 15—Wildcard
	internet-access	Internet availability status. A value of zero indicates no Internet availability and 1 indicates Internet availability.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	HotSpot WLAN:	nple shows how to configure the network type and Internet availability on an 802.11u

config wlan hotspot dot11u roam-oi

To configure a roaming consortium Organizational Identifier (OI) list on a 802.11u HotSpot WLAN, use the **config wlan hotspot dot11u roam-oi** command.

config wlan hotspot dot11u roam-oi {**add** *wlan_id oi-index oi is-beacon* | **modify** *wlan_id oi-index oi is-beacon* | **delete** *wlan_id oi-index*}

Syntax Description	add	Adds an OI.
	wlan-id	Wireless LAN identifier from 1 to 512.
	oi-index	Index in the range 1 to 32.
	oi	Number that must be a valid 6 digit hexadecimal number and 6 bytes in length. For example, 004096 or AABBDF.
	is-beacon	Beacon flag used to add an OI to the beacon. 0 indicates disable and 1 indicates enable. You can add a maximum of 3 OIs for a WLAN with this flag set.
	modify	Modifies an OI.
	delete	Deletes an OI.

Command Default	None.
-----------------	-------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

ExamplesThe following example shows how to configure the roaming consortium OI list:
(Cisco Controller) >config wlan hotspot dotllu roam-oi add 4 10 004096 1

config wlan hotspot hs2

To configure the HotSpot2 parameters, use the config wlan hotspot hs2 command.

config wlan hotspot hs2 {disable wlan_id | enable wlan_id | operator-name {add wlan_id index operator_name language-code | delete wlan_id index | modify wlan_id index operator-name language-code} | port-config {add wlan_id port_config_index ip-protocol port-number status | delete wlan_id port-config-index | modify wlan_id port-config-index ip-protocol port-number status} | wan-metrics wlan_id link-status symet-link downlink-speed uplink-speed }

Syntax Description

Disables HotSpot2.
Wireless LAN identifier from 1 to 512.
Enables HotSpot2.
Specifies the name of the 802.11 operator.
Adds the operator name, port configuration, or WAN metrics parameters to the WLAN configuration.
Index of the operator. The range is from 1 to 32.
Name of the operator.
Language used. An ISO-14962-1997 encoded string that defines the language. This string is a three character language code. Enter the first three letters of the language in English. For example, eng for English.
Deletes the operator name, port configuration, or WAN metrics parameters from the WLAN.
Modifies the operator name, port configuration, or WAN metrics parameters of the WLAN.
Configures the port configuration values.
Port configuration index. The range is from 1 to 32. The default value is 1.

ip-protocol	Protocol to use. This parameter provides information on the connection status of the most commonly used communication protocols and ports. The following options are available:
	1—ICMP
	6—FTP/SSH/TLS/PPTP-VPN/VoIP
	17—IKEv2 (IPSec-VPN/VoIP/ESP)
	50—ESP (IPSec-VPN)
port-number	Port number. The following options are available:
	0—ICMP/ESP (IPSec-VPN)
	20—FTP
	22—SSH
	443—TLS-VPN
	500—IKEv2
	1723—PPTP-VPN
	4500—IKEv2
	5060—VoIP
status	Status of the IP port. The following options are available:
	0—Closed
	1—Open
	2—Unknown
wan-metrics	Configures the WAN metrics.
link-status	Link status. The following options are available:
	• 0—Unknown
	• 1—Link up
	• 2—Link down
	• 3—Link in test state
symet-link	Symmetric link status. The following options are available:
	• 0—Link speed is different for uplink and downlink. For example: ADSL
	• 1—Link speed is the same for uplink and downlink. For example: DS1
downlink-speed	Downlink speed of the WAN backhaul link in kbps. Maximum value is 4,194,304 kbps.

	uplink-speed	Uplink speed of the WAN backhaul link in kbps. The maximum value is 4,194,304 kbps.
Command Default	None	
Command History	Release	Modification
Command History	Release 7.6	Modification This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan hotspot hs2 wan-metrics add 345 1 0 3333

config wlan hotspot msap

To configure the Mobility Service Advertisement Protocol (MSAP) parameters on a WLAN, use the **config** wlan hotspot msap command.

config wlan hotspot msap {enable | disable | server_id server_id} wlan_id

Syntax Description		
Syntax Description	enable	Enables MSAP on the WLAN.
	disable	Disables MSAP on the WLAN.
	server-id	Specifies the MSAP server id.
	server_id	MSAP server ID. The range is from 1 to 10.
	wlan_id	Wireless LAN identifier from 1 to 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	_	cample shows how to enable MSAP on a WLAN:

config wlan interface

To configure a wireless LAN interface or an interface group, use the config wlan interface command.

config wlan interface {wlan_id | foreignAp} {interface-name | interface-group-name}

Syntax Description	wlan_id	(Optional) Wireless LAN identifier (1 to 512).
	foreignAp	Specifies third-party access points.
	interface-name	Interface name.
	interface-group-name	Interface group name.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure an interface named VLAN901:

(Cisco Controller) >config wlan interface 16 VLAN901

config wlan ipv6 acl

To configure IPv6 access control list (ACL) on a wireless LAN, use the config wlan ipv6 acl command.

config wlan ipv6 acl wlan_id acl_name

Cuntax Description		
Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	acl_name	IPv6 ACL name.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples		xample shows how to configure an IPv6 ACL for local switching:

config wlan kts-cac

To configure the Key Telephone System-based CAC policy for a WLAN, use the **config wlan kts-cac** command.

config wlan kts-cac {enable | disable} wlan_id

Syntax Description	enable	Enables the KTS-based CAC policy.
	disable	Disables the KTS-based CAC policy.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	 Configure config wl Disable th config wl Disable F 	CTS-based CAC policy for a WLAN, ensure that you do the following: e the QoS profile for the WLAN to Platinum by entering the following command: an qos wlan-id platinum he WLAN by entering the following command: an disable wlan-id lexConnect local switching for the WLAN by entering the following command: an flexconnect local-switching wlan-id disable
Examples	The following	example shows how to enable the KTS-based CAC policy for a WLAN with the ID 4:
	(Cisco Contro	oller) >config wlan kts-cac enable 4
config wlan layer2 acl

To configure a Layer 2 access control list (ACL) on a centrally switched WLAN, use the **config wlan acl layer2** command.

config wlan layer2 aclwlan_id {acl_name | none}

Syntax Description	wlan_id	Wireless LAN identifier. The range is from 1 to 512.		
	acl_name	Layer2 ACL name. The name can be up to 32 alphanumeric characters.		
	none	Clears any Layer2 ACL mapped to the WLAN.		
Command Default	None			
Command History	Release	Modification		
· · · · · · · · · · · · · · · · · · ·	nelease			
	7.5	This command was introduced.		
Usage Guidelines	Y			
Usage Guidennes	You can create a maximum of 16 rules for a Layer 2 ACL.			
	You can create a maximum of 64 Layer 2 ACLs on a Cisco WLC.			
	A maximum of 16 Layer 2 ACLs are supported per access point because an access point supports a maximum of 16 WLANs.			
	2	that the Layer 2 ACL names do not conflict with the FlexConnect ACL names because an access point t support the same Layer 2 and Layer 3 ACL names.		
Examples	C 1	ole shows how to apply a Layer 2 ACL on a WLAN: >config wlan layer2 acl 1 acl_12_1		

config wlan learn-ipaddr-cswlan

To configure client IP address learning on a centrally switched WLAN, use the**config wlan** learn-ipaddr-cswlan command.

config wlan learn-ipaddr-cswlan *wlan_id* {enable | disable}

Syntax Description	wlan_id	Wireless LAN identifier from 1 to 512.	
	enable	Enables client IP address learning on the centrally switched WLAN	
	disable	Disables client IP address learning on the centrally switched WLAN	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines	If the client is configured with Layer 2 encryption, the Cisco WLC cannot learn the client IP address and will periodically drop the client. Disable this option so that the Cisco WLC maintains the client connection without waiting to learn the client IP address.		
Examples	The following example shows how to enable client IP address learning on a centrally switched WLAN: (Cisco Controller) >config wlan learn-ipaddr-cswlan 2 enable		

config wlan ldap

To add or delete a link to a configured Lightweight Directory Access Protocol (LDAP) server, use the **config** wlan ldap command.

config wlan ldap {**add** *wlan_id server_id* | **delete** *wlan_id* {**all** | *server_id*}}

AP server. n 1 and 512. d LDAP server. d LDAP server. lease earlier than Release 7.6. he WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web ftware release 4.2.
d LDAP server.
lease earlier than Release 7.6. ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
lease earlier than Release 7.6. ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ne WLAN. ust be configured and enabled: are release 4.1; LDAP support on Web
ust be configured and enabled: are release 4.1; LDAP support on Web
ared LDAP server with the WI

(Cisco Controller) >config wlan ldap add 100 4

config wlan load-balance

To override the global load balance configuration and enable or disable load balancing on a particular WLAN, use the **config wlan load-balance** command.

config wlan load-balance allow {enable | disable} wlan_id

Syntax Description	enable	Enables band selection on a wireless LAN.
	disable	Disables band selection on a wireless LAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	Load balancing	is enabled by default.
	Load balancing Release	is enabled by default. Modification
Command Default Command History		·

(Cisco Controller) >config wlan load-balance allow enable 3

config wlan mac-filtering

To change the state of MAC filtering on a wireless LAN, use the config wlan mac-filtering command.

config wlan mac-filtering {enable | disable} {wlan_id | foreignAp}

Syntax Description	enable	Enables MAC filtering on a wireless LAN.
	disable	Disables MAC filtering on a wireless LAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
	foreignAp	Specifies third-party access points.

Command Default None

Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	

Examples The following example shows how to enable the MAC filtering on WLAN ID 1:

(Cisco Controller) >config wlan mac-filtering enable 1

config wlan max-associated-clients

To configure the maximum number of client connections on a wireless LAN, guest LAN, or remote LAN, use the **config wlan max-associated-clients** command.

config wlan max-associated-clients max_clients wlan_id

Syntax Description	max_clients	Maximum number of client connections to be accepted.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	C	ample shows how to specify the maximum number of client connections on WLAN ID 2:

config wlan max-radio-clients

To configure the maximum number of WLAN client per access point, use the **config wlan max-radio-clients** command.

config wlan max-radio-clients max_radio_clients wlan_id

Syntax Description	max_radio_clients	Maximum number of client connections to be accepted per access point radio. The valid range is from 1 to 200.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exam	ple shows how to specify the maximum number of client connections per access point 2:

(Cisco Controller) >config wlan max-radio-clients 25 2

config wlan mdns

To configure an multicast DNS (mDNS) profile for a WLAN, use the config wlan mdns command.

config wlan mdns {**enable** | **disable** | **profile** {*profile-name* | **none**}} {*wlan_id* | **all**}

Syntax Description	enable	Enables mDNS snooping on a WLAN.
	disable	Disables mDNS snooping on a WLAN.
	profile	Configures an mDNS profile for a WLAN.
	profile-name	Name of the mDNS profile to be associated with a WLAN.
	none	Removes all existing mDNS profiles from the WLAN. You cannot configure mDNS profiles on the WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
	all	Configures the mDNS profile for all WLANs.
Command Default Command History	Release	Modification
	7.4	This command was introduced.
Usage Guidelines		WLAN before you use this command. Clients receive service advertisements only for I with the profile. The controller gives the highest priority to the profiles associated to
		wed by the interface profiles, and then the WLAN profiles. Each client is mapped to a rder of priority.
Examples	interface groups, follo profile based on the or	

config wlan media-stream

To configure multicast-direct for a wireless LAN media stream, use the config wlan media-stream command.

config wlan media-stream multicast-direct {*wlan_id* | all} {enable | disable}

Syntax Description		
Oyntax Description	multicast-direct	Configures multicast-direct for a wireless LAN media stream.
	wlan_id	Wireless LAN identifier between 1 and 512.
	all	Configures the wireless LAN on all media streams.
	enable	Enables global multicast to unicast conversion.
	disable	Disables global multicast to unicast conversion.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines		ast-direct requires load based Call Admission Control (CAC) to run. WLAN quality of to be set to either gold or platinum.
Examples	The following examp	ble shows how to enable the global multicast-direct media stream with WLAN ID 2:
	(Cisco Controller)	>config wlan media-stream multicast-direct 2 enable

config wlan mfp

To configure management frame protection (MFP) options for the wireless LAN, use the **config wlan mfp** command.

config wlan mfp {**client** [**enable** | **disable**] *wlan_id* | **infrastructure protection** [**enable** | **disable**] *wlan_id*}

Syntax Description	client		Configures client MFP for the wireless LAN.
	enable		(Optional) Enables the feature.
	disable		(Optional) Disables the feature.
	wlan_id		Wireless LAN identifier (1 to 512).
	infrastructure pro	otection	(Optional) Configures the infrastructure MFP for the wireless LAN.
Command Default	None		
Command History	Release	Modification	
	7.6	This comman	nd was introduced in a release earlier than Release 7.6.
Examples	The following exam	nple shows how	to configure client management frame protection for WLAN ID 1:
	(Cisco Controlle	r) > config wl a	an mfp client enable 1

config wlan mobility anchor

To change the state of MAC filtering on a wireless LAN, use the config wlan mobility anchor command.

config wlan mobility anchor {**add** | **delete**} *wlan_id ip_address*

Syntax Description	add Enables MAC filtering on a wireless LAN.		
	delete	Disables MAC filtering on a wireless LAN.	
wlan_id	wlan_id	Wireless LAN identifier between 1 and 512.	
	ip_address	Member switch IP address for anchoring the wireless LAN.	

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure the mobility wireless LAN anchor list with WLAN ID 4 and IP address 192.168.0.14:6:

(Cisco Controller) >config wlan mobility anchor add 4 192.168.0.14

config wlan mobility foreign-map

To configure interfaces or interface groups for foreign Cisco WLCs, use the **config wlan mobility foreign-map** command.

config wlan mobility foreign-map {**add** | **delete**} *wlan_id foreign_mac_address* {*interface_name* | *interface_group_name*}

Syntax Description	add	Adds an interface or interface group to the map of foreign controllers.
	delete	Deletes an interface or interface group from the map of foreign controllers.
	wlan_id	Wireless LAN identifier from 1 to 512.
	foreign_mac_address	Foreign switch MAC address on a WLAN.
	interface_name	Interface name up to 32 alphanumeric characters.
	interface_group_name	Interface group name up to 32 alphanumeric characters.
Command Default	None	
Command History	Release Mo	dification
	7.6 Th	is command was introduced in a release earlier than Release 7.6.
Examples	• •	hows how to add an interface group for foreign Cisco WLCs with WLAN ID 4 and dress on WLAN 00:21:1b:ea:36:60:

(Cisco Controller) >config wlan mobility foreign-map add 4 00:21:1b:ea:36:60 mygroup1

config wlan multicast buffer

To configure the radio multicast packet buffer size, use the config wlan multicast buffer command.

config wlan multicast buffer {enable | disable} buffer-size

Syntax Description	enable	Enables the multicast interface feature for a wireless LAN.
	disable	Disables the multicast interface feature on a wireless LAN.
	buffer-size	Radio multicast packet buffer size. The range is from 30 to 60. Enter 0 to indicate APs will dynamically adjust the number of buffers allocated for multicast.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default The default buffer size is 30

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure radio multicast buffer settings:

(Cisco Controller) >config wlan multicast buffer enable 45 222

config wlan multicast interface

To configure a multicast interface for a wireless LAN, use the config wlan multicast interface command.

config wlan multicast interface *wlan_id* {**enable** | **disable**} *interface_name*

Syntax Description			
	<i>wlan_id</i> Wireless LAN identifier between 1 and 512.		
	enable	Enables multicast interface feature for a wireless LAN.	
	delete	Disables multicast interface feature on a wireless LAN.	
	interface_name	Interface name.	
		Note The interface name can only be specified in lower case characters.	
Command Default	Multicast is disable	ed.	
Command History	Release	Modification	
Command History	Release 7.6	Modification This command was introduced in a release earlier than Release 7.6.	

(Cisco Controller) >config wlan multicast interface 4 enable myinterface1

config wlan nac

To enable or disable Network Admission Control (NAC) out-of-band support for a WLAN, use the **config** wlan nac command.

config wlan nac {**snmp** | **radius**} {**enable** | **disable**} *wlan_id*

Syntax Description	snmp	Configures SNMP NAC support.
	radius	Configures RADIUS NAC support.
	enable	Enables NAC for the WLAN.
	disable	Disables NAC for the WLAN.
	wlan_id	WLAN identifier from 1 to 512.
command Default	None	
command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
lsage Guidelines		ble AAA override before you enable the RADIUS NAC state. You also should disable ocal switching before you enable the RADIUS NAC state.
xamples	The following	example shows how to configure SNMP NAC support for WLAN 13:
	(Cisco Contro	oller) >config wlan nac snmp enable 13
	The following	example shows how to configure RADIUS NAC support for WLAN 34:
	(Cisco Contro	oller) >config wlan nac radius enable 20

config wlan override-rate-limit

To override the bandwidth limits for upstream and downstream traffic per user and per service set identifier (SSID) defined in the QoS profile, use the config wlan override-rate-limit command.

config wlan override-rate-limit wlan id { average-data-rate | average-realtime-rate | burst-data-rate | burst-realtime-rate } { per-ssid | per-client } { downstream | upstream } rate

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	average-data-rate	Specifies the average data rate for TCP traffic per user or per SSID. The range is from 0 to 51,2000 Kbps.
	average-realtime-rate	Specifies the average real-time data rate for UDP traffic per user or per SSID. The range is from 0 to 51,2000 Kbps.
	burst-data-rate	Specifies the peak data rate for TCP traffic per user or per SSID. The range is from 0 to 51,2000 Kbps.
	burst-realtime-rate	Specifies the peak real-time data rate for UDP traffic per user or per SSID. The range is from 0 to 51,2000 Kbps.
	per-ssid	Configures the rate limit for an SSID per radio. The combined traffic of all clients will not exceed this limit.
	per-client	Configures the rate limit for each client associated with the SSID.
	downstream	Configures the rate limit for downstream traffic.
	upstream	Configures the rate limit for upstream traffic.
	rate	Data rate for TCP or UDP traffic per user or per SSID. The range is form 0 to 51,2000 Kbps. A value of 0 imposes no bandwidth restriction on the QoS profile.
Command Default	None	
Command History	Release Modification	

This command was introduced in a release earlier than Release 7.6.

Release

7.6

Modification

Usage Guidelines The rate limits are enforced by the controller and the AP. For central switching, the controller handles the downstream enforcement of per-client rate limit and the AP handles the enforcement of the upstream traffic and per-SSID rate limit for downstream traffic. When the AP enters standalone mode it handles the downstream enforcement of per-client rate limits too.

In FlexConnect local switching and standalone modes, per-client and per-SSID rate limiting is done by the AP for downstream and upstream traffic. However, in FlexConnect standalone mode, the configuration is not saved on the AP, so when the AP reloads, the configuration is lost and rate limiting does not happen after reboot.

For roaming clients, if the client roams between the APs on the same controller, same rate limit parameters are applied on the client. However, if the client roams from an anchor to a foreign controller, the per-client downstream rate limiting uses the parameters configured on the anchor controller while upstream rate limiting uses the parameters of the foreign controller.

Examples The following example shows how to configure the burst real-time actual rate 2000 Kbps for the upstream traffic per SSID:

(Cisco Controller) >config wlan override-rate-limit 2 burst-realtime-rate per-ssid upstream 2000

config wlan passive-client

To configure passive-client feature on a wireless LAN, use the config wlan passive-client command.

config wlan passive-client {enable | disable} wlan_id

Syntax Description	enable	Enables the passive-client feature on a WLAN.
	disable	Disables the passive-client feature on a WLAN.
	wlan_id	WLAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines		able the global multicast mode and multicast-multicast mode by using the config network al and config network multicast mode commands before entering this command.
 Note	You should configure the multicast in multicast-multicast mode only not in unicast mode. The passive client feature does not work with multicast-unicast mode in this release.	
Examples	-	example shows how to configure the passive client on wireless LAN ID 2:
	(CISCO CONCIO	THET, SCONTLY WIGH PASSIVE-CITENT ENABLE 2

config wlan peer-blocking

To configure peer-to-peer blocking on a WLAN, use the config wlan peer-blocking command.

config wlan peer-blocking {disable | drop | forward-upstream} wlan_id

Syntax Description	disable	Disables peer-to-peer blocking and bridge traffic locally within the controller whenever possible.
	drop	Causes the controller to discard the packets.
	forward-upstream	Causes the packets to be forwarded on the upstream VLAN. The device above the controller decides what action to take regarding the packets.
	wlan_id	WLAN identifier between 1 and 512.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to disable the peer-to-peer blocking for WLAN ID 1:

(Cisco Controller) >config wlan peer-blocking disable 1

config wlan pmipv6 default-realm

To configure a default realm for a PMIPv6 WLAN, use the config wlan pmipv6 default-realm command.

config wlan pmipv6 default-realm { *default-realm-name* | **none** } *wlan_id*

Syntax Description	default-realm-name	Default realm name for the WLAN.
	none	Clears the realm name for the WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None.	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following even	pple shows how to configure a default realm name on a PMIPv6 WLAN:
	The following exam	The shows now to configure a default realing hand on a 1 will vol with the

config wlan pmipv6 mobility-type

To configure the mobility type on a WLAN, use the config wlan pmipv6 mobility-type command.

config wlan pmipv6 mobility-type {none | pmipv6 } { wlan_id | all }

Syntax Description	none	Configures a WLAN with Simple IP mobility.
	pmipv6	Configures a WLAN with PMIPv6 mobility.
	all	Enables the specified type of mobility for all WLANs.
	wlan_id	WLAN identifier between 1 and 512.
Command Default	None	

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines You must disable the WLAN when you configure the mobility type.

ExamplesThe following example shows how to configure the mobility type as PMIPv6 on a WLAN:
(Cisco Controller) >config wlan pmipv6 mobility-type pmipv6 16

config wlan pmipv6 profile_name

To configure a profile name for the PMIPv6 WLAN, use the config wlan pmipv6 profile_name command.

config wlan pmipv6 profile_name profile_name wlan_id

Syntax Description	profile_name	Profile name for the PMIPv6 WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This command binds a profile name to the PMIPv6 WLAN or SSID. Each time that a mobile node associate with the controller, it uses the profile name and NAI in the trigger to the PMIPV6 module. The PMIPV6 module extracts all the profile specific parameters such as LMA IP, APN, and NAI and sends the PBU to the ASR5K.	
Examples	-	umple shows how to create a profile named ABC01 on a PMIPv6 WLAN: er) >config wlan pmipv6 profile_name ABC01 16

config wlan policy

To configure a policy on a WLAN, use the **config wlan policy** command.

config wlan policy {**add** | **delete**} *priority-index wlan-id*

Syntax Description	add	Adds a policy on a WLAN.
	delete	Deletes an existing policy from a WLAN.
	priority-index	Priority index of the policy to be configured on the WLAN. The policies are applied to the clients according to the priority index. The range is from 1 to 16.
	policy_name	Name of the profiling policy.
	wlan-id	WLAN identifier from 1 to 512.
Command Default Command History	There is no WLAN polic	y. Modification
	7.5	This command was introduced.
Usage Guidelines Examples	0 1	olicies on a WLAN. hows how to configure a policy on a WLAN:

config wlan profiling

To configure client profiling on a WLAN, use the config wlan profiling command.

config wlan profiling {local | radius} {all | dhcp | http} {enable | disable} wlan_id

Syntax Description	local	Configures client profiling in Local mode for a WLAN.	
	radius	Configures client profiling in RADIUS mode on a WLAN.	
	all	Configures DHCP and HTTP client profiling in a WLAN.	
	dhcp	Configures DHCP client profiling alone in a WLAN.	
	http	Configures HTTP client profiling in a WLAN.	
	enable	Enables the specific type of client profiling in a WLAN.	
		When you enable HTTP profiling, the Cisco WLC collects the HTTP attributes of clients for profiling.	
		When you enable DHCP profiling, the Cisco WLC collects the DHCP attributes of clients for profiling.	
	disable	Disables the specific type of client profiling in a WLAN.	
	wlan_id	Wireless LAN identifier from 1 to 512.	
Usage Guidelines Command Default	Ensure that you Client profiling	a have disabled the WLAN before configuring client profiling on the WLAN.	
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Hoose Cuidelines			
Usage Guidelines	Only clients connected to port 80 for HTTP can be profiled. IPv6 only clients are not profiled.		
	If a session timeout is configured for a WLAN, clients must send the HTTP traffic before the configured timeout to get profiled.		
	This feature is	not supported on the following:	
	FlexConn	ect Standalone mode	

• FlexConnect Local Authentication

Examples

The following example shows how to enable both DHCP and HTTP profiling on a WLAN:

(Cisco Controller) >**config wlan profiling radius all enable 6** HTTP Profiling successfully enabled. DHCP Profiling successfully enabled.

config wlan qos

To change the quality of service (QoS) for a wireless LAN, use the config wlan qos command.

config wlan qos wlan_id {bronze | silver | gold | platinum}
config wlan qos foreignAp {bronze | silver | gold | platinum}

Description	wlan_id	Wireless LAN identifier between 1 and 512.
	bronze	Specifies the bronze QoS policy.
	silver	Specifies the silver QoS policy.
	gold	Specifies the gold QoS policy.
	platinum	Specifies the platinum QoS policy.
	foreignAp	Specifies third-party access points.

Command Default The default QoS policy is silver.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to set the highest level of service on wireless LAN 1:

(Cisco Controller) >config wlan qos 1 gold

config wlan radio

To set the Cisco radio policy on a wireless LAN, use the config wlan radio command.

config wlan radio *wlan_id* {all | 802.11a | 802.11bg | 802.11g | 802.11ag}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	all	Configures the wireless LAN on all radio bands.
	802.11a	Configures the wireless LAN on only 802.11a.
	802.11b g	Configures the wireless LAN on only 802.11b/g (only 802.11b if 802.11g is disabled).
	802.11g	Configures the wireless LAN on 802.11g only.
Command Default	None	

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure the wireless LAN on all radio bands:

(Cisco Controller) >config wlan radio 1 all

config wlan radius_server acct

To configure RADIUS accounting servers of a WLAN, use the config wlan radius_server acct command.

config wlan radius_server acct {enable | disable} *wlan_id |* **add** *wlan_id server_id |* **delete** *wlan_id* {**all** | *server_id*} | **framed-ipv6 { address | both | prefix }** *wlan_id*}

Syntax Description		
Syntax Description	enable	Enables RADIUS accounting for the WLAN.
	disable	Disables RADIUS accounting for the WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
	add	Adds a link to a configured RADIUS accounting server.
	server_id	RADIUS server index.
	delete	Deletes a link to a configured RADIUS accounting server.
	address	Configures an accounting framed IPv6 attribute to an IPv6 address.
	both	Configures the accounting framed IPv6 attribute to an IPv6 address and prefix.
	prefix	Configures the accounting framed IPv6 attribute to an IPv6 prefix.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	xample shows how to enable RADIUS accounting for the WLAN 2:
	(Cisco Contro	ller) >config wlan radius_server acct enable 2
	The following e	xample shows how to add a link to a configured RADIUS accounting server:

(Cisco Controller) > config wlan radius_server acct add 2 5

config wlan radius_server acct interim-update

To configure the interim update of a RADIUS accounting server of a WLAN, use the **config wlan** radius_server acct interim-update command.

config wlan radius_serveracctinterim-update {interval | enable | disable} wlan_id

Syntax Description	interim-update	Configures the interim update of the RADIUS accounting server.
	interval	Interim update interval that you specify. The valid range is 180 seconds to 3600 seconds.
	enable	Enables interim update of the RADIUS accounting server for the WLAN.
	disable	Disables interim update of the RADIUS accounting server for the WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default Interim update of a RADIUS accounting sever is set at 600 seconds.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to specify an interim update of 200 seconds to a RADIUS accounting server of WLAN 2:

(Cisco Controller) >config wlan radius_server acct interim-update 200 2

config wlan radius_server auth

7.6

To configure RADIUS authentication servers of a WLAN, use the config wlan radius_server auth command.

config wlan radius_server auth {enable wlan_id | disable wlan_id} {add wlan_id server_id | delete wlan_id
{all | server_id}}

Syntax Description	auth	Configures a RADIUS authentication
	enable	Enables RADIUS authentication for this WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.
	disable	Disables RADIUS authentication for this WLAN.
	add	Adds a link to a configured RADIUS server.
	server_id	RADIUS server index.
	delete	Deletes a link to a configured RADIUS server.
	all	Deletes all links to configured RADIUS servers.
Command Default	None	
Command History	Release	Modification

Examples The following example shows how to add a link to a configured RADIUS authentication server with WLAN ID 1 and Server ID 1:

This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan radius server auth add 1 1

config wlan radius_server acct interim-update

To configure a wireless LAN's RADIUS servers, use the **config wlan radius_server acct interim-update** command.

config wlan radius_serveracct interim-update {**enable** *wlan_id* | **disable** *wlan_id*} {*interval wlan_id*}

Syntax Description		
Syntax Description	enable	Enables RADIUS authentication or accounting for this WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
	disable	Disables RADIUS authentication or accounting for this WLAN.
	interval	Accounting interim interval between 180 to 3600 seconds.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	This command	helps to set some time as a default if the timeout interval is not specified.
Examples	The following e	example shows how to force the 10 minutes as the default, if timeout interval is not specified:
	(Cisco Contro	ller) >config wlan radius_server acct interim-update 600 1

config wlan radius_server overwrite-interface

To configure a wireless LAN's RADIUS dynamic interface, use the **config wlan radius_server overwrite-interface** command.

 $config \ wlan \ radius_server \ overwrite-interface \ \{apgroup \ | \ enable \ | \ disable \ | \ wlan \} \ wlan_id$

	-	
Syntax Description	apgroup	Enables AP group's interface for all RADIUS traffic on the WLAN.
	enable	Enables RADIUS dynamic interface for this WLAN.
	disable	Disables RADIUS dynamic interface for this WLAN.
	wlan	Enables WLAN's interface for all RADIUS traffic on the WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History		
Commanu mistory	Release	Modification
	Release7.6	Modification This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	7.6	
	7.6 The controller	This command was introduced in a release earlier than Release 7.6.
	7.6 The controller of dynamic interfais used. If the feature is	This command was introduced in a release earlier than Release 7.6. uses the management interface as identity. If the RADIUS server is on a directly connected
	7.6 The controller of dynamic interfais used. If the feature is source for all R	This command was introduced in a release earlier than Release 7.6. uses the management interface as identity. If the RADIUS server is on a directly connected ace, the traffic is sourced from the dynamic interface. Otherwise, the management IP address e enabled, controller uses the interface specified on the WLAN configuration as identity and

config wlan roamed-voice-client re-anchor

To configure a roamed voice client's reanchor policy, use the **config wlan roamed-voice-client re-anchor** command.

config wlan roamed-voice-client re-anchor {enable | disable} wlan id

Syntax Description	enable	Enables the roamed client's reanchor policy.
	disable	Disables the roamed client's reanchor policy.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default The roamed client reanchor policy is disabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable a roamed voice client's reanchor policy where WLAN ID is 1:

(Cisco Controller) >config wlan roamed-voice-client re-anchor enable 1

config wlan security 802.1X

To change the state of 802.1X security on the wireless LAN Cisco radios, use the **config wlan security 802.1X** command.

config wlan security 802.1X {**enable** {*wlan_id* | **foreignAp**} | **disable** {*wlan_id* | **foreignAp**} | **encryption** {*wlan_id* | **foreignAp**} {**0** | **40** | **104**} | **on-macfilter-failure** {**enable** | **disable**}}

Description enable	Enables the 802.1X settings.	
wlan_id	Wireless LAN identifier between 1 and 512.	
foreignAp	Specifies third-party access points.	
disable	Disables the 802.1X settings.	
encryption	Specifies the static WEP keys and indexes.	
0	Specifies a WEP key size of 0 (no encryption) bits. The default value is 104.	
	Note All keys within a wireless LAN must be the same size.	
40	Specifies a WEP key size of 40 bits. The default value is 104.	
	Note All keys within a wireless LAN must be the same size.	
104	Specifies a WEP key size of 104 bits. The default value is 104.	
	Note All keys within a wireless LAN must be the same size.	
on-macfilter-failure	Configures 802.1X on MAC filter failure.	
enable	Enables 802.1X authentication on MAC filter failure.	
disable	Disables 802.1X authentication on MAC filter failure.	

Command Default None

Command History

ReleaseModification7.6This command was introduced in a release earlier than Release 7.6.

Usage Guidelines	To change the encryption level of 802.1X security on the wireless LAN Cisco radios, use the following key sizes:
	• 0—no 802.1X encryption.
	• 40—40/64-bit encryption.
	• 104—104/128-bit encryption. (This is the default encryption setting.)
Examples	The following example shows how to configure 802.1X security on WLAN ID 16.
	(Cisco Controller) >config wlan security 802.1X enable 16

config wlan security ckip

To configure Cisco Key Integrity Protocol (CKIP) security options for the wireless LAN, use the **config wlan** security ckip command.

config wlan security ckip {enable | disable} wlan_id [akm psk set-key {hex | ascii} {40 | 104} key key index wlan id | mmh-mic {enable | disable} wlan id | kp {enable | disable} wlan id]

ntax Description		
	enable	Enables CKIP security.
	disable	Disables CKIP security.
	wlan_id	Wireless LAN identifier from 1 to 512.
	akm psk set-key	(Optional) Configures encryption key management for the CKIP wireless LAN.
	hex	Specifies a hexadecimal encryption key.
	ascii	Specifies an ASCII encryption key.
	40	Sets the static encryption key length to 40 bits for the CKIP WLAN. 40-bit keys must contain 5 ASCII text characters or 10 hexadecimal characters.
	104	Sets the static encryption key length to 104 bits for the CKIP WLAN. 104-bit keys must contain 13 ASCII text characters or 26 hexadecimal characters.
	key	Specifies the CKIP WLAN key settings.
	key_index	Configured PSK key index.
	mmh-mic	(Optional) Configures multi-modular hash message integrity check (MMH MIC) validation for the CKIP wireless LAN.
	kp	(Optional) Configures key-permutation for the CKIP wireless LAN.

Command Default None

Command Hi	storv

Release	Modification
7.6	This command was introduced in a release earlier than Release 7.6.
Examples The following example shows how to configure a CKIP WLAN encryption key of 104 bits (26 hexadecimal characters) for PSK key index 2 on WLAN 03:

(Cisco Controller) >config wlan security ckip akm psk set-key hex 104 key 2 03

config wlan security cond-web-redir

To enable or disable conditional web redirect, use the config wlan security cond-web-redir command.

config wlan security cond-web-redir {enable | disable} wlan_id

Syntax Description	enable	Enables conditional web redirect.
	disable	Disables conditional web redirect.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	example shows how to enable the conditional web direct on WLAN ID 2:

(Cisco Controller) >config wlan security cond-web-redir enable 2

config wlan security eap-passthru

To configure the 802.1X frames pass through on to the external authenticator, use the **config wlan security eap-passthru** command.

config wlan security eap-passthru {**enable** | **disable**} *wlan_id*

NUNTAY HECCHINTION		
Syntax Description	enable	Enables 802.1X frames pass through to external authenticator.
	disable	Disables 802.1X frames pass through to external authenticator.
	wlan_id	Wireless LAN identifier between 1 and 512.
ommand Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
	7.6	This command was introduced in a release earlier than Release 7.6.
xamples		This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan security eap-passthru enable 2

config wlan security ft

To configure 802.11r fast transition parameters, use the **config wlan security ft** command.

config wlan security ft {enable | disable | reassociation-timeout timeout-in-seconds} wlan_id

Syntax Description	enable	Enables 8	Enables 802.11r fast transition roaming support.	
	disable	Disables	802.11r fast transition roaming support.	
	reassociation-tin	neout Configure	es reassociation deadline interval.	
	timeout-in-second		ation timeout value in seconds. The valid range 0 seconds.	
	wlan_id	Wireless	LAN identifier between 1 and 512.	
Command Default	None			
Command History	Release	Modification		
	7.6	This command was introduced in a rel	ease earlier than Release 7.6.	
Usage Guidelines	Ensure that you ha	ave disabled the WLAN before you procee	d.	
Examples	The following exa	mple shows how to enable 802.11r fast tra	nsition roaming support on WLAN 2:	
	(Cisco Controller) >config wlan security ft enable 2			
	The following example shows how to set the reassociation timeout value of 20 seconds for 802.11r fast transition roaming support on WLAN 2:			
	(Cisco Controll	er) > config wlan security ft reasso	ciation-timeout 20 2	

config wlan security ft over-the-ds

To configure 802.11r fast transition parameters over a distributed system, use the **config wlan security ft over-the-ds** command.

config wlan security ft over-the-ds {enable | disable} wlan_id

Syntax Description	enable Enables 802.11r fast transition roaming support over a distributed sys	
	disable	Disables 802.11r fast transition roaming support over a distributed system.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	Enabled.	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	Ensure that you	a have disabled the WLAN before you proceed.
	Ensure that 802	2.11r fast transition is enabled on the WLAN.
Examples	The following example shows how to enable 802.11r fast transition roaming support over a distril on WLAN ID 2:	
	(Cisco Contro	oller) >config wlan security ft over-the-ds enable 2

config wlan security IPsec disable

To disable IPsec security, use the config wlan security IPsec disable command.

config wlan security IPsec disable {*wlan_id* | **foreignAp**}

Syntax Description	wlan_id Wireless LAN identifier between 1 and 512.		
	foreignAp	Specifies third-party access points.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	The following ex	ample shows how to disable the IPsec for WLAN ID 16:	

(Cisco Controller) >config wlan security IPsec disable 16

config wlan security IPsec enable

To enable IPsec security, use the config wlan security IPsec enable command.

config wlan security IPsec enable {*wlan_id* | **foreignAp**}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following ex	cample shows how to enable the IPsec for WLAN ID 16:

config wlan security IPsec authentication

To modify the IPsec security authentication protocol used on the wireless LAN, use the **config wlan security IPsec authentication** command.

config wlan security IPsec authentication {hmac-md5 | hmac-sha-1} {wlan id | foreignAp}

Syntax Description	hmac-md5	Specifies the IPsec HMAC-MD5 authentication protocol.
	hmac-sha-1	Specifies the IPsec HMAC-SHA-1 authentication protocol.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	IntergnAp	Specifics uniti-party access points.

Command Default None

Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	

Examples The following example shows how to configure the IPsec HMAC-SHA-1 security authentication parameter for WLAN ID 1:

(Cisco Controller) >config wlan security IPsec authentication hmac-sha-1 1

config wlan security IPsec encryption

To modify the IPsec security encryption protocol used on the wireless LAN, use the **config wlan security IPsec encryption** command.

config wlan security IPsec encryption {3des | aes | des} {*wlan_id* | foreignAp}

Syntax Description	3des	Enables IPsec 3DES encryption.
	aes	Enables IPsec AES 128-bit encryption.
	des	Enables IPsec DES encryption.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	_	ample shows how to configure the IPsec AES encryption:

config wlan security IPsec config

To configure the proprietary Internet Key Exchange (IKE) CFG-Mode parameters used on the wireless LAN, use the **config wlan security IPsec config** command.

config wlan security IPsec config qotd ip_address {wlan_id | foreignAp}

Syntax Description	qotd	Configures the quote-of-the day server IP for cfg-mode.
	ip_address	Quote-of-the-day server IP for cfg-mode.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	a way for the VI	method of distributing the session keys (encryption and authentication), as well as providing PN endpoints to agree on how the data should be protected. IKE keeps track of connections undle of Security Associations (SAs), to each connection.
Examples	The following ex WLAN 1:	cample shows how to configure the quote-of-the-day server IP 44.55.66.77 for cfg-mode for
	(Cisco Control	ler) >config wlan security IPsec config qotd 44.55.66.77 1

config wlan security IPsec ike authentication

To modify the IPsec Internet Key Exchange (IKE) authentication protocol used on the wireless LAN, use the **config wlan security IPsec ike authentication** command.

config wlan security IPsec ike authentication {**certificates** {*wlan_id* | **foreignAp**} | **pre-share-key** {*wlan_id* | **foreignAp**} *key* | **xauth-psk** {*wlan_id* | **foreignAp**} *key*}

Syntax Description	certificates	Enables the IKE certificate mode.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	pre-share-key	Enables the IKE Xauth with preshared keys.
	xauth-psk	Enables the IKE preshared key.
	key	Key required for preshare and xauth-psk.

Command Default	None
-----------------	------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure the IKE certification mode:

(Cisco Controller) >config wlan security IPsec ike authentication certificates 16

config wlan security IPsec ike dh-group

To modify the IPsec Internet Key Exchange (IKE) Diffie Hellman group used on the wireless LAN, use the **config wlan security IPsec ike dh-group** command.

config wlan security IPsec ike dh-group {*wlan_id* | foreignAp} {group-1 | group-2 | group-5}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	group-1	Specifies DH group 1 (768 bits).
	group-2	Specifies DH group 2 (1024 bits).
	group-5	Specifies DH group 5 (1536 bits).

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

ExamplesThe following example shows how to configure the Diffe Hellman group parameter for group-1:
(Cisco Controller) >config wlan security IPsec ike dh-group 1 group-1

config wlan security IPsec ike lifetime

To modify the IPsec Internet Key Exchange (IKE) lifetime used on the wireless LAN, use the **config wlan** security IPsec ike lifetime command.

config wlan security IPsec ike lifetime {*wlan_id* | **foreignAp**} *seconds*

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	seconds	IKE lifetime in seconds, between 1800 and 345600.
Command Default	None	
Command History	Release	Modification
Command History	Release 7.6	Modification This command was introduced in a release earlier than Release 7.6.
Command History Examples	7.6	

config wlan security IPsec ike phase1

To modify IPsec Internet Key Exchange (IKE) Phase 1 used on the wireless LAN, use the **config wlan security IPsec ike phase1** command.

config wlan security IPsec ike phase1 {aggressive | main} {wlan_id | foreignAp}

Syntax Description	aggressive	Enables the IKE aggressive mode.
	main	Enables the IKE main mode.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
ommand History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
xamples	The following ex	cample shows how to modify IPsec IKE Phase 1:

config wlan security IPsec ike contivity

To modify Nortel's Contivity VPN client support on the wireless LAN, use the **config wlan security IPsec ike contivity** command.

config wlan security IPsec ike contivity {enable | disable} {*wlan_id |* **foreignAp}**

Syntax Description	enable	Enables contivity support for this WLAN.
	disable	Disables contivity support for this WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
	_	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

ExamplesThe following example shows how to modify Contivity VPN client support:
(Cisco Controller) >config wlan security IPsec ike contivity enable 14

config wlan security passthru

To modify the IPsec pass-through used on the wireless LAN, use the config wlan security passthru command.

config wlan security passthru {**enable** | **disable**} {*wlan_id* | **foreignAp**} [*ip_address*]

Syntax Description	enable	Enables IPsec pass-through.
	disable	Disables IPsec pass-through.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
	ip_address	(Optional) IP address of the IPsec gateway (router) that is terminating the VPN tunnel.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following ex	cample shows how to modify IPsec pass-through used on the wireless LAN:

(Cisco Controller) >config wlan security passthru enable 3 192.12.1.1

config wlan security pmf

To configure 802.11w Management Frame Protection (MFP) on a WLAN, use the **config wlan security pmf** command.

config wlan security pmf {disable | optional | required | association-comeback

association-comeback_timeout | saquery-retrytimeout saquery-retry_timeout} wlan_id

	disable	Disables 802.11w MFP protection on a WLAN.	
	optional	Enables 802.11w MFP protection on a WLAN.	
	required	Requires clients to negotiate 802.11w MFP protection on a WLAN.	
	association-comeback	Configures the 802.11w association comeback time.	
	association-comeback_timeou	<i>t</i> Association comeback interval in seconds. Time interval that an associated client must wait before the association is tried again after it is denied with a status code 30. The status code 30 message is "Association request rejected temporarily; Try again later".	
		The range is from 1 to 20 seconds.	
	saquery-retrytimeout	Configures the 802.11w Security Association (SA) query retry timeout.	
	saquery-retry_timeout	Time interval identified in the association response to an already associated client before the association can be tried again. This time interval checks if the client is a real client and not a rogue client during the association comeback time. If the client does not respond within this time, the client association is deleted from the controller. The range is from 100 to 500 ms.	
	wlan_id	Wireless LAN identifier from 1 to 512.	
	Default SA query retry timeout is 200 milliseconds.		
Command Default			
Command Default	Default SA query retry timeo Default association comeback		
Command Default Command History		timeout is 1 second.	

to protect MAC management protocol data units (MMPDUs) from the source STA. The 802.11w IGTK key

	is derived using the four way handshake and is used only on WLANs that are configured with WPA or WPA2 security at Layer 2.
Examples	The following example shows how to enable 802.11w MFP protection on a WLAN: (Cisco Controller) > config wlan security pmf optional 1
Examples	The following example shows how to configure the SA query retry timeout on a WLAN: (Cisco Controller) > config wlan security pmf saquery-retrytimeout 300 1

config wlan security splash-page-web-redir

To enable or disable splash page web redirect, use the config wlan security splash-page-web-redir command.

config wlan security splash-page-web-redir {enable | disable} wlan_id

Syntax Description	enable	Enables splash page web redirect.
	disable	Disables splash page web redirect.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default Splash page web redirect is disabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

 Examples
 The following example shows how to enable spash page web redirect:

 (Cisco Controller) >config wlan security splash-page-web-redir enable 2

config wlan security static-wep-key authentication

To configure static Wired Equivalent Privacy (WEP) key 802.11 authentication on a wireless LAN, use the **config wlan security static-wep-key authentication** command.

config wlan security static-wep-key authentication {shared-key | open} wlan id

Syntax Description	shared-key	Enables shared key authentication.
	open	Enables open system authentication.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

(Cisco Controller) >config wlan security static-wep-key authentication shared-key 1

config wlan security static-wep-key disable

To disable the use of static Wired Equivalent Privacy (WEP) keys, use the **config wlan security static-wep-key disable** command.

config wlan security static-wep-key disable wlan_id

tax Description	wlan_id	Wireless LAN identifier between 1 and 512.
nd Default	None	
d History	Release	Modification

Examples The following example shows how to disable the static WEP keys for WLAN ID 1:

(Cisco Controller) >config wlan security static-wep-key disable 1

config wlan security static-wep-key enable

To enable the use of static Wired Equivalent Privacy (WEP) keys, use the **config wlan security static-wep-key enable** command.

config wlan security static-wep-key enable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Palaasa	Madification
Command History	Release	Modification

Examples The following example shows how to enable the use of static WEK keys for WLAN ID 1:

(Cisco Controller) >config wlan security static-wep-key enable 1

config wlan security static-wep-key encryption

To configure the static Wired Equivalent Privacy (WEP) keys and indexes, use the **config wlan security static-wep-key encryption** command.

config wlan security static-wep-key encryption *wlan_id* {40 | 104} {hex | ascii} *key key-index*

Syntax Description	wlan_id	Wireless LAN identifier from 1 to 512.
	40	Specifies the encryption level of 40.
	104	Specifies the encryption level of 104.
	hex	Specifies to use hexadecimal characters to enter key.
	ascii	Specifies whether to use ASCII characters to enter key.
	key	WEP key in ASCII.
	key-index	Key index (1 to 4).

l History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
idelines	1	EP key index can be applied to each wireless LAN. Because there are only four WEP key
idelines	1	EP key index can be applied to each wireless LAN. Because there are only four WEP key our wireless LANs can be configured for static WEP Layer 2 encryption.
iidelines	indexes, only fo	5 11 5 5
iidelines 5	indexes, only for Make sure to di The following o	our wireless LANs can be configured for static WEP Layer 2 encryption.

config wlan security tkip

To configure the Temporal Key Integrity Protocol (TKIP) Message Integrity Check (MIC) countermeasure hold-down timer, use the **config wlan security tkip** command.

config wlan security tkip hold-down time wlan_id

Syntax Description	hold-down	Configures the TKIP MIC countermeasure hold-down timer.
	time	TKIP MIC countermeasure hold-down time in seconds. The range is from 0 to 60 seconds.
	wlan_id	Wireless LAN identifier from 1 to 512.
Command Default	The default TKIP c	ountermeasure is set to 60 seconds.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	When this situation	are mode can occur if the access point receives 2 MIC errors within a 60 second period. occurs, the access point deauthenticates all TKIP clients that are associated to that 802.11 any clients for the countermeasure holdoff time.
Examples	-	nple shows how to configure the TKIP MIC countermeasure hold-down timer: r) >config wlan security tkip

config wlan security web-auth

To change the status of web authentication used on a wireless LAN, use the **config wlan security web-auth** command.

config wlan security web-auth {{**acl** | **enable** | **disable**} {*wlan_id* | **foreignAp**} [*acl_name* | **none**]} | {**on-macfilter-failure** *wlan_id*} | {**server-precedence** *wlan_id* | **local** | **ldap** | **radius**} | {**flexacl** *wlan_id* [*ipv4_acl_name* | **none**]} | {**ipv6 acl** *wlan_id* [*ipv6_acl_name* | **none**]}

acl	Configures the access control list.
enable	Enables web authentication.
disable	Disables web authentication.
wlan_id	Wireless LAN identifier from 1 to 512.
foreignAp	Specifies third-party access points.
acl_name	(Optional) ACL name (up to 32 alphanumeric characters).
none	(Optional) Specifies no ACL name.
on-macfilter-failure	Enables web authentication on MAC filter failure.
server-precendence	Configures the authentication server precedence order for Web-Auth users.
local	Specifies the server type.
ldap	Specifies the server type.
radius	Specifies the server type.
flexacl	Specifies the IPv4 ACL name. You can enter up to 32 alphanumeric characters.
ipv4_acl_name	(Optional) IPv4 ACL name. You can enter up to 32 alphanumeric characters.
ipv6_acl_name	(Optional) IPv6 ACL name. You can enter up to 32 alphanumeric characters.
	enable disable wlan_id foreignAp acl_name none on-macfilter-failure server-precendence local ldap radius flexacl ipv4_acl_name

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e ACL03:	example shows how to configure the security policy for WLAN ID 1 and an ACL named
	(Cisco Contro	oller) >config wlan security web-auth acl 1 ACL03

Cisco Wireless LAN Controller Command Reference, Release 7.5

config wlan security web-passthrough acl

To add an access control list (ACL) to the wireless LAN definition, use the **config wlan security web-passthrough acl** command.

config wlan security web-passthrough acl {*wlan_id* | **foreignAp**} {*acl_name* | **none**}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.	
	foreignAp	Specifies third-party access points.	
	acl_name	ACL name (up to 32 alphanumeric characters).	
	none	Specifies that there is no ACL.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Examples	The following ex	cample shows how to add an ACL to the wireless LAN definition:	

(Cisco Controller) > config wlan security web-passthrough acl 1 ACL03 $\,$

config wlan security web-passthrough disable

To disable a web captive portal with no authentication required on a wireless LAN, use the **config wlan** security web-passthrough disable command.

config wlan security web-passthrough disable {*wlan_id* | foreignAp}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	LAN ID 1:	ample shows how to disable a web captive portal with no authentication required on wireless

(Cisco Controller) >config wlan security web-passthrough disable 1

config wlan security web-passthrough email-input

To configure a web captive portal using an e-mail address, use the **config wlan security web-passthrough email-input** command.

config wlan security web-passthrough email-input {enable | disable} {*wlan_id* | foreignAp}

ntax Description	email-input	Configures a web captive portal using an e-mail address.
	enable	Enables a web captive portal using an e-mail address.
	disable	Disables a web captive portal using an e-mail address.
	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
ommand Default	None	
ommand Default ommand History	None Release	Modification

config wlan security web-passthrough enable

To enable a web captive portal with no authentication required on the wireless LAN, use the **config wlan** security web-passthrough enable command.

config wlan security web-passthrough enable {wlan_id | foreignAp}

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
	foreignAp	Specifies third-party access points.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	LAN ID 1:	ample shows how to enable a web captive portal with no authentication required on wireless

config wlan security wpa akm 802.1x

To configure authentication key-management (AKM) using 802.1X, use the **config wlan security wpa akm** 802.1x command.

config wlan security wpa akm 802.1x {enable | disable} wlan_id

Syntax Description	enable	Enables the 802.1X support.
	disable	Disables the 802.1X support.
	wlan_id	Wireless LAN identifier from 1 to 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	example shows how to configure authentication using 802.1X.

config wlan security wpa akm 802.1x enable 1

config wlan security wpa akm cckm

To configure authentication key-management using Cisco Centralized Key Management (CCKM), use the **config wlan security wpa akm cckm** command.

config wlan security wpa akm cckm {**enable** *wlan_id* | **disable** *wlan_id* | *timestamp-tolerance* }

Syntax Description	enable	Enables CCKM support.
	disable	Disables CCKM support.
	wlan_id	Wireless LAN identifier between 1 and 512.
	timestamp-tolerance	CCKM IE time-stamp tolerance. The range is between 1000 to 5000 milliseconds; the default is 1000 milliseconds.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following example	e shows how to configure authentication key-management using CCKM.
	(Cisco Controller)	>config wlan security wpa akm cckm 1500

config wlan security wpa akm ft

To configure authentication key-management using 802.11r fast transition 802.1X, use the **config wlan** security wpa akm ft command.

config wlan security wpa akm ft [over-the-air | over-the-ds | psk | [reassociation-timeout seconds]] {enable | disable} wlan_id

Syntax Description	over-the-air	(Optional) Configures 802.11r fast transition roaming over-the-air support.
	over-the-ds	(Optional) Configures 802.11r fast transition roaming DS support.
	psk	(Optional) Configures 802.11r fast transition PSK support.
	reassociation-timeout	(Optional) Configures the reassociation deadline interval.
		The valid range is between 1 to 100 seconds. The default value is 20 seconds.
	seconds	Reassociation deadline interval in seconds.
	enable	Enables 802.11r fast transition 802.1X support.
	disable	Disables 802.11r fast transition 802.1X support.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure authentication key-management using 802.11r fast transition:

(Cisco Controller) >config wlan security wpa akm ft reassociation-timeout 25 1

config wlan security wpa akm pmf

To configure Authenticated Key Management (AKM) of management frames, use the **config wlan security wpa akm pmf** command.

config wlan security wpa akm pmf {802.1x | psk} {enable | disable}*wlan_id*

Syntax Description	802.1x	Configures 802.1X authentication for protection of management frames (PMF).
	psk	Configures preshared keys (PSK) for PMF.
	enable	Enables 802.1X authentication or PSK for PMF.
	disable	Disables 802.1X authentication or PSK for PMF.
	wlan_id	Wireless LAN identifier from 1 to 512.

Command Default	Disabled.
-----------------	-----------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines 802.11w has two new AKM suites: 00-0F-AC:5 or 00-0F-AC:6. You must enable WPA and then disable the WLAN to configure PMF on the WLAN.

ExamplesThe following example shows how to enable 802.1X authentication for PMF in a WLAN:
(Cisco Controller) >config wlan security wpa akm pmf 802.1x enable 1

config wlan security wpa akm psk

To configure the Wi-Fi protected access (WPA) preshared key mode, use the **config wlan security wpa akm psk** command.

config wlan security wpa akm psk {enable | disable | set-key key-format key} wlan_id

Syntax Description	enable	Enables WPA-PSK.
	disable	Disables WPA-PSK.
	set-key	Configures a preshared key.
	key-format	Specifies key format. Either ASCII or hexadecimal.
	key	WPA preshared key.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to configure the WPA preshared key mode:

(Cisco Controller) >config wlan security wpa akm psk disable 1

config wlan security wpa disable

To disable WPA1, use the **config wlan security wpa disable** command.

config wlan security wpa disable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	xample shows how to disable WPA:
Examples	_	
	(Cisco Control	ler) >config wlan security wpa disable 1
config wlan security wpa enable

To enable WPA1, use the **config wlan security wpa enable** command.

config wlan security wpa enable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following ex	cample shows how to configure the WPA on WLAN ID 1:
	(Cisco Control	ler) >config wlan security wpa enable 1

config wlan security wpa ciphers

To configure the Wi-Fi protected authentication (WPA1) or Wi-Fi protected authentication (WPA2), use the **config wlan security wpa ciphers** command.

config wlan security wpa {wpa1 | wpa2} ciphers {aes | tkip} {enable | disable} wlan_id

Syntax Description	wpa1	Configures WPA1 support.	
	wpa2 Configures WPA2 support.		
	ciphers	Configures WPA ciphers.	
	aes	Configures AES encryption support.	
	tkip	Configures TKIP encryption support.	
	enable	Enables WPA AES/TKIP mode.	
	disable	Disables WPA AES/TKIP mode.	
	wlan_id	Wireless LAN identifier between 1 and 512.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines	If you are not sp	pecifying the WPA versions, it implies the following:	
	• If the cipher enabled is AES, you are configuring WPA2/AES.		
	• If the ciphers enabled is AES+TKIP, you are configuring WPA/TKIP, WPA2/AES, or WPA/TKIP.		
	-	er enabled is TKIP, you are configuring WPA/TKIP or WPA2/TKIP.	
Examples	The following e	example shows how to encrypt the WPA:	
	(Cisco Contro	ller) >config wlan security wpa wpal ciphers aes enable 1	

config wlan security wpa gtk-random

To enable the randomization of group temporal keys (GTK) between access points and clients on a WLAN, use the **config wlan security wpa gtk-random** command.

config wlan security wpa gtk-random {enable | disable} wlan_id

Syntax Description	enable Enables the randomization of GTK keys between the access point a		
	disable	Disables the randomization of GTK keys between the access point and clients.	
	wlan_id	WLAN identifier between 1 and 512.	
Command Default	None		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines	When you enable this command, the clients in the Basic Service Set (BSS) get a unique GTK key. The clients do not receive multicast or broadcast traffic.		
Examples	The following example shows how to enable the GTK randomization for each client associated on a WLAN (Cisco Controller) >config wlan security wpa gtk-random enable 3		

config wlan security wpa wpa1 disable

To disable WPA1, use the config wlan security wpa wpa1 disable command.

config wlan security wpa wpa1 disable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
		example shows how to disable WPA1:

(Cisco Controller) >config wlan security wpa wpa1 disable 1

config wlan security wpa wpa1 enable

To enable WPA1, use the **config wlan security wpa wpa1 enable** command.

config wlan security wpa wpa1 enable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following ex	kample shows how to enable WPA1:
	(Cisco Control	ler) >config wlan security wpa wpal enable 1

config wlan security wpa wpa2 disable

To disable WPA2, use the config wlan security wpa wpa2 disable command.

config wlan security wpa wpa2 disable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	xample shows how to disable WPA2:

(Cisco Controller) >config wlan security wpa wpa2 disable 1

config wlan security wpa wpa2 enable

To enable WPA2, use the **config wlan security wpa wpa2 enable** command.

config wlan security wpa wpa2 enable wlan_id

Syntax Description	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	xample shows how to enable WPA2:
	(Cisco Contro	ller) >config wlan security wpa wpa2 enable 1

config wlan security wpa wpa2 cache

To configure caching methods on a WLAN, use the config wlan security wpa wpa2 cache command.

config wlan security wpa wpa2 cache sticky {enable | disable} wlan_id

Syntax Description	sticky	Configures Sticky Key Caching (SKC) roaming support on the WLAN.
	enable	Enables SKC roaming support on the WLAN.
	disable	Disables SKC roaming support on the WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	In SKC (Sticky Key caching) also known as PKC (Pro Active Key caching), the client stores each Pairwise Master Key (PMK) ID (PMKID) against a Pairwise Master Key Security Association (PMKSA). When a client finds an AP for which it has a PMKSA, it sends the PMKID in the association request to the AP. If th PMKSA is alive in the AP, the AP provides support for fast roaming. In SKC, full authentication is done or each new AP to which the client associates and the client must keep the PMKSA associated with all APs.	
Examples	e	xample shows how to enable SKC roaming support on a WLAN:

config wlan security wpa wpa2 cache sticky

To configure Sticky PMKID Caching (SKC) on a WLAN, use the **config wlan security wpa wpa2 cache sticky** command.

config wlan security wpa wpa2 cache sticky {enable |disable} wlan_id

Syntax Description	enable	Enables SKC on a WLAN.
	disable	Disables SKC on a WLAN.
	wlan_id	Wireless LAN identifier between 1 and 512 (inclusive).
Command Default	Stkcky PMKID	Caching is disabled.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	Beginning in Release 7.2 and later releases, the controller supports Sticky PMKID Caching (SKC). With sticky PMKID caching, the client receives and stores a different PMKID for every AP it associates with. TH APs also maintain a database of the PMKID issued to the client. In SKC also known as PKC (Pro Active Ke caching), the client stores each Pairwise Master Key (PMK) ID (PMKID) against a Pairwise Master Key Security Association (PMKSA). When a client finds an AP for which it has the PMKSA, it sends the PMKI in the association request to the AP. If the PMKSA is alive in the AP, the AP provides support for fast roamin In SKC, full authentication is done on each new AP to which the client associates and the client must keep the PMKSA associated with all APs. For SKC, PMKSA is a per AP cache that the client stores and PMKS is precalculated based on the BSSID of the new AP.	
		ot use SKC for large scale deployments as the controller supports SKC only up to eight APs.
		not work across controllers in a mobility group.
	SKC worl	cs only on WPA2-enabled WLANs.
	• SKC worl	cs only on local mode APs.
Examples	e	example shows how to enable Sticky PMKID Caching on WLAN 5:

config wlan security wpa wpa2 ciphers

To configure WPA2 ciphers and enable or disable Advanced Encryption Standard (AES) or Temporal Key Integrity Protocol (TKIP) data encryption for WPA2, use the **config wlan security wpa wpa2 ciphers** command

config wlan security wpa wpa2 ciphers {aes | tkip} {enable | disable} wlan_id

Syntax Description	(Cisco Controller) > aes	Configures AES data encryption for WPA2.
	tkip	Configures TKIP data encryption for WPA2.
	enable	Enables AES or TKIP data encryption for WPA2.
	disable	Disables AES or TKIP data encryption for WPA2.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default AES is enabled by default.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable AES data encryption for WPA2: (Cisco Controller) >config wlan security wpa wpa2 ciphers are enable 1

config wlan sip-cac disassoc-client

To enable client disassociation in case of session initiation protocol (SIP) call admission control (CAC) failure, use the **config wlan sip-cac disassoc-client** command.

config wlan sip-cac disassoc-client {enable | disable} wlan_id

Syntax Description	enable	Enables a client disassociation on a SIP CAC failure.
	disable	Disables a client disassociation on a SIP CAC failure.
	wlan_id	Wireless LAN identifier between 1 and 512.

Command Default Client disassociation for SIP CAC is disabled.

Command History	Release	Modification		
	7.6	This command was introduced in a release earlier than Release 7.6.		

Examples The following example shows how to enable a client disassociation on a SIP CAC failure where the WLAN ID is 1:

(Cisco Controller) >config wlan sip-cac disassoc-client enable 1

config wlan sip-cac send-486busy

To configure sending session initiation protocol (SIP) 486 busy message if a SIP call admission control (CAC) failure occurs, use the **config wlan sip-cac send-486busy** command:

config wlan sip-cac send-486busy {enable | disable} wlan_id

Syntax Description		Eachlas and line a SID 496 hum massage upon a SID CAC failure
	enable	Enables sending a SIP 486 busy message upon a SIP CAC failure.
	disable	Disables sending a SIP 486 busy message upon a SIP CAC failure.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default Command History		on protocol is enabled by default.
Gommanu mistory	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	the WLAN ID i	xample shows how to enable sending a SIP 486 busy message upon a SIP CAC failure where s 1: ller) >config wlan sip-cac send-busy486 enable 1

config wlan static-ip tunneling

To configure static IP client tunneling support on a WLAN, use the config wlan static-ip tunneling command.

config wlan static-ip tunneling {enable | disable} wlan_id

Syntax Description	tunneling	Configures static IP client tunneling support on a WLAN.
	enable	Enables static IP client tunneling support on a WLAN.
disable Dis		Disables static IP client tunneling support on a WLAN.
	wlan_id	Wireless LAN identifier from 1 to 512.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable static IP client tunneling support for WLAN ID 3:

(Cisco Controller) >config wlan static-ip tunneling enable 34

config wlan session-timeout

To change the timeout of wireless LAN clients, use the config wlan session-timeout command.

config wlan session-timeout {*wlan_id* | **foreignAp**} *seconds*

Syntax Description	wlan_id	Wirele	ess LAN identifier between 1 and 512.	
	foreignAp	Specifies third-party access points. Timeout or session duration in seconds. A value of zero is equivalent to no timeout.		
	seconds			
		Note	The range of session timeout depends on the security type:	
			• Open system: 0-65535 (sec)	
			• 802.1x: 300-86400 (sec)	
			• static wep: 0-65535 (sec)	
			• cranite: 0-65535 (sec)	
			• fortress: 0-65535 (sec)	
			• CKIP: 0-65535 (sec)	
			• open+web auth: 0-65535 (sec)	
			• web pass-thru: 0-65535 (sec)	
			• wpa-psk: 0-65535 (sec)	
			• disable: To disable reauth/session-timeout timers.	

Command Default	None
-----------------	------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples

The following example shows how to configure the client timeout to 6000 seconds for WLAN ID 1:

(Cisco Controller) >config wlan session-timeout 1 6000

config wlan user-idle-threshold

To configure the threshold data sent by the client during the idle timeout for client sessions for a WLAN, use the **config wlan user-idle-threshold** command.

config wlan user-idle-threshold bytes wlan_id

Syntax Description	bytes	Threshold data sent by the client during the idle timeout for the client session for a WLAN. If the client send traffic less than the defined threshold, the client is removed on timeout. The range is from 0 to 10000000 bytes.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default Command History	The default tim	eout for threshold data sent by client during the idle timeout is 0 bytes.
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following e	example shows how to configure the threshold data sent by the client during the idle timeout ns for a WLAN:

(Cisco Controller) >config wlan user-idle-threshold 100 1

config wlan usertimeout

To configure the timeout for idle client sessions for a WLAN, use the config wlan usertimeout command.

config wlan usertimeout timeout wlan_id

Syntax Description	timeout	Timeout for idle client sessions for a WLAN. If the client sends traffic less than the threshold, the client is removed on timeout. The range is from 15 to 100000 seconds.
	wlan_id	Wireless LAN identifier between 1 and 512.
Command Default	The default clie	nt session idle timeout is 300 seconds.
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Usage Guidelines	The timeout val config network	ue that you configure here overrides the global timeout that you define using the command susertimeout .
Examples	The following example shows how to configure the idle client sessions for a WLAN: (Cisco Controller) >config wlan usertimeout 100 1	

config wlan webauth-exclude

To release the guest user IP address when the web authentication policy time expires and exclude the guest user from acquiring an IP address for three minutes, use the **config wlan webauth-exclude** command.

config wlan webauth-exclude wlan_id {enable | disable}

Syntax Description	wlan_id	Wireless LAN identifier (1 to 512).	
	enable	Enables web authentication exclusion.	
	disable	Disables web authentication exclusion.	
Command Default	Disabled.		
Command History	Release	Modification	
	7.6	This command was introduced in a release earlier than Release 7.6.	
Usage Guidelines		s command for guest WLANs that are configured with web authentication.	
	By default, when the web authentication timer expires for a guest user, the guest user can immediately reassociate with the same IP address before another guest user can acquire the IP address. If there are many guest users or limited IP address in the DHCP pool, some guest users might not be able to acquire an IP address.		
	authentication po The IP address i	le this feature on the guest WLAN, the guest user's IP address is released when the web olicy time expires and the guest user is excluded from acquiring an IP address for three minutes. is available for another guest user to use. After three minutes, the excluded guest user can acquire an IP address, if available.	
Examples	The following e	xample shows how to enable the web authentication exclusion for WLAN ID 5:	
	(Cisco Contro	ller) >config wlan webauth-exclude 5 enable	

config wlan wmm

To configure Wi-Fi Multimedia (WMM) mode on a wireless LAN, use the config wlan wmm command.

config wlan wmm {allow | disable | require} wlan_id

Syntax Description	allow	Allows WMM on the wireless LAN.
	disable	Disables WMM on the wireless LAN.
	require	Specifies that clients use WMM on the specified wireless LAN.
	wlan_id	Wireless LAN identifier (1 to 512).

Command Default	None
-----------------	------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Usage Guidelines When the controller is in Layer 2 mode and WMM is enabled, you must put the access points on a trunk port in order to allow them to join the controller.

Examples The following example shows how to configure wireless LAN ID 1 to allow WMM:

(Cisco Controller) >config wlan wmm allow 1

The following example shows how to configure wireless LAN ID 1 to specify that clients use WMM:

(Cisco Controller) >config wlan wmm require 1

clear Commands

This section lists the clear commands to clear existing configurations, log files, and other functions for WLANs

clear ipv6 neighbor-binding

To clear the IPv6 neighbor binding table entries or counters, use the clear ipv6 neighbor-binding command.

clear ipv6 neighbor-binding {table {mac mac_address | vlan vlan_id | port port | ipv6 ipv6-address | all} | counters}

Syntax Description	table	Clears the IPv6 neighbor binding table.
	mac	Clears the neighbor binding table entries for a MAC address.
	mac_address	MAC address of the client.
	vlan	Clears the neighbor binding table entries for a VLAN.
	vlan_id	VLAN identifier.
	port	Clears the neighbor binding table entries for a port.
	port	Port number.
	ipv6	Clears the neighbor binding table entries for an IPv6 address.
	ipv6_address	IPv6 address of the client.
	all	Clears the entire neighbor binding table.
	counters	Clears IPv6 neighbor binding counters.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following exa	mple shows how to clear the IPv6 neighbor binding table entries for a VLAN:

(Cisco Controller) >clear ipv6 neighbor-binding table vlan 1

debug Commands

This section lists the debug commands to manage debugging of WLANs managed by the controller.



Debug commands are reserved for use only under the direction of Cisco personnel. Do not use these commands without direction from Cisco-certified staff.

debug 11w-pmf

To configure the debugging of 802.11w, use the debug 11w-pmf command.

debug 11w-pmf {all | events| keys} {enable | disable}

Syntax Description	all	Configures the debugging of all 802.11w messages.
	keys	Configures the debugging of 802.11w keys.
	events	Configures the debugging of 802.11w events.
	enable	Enables the debugging of 802.1w options.
	disable	Disables the debugging of 802.1w options.
Command Default	None	
Command Default Command History	None Release	Modification

Examples

The following example shows how to enable the debugging of 802.11w keys: (Cisco Controller) >debug 11w-pmf keys enable

debug call-control

To configure the debugging of the SIP call control settings, use the debug call-control command.

debug call-control {all | event} {enable | disable}

Syntax Description	all	Configures the debugging options for all SIP call control messages.
	event	Configures the debugging options for SIP call control events.
	enable	Enables the debugging of SIP call control messages or events.
	disable	Disables the debugging of SIP call control messages or events.

Command Default Disabled.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

 Examples
 The following example shows how to enable the debugging of all SIP call control messages:

 (Cisco Controller) >debug call-control all enable

debug ccxdiag

To configure debugging of Cisco Compatible Extensions (CCX) diagnostic options, use the **debug ccxdiag** command.

debug ccxdiag {all | error | event | packet} {enable | disable}

Syntax Description	all	Configures debugging of all the CCX S69 messages.	
	error	Configures debugging of the CCX S69 errors.	
	event	Configures debugging of the CCX S69 events.	
	packet	Configures debugging of the CCX S69 packets.	
	enable	Enables debugging of the CCX S69 options.	_
	disable	Disables debugging of the CCX S69 options.	
Command Default	None		

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable CCX S69 packets debugging: (Cisco Controller) >debug ccxdiag packets enable

debug ccxrm

To configure debugging of the CCX Cisco Client eXtension (CCX) Radio Management (RM), use the **debug ccxrm** command.

debug ccxrm {all | detail | error | location-calibration | message | packet | warning} {enable | disable}

Syntax Description	all	Configures debugging of all CCX RM messages.
	detail	Configures detailed debugging of CCX RM.
	error	Configures debugging of the CCX RM errors.
	location-calibration	Configures debugging of the CCX RM location calibration.
	message	Configures debugging of CCX RM messages.
	packet	Configures debugging of the CCX RM packets.
	warning	Configures debugging of the CCX RM warnings.
	enable	Enables debugging of the CCX RM options.
	disable	Disables debugging of the CCX RM options.
ommand Default	None	
ommand History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable CCX RM debugging: (Cisco Controller) >

debug ccxs69

To configure debugging of CCX S69 tasks, use the debug ccxs69 command.

debug ccxs69 {all | error | event} {enable | disable}

Syntax Description		
	all	Configures debugging of all the CCX S69 messages.
	error	Configures debugging of the CCX S69 errors.
	event	Configures debugging of the CCX S69 events.
	enable	Enables debugging of the CCX S69 options.
	disable	Disables debugging of the CCX S69 options.
Command Default	None	
Command History	Release	Modification
Command History	Release 7.6	ModificationThis command was introduced in a release earlier than Release 7.6.
Command History		

(Cisco Controller) >debug ccxs69 all enable

debug client

To configure the debugging of a passive client that is associated correctly with the access point, use the **debug client** command.

debug client *mac_address*

Syntax Description	mac_address MAC address of the client.
Command Default	None
Examples	The following example shows how to debug a passive client with MAC address 00:0d:28:f4:c0:45:
	(Cisco Controller) >debug client 00:0d:28:f4:c0:45

debug dhcp

To configure the debugging of DHCP, use the **debug dhcp** command.

debug dhcp {message | packet} {enable | disable}

Syntax Description	message	Configures the debugging of DHCP error messages.
	packet	Configures the debugging of DHCP packets.
	enable	Enables the debugging DHCP messages or packets.
	disable	Disables the debugging of DHCP messages or packets.

Command Default None

Examples The following example shows how to enable the debugging of DHCP messages: (Cisco Controller) >debug dhcp message enable

debug dhcp service-port

To enable or disable debugging of the Dynamic Host Configuration Protocol (DHCP) packets on the service port, use the **debug dhcp service-port** command.

debug dhcp service-port {enable | disable}

Syntax Description	enable	Enables the debugging of DHCP packets on the service port.
	disable	Disables the debugging of DHCP packets on the service port.
Command Default	None	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	The following	example shows how to enable the debugging of DHCP packets on a service port:

The following example shows how to enable the debugging of DHCP packets on a service port: (Cisco Controller) >debug dhcp service-port enable

debug ft

To configure debugging of 802.11r, use the **debug ft** command.

debug ft {events | keys} {enable | disable}

Syntax Description	events	Configures debugging of the 802.11r events.
	keys	Configures debugging of the 802.11r keys.
	enable	Enables debugging of the 802.11r options.
	disable	Disables debugging of the 802.11r options.

Command Default None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable 802.11r debugging: (Cisco Controller) >debug ft events enable

debug hotspot

To configure debugging of HotSpot events or packets, use the debug hotspot command.

debug hotspot {events | packets} {enable | disable} {enable | disable}

Syntax Description events		Configures debugging of HotSpot events.	
	packets	Configures debugging of HotSpot packets.	
	enable	Enables the debugging of HotSpot options.	
	disable	Disables the debugging of HotSpot options.	

Command Default	None
-----------------	------

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

ExamplesThe following example shows how to enable debugging of HotSpot events:
(Cisco Controller) >debug hotspot events enable

debug ipv6

To configure debugging of IPv6 options, use the **debug ipv6** command.

debug ipv6 {all | bt | classifier | errors | events | filter | fsm | gleaner | hwapi | memory | ndsuppress | parser | policy | ra_throttler | switcher } {enable | disable }

Syntax Description	all	Configures debugging of all the IPv6 information.
	bt	Configures debugging of the IPv6 neighbor binding table.
	classifier	Configures debugging of the IPv6 packet classifiers.
	errors	Configures debugging of the IPv6 errors.
	events	Configures debugging of the IPv6 events.
	filter	Configures filters for the IPv6 debugs.
	fsm	Configures debugging of the IPv6 finite state machine (FSM).
	gleaner	Configures debugging of the IPv6 gleaner. Learning of entries is called gleaning.
	hwapi	Configures debugging of the IPv6 hardware APIs.
	memory	Configures debugging of the IPv6 binding table memory usage.
	ndsuppress	Configures debugging of the suppressed IPv6 neighbor discoveries.
	parser	Configures debugging of the IPv6 parser.
	policy	Configures debugging of the IPv6 policies.
	ra_throttler	Configures debugging of the IPv6 router advertising throttler.
	switcher	Configures debugging of the IPv6 switcher.
	enable	Enables debugging of the IPv6 options.
	disable	Disables debugging of the IPv6 options.

Command Default

None

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	-	example shows how to configure the debugging of IPv6 policies:

debug profiling

To configure the debugging of client profiling, use the **debug profiling** command.

debug profiling {enable | disable}

Syntax Description	enable	Enables the debugging of client profiling (HTTP and DHCP profiling).
	disable	Disables the debugging of client profiling (HTTP and DHCP profiling).
Command Default	Disabled.	
Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.
Examples	e	xample shows how to enable the debugging of client profiling:

debug wcp

Command Default

None

To configure the debugging of WLAN Control Protocol (WCP), use the debug wcp command.

debug wcp {events | packet} {enable | disable}

Syntax Description	events	Configures the debugging of WCP events.
	packet	Configures the debugging of WCP packets.
	enable	Enables the debugging of WCP settings.
	disable	Disables the debugging of WCP settings.

Command History	Release	Modification
	7.6	This command was introduced in a release earlier than Release 7.6.

Examples The following example shows how to enable the debugging of WCP settings: (Cisco Controller) >debug wcp packet enable

test Commands

This section lists the test commands for WLANs.

test pmk-cache delete

To delete an entry in the Pairwise Master Key (PMK) cache from all Cisco wireless LAN controllers in the mobility group, use the **test pmk-cache delete** command.

test pmk-cache delete {all | mac_address}

ddress MAC address of the Cisco wireless LAN entries have to be deleted.	
	controller from which PMK cache
e Modification	
This command was introduced in a release earl	lier than Release 7.6.
eas	ease Modification