

Model 8650-EO Remote Control Unit



20078

FEATURES

- Remote operates all functions of the Model 8600 Home Terminal, including volume control, complete channel control, IPPV buying, sleep timer, and all on-screen menu functions
- Ergonomic design uses multi-color, shaped keys to speed operation
- Raised arrow on channel up/down and volume up/down keys speed operation of the most frequently used keys
- Raised single dot on "5" key identifies center of numeric keypad
- Raised double dot on "POWER" key positively identifies on/off function
- Three on-screen menu keys simplify remote by serving multiple functions, depending on which menu the subscriber selects
- Subscriber quickly can remember what channel they are watching and the current time with one press of the "DISPLAY" key

Model 8650-E0 Remote Control Unit

KEY FEATURES

Buy — Initiates an IPPV purchase

Sleep — Sets sleep timer function on home terminal

Power — Turns home terminal on/off

0 through 9 — Allows direct entry of channel number

Menu — Enters/exits on-screen menu system

➡ — Moves on-screen arrow to point to next option in menu

Mute — Mutes the home terminal volume

Vol ▲ and Vol ▼ — Increments and decrements the home terminal volume level

Favorite — Tunes the next channel in the subscriber's favorite channel list

Last — Tunes the last channel that the home terminal was previously tuned to. Repeated pressing of the LAST key toggles the home terminal between two channels

CH ▲ and CH ▼ — Increment and decrement to the next valid channel

Display — Displays the channel name and number, the current time, and the sleep timer (if set), via the on-screen display

Select — Chooses the menu option that the arrow is pointing to



20078



Scientific-Atlanta, Inc.

<http://www.sciatl.com>

United States: 4261 Communications Drive, Norcross, GA 30093; Tel: 800-433-6222; Fax: 770-903-4617

Canada: 7725 Lougheed Highway, Burnaby, BC V5A 4V8; Tel: 604-420-5322; Fax: 604-420-5941

United Kingdom: Home Park Estate, Kings Langley, Herts WD4 8LZ, England; Tel: 44-923-266-133; Fax: 44-192-327-0448

Singapore: 1 Claymore Drive, #08-11 Orchard Towers, Singapore 229594; Tel: 65-733-4314; Fax: 65-733-2706

Hong Kong: Suite 56 & 57, 5/F New Henry House, 10 Ice House Street, Central, Hong Kong; Tel: 852-2522-5059; Fax: 852-2522-5624

88D183Z

© 1996 Scientific-Atlanta, Inc. All rights reserved.

Printed in USA.

0996M