




INDEX

Symbols

<cr> [xv](#)

? command [xiv](#)

A

adapter command [B2R-206](#)

algorithms, security encryption [B2R-339](#)

allocate lu command [B2R-316](#)

C

carriage return (<cr>) [xv](#)

cautions, usage in text [x](#)

certificate reload command [B2R-318](#)

certificates, security

 reloading [B2R-318](#)

 specifying location of [B2R-384](#)

channel-protocol command [B2R-208](#)

CIP (Channel Interface Processor) data rate, PCA
 configuration [B2R-208](#)

Cisco IOS configuration changes, saving [xviii](#)

claw (backup) command [B2R-269](#)

CLAW (Common Link Access for Workstations)

 backup group, displaying [B2R-282](#)

 IP datagram configuration [B2R-266, B2R-269, B2R-272](#)

 IP host backup group configuration [B2R-266](#)

 packing connections, displaying [B2R-283](#)

 packing names, displaying [B2R-283](#)

 packing statistics, displaying [B2R-285](#)

claw command [B2R-266](#)

clear dbconn connection command [B2R-154](#)

clear dbconn statistic command [B2R-155](#)

clear extended counters command [B2R-209](#)

clear txconn connection command [B2R-156](#)

clear txconn statistic command [B2R-157](#)

clear txconn transaction command [B2R-155](#)

client, nailing to pool [B2R-327](#)

client ip command [B2R-319](#)

client ip lu command [B2R-321](#)

client ip pool command [B2R-323, B2R-327](#)

client lu maximum command [B2R-325](#)

client pool command [B2R-327](#)

CMCC (Cisco Mainframe Channel Connection) adapter

 channel interface

 hardware, displaying [B2R-259](#)

 physical, monitoring [B2R-264](#)

 shutting down [B2R-263](#)

 specification [B2R-213](#)

 statistics, displaying [B2R-245](#)

channel statistics, displaying [B2R-240](#)

CLAW configuration [B2R-266, B2R-269, B2R-272](#)

CMPC

 configuration [B2R-288](#)

 subchannel, displaying [B2R-294](#)

 transmission group, displaying [B2R-303, B2R-310](#)

CMPC+

 configuration [B2R-288, B2R-312](#)

 subchannel, displaying [B2R-294](#)

 transmission group, displaying [B2R-303, B2R-310](#)

core dump, enabling [B2R-211](#)

CSNA

 configuration [B2R-290](#)

 subchannel, displaying [B2R-296](#)

- data rate parallel channel interface
 - configuration [B2R-208](#)
- DLUR (dependent logical unit requester)
 - configuration [B2R-333](#)
- DLUS backup configuration [B2R-335](#)
- ICMP stack, displaying [B2R-221](#)
- internal adapter
 - configuration [B2R-206](#)
- internal adapters
 - naming [B2R-218](#)
 - VRN configuration [B2R-439](#)
- internal LANs
 - configuration [B2R-215](#)
 - displaying [B2R-227](#)
- IP host backup
 - offload device configuration [B2R-277](#)
 - path configuration [B2R-280](#)
- IP stack, displaying [B2R-223](#)
- LLC2 sessions
 - displaying [B2R-229](#)
 - maximum, displaying [B2R-238](#)
 - maximum specification [B2R-217](#)
 - SAP, displaying [B2R-220](#)
- microcode version, displaying [B2R-219](#)
- NN server, TN3270 server configuration [B2R-368](#)
- SAP, LLC2 sessions, displaying [B2R-220](#)
- sessions, TN3270 server configuration [B2R-363](#)
- TCP/IP offload configuration [B2R-275](#)
- TCP connections, displaying [B2R-250](#)
- TCP stack, displaying [B2R-253](#)
- TN3270 server configuration [B2R-315 to B2R-440](#)
- UDP listener sockets, displaying [B2R-256](#)
- UDP stack, displaying [B2R-257](#)
- CMPC (Cisco Multipath Channel)
 - subchannel
 - configuration [B2R-288](#)
 - displaying [B2R-294](#)
 - transmission group, displaying [B2R-303, B2R-310](#)
- CMPC+ (Cisco Multipath Channel+)

- subchannel
 - configuration [B2R-288](#)
 - displaying [B2R-294](#)
- TG connection manager, displaying [B2R-292](#)
- transmission group
 - configuration [B2R-312](#)
 - displaying [B2R-303, B2R-310](#)
- cmpe command [B2R-288](#)
- command modes, understanding [xiii to xiv](#)
- commands
 - context-sensitive help for abbreviating [xiv](#)
 - default form, using [xvii](#)
 - no form, using [xvii](#)
- command syntax
 - conventions [ix](#)
 - displaying (example) [xv](#)
- configurations, saving [xviii](#)
- CPA (Channel Port Adapter) data rate, PCPA
 - configuration [B2R-208](#)
- creating security profile [B2R-369](#)
- CSNA (Cisco SNA) subchannel
 - configuration [B2R-290](#)
 - displaying [B2R-296](#)
- csna command [B2R-290](#)

D

- dbconn license command [B2R-160](#)
- dbconn pem command [B2R-162](#)
- dbconn ping command [B2R-163](#)
- dbconn server command [B2R-164](#)
- dbconn tcpserver command [B2R-167](#)
- debug dbconn command [B2R-170](#)
- default profile, specifying [B2R-330](#)
- default-profile command [B2R-330](#)
- digital certificates, reloading [B2R-318](#)
- disable (TN3270) command [B2R-332](#)
- disabling security, TN3270 server [B2R-332](#)
- DLUR (dependent logical unit requester) TN3270 server

- displaying [B2R-395, B2R-398](#)
- dlur command [B2R-333](#)
- DLUS backup, TN3270 server configuration [B2R-335](#)
- dlus-backup command [B2R-335](#)
- documentation
 - conventions [ix](#)
 - feedback, providing [xi](#)
 - modules [v to vii](#)
 - online, accessing [x](#)
 - ordering [xi](#)
- Documentation CD-ROM [x](#)
- documents and resources, supporting [viii](#)
- domain ID, specifying [B2R-336](#)
- domain-id command [B2R-336](#)
- DSPU (downstream physical unit)
 - activation request units, defining [B2R-4](#)
 - default PU, defining [B2R-5](#)
- Ethernet
 - host, defining [B2R-19](#)
 - LSAP address, enabling [B2R-10](#)
 - PU, defining [B2R-34](#)
 - upstream host [B2R-7](#)
- FDDI
 - host, defining [B2R-19](#)
 - LSAP address, enabling [B2R-10](#)
 - PU, defining [B2R-34](#)
 - upstream host [B2R-7](#)
- Frame Relay
 - host, defining [B2R-13](#)
 - LSAP address, enabling [B2R-10](#)
 - PU, defining [B2R-28](#)
 - upstream host [B2R-7](#)
- LAN, naming [B2R-53](#)
- LU pool, defining [B2R-26](#)
- LUs
 - defining [B2R-21](#)
 - inactivity timeout specification [B2R-26](#)
- monitoring [B2R-54](#)
- NCIA server
 - configuration [B2R-23](#)
 - PU, defining [B2R-34](#)
 - SAP, enabling [B2R-24](#)
- notification level specification [B2R-25](#)
- PU
 - Ethernet, defining [B2R-34](#)
 - FDDI, defining [B2R-34](#)
 - NCIA server, defining [B2R-34](#)
 - RSRB, defining [B2R-34](#)
 - Token Ring, defining [B2R-34](#)
 - VDLC, defining [B2R-34](#)
- QLLC
 - host, defining [B2R-15](#)
 - PU, defining [B2R-30](#)
 - upstream host [B2R-8](#)
 - X.121 subaddress, enabling [B2R-11](#)
- RSRB
 - defining [B2R-37](#)
 - host, defining [B2R-19](#)
 - PU, defining [B2R-34](#)
 - SAP, enabling [B2R-39, B2R-40](#)
 - starting [B2R-41](#)
- SAP, VDLC, enabling [B2R-47, B2R-49](#)
- SDLC
 - address, enabling [B2R-12](#)
 - host, defining [B2R-17](#)
 - PU, defining [B2R-32](#)
 - upstream host [B2R-9](#)
- starting [B2R-43](#)
- Token Ring
 - host, defining [B2R-19](#)
 - LSAP address, enabling [B2R-10](#)
 - PU, defining [B2R-34](#)
 - upstream host [B2R-7](#)
- VDLC
 - defining [B2R-45](#)
 - host, defining [B2R-19](#)
 - PU, defining [B2R-34](#)
 - SAP, enabling [B2R-47](#)

starting [B2R-51](#)

dspu activation-window command [B2R-4](#)

dspu default-pu command [B2R-5](#)

dspu enable-host (QLLC) command [B2R-8](#)

dspu enable-host (SDLC) command [B2R-9](#)

dspu enable-host (Token Ring, Ethernet, FDDI, Frame Relay) command [B2R-7](#)

dspu enable-pu (Ethernet, Frame Relay, Token Ring, FDDI) command [B2R-10](#)

dspu enable-pu (QLLC) command [B2R-11](#)

dspu enable-pu (SDLC) command [B2R-12](#)

dspu host (Frame Relay) command [B2R-13](#)

dspu host (QLLC) command [B2R-15](#)

dspu host (SDLC) command [B2R-17](#)

dspu host (Token Ring, Ethernet, FDDI, RSRB, VDLC) command [B2R-19](#)

dspu lu command [B2R-21](#)

dspu ncia command [B2R-23](#)

dspu ncia enable-pu command [B2R-24](#)

dspu notification-level command [B2R-25](#)

dspu pool command [B2R-26](#)

dspu pu (Frame Relay) command [B2R-28](#)

dspu pu (QLLC) command [B2R-30](#)

dspu pu (SDLC) command [B2R-32](#)

dspu pu (Token Ring, Ethernet, FDDI, RSRB, VDLC, NCIA) command [B2R-34](#)

dspu rsrb command [B2R-37](#)

dspu rsrb enable-host command [B2R-39](#)

dspu rsrb enable-pu command [B2R-40](#)

dspu rsrb start command [B2R-41](#)

dspu start command [B2R-43](#)

dspu vdlc command [B2R-45](#)

dspu vdlc enable-host command [B2R-47](#)

dspu vdlc enable-pu command [B2R-49](#)

dspu vdlc start command [B2R-51](#)

E

enable (TN3270) command [B2R-338](#)

enabling security, TN3270 server [B2R-338](#), [B2R-383](#)

encryption

security algorithm [B2R-339](#)

session key [B2R-351](#)

encryptorder command [B2R-339](#)

Ethernet, SNA service point

defining [B2R-66](#)

enabling [B2R-59](#)

exception slot command [B2R-211](#)

F

FDDI (Fiber Distributed Data Interface), SNA service point

defining [B2R-66](#)

enabling [B2R-59](#)

Feature Navigator

See platforms supported

filtering output, show and more commands [xviii](#)

Frame Relay, SNA service point

defining [B2R-60](#)

enabling [B2R-59](#)

G

generic-pool command [B2R-340](#)

global configuration mode, summary of [xiv](#)

H

hardware platforms

See platforms supported

help command [xiv](#)

I

ICMP stack, CMCC adapter [B2R-221](#)

idle-time command [B2R-342](#)

indexes, master [viii](#)

interface channel command [B2R-213](#)

interface configuration mode, summary of [xiv](#)
 internal adapters
 CMCC adapter, naming [B2R-218](#)
 VRN configuration [B2R-439](#)
 internal LANs, CMCC adapter
 configuration [B2R-215](#)
 displaying [B2R-227](#)
 IP addresses
 CMCC adapter offload device [B2R-275](#)
 TN3270 server
 configuration [B2R-354](#)
 displaying [B2R-401](#)
 IP datagram, CMCC adapter configuration [B2R-266](#),
 [B2R-269](#), [B2R-272](#)
 IP host backup
 CLAW configuration [B2R-266](#)
 CMCC adapter path configuration [B2R-280](#)
 TCP/IP offload configuration [B2R-277](#)
 IP precedence, TN3270 server configuration [B2R-344](#)
 ip precedence command [B2R-344](#)
 IP stack, CMCC adapter, displaying [B2R-223](#)
 IP ToS, TN3270 server configuration [B2R-346](#)
 ip tos command [B2R-346](#)

K

keepalive (TN3270) command [B2R-348](#)
 keylen command [B2R-351](#)

L

lan command [B2R-215](#)
 lan-name command [B2R-53](#)
 link (TN3270) command [B2R-352](#)
 listen point, associating a security profile with [B2R-381](#)
 listen-point command [B2R-354](#)
 LLC2 sessions, CMCC adapter [B2R-229](#), [B2R-238](#)
 lsap command [B2R-357](#)
 lu deletion command [B2R-359](#)

LU nailing, TN3270 server
 configuration [B2R-321](#)
 displaying [B2R-401](#)
 pool [B2R-323](#), [B2R-327](#)
 LU pools
 assigning LUs [B2R-316](#)
 DSPU, defining [B2R-26](#)
 TN3270 server
 configuration [B2R-365](#)
 displaying [B2R-404](#), [B2R-430](#)
 nailing [B2R-323](#), [B2R-327](#)

LUs (logical units)

DSPU
 activation failure notification [B2R-25](#)
 dedicating to host [B2R-21](#)
 defining [B2R-21](#)
 inactivity timeout specification [B2R-26](#)
 pool assignment [B2R-21](#)
 state change notification [B2R-25](#)
 TN3270 server
 assigning [B2R-316](#)
 displaying [B2R-404](#), [B2R-411](#), [B2R-430](#)

lu termination command [B2R-361](#)

M

maximum bit length, session encryption key [B2R-351](#)
 maximum-lus command [B2R-363](#)
 max-llc2-sessions command [B2R-217](#)
 MIB, descriptions online [viii](#)
 modes
 See command modes

N

nailing client to pool [B2R-327](#)
 name command [B2R-218](#)
 NN server, TN3270 server configuration [B2R-368](#)

notes, usage in text [x](#)

O

offload (backup) command [B2R-277](#)

offload alias command [B2R-275](#)

offload command [B2R-272](#)

P

path command [B2R-280](#)

physical channel interface monitoring [B2R-264](#)

ping sna command [B2R-78](#)

platforms supported

Feature Navigator, identify using [xix](#)

release notes, identify using [xix](#)

pool command [B2R-365](#)

preferred-nnserver command [B2R-368](#)

privileged EXEC mode, summary of [xiv](#)

profile command [B2R-369](#)

profiles

default, specifying [B2R-330](#)

security

associating with listen point [B2R-381](#)

creating [B2R-369](#)

modifying [B2R-369](#)

prompts, system [xiv](#)

pu (DLUR) command [B2R-371](#)

pu (listen-point) command [B2R-372](#)

pu (TN3270) command [B2R-374](#)

pu dlur (listen-point) command [B2R-376](#)

PUs (physical units)

DSPU

activation failure notification [B2R-25](#)

Ethernet, defining [B2R-34](#)

FDDI, defining [B2R-34](#)

Frame Relay, defining [B2R-28](#)

NCIA server, defining [B2R-34](#)

QLLC, defining [B2R-30](#)

RSRB, defining [B2R-34](#)

SDLC, defining [B2R-32](#)

state change notification [B2R-25](#)

Token Ring, defining [B2R-34](#)

VDLC, defining [B2R-34](#)

TN3270 server

configuration [B2R-372](#), [B2R-374](#)

displaying [B2R-385](#), [B2R-404](#), [B2R-430](#)

DLUR, configuring [B2R-376](#)

Q

QLLC (Qualified Logical Link Control), SNA service point

defining [B2R-62](#)

enabling [B2R-57](#)

question mark (?) command [xiv](#)

R

release notes

See platforms supported

reloading, digital certificates [B2R-318](#)

REPLY-PSID poweroff request, TN3270 server configuration [B2R-359](#)

response-time group, TN3270 server

client subnet configuration [B2R-319](#)

displaying [B2R-415](#), [B2R-418](#), [B2R-420](#)

response-time group command [B2R-379](#)

RFC

full text, obtaining [viii](#)

ROM monitor mode, summary of [xiv](#)

RSRB (remote source-route bridging)

DSPU

defining [B2R-37](#)

starting [B2R-41](#)

SNA service point

defining [B2R-66](#)

SAP, enabling [B2R-69](#)

starting [B2R-70](#)

S

SAP (Service Access Point)

DSPU

NCIA server, enabling [B2R-24](#)

RSRB, enabling [B2R-39](#), [B2R-40](#)

VDLC, enabling [B2R-49](#)

SNA service point, RSRB, enabling [B2R-69](#)

TN3270 server configuration [B2R-357](#)

SDLC (Synchronous Data Link Control), SNA service point

defining [B2R-64](#)

enabling [B2R-58](#)

sec-profile command [B2R-381](#)

security (TN3270) command [B2R-383](#)

security, TN3270 server

disabling [B2R-332](#)

enabling [B2R-338](#), [B2R-383](#)

modifying [B2R-383](#)

security certificates, specifying location of [B2R-384](#)

security encryption algorithm, specifying [B2R-339](#)

security profile

associating with listen point [B2R-381](#)

creating [B2R-369](#)

modifying [B2R-369](#)

servercert command [B2R-384](#)

session encryption key, maximum bit length [B2R-351](#)

show controllers channel command [B2R-219](#)

show dbconn connection command [B2R-170](#)

show dbconn license command [B2R-173](#)

show dbconn ports command [B2R-174](#)

show dbconn server command [B2R-175](#)

show dbconn statistic command [B2R-178](#)

show dbconn wlm command [B2R-181](#)

show dspu command [B2R-54](#)

show extended channel backup command [B2R-282](#)

show extended channel cmgr command [B2R-292](#)

show extended channel cmpc command [B2R-294](#)

show extended channel connection-map llc2
command [B2R-220](#)

show extended channel csna command [B2R-296](#)

show extended channel icmp-stack command [B2R-221](#)

show extended channel ip-stack command [B2R-223](#)

show extended channel lan command [B2R-227](#)

show extended channel llc2 command [B2R-229](#)

show extended channel max-llc2-sessions
command [B2R-238](#)

show extended channel packing names
command [B2R-283](#)

show extended channel packing stats command [B2R-285](#)

show extended channel statistics command [B2R-240](#)

show extended channel subchannel command [B2R-245](#)

show extended channel tcp-connections
command [B2R-250](#)

show extended channel tcp-stack command [B2R-253](#)

show extended channel tg command [B2R-303](#), [B2R-310](#)

show extended channel tn3270-server client-ip-address
command [B2R-389](#)

show extended channel tn3270-server client-name
command [B2R-392](#)

show extended channel tn3270-server command [B2R-385](#)

show extended channel tn3270-server dlur
command [B2R-395](#)

show extended channel tn3270-server dlurlink
command [B2R-398](#)

show extended channel tn3270-server nailed-domain
command [B2R-400](#)

show extended channel tn3270-server nailed-ip
command [B2R-401](#)

show extended channel tn3270-server nailed-name
command [B2R-403](#)

show extended channel tn3270-server pu
command [B2R-404](#), [B2R-430](#)

show extended channel tn3270-server pu lu
command [B2R-411](#)

show extended channel tn3270-server response-time
application command [B2R-415](#)

show extended channel tn3270-server response-time
global command [B2R-418](#)

show extended channel tn3270-server response-time link
 command [B2R-420](#)
 show extended channel tn3270-server security
 command [B2R-430](#)
 show extended channel udp-listeners command [B2R-256](#)
 show extended channel udp-stack command [B2R-257](#)
 show extended max-llc2-sessions command [B2R-238](#)
 show interfaces channel command [B2R-259](#)
 show sna command [B2R-56](#)
 show snasw class-of-service command [B2R-80](#)
 show snasw connection-network command [B2R-81](#)
 show snasw directory command [B2R-82](#)
 show snasw dlctrace command [B2R-84](#)
 show snasw dlus command [B2R-86](#)
 show snasw ipstrace command [B2R-88](#)
 show snasw link command [B2R-89](#)
 show snasw lu command [B2R-91](#)
 show snasw mode command [B2R-93](#)
 show snasw node command [B2R-94](#)
 show snasw pdlog command [B2R-96](#)
 show snasw port command [B2R-97](#)
 show snasw pu command [B2R-99](#)
 show snasw rtp command [B2R-101](#)
 show snasw session command [B2R-103](#)
 show snasw statistics command [B2R-105](#)
 show snasw summary-ipstrace command [B2R-107](#)
 show snasw topology command [B2R-109](#)
 show txconn connection command [B2R-182](#)
 show txconn destination command [B2R-184](#)
 show txconn license command [B2R-185](#)
 show txconn route command [B2R-186](#)
 show txconn server command [B2R-187](#)
 show txconn statistic command [B2R-189](#)
 show txconn transaction command [B2R-193](#)
 shutdown (CMCC) command [B2R-263](#)
 shutdown (TN3270) command [B2R-432](#)
 SNA (Systems Network Architecture)
 DSPU notification specification [B2R-25](#)
 RSRB configuration [B2R-68](#)

session switching
 TN3270 server, displaying [B2R-395, B2R-398](#)
 TN3270 server configuration [B2R-333, B2R-357, B2R-439](#)
 sna enable-host (QLLC) command [B2R-57](#)
 sna enable-host (SDLC) command [B2R-58](#)
 sna enable-host (Token Ring, Ethernet, Frame Relay, FDDI) command [B2R-59](#)
 sna host (Frame Relay) command [B2R-60](#)
 sna host (QLLC) command [B2R-62](#)
 sna host (SDLC) command [B2R-64](#)
 sna host (Token Ring, Ethernet, FDDI, RSRB, VDLC) command [B2R-66](#)
 sna rsrp command [B2R-68](#)
 sna rsrp enable-host command [B2R-69](#)
 sna rsrp start command [B2R-70](#)
 SNA service point
 Ethernet
 defining [B2R-66](#)
 enabling [B2R-59](#)
 FDDI
 defining [B2R-66](#)
 enabling [B2R-59](#)
 Frame Relay
 defining [B2R-60](#)
 enabling [B2R-59](#)
 monitoring [B2R-56](#)
 QLLC
 defining [B2R-62](#)
 enabling [B2R-57](#)
 RSRB
 defining [B2R-66](#)
 SAP, enabling [B2R-69](#)
 starting [B2R-70](#)
 SDLC
 defining [B2R-64](#)
 enabling [B2R-58](#)
 starting [B2R-71](#)
 Token Ring
 defining [B2R-66](#)

- enabling [B2R-59](#)
- VDLC
 - defining [B2R-66](#), [B2R-72](#)
 - SAP, enabling [B2R-74](#)
 - starting [B2R-75](#)
- sna start command [B2R-71](#)
- snasw cpname command [B2R-111](#)
- snasw dlcfiler command [B2R-113](#)
- snasw dlctrace command [B2R-115](#)
- snasw dlus command [B2R-117](#)
- snasw dump command [B2R-119](#)
- snasw event command [B2R-121](#)
- snasw ip-precedence command [B2R-122](#)
- snasw ipsfilter command [B2R-123](#)
- snasw ipstrace command [B2R-125](#)
- snasw link command [B2R-127](#)
- snasw location command [B2R-130](#)
- snasw mode command [B2R-132](#)
- snasw msgdump command [B2R-133](#)
- snasw pathswitch command [B2R-134](#)
- snasw pdlog command [B2R-135](#)
- snasw port command [B2R-137](#)
- snasw rtp pathswitch-timers command [B2R-142](#)
- snasw start command [B2R-143](#)
- snasw start cp-cp command [B2R-144](#)
- snasw start link command [B2R-145](#)
- snasw start port command [B2R-146](#)
- snasw stop command [B2R-147](#)
- snasw stop cp-cp command [B2R-148](#)
- snasw stop link command [B2R-149](#)
- snasw stop port command [B2R-150](#)
- snasw stop session command [B2R-151](#)
- sna vdlc command [B2R-72](#)
- sna vdlc enable-host command [B2R-74](#)
- sna vdlc start command [B2R-75](#)
- SNMP (Simple Network Management Protocol), DSPU
 - notification specification [B2R-25](#)
- state-tracks-signal command [B2R-264](#)

T

- Tab key, command completion [xiv](#)
- TCP/IP offload
 - backup group, displaying [B2R-282](#)
 - IP address configuration [B2R-275](#)
- TCP connections, [B2R-250](#)
- TCP port, TN3270 server configuration [B2R-434](#)
- tcp-port command [B2R-434](#)
- TCP stack, CMCC adapter, displaying [B2R-253](#)
- Telnet nops, TN3270 server configuration [B2R-348](#)
- TERMSELF request, TN3270 server
 - configuration [B2R-361](#)
- tg (CMPC) command [B2R-310](#)
- tg (CMPC+) command [B2R-312](#)
- TG connection manager, CMPC+, displaying [B2R-292](#)
- timing-mark command [B2R-435](#)
- timing marks, TN3270 server configuration [B2R-348](#), [B2R-435](#)
- TN3270 server
 - clients, displaying [B2R-389](#), [B2R-392](#)
 - configuration, displaying [B2R-385](#)
 - configuration mode, entering [B2R-437](#)
- DLUR
 - configuration [B2R-333](#)
 - displaying [B2R-395](#), [B2R-398](#)
- DLUS backup configuration [B2R-335](#)
- domain ID [B2R-336](#)
- generic pool LU configuration [B2R-340](#)
- host link configuration [B2R-352](#)
- idle time configuration [B2R-342](#)
- IP addresses
 - configuration [B2R-354](#)
 - displaying [B2R-401](#)
- IP precedence configuration [B2R-344](#)
- IP TOS configuration [B2R-346](#)
- listen points configuration [B2R-354](#)
- LU deletion [B2R-359](#)
- LU nailing

- configuration [B2R-321](#)
- displaying [B2R-401](#)
- pool, configuring [B2R-327](#)
- pool configuration [B2R-323](#)
- LU pool
 - assigning LUs [B2R-316](#)
 - client, nailing [B2R-323](#), [B2R-327](#)
 - configuration [B2R-365](#)
 - displaying [B2R-404](#), [B2R-430](#)
- LUs, displaying [B2R-404](#), [B2R-411](#), [B2R-430](#)
- LU sessions, limiting, per client [B2R-325](#)
- LU termination [B2R-361](#)
- nailed name, displaying [B2R-403](#)
- nailing statements, displaying [B2R-400](#)
- PU
 - direct configuration [B2R-372](#), [B2R-374](#)
 - displaying [B2R-385](#), [B2R-404](#), [B2R-430](#)
 - DLUR, configuring [B2R-376](#)
- response-time group
 - client subnet configuration [B2R-319](#)
 - configuration [B2R-379](#)
 - displaying [B2R-415](#), [B2R-418](#), [B2R-420](#)
- SAP configuration [B2R-357](#)
- security
 - certificates, location of [B2R-384](#)
 - disabling [B2R-332](#), [B2R-383](#)
 - enabling [B2R-338](#), [B2R-383](#)
- session disconnection idle time configuration [B2R-342](#)
- session encryption key [B2R-351](#)
- session maximum configuration [B2R-363](#)
- session termination [B2R-359](#), [B2R-361](#)
- shutting down [B2R-432](#)
- SNA session switch
 - configuration [B2R-439](#)
 - displaying [B2R-395](#), [B2R-398](#)
- SNA session switch configuration [B2R-333](#)
- starting [B2R-437](#)
- TCP port configuration [B2R-434](#)
- Telnet nops configuration [B2R-348](#)

- timing marks configuration [B2R-348](#), [B2R-435](#)
- UNBIND request configuration [B2R-438](#)
- tn3270-server command [B2R-437](#)
- Token Ring, SNA service point
 - defining [B2R-66](#)
 - enabling [B2R-59](#)
- txconn destination command [B2R-196](#)
- txconn license command [B2R-198](#)
- txconn ping command [B2R-200](#)
- txconn route command [B2R-201](#)
- txconn server command [B2R-202](#)

U

- UDP listener sockets, CMCC adapter [B2R-256](#)
- UDP stack, CMCC adapter [B2R-257](#)
- unbind-action command [B2R-438](#)
- UNBIND request, TN3270 server configuration [B2R-361](#)
- UNBIND response, TN3270 server
 - configuration [B2R-438](#)
- user EXEC mode, summary of [xiv](#)

V

- VDLC (Virtual Data Link Control)
 - DSPU
 - defining [B2R-45](#)
 - SAP, enabling [B2R-47](#), [B2R-49](#)
 - starting [B2R-51](#)
 - SNA service point
 - defining [B2R-66](#), [B2R-72](#)
 - SAP, enabling [B2R-74](#)
 - starting [B2R-75](#)
- vrn command [B2R-439](#)