



A

access privileges [2-7](#)
admin status
 configuring, card [3-7](#)
authentication [4-9](#)
auto-negotiation, configuring [3-14, 3-19](#)

B

backing up configuration files [4-7](#)
backplane, viewing [3-18](#)
baud rate [3-18](#)
boot configuration, setting [4-6](#)
bridge groups
 adding [6-3](#)
 configuring [6-3](#)
 deleting [6-4](#)
 properties [6-2](#)
 viewing [6-1](#)
bridging, port [3-11](#)

C

cards
 inventory [3-6](#)
 viewing [3-1](#)
 viewing properties [3-3](#)
CLI authentication [4-9](#)
configuration files
 backing up [4-7](#)
 boot config, setting [4-6](#)
 exporting [4-6](#)

importing [4-5](#)

saving [4-7](#)

current status

 card [3-4](#)

 ports [3-19](#)

D

data bits [3-18](#)
date, configuring [4-3](#)
disable
 port [3-13](#)
DNS [4-8](#)
documentation
 conventions [x](#)
 organization [ix](#)

E

enable
 port [3-13](#)
encryption key, configuring [4-11](#)
exporting
 configuration files [4-6](#)
 log files [4-6](#)

F

fan status [3-16](#)
files, deleting [4-4](#)
file system
 deleting files [4-4](#)
 viewing [4-4](#)

filter indicator [2-6](#)
frames, GUI
 Tree [1-2](#)
 View [1-6](#)
FRU number, card [3-5](#)
FTP [4-8](#)

G

gateway ports, internal [3-7](#)
global ITL
 attributes [7-1](#)
 policies [7-1](#)
 statistics [7-13](#)

H

hosts
 adding [7-5](#)
 configuring [7-5](#)
 deleting [7-5](#)
 ITLs [7-4](#)
 ITs [7-4](#)
 properties [7-3](#)
 viewing [7-2](#)
 WWPNs [7-3](#)
host-target-LUN policies [7-12](#)
host-target-LUN properties [7-12](#)
host-target policies [7-10](#)
host-target properties [7-11](#)

I

image files, importing [4-5](#)
importing
 configuration files [4-5](#)
 image files [4-5](#)
InfiniBand nodes

 viewing [5-5](#)
Infiniband Nodes
 properties [5-6](#)
InfiniBand ports
 properties [5-9](#)
 viewing [5-9](#)
initiators
 adding [7-5](#)
 configuring [7-5](#)
 deleting [7-5](#)
 ITLs [7-4](#)
 ITs [7-4](#)
 properties [7-3](#)
 viewing [7-2](#)
 WWPNs [7-3](#)
installing software [4-5](#)
internal gateway ports [3-7](#)
IOCs
 properties [5-17](#)
 services [5-18](#)
 viewing [5-16](#)
IOUs [5-16](#)
IP addresses
 Ethernet management port [3-19](#)
IT
 policies [7-10](#)
 properties [7-11](#)
ITL
 global attributes [7-1](#)
 global policies [7-1](#)
 policies [7-12](#)
 properties [7-12](#)

L

launching Chassis Manager [2-2](#)
location [4-2](#)
locator [2-6](#)
log files, exporting [4-6](#)

logging out of chassis manager [2-6](#)

LUNs

configuring [7-10](#)

ITLs [7-10](#)

properties [7-9](#)

viewing [7-8](#)

M

MAC (media access control) [3-19](#)

management ports, viewing [3-18](#)

max retry, configuring for RADIUS [4-11](#)

media access control (MAC) address [3-19](#)

N

name

configuring port names [3-13](#)

file [4-4](#)

switch name [4-2](#)

neighbor properties, viewing [5-15](#)

neighbors, InfiniBand [5-9, 5-14](#)

net mask, ports [3-19](#)

node neighbors, viewing [5-9](#)

node ports, viewing [5-8](#)

nodes

properties [5-6](#)

viewing [5-5](#)

viewing neighbors [5-9](#)

viewing ports [5-8](#)

NTP servers, assigning [4-3](#)

O

operational state, card [3-4](#)

P

parity [3-19](#)

PCA

assembly number

card [3-5](#)

serial number

card [3-5](#)

port bridging properties [3-11](#)

ports

administrative status [3-19](#)

auto-negotiation [3-14](#)

bridging properties [3-11](#)

configure properties [3-13](#)

current status [3-19](#)

enabling and disabling [3-13](#)

gateway [3-19](#)

IP address [3-19](#)

management ports [3-18](#)

name, configuring [3-13](#)

net mask [3-19](#)

node ports [5-8](#)

properties [3-8](#)

speed, configuring [3-14](#)

view all [3-8](#)

view internal gateway [3-7](#)

ports, InfiniBand

viewing [5-9](#)

Ports, InfiniBand Ports

properties [5-9](#)

power supply status [3-14](#)

prepare your switch [2-1](#)

prerequisites [2-1](#)

printed circuit assembly (PCA) [3-5](#)

R

RADIUS

adding [4-12](#)

- configuring [4-10](#)
- deleting [4-12](#)
- viewing [4-10](#)

RADIUS server

- configuring encryption key [4-11](#)
- configuring max retry value [4-11](#)
- configuring timeout [4-11](#)
- configuring UDP port [4-11](#)

- rebooting [4-7](#)

- reloading [4-7](#)

S

- saving configuration files [4-7](#)

- serial number [3-5](#)

- services (basic), configuring [4-8](#)

- setup [2-1](#)

- slot ID [3-4](#)

- software, installing [4-5](#)

- speed, port speed [3-14](#)

SRP Hosts

- adding [7-5](#)
- configuring [7-5](#)
- deleting [7-5](#)
- ITLs [7-4](#)
- ITs [7-4](#)
- properties [7-3](#)
- viewing [7-2](#)
- WWPNs [7-3](#)

- starting Chassis Manager [2-2](#)

- statistics, global ITL [7-13](#)

status

- viewing [2-7](#)

- stop bits [3-19](#)

subnet manager

- adding [5-3](#)
- configuring [5-3](#)
- deleting [5-3](#)
- properties [5-2](#)

- viewing [5-1](#)

subnet services

- properties [5-5](#)
- viewing [5-4](#)

- switch configuration [2-1](#)

- SYSLOG [4-9](#)

T

targets

- configuring [7-7](#)
- ITLs [7-8](#)
- ITs [7-7](#)
- properties [7-6](#)
- viewing [7-6](#)

- telnet [4-8](#)

- temperature sensor status [3-17](#)

- tiered locator [2-6](#)

- time, configuring [4-3](#)

- timeout, configuring for RADIUS server [4-11](#)

- Tree frame [1-2](#)

trunk groups

- adding [6-10](#)
- configuring [6-12](#)
- deleting [6-12](#)
- properties [6-10](#)
- viewing [6-8](#)

- type, card [3-4](#)

U

- UDP port, configuring [4-11](#)

V

- View frame [1-6](#)