



GET VPN

Technology Design Guide

December 2013

VALIDATED DESIGN

Table of Contents

Preface	1
CVD Navigator	2
Use Cases	2
Scope	2
Proficiency	2
Introduction	3
Technology Use Case	3
Use Case: Site-to-Site WAN Encryption using MPLS Services	3
Design Overview	
GET VPN Components	4
Deployment Details	7
Implementing Key Servers	7
Implementing Group Member	22
Appendix A: Product List	26
Appendix B: Device Configuration Files	28
GET VPN Key Server	28
GET VPN Group Member	33
Appendix C: Changes	38

Preface

Cisco Validated Designs (CVDs) provide the foundation for systems design based on common use cases or current engineering system priorities. They incorporate a broad set of technologies, features, and applications to address customer needs. Cisco engineers have comprehensively tested and documented each CVD in order to ensure faster, more reliable, and fully predictable deployment.

CVDs include two guide types that provide tested and validated design and deployment details:

- **Technology design guides** provide deployment details, information about validated products and software, and best practices for specific types of technology.
- **Solution design guides** integrate or reference existing CVDs, but also include product features and functionality across Cisco products and may include information about third-party integration.

Both CVD types provide a tested starting point for Cisco partners or customers to begin designing and deploying systems using their own setup and configuration.

How to Read Commands

Many CVD guides tell you how to use a command-line interface (CLI) to configure network devices. This section describes the conventions used to specify commands that you must enter.

Commands to enter at a CLI appear as follows:

configure terminal

Commands that specify a value for a variable appear as follows:

ntp server 10.10.48.17

Commands with variables that you must define appear as follows:

class-map [highest class name]

Commands at a CLI or script prompt appear as follows:

Router# enable

Long commands that line wrap are underlined. Enter them as one command:

police rate 10000 pps burst 10000 packets conform-action set-discard-classtransmit 48 exceed-action transmit

Noteworthy parts of system output or device configuration files appear highlighted, as follows:

interface Vlan64

ip address 10.5.204.5 255.255.255.0

Comments and Questions

If you would like to comment on a guide or ask questions, please use the feedback form.

For the most recent CVD guides, see the following site:

http://www.cisco.com/go/cvd/wan

CVD Navigator

The CVD Navigator helps you determine the applicability of this guide by summarizing its key elements: the use cases, the scope or breadth of the technology covered, the proficiency or experience recommended, and CVDs related to this guide. This section is a quick reference only. For more details, see the Introduction.

Use Cases

This guide addresses the following technology use cases:

- Site-to-Site WAN Encryption using MPLS Services— Many organizations require encryption in order to secure communications between sites over private-cloud services such as provider-managed Multiprotocol Label Switching (MPLS).
- For more information, see the "Use Cases" section in this guide.

Scope

This guide covers the following areas of technology and products:

 Design and configuration of Group Encrypted Transport Virtual Private Network (GET VPN)

For more information, see the "Design Overview" section in this guide.

Proficiency

This guide is for people with the following technical proficiencies—or equivalent experience:

- CCNA Routing and Switching-1 to 3 years installing, configuring, and maintaining routed and switched networks
- CCNP Security–3 to 5 years testing, deploying, configuring, maintaining security appliances and other devices that establish the security posture of the network



To view the related CVD guides, click the titles or visit the following site: http://www.cisco.com/go/cvd/wan

Introduction

This guide describes how to deploy Cisco Group Encrypted Transport VPN (GET VPN) technology to secure WAN and metropolitan-area network (MAN) connectivity between a primary site and up to 500 remote sites.

Technology Use Case

Organizations pay a great deal of attention to protecting their electronic assets from outside threats. This includes an important development: IT services are increasingly migrating toward cloud-based services.

With organizations moving toward cloud-based IT services and cloud computing, they have an increasing need to secure data in transit and ensure data confidentiality, integrity, and availability. This is further driven by government regulatory requirements and industry security standards such as the Health Insurance Portability and Accountability Act (HIPAA), the Federal Information Security Management Act (FISMA), the Sarbanes-Oxley Act, and the Payment Card Industry Data Security Standard (PCI DSS) that spell out the need and set standards for encrypting data transported over networks.

Furthermore, voice and video are becoming a prominent piece of the overall network traffic. Organizations are looking to leverage technologies (for example, rich media collaboration tools and interactive video solutions) to lower operating cost and reduce their carbon footprint by cutting down on travel. As a result, the distributed nature of voice and interactive video applications has accelerated the need for instantaneous, remote site-to-remote site communications. At the same time, current WAN technologies force organizations to make tradeoffs between enabling quality of service (QoS) to support these real-time applications and network transport security.

To address these challenges, Cisco introduced the next generation of WAN encryption technology, Cisco GET VPN, which addresses the security requirement while maintaining the instantaneous remote site-to-remote site communication needed for real-time applications. Cisco GET VPN eliminates the need for compromise between network intelligence and data privacy in private WAN environments. The technology introduces a new category of VPN that eliminates the need for tunnels, while providing strong encryption that meets the 140 series of the Federal Information Processing Standards (FIPS).

Use Case: Site-to-Site WAN Encryption using MPLS Services

This guide helps organizations that require encryption in order to secure communications between sites over private cloud services such as provider-managed Multiprotocol Label Switching (MPLS).

This design guide enables the following network capabilities:

- Any-to-any secure encrypted communications well suited for MPLS-based WAN services, for up to 500 locations.
- Encrypted traffic that follows the native routing path directly between remote sites, rather than following a tunnel overlay model.
- Encryption services, with single or dual MPLS service providers, that support resilient designs using single or dual routers in remote-site locations.
- Support for IP Multicast, allowing multicast replication after encryption within the service provider network.
- Compatibility with WAN transport solutions that *do not* perform Network Address Translations (NAT) after encryption.
- QoS for WAN traffic such as Voice over IP (VoIP) and business critical applications.

Design Overview

GET VPN is a tunnel-less VPN technology based on the IETF standard (RFC 3547). The technology provides end-to-end data encryption for network infrastructure while maintaining any-to-any communication between sites. You can deploy it across various WAN core transports, such as IP or Multiprotocol Label Switching (MPLS) networks. GET VPN leverages the Group Domain of Interpretation (GDOI) protocol to create a secure communication domain among network devices.

The benefits of GET VPN include the following:

- Highly scalable VPN technology that provides an any-to-any meshed topology without the need for complex peer-to-peer security associations
- · Low latency and jitter communication with direct traffic between sites
- · Centralized encryption policy and membership management with the key servers (KSs)
- Simplified network design due to leveraging of native routing infrastructure (no overlay routing protocol needed)
- · Efficient bandwidth utilization by supporting multicast-enabled network core
- · Network intelligence such as native routing path, network topology, and QoS

Figure 1 - Secure WAN using GET VPN



GET VPN Components

A *group member* (GM) is a router running Cisco IOS that encrypts and decrypts the data traffic. A GM registers with a key server to obtain the encryption keys necessary for encrypting and decrypting traffic streams traversing through the device. The GM also performs routing between secure and unsecure domains. Lastly, the GM participates in multicast communications that have been established in the network.

A *key server (KS)* is the brain of the GET VPN operation. It is responsible for authenticating GMs. The KS manages security policies that determine which traffic should be encrypted. The KS distributes session keys for traffic encryption and the security policies through GDOI protocol to GMs. There are two types of keys that the KS sends out to GMs: the key encryption key (KEK) and the traffic encryption key (TEK). The KS uses the KEK to secure communication between the KS and GMs. GMs use the TEK for bulk data encryption of traffic traversing between GMs.





The KS sends out rekey messages as needed. The rekey message contains new encryption policy and encryption keys to use when the old IPSec Security Association (SA) expires. The rekey message is sent in advance of the SA expiration, which helps ensure that the new keys are available to all GMs.

The KS is an essential component in the GET VPN deployment. If the KS becomes unavailable, new GMs will not be able to register and participate in the secure communication, and the existing GMs will not receive new rekeys and updated security policies when the existing ones expire.

To help ensure a highly available and resilient GET VPN network, redundant KSs operate in cooperative mode. Cooperative key servers (COOP KSs) share the GM registration load by jointly managing the GDOI registration of the group. When COOP KSs start up, they go through an election process and the KS with the highest priority assumes the primary role, while the other KSs remain in secondary roles. The primary KS is responsible for creating and redistributing the security policies and keys to GMs, as well as synchronizing the secondary KSs.





Deployment Details

This section covers the following:

- Deployment details for key servers
- · Deployment details for group members

Caution

If you are using a Cisco ASR 1000 Series router as a GET VPN GM, the required software release is version 15.2(2)S2. Additional details are included in the "Appendix A: Product List" section of this guide.



This section describes configuring the GET VPN KSs. Only the core relevant features are described.

Table 1 -	Parameters	used in	the dep	loyment	examples
-----------	------------	---------	---------	---------	----------

Host name	Port-channel number	IP address	Netmask	Default gateway	KS role	KS priority
KS-2951-1	21	10.4.32.151	255.255.255.192	10.4.32.129	Primary	100
KS-2951-2	22	10.4.32.152	255.255.255.192	10.4.32.129	Secondary	75

Procedure 1

Configure the distribution switch

Step 1: If a VLAN does not already exist on the distribution layer switch, configure it now.

vlan 350

name WAN_Service_Net

Step 2: If the Layer 3 SVI has not yet been configured, configure it now.

Be sure to configure a VLAN interface (SVI) for every new VLAN you add, so devices in the VLAN can communicate with the rest of the network.

```
interface Vlan350
ip address 10.4.32.129 255.255.255.192
no shutdown
```

Next, configure EtherChannel member interfaces.

Tech Tip EtherChannel is a logical interface that bundles multiple physical LAN links into a single logical link.

Step 3: Connect the KS EtherChannel uplinks in order to separate switches in the distribution layer switches or stack (for the Cisco Catalyst 4507R+E distribution layer, this separates redundant modules for additional resiliency), and then configure two physical interfaces to be members of the EtherChannel. Also, apply the egress QoS macro that was defined in the platform configuration procedure. This ensures traffic is prioritized appropriately.

Tech Tip

Configure the physical interfaces that are members of a Layer 2 EtherChannel prior to configuring the logical port-channel interface. Doing the configuration in this order allows for minimal configuration and reduces errors because most of the commands entered to a port-channel interface are copied to its members interfaces and do not require manual replication.

```
interface GigabitEthernet 1/0/9
description Link to KS-2951-1 Gig0/0
interface GigabitEthernet 2/0/9
description Link to KS-2951-1 Gig0/1
!
interface range GigabitEthernet 1/0/9, GigabitEthernet 2/0/9
switchport
macro apply EgressQoS
channel-group 21 mode on
logging event link-status
logging event bundle-status
```

Next, configure the EtherChannel. Access mode interfaces are used for the connection to the KSs.

Step 4: Assign the VLAN created at the beginning of the procedure to the interface. When using EtherChannel, the port-channel number must match the channel group configured in Step 3.

```
interface Port-channel 21
description EtherChannel link to KS-2951-1
switchport access vlan 350
logging event link-status
no shutdown
```

Procedure 2 Configure the KS

Within this design, there are features and services that are common across all KS routers. In this procedure, you configure system settings that simplify and secure the management of the solution.

Step 1: Configure the device host name to make it easy to identify the device.

Hostname KS-2951-1

Step 2: Configure the local login and password.

The local login account and password provide basic access authentication to a router, which provides only limited operational privileges. The enable password secures access to the device configuration mode. By enabling password encryption, you prevent the disclosure of plaintext passwords when viewing configuration files.

```
username admin password clscol23
enable secret clscol23
service password-encryption
aaa new-model
```

By default, HTTPS access to the router will use the enable password for authentication.

Step 3: If you want to configure centralized user authentication, perform this step.

As networks scale in the number of devices to maintain, the operational burden to maintain local user accounts on every device also scales. A centralized authentication, authorization, and accounting (AAA) service reduces operational tasks per device and provides an audit log of user access for security compliance and root-cause analysis. When AAA is enabled for access control, all management access to the network infrastructure devices (Secure Shell [SSH] Protocol and Secure HTTP [HTTPS]) is controlled by AAA.

TACACS+ is the primary protocol used to authenticate management logins on the infrastructure devices to the AAA server. A local AAA user database is also defined in Step 2 on each network infrastructure device in order to provide a fallback authentication source in case the centralized TACACS+ server is unavailable.

```
tacacs server TACACS-SERVER-1
address ipv4 10.4.48.15
key SecretKey
!
aaa group server tacacs+ TACACS-SERVERS
server name TACACS-SERVER-1
!
aaa authentication login default group TACACS-SERVERS local
aaa authorization exec default group TACACS-SERVERS local
aaa authorization console
ip http authentication aaa
```

Step 4: Configure device management protocols.

HTTPS and SSH are secure replacements for the HTTP and Telnet protocols. They use Secure Sockets Layer (SSL) and Transport Layer Security (TLS) to provide device authentication and data encryption.

The use of the SSH and HTTPS protocols enables secure management of the network device. Both protocols are encrypted for privacy, and the unsecure protocols–Telnet and HTTP–are turned off.

Specify the **transport preferred none** command on vty lines in order to prevent errant connection attempts from the CLI prompt. Without this command, if the ip name-server is unreachable, long timeout delays may occur for mistyped commands.

```
ip domain-name cisco.local
ip ssh version 2
no ip http server
ip http secure-server
line vty 0 15
transport input ssh
transport preferred none
```

When synchronous logging of unsolicited messages and debug output is turned on, console log messages are displayed on the console after interactive CLI output is displayed or printed. With this command, you can continue typing at the device console when debugging is enabled.

line con 0 logging synchronous

Enable Simple Network Management Protocol (SNMP) to allow the network infrastructure devices to be managed by a network management system (NMS). SNMPv2c is configured both for a read-only and a read/write community string.

```
snmp-server community cisco RO
snmp-server community cisco123 RW
```

Step 5: If operational support is centralized in your network, you can increase network security by using an access list to limit the networks that can access your device. In this example, only devices on the 10.4.48.0/24 network will be able to access the device via SSH or SNMP.

```
access-list 55 permit 10.4.48.0 0.0.0.255
line vty 0 15
access-class 55 in
!
snmp-server community cisco RO 55
snmp-server community cisco123 RW 55
```

```
Tech Tip
```

ĺ

If you configure an access list on the vty interface, you may lose the ability to use SSH to log in from one router to the next for hop-by-hop troubleshooting.

Step 6: Configure a synchronized clock.

The Network Time Protocol (NTP) is designed to synchronize a network of devices. An NTP network usually gets its time from an authoritative time source, such as a radio clock or an atomic clock attached to a time server. NTP then distributes this time across the organization's network.

You should program network devices to synchronize to a local NTP server in the network. The local NTP server typically references a more accurate clock feed from an outside source. By configuring console messages, logs, and debug output to provide time stamps on output, you can cross-reference events in a network.

```
ntp server 10.4.48.17
ntp update-calendar
!
clock timezone PST -8
clock summer-time PDT recurring
!
service timestamps debug datetime msec localtime
service timestamps log datetime msec localtime
```

Procedure 3 Configure connectivity to the LAN

Any links to adjacent distribution layers should be Layer 3 links or Layer 3 EtherChannels.

Step 1: Configure a Layer 3 interface.

```
interface Port-channel21
ip address 10.4.32.151 255.255.255.192
no shutdown
```

Step 2: Configure EtherChannel member interfaces.

Configure the physical interfaces to tie to the logical port-channel by using the **channel-group** command. The number for the port-channel and channel-group must match. Not all router platforms can support Link Aggregation Control Protocol (LACP) to negotiate with the switch, so EtherChannel is configured statically.

```
interface GigabitEthernet0/0
description WAN-D3750X Gig1/0/9
!
interface GigabitEthernet0/1
description WAN-D3750X Gig2/0/9
!
interface range GigabitEthernet0/0, GigabitEthernet0/1
no ip address
channel-group 21
no shutdown
```

Step 3: Configure a default route. This provides reachability information for the KS to reach GMs by using a default route.

```
ip route 0.0.0.0 0.0.0.0 10.4.32.129
```

```
Procedure 4 Generate and export an RSA key
```

This procedure is for the primary KS only. Perform this procedure before starting KS configuration.

Step 1: Generate an RSA key for use during rekeys.

crypto key generate rsa label GETVPN-REKEY-RSA modulus 2048 exportable

Tech Tip

Generate the RSA key pair on the primary KS. Make sure that the "exportable" option is used in generating the RSA keys. This allows you to export the key pair and install it into other KSs that will be running in COOP KS mode in the network.

Example

```
KS-2951-1(config)# crypto key generate rsa label GETVPN-REKEY-RSA modulus 2048 exportable
```

```
The name for the keys will be: GETVPN-REKEY-RSA
```

% The key modulus size is 2048 bits

% Generating 2048 bit RSA keys, keys will be exportable...[OK]

Step 2: Export RSA keys from the primary KS.

```
crypto key export rsa GETVPN-REKEY-RSA pem terminal 3des clscol23
```

Step 3: Copy and paste the output from Step 2 into a text file. Make sure that you capture both the public key and private key.

Tech Tip

It is recommended that you store the key file in a secure environment. You will use the key pair later to build secondary KSs or, in the case of hardware failure, to rebuild the primary KS.

Example

1

KS-2951-1(config)#crypto key export rsa GETVPN-REKEY-RSA pem terminal 3des c1sco123 % Key name: GETVPN-REKEY-RSA

Usage: General Purpose Key

Key data:

----BEGIN PUBLIC KEY----

MIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAtX3Cr8QUpSmgTpmLkyYG CySAY1PTnoy06umGRMmxXu/XB41s64BpfHnrmuCqhtNajrlOxKO9TYh6r7kUSSKO EpFqmtk3bEJq/MF+hUvCXxz6Qe8S+YC0dHUem1039/mZJdK9RBwjC7KlFbP4io6D h9WmlL9R8mvTms1CEfdu4ameRaR+8dt6Tbm9SGwamKA8U2I8q5BPXDXfJMHCe/4y Kijo+5gSy1hy+1SEXW9MiNtV4Htckb5KlH+vhtkxDIzhXT2m8/wUQz3t+9LXfRgU OWFSo9XjTqbMDcMpAGSNnhFsqHW6+DYqup1wJGypfRKlTFr5cQ8nCQx0q6pwzA+5 fwIDAQAB

-----END PUBLIC KEY-----

----BEGIN RSA PRIVATE KEY-----

Proc-Type: 4, ENCRYPTED

DEK-Info: DES-EDE3-CBC, B0EA38C0B90569C9

2BADU1kcBZQo3aY/C+1gT3jVQxbawIoidGi5OZtqpczzHX5KwkgjN/o36t1Wa7ka TtPh3XZ6UZJ1YCiAW/fzyuKD3ITx6eS/npaHQu2pKl0ToDUEman0ptdKklRv5ODV7 AQEMYwI27Uy16cbbOdTkX4y1y5VmzCz3oLWqcygEiYWe2pHaB1dP7TEHnKmnrp3H ztRJIwLWJc682EIOK2IuhhNb05XAt3xXO241wNSvgE5zAtE9p2Z8lGSevcWjfmoi Pp58T7EWL9hWoCmpUA6+S60b/OVTV+MG7tGENGiL0alquMKQnGRf/eK28KaLwg7x <key data deleted>

----END RSA PRIVATE KEY-----

Procedure 5 Configure KS policies

The Internet Security Association and Key Management Protocol (ISAKMP) policy for GET VPN uses the following:

- Advanced Encryption Standard (AES) with 256-bit key
- Secure Hash Standard (SHA)
- Diffie-Hellman Group: 5 (used for KS)
- Diffie-Hellman Group: 2 (used for GM)
- · Internet Key Exchange (IKE) lifetime: 86,400 (default, used for KS)
- IKE lifetime: 1200 (used for GM)

Step 1: Define ISAKMP policy for COOP KS.

```
crypto isakmp policy 10
encr aes 256
group 5
```

Step 2: Define ISAKMP policy for GMs.

```
crypto isakmp policy 15
encr aes 256
group 2
lifetime 1200
```

Although most ISAKMP policy parameters must be identically configured between KS and GM, IKE lifetime is negotiated between KS and GM to the lowest value configured. On the KS, change the IKE lifetime to 1200 seconds from the default 86400 seconds to centrally set the IKE lifetime for GM.

Step 3: Configure the IKE authentication method by using pre-shared key (PSK).

```
crypto isakmp policy 10
authentication pre-share
!
crypto isakmp policy 15
authentication pre-share
```

The default authentication method uses public key infrastructure (PKI) (authentication rsa-sig). For ease of deployment, this example uses PSK as the authentication method.

Step 4: Configure the PSK. For IKE authentication to be successful, the remote peer's PSK must match the local peer's PSK. You can uniquely configure the PSK on a per-peer basis, or you can use a wildcard PSK to allow a group of remote devices with the same level of authentication to share an IKE PSK.

crypto isakmp key **c1sco123** address 0.0.0.0 0.0.0.0

Step 5: Configure the IPsec encryption profile.

```
crypto ipsec transform-set AES256/SHA esp-aes 256 esp-sha-hmac
!
crypto ipsec profile GETVPN-PROFILE
set security-association lifetime seconds 7200
set transform-set AES256/SHA
```

This example defines the algorithm used for data encryption, as well as the traffic encryption key (TEK) lifetime. Using the AES-256 encryption algorithm provides more robust security. The TEK lifetime is set for 2 hours (7200 seconds).



unstable state.

Step 6: Configure GET VPN GDOI group parameters. Each GDOI group configured on the KS requires a unique group ID.

```
crypto gdoi group GETVPN-GROUP identity number 65511
```

Step 7: Designate the device as a GDOI KS and define the parameters that will be used during the rekey process.

```
server local
rekey algorithm aes 256
rekey retransmit 40 number 3
rekey authentication mypubkey rsa GETVPN-REKEY-RSA
rekey transport unicast
address ipv4 [KS address]
```

The default rekey transport is multicast, but in this example you use the unicast rekey transport mechanism, with two more retransmits at 40-second intervals. You configure the AES-256 cipher to encrypt rekey messages, and you configure authentication to use the RSA key pair generated earlier.

Configure the IPsec profile and security policies, which define the traffic to be encrypted, and then configure the time-based anti-replay (TBAR) window size.

```
sa ipsec 10
profile GETVPN-PROFILE
match address ipv4 GETVPN-POLICY-ACL
replay time window-size 5
```

Step 8: Configure the security policy access control list (ACL).

Define the security policy on the KS by using an extended IP ACL. You should only use the 5-tuple in the ACL (that is, source_ip_address, destination_ip_address, protocol, source_port, destination_port) to determine what to encrypt. The **permit** entries in the ACL define the traffic that should be encrypted, and the **deny** entries define the traffic that should be excluded from the GET VPN encryption. The **deny** entries in the ACL should be configured to exclude routing protocols and the traffic that is encrypted already, such as SSH, TACACS+, GDOI, ISAKMP, etc. The ACL is applied to the GET VPN configuration.

```
ip access-list extended GETVPN-POLICY-ACL
remark >> exclude transient encrypted traffic (ESP, ISAKMP, GDOI)
       esp any any
deny
deny udp any eq isakmp any eq isakmp
       udp any eq 848 any eq 848
deny
remark >> exclude encrypted in-band management traffic (SSH, TACACS+)
deny
      tcp any any eq 22
deny tcp any eq 22 any
deny tcp any any eq 49
deny tcp any eq 49 any
remark >> exclude routing protocol with MPLS provider
deny
      tcp any any eq bgp
deny tcp any eq bgp any
remark >> exclude routing protocol used for Layer 2 WAN
deny
      eigrp any any
remark >> exclude other protocols as necessary (multiple lines)
      [protocol] [source] [destination]
denv
remark >> Require all other traffic to be encrypted
permit ip any any
```

By migrating from an unencrypted network to GET VPN, you can use receive-only SAs while WAN edge routers are in the process of converting to GET VPN GMs. The receive-only SA allows a GM to register to a KS and start receiving security policies and keys used for encryption; however, the GM continues to forward traffic in clear. The receive-only SA option establishes the control plane for the GET VPN network without engaging the data plan. This serves to provide interoperability between the sites that have been migrated to the GET VPN network and the sites waiting to be migrated.

Step 9: If you want to use receive-only SAs while WAN edge routers are in the process of converting to GET VPN GMs, enable receive-only SA capability on the KS.

crypto gdoi group **GETVPN-GROUP** server local sa receive-only

Figure 4 - Receive-only mode



After your network is fully migrated to GET VPN and you have verified that the control plane is completely operational, you can enable the encryption for all GMs in a group by disabling the receive-only SA mode on the KS.

Step 10: Disable the receive-only SA mode on the KS.



Figure 5 - Steady-state operation



```
Example: Primary KS
```

```
crypto isakmp policy 10
encr aes 256
authentication pre-share
group 5
!
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
lifetime 1200
crypto isakmp key clscol23 address 0.0.0.0 0.0.0.0
Į.
!
crypto ipsec transform-set AES256/SHA esp-aes 256 esp-sha-hmac
1
crypto ipsec profile GETVPN-PROFILE
set security-association lifetime seconds 7200
set transform-set AES256/SHA
1
crypto gdoi group GETVPN-GROUP identity number 65511
 server local
 rekey algorithm aes 256
 rekey retransmit 40 number 3
 rekey authentication mypubkey rsa GETVPN-REKEY-RSA
 rekey transport unicast
 sa ipsec 10
  profile GETVPN-PROFILE
  match address ipv4 GETVPN-POLICY-ACL
  replay time window-size 5
 address ipv4 10.4.32.151
L
ip access-list extended GETVPN-POLICY-ACL
remark >> exclude transient encrypted traffic (ESP, ISAKMP, GDOI)
deny esp any any
deny udp any eq isakmp any eq isakmp
deny udp any eq 848 any eq 848
 remark >> exclude encrypted in-band management traffic (SSH, TACACS+)
 deny tcp any any eq 22
 deny tcp any eq 22 any
deny tcp any any eq 49
 deny tcp any eq 49 any
 remark >> exclude routing protocol with MPLS provider
 deny tcp any any eq bgp
deny tcp any eq bgp any
 remark >> exclude routing protocol used for Layer 2 WAN
```

```
deny
      eigrp any any
remark >> exclude PIM protocol
      pim any host 224.0.0.13
deny
remark >> exclude IGMP with MPLS provider
      igmp any host 224.0.0.1
deny
      igmp host 224.0.0.1 any
deny
deny
      igmp any host 224.0.1.40
      igmp host 224.0.1.40 any
denv
remark >> exclude icmp traffic destined to SP address
denv
      icmp any 192.168.3.0 0.0.0.255
      icmp 192.168.3.0 0.0.0.255 any
deny
deny
      icmp any 192.168.4.0 0.0.0.255
      icmp 192.168.4.0 0.0.0.255 any
deny
remark >> Require all other traffic to be encrypted
permit ip any any
```

Procedure 6 Configure secondary KS

This procedure is for the secondary KS only.

The secondary KSs are configured similarly to the primary KS. Begin by repeating Procedure 1, "Configure the distribution switch." Follow this with Procedure 2, "Configure the KS," and Procedure 3, "Configure connectivity to the LAN." Then, complete the following steps. Identical policies must be configured between the primary and secondary KS. This helps ensure that the same rules are redistributed to the GM if the secondary KS assumes the primary role.

Step 1: Import the RSA keys that were created in Procedure 4, "Generate and export an RSA key," from the primary KS. This step requires PEM-formatted keys. Cut and paste from the terminal to a new KS router. You need to paste the public and private keys separately.

crypto key import rsa GETVPN-REKEY-RSA exportable terminal clscol23

Example

```
KS-2951-2(config) # crypto key import rsa GETVPN-REKEY-RSA exportable terminal c1sco123
```

```
% Enter PEM-formatted public General Purpose key or certificate.
```

% End with a blank line or "quit" on a line by itself.

```
----BEGIN PUBLIC KEY-----
```

```
MIIBIjANBgkqhkiG9w0BAQEFAAOCAQ8AMIIBCgKCAQEAtX3Cr8QUpSmgTpmLkyYG
CySAY1PTnoy06umGRMmxXu/XB41s64BpfHnrmuCqhtNajr1OxKO9TYh6r7kUSSKO
EpFqmtk3bEJq/MF+hUvCXxz6Qe8S+YC0dHUem1039/mZJdK9RBwjC7KlFbP4io6D
h9WmlL9R8mvTms1CEfdu4ameRaR+8dt6Tbm9SGwamKA8U2I8q5BPXDXfJMHCe/4y
Kijo+5gSy1hy+1SEXW9MiNtV4Htckb5KlH+vhtkxDIzhXT2m8/wUQz3t+9LXfRgU
OWFSo9XjTqbMDcMpAGSNnhFsqHW6+DYqup1wJGypfRKlTFr5cQ8nCQx0q6pwzA+5
fwIDAQAB
```

```
----END PUBLIC KEY-----
```

quit

 $\ensuremath{\$$ Enter PEM-formatted encrypted private General Purpose key.

```
% End with "quit" on a line by itself.
```

----BEGIN RSA PRIVATE KEY-----

Proc-Type: 4, ENCRYPTED

DEK-Info: DES-EDE3-CBC, B0EA38C0B90569C9

2BADU1kcBZQo3aY/C+lgT3jVQxbawIoidGi5OZtqpczzHX5KwkgjN/o36t1Wa7ka TtPh3XZ6UZJ1YCiAW/fzyuKD3ITx6eS/npaHQu2pKl0ToDUEman0ptdKklRv5ODV AQEMYwI27Uy16cbbOdTkX4y1y5VmzCz3oLWqcygEiYWe2pHaB1dP7TEHnKmnrp3H ztRJIwLWJc682EIOK2IuhhNb05XAt3xXO241wNSvgE5zAtE9p2Z8lGSevcWjfmoi Pp58T7EWL9hWoCmpUA6+S60b/OVTV+MG7tGENGiL0alquMKQnGRf/eK28KaLwg7x <key data deleted>

----END RSA PRIVATE KEY-----

quit

i

% Key pair import succeeded.

Tech Tip

The RSA key pair must be identical on all KSs running in COOP KS mode. If a KS is added to a group without the RSA key, it will not be able to generate policies. This will result in the GM registered to this KS to stay in a fail-closed state and be unable to pass traffic with the rest of the GM in the group.

Step 2: Complete Procedure 5, "Configure KS policies" for the secondary KS.



Step 3: Configure periodic dead peer protection on all secondary KSs running in COOP KS mode so that the primary KS can track state for the secondary KS.

crypto isakmp keepalive 15 periodic

Step 4: Configure KS redundancy by enabling the cooperative KS function on the secondary KS and setting the KS priority to 75, which is less than that of the primary KS (which is set to 100).



```
Example: Secondary KS
```

```
crypto isakmp policy 10
encr aes 256
authentication pre-share
group 5
!
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
lifetime 1200
crypto isakmp key clscol23 address 0.0.0.0 0.0.0.0
crypto isakmp keepalive 15 periodic
!
1
crypto ipsec transform-set AES256/SHA esp-aes 256 esp-sha-hmac
1
crypto ipsec profile GETVPN-PROFILE
set security-association lifetime seconds 7200
set transform-set AES256/SHA
T
crypto gdoi group GETVPN-GROUP
identity number 65511
server local
 rekey algorithm aes 256
 rekey retransmit 40 number 3
 rekey authentication mypubkey rsa GETVPN-REKEY-RSA
 rekey transport unicast
 sa ipsec 10
  profile GETVPN-PROFILE
  match address ipv4 GETVPN-POLICY
  replay time window-size 5
 address ipv4 10.4.32.152
 redundancy
  local priority 75
  peer address ipv4 10.4.32.151
I.
ip access-list extended GETVPN-POLICY-ACL
 remark >> exclude transient encrypted traffic (ESP, ISAKMP, GDOI)
deny esp any any
deny udp any eq isakmp any eq isakmp
deny udp any eq 848 any eq 848
 remark >> exclude encrypted in-band management traffic (SSH, TACACS+)
 deny tcp any any eq 22
 deny tcp any eq 22 any
 deny tcp any any eq 49
```

tcp any eq 49 any deny remark >> exclude routing protocol with MPLS provider tcp any any eq bqp deny deny tcp any eq bgp any remark >> exclude routing protocol used for Layer 2 WAN eigrp any any deny remark >> exclude PIM protocol pim any host 224.0.0.13 denv remark >> exclude IGMP with MPLS provider denv igmp any host 224.0.0.1 deny igmp host 224.0.0.1 any deny igmp any host 224.0.1.40 igmp host 224.0.1.40 any deny remark >> exclude icmp traffic destined to SP address icmp any 192.168.3.0 0.0.0.255 deny denv icmp 192.168.3.0 0.0.0.255 any icmp any 192.168.4.0 0.0.0.255 deny deny icmp 192.168.4.0 0.0.0.255 any remark >> Permit all other traffic to be encrypted permit ip any any

Procedure 7 Configure redundancy on primary KS

It is recommended that you have at least two KSs running in COOP KS mode in order to achieve redundancy and high availability in a GET VPN network. COOP KSs ensure that the group security policies, encryption keys, and registered GM information are shared and synchronized between KSs. From among the available KSs running in COOP mode, a primary KS is determined based first on highest priority, and then on the highest IP address used for rekey.

The primary KS is responsible for creating and redistributing group policies, and it also sends out updates on group information to other KSs to keep the secondary KSs in sync. If the primary KS is unavailable, a secondary KS can declare itself primary KS for the group and transition to the primary KS role if it does not detect other KS with higher priority.

Step 1: Configure KS redundancy on the primary KS and set the KS priority to 100.

crypto gdoi group **GETVPN-GROUP** server local redundancy local priority **100** peer address ipv4 **10.4.32.152** **Step 2:** Configure periodic dead peer protection on the primary KS running in COOP KS mode so that the secondary KS can track the state for the primary KS.

crypto isakmp keepalive 15 periodic

Example: Primary KS with redundancy

crypto isakmp keepalive 15 periodic crypto gdoi group **GETVPN-GROUP** identity number **65511** server local redundancy local priority **100** peer address ipv4 **10.4.32.152**

PROCESS

Implementing Group Member

1. Configure a GM

2. Configure shared key ring for GET VPN and DMVPN single-router sites

This process adds GM functionality to an already configured WAN router. It includes only the additional steps required to enable the GM capabilities.

Procedure 1 Configure a GM

The GM registers with the KS in order to obtain the IPSec SA and the encryption keys that are necessary to encrypt traffic. During registration, the GM presents a group ID to the KS to get the respective policies and keys for the group. Because most of the intelligence resides on the KS, the configuration on a GM is relatively simple and is identical across all GMs.

This procedure assumes that all of the basic connectivity configurations (such as default route, routing protocols, etc.) are already set up. This procedure needs to be repeated for every GM that runs GET VPN.

Step 1: Configure ISAKMP policy.

The ISAKMP policy for GET VPN uses the following:

- AES with 256-bit key
- SHA
- Diffie-Hellman Group 2
- PSK authentication

```
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
```

Step 2: Configure the PSK for the KSs.

crypto isakmp key **clscol23** address **10.4.32.151** crypto isakmp key **clscol23** address **10.4.32.152**

For IKE authentication to be successful, the remote peer's PSK must match the local peer's PSK. You only need to specify the PSKs with the KSs.

Step 3: Configure the GDOI group information.

```
crypto gdoi group GETVPN-GROUP
identity number 65511
server address ipv4 10.4.32.151
server address ipv4 10.4.32.152
```

You do not need to configure IPsec transform-set and profile on a GM. When the GM successfully registers with the KS, it downloads these parameters. A GM needs to define only the GDOI group identity and the address of the KSs.

Step 4: Define the crypto map with the GDOI option and associate it to the GDOI group created in the previous step. Although the sequence number is arbitrary, it is a best practice to use the same value on all GMs.

```
crypto map GETVPN-MAP local-address Loopback0
crypto map GETVPN-MAP [Sequence number] gdoi
set group GETVPN-GROUP
```

Step 5: Activate GET VPN configuration on the GM.



interface [type] [number]
crypto map GETVPN-MAP

Step 6: Apply the **ip tcp adjust-mss 1360** command on the WAN interface to account for the IPsec overhead. This command results in lowering the maximum segment size (MSS) for TCP traffic traverse through the interface to avoid the overhead caused by the IPsec header. This command affects only TCP traffic and is not applicable to UDP traffic.

```
interface [type] [number]
ip tcp adjust-mss 1360
```

Example: MPLS and Layer 2 WAN

```
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
crypto isakmp key clscol23 address 10.4.32.151
crypto isakmp key clscol23 address 10.4.32.152
!
crypto gdoi group GETVPN-GROUP
identity number 65511
server address ipv4 10.4.32.151
server address ipv4 10.4.32.152
1
!
crypto map GETVPN-MAP local-address Loopback0
crypto map GETVPN-MAP 10 gdoi
set group GETVPN-GROUP
```

Example: MPLS CE router

interface GigabitEthernet0/0/3
description Connection to MPLS PE router
ip tcp adjust-mss 1360
crypto map GETVPN-MAP

Example: Layer 2 WAN CE router (with trunked demarcation)
interface GigabitEthernet0/0/3.38
encapsulation dot1Q 38
description Connection to Layer 2 WAN
ip tcp adjust-mss 1360
crypto map GETVPN-MAP

(Optional)

1

If you are configuring a secondary Internet link with DMVPN on an MPLS or Layer 2 WAN primary router that is also running GET VPN, you must use a single shared crypto key ring in order for GET VPN and DMVPN to work concurrently. This is applicable to DMVPN remote-site configurations that do not include front-door VRF for local Internet access.

Step 1: Move the pre-shared keys for GET VPN to the global key ring.

```
crypto keyring GLOBAL-KEYRING
pre-shared-key address 10.4.32.151 key clsco123
pre-shared-key address 10.4.32.152 key clsco123
pre-shared-key address 0.0.0.0 0.0.0.0 key cisco123
```

Tech Tip

When a key ring is configured in the global table, it takes precedence over other preshared key configurations.

When you add the following crypto keyring command to configuration,

```
crypto keyring GLOBAL-KEYRING pre-shared-key address 0.0.0.0 0.0.0.0 key cisco123
```

then the following ISAKMP pre-shared key statements become invalid:

crypto isakmp key **clscol23** address **10.4.32.151** crypto isakmp key **clscol23** address **10.4.32.152**

If you require concurrent GET VPN and DMVPN in a non-VRF-aware configuration, merge all ISAKMP pre-shared keys into the global crypto key ring.

Appendix A: Product List

WAN Remote Site

Functional Area	Product Description	Part Numbers	Software	
Modular WAN Remote-site Router	Cisco ISR 4451-X Security Bundle w/SEC license PAK	ISR4451-X-SEC/K9	15.3(3)S securityk9 license	
	Cisco 3945 Voice Sec. Bundle, PVDM3-64, UC and SEC License PAK	C3945-VSEC/K9	15.2(4)M4 securityk9 license	
	Cisco 3925 Voice Sec. Bundle, PVDM3-64, UC and SEC License PAK	C3925-VSEC/K9	datak9 license	
	Data Paper PAK for Cisco 3900 series	SL-39-DATA-K9		
	Cisco 2951 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2951-VSEC/K9		
	Cisco 2921 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2921-VSEC/K9		
	Cisco 2911 Voice Sec. Bundle, PVDM3-32, UC and SEC License PAK	C2911-VSEC/K9		
	Data Paper PAK for Cisco 2900 series	SL-29-DATA-K9		
Fixed WAN Remote-site Router	Cisco 881 SRST Ethernet Security Router with FXS FXO 802.11n FCC Compliant	C881SRST-K9	15.2(4)M4 securityk9 license datak9 license	

WAN Aggregation

Functional Area	Product Description	Part Numbers	Software	
GET VPN Key Server	Cisco 2951 Security Bundle with Security License	CISCO2951-SEC/K9	15.2(4)M4 securityk9 license	
WAN-aggregation Router	Aggregation Services 1002X Router	ASR1002X-5G-VPNK9	IOS-XE 15.3(3)S Advanced Enterprise license	
	Aggregation Services 1002 Router	ASR1002-5G-VPN/K9		
	Aggregation Services 1001 Router	ASR1001-2.5G-VPNK9		
	Cisco 3945 Security Bundle w/SEC license PAK	CISCO3945-SEC/K9	15.2(4)M4 securityk9 license datak9 license	
	Cisco 3925 Security Bundle w/SEC license PAK	CISCO3925-SEC/K9		
	Data Paper PAK for Cisco 3900 series	SL-39-DATA-K9		

LAN Distribution Layer

Functional Area	Product Description	Part Numbers	Software	
Modular Distribution Layer Virtual Switch Pair	Cisco Catalyst 6500 E-Series 6-Slot Chassis	WS-C6506-E	15.1(1)SY IP services license	
	Cisco Catalyst 6500 VSS Supervisor 2T with 2 ports 10GbE and PFC4	VS-S2T-10G		
	Cisco Catalyst 6500 4-port 40GbE/16-port 10GbE Fiber Module w/DFC4	WS-X6904-40G-2T		
	Cisco Catalyst 6500 4-port 10GbE SFP+ adapter for WX-X6904-40G module	CVR-CFP-4SFP10G		
	Cisco Catalyst 6500 24-port GbE SFP Fiber Module w/DFC4	WS-X6824-SFP-2T		
Modular Distribution Layer Switch	Cisco Catalyst 4507R+E 7-slot Chassis with 48Gbps per slot	WS-C4507R+E	3.4.0.SG(15.1-2SG) Enterprise Services license	
	Cisco Catalyst 4500 E-Series Supervisor Engine 7-E, 848Gbps	WS-X45-SUP7-E		
	Cisco Catalyst 4500 E-Series 24-port GbE SFP Fiber Module	WS-X4624-SFP-E		
	Cisco Catalyst 4500 E-Series 12-port 10GbE SFP+ Fiber Module	WS-X4712-SFP+E		
Stackable Distribution Layer Switch	Cisco Catalyst 3750-X Series Stackable 12 GbE SFP ports	WS-C3750X-12S-E	15.0(2)SE2 IP Services license	
	Cisco Catalyst 3750-X Series Two 10GbE SFP+ and Two GbE SFP ports network module	C3KX-NM-10G		
	Cisco Catalyst 3750-X Series Four GbE SFP ports network module	C3KX-NM-1G		

Appendix B: Device Configuration Files

GET VPN Key Server

```
version 15.1
service timestamps debug datetime msec localtime
service timestamps log datetime msec localtime
service password-encryption
!
hostname KS-2951-1
!
boot-start-marker
boot-end-marker
!
!
!
aaa new-model
1
!
aaa group server tacacs+ TACACS-SERVERS
 server name TACACS-SERVER-1
!
aaa authentication login default group TACACS-SERVERS local
aaa authorization console
aaa authorization exec default group TACACS-SERVERS local
aaa authorization console
ip http authentication aaa
aaa session-id common
1
clock timezone PST -8 0
clock summer-time PDT recurring
!
crypto pki token default removal timeout 0
!
no ipv6 cef
ipv6 spd queue min-threshold 62
ipv6 spd queue max-threshold 63
ip source-route
ip cef
!
!
```

```
ļ
!
Ţ.
ip domain name cisco.local
!
multilink bundle-name authenticated
!
1
!
!
!
voice-card 0
!
!
!
!
!
1
!
license udi pid CISCO2951/K9 sn **********
license boot module c2951 technology-package securityk9
hw-module pvdm 0/0
!
!
!
!
redundancy
!
!
!
!
ip ssh version 2
!
1
crypto isakmp policy 10
encr aes 256
authentication pre-share
group 5
!
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
 lifetime 1200
crypto isakmp key clscol23 address 0.0.0.0 0.0.0.0
crypto isakmp keepalive 15 periodic
```

```
ļ
!
crypto ipsec transform-set AES256/SHA esp-aes 256 esp-sha-hmac
!
crypto ipsec profile GETVPN-PROFILE
set security-association lifetime seconds 7200
set transform-set AES256/SHA
!
crypto gdoi group GETVPN-GROUP
 identity number 65511
server local
 rekey algorithm aes 256
 rekey retransmit 40 number 3
 rekey authentication mypubkey rsa GETVPN-REKEY-RSA
 rekey transport unicast
  sa ipsec 10
  profile GETVPN-PROFILE
  match address ipv4 GETVPN-POLICY-ACL
  replay time window-size 5
 address ipv4 10.4.32.151
 redundancy
  local priority 100
  peer address ipv4 10.4.32.152
!
!
!
T
L
interface Port-channel21
ip address 10.4.32.151 255.255.255.192
hold-queue 150 in
1
interface Embedded-Service-Engine0/0
no ip address
shutdown
!
interface GigabitEthernet0/0
no ip address
duplex auto
speed auto
channel-group 21
!
interface GigabitEthernet0/1
no ip address
duplex auto
 speed auto
channel-group 21
```

```
ļ
interface GigabitEthernet0/2
no ip address
shutdown
duplex auto
speed auto
!
ip forward-protocol nd
1
no ip http server
ip http secure-server
1
ip route 0.0.0.0 0.0.0.0 10.4.32.129
!
ip access-list extended GETVPN-POLICY-ACL
remark >> exclude transient encrypted traffic (ESP, ISAKMP, GDOI)
deny esp any any
deny udp any eq isakmp any eq isakmp
      udp any eq 848 any eq 848
deny
remark >> exclude encrypted in-band management traffic (SSH, TACACS+)
deny tcp any any eq 22
deny tcp any eq 22 any
deny tcp any any eq tacacs
deny tcp any eq tacacs any
remark >> exclude routing protocol with MPLS provider
deny tcp any any eq bgp
deny tcp any eq bgp any
remark >> exclude routing protocol used for Layer 2 WAN
deny
      eigrp any any
remark >> exclude PIM protocol
deny pim any host 224.0.0.13
remark >> exclude IGMP with MPLS provider
deny
      igmp any host 224.0.0.1
deny igmp host 224.0.0.1 any
deny igmp any host 224.0.1.40
deny igmp host 224.0.1.40 any
remark >> exclude icmp traffic destined to SP address
       icmp any 192.168.3.0 0.0.0.255
deny
deny icmp 192.168.3.0 0.0.0.255 any
deny
      icmp any 192.168.4.0 0.0.0.255
       icmp 192.168.4.0 0.0.0.255 any
deny
remark >> Require all other traffic to be encrypted
permit ip any any
!
I
I
!
```

```
!
nls resp-timeout 1
cpd cr-id 1
!
snmp-server community cisco RO
snmp-server community cisco123 RW
!
1
!
control-plane
!
!
!
!
mgcp profile default
!
tacacs server TACACS-SERVER-1
address ipv4 10.4.48.15
key 7 113A1C0605171F270133
!
1
ļ
!
gatekeeper
shutdown
1
!
!
line con 0
logging synchronous
line aux 0
line 2
no activation-character
no exec
transport preferred none
transport input all
transport output pad telnet rlogin lapb-ta mop udptn v120 ssh
 stopbits 1
line vty 0 4
transport input ssh
line vty 5 15
transport input ssh
!
scheduler allocate 20000 1000
ntp update-calendar
ntp server 10.4.48.17
end
```

GET VPN Group Member

```
version 15.1
service timestamps debug datetime msec localtime
service timestamps log datetime msec localtime
service password-encryption
no platform punt-keepalive disable-kernel-core
1
hostname CE-ASR1002-1
!
boot-start-marker
boot-end-marker
!
!
vrf definition Mgmt-intf
 !
 address-family ipv4
 exit-address-family
 1
 address-family ipv6
 exit-address-family
!
!
aaa new-model
!
T.
aaa group server tacacs+ TACACS-SERVERS
server name TACACS-SERVER-1
1
aaa authentication login default group TACACS-SERVERS local
aaa authorization console
aaa authorization exec default group TACACS-SERVERS local
aaa authorization console
ip http authentication aaa
!
!
!
L
1
aaa session-id common
clock timezone PST -8 0
clock summer-time PDT recurring
1
!
!
ip domain name cisco.local
```

```
ip multicast-routing distributed
!
!
!
1
!
!
multilink bundle-name authenticated
!
!
!
!
!
!
1
!
!
!
redundancy
mode none
!
!
!
!
!
ip tftp source-interface Loopback0
ip ssh source-interface Loopback0
ip ssh version 2
!
!
1
crypto isakmp policy 15
encr aes 256
authentication pre-share
group 2
crypto isakmp key clscol23 address 10.4.32.151
crypto isakmp key clscol23 address 10.4.32.152
!
L
crypto gdoi group GETVPN-GROUP
identity number 65511
server address ipv4 10.4.32.151
server address ipv4 10.4.32.152
!
!
crypto map GETVPN-MAP local-address Loopback0
```

```
crypto map GETVPN-MAP 10 gdoi
set group GETVPN-GROUP
I.
l
T
L
L
interface Loopback0
ip address 10.4.32.241 255.255.255.255
ip pim sparse-mode
I.
interface Port-channel1
ip address 10.4.32.2 255.255.255.252
ip pim sparse-mode
no negotiation auto
!
interface GigabitEthernet0/0/0
no ip address
negotiation auto
channel-group 1 mode active
1
interface GigabitEthernet0/0/1
no ip address
negotiation auto
channel-group 1 mode active
!
interface GigabitEthernet0/0/2
no ip address
shutdown
negotiation auto
!
interface GigabitEthernet0/0/3
description WAN Interface
bandwidth 300000
ip address 192.168.3.1 255.255.255.252
ip tcp adjust-mss 1360
negotiation auto
crypto map GETVPN-MAP
!
interface GigabitEthernet0
vrf forwarding Mgmt-intf
no ip address
shutdown
negotiation auto
!
I
router eigrp 100
```

```
distribute-list route-map BLOCK-TAGGED-ROUTES in
 default-metric 100000 100 255 1 1500
network 10.4.0.0 0.1.255.255
redistribute bgp 65511
passive-interface default
no passive-interface Port-channel1
eigrp router-id 10.4.32.241
!
router bgp 65511
bgp router-id 10.4.32.241
bgp log-neighbor-changes
network 0.0.0.0
network 192.168.3.0 mask 255.255.255.252
redistribute eigrp 100
neighbor 10.4.32.242 remote-as 65511
neighbor 10.4.32.242 update-source Loopback0
neighbor 10.4.32.242 next-hop-self
neighbor 192.168.3.2 remote-as 65401
!
ip forward-protocol nd
!
no ip http server
ip http authentication aaa
ip http secure-server
ip pim autorp listener
ip tacacs source-interface Loopback0
!
!
route-map BLOCK-TAGGED-ROUTES deny 10
match tag 65401 65402 65512
!
route-map BLOCK-TAGGED-ROUTES permit 20
!
snmp-server community cisco RO
snmp-server community cisco123 RW
snmp-server trap-source Loopback0
!
tacacs server TACACS-SERVER-1
address ipv4 10.4.48.15
key 7 113A1C0605171F270133
!
!
control-plane
!
L
I
!
```

```
!
line con 0
logging synchronous
stopbits 1
line aux 0
stopbits 1
line vty 0 4
transport input ssh
line vty 5 15
transport input ssh
!
ntp source Loopback0
ntp server 10.4.48.17
end
```

Appendix C: Changes

This appendix summarizes the changes to this guide since its last edition.

- Added support for Cisco 4451-X Integrated Services Router platform.
- Added configuration for single-router remote-sites that support GET VPN and DMVPN for local Internet designs.

Feedback

Please use the feedback form to send comments and suggestions about this guide.

Americas Headquarters Cisco Systems, Inc. San Jose, CA Asia Pacific Headquarters Cisco Systems (USA) Pte. Ltd. Singapore Europe Headquarters Cisco Systems International BV Amsterdam, The Netherlands

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices.

ALL DESIGNS, SPECIFICATIONS, STATEMENTS, INFORMATION, AND RECOMMENDATIONS (COLLECTIVELY, "DESIGNS") IN THIS MANUAL ARE PRESENTED "AS IS," WITH ALL FAULTS. CISCO AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT OR ARISING FROM A COURSE OF DEALING, USAGE, OR TRADE PRACTICE. IN NO EVENT SHALL CISCO OR ITS SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, OR INCIDENTAL DAMAGES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS OR LOSS OR DAMAGE TO DATA ARISING OUT OF THE USE OR INABILITY TO USE THE DESIGNS, EVEN IF CISCO OR ITS SUPPLIERS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE DESIGNS ARE SUBJECT TO CHANGE WITHOUT NOTICE. USERS ARE SOLELY RESPONSIBLE FOR THEIR APPLICATION OF THE DESIGNS. THE DESIGNS DO NOT CONSTITUTE THE TECHNICAL OR OTHER PROFESSIONAL ADVICE OF CISCO, ITS SUPPLIERS OR PARTNERS. SHOULD CONSULT THEIR OWN TECHNICAL ADVISORS BEFORE IMPLEMENTING THE DESIGNS. RESULTS MAY VARY DEPENDING ON FACTORS NOT TESTED BY CISCO.

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2013 Cisco Systems, Inc. All rights reserved.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

B-0000185-1 01/14