



INDEX

Symbols

* (asterisk)

first operational port [6-21](#)

Numerics

12-port 4-Gbps switching modules

BB_credit buffers [4-13](#)

configuration guidelines [3-18](#)

default settings [3-40](#)

See also switching modules

16-port switching modules

configuring BB_credits [4-1](#)

LEDs [2-16](#)

See also switching modules

24-port 4-Gbps switching modules

bandwidth fairness [3-32](#)

configuration guidelines [3-17](#)

default settings [3-40](#)

example configurations [3-37, 3-39, 4-12](#)

oversubscription [3-26](#)

shared resources [3-9](#)

See also switching modules

24-port 8-Gbps switching modules

default settings [3-41](#)

example configurations [4-8](#)

32-port switching modules

configuring BB_credits [4-1](#)

See also switching modules

4/44-port 8-Gbps switching modules

default settings [3-41](#)

example configurations [4-9](#)

48-port 4-Gbps switching modules

bandwidth fairness [3-32](#)

configuration guidelines [3-17](#)

default settings [3-40](#)

example configurations [3-38, 3-39, 4-10](#)

oversubscription [3-26](#)

shared resources [3-9](#)

See also switching modules

48-port 8-Gbps switching modules

default settings [3-41](#)

example configurations [3-36, 4-7](#)

See also switching modules

4-port 10-Gbps switching modules

BB_credit buffers [4-15](#)

configuration guidelines [3-18](#)

default settings [3-40](#)

See also switching modules

A

ACL adjacency sharing

disabling for downgrading [3-35](#)

administrative speeds

configuring [2-14](#)

administrative states

description [2-8](#)

setting [2-12](#)

ALPA caches

allocation [2-31](#)

clearing [2-32](#)

description [2-30](#)

displaying contents [2-32](#)

inserting entries manually [2-32](#)

Send documentation comments to mdsfeedback-doc@cisco.com

auto mode

configuring [2-13](#)

auto port mode

description [2-7](#)

interface configuration [2-3](#)

autosensing speed

Generation 2 switching modules [2-15](#)

B

bandwidth fairness

disabling [3-33](#)

enabling [3-32](#)

Generation 2 switching modules [3-32](#)

BB_credit buffers

12-port 4-Gbps switching module allocations [4-13](#)

12-port 4-Gbps switching module
considerations [4-14](#)

24-port 4-Gbps switching module allocations [4-12](#)

24-port 4-Gbps switching module
considerations [4-12, 4-13](#)

24-port 8-Gbps switching module considerations [4-8](#)

4/44-port 8-Gbps switching module
considerations [4-9](#)

48-port 4-Gbps switching module
considerations [4-10](#)

48-port 8-Gbps switching module considerations [4-7](#)

4-port 10-Gbps switching module allocations [4-15](#)

4-port 10-Gbps switching module
considerations [4-15, 4-16, 4-17](#)

allocation defaults (table) [4-7, 4-8, 4-9, 4-10](#)

BB_credits

configuring [4-2](#)

description [4-1](#)

reason codes [2-9](#)

BB_SC

enabling [4-21](#)

beacon modes

configuring [2-17](#)

identifying LEDs [2-16](#)

bit errors

reasons [2-18](#)

bit error thresholds

configuring [2-17](#)

description [2-17](#)

B port mode

description [2-7](#)

interface modes [2-7](#)

bridge port mode. See B port mode

buffer pools

Generation 2 switching modules [4-3](#)

buffer-to-buffer credits. See BB_credits

buffer-to-buffer start change. See BB_SC

C

Cisco MDS 9216i switches

configuring extended BB_credits [4-19](#)

configuring NPV [7-9](#)

D

dedicated rate mode

description [3-6](#)

migrating from shared rate mode [3-16, 3-17](#)

migrating to shared rate mode [3-16, 3-17](#)

destination IDs

exchange based [6-5](#)

flow based [6-4](#)

domain IDs

assignment failures [2-10](#)

domain manager

isolation [2-10](#)

downgrading

disabling ACL adjacency sharing [3-35](#)

dynamic bandwidth management

description [3-8](#)

Send documentation comments to mdsfeedback-doc@cisco.com

E

EISLs

PortChannel links [6-2](#)

enhanced ISLs. See EISLs

E port mode

classes of service [2-4](#)

description [2-4](#)

E ports

32-port guidelines [2-2](#)

32-port switching module configuration guidelines [6-8](#)

configuring [2-13](#)

isolation [2-10](#)

exchange link parameter. See ELP

expansion port mode. See E port mode

extended BB_credits

configuring [4-20](#)

displaying information [4-22](#)

Generation 2 switching modules [4-18](#)

licensing [4-18](#)

F

fabric loop port mode. See FL port mode

fabric port mode. See F port mode

fcdomains

overlap isolation [2-10](#)

Fiber Channel interfaces

configuring system default port mode f [2-13](#)

Fibre Channel interface

default settings [2-49](#)

Fibre Channel interfaces

administrative states [2-8](#)

BB_credits [4-1](#)

characteristics [2-2 to 2-12](#)

configuring [2-11](#)

configuring auto port mode [2-13](#)

configuring beacon modes [2-17](#)

configuring bit error thresholds [2-17](#)

configuring descriptions [2-15](#)

configuring frame encapsulation [2-16](#)

configuring port modes [2-13](#)

configuring receive data field sizes [4-22](#)

configuring speeds [2-14](#)

deleting from PortChannels [6-15](#)

disabling [2-12](#)

displaying capabilities on Generation 2 switching modules [3-15](#)

displaying information [2-20 to 2-27](#)

enabling [2-12](#)

graceful shutdown [2-12](#)

modes [2-3 to 2-7](#)

operational states [2-8](#)

performance buffers [4-3](#)

reason codes [2-8](#)

states [2-7](#)

taking out of service on Generation 2 switching modules [3-33](#)

troubleshooting operational states [2-9](#)

See also interfaces [2-7](#)

FL port mode

classes of service [2-5](#)

description [2-5](#)

FL ports

configuring [2-13](#)

description [2-5](#)

nonparticipating code [2-10](#)

See also Fx ports

F port mode

classes of service [2-5](#)

description [2-5](#)

F ports

configuring [2-13](#)

description [2-5](#)

See also Fx ports

frame encapsulation

configuring [2-16](#)

Send documentation comments to mdsfeedback-doc@cisco.com

Fx ports

- 32-port default [2-3](#)
- configuring [2-13](#)
- description [2-7](#)
- interface modes [2-7](#)
- See also F ports; FL ports [2-7](#)

G

Generation 1 switching modules

- extended BB_credits [4-18](#)
- port index allocations [3-10](#)

Generation 2 switching modules

- buffer groups [4-3 to ??](#)
- configuring [3-14 to 4-21](#)
- configuring port speeds [3-19](#)
- configuring rate modes [3-21](#)
- default settings [3-40](#)
- description [3-1 to 3-3](#)
- disabling ACL adjacency sharing [3-35](#)
- displaying port resources [3-34](#)
- dynamic bandwidth management [3-8](#)
- example configurations [3-36 to 3-40](#)
- extended BB_credits [4-18, 4-19](#)
- interface capabilities [3-15](#)
- out-of-service interfaces [3-8](#)
- port groups [3-3](#)
- port index allocations [3-10](#)
- port rate modes [3-4](#)
- recovering from powered-down state [3-12](#)
- releasing shared resources [3-34](#)
- taking interfaces out of service [3-33](#)

Generation 3 switching modules

- default settings [3-41](#)

I

interfaces

- adding to PortChannels [6-13, 6-14](#)
- configuring descriptions [2-15](#)
- default settings [2-49](#)
- deleting from PortChannels [6-15](#)
- displaying information [2-20 to 2-27](#)
- displaying SFP information [2-26](#)
- forced addition to PortChannels [6-14](#)
- isolated states [6-13](#)
- suspended states [6-13](#)

IPv4 default gateways

- configuring mgmt0 interfaces [2-46](#)

ISLs

- PortChannel links [6-2](#)

L

LEDs

- beacon mode states [2-16](#)
- speed [2-17](#)

licenses

- extended BB_credits [4-18](#)

load balancing

- description [6-4](#)
- PortChannels [6-2](#)

M

management interfaces

- configuring [2-46, 2-47](#)
- default settings [2-49](#)
- displaying information [2-47](#)
- features [2-46](#)

mgmt0 interfaces

- configuring [2-46, 2-47](#)
- default settings [2-49](#)
- features [2-46](#)

MPS-14/2 modules

- configuring extended BB_credits [4-19](#)

Send documentation comments to mdsfeedback-doc@cisco.com

N

NL ports

interface modes [2-7](#)

nonparticipating codes

description [2-10](#)

NPIV

description [7-1](#)

enabling [7-2](#)

NP links [7-5](#)

N port identifier virtualization. See NPIV

NL ports

See also Nx ports

NP-ports [7-5](#)

NPV, configuring [7-9](#)

NPV mode [7-4](#)

O

operational states

configuring on Fibre Channel interfaces [2-13](#)

description [2-8](#)

out-of-service interfaces

description [3-8](#)

oversubscription

disabling restrictions [3-28](#)

enabling restrictions [3-31](#)

Generation 2 switching modules [3-26](#)

ratios [3-26](#)

P

performance buffers

configuring [4-3](#)

description [4-3](#)

PortChannel modes

description [6-6](#)

PortChannel Protocol

autocreation [6-18](#)

configuring autocreation [6-18](#)

converting autocreated groups to manually configured [6-19](#)

creating channel group [6-16](#)

description [6-15](#)

enabling autocreation [6-18](#)

PortChannels

adding interfaces [6-13, 6-14](#)

administratively down [2-10](#)

comparison with trunking [6-3](#)

compatibility checks [6-13](#)

configuration guidelines [6-10](#)

configuring [6-9 to 6-11](#)

creating [6-11](#)

default settings [6-25](#)

deleting [6-12](#)

deleting interfaces [6-15](#)

description [6-1](#)

examples [6-2](#)

forcing interface additions [6-14](#)

Generation 2 switching module interfaces [3-12](#)

interface states [6-13](#)

load balancing [6-4](#)

misconfiguration error detection [6-11](#)

verifying configurations [6-21 to 6-24](#)

port groups

assigning extended BB_credits [4-19](#)

description [3-3](#)

Generation 2 Fibre Channel switching modules [3-3](#)

Generation 3 Fibre Channel switching modules [3-7](#)

port indexes

description [3-10](#)

port modes

auto [2-7](#)

description [2-3 to 2-7](#)

port rate modes

configuring [3-21](#)

dedicated [3-6](#)

description [3-4](#)

Send documentation comments to mdsfeedback-doc@cisco.com

oversubscribed [3-7](#)

shared [3-7](#)

See also rate modes

port speeds

configuring [2-14](#)

configuring on Generation 2 switching module
interfaces [3-19](#)

displaying configuration [3-20](#)

private devices

TL ports [2-31](#)

R

rate modes

configuring on Generation 2 switching module
interfaces [3-21](#)

verifying configuration [3-21](#)

See also port rate modes

reason codes

description [2-8](#)

receive buffer groups. See buffer groups

receive data field sizes

configuring [4-22](#)

recovery

from powered-down state [3-12](#)

S

SD port mode

description [2-6](#)

interface modes [2-6](#)

SD ports

configuring [2-13](#)

SFPs

displaying transmitter types [2-26](#)

transmitter types [2-19](#)

shared rate mode

description [3-7](#)

migrating from dedicated rate mode [3-16, 3-17](#)

migrating to dedicated rate mode [3-16, 3-17](#)

oversubscription [3-26](#)

source IDs

exchange based [6-5](#)

flow based [6-4](#)

SPAN destination port mode. See SD port mode

SPAN tunnel port mode. See ST port mode

ST port mode

description [2-7](#)

interface modes [2-7](#)

limitations [2-7](#)

ST ports

interface modes [2-7](#)

subnet masks

configuring mgmt0 interfaces [2-46](#)

switch ports

configuring attribute default values [2-18](#)

T

TE port mode

classes of service [2-6](#)

description [2-6](#)

TE ports

trunking restrictions [5-3](#)

TF port mode

classes of service [2-6](#)

description [2-6](#)

TL port mode

classes of service [2-5](#)

description [2-5](#)

TL ports

ALPA caches [2-30](#)

configuring [2-13, 2-30](#)

description [2-28](#)

displaying information [2-31](#)

private devices [2-31](#)

virtual devices [2-31](#)

translative loop port mode. See TL port mode

Send documentation comments to mdsfeedback-doc@cisco.com

trunk-allowed VSAN lists

description [5-9 to 5-12](#)

trunking

comparison with PortChannels [6-3](#)

configuration guidelines [5-4](#)

configuring modes [5-8](#)

default settings [5-14](#)

description [5-1](#)

displaying information [5-13](#)

link state [5-8](#)

merging traffic [5-4](#)

restrictions [5-3](#)

trunking E port mode. See TE port mode

trunking F port mode. See TF port mode

trunking protocol

default settings [5-14](#)

default state [5-7](#)

description [5-7](#)

detecting port isolation [5-4](#)

disabling [5-8](#)

enabling [5-8](#)

trunk mode

administrative default [2-19](#)

configuring [5-8, 5-9](#)

default settings [5-14](#)

status [5-9](#)

trunk ports

displaying information [5-14](#)

description [2-48](#)

displaying information [2-49](#)

VSANs

allowed-active [5-4](#)

configuring allowed-active lists [5-12](#)

loop devices [2-31](#)

mismatches [2-10](#)

TE port mode [2-6](#)

TF port mode [2-6](#)

trunk-allowed [5-4](#)

VSAN trunking. See trunking

W

WWNs

suspended connections [2-10](#)

Z

zones

merge failures [2-10](#)

V

virtual devices

TL ports [2-31](#)

VSAN IDs

allowed list [5-14](#)

multiplexing traffic [2-6](#)

VSAN interfaces

configuring [2-48](#)

creating [2-48](#)

Send documentation comments to mdsfeedback-doc@cisco.com