



0 Commands

This chapter describes the Cisco Nexus 1000V commands that begin with the letter O.

option exporter-stats timeout

To specify a timeout period for resending NetFlow flow exporter data, use the **option exporter-stats timeout** command. To remove the timeout period, use the **no** form of this command.

option exporter-stats timeout *time*

no option exporter-stats timeout

Syntax Description	<i>time</i>	A time period between 1 and 86400 seconds.
---------------------------	-------------	--

Defaults	None
-----------------	------

Command Modes	Netflow Flow Exporter Version 9 Configuration (config-flow-exporter-version-9)
----------------------	---

Supported User Roles	network-admin
-----------------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines	
-------------------------	--

Examples	This example shows how to configure a 3600-second timeout period for resending NetFlow flow exporter data:
-----------------	--

Send document comments to nexus1k-docfeedback@cisco.com.

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# option exporter-stats timeout 3600
```

This example shows how to remove the timeout period for resending NetFlow flow exporter data:

```
n1000v# config t
n1000v(config)# flow exporter ExportTest
n1000v(config-flow-exporter)# version 9
n1000v(config-flow-exporter-version-9)# no option exporter-stats timeout
n1000v(config-flow-exporter)#
```

Related Commands

Command	Description
version 9	Designates NetFlow export version 9 in the NetFlow exporter.
option interface-table timeout	Specifies a timeout resend period for the NetFlow flow exporter interface table.
template data timeout	Specifies a timeout resend period for NetFlow flow exporter template data.
flow exporter	Creates a Flexible NetFlow flow exporter.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.

Send document comments to nexus1k-docfeedback@cisco.com.

option interface-table timeout

To specify the timeout period for resending the NetFlow flow exporter interface table, use the **option interface-table timeout** command. To remove the timeout period, use the **no** form of this command.

option interface-table timeout *time*

no option interface-table timeout

Syntax Description	<i>time</i>	A time period between 1 and 86400 seconds.
--------------------	-------------	--

Defaults	None
----------	------

Command Modes	Netflow Flow Exporter Version 9 Configuration (config-flow-exporter-version-9)
---------------	---

Supported User Roles	network-admin
----------------------	---------------

Command History	Release	Modification
	4.0(4)SV1(1)	This command was introduced.

Usage Guidelines

Examples	This example shows how to configure a 3600 second timeout period for resending the NetFlow flow exporter interface table: <pre>n1000v# config t n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# version 9 n1000v(config-flow-exporter-version-9)# option exporter-stats timeout 3600</pre>
	This example shows how to remove the timeout period for resending the NetFlow flow exporter interface table: <pre>n1000v# config t n1000v(config)# flow exporter ExportTest n1000v(config-flow-exporter)# version 9 n1000v(config-flow-exporter-version-9)# no option exporter-stats timeout n1000v(config-flow-exporter)#</pre>

Related Commands	Command	Description
	version 9	Designates NetFlow export version 9 in the NetFlow exporter.

Send document comments to nexus1k-docfeedback@cisco.com.

Command	Description
option exporter-stats timeout	Specifies a timeout resend period for NetFlow flow exporter data.
template data timeout	Specifies a timeout resend period for NetFlow flow exporter template data.
flow exporter	Creates a Flexible NetFlow flow exporter.
flow record	Creates a Flexible NetFlow flow record.
flow monitor	Creates a Flexible NetFlow flow monitor.
show flow exporter	Displays information about the NetFlow flow exporter.
show flow record	Displays information about NetFlow flow records.
show flow monitor	Displays information about the NetFlow flow monitor.