



D Commands

This chapter describes the system management commands that begin with D.

diagnostic bootup level

To configure the bootup diagnostic level to trigger diagnostics when the device boots, use the **diagnostic bootup level** command. To remove bootup diagnostic level configuration, use the **no** form of this command.

diagnostic bootup level {bypass | complete}

no diagnostic bootup level {bypass | complete}

Syntax Description	bypass	Specifies that all bootup tests are skipped.
	complete	Specifies that all bootup diagnostics are performed. This is the default value.

Command Default	Complete
------------------------	----------

Command Modes	Global configuration mode
----------------------	---------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Examples This example shows how to configure the bootup diagnostics level to trigger the complete diagnostics:

```
switch(config)# diagnostic bootup level complete
switch(config)#
```

This example shows how to remove the bootup diagnostics level configuration:

```
switch(config)# no diagnostic bootup level complete
switch(config)#
```

Related Commands	Command	Description
	show diagnostic bootup level	Displays the bootup diagnostics level.
	show diagnostic bootup result	Displays the results of the diagnostics tests.

description (SPAN, ERSPAN)

To add a description to an Ethernet Switched Port Analyzer (SPAN) or an Encapsulated Remote Switched Port Analyzer (ERSPAN) session configuration, use the **description** command. To remove the description, use the **no** form of this command.

description *description*

no description

Syntax Description

<i>description</i>	String description of the SPAN session configuration. This string is limited to 80 characters.
--------------------	--

Command Default

No description is added.

Command Modes

SPAN session configuration mode
ERSPAN session configuration mode

Command History

Release	Modification
5.2(1)N1(1)	This command was introduced.

Usage Guidelines

Use the **description** command to provide a reminder in the configuration to describe what certain SPAN sessions are used for. The description appears in the output of the following commands such as **show monitor session** and **show running-config monitor**.

Examples

This example shows how to add a description for a SPAN session:

```
switch# configure terminal
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)#
```

This example shows how to add a description for an ERSPAN session:

```
switch# configure terminal
switch(config)# monitor session 9 type erspan-source
switch(config-erspan-src)# description An ERSPAN session
switch(config-erspan-src)#
```

Related Commands

Command	Description
destination (SPAN session)	Configures a destination SPAN port.
monitor session	Creates a new SPAN session configuration.

Command	Description
show monitor session	Displays SPAN session configuration information.
show running-config monitor	Displays the running configuration information of a SPAN session.
source (SPAN session)	Configures a source SPAN port.

destination (ERSPAN)

To configure an Encapsulated Remote Switched Port Analyzer (ERSPAN) destination IP address, use the **destination** command. To remove the destination ERSPAN IP address, use the **no** form of this command.

destination ip *ip_address*

no destination ip *ip_address*

Syntax Description	ip	Configures the remote IP address.
	<i>ip_address</i>	IPv4 address in the format <i>A.B.C.D</i> .

Command Default	None
------------------------	------

Command Modes	ERSPAN session configuration mode
----------------------	-----------------------------------

Command History	Release	Modification
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines	You can configure only one destination IP address for an ERSPAN source session. This command does not require a license.
-------------------------	--

Examples	This example shows how to configure an ERSPAN destination IP address:
-----------------	---

```
switch# configure terminal
switch(config)# monitor session 1 type erspan-source
switch(config-erspan-src)# destination ip 192.0.3.1
switch(config-erspan-src)#
```

Related Commands	Command	Description
	monitor session	Creates a new SPAN session configuration.
	show monitor session	Displays SPAN session configuration information.
	show running-config monitor	Displays the running configuration information of a SPAN session.
	source (SPAN session)	Configures a source SPAN port.
	source (ERSPAN session)	Configures a source VLAN or VSAN interface.

destination (SPAN session)

To configure a Switched Port Analyzer (SPAN) destination port, use the **destination** command. To remove the destination SPAN port, use the **no** form of this command.

destination interface {**ethernet** *slot*[/*QSFP-module*]/*port*}

no source interface {**ethernet** *slot*[/*QSFP-module*]/*port*}

Syntax Description	interface	Specifies the interface type to use as the destination SPAN port.
	ethernet <i>slot</i> [/ <i>QSFP-module</i>]/ <i>port</i>	Specifies the Ethernet interface to use as the destination SPAN port. The slot number is from 1 to 255. The <i>QSFP-module</i> number is from 1 to 4. The port number is from 1 to 128.
	Note	The <i>QSFP-module</i> number applies only to the QSFP+ Generic Expansion Module (GEM).

Command Default None

Command Modes SPAN session configuration mode

Command History	Release	Modification
	6.0(2)N1(2)	Support for the QSFP+ GEM was added.
	5.2(1)N1(1)	This command was introduced.

Usage Guidelines Each local SPAN session destination session must have a destination port (also called a *monitoring port*) that receives a copy of traffic from the source port.

The destination port can be any Ethernet physical port and must reside on the same switch as the source port (for a local SPAN session). The destination port cannot be a source port, a port channel, or SAN port channel group.

A destination port receives copies of sent and received traffic for all monitored source ports. If a destination port is oversubscribed, it can become congested. This congestion can affect traffic forwarding on one or more of the source ports.

Examples This example shows how to configure an Ethernet interface SPAN destination port and activate the SPAN session:

```
switch# configure terminal
switch(config)# interface ethernet 1/5
switch(config-if)# switchport monitor
switch(config-if)# exit
switch(config)# monitor session 9 type local
switch(config-monitor)# description A Local SPAN session
switch(config-monitor)# source interface ethernet 1/1
```

```
switch(config-monitor)# destination interface ethernet 1/5
switch(config-monitor)# no shutdown
switch(config-monitor)#
```

Related Commands

Command	Description
source (SPAN session)	Configures a source SPAN port.
monitor session	Creates a new SPAN session configuration.
show monitor session	Displays SPAN session configuration information.
show running-config monitor	Displays the running configuration information of a SPAN session.

■ destination (SPAN session)