

## **B** Commands

This chapter describes the Cisco NX-OS Border Gateway Protocol (BGP) commands that begin with B.

## bestpath (BGP)

To change the default best-path selection algorithm, use the **bestpath** command. To return the Border Gateway Protocol (BGP) routing process to the default operation, use the **no** form of this command.

bestpath {always-compare-med | compare-routerid | {med {missing-as-worst | non-deterministic}}

no bestpath {always-compare-med | compare-routerid | {med {missing-as-worst | non-deterministic}}

Syntax Description	always-compare-med	Compares the Multi-Exit Discriminator (MED) on paths from a different autonomous system (AS).	
	compare-routerid	Configures a Border Gateway Protocol (BGP) routing process to compare identical routes received from different external peers during the best path selection process and to select the route with the lowest router ID as the best path.	
	med missing-as-worst	Assigns the value of infinity to received routes that do not carry the MED attribute, making these routes the least desirable.	
	med non-deterministic	Specifies that the best-MED path among paths is not picked from the same AS.	
Command Default	The default settings are as follows: med missing-as-worst: A value of 0 is assigned to the missing MED med non-deterministic: Disabled		
Command Modes	Router configuration mode		
Command History	Release	Modification	
	5.2(1)N1(1)	This command was introduced.	
Usage Guidelines	Before you use this command, ensure that BGP is enabled on the switch by using the <b>feature bgp</b> command.		
	To enable the comparison of the MED for paths from neighbors in different autonomous systems, use the <b>bgp always-compare-med</b> command.		
	This command requires the LAN Enterprise Services license.		
Examples	This example shows how to change the default best-path selection algorithm to compare the MED on paths from different autonomous systems:		
	switch(config)# <b>router bgp 64496</b> switch(config-router)# <b>bestpath always-compare-med</b>		

switch(config-router)#

**Related Commands** 

nds	Command	Description
	feature bgp	Enables BGP globally.
	show ip bgp	Displays information about BGP routes.