

Confidential

Show Commands

This chapter describes the Cisco NX-OS MSDP **show** commands.

show ip msdp count

To display information about Multicast Source Discovery Protocol (MSDP) counts, use the **show ip msdp count** command.

show ip msdp count [asn] [vrf {vrf-name | all}]

Syntax Description

asn	(Optional) Autonomous system (AS) number.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display MSDP counts:

switch(config)# show ip msdp count

show ip msdp event-history

To display information in the Multicast Source Discovery Protocol (MSDP) event history buffers, use the **show ip msdp event-history** command.

show ip msdp event-history {errors | msgs | statistics}

_	_	
Syntax	D	
NNTAY	HIDER	rintion

errors	Displays events of type error.
msgs	Displays events of type msg.
statistics	Displays events of type statistics.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Examples

This example shows how to display information in the MSDP msgs event history buffer:

switch(config)# show ip msdp event-history msgs

Command	Description
clear ip msdp event-history	Clears the contents of the MSDP event history buffers.
ip msdp event-history	Configures the size of MSDP event history buffers.

show ip msdp mesh-group

To display information about Multicast Source Discovery Protocol (MSDP) mesh groups, use the **show ip msdp mesh-group** command.

show ip msdp mesh-group [mesh-group] [vrf {vrf-name | all}]

Syntax Description

mesh-group	(Optional) Mesh group name.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display information about MSDP mesh groups:

switch(config)# show ip msdp mesh-group

show ip msdp peer

To display information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp peer** command.

show ip msdp peer [peer-address] [vrf {vrf-name | all}]

Syntax Description

peer-address	(Optional) IP address of an MSDP peer.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display information about MSDP peers:

switch(config)# show ip msdp peer

show ip msdp policy statistics sa-policy

To display information about Multicast Source Discovery Protocol (MSDP) Source-Active (SA) policies, use the **show ip msdp policy statistics sa-policy** command.

show ip msdp policy statistics sa-policy peer-address {in | out} [vrf {vrf-name}]

Syntax Description

peer-address	IP address of the MSDP peer for the SA policy.	
in	Specifies the input policy.	
out	Specifies the output policy.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display information about MSDP SA policies:

switch(config) # show ip msdp policy statistics sa-policy 192.168.1.10 in

show ip msdp route

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp route** command.

show ip msdp route [{source [group]} | {group [source]}] [asn] [**peer** peer] [**detail**] [**vrf** {vrf-name | all}]

Syntax Description

source	Source address for SA cache information.	
group	(Optional) Group address for SA cache information.	
asn	(Optional) Autonomous system (AS) number.	
peer peer	(Optional) Specifies the IP address of a peer.	
detail	(Optional) Displays detailed information.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

The **show ip msdp sa-cache** command is an alternative form of this command.

This command requires the LAN Base Services license.

Examples

This example shows how to display information about the MSDP SA cache:

switch(config) # show ip msdp route

Command	Description
clear ip msdp route	Clears routes in the MSDP Source-Active cache.
show ip msdp sa-cache	Displays information about the MSDP SA cache.

show ip msdp rpf

To display information about the Multicast Source Discovery Protocol (MSDP) next-hop autonomous system (AS) on the Border Gateway Protocol (BGP) path to a rendezvous point (RP) address, use the **show ip msdp rpf** command.

show ip msdp rpf rp-address [vrf {vrf-name all}]

Syntax Description

rp-address	IP address of the RP.		
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.		
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.		
all	Specifies all VRFs.		

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display information about MSDP reverse path forwarding (RPF) peers: switch(config)# show ip msdp rpf 192.168.1.10

show ip msdp sa-cache

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) cache, use the **show ip msdp sa-cache** command.

show ip msdp sa-cache [{source [group]} | {group [source]}] [asn] [peer peer] [detail] [vrf
{vrf-name | all}]

Syntax Description

source	Source address for SA cache information.	
group	(Optional) Group address for SA cache information.	
asn	(Optional) Autonomous system (AS) number.	
peer peer	(Optional) Specifies the IP address of a peer.	
detail	(Optional) Displays detailed information.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

The **show ip msdp route** command is an alternative form of this command.

This command requires the LAN Base Services license.

Examples

This example shows how to display information about the MSDP SA cache:

switch(config) # show ip msdp sa-cache

Command	Description
clear ip msdp sa-cache	Clears routes in the MSDP Source-Active cache.
show ip msdp route	Displays information about the MSDP SA cache.

show ip msdp route

To display information about the Multicast Source Discovery Protocol (MSDP) Source-Active (SA) route cache, use the **show ip msdp route** command.

show ip msdp route [{source [group]} | {group [source]}] [asn] [**peer** peer] [**detail**] [**vrf** {vrf-name | all}]

Syntax Description

source	Source address for SA cache information.	
group	(Optional) Group address for SA cache information.	
asn	(Optional) Autonomous system (AS) number.	
peer peer	(Optional) Specifies the IP address of a peer.	
detail	(Optional) Displays detailed information.	
vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.	
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.	
all	Specifies all VRFs.	

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

The **show ip msdp route** command is an alternative form of this command.

This command requires the LAN Base Services license.

Examples

This example shows how to display information about the MSDP SA cache:

switch(config)# show ip msdp sa-cache

Command	Description
clear ip msdp sa-cache	Clears routes in the MSDP Source-Active cache.
show ip msdp route	Displays information about the MSDP SA cache.

show ip msdp sources

To display information about Multicast Source Discovery Protocol (MSDP) learned sources, use the **show ip msdp sources** command.

show ip msdp sources [vrf {vrf-name | all}]

•		_	
.51	/ntax	Descri	intion

vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
all	Specifies all VRFs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display information about MSDP learned sources:

switch(config) # show ip msdp sources

show ip msdp summary

To display summary information about Multicast Source Discovery Protocol (MSDP) peers, use the **show ip msdp summary** command.

show ip msdp summary [vrf {vrf-name | all}]

•		
Syntax	Descri	ption

vrf	(Optional) Applies to a virtual routing and forwarding (VRF) instance.
vrf-name	VRF name. The name can be a maximum of 32 alphanumeric characters and is case sensitive.
all	Specifies all VRFs.

Command Default

None

Command Modes

Any command mode

Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

Usage Guidelines

This command requires the LAN Base Services license.

Examples

This example shows how to display summary information about MSDP peers:

switch(config)# show ip msdp summary

show running-config msdp

To display information about the running-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show running-config msdp** command.

show running-config msdp [all]

Syntax Description	all	(Optional) Displays configured and default information.	
--------------------	-----	---	--

Command Default None

Command Modes Any command mode

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

Usage Guidelines This command requires the LAN Base Services license.

Examples

This example shows how to display information about the MSDP running-system configuration:

Need new output1

```
switch(config) # show running-config msdp
!Command: show running-config msdp
!Time: Sat Apr 12 09:14:49 2008
version 5.0(3)N1(1)
feature msdp
switch(config) #
```

show startup-config msdp

To display information about the startup-system configuration for Multicast Source Discovery Protocol (MSDP), use the **show startup-config msdp** command.

show startup-config msdp [all]

Syntax Description	all (Optional) Displays configured and default information.	
Command Default	None		
Command Modes	Any command mod	le	
Command History	Release	Modification	
	6.0(2)N1(1)	This command was introduced.	
Usage Guidelines	This command requ	tires the LAN Base Services license.	
Examples	This example shows how to display information about the startup-system configuration for MSDP:		

switch(config) # show startup-config msdp