



## C Commands

---

This chapter describes the system management commands that begin with C.

# clear logging logfile

To clears the contents of the log file, use the **clear logging logfile** command.

## clear logging logfile

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)N1(1)	This command was introduced.

<b>Examples</b>	This example shows how to clear the logging logfile:
-----------------	--

```
switch# clear logging logfile
switch#
```

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show logging logfile	Displays the messages in the log file.

# clear logging nvram

To clear the NVRAM logs, use the **clear logging nvram** command.

**clear logging nvram**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	Release	Modification
	6.0(2)N1(1)	This command was introduced.

<b>Examples</b>	<p>This example shows how to clear the NVRAM logs:</p> <pre>switch# clear logging nvram</pre>
-----------------	---

<b>Related Commands</b>	Command	Description
	show logging nvram	Displays the NVRAM logs.

# clear logging onboard

To clear the onboard failure logging (OBFL) entries in the persistent log, use the **clear logging onboard** command.

**clear logging onboard** [**environmental-history**] [**exception-log**] [**obfl-log**] [**stack-trace**]

## Syntax Description

<b>environmental-history</b>	(Optional) Clears the OBFL environmental history.
<b>exception-log</b>	(Optional) Clears the OBFL exception log entries.
<b>obfl-log</b>	(Optional) Clears the OBFL (boot-uptime/device-version/obfl-history).
<b>stack-trace</b>	(Optional) Clears the OBFL stack trace entries.

## Command Default

None

## Command Modes

EXEC mode

## Command History

Release	Modification
6.0(2)N1(1)	This command was introduced.

## Examples

This example shows how to clear the OBFL environmental history entries:

```
switch# clear logging onboard environmental-history
```

This example shows how to clear the OBFL exception-log entries:

```
switch# clear logging onboard exception-log
```

This example shows how to clear the OBFL (boot-uptime/device-version/obfl-history) entries:

```
switch# clear logging onboard obfl-log
```

This example shows how to clear the OBFL stack trace entries:

```
switch# clear logging onboard stack-trace
```

## Related Commands

Command	Description
<b>show logging onboard</b>	Displays onboard failure logs.

# clear logging session

To clear the current logging session, use the **clear logging session** command.

**clear logging session**

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)N1(1)	This command was introduced.

<b>Examples</b>	<p>This example shows how to clear the current logging session:</p> <pre>switch# <b>clear logging session</b></pre>
-----------------	---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>show logging session</b>	Displays the logging session status.

# clear ntp session

To clear the Network Time Protocol (NTP) session, use the **clear ntp session** command.

**clear ntp session**

---

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

---

<b>Command Default</b>	None
------------------------	------

---

<b>Command Modes</b>	EXEC mode
----------------------	-----------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)N1(1)	This command was introduced.

---

---

<b>Examples</b>	This example shows how to discard the NTP Cisco Fabric Services (CFS) distribution session in progress:
-----------------	---

```
switch# clear ntp session
```

---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	show ntp	Displays NTP information.

---

# clear ntp statistics

To clear the Network Time Protocol (NTP) session, use the **clear ntp statistics** command.

**clear ntp statistics {all-peers | io | local | memory}**

Syntax Description	<b>all-peers</b>	Clears all peer transaction statistics.
	<b>io</b>	Clears I/O statistics.
	<b>local</b>	Clears local statistics.
	<b>memory</b>	Clears memory statistics.

<b>Command Default</b>	None
------------------------	------

<b>Command Modes</b>	EXEC mode
----------------------	-----------

Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.

<b>Examples</b>	<p>This example shows how to discard the NTP I/O statistics:</p> <pre>switch# clear ntp statistics io</pre>
-----------------	---

Related Commands	Command	Description
	<b>show ntp</b>	Displays NTP information.

# commit (session)

To commit the current configuration session, use the **commit** command.

**commit**

---

<b>Syntax Description</b>	This command has no arguments or keywords.
---------------------------	--

---

<b>Command Default</b>	None
------------------------	------

---

<b>Command Modes</b>	Session configuration mode
----------------------	----------------------------

---

<b>Command History</b>	<b>Release</b>	<b>Modification</b>
	6.0(2)N1(1)	This command was introduced.

---

---

<b>Examples</b>	This example shows how to commit the current session:
-----------------	---

```
switch(config-s)# commit
switch(config-s)#
```

---

<b>Related Commands</b>	<b>Command</b>	<b>Description</b>
	<b>configure session</b>	Creates a configuration session.
	<b>show configuration session</b>	Displays the contents of the session.
	<b>verify</b>	Verifies a session.

---