

C Commands

This chapter describes the Cisco NX-OS Open Shortest Path First (OSPF) commands that begin with C.

clear ip ospf neighbor

To clear neighbor statistics and reset adjacencies for Open Shortest Path First (OSPF), use the **clear ip ospf neighbor** command.

clear ip ospf [instance-tag] neighbor {* | neighbor-id | interface-type number | loopback number | port-channel number } [vrf vrf-name]

Syntax Description	instance-tag	(Optional) Instance tag. Specify as an alphanumeric string of up to 20 characters.	
	*	Clears all neighbors.	
	neighbor-id	Neighbor ID (as an IP address) of the neighbor to clear.	
	interface-type number	Interface from which to clear all neighbors.	
	loopback number	Clears all neighbors on a loopback interface.	
	port-channel number	nel number Clears all neighbors on a port-channel interface.	
	vrf vrf-name	(Optional) Specifies the name of the OSPF virtual routing and forwarding (VRF) instance. The <i>vrf-name</i> argument can be any alphanumeric string of up to 32 characters, except "default" and "all".	
Command Default	None		
Command Modes	Any command mode		
Command History	Release	Modification	
	6.0(2)N1(1)	This command was introduced.	
Usage Guidelines	command. Use the <i>instance-tag</i> argument to clear the neighbor details from one OSPF instance. do not use the <i>instance-tag</i> argument, Cisco Nexus 6000 clears the neighbor details from all OS instances. Use the show ip ospf neighbor command to find the neighbor ID.		
	This command require	s the LAN Base Services license.	
Examples	This example shows how to clear all OSPF neighbor details for neighbor 192.0.2.1 for instance tag 201:		
	switch# clear ip ospf 201 neighbor 192.0.2.1		
	This example shows how to clear all OSPF neighbor details for all OSPF instances:		
	switch# clear ip ospf neighbor *		
	This example shows how to clear all OSPF neighbor details for all neighbors on Ethernet interface 1/2 for OSPF instance 202:		

switch# clear ip ospf 202 neighbor ethernet 1/2

Related Commands

Command Description show ip ospf neighbor Displays details for OSPF neighbors including the neighbor ID.

clear ip ospf policy statistics

To clear policy statistics for Open Shortest Path First (OSPF), use the **clear ip ospf policy statistics** command.

clear ip ospf [*instance-tag*] **policy statistics** {**area** *area-id* **filter-list** {**in** | **out**} | **redistribute** {**bgp** *autonomous-system* | **direct** | **eigrp** *id* | **ospf** *id* | **rip** *id* | **static**} } [**vrf** *vrf-name*]

Syntax Description	instance-tag	(Optional) Instance tag. Specify as an alphanumeric string of up to 20
	-	characters.
	area	Clears policy statistics for an area.
	area-id	Area ID as an integer or IP address.
	filter-list	Specifies the policy statistics for filtered prefixes between OSPF areas.
	in	Filters prefixes sent into this OSPF area.
	out	Filters prefixes sent from this OSPF area.
	redistribution	Clears OSPF route redistribution statistics.
	bgp autonomous-system	Specifies the autonomous system number for the Border Gateway Protocol. Specify the autonomous system number as x.y, where the range is from 1 to 65535 for both x and y, or as a single integer, where the range is from 1 to 65535.
	direct	Specifies directly connected routes.
	eigrp id	Specifies the autonomous system number for the Enhanced Interior Gateway Protocol. Specify the <i>id</i> argument as any case-sensitive, alphanumeric string.
	ospf id	Specifies the Open Shortest Path First version 2 instance. Specify the <i>id</i> argument as any case-sensitive, alphanumeric string.
	rip id	Specifies the Routing Information Protocol instance. Specify the <i>id</i> argument as any case-sensitive, alphanumeric string.
	static	Specifies static routes.
	vrf vrf-name	(Optional) Specifies the name of the OSPF virtual routing and forwarding (VRF) instance. The <i>vrf-name</i> argument can be any alphanumeric string of up to 32 characters, except "default" and "all".
ommand Default	None	
ommand Modes	Any command mode	
command History	Release	Modification
ommanu mistory		

Usage Guidelines	statistics command. Use the <i>instance</i> If you do not specify the instance ta	mand to learn the policy statistics shown in the show ip ospf policy <i>e-tag</i> argument to clear the policy statistics from one OSPF instance. g, Cisco Nexus 6000 clears the policy statistics from all OSPF cy statistics command to to view the statistics that you are clearing. use Services license.		
Examples	This example shows how to clear all OSPF policy statistics for area 99 inbound filtered routes for OSPF 201:			
	switch# clear ip ospf 201 policy statistics area 99 filter-list in			
	This example shows how to clear all OSPF policy statistics for all BGP redistributed routes for OSPF 202:			
	switch# clear ip ospf 202 policy statistics redistribute bgp			
Related Commands	Command	Description		
	show ip ospf policy statistics	Displays details for OSPF policies.		

clear ip ospf redistribution

To clear redistribution information for Open Shortest Path First (OSPF), use the **clear ip ospf redistribution** command.

clear ip ospf redistribution [vrf {vrf-name | all | default | management}]

Related Commands	Command	Description
Examples	This example shows how to clear redistribution information: switch# clear ip ospf redistribution	
Usage Guidelines	This command requires the LAN Base Services license.	
	6.0(2)N1(1)	This command was introduced.
Command History	Release	Modification
Command Modes	Any command mode	
Command Default	None	
	management	(Optional) Specifies the management VRF.
	default	(Optional) Specifies the default VRF.
	all	(Optional) Specifies the "all" VRF instance.
Syntax Description	vrf vrf-name	(Optional) Specifies a particular virtual routing and forwarding (VRF) instance. The VRF name is a case-sensitive, alphanumeric string of up to 32 characters.

Enables the OSPF feature.

feature ospf

clear ip ospf statistics

To clear Open Shortest Path First (OSPF) event statistics, use the clear ip ospf statistics command.

clear ip ospf [instance-tag] statistics [vrf vrf-name]

Syntax Description	instance-tag	(Optional) Instance tag. Specify as an alphanumeric string of up to 20 characters.
	vrf vrf-name	(Optional) Specifies the name of the OSPF virtual routing and forwarding (VRF) instance. The <i>vrf-name</i> argument can be any alphanumeric string of up to 32 characters, except "default" and "all".
Command Default	None	
Command Modes	Any command me	ode
Command History	Release	Modification
	6.0(2)N1(1)	This command was introduced.
Usage Guidelines	Use the clear ip o If you do not spec	This command was introduced. Sepf statistics command to clear the event statistics from one or more OSPF instances cify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears statistics from all OSPF e show ip ospf statistics command to to view the statistics that you are clearing.
Usage Guidelines	Use the clear ip o If you do not spec instances. Use the	ospf statistics command to clear the event statistics from one or more OSPF instances cify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears statistics from all OSPF
Usage Guidelines Examples	Use the clear ip of If you do not speci instances. Use the This command re	ospf statistics command to clear the event statistics from one or more OSPF instances cify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears statistics from all OSPF e show ip ospf statistics command to to view the statistics that you are clearing.
	Use the clear ip o If you do not spec instances. Use the This command re This example sho	ospf statistics command to clear the event statistics from one or more OSPF instances cify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears statistics from all OSPF e show ip ospf statistics command to to view the statistics that you are clearing. quires the LAN Base Services license.
	Use the clear ip o If you do not spec instances. Use the This command re This example sho	Sumple statistics command to clear the event statistics from one or more OSPF instances cify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears statistics from all OSPF e show ip ospf statistics command to to view the statistics that you are clearing. quires the LAN Base Services license.

clear ip ospf traffic

To clear Open Shortest Path First (OSPF) traffic statistics, use the clear ip ospf traffic command.

clear ip ospf [instance-tag] traffic [interface] [vrf vrf-name]

Syntax Description	instance-tag	(Optional) Instance tag. Specify as an alphanumeric string of up to 20 characters.	
	interface	(Optional) Interface to clear traffic statistics for. Use the ? option to see the interface options.	
	vrf vrf-name	(Optional) Specifies the name of the OSPF virtual routing and forwarding (VRF) instance. The <i>vrf-name</i> argument can be any alphanumeric string of up to 32 characters, except "default" and "all".	
Command Default	None		
Command Modes	Any command mode		
Command History	Release	Modification	
	6.0(2)N1(1)	This command was introduced.	
Usage Guidelines	Use the clear ip ospf traffic command to clear the traffic statistics from one or more OSPF instances. If you do not specify the <i>instance-tag</i> argument, Cisco Nexus 6000 clears traffic statistics from all OSPF instances. Use the show ip ospf traffic statistics command to view the statistics that you are clearing.		
	This command requires the LAN Base Services license.		
Examples	This example shows how to clear OSPF traffic statistics for OSPF 100:		
	switch# clear ip ospf 100 traffic		
Related Commands	Command	Description	
	show ip ospf traffic statistics	Displays OSPF traffic statistics.	

clear ip traffic

To clear IP traffic information, use the **clear ip traffic** command.

clear ip traffic

Syntax Description	This command has no arguments or keywords.		
Command Default	None		
Command Modes	Any command mod	e	
Command History	Release 6.0(2)N1(1)	Modification This command was introduced.	
Examples	This example shows how to clear the IP traffic information: switch(config)# clear ip traffic		
Related Commands	Command	Description	

Related Commands	Command	Description
	show ip traffic	Displays IP traffic information.