

Cisco IOS Release Notes for Cisco EnergyWise, EnergyWise Version 2.7

October 15, 2012

If your switch is stacking-capable (for example, a Catalyst 3750-X, 3750-E, or 3750), the term *switch* refers to both a standalone switch and a switch stack unless otherwise noted.

These release notes include important information about Cisco EnergyWise Version 2.7 and any limitations, restrictions, and documentation updates that apply to Cisco devices running EnergyWise. To verify that these release notes are correct for your switch, see the "Supported Devices" section on page 2.

For information about a specific Cisco device running Cisco EnergyWise Version 2.7, see the release notes for the Cisco IOS software running on your device. To verify that these release notes are correct for your switch, use the **show version** privileged EXEC command.

For the list of EnergyWise Version 2.7 documentation, see the "Related Documentation" section on page 12.



Voice over IP (VoIP) service and the emergency calling service do not function if power fails or is disrupted. After power is restored, you might have to reset or reconfigure equipment to regain access to VoIP and the emergency calling service. In the USA, this emergency number is 911. You need to be aware of the emergency number in your country.

For information about this warning, see the "Importance Notice" appendix in the *Cisco EnergyWise IOS Configuration Guide, EnergyWise Version* 2.7 on Cisco.com.



Contents

- Supported Devices, page 2
- Compatibility Matrixes, page 8
- New Features, page 9
- Limitations and Restrictions, page 11
- Open Caveats, page 11
- Related Documentation, page 12
- Obtaining Documentation and Support on the Cisco Developer Network, page 12
- Obtaining Documentation, Support, and Security Guidelines, page 12

Supported Devices

To display the EnergyWise version and the Cisco IOS software running on the domain member, use the **show energywise version** and **show version** privileged EXEC command-line interface (CLI) commands. For information additional information about these commands, see the *Cisco EnergyWise IOS Configuration Guide* on Cisco.com.

To see the EnergyWise version, you can also use the energywise_utl_getVersion() function or go to the toolkit on the Cisco Developer Network: http://developer.cisco.com/web/esdk/home.



Note

Prior development of the Cisco EnergyWise feature set has been noted and distinguished through a series of EnergyWise phases. For these Release Notes and for all future EnergyWise documentation, feature set development will be noted and distinguished through EnergyWise versions. For current reference, EnergyWise Phase 2 is EnergyWise Version 2.6 and EnergyWise Phase 2.5 is EnergyWise Version 2.7.

The following tables list the EnergyWise supported switches, supervisors, Ethernet modules, IP phones, and other devices and their Cisco IOS software and EnergyWise versions:

- Cisco Catalyst 6500 series switches (supervisors and modules)—Table 1 on page 3
- Cisco Catalyst 4500 series switches and supervisors—Table 2 on page 4
- Cisco Catalyst 3700 and 3500 switches—Table 3 on page 4
- Cisco Catalyst 2900 switches—Table 4 on page 5
- Cisco Unified IP Phones—Table 5 on page 7
- Cisco Router and Management Systems—Table 6 on page 8



For additional information about compatibility between domain members and endpoints, see Compatibility Matrixes, page 8.

Table 1 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco Catalyst 6500 series switches (supervisors and modules):

Product SKU	Recommende	ed Version	First V	ersion
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
VS-S2T-10G	15.0(1)SY1	2.7	15.0(1)SY1	2.6
VS-S720-10G	15.0(1)SY1	2.7	15.0(1)SY1	2.6
WS-6148-GE-45AF	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148-GE-TX	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148-RJ21	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148-RJ21V	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148-RJ45	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148-RJ45V	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148A-GE-TX	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148A-RJ45	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6148V-GE-TX	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6248-RJ45	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6248-TEL	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6248A-TEL	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6348-RJ21	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6348-RJ21V	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-6348-RJ45V	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-SUP720-3BXL	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6148A-GE-45AF	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6148E-GE-45AT	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6148X2-45-AF	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6148X2-RJ-45	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6196-21-AF	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6196-RJ-21	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6548-GE-TX	12.2(33)SXJ	2.7	12.2(33)SXI4	2
WS-X6548V-GE-TX	12.2(33)SXJ	2.7	12.2(33)SXI4	2

Table 1 Supported EnergyWise Devices - Catalyst 6500

Table 2 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco Catalyst 4500 series switches and supervisors:

Product SKU or Device Name	Recommended Version		First Version	
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
Catalyst 4500 series switches Sup 7E	IOS-XE 3.3.0SG	2.7	3.1(0)XO	2.5
Catalyst 4500 series switches Sup 7LE	IOS-XE 3.3.0SG	2.7	3.1(0)XO	2.5
Catalyst 4500 series switches Sup 6E	Classical IOS 15.1.(1)SG.	2.7	12.2(52)SG	2
Catalyst 4500 series switches Sup 6LE	Classical IOS 15.1.(1)SG.	2.7	12.2(52)SG	2

Table 2 Supported EnergyWise Devices-Catalyst 4500

Table 3 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco Catalyst 3700 and 3500 switches:

Product SKU or Device Name	Recommende	d Version	First Ve	rsion
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
Catalyst 3560v2 series switches	15.0.1-SE2	2.7	12.2(53)SE2	2
Catalyst 3560-E series switches	15.0.1-SE2	2.7	12.2(50)SE	1
Catalyst 3560-C series switches	12.2(55)EX3	2.7	12.2(55)EX	2
Catalyst 3560-X series switches	15.0.1-SE2	2.7	12.2(53)SE2	2
Catalyst 3750-X series switches	15.0.1-SE2	2.7	12.2(53)SE2	2
Catalyst 3750v2 series switches	15.0.1-SE2	2.7	12.2(53)SE2	2
3560-8P	15.0.1-SE2	2.7	12.55SE	2.5
3560C-8PC-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
3560C-12PC-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
3560CG-8PC-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
3560CG-8TC-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
3560CPD-8PT-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
3560G-24P	15.0.1-SE2	2.7	12.55SE	2.5
3560G-24T	15.0.1-SE2	2.7	12.55SE	2.5
3750G-24TS-1U	15.0.1-SE2	2.7	12.55SE	2.5
3750G-48PS	15.0.1-SE2	2.7	12.55SE	2.5
3750v2-24FS 100FX	15.0.1-SE2	2.7	12.2(58)SE1	2.5
3750V2-24PS	15.0.1-SE2	2.7	12.55SE	2.5

Table 3 Supported EnergyWise Devices- Catalyst 3700 and 3500

Product SKU or Device Name	Recommended Version		First Ve	rsion
3750V2-24TS	15.0.1-SE2	2.7	12.55SE	2.5
3750V2-48P	15.0.1-SE2	2.7	12.55SE	2.5
3750V2-48T	15.0.1-SE2	2.7	12.55SE	2.5
3750G-48TS	15.0.1-SE2	2.7	12.55SE	2.5

Table 3 Supported EnergyWise Devices- Catalyst 3700 and 3500 (continued)

Table 4 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco Catalyst 2900 switches:

Product SKU or Device Name	Recommende	d Version	First Ve	ersion
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
Catalyst 2960 series switches running the LAN base or the LAN lite image	15.0.1-SE2	2.7	12.2(50)SE	1
Catalyst 2960-C series switches	12.2(55)EX3	2.7	12.2(55)EX	2
Catalyst 2960-S series switches	15.0.1-SE2	2.7	12.2(53)SE2	2
2960-8TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-8TC-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-24LC-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-24LT-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-24PC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-24PC-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-24TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-24-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-24TC-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-24TT-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-48PST-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-48PST-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-48TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-48TC-S	15.0.1-SE2	2.7	12.55SE	2.5
2960-48TT-L	15.0.1-SE2	2.7	12.55SE	2.5
2960-48TT-S	15.0.1-SE2	2.7	12.55SE	2.5
2960C-8PC-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960C-8TC-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960C-8TC-S	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960C-12PC-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5

Table 4 Supported EnergyWise Devices - Catalyst 2900

Product SKU or Device Name	Recommend	ed Version	First Ver	sion
2960CG-8TC-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960CPD-8PT-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960CPD-8TT-L	12.2(55)EX3	2.7	12.2(55)EX3	2.5
2960G-24TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960G-48TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960G-8TC-L	15.0.1-SE2	2.7	12.55SE	2.5
2960PD-8TT-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-24PD-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-24PS-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-24TD-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-24TS-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48FPD-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48FPS-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48LPD-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48LPS-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48TD-L	15.0.1-SE2	2.7	12.55SE	2.5
2960S-48TS-L	15.0.1-SE2	2.7	12.55SE	2.5
WS-C2918-24TC-C	12.2(58)SE1	2.5	12.2(58)SE1	2.5
WS-C2918-24TT-C	12.2(58)SE1	2.5	12.2(58)SE1	2.5
WS-C2918-48TC-C	12.2(58)SE1	2.5	12.2(58)SE1	2.5
WS-C2918-48TT-C	12.2(58)SE1	2.5	12.2(58)SE1	2.5

Table 4 Supported EnergyWise Devices - Catalyst 2900 (continued)

Table 5 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco Unified IP phones:



The Cisco Unified IP phones listed below require Cisco Unified Communications Manager (formerly Cisco Unified CallManager), 8.5(1).

Product SKU	Recommended V	ersion	First Versio	n
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
CP-6901	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-6911	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-6921	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-6941	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-6945	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-6961	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-7911G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7931G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7941G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7941G-GE	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7942G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7945G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7961G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7961G-GE	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-7962G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7965G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7970G	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-7971G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-7975G	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-8941	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-8945	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-8961	9.2(1) (SCCP and SIP)	2.5	9.2(1) (SCCP and SIP)	2
CP-9951	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2
CP-9971	9.2(1) (SCCP)	2.5	9.2(1) (SCCP)	2

Table 5 Supported EnergyWise Devices-Cisco Unified IP Phones

Table 6 displays the first and recommended Cisco IOS software and EnergyWise versions for the Cisco routers and management systems

Product SKU	Recommended V	Recommended Version		
	IOS Version	EnergyWise Version	IOS Version	EnergyWise Version
Cisco Integrated Services Router Generation 2	15.0(1)M2	2	15.0(1)M2	2
(ISR G2), including Cisco 3900, 2900, and 1900 ISRs				
LMS-4.0	4.0	2	4.0	2
LMS-4.1	4.1	2.5	4.1	2.5

 Table 6
 Supported EnergyWise Devices/Systems - Cisco Routers and Management Systems

Compatibility Matrixes

Verify that the EnergyWise specification of the domain member is compatible with the other domain members, the management station, and the connected endpoints.

Use the **show energywise version** privileged EXEC command to display the Cisco IOS release, the Cisco EnergyWise specification, and the toolkit version:

```
DomainMember# show energywise version
EnergyWise is Enabled
IOS Version: 12.2(58)SE
EnergyWise Specification: (rel2_7)1.2
```

In this example

- Cisco IOS release is Cisco IOS Release 12.2(58)SE.
- Cisco EnergyWise specification is rel2_7.
- Toolkit version is 1.2.

Table 7 Compatibility Matrix for Cisco IOS Release 12.2SE

Cisco IOS Release	EnergyWise Version	Cisco EnergyWise Specification	Compatible EnergyWise Specification	Compatible Toolkit Version
12.2(50)SE	0.6	0.6.n	—	—
12.2(52)SE	2	rel2 ¹	rel2_25	_
12.2(53)SE	2.2	rel2_25	rel2 rel2_5 rel2_6 rel2_7	
12.2(53)SE1	2.5	rel2_5	re12_25 re12_6 re12_7	

Table 7	Compatibility Matrix for Cisco IOS Release 12.2SE (continued)

Cisco IOS Release	EnergyWise Version	Cisco EnergyWise Specification	Compatible EnergyWise Specification	Compatible Toolkit Version
12.2(53)SE2	2.5	rel2_5	rel2_5 rel2_6 rel2_7	_
12.2(55)SE 12.2(55)EX	2.6	rel2_6	rel2_25 rel2_5 rel2_7	_
12.2(58)SE	2.7	rel2_7	rel2_25 rel2_5 rel2_6	1.2

1. Cisco EnergyWise Specification rel2 is not compatible with Cisco EnergyWise Specification rel2_5 or Cisco EnergyWise Specification rel2_6.

Table 8 Compatibility Matrix for Cisco IOS Release 12.2SX

Cisco IOS Release	EnergyWise Version		Compatible EnergyWise Specification	Compatible Toolkit Version
12.2(33)SXI4	2	rel2 ¹	rel2_25	_
12.2(33)SXJ	2.6	rel2_6	rel2_25	_

1. Cisco EnergyWise Specification rel2 is not compatible with Cisco EnergyWise Specification rel2_5 or Cisco EnergyWise Specification rel2_6.

Table 9 Compatibility Matrix for Cisco IOS Release 15SG

Cisco IOS Release	EnergyWise Version	Cisco EnergyWise Specification	Compatible EnergyWise Specification	Compatible Toolkit Version
15.0(2)SG/3.2(0) SG	2.6	rel2_6	rel2_25 rel2_5 rel2_7	
15.1(1)SG/3.3(0) SG	2.7	rel2_7	rel2_25 rel2_5 rel2_6	1.2

New Features

- Enhanced output for the **show energywise children** privileged EXEC command for Catalyst 6500 switches running Cisco IOS Release 15.1(1)SY and EnergyWise Version 2.7. The output displays all the line cards in the system as separate EnergyWise entities. For more information, see Appendix B of the software configuration guide.
- An EnergyWise query to analyze and display domain information.
- Wake on LAN (WoL) to remotely power on and off a WoL-capable PC.
- The clear energywise endpoints [all | cached] privileged EXEC command to remove either operational or nonoperational (cached) EnergyWise endpoints.

- EnergyWise plug and play to enable endpoint discovery without domain configuration.
- EnergyWise return-to-caller to let domain members forward responses directly to the management station without the responses passing through another domain member.
- When you use the EnergyWise endpoint software development kit (SDK) version 1.2 or the management application programming interface (API) version 1.2, we recommend that Catalyst 3750-X, 3750-E, 3750v2, 3750, 3560-X, 3560-E, 3560, 2960-S, and 2960 switches run Cisco IOS Release 12.2(58)SE.
- Cisco Unified IP Phone 6900, 7900, 8900, and 9900 series support the Cisco EnergyWise Power Save Plus mode. You can use this feature to configure the phone to sleep (power down) and wake (power up). To use this feature, your system should include an EnergyWise controller, such as a Cisco switch with the EnergyWise feature enabled. The following switches support this feature:
 - Catalyst 6500 series switches running Cisco IOS Release 12.2(33)SXJ.
 - Catalyst 4500 series switches running Cisco IOS Releases 3.2.0 SG and 15.0(2)SG.
 - Catalyst 2960, 2960-S, 3560, 3560-E, 3560-X, 3750, 3750-E, and 3750-X series switches running Cisco IOS Release 12.2(58)SE1.

For more information about the Cisco EnergyWise Power Save Plus mode, see the following resources:

- Cisco Unified IP Phone 6900 series: http://www.cisco.com/en/US/docs/voice_ip_comm/cuipph/6921_6941_6961/firmware/9_2_1/ english/release/notes/6921_921_sip.html#wp199915 http://www.cisco.com/en/US/products/ps10326/tsd_products_support_series_home.html
- Cisco Unified IP Phone 7900 series: http://www.cisco.com/en/US/partner/docs/voice_ip_comm/cuipph/firmware/9_2_1/english/rel ease/notes/7900_921.html#wp50106 http://www.cisco.com/en/US/partner/products/hw/phones/ps379/tsd_products_support_series_ home.html
- Cisco Unified IP Phone 8900 series: http://www.cisco.com/en/US/docs/voice_ip_comm/cuipph/9971_9951_8961/firmware/9_2_1/r elease_notes/9900_8900_921.html#wp219153 http://www.cisco.com/en/US/products/ps10451/tsd_products_support_series_home.html
- Cisco Unified IP Phone 9900 series: http://www.cisco.com/en/US/docs/voice_ip_comm/cuipph/9971_9951_8961/firmware/9_2_1/r elease_notes/9900_8900_921.html#wp219153 http://www.cisco.com/en/US/products/ps10453/tsd_products_support_series_home.html
- Cisco EnergyWise Return on Investment with Cisco Unified IP Phones Whitepaper: http://www.cisco.com/en/US/prod/collateral/voicesw/ps6788/phones/ps10326/solution_overvi ew_c22-589129.html

Limitations and Restrictions

Note

Prior development of the Cisco EnergyWise feature set has been noted and distinguished through a series of EnergyWise phases. For these Release Notes and for all future EnergyWise documentation, feature set development will be noted and distinguished through EnergyWise versions. For current reference, EnergyWise Phase 2 is EnergyWise Version 2.6 and EnergyWise Phase 2.5 is EnergyWise Version 2.7.

You should review this section before you begin working with EnergyWise. These are known limitations that will not be fixed, and there is not always a workaround.

- EnergyWise Version 2.7 (formerly Phase 2.5) is not backward-compatible EnergyWise Phase 1.
- EnergyWise Version 2.6 (formerly Phase 2) is not backward-compatible with EnergyWise Phase 1.
- EnergyWise Version 2.6 (formerly Phase 2) does not support IPv6.
- The Cisco EnergyWise software development kit (SDK) or the management application programming interface (MAPI) Version 1.2, also referred to as the EnergyWise toolkit Version 1.2, is compatible with Cisco EnergyWise Specification rel2_7. We recommend that you use the SDK or MAPI Specification rel2_7 with domain members running Cisco IOS Release 12.2(58)SE. The toolkit Version 1.2 is not backward-compatible with Cisco EnergyWise Specification rel2_5 or Cisco EnergyWise Specification rel2_6 (CSCtn68547).

Open Caveats

CSCti19539

If you use the **energywise** interface configuration command, not all EnergyWise interface configurations revert to the default values.

Use one of these workarounds:

- Set each one of the interface configuration parameters to the default value.
- Use the **no energywise domain** global configuration command to remove the EnergyWise configuration. When you configure a new EnergyWise domain, default values are assigned to all parameters.

L

Related Documentation

For information about configuring Cisco devices, see the *Cisco EnergyWise Configuration Guide* on Cisco.com.

For Cisco Integrated Service Routers Generation 2 (ISR G2), see the *Configuring Cisco EnergyWise Feature for Branch Routers*:

http://www.cisco.com/en/US/docs/routers/access/1900/software/configuration/guide/enrgyz_artg.html

To locate and download MIBs for a specific Cisco product and release, use the Cisco MIB Locator: http://cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml.

These partner documents provide information about the management API and endpoint SDK and are available on the Cisco Developer Network at http://developer.cisco.com/web/esdk/home.

- Cisco EnergyWise Documentation Roadmap
- Cisco EnergyWise Partner Development Guide
- Cisco EnergyWise Programmer Reference Guide for the End-Point SDK
- Cisco EnergyWise Programmer Reference Guide for the Management API
- Release Notes for Cisco EnergyWise, EnergyWise Phase 2.7

Obtaining Documentation and Support on the Cisco Developer Network

Cisco EnergyWise development partners can access the EnergyWise documents, API and SDK software code, and Cisco IOS software by joining the Cisco Developer Network: http://developer.cisco.com/web/esdk/home.

You need a support contract and license to access EnergyWise resources on the Cisco Developer Network and on TAC. The business development manager who registered your licence must set up your Cisco.com account with the appropriate access privileges.

The forum, wiki, and other resources on the Cisco Developer Network provide a self-help knowledge base and community for EnergyWise application developers and programmers. You can get additional support by opening a case in the TAC Service Request Tool: http://tools.cisco.com/ServiceRequestTool/create/launch.do.

Obtaining Documentation, Support, and Security Guidelines

For information on obtaining documentation, submitting a service request, and gathering additional information, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation:

http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html

Subscribe to the *What's New in Cisco Product Documentation* as a Really Simple Syndication (RSS) feed, and set content to be delivered directly to your desktop by a reader application. The RSS feeds are a free service, and Cisco supports RSS version 2.0.

This document is to be used in conjunction with the documents listed in the "Related Documentation" section.

Cisco and the Cisco Logo are trademarks of Cisco Systems, Inc. and/or its affiliates in the U.S. and other countries. A listing of Cisco's trademarks can be found at www.cisco.com/go/trademarks. Third party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1005R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

© 2011 Cisco Systems, Inc. All rights reserved.