



## Accessing Cisco UCS MIB Files

---

This chapter includes the following sections:

- [Download Cisco UCS MIB Files](#), page 1
- [Downloading Cisco UCS MIB Files from Cisco.com](#), page 1
- [Enabling Passive FTP in Internet Explorer](#), page 2
- [Downloading MIB Files with Passive FTP](#), page 2

## Download Cisco UCS MIB Files

You can download Cisco UCS MIB files in either of the following ways:

- Using the file save feature in your browser from the list on [cisco.com](http://cisco.com).
- Using passive FTP to access the MIB files on <ftp://ftp.cisco.com>.

## Downloading Cisco UCS MIB Files from Cisco.com

### Procedure

---

- Step 1** Open a browser and go to the following URL:  
<http://www.cisco.com/public/sw-center/netmgmt/cmtk/mibs.shtml>  
The SNMP support page provides a list of supported MIBs for each UCS release.
- Step 2** From the Unified Computing drop-down list, choose **UCS Manager**.  
This displays the UCS Networking (NX-OS) MIBs for Cisco UCS Manager for software Release 1.0 and later, and the Cisco UCS Manager MIBs supported by software Release 1.4 and later.
- Step 3** Select and save each MIB that you want to download from the list.
-

## Enabling Passive FTP in Internet Explorer

If you are using Internet Explorer, you might need to enable passive FTP.

### Procedure

- 
- Step 1** Open Internet Explorer.
  - Step 2** Choose **Tools > Internet Options**.
  - Step 3** Click the **Advanced** tab.
  - Step 4** Scroll down and check the **Use Passive FTP** (for firewall and DSL modem compatibility) check box.
  - Step 5** Click **OK** to save changes.
- 

## Downloading MIB Files with Passive FTP



### Note

This procedure assumes that your passive FTP utility has UNIX-like commands.

### Before You Begin

Before you download the MIB files, ensure the following:

- You know the names of the MIB files you want to download. For the location of the appropriate MIB support list, see [Cisco UCS MIB Support List Locations](#).
- Passive FTP is enabled on your browser.

### Procedure

- 
- Step 1** Access <ftp://ftp.cisco.com/pub/mibs/supportlists/ucs/ucs-manager-supportlist.html> using passive FTP.
  - Step 2** Log in with your cisco.com username and password, or as anonymous, with your e-mail address.
  - Step 3** Enter `cd /pub/mibs/ucs-mibs/` to change directories.
  - Step 4** Use the **get** command to copy the desired files to your local system.
  - Step 5** Use the **quit** command to exit passive FTP.
-