


CISCO DESKTOP COLLABORATION EXPERIENCE DX650 QUICK START



1	Shutter switch	9	Hold
2	Camera	10	Conference
3	Phone screen	11	Stop Video
4	Keypad	12	Speakerphone
5	microSD slot	13	Mute
6	Lock	14	Headset
7	Transfer	15	Volume
8	End Call	16	Handset with MWI

12	3 4 5	6	7	89

1	Security slot	6	Computer port
2	microUSB port	7	Auxiliary port
3	Line in/out	8	USB port
4	Power	9	HDMI
5	Network port		

Set up your phone

You are prompted to set up your phone the first time that you turn the phone on. You will not be prompted for some or all of these steps if your administrator has set your phone up for you.

- 1. Select a wireless network, enter your credentials, and tap Connect.
- 2. Enter your TFTP server settings and tap Continue. If updated firmware is available, it is installed and your phone restarts.
- **3.** On the Welcome screen, select **Tap here to begin**, and follow the prompts for self-provisioning, application setup, and selection of a PIN or Password.

Accessories

You can attach accessories to your phone, such as an external monitor through the HDMI port, a keyboard and mouse through the USB ports, and a headset or mobile phone through Bluetooth.

Unlock screen

To unlock the screen, enter your PIN or password and press #.

Log in with Cisco Extension Mobility

- 1. Tap Sign In As New User.
- **2**. Enter your user ID and PIN.
- 3. If you are prompted, select a device profile.

Gestures

0	8 - 4
Gesture	Action
Tap	Use your fingertip to press the touchscreen.
Tap and hold	Tap and wait two seconds.
Swipe	Tap and move.
Drag	Tap and hold, then move.
Double tap	Tap twice in quick succession.
Pinch open	Tap with two fingers, then move your fingers apart.
Pinch close	Tap with two fingers, then move your fingers together.

Navigation

lcon	Action
¢	Tap Back to go to the previous page or application, or to dismiss the onscreen keyboard.
	Tap Home to view the home screen.
r_	Tap Phone to launch the phone application.
	Tap Recents to view the list of recently used applications.

Widgets

Use widgets to access phone features and other applications on your home screen.

To add a widget to the home screen:

- **1**. Tap 🛄.
- 2. Tap Widgets.
- **3**. Tap and hold a widget.
- **4.** Drag the widget to an empty space on the home screen.

Phone application

Place call

To a contact



2. Drag a contact from the contact list to the call.

With speakerphone



2. Dial the number.

With headset

Press and enter a number. If is lit, press New Call and enter a number.

End call


With speakerphone



With headset



Keep another call on same line



Americas Headquarters Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-NETS (6387) Fax: 408 527-0883



Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2013 Cisco Systems, Inc. All rights reserved.

Printed in the USA on recycled paper containing 10% postconsumer waster

Answer call

To answer a call, lift the handset. Or, tap Answer.

With speakerphone

Press or tap Answer.

With headset

Press . Or, if . is lit, press Answer.

During an active call

Tap Answer.

Divert call to Voicemail

Tap Divert.

Mute

To mute a call:

1. Press 🞑

2. To unmute a call, press again.

Stop Video

To stop your video transmission:

- 1. Press
- 2. To resume video transmission, press again.

Hold call

To place a call on hold:

- 1. Make sure that the call you want to put on hold is highlighted.
- 2. Press

Multiple calls

An active call goes on hold whenever you pick up an incoming or held call, start a new call, or initiate a transfer or a conference.

Call Forward

To forward your calls:

- **1**. Tap ***
- 2. Tap 🏝 and enter a target phone number.
- 3. To cancel Call Forward, tap 👗 again.

Transfer

To transfer a call:

- 1. Press 🗠
- **2**. Enter the target number.
- 3. To complete the transfer, press again or press End to cancel.
- **4.** If your phone has on-hook transfer enabled, complete the transfer by hanging up.

Conference

To create a conference call:

- 1. From a call, press
- 2. Enter the phone number of the participant.
- **3**. Wait for the call to connect.
- **4.** To add the participant to your call, press **ease** again.
- 5. To add more participants, repeat Steps 1 to 4.

Add contact to conference

- 1. Tap 🖪.
- **2**. Drag a contact from the contact list to the call.
- **3**. Repeat to add additional participants.

Do Not Disturb

To turn Do Not Disturb on and off:

- 1. Tap •••
- 2. Tap Do Not Disturb to turn it on.
- 3. To turn it off, tap Do Not Disturb again.

Call history

To view your call history, tap Recents.

Voicemail

The Message Waiting Indicator (MWI) light on the handset indicates that you have a new voice message. To view your voice messages:

- 1. Tap Recents.
- 2. Tap Messages.

Play voice message

Tap Play.

Intelligent Proximity

Pair a mobile phone to use the mobile line through your DX650. Once the mobile phone is paired, you can place and receive calls on the mobile line from your DX650.

- **1**. Put the mobile phone in discoverable mode.
- 2. On your DX650, open the Settings application and tap Bluetooth.
- **3.** Select the mobile phone from the available devices list to pair.
- **4.** Verify the passkey on the mobile phone and the DX650.
- When you are prompted, choose to make your mobile phone contacts and call history available on your Cisco DX650.

Other applications

Contacts

To view your contacts, tap Contacts.

Quick Contact Badge

Tap an avatar for one of your local contacts. If you see an arrow in the bottom corner, the Quick Contact Badge is available.

Tap an email address, phone number, or IM address to start a conversation in that medium.

Calendar

To schedule and keep track of your events, use the Calendar application.

Add event

To add an event to your calendar, tap + Event.

Email

To send and receive email from multiple accounts, use the Email application.

Send email message

To send an email message, tap + New Message.

Jabber IM

To chat with your contacts and to update your status, use the Chat application.

Start conversation

To start a conversation, tap a contact name.

Cisco WebEx

To participate in WebEx meetings, use the WebEx application.

During a WebEx meeting, participants can:

- Join the audio conference
- View shared presentations
- See and chat with other participants

Settings

To edit and customize phone settings and applications, or to view the *User Guide* and other documentation, use the Settings application.