





Cisco IP Phone Messenger for Cisco Unified Presence Server Release 1.0(1)

INCLUDING LICENSE AND WARRANTY

Corporate Headquarters

Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA http://www.cisco.com Tel: 408 526-4000 800 553-NETS (6387) Fax: 408 526-4100



Character Keys

Key	Characters
1	1!!':;^
2	a b c 2 A B C
3	d e f 3 D E F
4	g h i 4 G H I
5	j k l 5 J K L
6	m n o 6 M N O
7	pqrs7PQRS
8	t u v 8 T U V
9	w x y z 9 W X Y Z
0	0 = , <space></space>
*	.@ ~ * & %
#	# + \$ <euro symbol=""> \pounds \</euro>





Cisco IP Phone Messenger for Cisco Unified Presence Server Release 1.0(1)

Common Tasks Softkey Definitions Contact Availability Icons Character Keys

Common Tasks

Log into the IP Phone Messenger to perform most of these tasks. Tasks requiring the User Options web pages are specified.

Note: Refer to the "Logging into Cisco IP Phone Messenger" section on page 2 if you need assistance logging into Cisco IP Phone Messenger.

Display a Contact	Choose Contacts.
list	
Display a contact's devices and status	Choose Contacts . Choose a contact and press Details .
Add contacts by user name	Choose Contacts and press Add .
Add contacts by extension	Choose Contacts and press AddByExt .
Add sender of active message to contact list	Choose Contacts and press AddCtct.
Limit contacts shown	Choose Contacts and press Filter .
Call a contact	Choose Contacts . Choose a contact, press Details , and press Dial .
Delete a contact	Choose Contacts . Choose a contact, press Details , and press Delete .
Display a contact's availability	Choose Contacts.
Display a contact's availability by device	Choose Contacts . Choose a contact, press Details .
Set your availability status	Choose Settings > Status.



Cisco, Cisco IOS, Cisco Systems, and the Cisco Systems logo are registered trademarks of Cisco Systems, Inc. or its affiliates in the United States and certain other countries. All other brands, names, or trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0501R)

© 2006 Cisco Systems, Inc. All rights reserved.

OL-9369-01

Managing Your Messages		
View recent messages	Choose Messages.	
Delete one message	Choose Messages . Scroll to a message, press Details , and press Delete .	
Delete all messages	Choose Messages . Press DelAll .	
Send a default message	Choose Messages . Press Msg , choose a default messages, and press Send .	
Send a custom message	Choose Messages . Press Msg and press Compose . Enter message and press Send .	
Reply to a message	Press Reply or Msg.	
Call a message sender	Choose Messages, press Details, and press Dial.	
Create custom default response	Access User Options > Response Messages.	
Send broadcast message	Access User Options > Broadcast Messages.	
Review broadcast messages	Choose Messages or System Messages.	
Require a PIN for accessing messages and settings	Choose Settings > PIN Protection.	
Set an audible alert to indicate when message arrives	Choose Settings > Audible Alert > On.	

Softkey Definitions

Add	Add a contact using a user ID
AddByExt	Add a contact using an extension
AddCtct	Add sender of active message to your Contact List
Cancel	Cancel an action or exit a screen without applying changes
Compose	Create a custom text message
DelAll	Delete all messages
Delete	Remove a message or contact
Details	Display additional information about message or contact
Dial	Call a message sender
Exit	Return to the previous screen
Filter	Limit contacts displayed in list
Logout	Log out of the application
more	Display additional softkeys
Msg	Display the Messages menu
No	Reject the request
OK	Acknowledge prompt
PgDn	Show more messages and contacts
PgUp	Show previous messages and contacts
Reply	Reply to a received message
Retry	Re-attempt text or number entry
Select	Select an item on the screen
Send	Send a custom message
Submit	Confirm entered text
Yes	Confirm the request
<<	Delete entered characters

Contact Availability Icons

Contact List		
$\overline{}$	Available	
0	Unavailable	
	Busy	
?	Unknown status	
1	Do not disturb	
1	Out of the office	
\sim	Vacation	
Т	Available via instant message	
E .	Available via phone	
e	Currently on the phone	
Contact	Details	
Т	Available via instant message	
Т	Unavailable via instant message	
E.	Available via phone	
4	Unavailable, currently on phone	
	Available via camera phone	
D(Unavailable via camera phone	



Contents

User Guide 1 Quick Reference 1 Common Tasks 1 Character Keys 1 Softkey Definitions 2 Contact Availability Icons 2

Getting Started 1

About Cisco IP Phone Messenger 1 Using Cisco IP Phone Messenger on the Phone or Web 1 Logging into Cisco IP Phone Messenger 2 Logging Out of Cisco IP Phone Messenger 4 Entering Text on the Phone 5

Organizing Your Contacts 6

Adding Contacts 6 Deleting Contacts 8 Displaying Your Contact List 9 Displaying a Contact's Availability 11

Managing Your Messages 12

Displaying Messages 12 Handling Incoming Messages 14 Sending Messages 15 Deleting Messages 18 Creating New Personal Response Messages 19

Troubleshooting 21

Resolving Error Messages 21 Frequently Asked Questions 23

Index 25



Getting Started

Cisco IP Phone Messenger enables your Cisco Unified IP phone to receive, send, and reply to instant messages. It is only available on your phone if your company is using the Cisco Unified Presence Server, and your system administrator has enabled Cisco IP Phone Messenger. Check with your system administrator if you are not sure if Cisco IP Phone Messenger is available for you.

About Cisco IP Phone Messenger

Cisco IP Phone Messenger lets you manage your instant messages and contacts on a Cisco Unified IP Phone in the following ways:

Task	For More Information
Create a contact list.	Organizing Your Contacts, page 6
Send instant messages to coworkers on your contact list.	Sending Messages, page 15
Set notification preferences for incoming messages	Handling Incoming Messages, page 14
View the availability status of coworkers who are using Cisco IP Phone Messenger.	Displaying a Contact's Availability, page 11
Customize access and display of your messages	Displaying Messages, page 12

Using Cisco IP Phone Messenger on the Phone or Web

The Cisco IP Phone Messenger service consists of two task management components: a service application on your Cisco Unified IP Phone and User Options web pages. You can perform some tasks using either component, but other tasks require you to use just one of these.

User Options Web Pages

Some tasks require that you use the Cisco IP Phone Messenger User Options web pages, which you can access using a a supported web browser on your computer. You use the User Options web pages to customize settings, create personal response messages, organize contacts, and send broadcast messages.

Supported web browsers include:

- Microsoft Internet Explorer version 6.0 or later
- Netscape Navigator version 7.1 or later

The Cisco IP Phone Messenger User Options web pages are located on a different server than the Cisco CallManager User Options web pages. Your system administrator should provide you with the information you need.

Phone Service

The Cisco IP Phone Messenger service is an application that runs on your Cisco Unified IP Phone. (A service is a special type of XML-based application that can run on Cisco Unified IP Phones.) You use this service to communicate with your co-workers using text-based instant messaging on your Cisco Unified IP Phone. Your system administrator must first assign this service to the phone before you can access it.

This service might be assigned to a phone associated with your user ID (assigned) or not associated (unassigned). This assignment impacts the information required to access Cisco IP Phone Messenger on your phone.

Logging into Cisco IP Phone Messenger

You can log into Cisco IP Phone Messenger using either component, as follows:

- User Options web pages—You must use your computer and a web browser to log into the User Options web pages.
- Phone service—Depending on whether the service is assigned or unassigned, you must log into the service by entering your PIN and in some cases your user ID as follows:
 - Assigned—your user ID is not required to log in on a phone assigned to you. Typically, you cannot log into Cisco IP Phone Messenger on a phone assigned to another user: your PIN will not work with someone else's user ID. The exception is if the phone has Extension Mobility configured on it, in which case you can log into Extension Mobility and then log into Cisco IP Phone Messenger.
 - Unassigned—your user ID is required to log in. Any user with a valid user ID and PIN configured to use Cisco IP Phone Messenger can log in on an unassigned phone.



If you are already logged into Cisco IP Phone Messenger on another phone, a multi-login alert will display when you attempt to log in. You must respond to this alert before you can log in. Choose **Yes** to log out of other phones automatically or **No** to remain logged into other phones. When you are logged into multiple phones simultaneously, all instant messages appear on each phone, which might be a privacy concern.

Logging into	On the Phone	From the User Options Web Pages
User Options web pages	Not applicable	1. Open a supported web browser on your computer.
		2. Enter the web page provided by your system administrator, similar to: http://< <i>CUPS server</i> >/ccmuser.
		3. Enter your user name and password, provided by your system administrator.
		4. Choose the User Options menu, and the following options display:
		– Preferences
		 Contact List
		- Response Messages
		 Broadcast Messages
Phone service	 Using your Cisco Unified IP Phone, press > Phone Messenger (or similar name). 	Not applicable
	Note Your system administrator can customize the name of this service, so confirm the name used on your phone.	
	 Enter your PIN and user ID (if requested). See "Entering Text on the Phone" section on page 5 for tips on entering text. Press << to delete characters or Exit to cancel. 	
	3. Press Submit.	
	The Cisco IP Phone Messenger main menu displays with the following options:	
	– Messages	
	– Contacts	
	– Settings	
	- System Messages	

Logging Out of Cisco IP Phone Messenger

You can log out of Cisco IP Phone Messenger at any time:

- User Options web pages—You can log out of the User Options web pages at any time. However, for security purposes, you will be automatically logged out of the User Options web pages after about 30 minutes of inactivity.
- Phone Service—You can log out of Cisco IP Phone Messenger on your phone at any time, but you can also set a maximum session time, for increased security. Depending on whether your user ID is associated with the phone on which you are using Cisco IP Phone Messenger, you might need to enter your PIN when logging out:
 - Assigned—PIN is required to log out
 - Unassigned—PIN is not required to log out, but you can require an unassigned phone to log you out automatically, for increased security

Logging out of	On the Phone	From the User Options Web Pages
User Options web pages	Not applicable	 Choose User Options > Preferences. Click Logout. Click OK to accept or click Cancel.
Phone service	 From the main menu of Cisco IP Phone Messenger, press Logout. If requested, enter PIN. See "Entering Text on the Phone" section on page 5 for tips on entering text. Press << to delete characters or Exit to cancel. Press Yes to log out or No or Cancel to return to the main menu. 	Not applicable
Unassigned phone automatically	 Press > Phone Messenger > Settings. Use the Navigation button to scroll to Session Timer and press Select. Enter a value from 1-9999 (in minutes). Press Submit. 	 Choose User Options > Preferences. Enter a value from 1-9999 (in minutes) in the Session Timer field. Click Save.

Entering Text on the Phone

When you compose an instant message or enter a user ID to add a contact to your contact list, use the Cisco Unified IP Phone dial pad to enter letters, numbers, and other characters. You press a key once to select the first available character on the key, twice to select the second available character, three times to select the third available character, and so on.

For example, you press the 2 key once for *a*, twice for *b*, three time for *c*, and four times for 2.

Key	Characters
1	1!!':;^
2	a b c 2 A B C
3	d e f 3 D E F
4	g h i 4 G H I
5	j k l 5 J K L
6	m n o 6 M N O
7	pqrs7PQRS
8	t u v 8 T U V
9	w x y z 9 W X Y Z
0	0 = , <space></space>
*	.@ ~ * & %
#	# + \$ <euro symbol=""> \pounds \</euro>

You can organize your Contact list using either the Cisco IP Phone Messenger service application on your Cisco Unified IP Phone or the User Options web pages on the web. However, some tasks are not available in both places. For those tasks, you must use either the phone or web, as indicated.

Adding Contacts

You can add a contact to the Contact list using either the Cisco IP Phone Messenger service or User Options web pages, depending on how you identify the contact.

Before You Begin

- Your system administrator sets the number of contacts you can have on your list, with a maximum of 100. Contact your system administrator to verify the contact limit on your phone.
- You can only add contacts to your contact list if they have a valid user ID or extension number within your organization.
- The UserID, Nickname, and Extension fields accept a maximum of 255 characters.
- If you enter an invalid or duplicate user ID, an error message displays. See "Resolving Error Messages" section on page 21.
- Refer to "Entering Text on the Phone" section on page 5 for tips on entering contact names

Add contact by	On the Phone	From the User Options Web Pages
User ID	You can add a contact by entering the user ID, which must correspond to a valid user ID within your organization. 1. Choose S > Phone Messenger	 Choose User Options > Contact List. Click Add New. Enter the following information:
	 > Contacts. 2. Press Add. 3. Enter the following information: UserID—user ID of the contact. This field is required. 	 UserID—user ID of the contact. This field is required. Nickname—enter any text. This field is optional and will display in the Contact list.
	 Nickname—enter any text. This field is optional and will display in the Contact list. 	4. Click Display on Phone to display the contact on the Contact list on the phone.
	4. Press Submit.	5. Click Save.

Add contact by	On the Phone	From the User Options Web Pages
Extension number	You can add a contact by entering the user ID, which must correspond to a valid user ID within your organization.	Not applicable
	1. Choose > Phone Messenger > Contacts.	
	2. Press AddbyExt (you might have to press more to display this softkey).	
	3 . Enter the following information:	
	 Extension—extension number of the contact. This field is required. 	
	 Nickname—enter any text. This field is optional and will display in the Contact list. 	
	4. Press Submit.	
Message sender	Coworkers who are not on your contact list can send you instant messages, and you can easily add them to your contact list.	Not applicable
	1. Choose > Phone Messenger > Messages.	
	2. Use the Navigation buttons to scroll to and highlight a message.	
	3. Press Details (you might have to press more to display this softkey).	
	4. Press AddCtct (you might have to press more to display this softkey).	
	5 . Enter the following information:	
	 Extension—extension number of the contact. This field is required. 	
	 Nickname—enter any text. This field is optional and will display in the Contact list. 	
	6. Press Submit.	

Deleting Contacts

Delete	On the Phone	From the User Options Web Pages
All contacts	Not applicable	You can delete your entire contact list at once.
		1. Choose User Options > Contact List.
		2. Click Select All.
		3 . Click Delete Selected.
		4. Click OK to accept or Cancel.
Individual contacts	You can remove contacts from your contact list one at a time.	You can remove contacts from your contact list one at a time.
	1. Choose > Phone Messenger > Contacts.	1. Choose User Options > Contact List.
	2. Use the Navigation button to scroll to select a contact.	2. Click the checkbox next to the contact's name you want to delete.
	3. Press Details.	3. Click Delete Selected.
	4. Press Delete to delete the contact.	4. Click OK to accept or Cancel.
	5. Press OK to return to the Contact list.	

You can delete all contacts or individual contacts depending whether you are using the phone or web.

Displaying Your Contact List

Once you have added some contacts to your contact list, you can view a list of them using Cisco IP Phone Messenger on your phone or web.

Display	On the Phone	From the User Options Web Pages
All contacts	You can display all contacts on your contact list.	You can display all contacts on your contact list.
	 Choose > Phone Messenger > Contacts. Press Filter. The prompt field displays the current setting. Use the Navigation button to scroll to select Show all Contacts. Press Select and press Exit to return to the Contact list. Press PgDn to display additional contacts, and press PgUp to display 	 Choose User Options > Preferences. Choose Display all contacts from the Contact Filtering field. Click Save. Choose User Options > Contact List. In Search Options, choose User ID "is not empty" to display all contacts matching the filter criteria. Click Find.
Available contacts	previous contacts. You can display only those contacts who	You can display only those contacts who
	 are currently available. Choose > Phone Messenger > Contacts. Press Filter. The prompt field displays the current setting. Use the Navigation button to scroll to select Show available Contacts. Press Select and press Exit to return to the Contact list. Press PgDn to display additional contacts, and press PgUp to display previous contacts. 	 are currently available. Choose User Options > Preferences. Choose Display online contacts only from the Contact Filtering field. Click Save. Choose User Options > Contact List. In Search Options, choose User ID "is not empty" to display all contacts matching the filter criteria. Click Find.

Display	On the Phone	From the User Options Web Pages
Frequently updated contact	You can modify how frequently you want the contact list to update.	You can modify how frequently you want the contact list to update.
list	 Choose > Phone Messenger > Settings. Use the Navigation buttons to scroll to select Refresh Interval and press Select. Enter a value (in seconds) from 7-3600 seconds. Choose a lower value to update the contact list frequently. Press Submit. 	 Choose User Options > Preferences. Enter a value (in seconds) from 7-3600 in the Phone Display Refresh Interval field. Choose a lower value to update the contact list frequently. Click Save.

Displaying a Contact's Availability

You can quickly determine a contact's availability. See the "Contact Availability Icons" section on page 2 for an explanation of the availability icons that display.

P	
Tip	

When viewing availability, if your contact is available via phone, you can press Dial to call the contact rather than send an instant message..

Display	On the Phone	From the User Options Web Pages
Overall	You can display the overall status.	Not applicable
availability	Choose > Phone Messenger > Contacts.	
	Status is calculated by the server and displays with these caveats:	
	• T displays when at least one device is available.	
	• displays if the phone is available, but Cisco IP Phone Messenger is not.	
Availability by device	You can display how many devices each contact has available, their capability (instant messages, phone, video), and the status for each device.	Not applicable
	1. Choose > Phone Messenger > Contacts.	
	2 . Use the Navigation button to scroll to select a contact.	
	3. Press Details.	

Cisco IP Phone Messenger enables you to send and receive instant messages from users who have a valid user ID or extension number within your organization.

Displaying Messages

Display	On the Phone	From the User Options Web Pages
Incoming messages	If you are logged in and available, incoming messages are automatically displayed on your phone screen.	Not applicable
All received messages	You can review received (un-deleted) messages. Your system administrator determines the maximum number of received messages that Cisco IP Phone Messenger stores for you.	Not applicable
	1. Choose > Phone Messenger > Messages.	
	2. Press PgDn to display additional contacts, and press PgUp to display previous contacts.	
Message details	You can use this option to see more information about the message (such as the complete message and timestamp), to delete individual messages, and to add the message sender to your contact list.	Not applicable
	1. Choose > Phone Messenger > Messages.	
	2. Use the Navigation button to scroll to select a message.	
	3. Press Details.	

You can customize how you want to display messages on Cisco IP Phone Messenger:

Display	On the Phone	From the User Options Web Pages
Protected messages	For increased privacy, you can require your PIN to be entered to access your message list.	For increased privacy, you can require your PIN to be entered to access your message list.
	1. Choose > Phone Messenger > Settings.	1. Choose User Options > Preferences.
	2. Use the Navigation buttons to scroll to select PIN protection.	2. From the PIN Protected field, choose:
	3. Scroll to select:On—to require a PIN to view	- On—to require a PIN to view messages
	messages Off—to disable PIN protection 	 Off—to disable PIN protection
	4. Press Select.	3. Click Save.
	5. Choose > Phone Messenger > Messages.	4. Choose S > Phone Messenger > Messages.
	6. Enter your PIN and press Submit.	5 . Enter your PIN and press Submit .
System messages	Your system administrator can send you special broadcast messages, which you can review at a later time.	Not applicable
	1. Choose System Messages.	
	2. Use the Navigation buttons to scroll to select a specific message.	
	3. Press Details to display additional information.	

Handling Incoming Messages

You can receive incoming messages from co-workers in your organization, even if they are not on your contact list. You can control how you are notified about incoming messages and if you are available to receive them:

When receiving a message	On the Phone	From the User Options Web Pages
Play an alert	 You can set your phone to ring when an incoming message arrives. 1. Choose > Phone Messenger > Settings. 2. Use the Navigation buttons to scroll to select Audible Alert. 3. Scroll to select: On—to enable the alert Off—to disable the alert 4. Press Select. 	 You can set your phone to ring when an incoming message arrives. 1. Choose User Options > Preferences. 2. From the Audible Notification field, choose: On—to enable the alert Off—to disable the alert 3. Click Save.
Display message waiting indicator	The message waiting indicator on the handset flashes during an incoming message. You cannot configure this.	Not applicable
Prevent users from sending you messages	 You can make yourself unavailable so that other users cannot send you messages. 1. Choose > Phone Messenger > Settings. 2. Use the Navigation buttons to scroll to select Status. 3. Choose any status except: Available Busy but Interruptible 4. Press Select. 	Not applicable

Sending Messages

You can send messages to any co-workers in your organization who are on your Contact list or respond to received messages from others who are not yet on your Contact list.



When sending or replying to a message, if your contact is available via phone, you can press **Dial** to call the contact rather than send an instant message.

Before You Begin

Refer to "Entering Text on the Phone" section on page 5 for tips on entering text.

Send a	On the Phone	From the User Options Web Pages
New message (pre-set)	 You can send a message from a list of pre-set (or "canned) responses. You can have a maximum of 25 pre-set messages. Your system administrator owns 10 of these, and you can create an additional 15 personal response messages. See the Creating New Personal Response Messages, page 19. 1. Choose > Phone Messager > Contact. 	Not applicable
	2. Use the Navigation button to scroll to select a contact.	
	3. Press Details.	
	4. Press Msg.	
	5. Scroll to select one of the pre-set messages, and press Select.	
	6. Press OK or Exit.	

Send a	On the Phone	From the User Options Web Pages
New message (custom)	Your can use the phone's dial pad to enter a custom message.	Not applicable
	1. Choose > Phone Messenger > Contact.	
	2. Use the Navigation button to scroll to select a contact.	
	3. Press Details.	
	4. Press Msg.	
	5. Press Compose and enter the text message.	
	6. Enter Press Send or Exit.	
	7. Press OK or Exit.	
Reply	You can respond to a received	Not applicable
	message.	
	1. Choose S > Phone Messenger > Messages.	
	2. Use the Navigation button to scroll to select a received message.	
	3. Press Details.	
	4. Press Reply (if sender is on your Contact list) or Msg.	
	5. Press:	
	- Select—See New message (pre-set), page 15	
	- Compose—See New message (custom), page 16	

Send a	On the Phone	From the User Options Web Pages
Broadcast message	Not applicable	You can send a short message (maximum of 150 characters) to some or all contacts on your contact list.
		1. Choose User Options > Broadcast Messages
		2. In Search Options, enter your search criteria.
		For example, to send a broadcast message to your entire contact list, choose User ID "is not empty" to display all contacts.
		3. Click the checkbox next to the contact's name you want to send the message. Or, click Select All .
		4. Enter your message in the Msg field.
		5. Click Broadcast.
		6. Click OK to accept or Cancel.

Deleting Messages

You can delete messages that you no longer need. However, once you delete an instant message, there is no stored copy that you can use to restore the instant message. Make sure you do not need an instant message before you delete it.

Delete	On the Phone	From the User Options Web Pages
All messages	You can delete all received messages at the same time.	Not applicable
	1. Choose > Phone Messenger > Messages.	
	2. Press Del All (you might have to press more to display this softkey).	
	3. Press Yes to delete all messages or No to cancel.	
Individual	You can delete a specific message.	Not applicable
messages	1. Choose > Phone Messenger > Messages.	
	2. Use the Navigation button to scroll to select a message.	
	3. Press Details.	
	4. Press Delete to delete the message.	
	5. Press OK to return to the messages.	

Creating New Personal Response Messages

You can create new pre-set personal response messages. These messages save you time in typing a custom text message each time you send a message. You can create up to 15 of these messages, and your system administrator can create an additional 10. Your personal response messages always display after the ones created by your system administrator.

То	On the Phone	From the User Options Web Pages
Create new personal response message	Not applicable	You can create up to 15 new personal response messages using a maximum of 255 characters each.
		1. Choose User Options > Response Messages.
		2. Click Add New.
		3. Enter your message in the Response Message field.
		4. Click Save.
Display available personal response	You can display your currently available personal response messages.	You can display your currently available personal response messages.
messages	1. Choose > Phone Messenger > Contact.	1. Choose User Options > Response Messages.
	2. Use the Navigation button to scroll to select a contact.	All available messages appear.
	3. Press Details.	
	4. Press Msg.	
	The available personal messages appear at the bottom of the list.	
Re-order personal response messages	Not applicable	You can rearrange the order in which your personal response messages appear on the list.
		1. Choose User Options > Response Messages.
		2. Click Up and Down to rearrange the order of your personal messages.

То	On the Phone	From the User Options Web Pages
Delete all personal response	Not applicable	You can delete all personal messages at once.
messages		 Choose User Options > Response Messages.
		2. Click Select All.
		3. Click Delete Selected.
		4. Click OK to accept or Cancel.
Delete a specific personal response	Not applicable	You can delete personal messages one at a time.
message		 Choose User Options > Response Messages.
		2. Click the checkbox next to the contact's name you want to delete.
		3. Click Delete Selected.
		4. Click OK to accept or Cancel.

Troubleshooting

If you experience an error message or other difficulty when using Cisco IP Phone Messenger, these tips can assist you.

Resolving Error Messages

Cisco IP Phone Messenger will display error messages if it encounters a problem. Refer to the following table for tips on understanding and resolving these errors.

Error Title	Error Text	Explanation
Send message failure	Your message to <user id=""> could not be delivered. User may have logged off.</user>	The contact likely logged off just as you were sending the message. Check the contact's availability and re-send the message.
		See the "Displaying a Contact's Availability" section on page 11.
Presence status failure	Due to unavailability of presence services at this time, presence status may not be working correctly. Please notify your system administrator.	Contact your system administrator.
System configuration error	You were trying to access IP Phone Messenger service from a device not provisioned on Cisco CallManager server. Please work with your system administrator to get this device configured.	Contact your system administrator.
Add Contact Failure	No UserID matches the extension you entered. Press OK to enter another extension, or Cancel to contact list.	You must enter a valid extension number of a contact within your organization.
Adding Contact Failed	Invalid, duplicate, or non-existing contact name.	You must enter a valid extension number of a contact within your organization.

Error Title	Error Text	Explanation
Host Not Found		Cisco IP Phone Messenger is not available. Contact your system administrator for assistance.
Invalid Message Identifier	You were trying to retrieve a message that had been deleted from the EPAS server. Press Ok or Exit to return to IP Phone Messenger main menu.	If you are logged into more than one phone at a time, Multi-login state. Was deleting messages on one phone and attempting to view one on another.
Invalid PIN	Your PIN is invalid. Press Retry to re-enter your PIN.	Your phone has PIN protection enabled, but you have not entered the correct PIN. If you need additional assistance, contact your system administrator to verify your PIN.
Login Failed	Login failed. Your UserID or PIN was invalid. Press Retry to re-enter your UserID and PIN.	Cisco IP Phone Messenger requires that you enter your PIN when logging in. You have entered an incorrect PIN. If you need additional assistance, contact your system administrator to verify your PIN.
Login Failed	Login failed due to server error. Please contact your system administrator.	When using an unassigned phone, Cisco IP Phone Messenger requires that you enter your user ID when logging in. You have entered an incorrect user ID. See the "Entering Text on the Phone" section on page 5 to verify that you are entering your user ID correctly. If you need additional assistance, contact your system administrator to verify your user ID.

Error Title	Error Text	Explanation
Multi-login Alert	You are currently logged in from other phones. Press Yes to log out of other phones (recommended for security reasons). Press No to leave other phones logged in. Incoming messages will show on all your other logged-in phones in addition to this phone. Press OK to go to the main menu.	You are attempting to log into Cisco IP Phone Messenger on more than one phone. Although this is supported, you should be aware that all instant messages will appear on each phone. This might be a privacy concern.
Refresh Interval	Invalid refresh interval. Enter a number between 7 and 3600.	You cannot enter an interval outside the given range (in seconds).
Session Timer	Invalid session timer. Enter a number between 1 and 9999.	You cannot enter an interval outside the given range (in minutes).

Frequently Asked Questions

The following table provides you with answers to some common questions about Cisco IP Phone Messenger.

Question	Explanation
Cisco IP Phone Messenger Phone Service	
Why is the Msg softkey unavailable when I am attempting to send a message to someone on my contact list?	The contact has selected a status that does not allow any incoming messages. Check the contact's status. See the "Displaying a Contact's Availability" section on page 11.
Why is the Dial softkey unavailable when I am attempting to call someone on my contact list?	The contact has selected a status that does not allow any incoming calls. Check the contact's status. See the "Displaying a Contact's Availability" section on page 11.
Why do I have to enter my PIN every time I try to access the Messages list or Settings?	You have enabled PIN Protection. See the "Protected messages" section on page 13.

Question	Explanation
Cisco IP Phone Messenger User Options	1
I am accessing the User Options web page, but I do not see any of the options mentioned.	Verify that you are accessing the User Options web pages for Cisco IP Phone Messenger, not Cisco Unified CallManager. Contact your system administrator for assistance and see the "Logging into Cisco IP Phone Messenger" section on page 2.
Why do I have to re-enter my user name and password?	The User Options web pages automatically log you out after a period of inactivity for increased security.



Index

Symbols

<<, softkey usage> **3**, **4**

A

Add, softkey definition 2 usage 6 AddByExt, softkey definition 2 usage 7 AddCtct, softkey definition 2 usage 7 alert tone 14 assigned phone description 2 logging into 2 audible alert 14 audible notification 14

В

broadcast messages 17

С

call contact 11, 15 Cancel, softkey definition 2 usage 4 Cisco IP Phone Messenger, description 1 Compose, softkey definition 2 usage 16 Contact filtering, field 9 Contact List, menu 6 contacts adding 6 availability of 11 deleting 8 displaying 9 Contacts, menu 6

D

DelAll, softkey definition 2 Delete Selected, usage 8 Delete, softkey definition 2 usage 8, 18 Details, softkey definition 2 usage 11, 12 Dial, softkey definition 2 usage 11, 15 Display all contacts, description 9

E

error messages 21 Exit, softkey definition 2 usage 3, 4 extension number 7

F

Filter, softkey definition 2 usage 9

L

logging in Phone Service User Options using PIN using user ID logging out Phone Service **2**, PIN required **2**, User Options **2**, Logout, softkey definition **2** usage **4**

Μ

menu items Phone Service User Options message waiting indicator messages displaying types of more, softkey Msg, softkey definition usage **15** multi-login warning

Ν

nickname 6, 7 No, softkey definition 2 usage 2, 4

0

OK, softkey definition **2**

Ρ

personal response messages 19

PgDn, softkey	Add 2
definition 2	AddByExt 2
usage 12	AddCtct 2
PgUp, softkey	Cancel 2
definition 2	Compos 2
usage 12	DelAll 2
Phone Service	Delete 2
description 2	Details 2
logging in 3	Dial 2
logging out 2, 4	Exit 2
menu items 3	Filter 2
PIN	Logout 2
required for logging in 2	more 2
required for logging out 2, 4	Msg 2
PIN protection 13	No 2
	OK 2
D	PgDn 2

R

Reply, softkey definition **2** usage **16** Retry, softkey definition **2**

S

Select, softkey definition **2** usage **4** Send, softkey definition **2** Show all Contacts, description **9** softkey

g. PgUp 2 Reply 2 Retry 2 Select 2 Send 2 Submit 2 Yes 2 status of contacts 11 setting 14 Submit, softkey definition **2** usage 4 system messages 13

U

unassigned phone description 2 logging into 2 User Options description 1 logging in 3 logging out 2, 4 menu items 3 UserID 6

W

web browsers, supported 1

Y

Yes, softkey definition 2 usage 2, 4 **EFT - CISCO CONFIDENTIAL**



Corporate Headquarters Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA www.cisco.com Tel: 408 526-4000 800 553-NETS (6387) Fax: 408 526-4100 European Headquarters Cisco Systems International BV Haarlerbergpark Haarlerbergweg 13-19 1101 CH Amsterdam The Netherlands www-europe.cisco.com Tel: 31 0 20 357 1000 Fax: 31 0 20 357 1100 Americas Headquarters Cisco Systems, Inc. 170 West Tasman Drive San Jose, CA 95134-1706 USA www.cisco.com Tel: 408 526-7660 Fax: 408 527-0883 Asia Pacific Headquarters Cisco Systems, Inc. 168 Robinson Road #28-01 Capital Tower Singapore 068912 www.cisco.com Tel: +65 6317 7777 Fax: +65 6317 7799

Cisco Systems has more than 200 offices in the following countries. Addresses, phone numbers, and fax numbers are listed on the Cisco Website at www.cisco.com/go/offices

Argentina • Australia • Australia • Australia • Belgium • Brazil • Bulgaria • Canada • Chile • China PRC • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Dubai, UAE Finland • France • Germany • Greece • Hong Kong SAR • Hungary • India • Indonesia • Ireland • Israel • Italy • Japan • Korea • Luxembourg • Malaysia • Mexico The Netherlands • New Zealand • Norway • Peru • Philippines • Poland • Portugal • Puerto Rico • Romania • Russia • Saudi Arabia • Scotland • Singapore Slovakia • Slovenia • South Africa • Spain • Sweden • Switzerland • Taiwan • Thailand • Turkey • Ukraine • United Kingdom • United States • Venezuela • Vienam • Zimbabwe

CCSP, CCVP, the Cisco Square Bridge logo, Follow Me Browsing, and StackWise are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn, and iQuick Study are service marks of Cisco Systems, Inc.; and Access Registrar, Aironet, ASIST, BPX, Catalyst, CCDA, CCDP, CCIE, CCPA, CCNA, CCNP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Empowering the Internet Generation, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, FormShare, GigaDrive, GigaZitack, HomeLink, Internet Quotient, IOS, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, LightStream, Linksys, MeetingPlace, MGX, the Networkers logo, Networking Academy, Network Registrar, *Packet*, PIX, Post-Routing, Pre-Routing, ProConnect, RateMUX, ScriptShare, SlideCast, SMARTnet, StratAiven Plus, TeleRouter, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

All other trademarks mentioned in this document or Website are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (0502R)

© 2006 Cisco Systems, Inc. All rights reserved.

Printed in the USA on recycled paper containing 10% postconsumer waste.

OL-9369-01 DOC-78xxxx=