



# Supported IPv6 Commands

The Release 15.1(1)MR for the Cisco MWR 2941 router provides support for a subset of the IPv6 features supported in Cisco IOS Release 15.1(1)S.

Table 1 summarizes the supported commands in Release 15.1(1)MR. For more information about these commands, refer to the [Cisco IOS IPv6 Command Reference](#).



**Note** The Cisco MWR 2941 does not support other IPv6 commands listed in the Cisco IOS IPv6 Command Reference.

**Table 1** *Supported IPv6 Commands*

<b>aaa new-model</b>	<b>ipv6 ospf hello-interval</b>	<b>show clock</b>
<b>clear cef table</b>	<b>ipv6 ospf mtu-ignore</b>	<b>show ipv6 cef</b>
<b>clear ipv6 dhcp binding</b>	<b>ipv6 ospf name-lookup</b>	<b>show ipv6 cef adjacency</b>
<b>clear ipv6 dhcp client</b>	<b>ipv6 ospf neighbor</b>	<b>show ipv6 cef non-recursive</b>
<b>clear ipv6 dhcp conflict</b>	<b>ipv6 ospf network</b>	<b>show ipv6 cef platform</b>
<b>clear ipv6 dhcp relay binding</b>	<b>ipv6 ospf priority</b>	<b>show ipv6 cef summary</b>
<b>clear ipv6 mtu</b>	<b>ipv6 ospf retransmit-interval</b>	<b>show ipv6 cef switching statistics</b>
<b>clear ipv6 neighbors</b>	<b>ipv6 ospf transmit-delay</b>	<b>show ipv6 cef traffic prefix-length</b>
<b>clear ipv6 route</b>	<b>ipv6 prefix-list</b>	<b>show ipv6 cef tree</b>
<b>clear ipv6 traffic</b>	<b>ipv6 prefix-list sequence-number</b>	<b>show ipv6 cef vrf</b>
<b>crypto key generate rsa</b>	<b>ipv6 route</b>	<b>show ipv6 dhcp</b>
<b>debug ipv6 cef drop</b>	<b>ipv6 route static bfd</b>	<b>show ipv6 dhcp binding</b>
<b>debug ipv6 cef events</b>	<b>ipv6 router ospf</b>	<b>show ipv6 dhcp conflict</b>
<b>debug ipv6 cef receive</b>	<b>ipv6 source-route</b>	<b>show ipv6 dhcp database</b>
<b>debug ipv6 cef table</b>	<b>ipv6 unicast-routing</b>	<b>show ipv6 dhcp interface</b>
<b>debug ipv6 dhcp</b>	<b>match dscp</b>	<b>show ipv6 dhcp pool</b>
<b>debug ipv6 dhcp database</b>	<b>match protocol</b>	<b>show ipv6 interface</b>
<b>debug ipv6 icmp</b>	<b>match protocol (zone)</b>	<b>show ipv6 mtu</b>
<b>debug ipv6 nd</b>	<b>maximum-paths (IPv6)</b>	<b>show ipv6 neighbors</b>
<b>debug ipv6 packet</b>	<b>mpls ldp router-id</b>	<b>show ipv6 ospf</b>

Text Part Number: OL-23890-01

**Table 1** Supported IPv6 Commands

<b>hostname</b>	<b>neighbor activate</b>	<b>show ipv6 ospf border-routers</b>
<b>ip address</b>	<b>neighbor ebgp-multipath</b>	<b>show ipv6 ospf database</b>
<b>ip unnumbered</b>	<b>neighbor remote-as</b>	<b>show ipv6 ospf event</b>
<b>ipv6 address</b>	<b>neighbor send-community</b>	<b>show ipv6 ospf flood-list</b>
<b>ipv6 address anycast</b>	<b>neighbor send-label</b>	<b>show ipv6 ospf graceful-restart</b>
<b>ipv6 address autoconfig</b>	<b>neighbor translate-update</b>	<b>show ipv6 ospf interface</b>
<b>ipv6 address eui-64</b>	<b>neighbor update-source</b>	<b>show ipv6 ospf neighbor</b>
<b>ipv6 address link-local</b>	<b>network (BGP and multiprotocol BGP)</b>	<b>show ipv6 ospf request-list</b>
<b>ipv6 cef</b>	<b>network (IPv6)</b>	<b>show ipv6 ospf retransmission-list</b>
<b>ipv6 cef accounting</b>	<b>passive-interface (IPv6)</b>	<b>show ipv6 ospf statistics</b>
<b>ipv6 dhcp database</b>	<b>ping</b>	<b>show ipv6 ospf summary-prefix</b>
<b>ipv6 dhcp pool</b>	<b>ping ipv6</b>	<b>show ipv6 ospf timers rate-limit</b>
<b>ipv6 dhcp server</b>	<b>ping vrf</b>	<b>show ipv6 ospf traffic</b>
<b>ipv6 enable</b>	<b>prefix-delegation</b>	<b>show ipv6 ospf virtual-links</b>
<b>ipv6 hop-limit</b>	<b>prefix-delegation pool</b>	<b>show ipv6 protocols</b>
<b>ipv6 host</b>	<b>set dscp</b>	<b>show ipv6 route</b>
<b>ipv6 icmp error-interval</b>	<b>show adjacency</b>	<b>show ipv6 route summary</b>
<b>ipv6 mtu</b>	<b>show bfd neighbors</b>	<b>show ipv6 route vrf</b>
<b>ipv6 nd advertisement-interval</b>	<b>show bfd summary</b>	<b>show ipv6 routers</b>
<b>ipv6 nd cache interface-limit (global)</b>	<b>show bgp ipv6 unicast</b>	<b>show ipv6 static</b>
<b>ipv6 nd cache interface-limit (interface)</b>	<b>show bgp ipv6 community</b>	<b>show ipv6 traffic</b>
<b>ipv6 nd dad attempts</b>	<b>show bgp ipv6 community-list</b>	<b>show isis database</b>
<b>ipv6 nd dad time</b>	<b>show bgp ipv6 unicast dampening dampened-paths</b>	<b>show isis ipv6 rib</b>
<b>ipv6 nd managed-config-flag</b>	<b>show bgp ipv6 filter-list</b>	<b>show isis spf-log</b>
<b>ipv6 nd ns-interval</b>	<b>show bgp ipv6 flap-statistics</b>	<b>show isis topology</b>
<b>ipv6 nd other-config-flag</b>	<b>show bgp ipv6 inconsistent-as</b>	<b>show key chain</b>
<b>ipv6 nd prefix</b>	<b>show bgp ipv6 labels</b>	<b>show mpls forwarding-table</b>
<b>ipv6 nd ra interval</b>	<b>show bgp ipv6 neighbors</b>	<b>ssh</b>
<b>ipv6 nd ra lifetime</b>	<b>show bgp ipv6 paths</b>	<b>summary-prefix (IPv6 OSPF)</b>
<b>ipv6 nd ra suppress</b>	<b>show bgp ipv6 peer-group</b>	<b>synchronization (IPv6)</b>
<b>ipv6 nd reachable-time</b>	<b>show bgp ipv6 prefix-list</b>	<b>telnet</b>
<b>ipv6 nd router-preference</b>	<b>show bgp ipv6 quote-regexp</b>	<b>telnet</b>
<b>ipv6 neighbor</b>	<b>show bgp ipv6 regexp</b>	<b>timers lsa arrival</b>
<b>ipv6 ospf area</b>	<b>show bgp ipv6 route-map</b>	<b>timers pacing flood (IPv6)</b>
<b>ipv6 ospf authentication</b>	<b>show bgp ipv6 summary</b>	<b>timers pacing lsa-group (IPv6)</b>

**Table 1** Supported IPv6 Commands

<b>ipv6 ospf bfd</b>	<b>show bgp vpng6 unicast</b>	<b>timers pacing retransmission (IPv6)</b>
<b>ipv6 ospf cost</b>	<b>show cdp entry</b>	<b>timers spf (IPv6)</b>
<b>ipv6 ospf database-filter all out</b>	<b>show cdp neighbors</b>	<b>timers throttle lsa</b>
<b>ipv6 ospf dead-interval</b>	<b>show cef</b>	<b>timers throttle spf</b>
<b>ipv6 ospf demand-circuit</b>	<b>show cef interface</b>	<b>traceroute</b>
<b>ipv6 ospf encryption</b>	<b>show cef table</b>	<b>vrf definition</b>
<b>ipv6 ospf flood-reduction</b>	<b>show clns neighbors</b>	<b>vrf forwarding</b>

For information about IPv6 support, see the *Release Notes for Cisco MWR 2941-DC Mobile Wireless Edge Router, Release 15.1(1)MR* and the *Cisco MWR 2941 Router Command Reference, Release 15.1(1)MR*.

